

53-1002428-04  
16 May 2012



# Unified IP

---

## MIB Reference

**Supporting Multi-Service IronWare Release 05.3.00a and FastIron Release 07.4.00**

**BROCADE**

Copyright © 2011-2012 Brocade Communications Systems, Inc. All Rights Reserved.

Brocade, Brocade Assurance, the B-wing symbol, DCX, Fabric OS, MLX, SAN Health, VCS, and VDX are registered trademarks, and AnyIO, Brocade One, CloudPlex, Effortless Networking, ICX, NET Health, OpenScript, and The Effortless Network are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of their respective owners.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. shall have no liability or responsibility to any person or entity with respect to any loss, cost, liability, or damages arising from the information contained in this book or the computer programs that accompany it.

The product described by this document may contain "open source" software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

## Brocade Communications Systems, Incorporated

Corporate and Latin American Headquarters  
Brocade Communications Systems, Inc.  
130 Holger Way  
San Jose, CA 95134  
Tel: 1-408-333-8000  
Fax: 1-408-333-8101  
E-mail: [info@brocade.com](mailto:info@brocade.com)

Asia-Pacific Headquarters  
Brocade Communications Systems China HK, Ltd.  
No. 1 Guanghua Road  
Chao Yang District  
Units 2718 and 2818  
Beijing 100020, China  
Tel: +8610 6588 8888  
Fax: +8610 6588 9999  
E-mail: [china-info@brocade.com](mailto:china-info@brocade.com)

European Headquarters  
Brocade Communications Switzerland Sàrl  
Centre Swissair  
Tour B - 4ème étage  
29, Route de l'Aéroport  
Case Postale 105  
CH-1215 Genève 15  
Switzerland  
Tel: +41 22 799 5640  
Fax: +41 22 799 5641  
E-mail: [emea-info@brocade.com](mailto:emea-info@brocade.com)

Asia-Pacific Headquarters  
Brocade Communications Systems Co., Ltd. (Shenzhen WFOE)  
Citic Plaza  
No. 233 Tian He Road North  
Unit 1308 - 13th Floor  
Guangzhou, China  
Tel: +8620 3891 2000  
Fax: +8620 3891 2111  
E-mail: [china-info@brocade.com](mailto:china-info@brocade.com)

## Document History

Title	Publication number	Summary of changes	Date
Unified IP MIB Reference	53-1002223-01	New document.	June 2011
Unified IP MIB Reference	53-1002371-01	Included the support for MP-MR2 MIBs for the NetIron release 05.2.00b.	August 2011
Unified IP MIB Reference	53-1002391-01	Included the MIBs to support Brocade FCX and Brocade ICX 6610 of FastIron devices.	October 2011
Unified IP MIB Reference	53-1002428-01	Included the MIBs to support the NetIron release 05.3.00.	January 2012
Unified IP MIB Reference	53-1002428-02	Included the MIBs to support Brocade ICX 6430 and Brocade ICX 6450 devices.	February 2012

<b>Title</b>	<b>Publication number</b>	<b>Summary of changes</b>	<b>Date</b>
Unified IP MIB Reference	53-1002428-03	Released to support the patch release.	April 2012
Unified IP MIB Reference	53-1002428-04	Released to support the patch release.	May 2012



# Contents

---

## About This Document

Supported hardware and software .....	xxiii
Document conventions.....	xxiii
Text formatting .....	xxiv
Command syntax conventions .....	xxiv
Notes.....	xxiv
Trademark references.....	xxv
Getting technical help.....	xxv
Document feedback .....	xxv

## Chapter 1

### Overview of the Unified IP MIB

Introduction .....	1
Obtaining and installing the Unified IP MIBs.....	1
Downloading the MIB from the Technical Support website ....	1
Downloading the MIB from the Brocade FTP site .....	2
Importing Unified IP MIB into a UNIX environment .....	2
Reloading MIBs into a third-party NMS .....	2
Standard objects.....	2
Proprietary objects .....	3
SNMPv3 support.....	3

## Chapter 2

### Supported Standard MIBs

Supported on FastIron devices .....	6
Supported on NetIron devices .....	6
RFC compliance - management .....	7
IEEE standards.....	8
LLDP MIB support .....	8
LLDP\LLDP-MED MIB support .....	9
RFC 1493: Definitions of Managed Objects for Bridges .....	9
RFC 1643: Definitions of Managed Objects for Ethernet-like Interface Types .....	10
RFC 1757: Remote Network Monitoring Management Information Base.....	10
RFC 2096: IP Forwarding Table MIB .....	11
RFC 2233: The Interfaces Group MIB using SMIv2 .....	11

RFC 2515: Definitions of Managed Objects for ATM Management . . . . .	12
ATM interface configuration parameters table . . . . .	12
ATM interface transmission convergence sub-layer table. . . . .	12
AAL5 virtual channel connection performance statistics table . . . . .	12
RFC 2665: Definitions of Managed Objects for the Ethernet-like Interface Types . . . . .	13
RFC 2674: Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions . . . . .	13
RFC 2819: Remote Network Monitoring Management Information Base. . . . .	14
History control group . . . . .	14
Ethernet history group . . . . .	15
Alarm group . . . . .	15
Event group . . . . .	16
RFC 2863: The Interfaces Group MIB . . . . .	16
ifIndex . . . . .	16
ifType for interfaces . . . . .	17
Statistics for virtual routing interfaces on 8x10 modules. . . . .	18
Preserved SNMP statistics on interfaces. . . . .	19
RFC 2932: IPv4 Multicast Routing MIB. . . . .	21
IP multicast scalar . . . . .	22
ipMRouteTable (IP multicast route table). . . . .	22
ipMRouteNextHopTable (IP multicast route next hop table) . . . . .	23
ipMRouteInterfaceTable (IP multicast route interface table). . . . .	24
RFC 2933: Internet Group Management Protocol MIB . . . . .	25
Support on FastIron devices . . . . .	25
Support on other devices . . . . .	25
igmpInterfaceTable (IGMP interface table) . . . . .	26
igmpCacheTable (IGMP cache table) . . . . .	27
RFC 2934: Protocol Independent Multicast MIB for IPv4 . . . . .	27
Support on FastIron devices . . . . .	27
Support on other devices . . . . .	28
pimInterfaceTable (PIM interface table). . . . .	29
pimNeighborTable (PIM neighbor table). . . . .	29
pimIpMRouteTable (PIM IP multicast route table). . . . .	30
pimIpMRouteNextHopTable (PIM IP multicast route next hop table) . . . . .	30
pimRpTable (PIM RP table) . . . . .	31
pimRpSetTable (PIM RP set table) . . . . .	31
pimCandidateRPTTable (PIM candidate-RP table). . . . .	31
pimComponentTable (PIM component table) . . . . .	32
RFC 3176: InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched and Routed Networks. . . . .	32

RFC 3289: Management Information Base for the Differentiated Services Architecture . . . . .	33
diffServMultiFieldClfrTable . . . . .	33
RFC 3813: Multiprotocol Label Switching (MPLS) Label Switching Router (LSR) Management Information Base (MIB). . . . .	34
MPLS interface table objects . . . . .	35
MPLS in-segment table objects . . . . .	35
MPLS in-segment performance table objects . . . . .	35
MPLS out-segment table objects . . . . .	36
MPLS cross-connect table objects . . . . .	36
MPLS label stack scalar object. . . . .	37
RFC 3815: Definitions of Managed Objects for the Multiprotocol Label Switching (MPLS), Label Distribution Protocol (LDP). . . . .	37
mplsLdpLsr objects . . . . .	37
mplsLdpEntity objects . . . . .	37
mplsLdpEntity table. . . . .	37
mplsLdpEntityStats table . . . . .	39
mplsLdpSession objects . . . . .	39
mplsLdpPeer table. . . . .	39
mplsLdpSession table . . . . .	40
mplsLdpSessionStats table. . . . .	40
mplsLdpHelloAdjacency table . . . . .	40
mplsFec objects . . . . .	41
mplsFec table. . . . .	41
mplsLdpSessionPeerAddr table . . . . .	41
RFC 4022: Management Information Base for the Transmission Control Protocol (TCP) . . . . .	42
RFC 4087: IP Tunnel MIB . . . . .	42
tunnelIfTable. . . . .	42
tunnelInetConfigTable . . . . .	43
ifTable support . . . . .	43
ifXTable . . . . .	44
RFC 4113: Management Information Base for the User Datagram Protocol (UDP). . . . .	45
RFC 4273: Definitions of Managed Objects for BGP-4. . . . .	45
draft-ietf-idr-bgp4-mibv2-12 MIB . . . . .	46
BGP4v2 per-peer session management information . . . . .	47
BGP4v2 per-peer error management information. . . . .	49
BGP4v2 per-peer event times table . . . . .	50
BGP4v2 NLRI table . . . . .	50
RFC 4292: IP Forwarding Table MIB . . . . .	54
RFC 4293: Management Information Base for the Internet Protocol (IP). . . . .	55

RFC 4444: Management Information Base for Intermediate System to Intermediate System (IS-IS) . . . . .	56
Scalar isisSys objects . . . . .	56
Supported tables in RFC 4444 . . . . .	57
Notifications . . . . .	58
RFC 4807: IPsec Security Policy Database Configuration MIB . . . . .	59
spdLocalConfigObjects . . . . .	59
spdEndpointToGroupTable . . . . .	59
spdGroupContentsTable . . . . .	60
spdRuleDefinitionTable . . . . .	60
spdStaticFilters . . . . .	61
spdStaticActions . . . . .	61
IEEE8021-CFM-MIB . . . . .	62
dot1agCfmMdTable . . . . .	62
dot1agCfmMaNetTable . . . . .	63
dot1agCfmMaCompTable . . . . .	63
dot1agCfmMaMepListTable . . . . .	63
dot1agCfmMepTable . . . . .	64
dot1agCfmLtrTable . . . . .	66
dot1agCfmMepDbTable . . . . .	67
LLDP-MIB . . . . .	68
lldpPortConfigTable . . . . .	68
lldpConfigManAddrTable . . . . .	68
lldpstatistics . . . . .	69
lldpStatsTxPortTable . . . . .	69
lldpStatsRxPortTable . . . . .	69
lldpLocalSystemData . . . . .	69
lldpLocPortTable . . . . .	70
lldpLocManAddrTable . . . . .	70
lldpRemTable . . . . .	70
lldpRemManAddrTable . . . . .	71
lldpRemUnknownTLVTable . . . . .	71
lldpRemOrgDefInfoTable . . . . .	71
LLDP-EXT-DOT1-MIB . . . . .	72
lldpXdot1ConfigPortVlanTable . . . . .	72
lldpXdot1ConfigVlanNameTable . . . . .	72
lldpXdot1ConfigProtoVlanTable . . . . .	72
lldpXdot1ConfigProtocolTable . . . . .	73
lldpXdot1LocTable . . . . .	73
lldpXdot1LocProtoVlanTable . . . . .	73
lldpXdot1LocVlanNameTable . . . . .	73
lldpXdot1LocProtocolTable . . . . .	73
lldpXdot1RemTable . . . . .	74
lldpXdot1RemProtoVlanTable . . . . .	74
lldpXdot1RemVlanNameTable . . . . .	74
lldpXdot1RemProtocolTable . . . . .	74



	LLDP-EXT-DOT3-MIB .....	75
	IldpXdot3PortConfigTable .....	75
	IldpXdot3LocPortTable .....	75
	IldpXdot3LocPowerTable .....	76
	IldpXdot3LocLinkAggTable .....	76
	IldpXdot3LocMaxFrameSizeTable .....	76
	IldpXdot3RemPortTable .....	76
	IldpXdot3RemPowerTable .....	77
	IldpXdot3RemLinkAggTable .....	77
	IldpXdot3RemMaxFrameSizeTable .....	77
<b>Chapter 3</b>	<b>Registration MIB Definition</b>	
<b>Chapter 4</b>	<b>Agent MIB Definition</b>	
	General chassis information .....	109
	Fan status .....	110
	Flash card .....	115
	Power supply table .....	117
	Stacking power supply table .....	118
	Fan table .....	118
	Stacking fan table .....	119
	Stacking chassis unit information .....	119
<b>Chapter 5</b>	<b>Agent Groups</b>	
	Agent global group .....	121
	Image and configuration file download and upload .....	122
	Default gateway IP address .....	126
	Configuration notes .....	126
	Usage notes on CPU utilization and system CPU utility table .....	127
	Image version .....	129
	Agent board table .....	136
	Agent stacking board table .....	144
	Trap receiver table .....	147
	Boot sequence table .....	148
	SP boot sequence table .....	149
	Encoded octet strings table .....	150
<b>Chapter 6</b>	<b>Agent System Parameters</b>	
	Agent system parameters configuration table .....	153
	Configured module table .....	154
	Configuration module table for stacking .....	159

	Agent user access group .....	163
	Agent user account table .....	163
	Agent redundant group .....	164
	System CPU utilization table .....	165
	System process utilization table .....	166
	Hardware integrated central buffer manager counter table .....	167
<b>Chapter 7</b>	<b>Switch Group Configuration</b>	
	Switch group configuration .....	169
<b>Chapter 8</b>	<b>Switch Port Information Group</b>	
	Switch port information .....	177
<b>Chapter 9</b>	<b>Interface ID Registration Group</b>	
	Interface ID to ifIndex lookup table .....	191
	ifIndex to interface ID lookup table .....	192
	Interface ID2 to ifIndex lookup table .....	193
	ifIndex to interface ID2 lookup table .....	194
	ifIndex to optical parameters table .....	195
	Optical lane monitoring table .....	196
	Interface media information table .....	197
	Loopback interface configuration table .....	197
<b>Chapter 10</b>	<b>CAM Statistics</b>	
	IP CAM statistics table .....	199
	CAM statistics table .....	200
	CAM profile .....	202
	CAM usage for Layer 3 traffic .....	202
	CAM usage for Layer 2 traffic .....	203
	CAM usage session table .....	204
	CAM usage other table .....	205
<b>Chapter 11</b>	<b>System DRAM</b>	
	System DRAM information group .....	207
	System debug group .....	207
	System temperature table .....	209
	System temperature threshold table .....	209
	System stacking temperature table .....	210

	Software licensing. . . . .	210
	License information. . . . .	212
	Package upgrade operation . . . . .	212
	Package upgrade result table . . . . .	214
	Interface module auto-upgrade objects. . . . .	214
<b>Chapter 12</b>	<b>SNTP MIB Definition</b>	
	NTP general group. . . . .	217
	NTP server table (IPv4). . . . .	219
	SNTP server table (FastIron X series IPv6 devices) . . . . .	220
<b>Chapter 13</b>	<b>DNS2 MIB Definition</b>	
	DNS table (FastIron devices) . . . . .	221
	DNS address table (FastIron devices) . . . . .	221
<b>Chapter 14</b>	<b>Trace route group</b>	
	Trace route group . . . . .	223
	General trace route group . . . . .	223
	Trace route result table. . . . .	224
	IP forwarding cache table. . . . .	225
	IP AS-Path access list table . . . . .	226
	IP community list table . . . . .	227
	IP prefix list table. . . . .	228
	IP AS-Path access list string table . . . . .	230
	IP community list string table. . . . .	230
<b>Chapter 15</b>	<b>Power Over Ethernet MIB</b>	
	Power Over Ethernet global objects. . . . .	233
	Power Over Ethernet port table . . . . .	233
	Power over module table . . . . .	234
	POE unit table . . . . .	235
<b>Chapter 16</b>	<b>POS MIB Definition</b>	
	Packet port information table . . . . .	237
	POS MIB information table . . . . .	241
	POS PPP group . . . . .	243
	POS cHDLC group . . . . .	244
<b>Chapter 17</b>	<b>Stackable Management Group</b>	
	General stackable management information . . . . .	245

	Stackable management secondary switch information . . . . .	246
<b>Chapter 18</b>	<b>Stacking MIB Definition</b>	
	Global objects for stacking . . . . .	249
	Stacking configuration unit table . . . . .	250
	Stacking operation unit table . . . . .	251
<b>Chapter 19</b>	<b>FDP MIB Definitions</b>	
	FDP interface table . . . . .	253
	FDP cache table . . . . .	253
	FDP global configuration objects . . . . .	255
	FDP cached address entry table . . . . .	256
<b>Chapter 20</b>	<b>Network Processor MIB Definition</b>	
	NP statistics table . . . . .	257
	NP QoS statistics table . . . . .	261
<b>Chapter 21</b>	<b>System Logging Group</b>	
	Global system logging group objects . . . . .	263
	Dynamic system logging buffer table . . . . .	265
	Static system logging buffer table . . . . .	266
	System log server table . . . . .	267
	IPv4/IPv6 sysLog server table . . . . .	268
<b>Chapter 22</b>	<b>NetFlow and sFlow MIB</b>	
	NetFlow Export . . . . .	269
	Global NetFlow objects . . . . .	269
	NetFlow Export collector table . . . . .	269
	NetFlow Export aggregation table . . . . .	270
	NetFlow Export interface table . . . . .	272
	sFlow . . . . .	272
	sFlow collector table . . . . .	272
<b>Chapter 23</b>	<b>VLAN Layer 2 Switch MIB Definition</b>	
	VLAN by port information table . . . . .	275
	VLAN by port membership table . . . . .	279
	Port VLAN configuration table . . . . .	280
	VLAN by protocol configuration table . . . . .	283
	VLAN by IP subnet configuration table . . . . .	285
	VLAN by IPX network configuration table . . . . .	287

	VLAN by AppleTalk cable configuration table . . . . .	289
	VLAN extended statistics . . . . .	290
	VLAN extended statistics for VPLS . . . . .	292
	VLAN extended statistics for VLL and VLL-local endpoints . . . . .	292
<b>Chapter 24</b>	<b>Forwarding Database Group</b>	
	Forwarding database static table information . . . . .	295
<b>Chapter 25</b>	<b>Port STP Configuration Group</b>	
	Port STP configuration groups . . . . .	297
	Port STP table . . . . .	297
	STP table . . . . .	300
<b>Chapter 26</b>	<b>MRP MIB Definition</b>	
	MRP table . . . . .	303
<b>Chapter 27</b>	<b>Trunk Port Configuration Group</b>	
	Trunk port configuration group . . . . .	307
	Multi-slot trunk port table . . . . .	307
	Switch configuration summary group . . . . .	308
<b>Chapter 28</b>	<b>RADIUS Group</b>	
	RADIUS general group . . . . .	311
	RADIUS server table (IPv4) . . . . .	313
	RADIUS server table (FastIron X series IPv6 devices) . . . . .	314
<b>Chapter 29</b>	<b>TACACS Group</b>	
	TACACS general MIBs . . . . .	315
	TACACS server table (IPv4) . . . . .	316
	TACACS server table (FastIron X series IPv6 devices) . . . . .	316
<b>Chapter 30</b>	<b>802.1X Authentication MIB</b>	
	802.1X authentication scalar group types . . . . .	319
	802.1X port statistics table . . . . .	321
	802.1X port configuration table . . . . .	322
	802.1x port state table . . . . .	322
	802.1X MAC sessions table . . . . .	323
	802.1x authentication global administration . . . . .	324

<b>Chapter 31</b>	<b>DHCP Gateway List</b>	
	DHCP gateway list table . . . . .	327
	DNS group (IPv4) . . . . .	327
	IPv4 and IPv6 MIB table for DNS servers . . . . .	328
<b>Chapter 32</b>	<b>MAC Filters</b>	
	MAC filters . . . . .	329
	MAC filter table . . . . .	329
	MAC filter port access table . . . . .	330
	MAC filter ifaccess table . . . . .	331
<b>Chapter 33</b>	<b>Port MAC Security</b>	
	Port MAC security table . . . . .	333
	Port MAC security module statistics table . . . . .	334
	Port MAC security interface table . . . . .	335
	Port MAC security interface MAC table . . . . .	336
	Port MAC security autosave MAC table . . . . .	336
	Port MAC security global MIB group . . . . .	337
	Port monitor table . . . . .	337
<b>Chapter 34</b>	<b>MAC Authentication MIB Definition</b>	
	Multi-device port authentication . . . . .	339
	MAC clear interface multi-device port authentication objects . . . . .	339
	Multi-device port authentication objects . . . . .	340
	Multi-device port authentication clear sessions . . . . .	340
<b>Chapter 35</b>	<b>MAC VLAN MIB Definition</b>	
	MAC-based VLAN global scalar objects . . . . .	343
	MAC-based VLAN port table objects . . . . .	343
	MAC-based VLAN interface table objects . . . . .	344
	MAC-based VLAN table objects . . . . .	344
<b>Chapter 36</b>	<b>DHCP Snooping MIB Definition</b>	
	DHCP Snooping global scalar object . . . . .	347
	DHCP Snooping VLAN configuration table . . . . .	347
	DHCP Snooping interface configuration table . . . . .	347
	DHCP Snooping binding database table . . . . .	348

<b>Chapter 37</b>	<b>IP Source Guard MIB Definition</b>	
	IP source guard interface configuration table . . . . .	351
	IP source guard per port per VLAN configuration table . . . . .	351
	IP source guard binding table . . . . .	352
<b>Chapter 38</b>	<b>DAI MIB Definition</b>	
	DAI VLAN configuration table . . . . .	353
	DAI interface configuration table . . . . .	353
	DAI entry table . . . . .	353
<b>Chapter 39</b>	<b>Traffic Manager MIB Definition</b>	
	TM statistics information group . . . . .	355
	TM statistics table . . . . .	356
	TM VOQ statistics table . . . . .	357
	TM unicast VOQ statistics table . . . . .	359
	TM multicast VOQ statistics table . . . . .	361
	TM multicast stream VOQ statistics table . . . . .	363
	TM CPU VOQ statistics table . . . . .	365
	TM CPU VOQ information table . . . . .	367
<b>Chapter 40</b>	<b>IPv4 ACL MIB Definition</b>	
	IPv4 ACL table . . . . .	369
	ACL bind to port table . . . . .	376
	ACL port table . . . . .	377
	ACL accounting table . . . . .	378
	Textual conventions . . . . .	380
	Layer 2 ACL next clause table . . . . .	380
	Layer 2 ACL configuration table . . . . .	381
	Layer 2 ACL binding configuration table . . . . .	384
<b>Chapter 41</b>	<b>IPv6 ACL MIB Definition</b>	
	IPv6 ACL table (FastIron X series IPv6 devices) . . . . .	385
<b>Chapter 42</b>	<b>IP VRRP MIB Definition</b>	
	VRRP and VRRP-Extended MIBs . . . . .	387
	VRRP interface table . . . . .	388
	VRRP and VRRP-E interface table . . . . .	389
	VRRP virtual router table . . . . .	389

	VRRP and VRRP-E virtual router configuration table . . . . .	394
<b>Chapter 43</b>	<b>VSRP MIB Definition</b>	
	Global VSRP objects . . . . .	399
	VSRP interface table . . . . .	400
	VSRP virtual router table . . . . .	400
<b>Chapter 44</b>	<b>ARP MIB Definition</b>	
	Global ARP statistics . . . . .	407
<b>Chapter 45</b>	<b>IP MIB Definition</b>	
	Global router MIB . . . . .	409
	IP general group . . . . .	410
	IP static route table . . . . .	412
	IP filter table . . . . .	413
	RARP table . . . . .	415
	Static ARP table . . . . .	416
	IP interface port address table . . . . .	417
	IP interface port access table . . . . .	418
	Port configuration tables . . . . .	419
	IP interface port configuration table . . . . .	419
	IP interface address table . . . . .	420
	IP interface port access table . . . . .	420
	IP interface configuration table . . . . .	421
	IP interface counter table . . . . .	422
<b>Chapter 46</b>	<b>IPV6 IP MIB Definition</b>	
	ECMP MIB objects . . . . .	423
<b>Chapter 47</b>	<b>IPX MIB Definition</b>	
	IPX general objects . . . . .	425
	IPX cache table . . . . .	427
	IPX route table . . . . .	428
	IPX server table . . . . .	429
	IPX forward filter table . . . . .	429
	IPX RIP filter table . . . . .	430
	IPX SAP filter table . . . . .	431
	IPX IF forward access table . . . . .	432
	IPX IF RIP access table . . . . .	432



IPX IF SAP access table . . . . .	433
IPX port address table . . . . .	433
IPX port counters table . . . . .	434

**Chapter 48**

**BGP4 MIB Definition**

BGP4 general variables . . . . .	437
BGP4 address filter table . . . . .	447
BGP4 aggregate address table . . . . .	448
BGP4 AS-Path filter table . . . . .	449
BGP4 community filter table . . . . .	450
BGP4 neighbor general configuration table . . . . .	451
BGP4 neighbor distribute group table . . . . .	454
BGP4 neighbor filter group table . . . . .	456
BGP4 neighbor route map table . . . . .	457
BGP4 network table . . . . .	458
BGP4 redistribution of routes table . . . . .	459
BGP4 route map filter table . . . . .	460
BGP4 route map match table . . . . .	461
BGP4 neighbor operational status table . . . . .	465
BGP4 router operational status table . . . . .	467
BGP4 neighbor summary table . . . . .	469
BGP4 attribute entries table . . . . .	470
BGP4 clear neighbor command table . . . . .	471
BGP4 neighbor prefix group table . . . . .	472

**Chapter 49**

**OSPF MIB Definition**

OSPF general objects . . . . .	473
OSPF area table . . . . .	475
Area range table . . . . .	476
OSPF interface configuration tables . . . . .	477
OSPF interface configuration table . . . . .	477
OSPF interface 2 configuration table . . . . .	480
OSPF virtual interface table . . . . .	483
OSPF redistribution of routes table . . . . .	486
OSPF neighbor table . . . . .	487
OSPF virtual neighbor table . . . . .	489
OSPF link-state database . . . . .	491
OSPF link-state database (external) . . . . .	492

	OSPF area status table . . . . .	493
	OSPF interface status table . . . . .	494
	OSPF virtual interface status table . . . . .	497
	OSPF routing information table . . . . .	499
	Trap support objects . . . . .	500
<b>Chapter 50</b>	<b>Broadcast Forwarding Group</b>	
	General UDP broadcast forwarding group . . . . .	501
	UDP broadcast forwarding port table . . . . .	501
	UDP helper table . . . . .	502
<b>Chapter 51</b>	<b>Router IP RIP MIB</b>	
	IP RIP general group . . . . .	505
	IP RIP port configuration table . . . . .	507
	IP RIP redistribution table . . . . .	508
	IP RIP route filter table . . . . .	509
	IP RIP neighbor filter table . . . . .	510
	IP RIP port access table . . . . .	511
	Global RIP statistics . . . . .	512
<b>Chapter 52</b>	<b>DVMRP MIB Definition</b>	
	Global DVMRP objects . . . . .	515
	DVMRP virtual interface table . . . . .	517
	DVMRP neighbor table . . . . .	518
	DVMRP route table . . . . .	519
	DVMRP routing next hop table . . . . .	520
	DVMRP virtual interface statistics table . . . . .	521
<b>Chapter 53</b>	<b>FSRP MIB Definition</b>	
	FSRP objects . . . . .	523
	FSRP global variables . . . . .	523
	FSRP interface table . . . . .	524
<b>Chapter 54</b>	<b>PIM MIB Definition</b>	
	Common PIM objects . . . . .	527
	PIM virtual interface table . . . . .	528
	PIM neighbor table . . . . .	529
	PIM virtual interface statistics table . . . . .	530

	PIM-SM.....	532
	PIM Sparse: candidate BSR table.....	532
	PIM RP set table.....	532
	PIM RP candidate table.....	533
<b>Chapter 55</b>	<b>IGMP MIB Definition</b>	
	General IGMP objects.....	535
	IGMP interface table.....	536
	IGMP static group table.....	536
<b>Chapter 56</b>	<b>QoS Profile Group</b>	
	QoS profile table.....	539
	QoS bind table.....	539
	DOS attack statistics.....	540
	DOS attack port table.....	540
	Authorization and accounting.....	541
<b>Chapter 57</b>	<b>CAR MIB Definition</b>	
	CAR port table.....	543
	Rate limit counter table.....	544
	VLAN CAR objects.....	545
<b>Chapter 58</b>	<b>LAG MIB Definition</b>	
	LAG group table.....	547
	LAG group port table.....	548
<b>Chapter 59</b>	<b>MPLS MIB Definition</b>	
	Pseudo wire MIB.....	549
	pwTable.....	549
	Draft-ietf-pwe3-pw-mib-11.txt.....	552
	Values that affect some VLL services.....	553
	Supported objects in draft-ietf-pwe3-pw-mib-06.txt.....	554
	Proprietary extension.....	556
	MPLS or BGP Layer 3 VPN MIB.....	556
	VPN interface configuration table.....	556
	VRF configuration table.....	557
	VRF route target table.....	558
	VRF security table.....	558
	VRF performance table.....	558
	VRF routing table.....	559
	Supported objects in VPLS-generic-draft-01-mib.....	559
	General MPLS objects.....	562
	MPLS LSP table.....	562

	MPLS administrative group table . . . . .	566
	MPLS interface table . . . . .	567
<b>Chapter 60</b>	<b>MPLS Layer 2 VPN MIB Definition</b>	
	VLL endpoint table . . . . .	569
	VPLS endpoint2 table . . . . .	570
	VPLS instance table . . . . .	571
<b>Chapter 61</b>	<b>BFD MIB Definition</b>	
	BFD session table . . . . .	573
	BFD session performance table . . . . .	575
	BFD session mapping table . . . . .	576
	BFD scalar objects . . . . .	577
<b>Chapter 62</b>	<b>AppleTalk MIB Definition</b>	
	AppleTalk general group . . . . .	579
	AppleTalk socket priority table . . . . .	581
	AppleTalk port zone filter table . . . . .	582
	AppleTalk port table . . . . .	583
	AppleTalk forwarding cache table . . . . .	584
	AppleTalk zone table . . . . .	585
	AppleTalk additional zone filter table . . . . .	585
<b>Chapter 63</b>	<b>Layer 4 Switch Group MIB Definition</b>	
	Layer 4 general MIBs . . . . .	588
	Server load balancing table . . . . .	588
	Server load balancing traffic information . . . . .	589
	Session . . . . .	590
	Hot standby . . . . .	590
	Enabling or disabling Layer 4 traps . . . . .	592
	Server cache groups . . . . .	593
	GSLB group global . . . . .	594
	Virtual server configuration table . . . . .	595
	Real server configuration table . . . . .	597
	Virtual server port configuration table . . . . .	598
	Real server port configuration table . . . . .	600
	Layer4 bind table . . . . .	600
	Virtual server statistics table . . . . .	601

Virtual server port statistics table . . . . .	603
Real server port statistics table . . . . .	604
Layer 4 policy table . . . . .	606
Layer 4 policy port access table. . . . .	607
Layer 4 trap variable binding table . . . . .	608
Web cache table . . . . .	609
Web cache group table . . . . .	610
Web cache traffic statistics table. . . . .	611
Web uncached traffic statistics table . . . . .	613
Web cache real server port table. . . . .	614
GSLB remote ServerIron configuration table . . . . .	615
Real server history control table . . . . .	616
Real server history group table . . . . .	617
Real server port history control group table . . . . .	618
Real server port history group table . . . . .	620
Virtual server history control group table . . . . .	621
Virtual server history table . . . . .	622
Virtual server port history control table. . . . .	624
Virtual server port history table . . . . .	625

## Chapter 64

### Wireless MIB Definition

General MIB objects . . . . .	627
WiFi interface table . . . . .	628
Roaming peer table. . . . .	629
Access Point ADC table. . . . .	629
VPN passthrough server table . . . . .	630
VPN passthrough filter table. . . . .	630
VPN passthrough policy table. . . . .	631

## Chapter 65

### Trap MIB Definition

Objects to enable or disable standard traps. . . . .	633
Standard traps. . . . .	634
System status traps. . . . .	634
Traps for STP . . . . .	635
Traps for alarms . . . . .	635
Pseudo wire traps . . . . .	636
MPLS Layer 3 VPN traps . . . . .	637

Proprietary traps . . . . .	639
General traps . . . . .	639
Traps for optics . . . . .	644
Traps for TM . . . . .	645
Packet over SONET traps . . . . .	647
MAC-based VLAN traps . . . . .	647
VRRP traps . . . . .	648
FSRP traps . . . . .	648
VSRP traps . . . . .	648
OSPF traps . . . . .	648
Layer 4 traps . . . . .	654
ICMP traps . . . . .	658
TCP traps . . . . .	658
BGP traps . . . . .	658
Port security traps . . . . .	659
MRP traps . . . . .	660
MPLS notifications . . . . .	660
MPLS LSP notification . . . . .	661
MPLS LSR notification . . . . .	662
Traps for BFD . . . . .	662
Traps for CAM overflow . . . . .	663
Traps for wireless features . . . . .	664
SNMP traps for RSVP-signaled LSP state . . . . .	666
UDLD traps . . . . .	667
BPDU guard and root guard traps . . . . .	667
Traps for optics . . . . .	668
Traps for stacking . . . . .	670
Trap specific to FWS . . . . .	671
Software licensing traps . . . . .	672
Trap receiver table (FastIron X series IPv6 devices) . . . . .	672
Examples . . . . .	673
RMON event traps . . . . .	673
General traps for the Brocade NetIron devices . . . . .	673

**Appendix A      Unsupported MIB Objects**

Proprietary MIBs . . . . .	679
Traps . . . . .	689

# About This Document

---

## In this chapter

- [Supported hardware and software](#) ..... xxiii
- [Document conventions](#) ..... xxiii
- [Trademark references](#) ..... xxv
- [Getting technical help](#) ..... xxv
- [Document feedback](#) ..... xxv

## Supported hardware and software

This document provides information for the following devices that support the Unified IP MIB:

Brocade FastIron and Turbolron devices running software release 07.2.02 and later:

- Brocade FastIron Edge Swich X Series
- Brocade FastIron SX 800 and FastIron SX 1600
- Brocade FastIron SuperX
- Brocade FastIron GS and FastIron GS-STK
- Brocade FastIron LS and FastIron LS-STK
- Brocade FastIron WS
- Brocade FCX
- Brocade ICX
- Brocade Turbolron

Brocade NetIron devices running software release 05.2.00 and later:

- Brocade MLX
- Brocade MLXe
- Brocade NetIron XMR
- Brocade NetIron CES
- Brocade NetIron CER series

## Document conventions

This section describes text formatting conventions and important notice formats used in this document.

## Text formatting

The narrative-text formatting conventions that are used are as follows:

<b>bold text</b>	Identifies command names Identifies the names of user-manipulated GUI elements Identifies keywords Identifies text to enter at the GUI or CLI
<i>italic text</i>	Provides emphasis Identifies variables Identifies document titles
code text	Identifies CLI output

For readability, command names in the narrative portions of this guide are presented in mixed lettercase: for example, **switchShow**. In actual examples, command lettercase is all lowercase.

## Command syntax conventions

Command syntax in this manual follows these conventions:

<b>command</b>	Commands are printed in bold.
<b>--option, option</b>	Command options are printed in bold.
<b>-argument, arg</b>	Arguments.
[ ]	Optional elements appear in brackets.
<i>variable</i>	Variables are printed in italics. In the help pages, values are <u>underlined</u> or enclosed in angled brackets < >.
...	Repeat the previous element, for example “member[;member...]”
value	Fixed values following arguments are printed in plain font. For example, <b>--show WWN</b>
	Boolean. Elements are exclusive. Example: <b>--show -mode egress   ingress</b>

## Notes

The following notice statements are used in this manual.

---

### NOTE

A note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

---

### ATTENTION

An Attention statement indicates potential damage to hardware or data.

---



## Trademark references

This document may contain references to the trademarks of the following corporations. These trademarks are the properties of their respective companies and corporations.

These references are made for informational purposes only.

Corporation	Referenced Trademarks and Products
Hewlett-Packard Development Company	HP OpenView
The Open Group	UNIX

## Getting technical help

To contact Technical Support, go to <http://www.brocade.com/services-support/index.page> for the latest e-mail and telephone contact information.

## Document feedback

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. Forward your feedback to:

documentation@brocade.com

Provide the title and version number of the document and as much detail as possible about your comment, including the topic heading and page number and your suggestions for improvement.

Document feedback

# Overview of the Unified IP MIB

---

## In this chapter

- Introduction ..... 1
- Obtaining and installing the Unified IP MIBs ..... 1
- Standard objects ..... 2
- Proprietary objects ..... 3
- SNMPv3 support ..... 3

## Introduction

The Management Information Base (MIB) is a database of objects that can be used by a Network Management System (NMS) to manage and monitor devices on the network. The MIB can be retrieved by a network management system that uses Simple Network Management Protocol (SNMP). The MIB structure determines the scope of management access allowed by a device. By using SNMP, a manager application can issue read or write operations within the scope of the MIB.

The Unified IP MIB consolidates proprietary MIBs used by all Brocade IP devices into one proprietary MIB file. With this consolidation, all MIBs from IP devices are fully synchronized from one device to another. It also ensures that each MIB object across various IP products have consistent definition. The SNMP Manager can compile MIBs safely from various platforms and not expect to get warnings due to conflicting OIDs, data types, or enumeration. The supported standard MIBs are not affected.

The Unified IP MIB is not backward-compatible; for this reason, if you have Brocade devices that do not support the Unified IP MIB, you may need to rewrite your SNMP scripts if the scripts contain objects that were changed in the Unified IP MIB.

## Obtaining and installing the Unified IP MIBs

You can obtain the Unified IP MIBs by downloading the file from the Brocade Technical Support website.

After obtaining the MIB, follow the instructions for your network management system (NMS) to be able to use the MIB with your system.

### Downloading the MIB from the Technical Support website

To download the MIB from the Brocade Technical Support website, you must have a user name and password to access the Brocade support site and perform the following steps.

# 1 Overview of the Unified IP MIB

1. Go to <http://www.brocade.com> in your Web browser.
2. Log in with your user name and password.
3. Click the Downloads tab, and then click the Knowledge Portal link.
4. Log in to the Knowledge Portal, and then click the Software tab.
5. Click the product name. Each product release has a link for its corresponding MIB.
6. Navigate to the link for the MIB and either open the file or save it to disk.

## Downloading the MIB from the Brocade FTP site

You can also download the MIB from the Knowledge Portal. Contact Brocade Technical Support for details. For the latest edition of this document, which contains the most up-to-date information, refer to the Product Manuals tab at <http://www.brocade.com>.

## Importing Unified IP MIB into a UNIX environment

You can import the Unified IP MIB into third-party network management applications, such as HP OpenView. By default, the Unified IP MIB files are in DOS ASCII format that uses the following characters:

- CR/LF – Indicates the end of a line
- ^Z - Indicates the end of a file

However, in a UNIX environment, the characters LF are used to indicate the end of a line. No character indicates the end of a file. Thus, if you need to import the Unified IP MIB into a UNIX environment, you must use a tool that converts the DOS ASCII into UNIX ASCII, such as the dos2unix tool.

## Reloading MIBs into a third-party NMS

Third-party network management systems, such as HP OpenView may have problems reloading MIB files. Ensure that you must upload the following when reloading the Brocade Unified IP MIBs:

- Unload the Enterprise MIBs which were installed from the previous upgrade before reloading any new Enterprise MIB file.
- Unload the Standard MIBs which were installed from the previous upgrade before reloading any new Standard MIB file.

## Standard objects

The Unified IP MIB supports certain standard MIB objects, which are derived from Request for Comments (RFCs) documents. Refer to [Chapter 2, “Supported Standard MIBs”](#) for details on the supported standard MIBs.

## Proprietary objects

Proprietary objects are MIB objects that have been developed specifically to manage Brocade IP devices. The object identifier (OID) for these MIB objects begin with *1.3.6.1.4.1.1991*. In this manual, the prefix *1.3.6.1.4.1.1991* is represented by the characters *brcdIp*.

For example, the OID for the object *snChassis* is *1.3.6.1.4.1.1991.1.1.1*, but documented as *brcdIp.1.1.1* in this manual.

## SNMPv3 support

The SNMPv3 engine is supported on the Brocade IP devices. The SNMPv3 engine can accept V1, V2c, and V3 packet formats.

# 1 Overview of the Unified IP MIB

# Supported Standard MIBs

---

## In this chapter

- Supported on FastIron devices . . . . . 6
- Supported on NetIron devices . . . . . 6
- LLDP MIB support . . . . . 8
- LLDP\LLDP-MED MIB support . . . . . 9
- RFC 1493: Definitions of Managed Objects for Bridges . . . . . 9
- RFC 1643: Definitions of Managed Objects for Ethernet-like Interface Types 10
- RFC 1757: Remote Network Monitoring Management Information Base . . 10
- RFC 2096: IP Forwarding Table MIB . . . . . 11
- RFC 2233: The Interfaces Group MIB using SMIPv2 . . . . . 11
- RFC 2515: Definitions of Managed Objects for ATM Management . . . . . 12
- RFC 2665: Definitions of Managed Objects for the Ethernet-like Interface Types 13
- RFC 2674: Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions 13
- RFC 2819: Remote Network Monitoring Management Information Base . . 14
- RFC 2863: The Interfaces Group MIB . . . . . 16
- RFC 2932: IPv4 Multicast Routing MIB . . . . . 21
- RFC 2933: Internet Group Management Protocol MIB . . . . . 25
- RFC 2934: Protocol Independent Multicast MIB for IPv4 . . . . . 27
- RFC 3176: InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched and Routed Networks 32
- RFC 3289: Management Information Base for the Differentiated Services Architecture 33
- RFC 3813: Multiprotocol Label Switching (MPLS) Label Switching Router (LSR) Management Information Base (MIB) 34
- RFC 3815: Definitions of Managed Objects for the Multiprotocol Label Switching (MPLS), Label Distribution Protocol (LDP) 37
- RFC 4022: Management Information Base for the Transmission Control Protocol (TCP) 42
- RFC 4087: IP Tunnel MIB . . . . . 42
- RFC 4113: Management Information Base for the User Datagram Protocol (UDP) 45
- RFC 4273: Definitions of Managed Objects for BGP-4 . . . . . 45
- RFC 4292: IP Forwarding Table MIB . . . . . 54
- RFC 4293: Management Information Base for the Internet Protocol (IP) . . 55
- RFC 4444: Management Information Base for Intermediate System to Intermediate System (IS-IS) 56

- [RFC 4807: IPsec Security Policy Database Configuration MIB](#) . . . . . 59
- [IEEE8021-CFM-MIB](#) . . . . . 62

This section summarizes the standard objects that are supported in the Unified IP MIB. It does not document all the supported standard objects, but presents those standard MIBs that are not fully supported.

For example, although RFC 1493 is supported in the Unified IP MIB, some groups and tables in that MIB are not supported.

## Supported on FastIron devices

FastIron devices support the following RFCs:

- 2863 – The Interfaces Group MIB
- 3411 – SNMP Framework MIB
- 3412 – Message Processing and Dispatching (MPD) for the SNMP MIB
- 3413 – SNMP Target MIB
- 3414 – User-Security Model for SNMPv3 MIB
- 3415 – View-based Access Control Model for SNMP MIB
- 4188 – Definitions of Managed Objects for Bridges
- 4273 – Definitions of Managed Objects for BGP-4

FastIron X Series IPv6 devices support the following standard MIBs:

- 2452 – IP Version 6 Management Information Base for the Transmission Control Protocol
- 2454 – IP Version 6 Management Information Base for the User Datagram Protocol
- 2465 – Management Information Base for IP Version 6: Textual Conventions and General Group

---

**NOTE**

RFC 2465 MIB support on FastIron X Series IPv6 devices is limited to `ipv6NetToMediaTable` and `ipv6AddrTable` only.

---

- 2466 – Management Information Base for IP Version 6: ICMPv6 Group
- 2932 – IPv4 Multicast Routing MIB
- 2933 – Internet Group Management Protocol MIB
- 2934 – Protocol Independent Multicast MIB for IPv4
- 4001 – Textual Conventions for Internet Network Addresses

## Supported on NetIron devices

The following RFCs are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

- 1213 – MIB II
- 1493 – Bridge MIB (excluding filtering of objects)
- 1724 – RIPv2 MIB



- 2665 – Ethernet-Like MIB
- 2674 – 802.1Q and 802.1p Bridge MIB
- 2787 – VRRP MIB
- 2819 – Remote Network Monitoring Management Information Base
- 2863 – Interfaces Group MIB
- 2932 – Multicast Routing MIB for IPv4 (Refer to [“RFC 2932: IPv4 Multicast Routing MIB”](#) on page 21 for details.)
- 2933 – IGMP MIB (Refer to [“RFC 2933: Internet Group Management Protocol MIB”](#) on page 25 for details.)
- 2934 – PIM MIB (Refer to [“RFC 2934: Protocol Independent Multicast MIB for IPv4”](#) on page 27 details.)
- 3289 – Management Information Base for the Differentiated Services Architecture
- 3418 – Management Information Base (MIB) for the SNMP
- 3592 – SDH/SONET MIB (partially supported)
- 3812 – MPLS TE Standard MIB
- 3813 – Multiprotocol Label Switching (MPLS) Label Switching Router (LSR) Management Information Base (MIB)
- 4022 – Management Information Base for the Transmission Control Protocol (TCP)
- 4087 – IP Tunnel MIB
- 4113 – Management Information Base for the User Datagram Protocol (UDP)
- 4292 – IP Forwarding MIB
- 4293 – Management Information Base for the Internet Protocol (IP). (Refer to [“RFC 4293: Management Information Base for the Internet Protocol \(IP\)”](#) on page 55 for details.)
- 4382 – MPLS/BGP Layer 3 Virtual Private Network (VPN) Management Information Base
- 4444 – Management Information Base for Intermediate System to Intermediate System (IS-IS) (Refer to [“RFC 4444: Management Information Base for Intermediate System to Intermediate System \(IS-IS\)”](#) on page 56 for details.)
- 4807 – IP Security Policy Database Configuration Management Information Base
- draft-ietf-bfd – Bidirectional Forwarding Detection Management Information Base
- draft-ietf-pwe3-enet-mib-11.txt – Ethernet Pseudo Wire (PW) Management Information Base
- draft-thaler-dvmrp-mib-09.txt – Distance-Vector Multicast Routing Protocol MIB

## RFC compliance - management

- 854 – TELNET
- 1445 – Administrative Model for SNMPv2 - Support for View Subtree (partially supported)
- 1492 – TACACS+
- 2030 – SNTF
- 2068 – HTTP
- 2284 – PPP EAP - Support EAP extension
- 2578 – SNMPV2
- 2579 – Textual Conventions for SMIV2

## 2 Supported Standard MIBs

- 2865 – RADIUS
- 2866 – RADIUS Accounting
- 2868 – RADIUS Attributes for Tunnel Protocol (partially supported)
- 2869 – RADIUS Extensions - EAP Message (type 79) and Message-Authenticator (type 80)
- 3164 – BSD Syslog Protocol
- 3176 – sFlow (Refer to [“RFC 3176: InMon Corporation’s sFlow: A Method for Monitoring Traffic in Switched and Routed Networks”](#) on page 32 for details.)
- 3410 – SNMPV3
- 3411 – Architecture for SNMP
- 3412 – Message Processing and Dispatching for SNMP
- 3413 – Simple Network Management Protocol (SNMP) Applications (partially supported)
- 3414 – USM for SNMPV3
- 3415 – VACM for SNMPV3
- 3416 – Version 2 of the Protocol Operations for the SNMP
- 3579 – RADIUS Support for Extensible Authentication Protocol (EAP) (partially supported)
- 3584 – Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework
- 3815 – Managed Objects for the Multiprotocol Label Switching (MPLS) and Label Distribution Protocol (LDP)
- 3826 – The Advanced Encryption Standard (AES) Cipher Algorithm in the SNMP User-based Security Model
- 4188 – Definitions of Managed Objects for Bridges
- 4251 – The Secure Shell (SSH) Protocol Architecture
- 4252 – The Secure Shell (SSH) Authentication Protocol
- 4253 – The Secure Shell (SSH) Transport Protocol
- 4254 – The Secure Shell (SSH) Connection Protocol
- 4273 – Definitions of Managed Objects for BGP-4 (Refer to [“RFC 4273: Definitions of Managed Objects for BGP-4”](#) on page 45 for details.)
- [“draft-ietf-idr-bgp4-mibv2-12 MIB”](#) – Definitions of Managed Objects for the Fourth Version of Border Gateway Protocol (BGP-4), Second Version
- 4330 – Simple Network Time Protocol (SNTP) Version 4 for IPv4 and IPv6
- draft-grant-tacacs-02.txt – The TACACS+ Protocol
- draft-ietf-pwe3-pw-mib-11.txt – PW-STD-MIB Definitions (read-only)

### IEEE standards

- [“IEEE8021-CFM-MIB”](#) – IEEE 802.1ag CFM MIB

## LLDP MIB support

The following standard MIBs are supported on Brocade Netlron devices with LLDP capability.

The following MIBs are in the 802.1AB standard, Station and Media Access Control Connectivity Discovery:

- “LLDP-MIB”
- “LLDP-EXT-DOT1-MIB”
- “LLDP-EXT-DOT3-MIB”

## LLDP\LLDP-MED MIB support

The following standard MIBs are not supported on Brocade NetIron devices with LLDP\LLDP-MED capability.

- LLDP-EXT-DOT1-MIB
- LLDP-EXT-DOT3-MIB

The following MIB is in the ANSI/TIA-1057 standard, Link Layer Discovery Protocol (LLDP) for Media Endpoint Devices (MED):

- LLDP-EXT-MED-MIB

## RFC 1493: Definitions of Managed Objects for Bridges

The following groups are supported on the NetIron devices.

---

### NOTE

RFC 4188 obsoletes RFC 1493 on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

Object group name	Object identifier
dot1dBridge	1.3.6.1.2.1.17
dot1dBase	1.3.6.1.2.1.17.1
dot1dStp	1.3.6.1.2.1.17.2
dot1dTp	1.3.6.1.2.1.17.4

---

### NOTE

The dot1dTpFdbTable (OID 1.3.6.1.2.1.17.4.4) in RFC 1493 is used to find dynamically learned MAC addresses. Statically configured MAC addresses are in the snFdbTable (refer to [“Forwarding database static table information”](#) on page 295).

---



---

### NOTE

The SNMP MIB object dot1dStpPortTable (OID 1.3.6.1.2.1.17.2.15) does not display information for tagged ports that belong to an 802.1W RSTP configuration. The design of that MIB table is based on a Single STP standard, and does not accommodate Multiple STPs. Thus, the table displays information only for SSTP and for untagged ports.

---

---

**NOTE**

RFC 4188 has been converted to SMIv2 format. The object dot1dStpPortPathCost32 was added to support IEEE 802. The existing MIB dot1dStpPortPathCost has an upper range of 65535. Over that value, this MIB stays at the upper value and you should access dot1dStpPortPathCost32, which has a higher upper-range value.

---

## RFC 1643: Definitions of Managed Objects for Ethernet-like Interface Types

The following groups from RFC 1643 are supported on the NetIron devices.

---

**NOTE**

RFC 1643 is supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

Object group name	Object identifier
dot3	1.3.6.1.2.1.10.7
dot3StatsTable	1.3.6.1.2.1.10.7.2
dot3CollTable	1.3.6.1.2.1.10.7.5
dot3Tests	1.3.6.1.2.1.10.7.6
dot3Errors	1.3.6.1.2.1.10.7.7
dot3ChipSets	1.3.6.1.2.1.10.7.8

**NOTE:** This table is not supported on FastIron devices.

---

## RFC 1757: Remote Network Monitoring Management Information Base

The following groups from this RFC are supported on NetIron devices.

---

**NOTE**

This RFC is obsolete and is replaced by RFC 2819 for the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

Object group name	Object identifier
rmon	1.3.6.1.2.1.16
	<b>NOTE:</b> This group is not supported on FastIron devices.
statistics	1.3.6.1.2.1.16.1
history	1.3.6.1.2.1.16.2
alarm	1.3.6.1.2.1.16.3
event	1.3.6.1.2.1.16.9

---

The following object groups in RFC 1757 are not supported on NetIron devices:

- hosts
- hostTopN
- matrix
- filter
- capture (packet capture)

## RFC 2096: IP Forwarding Table MIB

RFC 2096 is supported on the following devices:

- On FastIron devices, RFC 2096 replaces RFC 1213.
- On NetIron devices, RFC 2096 is obsoleted by RFC 4292 and it supports both IPv4 and IPv6 forwarding tables.

Object group name	Object identifier
ipCidrRouteDest	1.3.6.1.2.1.4.24.4.1.1
ipCidrRouteMask	1.3.6.1.2.1.4.24.4.1.2
ipCidrRouteTos	1.3.6.1.2.1.4.24.4.1.3
ipCidrRouteNextHop	1.3.6.1.2.1.4.24.4.1.4
ipCidrRouteIfIndex	1.3.6.1.2.1.4.24.4.1.5
ipCidrRouteType	1.3.6.1.2.1.4.24.4.1.6
ipCidrRouteProto	1.3.6.1.2.1.4.24.4.1.7
ipCidrRouteAge	1.3.6.1.2.1.4.24.4.1.8
ipCidrRouteInfo	1.3.6.1.2.1.4.24.4.1.9
ipCidrRouteNextHopAS	1.3.6.1.2.1.4.24.4.1.10
ipCidrRouteMetric1	1.3.6.1.2.1.4.24.4.1.11
ipCidrRouteMetric2	1.3.6.1.2.1.4.24.4.1.12
ipCidrRouteMetric3	1.3.6.1.2.1.4.24.4.1.13
ipCidrRouteMetric4	1.3.6.1.2.1.4.24.4.1.14
ipCidrRouteMetric5	1.3.6.1.2.1.4.24.4.1.15
ipCidrRouteStatus	1.3.6.1.2.1.4.24.4.1.16

## RFC 2233: The Interfaces Group MIB using SMIv2

The interface entry table or ifXTable is based on RFC 2233. It contains information about the interfaces. Each sub-layer is considered to be an interface. This table contains entries for the ATM physical ports, as well as for any sub-interfaces that have been configured.

Object group name	Object identifier
ifMIB	1.3.6.1.2.1.31
ifMIBObjects	1.3.6.1.2.1.31.1
ifTable	1.3.6.1.2.1.2.2
ifXtable	1.3.6.1.2.1.31.1.1
ifStackTable	1.3.6.1.2.1.31.1.2
ifConformance	1.3.6.1.2.1.31.2
ifCounterDiscontinuityGroup	1.3.6.1.2.1.31.2.1.13

**NOTE:** Supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

## RFC 2515: Definitions of Managed Objects for ATM Management

Only the following object groups from RFC 2515 are supported on devices that support ATM.

### ATM interface configuration parameters table

The ATM Interface Configuration Table from RFC 2515 contains the configuration of cell layers on the ATM interface of a local device. This information is in addition to the information contained in the ifTable.

The table contains one entry for each ATM interface port. [Table 1](#) has the object identifier for the atmInterfaceConf table.

### ATM interface transmission convergence sub-layer table

The ATM Interface Transmission Convergence sub-layer table from RFC 2515 contains configuration and state parameters of the ATM interfaces that use the Transmission Convergence sub-layer for carrying ATM cells over SONET/SDH or DS3. [Table 1](#) has the object identifier for the atmInterfaceTC table.

### AAL5 virtual channel connection performance statistics table

The ATM Adaptation Layer Type 5 (AAL5) virtual channel connection performance statistics table from RFC 2515 contains the performance statistics of a virtual channel connection at the interface associated with an AAL5 entity in an ATM host or ATM switch. [Table 1](#) has the object identifier for the aal5Vcc table.

**TABLE 1** Object group names and OIDs

Object group name	Object identifier
atmMIB	1.3.6.1.2.1.37
atmMIBObjects	1.3.6.1.2.1.37.1
atmInterfaceConfTable	1.3.6.1.2.1.37.1.2
atmInterfaceTCTable	1.3.6.1.2.1.37.1.4
aal5VccTable	1.3.6.1.2.1.37.1.12
atmTCMIB	1.3.6.1.2.1.37.3

Other object groups from this RFC are not supported.

## RFC 2665: Definitions of Managed Objects for the Ethernet-like Interface Types

On the Brocade MLXe devices, interface statistics from the following objects of the dot3StatsTable are preserved when the **clear statistics** command is entered on the CLI, if the **snmp-server preserve-statistics** command is enabled:

- dot3StatsAlignmentErrors
- dot3StatsFCSErrors
- dot3StatsFrameTooLongs
- dot3StatsLateCollisions
- dot3StatsSingleCollisionFrames
- dot3StatsMultipleCollisionFrames
- dot3StatsSQETestErrors
- dot3StatsDeferredTransmissions
- dot3StatsExcessiveCollisions
- dot3StatsInternalMacTransmitErrors
- dot3StatsCarrierSenseErrors
- dot3StatsInternalMacReceiveErrors
- dot3StatsSymbolErrors

## RFC 2674: Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions

The following groups from this RFC are supported.

Object group name	Object identifier
pBridgeMib	1.3.6.1.2.1.17.6
qBridgeMib	1.3.6.1.2.1.17.7

## RFC 2819: Remote Network Monitoring Management Information Base

On the Brocade MLXe devices, interface statistics from the following objects of the etherStatsTable are preserved when the **clear statistics** command is entered on the CLI, if the **snmp-server preserve-statistics** command is enabled:

- etherStatsDropEvents
- etherStatsOctets
- etherStatsPkts
- etherStatsBroadcastPkts
- etherStatsMulticastPkts
- etherStatsCRCAlignErrors
- etherStatsUndersizePkts
- etherStatsOversizePkts
- etherStatsFragments
- etherStatsPkts64Octets
- etherStatsPkts65to127Octets
- etherStatsPkts128to255Octets
- etherStatsPkts256to511Octets
- etherStatsPkts512to1023Octets
- etherStatsPkts1024to1518Octets

### History control group

On the NetIron devices, the history control group controls the periodic statistical sampling of data from various types of networks. The following objects in the historyControlTable store configuration entries that each define an interface, polling period, and other parameters:

- historyControlIndex
- historyControlDataSource
- historyControlBucketsRequested
- historyControlBucketsGranted
- historyControlInterval
- historyControlOwner
- historyControlStatus



## Ethernet history group

On the Netlon devices, the Ethernet history group records periodic statistical samples from a network and stores them for later retrieval. The following objects of the group define the etherHistoryTable for Ethernet networks:

- etherHistoryIndex
- etherHistorySampleIndex
- etherHistoryIntervalStart
- etherHistoryDropEvents
- etherHistoryOctets
- etherHistoryPkts
- etherHistoryBroadcastPkts
- etherHistoryMulticastPkts
- etherHistoryCRCAlignErrors
- etherHistoryUndersizePkts
- etherHistoryOversizePkts
- etherHistoryFragments
- etherHistoryJabbers
- etherHistoryCollisions
- etherHistoryUtilization

## Alarm group

On the Netlon devices, the Alarm group periodically takes statistical samples from variables in the probe and compares them to thresholds that have been configured. The alarm table stores configuration entries that each define a variable, polling period, and threshold parameters:

- alarmIndex
- alarmInterval
- alarmVariable
- alarmSampleType
- alarmValue
- alarmStartupAlarm
- alarmRisingThreshold
- alarmFallingThreshold
- alarmRisingEventIndex
- alarmFallingEventIndex
- alarmOwner
- alarmStatus

### Event group

On the NetIron devices, the following objects in the Event group control the generation and notification of events from the devices. Each entry in the eventTable describes the parameters of the event that can be triggered:

- eventIndex
- eventDescription
- eventType
- eventCommunity
- eventLastTimeSent
- eventOwner
- eventStatus

## RFC 2863: The Interfaces Group MIB

RFC 2863 is supported only on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

### ifIndex

On the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices, there can be 20, 40, 48, or 64 ifIndexes per module. (Refer to the Configuring SNMP ifIndex section of the Configuring Basic Parameters chapter in the *NetIron Configuration Guide* for details.) The default is 20. Issue the **snmp-server max-ifindex-per-module 40** CLI command to change the ifIndex to 40 (for example, for backward-compatibility).

On the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices, every trunk group will appear as a row within the ifTable and ifXTable. The ifIndex range involves all the physical ports, virtual ports, loopback ports, multicast tunnels, GRE tunnels, MPLS tunnels, and Trunks in that order.

Use the Get operations on snInterfaceLookupIfIndex (indexed by ifIndex) to get InterfaceId (in a simple OID form).

[Table 2](#) details the XMR or MLX index ranges and they are subject to change from one release to the next.

**TABLE 2** XMR or MLX index ranges

	<b>4-slot</b>	<b>8-slot</b>	<b>16-slot</b>	<b>32-slot</b>	<b>Allocation</b>
Physical port	1-192	1-384	1-768	1-1536	20 per slot (NetIron release 3.7 and later) 40 per slot (NetIron releases prior to 3.7) 48 per slot (NetIron releases prior to 5.2)
Mgmt port	2	2	2	2	1 active, 1 standby
Virtual port	255 default, 40 minimum, 4096 maximum	255 default, 40 minimum, 4096 maximum	255 default, 40 minimum, 4096 maximum	255 default, 40 minimum, 4096 maximum	
Loopback port	64 default	64 default	64 default	64 default	
IP tunnels	8192	8192	8192	8192	
MPLS tunnels	16384	16384	16384	16384	
Trunk	128 default, 128 minimum, 256 maximum	128 default, 128 minimum, 256 maximum	128 default, 128 minimum, 256 maximum	128 default, 128 minimum, 256 maximum	

### *ifIndex assignment persistence*

The following interfaces on the Brocade NetIron XMR, Brocade MLXe, and Brocade MLX have ifIndex assignments that are persistent across reboots and switchover operations:

- Physical ports
- Virtual ports
- Loopback ports

#### **NOTE**

The ifIndex should be derived from the snIfIndexLookupTable using the InterfaceId (in OID form), instead of assuming that the ifIndex will always stay persistent across reloads.

On the following interfaces, ifIndex assignments are not persistent across reboots and switchover operations:

- MPLS tunnel interfaces
- Trunk ports
- IP tunnels

### **ifType for interfaces**

On Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices, ifType for all Ethernet interfaces (10/100/1G/10G) returns the value **ethernetCsmacd(6)** as mandated by RFC 2665.

If the command **snmp-server legacy iftype** is configured on the device CLI, ifType returns **gigabitEthernet(117)** or **fastEther(62)**. If the command is not configured (or **no snmp-server legacy iftype** is issued), then ifType returns the value **ethernetCsmacd(6)**.

## Statistics for virtual routing interfaces on 8x10 modules

The ifTable and ifXTable display information for switched and routed packets on virtual routing interface of the 8x10 modules installed on the Brocade MLXe, Brocade NetIron XMR, and Brocade MLX devices. This feature is available on Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices. The **extended-counter routed-switched** command must be configured to enable separate accounting of routed and switched packets on virtual routing interfaces.

### *ifTable attributes*

The following MIB attributes of the ifTable return information for switched and routed packets for the 8x10 modules.

MIB attribute	Physical	Virtual	Loopback	IP tunnel	MPLS tunnel	Trunk
ifInOctets	Yes	Yes	No	No	No	Yes
ifOutOctets	Yes	Yes	No	No	Yes	Yes
ifInUcastPkts	Yes	Yes	No	Yes	No	Yes
ifOutUcastPkts	Yes	Yes	No	No	Yes	Yes
ifInNUcastPkts	Yes	No	No	No	No	Yes
ifInDiscards	Yes	No	No	No	No	Yes
ifInErrors	Yes	No	No	No	No	Yes
ifInUnknownProtos	Yes	No	No	No	No	Yes
ifOutNUcastPkts	Yes	No	No	No	No	Yes
ifOutDiscards	Yes	No	No	No	No	Yes
ifOutErrors	Yes	No	No	No	No	Yes
ifOutQLen	Yes	No	No	No	No	Yes

### *ifXTable attributes*

The following MIB attributes of the ifXTable return information for switched and routed packets for the 8x10 modules.

MIB attribute	Physical	Virtual	Loopback	IP tunnel	MPLS tunnel	Trunk
ifHCInOctets	Yes	Yes	No	No	No	Yes
ifHCOctets	Yes	Yes	No	Yes	Yes	Yes
ifHCInUcastPkts	Yes	Yes	No	Yes	No	Yes
ifHCOUcastPkts	Yes	Yes	No	Yes	Yes	Yes
ifInMulticastPkts	Yes	No	No	No	No	Yes

MIB attribute	Physical	Virtual	Loopback	IP tunnel	MPLS tunnel	Trunk
ifInBroadcastPkts	Yes	No	No	No	No	Yes
ifOutMulticastPkts	Yes	No	No	No	No	Yes
ifOutBroadcastPkts	Yes	No	No	No	No	Yes
ifHCInMulticastPkts	Yes	No	No	No	No	Yes
ifHCInBroadcastPkts	Yes	No	No	No	No	Yes
ifHCOmulticastPkts	Yes	No	No	No	No	Yes
ifHCOBroadcastPkts	Yes	No	No	No	No	Yes

## Preserved SNMP statistics on interfaces

SNMP statistics in the ifTable and ifXTable for physical interfaces on Brocade MLXe and NetIron devices are preserved when the **snmp-server preserve-statistics** command is configured. After configuring **snmp-server preserve-statistics**, the SNMP statistics listed in the following tables are separated from the CLI statistics. When the **clear statistics <interface-type> <interface-id>** command is entered on the CLI, the command clears only CLI statistics, leaving the SNMP statistics intact.

### *IF-MIB (RFC 2863) ifTable objects*

Statistics from the following objects in the ifTable are preserved when the **snmp-server preserve-statistics** command is enabled on the CLI.

ifTable objects	Syntax
ifInOctets	Counter32
ifInUcastPkts	Counter32
ifInNUcastPkts	Counter32
<b>NOTE:</b> This object is deprecated in the 8x10 modules installed on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices.	
ifInDiscards	Counter32
ifInErrors	Counter32
ifInUnknownProtos	Counter32
ifOutOctets	Counter32
ifOutUcastPkts	Counter32
ifOutNUcastPkts	Counter32
<b>NOTE:</b> This object is deprecated in the 8x10 modules installed on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices.	

<b>ifTable objects</b>	<b>Syntax</b>
ifOutDiscards	Counter32
ifOutErrors	Counter32

### *IF-MIB (RFC 2863) ifXTable objects*

Statistics from the following objects in the ifXTable are preserved when the **snmp-server preserve-statistics** command is enabled on the CLI.

<b>ifXTable objects</b>	<b>Syntax</b>
ifInMulticastPkts	Counter32
ifInBroadcastPkts	Counter32
ifOutMulticastPkts	Counter32
ifOutBroadcastPkts	Counter32
ifHCInOctets	Counter64
ifHCInUcastPkts	Counter64
ifHCInMulticastPkts	Counter64
ifHCInBroadcastPkts	Counter64
ifHCOctets	Counter64
ifHCOUcastPkts	Counter64
ifHCOmulticastPkts	Counter64
ifHCOBroadcastPkts	Counter64
snSwIfInOctets	Counter32
snSwIfOutOctets	Counter32

### *EthernetLike-MIB (RFC 2665) dot3StatsTable objects (Ethernet ports only)*

Statistics from the following objects in the dot3StatsTable are preserved when the **snmp-server preserve-statistics** command is enabled on the CLI.

<b>dot3StatsTable objects</b>	<b>Syntax</b>
dot3StatsIndex	Interface Index
dot3StatsAlignmentErrors	Counter32
dot3StatsFCSErrors	Counter32
dot3StatsFrameTooLongs	Counter32
dot3StatsLateCollisions	Counter32
dot3StatsSingleCollisionFrames	Counter32
dot3StatsMultipleCollisionFrames	Counter32
dot3StatsSQETestErrors	Counter32
dot3StatsDeferredTransmissions	Counter32

<b>dot3StatsTable objects</b>	<b>Syntax</b>
dot3StatsExcessiveCollisions	Counter32
dot3StatsInternalMacTransmitErrors	Counter32
dot3StatsCarrierSenseErrors	Counter32
dot3StatsInternalMacReceiveErrors	Counter32
dot3StatsEtherChipSet	Object Identifier
dot3StatsSymbolErrors	Counter32
dot3StatsDuplexStatus	Integer

### ***RMON-MIB (RFC 2819) etherStatsTable objects (Ethernet ports only)***

Statistics from the following objects in the etherStatsTable are preserved when the **snmp-server preserve-statistics** command is enabled on the CLI.

<b>etherStatsTable objects</b>	<b>Syntax</b>
etherStatsDropEvents	Counter32
etherStatsOctets	Counter32
etherStatsPkts	Counter32
etherStatsBroadcastPkts	Counter32
etherStatsMulticastPkts	Counter32
etherStatsCRCAlignErrors	Counter32
etherStatsUndersizePkts	Counter32
etherStatsOversizePkts	Counter32
etherStatsFragments	Counter32
etherStatsPkts64Octets	Counter32
etherStatsPkts65to127Octets	Counter32
etherStatsPkts128to255Octets	Counter32
etherStatsPkts256to511Octets	Counter32
etherStatsPkts512to1023Octets	Counter32
etherStatsPkts1024to1518Octets	Counter32

## **RFC 2932: IPv4 Multicast Routing MIB**

Support for RFC 2932 is available on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

### **NOTE**

This MIB is not VRF-aware. MIB entries are based on the default VRF IP multicast routing tables.

## IP multicast scalar

Object	Object identifier	Supported?
ipMRouteEnable	1.3.6.1.2.1.83.1.1.1	Yes. Use either the <b>[no] ip multicast-routing</b> or <b>[no] router pim</b> command to configure IP multicast routing on the router.
ipMRouteEntryCount	1.3.6.1.2.1.83.1.1.7	Yes. Use the <b>show ip pim mcache [count]</b> command to display the the number of rows in the ipMRouteTable.

## ipMRouteTable (IP multicast route table)

Use the **show ip pim mcache** CLI command to display the information for the IP multicast route table.

Use the **show ip route** and **show ip mroute** commands to display the route information (ipMRouteRtAddress, ipMRouteRtMask, and ipMRouteRtType).

The SET request is not supported for this table.

Object	Object identifier	Supported?
ipMRouteGroup	1.3.6.1.2.1.83.1.1.2.1.1	Yes
ipMRouteSource	1.3.6.1.2.1.83.1.1.2.1.2	Yes
ipMRouteSourceMask	1.3.6.1.2.1.83.1.1.2.1.3	Yes
ipMRouteUpstreamNeighbor	1.3.6.1.2.1.83.1.1.2.1.4	Yes, but read-only.
ipMRouteInIfIndex	1.3.6.1.2.1.83.1.1.2.1.5	Yes, but read-only.
ipMRouteUpTime	1.3.6.1.2.1.83.1.1.2.1.6	Yes, but read-only.
ipMRouteExpiryTime	1.3.6.1.2.1.83.1.1.2.1.7	Yes, but read-only.
ipMRoutePkts	1.3.6.1.2.1.83.1.1.2.1.8	Yes, but read-only.
ipMRouteDifferentInIfPackets	1.3.6.1.2.1.83.1.1.2.1.9	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.
ipMRouteOctets	1.3.6.1.2.1.83.1.1.2.1.10	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.
ipMRouteProtocol	1.3.6.1.2.1.83.1.1.2.1.11	Yes, but read-only.
ipMRouteRtProto	1.3.6.1.2.1.83.1.1.2.1.12	Yes, but read-only.
ipMRouteRtAddress	1.3.6.1.2.1.83.1.1.2.1.13	Yes, but read-only.
ipMRouteRtMask	1.3.6.1.2.1.83.1.1.2.1.14	Yes, but read-only.



Object	Object identifier	Supported?
ipMRouteRtType	1.3.6.1.2.1.83.1.1.2.1.15	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.
ipMRouteHCOctets	1.3.6.1.2.1.83.1.1.2.1.16	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## ipMRouteNextHopTable (IP multicast route next hop table)

In this table, “*NextHop*” refers to the downstream traffic.

The following CLI commands display information about the objects in the IP multicast route next hop table:

- show ip pim mcache
- show ip pim neighbor

The SET request is not supported for this table.

Object	Object identifier	Supported?
ipMRouteNextHopGroup	1.3.6.1.2.1.83.1.1.3.1.1	Yes
ipMRouteNextHopSource	1.3.6.1.2.1.83.1.1.3.1.2	Yes
ipMRouteNextHopSourceMask	1.3.6.1.2.1.83.1.1.3.1.3	Yes
ipMRouteNextHopIfIndex	1.3.6.1.2.1.83.1.1.3.1.4	Yes
ipMRouteNextHopAddress	1.3.6.1.2.1.83.1.1.3.1.5	Yes
ipMRouteNextHopState	1.3.6.1.2.1.83.1.1.3.1.6	Yes, but read-only. Always shows forwarding(2).
ipMRouteNextHopUpTime	1.3.6.1.2.1.83.1.1.3.1.7	Yes, but read-only.
ipMRouteNextHopExpiryTime	1.3.6.1.2.1.83.1.1.3.1.8	Yes, but read-only.
ipMRouteNextHopClosestMember Hop	1.3.6.1.2.1.83.1.1.3.1.9	Yes, but read-only.

Object	Object Identifier	Supported?
ipMRouteNextHopProtocol	1.3.6.1.2.1.83.1.1.3.1.10	Yes, but read-only.
ipMRouteNextHopPkts	1.3.6.1.2.1.83.1.1.3.1.11	No

**NOTE:** This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## ipMRouteInterfaceTable (IP multicast route interface table)

This is the IP multicast route table for interfaces.

The **show ip pim interface** command is used to display information about this table.

The following interface-level commands are used to create an entry to the IP multicast route interface table:

- ip pim
- ip pim-sparse
- ip pim ttl-threshold <value>

The SET request is not supported for this table.

Object	Object Identifier	Supported?
ipMRouteInterfaceIndex	1.3.6.1.2.1.83.1.1.4.1.1	Yes
ipMRouteInterfaceTtl	1.3.6.1.2.1.83.1.1.4.1.2	Yes, but read-only.
ipMRouteInterfaceProtocol	1.3.6.1.2.1.83.1.1.4.1.3	Yes, but read-only.
ipMRouteInterfaceRateLimit	1.3.6.1.2.1.83.1.1.4.1.4	No
ipMRouteInterfaceInMcastOctets	1.3.6.1.2.1.83.1.1.4.1.5	No

**NOTE:** This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

ipMRouteInterfaceOutMcastOctets	1.3.6.1.2.1.83.1.1.4.1.6	No
---------------------------------	--------------------------	----

**NOTE:** This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Object	Object identifier	Supported?
ipMRouteInterfaceHCInMcastOctets	1.3.6.1.2.1.83.1.1.4.1.7	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.
ipMRouteInterfaceHCOutMcastOctets	1.3.6.1.2.1.83.1.1.4.1.8	No <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

**NOTE**

The ipMRouteBoundaryTable and ipMRouteScopeNameTable tables are not supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

## RFC 2933: Internet Group Management Protocol MIB

### Support on FastIron devices

FastIron devices support the following objects from RFC 2933.

#### *igmpInterfaceTable (IGMP interface table)*

Object	Object identifier
igmpInterfaceStatus	1.3.6.1.2.1.85.1.1.1.3
igmpInterfaceQuerier	1.3.6.1.2.1.85.1.1.1.5

#### *igmpCacheTable (IGMP cache table)*

Object	Object identifier
igmpCacheSelf	1.3.6.1.2.1.85.1.2.1.3
igmpCacheLastReporter	1.3.6.1.2.1.85.1.2.1.4
igmpCacheStatus	1.3.6.1.2.1.85.1.2.1.7

### Support on other devices

RFC 2933 is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices:

The following limitations apply to the support of RFC 2933 on the Brocade MLXe devices:

- IGMP Snooping is not supported.
- Tables are read-only.
- VRF support is only for the default VRF.
- Data is available only for physical ports.

### igmpInterfaceTable (IGMP interface table)

The **show ip igmp interface** command is used to display information about the IGMP interface table.

The SET request is not supported for this table.

Object	Object identifier	Supported?
igmpInterfaceIndex	1.3.6.1.2.1.85.1.1.1.1	Yes
igmpInterfaceQueryInterval	1.3.6.1.2.1.85.1.1.1.2	Yes, but read-only
igmpInterfaceStatus	1.3.6.1.2.1.85.1.1.1.3	Yes, always returns "active". <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade Netron XMR, Brocade Netron CES, and Brocade Netron CER series devices, the constant value for this object is active(1).
igmpInterfaceVersion	1.3.6.1.2.1.85.1.1.1.4	Yes, but read-only.
igmpInterfaceQuerier	1.3.6.1.2.1.85.1.1.1.5	Yes, but read-only.
igmpInterfaceQueryMaxResponseTime	1.3.6.1.2.1.85.1.1.1.6	Yes, but read-only.
igmpInterfaceQuerierUpTime	1.3.6.1.2.1.85.1.1.1.7	Yes, but read-only.
igmpInterfaceQuerierExpiryTime	1.3.6.1.2.1.85.1.1.1.8	Yes, but read-only.
igmpInterfaceVersion1QuerierTimer	1.3.6.1.2.1.85.1.1.1.9	No. <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade Netron XMR, Brocade Netron CES, and Brocade Netron CER series devices.
igmpInterfaceWrongVersionQueries	1.3.6.1.2.1.85.1.1.1.10	No. <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade Netron XMR, Brocade Netron CES, and Brocade Netron CER series devices.
igmpInterfaceJoins	1.3.6.1.2.1.85.1.1.1.11	Yes, but read-only.
igmpInterfaceProxyIndex	1.3.6.1.2.1.85.1.1.1.12	No. Returns "0".
igmpInterfaceGroups	1.3.6.1.2.1.85.1.1.1.13	Yes, but read-only.

Object	Object identifier	Supported?
igmpInterfaceRobustness	1.3.6.1.2.1.85.1.1.1.14	Yes, but read-only.
igmpInterfaceLastMemQueryInterval	1.3.6.1.2.1.85.1.1.1.15	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, the constant value for this object is Global.

## igmpCacheTable (IGMP cache table)

Use the **show ip igmp group** command to display information about the IGMP cache table.

The SET request is not supported for this table.

Object	Object identifier	Supported?
igmpCacheAddress	1.3.6.1.2.1.85.1.2.1.1	Yes
igmpCacheSelfIndex	1.3.6.1.2.1.85.1.2.1.2	Yes
igmpCacheSelf	1.3.6.1.2.1.85.1.2.1.3	Yes, but read-only.
igmpCacheLastReporter	1.3.6.1.2.1.85.1.2.1.4	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, the constant value for this object is 0.
igmpCacheUpTime	1.3.6.1.2.1.85.1.2.1.5	Yes, but read-only.
igmpCacheExpiryTime	1.3.6.1.2.1.85.1.2.1.6	Yes, but read-only.
igmpCacheStatus	1.3.6.1.2.1.85.1.2.1.7	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, the constant value for this object is active(1).
igmpCacheVersion1HostTimer	1.3.6.1.2.1.85.1.2.1.8	Yes, but read-only.

## RFC 2934: Protocol Independent Multicast MIB for IPv4

### Support on FastIron devices

FastIron devices support the following objects from RFC 2934. FastIron devices do not support PIM Border.

Object	Object Identifier
pimJoinPruneInterval	1.3.6.1.3.61.1.1.1

### *pimInterfaceTable (PIM interface table)*

Object	Object Identifier
pimInterfaceIndex	1.3.6.1.3.61.1.1.2.1.1
pimInterfaceAddress	1.3.6.1.3.61.1.1.2.1.2
pimInterfaceNetMask	1.3.6.1.3.61.1.1.2.1.3
pimInterfaceMode	1.3.6.1.3.61.1.1.2.1.4
pimInterfaceDR	1.3.6.1.3.61.1.1.2.1.5
pimInterfaceHelloInterval	1.3.6.1.3.61.1.1.2.1.6
pimInterfaceStatus	1.3.6.1.3.61.1.1.2.1.7
pimInterfaceJoinPruneInterval	1.3.6.1.3.61.1.1.2.1.8
pimInterfaceBSRPreference	1.3.6.1.3.61.1.1.2.1.9

### *pimNeighborTable (PIM neighbor table)*

Object	Object Identifier
pimNeighborAddress	1.3.6.1.3.61.1.1.3.1.1
pimNeighborIndex	1.3.6.1.3.61.1.1.3.1.2

### *pimComponentTable (PIM component table)*

Object	Object Identifier
pimComponentIndex	1.3.6.1.3.61.1.1.12.1.1
pimComponentBSRAddress	1.3.6.1.3.61.1.1.12.1.2
pimComponentBSRExpiryTime	1.3.6.1.3.61.1.1.12.1.3

## Support on other devices

RFC 2934 is supported on the following other Brocade devices:

- Brocade NetIron XMR devices
- Brocade MLX devices
- Brocade MLXe devices
- Brocade NetIron CES and Brocade NetIron CER series devices

### NOTE

On the Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices, only default VRF is supported.

Support for RFC 2934 in these devices is presented in the following sections.

Object	Object identifier	Supported?
pimJoinPruneInterval	1.3.6.1.3.61.1.1.1	Yes, but read-only.

## pimInterfaceTable (PIM interface table)

Use the **show ip pim interface** command to display information about the PIM interface table.

The SET request is not supported for this table.

Object	Object identifier	Supported?
pimInterfaceIndex	1.3.6.1.3.61.1.1.2.1.1	Yes
pimInterfaceAddress	1.3.6.1.3.61.1.1.2.1.2	Yes, but read-only.
pimInterfaceNetMask	1.3.6.1.3.61.1.1.2.1.3	Yes, but read-only.
pimInterfaceMode	1.3.6.1.3.61.1.1.2.1.4	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, only dense and sparse modes are supported.
pimInterfaceDR	1.3.6.1.3.61.1.1.2.1.5	Yes, but read-only.
pimInterfaceHelloInterval	1.3.6.1.3.61.1.1.2.1.6	Yes, but read-only.
pimInterfaceStatus	1.3.6.1.3.61.1.1.2.1.7	Yes, but read-only. Returns "active".
pimInterfaceJoinPruneInterval	1.3.6.1.3.61.1.1.2.1.8	Yes, but read-only.
pimInterfaceCBSRPreference	1.3.6.1.3.61.1.1.2.1.9	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, the constant value for this object is 0.

## pimNeighborTable (PIM neighbor table)

Use the **show ip pim neighbor** command to display information about the PIM neighbor table.

The SET request is not supported for this table.

Object	Object identifier	Supported?
pimNeighborAddress	1.3.6.1.3.61.1.1.3.1.1	Yes
pimNeighborIfIndex	1.3.6.1.3.61.1.1.3.1.2	Yes, but read-only.
pimNeighborUpTime	1.3.6.1.3.61.1.1.3.1.3	Yes, but read-only.

Object	Object identifier	Supported?
pimNeighborExpiryTime	1.3.6.1.3.61.1.1.3.1.4	Yes, but read-only.
pimNeighborMode	1.3.6.1.3.61.1.1.3.1.5	Yes, but read-only.

## pimIpMRouteTable (PIM IP multicast route table)

### NOTE

The PIM IP multicast route table MIBs are not supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

The **show ip pim mcache** command displays information about the PIM IP multicast route table.

Object	Object identifier	Supported?
ipMRouteGroup	1.3.6.1.2.1.83.1.1.2.1.1	Yes, but read-only.
ipMRouteSource	1.3.6.1.2.1.83.1.1.2.1.2	Yes, but read-only.
ipMRouteSourceMask	1.3.6.1.2.1.83.1.1.2.1.3	Yes, but read-only.
pimIpMRouteUpstreamAssertTimer	1.3.6.1.3.61.1.1.4.1.1	Yes, but read-only.
pimIpMRouteAssertMetric	1.3.6.1.3.61.1.1.4.1.2	Yes, but read-only.
pimIpMRouteAssertMetricPref	1.3.6.1.3.61.1.1.4.1.3	Yes, but read-only.
pimIpMRouteAssertRPTBit	1.3.6.1.3.61.1.1.4.1.4	No. <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.
pimIpMRouteFlags	1.3.6.1.3.61.1.1.4.1.5	No. <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## pimIpMRouteNextHopTable (PIM IP multicast route next hop table)

The **show ip pim mcache sg** command displays information about the PIM IP multicast route next hop table.

Object	Object identifier	Supported?
ipMRouteNextHopGroup	1.3.6.1.2.1.83.1.1.3.1.1	Yes
ipMRouteNextHopSource	1.3.6.1.2.1.83.1.1.3.1.2	Yes
ipMRouteNextHopSourceMask	1.3.6.1.2.1.83.1.1.3.1.3	Yes
ipMRouteNextHopIfIndex	1.3.6.1.2.1.83.1.1.3.1.4	Yes



Object	Object Identifier	Supported?
ipMRouteNextHopAddress	1.3.6.1.2.1.83.1.1.3.1.5	Yes
pimIpMRouteNextHopPrune Reason	1.3.6.1.3.61.1.1.7.1.2	Yes, but read-only. <b>NOTE:</b> On Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, only read-only is supported for this object.

## pimRpTable (PIM RP table)

### NOTE

On the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, this table has been replaced by [“pimRpSetTable \(PIM RP set table\)”](#)

Object	Object Identifier	Supported?
pimRPGroupAddress	1.3.6.1.3.61.1.1.5.1.1	Yes, but read-only and only active groups.
pimRPAddress	1.3.6.1.3.61.1.1.5.1.2	Yes, but read-only.
pimRPState	1.3.6.1.3.61.1.1.5.1.3	Yes, but read-only and value is always up(1).
pimRPStateTimer	1.3.6.1.3.61.1.1.5.1.4	No.
pimRPLastChange	1.3.6.1.3.61.1.1.5.1.5	No.
pimRPRowStatus	1.3.6.1.3.61.1.1.5.1.6	Yes, but read-only.

## pimRpSetTable (PIM RP set table)

Use the `show ip pim rp-set` command to display information about the PIM RP set table.

Object	Object Identifier	Supported?
pimRpSetGroupAddress	1.3.6.1.3.61.1.1.6.1.1	Yes
pimRpSetGroupMask	1.3.6.1.3.61.1.1.6.1.2	Yes
pimRpSetAddress	1.3.6.1.3.61.1.1.6.1.3	Yes
pimRpSetHoldTime	1.3.6.1.3.61.1.1.6.1.4	Yes, but read-only.
pimRpSetExpiryTime	1.3.6.1.3.61.1.1.6.1.5	Yes, but read-only.
pimRpSetComponent	1.3.6.1.3.61.1.1.6.1.6	Yes, but only one PIM domain is supported.

## pimCandidateRPTable (PIM candidate-RP table)

The `show ip pim bsr` command displays information about the PIM candidate-RP table.

Object	Object Identifier	Supported?
pimCandidateRPGroupAddress	1.3.6.1.3.61.1.1.11.1.1	Yes
pimCandidateRPGroupMask	1.3.6.1.3.61.1.1.11.1.2	Yes.

Object	Object identifier	Supported?
pimCandidateRPAAddress	1.3.6.1.3.61.1.1.11.1.3	Yes, but read-only.
pimCandidateRPRowStatus	1.3.6.1.3.61.1.1.11.1.4	Yes, but read-only. Returns "active".

### pimComponentTable (PIM component table)

This table contains objects specific to PIM domain and has only one row for each domain to which the router is connected.

Use the `ip pim border` CLI command at the interface level to stop the flooding of the bootstrap messages.

The `show ip pim bsr` command displays information about the PIM component table.

Object	Object identifier	Supported?
pimComponentIndex	1.3.6.1.3.61.1.1.12.1.1	Yes
pimComponentBSRAddress	1.3.6.1.3.61.1.1.12.1.2	Yes, but read-only.
pimComponentBSRExpiryTime	1.3.6.1.3.61.1.1.12.1.3	Yes, but read-only.
pimComponentCRPHoldTime	1.3.6.1.3.61.1.1.12.1.4	Yes, but read-only.
pimComponentStatus	1.3.6.1.3.61.1.1.12.1.5	Yes, but read-only. Returns "active".

## RFC 3176: InMon Corporation’s sFlow: A Method for Monitoring Traffic in Switched and Routed Networks

RFC 3176 MIBs enable you to configure the sFlow Export feature. Support for this RFC is available on the following devices:

- Brocade MLX devices
- Brocade MLXe devices
- Brocade NetIron XMR
- Brocade NetIron CES and Brocade NetIron CER series devices

The following groups from RFC 3176 are supported in the devices.

Object	Object identifier	Description
sFlowAgent	1.3.6.1.4.1.4300.1.1	The sFlow agent sampler.
sFlowVersion	1.3.6.1.4.1.4300.1.1.1	Returns a version string (for example, "1.2; Brocade").
sFlowAgentAddressType	1.3.6.1.4.1.4300.1.1.2	Returns value 1 (IPv4).
sFlowAgentAddress	1.3.6.1.4.1.4300.1.1.3	Management IP.
sFlowTable	1.3.6.1.4.1.4300.1.1.4	sFlow Table.
sFlowDataSource	1.3.6.1.4.1.4300.1.1.4.1.1	ifIndex of sFlow port.

Object	Object identifier	Description
sFlowOwner	1.3.6.1.4.1.4300.1.1.4.1.2	Always null. Not supported in the CLI.
sFlowTimeout	1.3.6.1.4.1.4300.1.1.4.1.3	Always 0. Not supported in the CLI.
sFlowPacketSamplingRate	1.3.6.1.4.1.4300.1.1.4.1.4	Port sampling rate. Set this value to 0 to disable sFlow for a port.
sFlowCounterSamplingInterval	1.3.6.1.4.1.4300.1.1.4.1.5	Global counter poll interval.
sFlowMaximumHeaderSize	1.3.6.1.4.1.4300.1.1.4.1.6	Always 128.
sFlowMaximumDatagramSize	1.3.6.1.4.1.4300.1.1.4.1.7	Always 1400.
sFlowCollectorAddressType	1.3.6.1.4.1.4300.1.1.4.1.8	Always 1 (IPv4).
sFlowCollectorAddress	1.3.6.1.4.1.4300.1.1.4.1.9	Address of first collector. For other collectors, use snSflowCollectorTable. (Refer to <a href="#">“sFlow collector table”</a> on page 272.)
sFlowCollectorPort	1.3.6.1.4.1.4300.1.1.4.1.10	Port of first collector. For other collectors, use snSflowCollectorTable. (Refer to <a href="#">“sFlow collector table”</a> on page 272.)
sFlowDatagramVersion	1.3.6.1.4.1.4300.1.1.4.1.11	Always 4.

## RFC 3289: Management Information Base for the Differentiated Services Architecture

The Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices support RFC 3289, Management Information Base for the Differentiated Services Architecture.

### diffServMultiFieldClfrTable

The following table defines the MIB objects that describe a classifier element for matching on various fields of an IP address and upper-layer protocol header.

#### NOTE

The following table supports only the SNMP GET and GET-NEXT options.

Object	Object identifier	Access
diffServMultiFieldClfrId	1.3.6.1.2.1.97.1.2.6.1.1	Incremental ID.
diffServMultiFieldClfrAddrType	1.3.6.1.2.1.97.1.2.6.1.2	The type of an IP address used by the classifier entry. <ul style="list-style-type: none"> <li>unknown(0)</li> <li>ipv4(1)</li> <li>ipv6(2)</li> </ul>

Object	Object identifier	Access
diffServMultiFieldClfrDstAddr	1.3.6.1.2.1.97.1.2.6.1.3	Maps to the destination address.
diffServMultiFieldClfrDstPrefixLength	1.3.6.1.2.1.97.1.2.6.1.4	Maps to the destination address prefix length.
diffServMultiFieldClfrSrcAddr	1.3.6.1.2.1.97.1.2.6.1.5	Maps to the source address.
diffServMultiFieldClfrSrcPrefixLength	1.3.6.1.2.1.97.1.2.6.1.6	Maps to the source address prefix length.
diffServMultiFieldClfrDscp	1.3.6.1.2.1.97.1.2.6.1.7	Not supported.
diffServMultiFieldClfrFlowId	1.3.6.1.2.1.97.1.2.6.1.8	Not supported.
diffServMultiFieldClfrProtocol	1.3.6.1.2.1.97.1.2.6.1.9	Maps to a protocol.
diffServMultiFieldClfrDstL4PortMin	1.3.6.1.2.1.97.1.2.6.1.10	Maps to the destination port minimum.
diffServMultiFieldClfrDstL4PortMax	1.3.6.1.2.1.97.1.2.6.1.11	Maps to the destination port maximum.
diffServMultiFieldClfrSrcL4PortMin	1.3.6.1.2.1.97.1.2.6.1.12	Maps to the source port minimum.
diffServMultiFieldClfrSrcL4PortMax	1.3.6.1.2.1.97.1.2.6.1.13	Maps to the source port maximum.
diffServMultiFieldClfrStorage	1.3.6.1.2.1.97.1.2.6.1.14	Always returns volatile(2).
diffServMultiFieldClfrStatus	1.3.6.1.2.1.97.1.2.6.1.15	Always returns active(1).

**NOTE**

The diffServDataPathTable, diffServClfrTable, diffServClfrElementTable, diffServMeterTable, diffServTBPParamTable, diffServActionTable, diffServDscpMarkActTable, diffServCountActTable, diffServAlgDropTable, diffServRandomDropTable, diffServQTable, diffServSchedulerTable, diffServMinRateTable, and diffServMaxRateTable are not supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

## RFC 3813: Multiprotocol Label Switching (MPLS) Label Switching Router (LSR) Management Information Base (MIB)

The Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices support RFC 3813, Multiprotocol Label Switching (MPLS) Label Switching Router (LSR).

**NOTE**

Only the SNMP GET and GET-NEXT are supported. The SNMP SET is not supported for all the LSR MIB objects, except the mplsXCNotificationsEnable object.

## MPLS interface table objects

The following table lists the MPLS interface table objects.

Object	Object identifier	Supported?
mplsInterfaceIndex	1.3.6.1.2.1.10.166.2.1.1.1.1	Yes
mplsInterfaceLabelMinIn	1.3.6.1.2.1.10.166.2.1.1.1.2	No
mplsInterfaceLabelMaxIn	1.3.6.1.2.1.10.166.2.1.1.1.3	No
mplsInterfaceLabelMinOut	1.3.6.1.2.1.10.166.2.1.1.1.4	No
mplsInterfaceLabelMaxOut	1.3.6.1.2.1.10.166.2.1.1.1.5	No
mplsInterfaceTotalBandwidth	1.3.6.1.2.1.10.166.2.1.1.1.6	Yes
mplsInterfaceAvailableBandwidth	1.3.6.1.2.1.10.166.2.1.1.1.7	Yes
mplsInterfaceLabelParticipationType	1.3.6.1.2.1.10.166.2.1.1.1.8	Yes

## MPLS in-segment table objects

The following table lists the MPLS in-segment table objects.

Object	Object identifier	Supported?
mplsInSegmentIndex	1.3.6.1.2.1.10.166.2.1.4.1.1	Yes
mplsInSegmentInterface	1.3.6.1.2.1.10.166.2.1.4.1.2	No
mplsInSegmentLabel	1.3.6.1.2.1.10.166.2.1.4.1.3	Yes
mplsInSegmentLabelPtr	1.3.6.1.2.1.10.166.2.1.4.1.4	Yes
mplsInSegmentNPop	1.3.6.1.2.1.10.166.2.1.4.1.5	Yes
mplsInSegmentAddrFamily	1.3.6.1.2.1.10.166.2.1.4.1.6	Yes
mplsInSegmentXCIndex	1.3.6.1.2.1.10.166.2.1.4.1.7	Yes
mplsInSegmentOwner	1.3.6.1.2.1.10.166.2.1.4.1.8	Yes
mplsInSegmentTrafficParamPtr	1.3.6.1.2.1.10.166.2.1.4.1.9	Yes
mplsInSegmentRowStatus	1.3.6.1.2.1.10.166.2.1.4.1.10	Yes
mplsInSegmentStorageType	1.3.6.1.2.1.10.166.2.1.4.1.11	Yes

## MPLS in-segment performance table objects

The following table lists the MPLS in-segment performance table objects.

Object	Object identifier	Supported?
mplsInSegmentPerfOctets	1.3.6.1.2.1.10.166.2.1.5.1.1	No
mplsInSegmentPerfPackets	1.3.6.1.2.1.10.166.2.1.5.1.2	Yes
mplsInSegmentPerfErrors	1.3.6.1.2.1.10.166.2.1.5.1.3	No
mplsInSegmentPerfDiscards	1.3.6.1.2.1.10.166.2.1.5.1.4	No

Object	Object identifier	Supported?
mplsInSegmentPerfHCOctets	1.3.6.1.2.1.10.166.2.1.5.1.5	No
mplsInSegmentPerfDiscontinuityTime	1.3.6.1.2.1.10.166.2.1.5.1.6	No

### MPLS out-segment table objects

The following table lists the MPLS out-segment table objects.

Object	Object identifier	Supported?
mplsOutSegmentIndex	1.3.6.1.2.1.10.166.2.1.7.1.1	Yes
mplsOutSegmentInterface	1.3.6.1.2.1.10.166.2.1.7.1.2	No
mplsOutSegmentPushTopLabel	1.3.6.1.2.1.10.166.2.1.7.1.3	Yes
mplsOutSegmentTopLabel	1.3.6.1.2.1.10.166.2.1.7.1.4	Yes
mplsOutSegmentTopLabelPtr	1.3.6.1.2.1.10.166.2.1.7.1.5	Yes
mplsOutSegmentNextHopAddrType	1.3.6.1.2.1.10.166.2.1.7.1.6	Yes
mplsOutSegmentNextHopAddr	1.3.6.1.2.1.10.166.2.1.7.1.7	Yes
mplsOutSegmentXCIndex	1.3.6.1.2.1.10.166.2.1.7.1.8	Yes
mplsOutSegmentOwner	1.3.6.1.2.1.10.166.2.1.7.1.9	Yes
mplsOutSegmentTrafficParamPtr	1.3.6.1.2.1.10.166.2.1.7.1.10	Yes
mplsOutSegmentRowStatus	1.3.6.1.2.1.10.166.2.1.7.1.11	Yes
mplsOutSegmentStorageType	1.3.6.1.2.1.10.166.2.1.7.1.12	Yes

### MPLS cross-connect table objects

The following table lists the MPLS cross-connect table objects.

Object	Object identifier	Supported?
mplsXCIndex	1.3.6.1.2.1.10.166.2.1.10.1.1	Yes
mplsXCInSegmentIndex	1.3.6.1.2.1.10.166.2.1.10.1.2	Yes
mplsXCOutSegmentIndex	1.3.6.1.2.1.10.166.2.1.10.1.3	Yes
mplsXCLspld	1.3.6.1.2.1.10.166.2.1.10.1.4	Yes
mplsXCLabelStackIndx	1.3.6.1.2.1.10.166.2.1.10.1.5	Yes
mplsXCOwner	1.3.6.1.2.1.10.166.2.1.10.1.6	Yes
mplsXCRowStatus	1.3.6.1.2.1.10.166.2.1.10.1.7	Yes
mplsXCStorageType	1.3.6.1.2.1.10.166.2.1.10.1.8	Yes
mplsXCAdminStatus	1.3.6.1.2.1.10.166.2.1.10.1.9	Yes
mplsXCOperStatus	1.3.6.1.2.1.10.166.2.1.10.1.10	Yes

The tables mplsInterfacePerfTable, mplsOutSegmentPerfTable, mplsLabelStackTable, and mplsInSegmentMapTable are not supported.

## MPLS label stack scalar object

The following table lists the MPLS label stack scalar objects. The scalar objects `mplsInSegmentIndexNext`, `mplsOutSegmentIndexNext`, `mplsXCIndexNext`, and `mplsLabelStackIndexNext` are not supported.

Object	Object identifier	Supported?
<code>mplsMaxLabelStackDepth</code>	1.3.6.1.2.1.10.166.2.1.11	Yes. Always returns the maximum label stack depth of 3.

## RFC 3815: Definitions of Managed Objects for the Multiprotocol Label Switching (MPLS), Label Distribution Protocol (LDP)

The Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices support RFC 3815, Definitions of Managed Objects for the Multiprotocol Label Switching (MPLS), and Label Distribution Protocol (LDP).

Support for this MIB enables configuration and monitoring of the LDP.

### mplsLdpLsr objects

Object	Object identifier	Supported?
<code>mplsLdpLsrId</code>	1.3.6.1.2.1.10.166.4.1.1	Yes
<code>mplsLdpLsrLoopDetectionCapable</code>	1.3.6.1.2.1.10.166.4.1.2	Returns none(1) or hopCountAndPathVector(5).

### mplsLdpEntity objects

Object	Object identifier	Supported?
<code>mplsLdpEntityLastChange</code>	1.3.6.1.2.1.10.166.4.1.2.1	Always returns 0.
<code>mplsLdpEntityIndexNext</code>	1.3.6.1.2.1.10.166.4.1.2.2	Always returns 0.

### mplsLdpEntity table

This `mplsLdpEntity` table contains information about MPLS Label Distribution Protocol Entities which exist on this Label Switching Router (LSR) or Label Edge Router (LER).

#### NOTE

The following table currently supports the read-only access.

## 2 Supported Standard MIBs

Object	Object identifier	Supported?
mplsLdpEntityLdpld	1.3.6.1.2.1.10.166.4.1.2.3.1.1	Index
mplsLdpEntityIndex	1.3.6.1.2.1.10.166.4.1.2.3.1.2	Index
mplsLdpEntityProtocolVersion	1.3.6.1.2.1.10.166.4.1.2.3.1.3	Yes
mplsLdpEntityAdminStatus	1.3.6.1.2.1.10.166.4.1.2.3.1.4	The administrative status of the LDP Entity. The values are: <ul style="list-style-type: none"> <li>• up(1) mapped to enable(1)</li> <li>• down(2) or testing(3) mapped to disable(2)</li> </ul>
mplsLdpEntityOperStatus	1.3.6.1.2.1.10.166.4.1.2.3.1.5	Displays the operational status of this LDP Entity. The values are: <ul style="list-style-type: none"> <li>• up(1) mapped to enabled(2)</li> <li>• down(2) mapped to disabled(3)</li> <li>• testing(3) mapped to disabled(3)</li> <li>• unknown(4) mapped to unknown(1)</li> <li>• dormant(5) mapped to disabled(3)</li> <li>• notpresent(6) mapped to disabled(3)</li> </ul>
mplsLdpEntityTcpPort	1.3.6.1.2.1.10.166.4.1.2.3.1.6	Yes
mplsLdpEntityUdpDscPort	1.3.6.1.2.1.10.166.4.1.2.3.1.7	Yes
mplsLdpEntityMaxPduLength	1.3.6.1.2.1.10.166.4.1.2.3.1.8	Yes
mplsLdpEntityKeepAliveHoldTimer	1.3.6.1.2.1.10.166.4.1.2.3.1.9	Yes
mplsLdpEntityHelloHoldTimer	1.3.6.1.2.1.10.166.4.1.2.3.1.10	Yes
mplsLdpEntityInitSessionThreshold	1.3.6.1.2.1.10.166.4.1.2.3.1.11	Yes
mplsLdpEntityLabelDistMethod	1.3.6.1.2.1.10.166.4.1.2.3.1.12	Yes
mplsLdpEntityLabelRetentionMode	1.3.6.1.2.1.10.166.4.1.2.3.1.13	Yes
mplsLdpEntityPathVectorLimit	1.3.6.1.2.1.10.166.4.1.2.3.1.14	Yes
mplsLdpEntityHopCountLimit	1.3.6.1.2.1.10.166.4.1.2.3.1.15	Yes
mplsLdpEntityTransportAddrKind	1.3.6.1.2.1.10.166.4.1.2.3.1.16	The IP address of the interface from which hello messages are sent is used as the transport address in the hello message. Returns interface(1).
mplsLdpEntityTargetPeer	1.3.6.1.2.1.10.166.4.1.2.3.1.17	Yes
mplsLdpEntityTargetPeerAddrType	1.3.6.1.2.1.10.166.4.1.2.3.1.18	Displays the type of the internetwork layer address used for the Extended Discovery. Possible types: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• unknown(0)</li> </ul>



Object	Object identifier	Supported?
mplsLdpEntityTargetPeerAddr	1.3.6.1.2.1.10.166.4.1.2.3.1.19	Yes
mplsLdpEntityLabelType	1.3.6.1.2.1.10.166.4.1.2.3.1.20	Yes
mplsLdpEntityDiscontinuityTime	1.3.6.1.2.1.10.166.4.1.2.3.1.21	Yes
mplsLdpEntityStorageType	1.3.6.1.2.1.10.166.4.1.2.3.1.22	Yes
mplsLdpEntityRowStatus	1.3.6.1.2.1.10.166.4.1.2.3.1.23	Yes

## mplsLdpEntityStats table

The mplsLdpEntityStats table is a read-only table which augments the mplsLdpEntityTable. This table keeps statistical information about the LDP Entities on the LSR. This table is read-only.

Object	Object identifier	Supported?
mplsLdpEntityStatsSessionAttempts	1.3.6.1.2.1.10.166.4.1.2.4.1.1	Yes
mplsLdpEntityStatsSessionRejectedNoHelloErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.2	Yes
mplsLdpEntityStatsSessionRejectedAdErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.3	Yes
mplsLdpEntityStatsSessionRejectedMaxPduErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.4	Yes
mplsLdpEntityStatsSessionRejectedLRErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.5	Yes
mplsLdpEntityStatsBadLdpIdentifierErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.6	Yes
mplsLdpEntityStatsBadPduLengthErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.7	Yes
mplsLdpEntityStatsBadMessageLengthErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.8	Yes
mplsLdpEntityStatsBadTlvLengthErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.9	Yes
mplsLdpEntityStatsMalformedTlvValueErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.10	Yes
mplsLdpEntityStatsKeepAliveTimerExpErrors	1.3.6.1.2.1.10.166.4.1.2.4.1.11	Yes
mplsLdpEntityStatsShutdownReceivedNotifications	1.3.6.1.2.1.10.166.4.1.2.4.1.12	Yes
mplsLdpEntityStatsShutdownSentNotifications	1.3.6.1.2.1.10.166.4.1.2.4.1.13	Yes

## mplsLdpSession objects

Object	Object identifier	Supported?
mplsLdpPeerLastChange	1.3.6.1.2.1.10.166.4.1.3.1	Unsupported, Always returns 0.
mplsLdpLspFecLastChange	1.3.6.1.2.1.10.166.4.1.3.2	Yes

## mplsLdpPeer table

The mplsLdpPeer table has information about LDP peers known by Entities in the mplsLdpEntityTable. The information in this table is based on information from the Entity-Peer interaction during session initialization but is not appropriate for the mplsLdpSessionTable, because objects in this table may or may not be used in session establishment.

Object	Object identifier	Supported?
mplsLdpPeerLdpId	1.3.6.1.2.1.10.166.4.1.3.2.1.1	Yes
mplsLdpPeerLabelDistMethod	1.3.6.1.2.1.10.166.4.1.3.2.1.2	Yes
mplsLdpPeerPathVectorLimit	1.3.6.1.2.1.10.166.4.1.3.2.1.3	Yes
mplsLdpPeerTransportAddrType	1.3.6.1.2.1.10.166.4.1.3.2.1.4	Displays the type of the Internet address for the mplsLdpPeerTransportAddr object. Possible types: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• unknown(0)</li> </ul>
mplsLdpPeerTransportAddr	1.3.6.1.2.1.10.166.4.1.3.2.1.5	Yes

### mplsLdpSession table

The mplsLdpSession table contains information of sessions between the LDP Entities and LDP Peers. This table augments the mplsLdpPeerTable. Each row in this table represents a single session. This table is read-only.

Object	Object identifier	Supported?
mplsLdpSessionStateLastChange	1.3.6.1.2.1.10.166.4.1.3.3.1.1	Unsupported. Returns 0.
mplsLdpSessionState	1.3.6.1.2.1.10.166.4.1.3.3.1.2	Yes
mplsLdpSessionRole	1.3.6.1.2.1.10.166.4.1.3.3.1.3	Yes
mplsLdpSessionProtocolVersion	1.3.6.1.2.1.10.166.4.1.3.3.1.4	Yes
mplsLdpSessionKeepAliveHoldTime Rem	1.3.6.1.2.1.10.166.4.1.3.3.1.5	Yes
mplsLdpSessionKeepAliveTime	1.3.6.1.2.1.10.166.4.1.3.3.1.6	Yes
mplsLdpSessionMaxPduLength	1.3.6.1.2.1.10.166.4.1.3.3.1.7	Yes
mplsLdpSessionDiscontinuityTime	1.3.6.1.2.1.10.166.4.1.3.3.1.8	Yes

### mplsLdpSessionStats table

A table of statistics between the LDP Entities and LDP Peers. This table is read-only.

Object	Object identifier	Supported?
mplsLdpSessionStatsUnknownMesType Errors	1.3.6.1.2.1.10.166.4.1.3.4.1.1	Yes
mplsLdpSessionStatsUnknownTlvErrors	1.3.6.1.2.1.10.166.4.1.3.4.1.2	Yes

### mplsLdpHelloAdjacency table

A table of hello adjacencies for the sessions. This table is read-only.

Object	Object identifier	Supported?
mplsLdpHelloAdjacencyIndex	1.3.6.1.2.1.10.166.4.1.3.5.1.1.1	Index
mplsLdpHelloAdjacencyHoldTimeRem	1.3.6.1.2.1.10.166.4.1.3.5.1.1.2	Yes
mplsLdpHelloAdjacencyHoldTime	1.3.6.1.2.1.10.166.4.1.3.5.1.1.3	Yes
mplsLdpHelloAdjacencyType	1.3.6.1.2.1.10.166.4.1.3.5.1.1.4	Yes

## mplsFec objects

A table of MPLS Forwarding Equivalence Class (FEC) objects.

Object	Object identifier	Supported?
mplsFecLastChange	1.3.6.1.2.1.10.166.4.1.3.8.1	Same data as mplsLdpLspFecLastChange.
mplsFecIndexNext	1.3.6.1.2.1.10.166.4.1.3.8.2	Unsupported. Always returns 0.

## mplsFec table

The mplsFec table represents the FEC information associated with an LSP.

### NOTE

This table currently supports read-only access.

Object	Object identifier	Supported?
mplsFecIndex	1.3.6.1.2.1.10.166.4.1.3.8.3.1.1	Index
mplsFecType	1.3.6.1.2.1.10.166.4.1.3.8.3.1.2	Yes
mplsFecAddrPrefixLength	1.3.6.1.2.1.10.166.4.1.3.8.3.1.3	Yes
mplsFecAddrType	1.3.6.1.2.1.10.166.4.1.3.8.3.1.4	Displays the value of this object and the type of the Internet address. Possible values: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• unknown(0)</li> </ul>
mplsFecAddr	1.3.6.1.2.1.10.166.4.1.3.8.3.1.5	Yes
mplsFecStorageType	1.3.6.1.2.1.10.166.4.1.3.8.3.1.6	Yes
mplsFecRowStatus	1.3.6.1.2.1.10.166.4.1.3.8.3.1.7	Yes

## mplsLdpSessionPeerAddr table

The mplsLdpSessionPeerAddr table extends the mplsLdpSessionTable. This table is used to store Label Address information from Label Address Messages received by this LSR from Peers. This table is read-only and should be updated when Label Withdraw Address Messages are received (for example, rows should be deleted as appropriate).

**NOTE**

As more than one address may be contained in a Label Address Message, this table **sparsely augments** the mplsLdpSessionTable's information.

Object	Object identifier	Supported?
mplsLdpSessionPeerAddrIndex	1.3.6.1.2.1.10.166.4.1.3.11.1.1	Index
mplsLdpSessionPeerNextHopAddrType	1.3.6.1.2.1.10.166.4.1.3.11.1.2	Displays the internetwork layer address type of this Next Hop Address as specified in the Label Address Message associated with this Session. Possible values: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• unknown(0)</li> </ul>
mplsLdpSessionPeerNextHopAddr	1.3.6.1.2.1.10.166.4.1.3.11.1.3	Yes

## RFC 4022: Management Information Base for the Transmission Control Protocol (TCP)

The Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices support RFC 4022, Management Information Base for Transmission Control Protocol (TCP). All objects have read-only access, except for the tcpConnectionState object in the tcpConnectionTable. The tcpConnectionState object has read-write access.

## RFC 4087: IP Tunnel MIB

The following tables in RFC 4087 are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

### tunnellfTable

The tunnellfTable contains information on configured tunnels.

Object names	Description
tunnellfLocalAddress	Not supported as it is deprecated.
tunnellfRemoteAddress	Not supported as it is deprecated.
tunnellfEncapsMethod	Read-only. Only 6to4 and GRE tunnel types are supported. This is the encapsulation method used by the tunnel.
tunnellfHopLimit	Read-only. This is the IPv4 time-to-live (TTL) or IPv6 Hop Limit to use in the outer IP header. A value of 0 indicates that the value is copied from the payload's header.
tunnellfSecurity	Read-only. Always returns none(1).
tunnellfTOS	Read-only.

Object names	Description
tunnellfFlowLabel	Read-only. Always returns -1 which indicates a wildcard as suggested by RFC 3595.
tunnellfAddressType	Read-only.
tunnellfLocalInetAddress	Read-only.
tunnellfRemoteInetAddress	Read-only.
tunnellfEncapsLimit	Read-only. This is the maximum number of additional encapsulations permitted for packets undergoing encapsulation at this node. A value of -1 indicates that no limit is present, except as a result of the packet size.

## tunnellnetConfigTable

The tunnellnetConfigTable can be used to map a set of tunnel endpoints to the associated ifIndex value. Every row in the tunnellfTable with a fixed destination address should have a corresponding row in the tunnellnetConfigTable.

Object names	Description
tunnellnetConfigAddressType	Read-only. Index value.
tunnellnetConfigLocalAddress	Read-only. Index value.
tunnellnetConfigRemoteAddress	Read-only. Index value.
tunnellnetConfigEncapsMethod	Read-only. Index value. This is the encapsulation method used by the tunnel. Only 6to4 and GRE tunnel types are supported.
tunnellnetConfigID	Read-only. Index value. Always 1 in 6to4 tunnel type.
tunnellnetConfigIfIndex	Read-only.
tunnellnetConfigStatus	Read-only. Always returns active(1).
tunnellnetConfigStorageType	Read-only. Always returns nonVolatile(3).

## ifTable support

Support for the tunnellfTable and tunnellnetConfigTable affects the ifTable (RFC 1213).

Object names	Description
ifIndex	Read-only. Index value.
ifDescr	Read-only.
ifType	Read-only.
ifMtu	Read-only.
ifSpeed	Not supported.
ifPhysAddress	Not supported.
ifAdminStatus	Read-only.
ifOperStatus	Read-only.
ifLastChange	Read-only. Always returns 0.

## 2 Supported Standard MIBs

Object names	Description
ifSpecific	Read-only. This is a deprecated MIB object.
ifInOctets	Not supported.
ifInUcastPkts	Read-only. Reports total received packet count from tunnel.
ifInNUcastPkts	Not supported. Returns 0. This is a deprecated MIB object.
ifInDiscards	Not supported.
ifInErrors	Not supported.
ifInUnknownProtos	Not supported.
ifOutOctets	Not supported.
ifOutUcastPkts	Read-only. Reports total transmitted packet count to tunnel and total received packet count from tunnel.
ifOutNUcastPkts	Not supported. Returns 0. This is a deprecated MIB object.
ifOutDiscards	Not supported.
ifOutErrors	Not supported.
ifOutQLen	Read-only.

### ifXTable

Support for the tunnelIfTable and tunnelInetConfigTable also affects ifXTable (RFC 2233).

Object names	Description
ifName	Read-only.
ifInMulticastPkts	Not supported. Returns 0.
ifInBroadcastPkts	Not supported. Returns 0.
ifOutMulticastPkts	Not supported. Returns 0.
ifOutBroadcastPkts	Not supported. Returns 0.
ifHCInOctets	Not supported. Returns 0.
ifHCInUcastPkts	Read-only. Reports total received packet count from tunnel.
ifHCInBroadcastPkts	Not supported. Returns 0.
ifHCOctets	Not supported. Returns 0.
ifHCOUcastPkts	Read-only. Reports total received packet count from tunnel.
ifHCOUmulticastPkts	Not supported. Returns 0.
ifHCOUbroadcastPkts	Not supported. Returns 0.
ifLinkUpDownTrapEnable	Read-only. Always returns disabled(2).
ifHighSpeed	Not supported. Returns 0.
ifPromiscuousMode	Read-only. Always returns true(1).
ifConnectorPresent	Read-only. Always returns false(2).

Object names	Description
ifAlias	Read-only.
ifCounterDiscontinuityTime	Read-only.

## RFC 4113: Management Information Base for the User Datagram Protocol (UDP)

RFC 4113, Management Information Base for the User Datagram Protocol (UDP) is supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

All objects have read-only access.

## RFC 4273: Definitions of Managed Objects for BGP-4

RFC 4273 is supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

### NOTE

The definitions of managed objects for BGP-4 (OID 1.3.6.1.2.1.15.3) is used instead of RFC 1567, Definitions of Managed Objects for the Fourth Version of the Border Gateway Protocol (BGP-4) using SMIv2. RFC 1657 has been obsoleted in RFC 4273.

Object group name	Object identifier	Notes
bgpVersion	1.3.6.1.2.1.15.1	The vector of the supported BGP version numbers.
bgpLocalAS	1.3.6.1.2.1.15.2	The local autonomous system number. The Brocade MLXe and NetIron devices return "AS_TRANS (23456)" if the number is greater than 16 bits.
bgpPeerTable	1.3.6.1.2.1.15.3	The bgpPeerRemoteAs object is the remote autonomous system number received in the BGP OPEN message. The Brocade MLXe and NetIron devices return "AS_TRANS (23456)" for this object if the number is greater than 16 bits.
bgpPeerEntry	1.3.6.1.2.1.15.3.1	-
bgpPeerIdentifier	1.3.6.1.2.1.15.3.1.1	-
bgpPeerState	1.3.6.1.2.1.15.3.1.2	-
bgpPeerAdminStatus	1.3.6.1.2.1.15.3.1.3	-
bgpPeerNegotiatedVersion	1.3.6.1.2.1.15.3.1.4	-
bgpPeerLocalAddr	1.3.6.1.2.1.15.3.1.5	-
bgpPeerLocalPort	1.3.6.1.2.1.15.3.1.6	-

## 2 Supported Standard MIBs

Object group name	Object identifier	Notes
bgpPeerRemoteAddr	1.3.6.1.2.1.15.3.1.7	-
bgpPeerRemotePort	1.3.6.1.2.1.15.3.1.8	-
bgpPeerRemoteAs	1.3.6.1.2.1.15.3.1.9	-
bgpPeerInUpdates	1.3.6.1.2.1.15.3.1.10	-
bgpPeerOutUpdates	1.3.6.1.2.1.15.3.1.11	-
bgpPeerInTotalMessages	1.3.6.1.2.1.15.3.1.12	-
bgpPeerOutTotalMessages	1.3.6.1.2.1.15.3.1.13	-
bgpPeerLastError	1.3.6.1.2.1.15.3.1.14	-
bgpPeerFsmEstablishedTransitions	1.3.6.1.2.1.15.3.1.15	-
bgpPeerFsmEstablishedTime	1.3.6.1.2.1.15.3.1.16	-
bgpPeerConnectRetryInterval	1.3.6.1.2.1.15.3.1.17	-
bgpPeerHoldTime	1.3.6.1.2.1.15.3.1.18	-
bgpPeerKeepAlive	1.3.6.1.2.1.15.3.1.19	-
bgpPeerHoldTimeConfigured	1.3.6.1.2.1.15.3.1.20	-
bgpPeerKeepAliveConfigured	1.3.6.1.2.1.15.3.1.21	-
bgpPeerMinASOriginationInterval	1.3.6.1.2.1.15.3.1.22	-
bgpPeerMinRouteAdvertisementInterval	1.3.6.1.2.1.15.3.1.23	-
bgpPeerInUpdateElapsedTime	1.3.6.1.2.1.15.3.1.24	-
bgp4PathAttrTable	1.3.6.1.2.1.15.6	This table is supported on the Brocade MLXe and NetIron devices.
bgp4PathAttrASPathSegment	1.3.6.1.2.1.15.6.1.5	This object is the sequence of AS path segments. Each AS path segment is represented by a triplet of <type>, <length>, and <value>. The Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices return "AS_TRANS" if the AS number is greater than 2 bytes.
bgp4PathAttrAggregatorAS	1.3.6.1.2.1.15.6.1.10	The AS number of the last BGP4 speaker that performed route aggregation. A value of zero (0) indicates the absence of this attribute. The Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices return "AS_TRANS (23456)" for this object if remote AS is greater than 16 bits.

## draft-ietf-idr-bgp4-mibv2-12 MIB

The following section of draft-ietf-idr-bgp4-mibv2-12 defines MIB objects for managing the Border Gateway Protocol, version 4.



## BGP4v2 per-peer session management information

The following table displays information about the BGP4v2 per-peer session management information group. Use the **show ip bgp neighbor <id>** command to display the BGP4v2 per-peer session management information.

### NOTE

The following table is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, and Brocade NetIron CER series devices and it is not supported on the Brocade NetIron CES 2000 series BASE Packages device.

Name, OID, and syntax	Access	Description
bgp4V2PeerTable brcdIp.3.5.1.1.2	None	The BGP4v2 per-peer table. The table contains one entry per BGP peer and the information about the connections with the BGP peers.
bgp4V2PeerInstance brcdIp.3.5.1.1.2.1.1 Syntax: Unsigned32	None	Specifies the routing instance index. Some of the BGP implementations permit the creation of multiple instances of a BGP routing process. The implementations that do not support multiple routing instances, return 1 for this object. The VRF index is used to identify the peer instance. The VRF index is a zero-based index.
bgp4V2PeerLocalAddrType brcdIp.3.5.1.1.2.1.2 Syntax: InetAddressType	None	Specifies the address family of a local-end peering session. The following address types are supported: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul>
bgp4V2PeerLocalAddr brcdIp.3.5.1.1.2.1.3 Syntax: InetAddress	None	Specifies the local IP address of the received BGP connection.
bgp4V2PeerRemoteAddrType brcdIp.3.5.1.1.2.1.4 Syntax: InetAddressType	None	Specifies the address family of a remote end peering session. The following address types are supported: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul>
bgp4V2PeerRemoteAddr brcdIp.3.5.1.1.2.1.5 Syntax: InetAddress	None	Specifies the remote IP address of the received BGP peer.
bgp4V2PeerLocalPort brcdIp.3.5.1.1.2.1.6 Syntax: InetPortNumber	Read-only	Indicates the local port for the TCP connection between the BGP peers.
bgp4V2PeerLocalAs brcdIp.3.5.1.1.2.1.7 Syntax: InetAutonomousSystemNumber	Read-only	Indicates a Autonomous System (AS) is the peering session that represents itself to the remote peer. Some implementations of BGP can represent itself as multiple autonomous systems.
bgp4V2PeerLocalIdentifier brcdIp.3.5.1.1.2.1.8 Syntax: Bgp4V2IdentifierTC	Read-only	Specifies the BGP identifier of the local system for the peering session. It is required that all the values of bgp4V2PeerLocalIdentifier and bgp4V2PeerInstance objects must be identical.

## 2 Supported Standard MIBs

Name, OID, and syntax	Access	Description
bgp4V2PeerRemotePort brcdIp.3.5.1.1.2.1.9 Syntax: InetPortNumber	Read-only	Specifies the remote port for the TCP connection between the BGP peers.  <b>NOTE:</b> The objects bgp4V2PeerLocalAddr, bgp4V2PeerLocalPort, bgp4V2PeerRemoteAddr, and bgp4V2PeerRemotePort provides the appropriate references to the standard MIB TCP connection table or to the IPv6 TCP MIB as referenced in RFC 4022.
bgp4V2PeerRemoteAs brcdIp.3.5.1.1.2.1.10 Syntax: InetAutonomousSystemNumber	Read-only	Specifies the remote AS number received in the BGP OPEN message.
bgp4V2PeerRemotIdentifier brcdIp.3.5.1.1.2.1.11 Syntax: Bgp4V2IdentifierTC	Read-only	Specifies the BGP identifier of the received remote BGP peer.  The entry received must be 0.0.0.0 unless the bgp4V2PeerState is in the openconfirm(5) or in established(6) state.
bgp4V2PeerAdminStatus brcdIp.3.5.1.1.2.1.12 Syntax: Integer	Read-only	Specifies whether the BGP finite state machine (FSM) for the remote peer is halted or running, the BGP FSM for a remote peer is halted after processing a stop event. Likewise, if in the running state after processing a start event.  The bgp4V2PeerState is in the idle state when the FSM is halted. Although, some extensions such as Graceful Restart leaves the peer in the idle state with the FSM running. <ul style="list-style-type: none"> <li>• halted(1)</li> <li>• running(2)</li> </ul>
bgp4V2PeerState brcdIp.3.5.1.1.2.1.13 Syntax: Integer	Read-only	Indicates the BGP peer connection states: <ul style="list-style-type: none"> <li>• idle(1)</li> <li>• connect(2)</li> <li>• active(3)</li> <li>• opensent(4)</li> <li>• openconfirm(5)</li> <li>• established(6)</li> </ul>
bgp4V2PeerDescription brcdIp.3.5.1.1.2.1.14 Syntax: SnmpAdminString	Read-only	Specifies a user-configured description identifying the peer. The object must contain a description that is unique within the existing BGP instance for the peer.

## BGP4v2 per-peer error management information

The following table contains the BGP4v2 per-peer error management information objects.

### NOTE

The following table is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, and Brocade NetIron CER series devices and it is not supported on the Brocade NetIron CES 2000 series BASE Packages device.

Name, OID, and syntax	Access	Description
bgp4V2PeerErrorsTable brcdIp.3.5.1.1.3	None	On a per-peer basis, the table reflects the last protocol-defined error encountered and reported on the peer session.
bgp4V2PeerLastErrorCodeReceived brcdIp.3.5.1.1.3.1.1 Syntax: Unsigned32	Read-only	Specifies the last error code received from the peer through a notification message on the connection. The field is zero(0), if no error occurs.
bgp4V2PeerLastErrorSubCodeReceived brcdIp.3.5.1.1.3.1.2 Syntax: Unsigned32	Read-only	Specifies the last error subcode received from the peer through a notification message on the connection. The field is zero(0), if no error occurs.
bgp4V2PeerLastErrorReceivedTime brcdIp.3.5.1.1.3.1.3 Syntax: TimeStamp	Read-only	Indicates the time stamp when the last notification is received from the peer.
bgp4V2PeerLastErrorReceivedText brcdIp.3.5.1.1.3.1.4 Syntax: SnmpAdminString	Read-only	Specifies the implementation-specific explanation of the error reported.
bgp4V2PeerLastErrorReceivedData brcdIp.3.5.1.1.3.1.5 Syntax: Octet String <b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices	Read-only	Specifies the data of the last error code received by the peer. As per RFC 2578, some implementations have limitations dealing with Octet Strings that are larger than 255. So, the data is truncated.
bgp4V2PeerLastErrorCodeSent brcdIp.3.5.1.1.3.1.6 Syntax: Unsigned32	Read-only	Specifies the last error code sent to the peer through a notification message on the connection. The field is zero(0), if no error occurs.
bgp4V2PeerLastErrorSubCodeSent brcdIp.3.5.1.1.3.1.7 Syntax: Unsigned32	Read-only	Specifies the last error subcode sent to the peer through a notification message on the connection. The field is zero(0), if no error occurs.
bgp4V2PeerLastErrorSentTime brcdIp.3.5.1.1.3.1.8 Syntax: TimeStamp	Read-only	Indicates the time stamp when the last notification is sent to the peer.

Name, OID, and syntax	Access	Description
bgp4V2PeerLastErrorSentText brcdIp.3.5.1.1.3.1.9 Syntax: SnmpAdminString	Read-only	Specifies the implementation-specific explanation of the error reported.
bgp4V2PeerLastErrorSentData brcdIp.3.5.1.1.3.1.10 Syntax: Octet String <b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices	Read-only	Specifies the data of the last error code sent to the peer. As per RFC 2578, some implementations have limitations dealing with Octet Strings that are larger than 255. So, the data is truncated.

## BGP4v2 per-peer event times table

The following table contains the BGP4v2 per-peer event times-related objects.

### NOTE

The following table is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, and Brocade NetIron CER series devices and it is not supported on the Brocade NetIron CES 2000 series BASE Packages device.

Name, OID, and syntax	Access	Description
bgp4V2PeerEventTimesTable brcdIp.3.5.1.1.4	None	A table reporting the per-peering session amount of time elapsed and update events while the peering session advanced into the established state.
bgp4V2PeerFsmEstablishedTime brcdIp.3.5.1.1.4.1.1 Syntax: Gauge32	Read-only	Indicates how long (in seconds) the peer has been in the established state or how long since the peer was last in the established state. The value of the object is set to zero(0) when a new peer is configured or when the router is booted. The value remains zero if the peer has never reached the established state.
bgp4V2PeerInUpdatesElapsedTime brcdIp.3.5.1.1.4.1.2 Syntax: Gauge32	Read-only	Indicates the elapsed time (in seconds) since the last BGP update message was received from the peer. The value of the object is set to zero(0) each time bgpPeerInUpdates is incremented.

## BGP4v2 NLRI table

The following table contains the BGP4v2 Network Layer Reachability Information (NLRI) objects. Use the **show ip bgp routes detail** command to display all the BGP attributes of a route, such as communities. Use the **show ip bgp routes** command to display the entries learned through NLRI available in the update.

**NOTE**

The following table is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, and Brocade NetIron CER series devices and it is not supported on the Brocade NetIron CES 2000 series BASE Packages device.

Name, OID, and syntax	Access	Description
bgp4V2NlriTable brcdIp.3.5.1.1.9	None	The BGP4v2-received path attribute table contains information about paths to destination networks received from all the BGP4 peers. Collectively, this represents the Adj-Ribs-In. For NLRI, the route in which the bgp4V2NlriBest object is true represents the route that is installed in the LocRib from the Adj-Ribs-In.
bgp4V2NlriIndex brcdIp.3.5.1.1.9.1.1 Syntax: Unsigned32 <b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices	None	Specifies the index that allows multiple instances of a base prefix for a certain AFI-SAFI from a given peer. This is used to allow a peer in future implementations to send more than a single route instance and allow extensions that extend an NLRI field to send the same prefix while utilizing other extension-specific information. The index is always 1.
bgp4V2NlriAfi brcdIp.3.5.1.1.9.1.2 Syntax: Bgp4V2AddressFamilyIdentifierTC	None	Specifies the address family of the prefix for NLRI. <b>NOTE:</b> It is not necessary that an AFI definition is equivalent to an InetAddressType.
bgp4V2NlriSafi brcdIp.3.5.1.1.9.1.3 Syntax: Bgp4V2SubsequentAddressFamilyIdentifierTC	None	Specifies the subsequent address family of the prefix for NLRI.
bgp4V2NlriPrefixType brcdIp.3.5.1.1.9.1.4 Syntax: InetAddressType	None	Specifies the type of the IP address prefix in an NLRI field. The value of the object is derived from the appropriate value from the bgp4V2NlriAfi field. Where an appropriate InetAddressType is not available, the value of the object is unknown(0).
bgp4V2NlriPrefix brcdIp.3.5.1.1.9.1.5 Syntax: InetAddress	None	Indicates an IP address prefix in an NLRI field. The object is an IP address containing the prefix with the length specified by the bgp4V2NlriPrefixLen object. Any bits beyond the length specified by the bgp4V2NlriPrefixLen object are set to zero(0).
bgp4V2NlriPrefixLen brcdIp.3.5.1.1.9.1.6 Syntax: InetAddressPrefixLength	None	Indicates the length in bits of the address prefix in an NLRI field.
bgp4V2NlriBest brcdIp.3.5.1.1.9.1.7 Syntax: TruthVal	Read-only	Indicates whether the route is chosen as the best BGP4 route for the destination.
bgp4V2NlriCalcLocalPref brcdIp.3.5.1.1.9.1.8 Syntax: Unsigned32	Read-only	Specifies the degree of preference calculated by the receiving BGP4 speaker for an advertised route. The value of the object is zero (0) where the prefix is ineligible.

## 2 Supported Standard MIBs

Name, OID, and syntax	Access	Description
bgp4V2NlriOrigin brcdIp.3.5.1.1.9.1.9 Syntax: Integer	Read-only	Specifies the ultimate origin of the path information: <ul style="list-style-type: none"> <li>• igp(1) - The networks that are interior.</li> <li>• egp(2) - The networks learned through an Exterior Gateway Protocol (EGP).</li> <li>• incomplete(3) - The networks that are learned by some other means.</li> </ul>
bgp4V2NlriNextHopAddrType brcdIp.3.5.1.1.9.1.10 Syntax: InetAddressType	Read-only	Specifies the address family of the address for the border router that is used to access the destination network.
bgp4V2NlriNextHopAddr brcdIp.3.5.1.1.9.1.11 Syntax: InetAddress	Read-only	Specifies the address of the border router that is used to access the destination network. The address is the next-hop address received in the update packet associated with the prefix: <ul style="list-style-type: none"> <li>• For RFC 2545 style double nexthops, the object contains the global scope next hop.</li> <li>• For bgpPathAttrLinkLocalNextHop, the object contains the link local scope next hop, if it is present.</li> <li>• For bgp4V2NlriNextHopAddr, the object contains the link local next hop, if a mechanism is developed to use only a link local next hop.</li> </ul>
bgp4V2NlriLinkLocalNextHopAddrType brcdIp.3.5.1.1.9.1.12 Syntax: InetAddressType	Read-only	Specifies the address type for an IPv6 link local address. The object is present only when receiving RFC 2545 style double nexthops. The object is present optionally in BGP implementations that do not support IPv6. The value of the object is unknown(0) when there is no IPv6 link local next hop present.
bgp4V2NlriLinkLocalNextHopAddr brcdIp.3.5.1.1.9.1.13 Syntax: InetAddress	Read-only	Indicates the value that contains an IPv6 link local address and is present only when receiving RFC 2545 style double nexthops. The object is present optionally in BGP implementations that do not support IPv6. The length of the object is zero(0) when there is no IPv6 link local next hop present.
bgp4V2NlriLocalPrefPresent brcdIp.3.5.1.1.9.1.14 Syntax: TruthVal	Read-only	Indicates if the value is true when the LOCAL_PREF value is sent in the UPDATE message. The value is always true.
bgp4V2NlriLocalPref brcdIp.3.5.1.1.9.1.15 Syntax: Unsigned32	Read-only	Specifies the degree of preference of the originating BGP4 speaker for an advertised route.
bgp4V2NlriMedPresent brcdIp.3.5.1.1.9.1.16 Syntax: TruthVal	Read-only	Indicates if the value is true when a Multi-Exit Discriminator (MED) value is sent in the UPDATE message.
bgp4V2NlriMed brcdIp.3.5.1.1.9.1.17 Syntax: Unsigned32	Read-only	Indicates the metric used to discriminate between multiple exit points to an adjacent autonomous system. When an MED value is absent but has a calculated default value, the object will contain the calculated value.
bgp4V2NlriAtomicAggregate brcdIp.3.5.1.1.9.1.18 Syntax: TruthVal	Read-only	Indicates if the value is true when the ATOMIC_AGGREGATE path attribute is present and indicates that NLRI cannot be made more specific.

Name, OID, and syntax	Access	Description
bgp4V2NlriAggregatorPresent brcdIp.3.5.1.1.9.1.19 Syntax: TruthVal	Read-only	Indicates if the value is true when the AGGREGATOR path attribute is sent in the UPDATE message.
bgp4V2NlriAggregatorAS brcdIp.3.5.1.1.9.1.20 Syntax: InetAutonomousSystemNumber	Read-only	Specifies an AS number of the last BGP4 speaker that performed route aggregation. The value of the object is zero(0) when the bgp4V2NlriAggregatorPresent object is false.
bgp4V2NlriAggregatorAddr brcdIp.3.5.1.1.9.1.21 Syntax: Bgp4V2IdentifierTC	Read-only	Specifies the IP address of the last BGP4 speaker that performed route aggregation. The value of the object is 0.0.0.0 when the bgp4V2NlriAggregatorPresent object is false.
bgp4V2NlriAsPathCalcLength brcdIp.3.5.1.1.9.1.22 Syntax: Unsigned32	Read-only	Indicates the value that represents the calculated length of the AS-Path according to the rules in the BGP specification. The value is used in route selection.
bgp4V2NlriAsPathString brcdIp.3.5.1.1.9.1.23 Syntax: SnmpAdminString	Read-only	<p>Specifies a string depicting the AS-Path to the network, which is received from the peer that is advertised.</p> <p>The format of the string is implementation-dependent and it must be designed for operator readability.</p> <p>SnmpAdminString is capable of representing a maximum of 255 characters. This may lead to the string being truncated in the presence of a large AS-Path.</p> <p><b>NOTE:</b> It is recommended that when the content of the object is truncated, the final three octets should be reserved for the ellipses string (...). The bgp4V2NlriAsPath object gives access to the full AS-Path.</p>

Name, OID, and syntax	Access	Description
bgp4V2NlriAsPath brcdIp.3.5.1.1.9.1.24 Syntax: Octet String	Read-only	<p>Specifies the contents of the BGP4 AS_PATH attribute to provide an authorized form of the BGP4 AS_PATH along with the human-readable bgp4V2NlriAsPathString object that can be truncated. The object is parsed using the rules defined for four-octet autonomous systems as defined in RFC 4893. RFC 4271 and RFC 5065 define the general format of the AS_PATH attribute and its code points.</p> <p>The AS_PATH attribute is composed of a sequence of AS segments. Each AS segment is represented in the following fields:</p> <ul style="list-style-type: none"> <li>The <i>path segment type and path segment</i> are one octet in length each. Any one of the following can represent the <i>path segment type</i> field:                             <ul style="list-style-type: none"> <li>1 - AS_SET (RFC 4721)</li> <li>2 - AS_SEQUENCE (RFC 4721)</li> <li>3 - AS_CONFED_SEQUENCE (RFC 3065)</li> <li>4 - AS_CONFED_SET (RFC 3065)</li> </ul> </li> <li>The <i>path segment length</i> field contains the number of autonomous systems (not the number of octets) in the <i>path segment value</i> field.</li> <li>The <i>path segment value</i> field contains one or more autonomous system numbers, each encoded as a four octet length field in network-byte order.</li> </ul> <p><b>NOTE:</b> An SNMP agent can truncate the objects that are less than its maximum theoretical length of 4072 octets. It is recommended that when such truncation occurs on the boundary of an encoded AS, the partial AS be discarded from the object and the object size adjusted accordingly. When such truncation happens, either alone or in conjunction with the truncation of a partially encoded AS, it will yield an empty path segment value. In that case, the path segment type and path segment length components of the truncated AS_PATH attribute are also discarded and the object size is adjusted accordingly.</p>
bgp4V2NlriPathAttrUnknown brcdIp.3.5.1.1.9.1.25 Syntax: Octet String	Read-only	<p>Specifies the path attributes that are not understood by the implementation are presented. These path attributes use the type, length, and value encoding from RFC 4271.</p> <p><b>NOTE:</b> An SNMP agent can truncate the objects that are less than its maximum theoretical length of 4072 octets.</p>

## RFC 4292: IP Forwarding Table MIB

The Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices support the entire RFC 4292 with the following exceptions. RFC 4292 replaces RFC 2096 and RFC 2465.

- The object inetCidrRouteDiscards is not supported.
- The objects inetCidrRouteMetric2, inetCidrRouteMetric3, inetCidrRouteMetric4, and inetCidrRouteMetric5 in the inetCidrRouteTable are not supported.
- All objects have read-only access.



## RFC 4293: Management Information Base for the Internet Protocol (IP)

RFC 4293, Management Information Base for the Internet Protocol (IP) obsoletes the following:

- RFC 2011: SNMPv2 Management Information Base for the Internet Protocol using SMIv2
- RFC 2465: Management Information Base for IP Version 6: Textual Conventions and General Group
- RFC 2466: Management Information Base for IP Version 6: ICMPv6 Group

This RFC is supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

The following table summarizes the tables from the RFC that are supported.

Object group name	Object identifier	Supported IP version	Access
IP scalar variables	1.3.6.1.2.1.4	IPv4 and IPv6	Only the following objects have read-write access: <ul style="list-style-type: none"> <li>• ipDefaultTTL</li> <li>• ipv6IpDefaultHopLimit</li> <li>• ipv6IpForwarding</li> </ul> All other scalar variables are read-only.
ipv4InterfaceTable	1.3.6.1.2.1.4.28	IPv4	All objects are read-only.
ipv6InterfaceTable	1.3.6.1.2.1.4.30	IPv6	All objects are read-only.
ipSystemStatsTable	1.3.6.1.2.1.4.31.1	IPv4 and IPv6	All objects are read-only.
ipIfStatsTableLastChange	1.3.6.1.2.1.4.31.2	IPv4 and IPv6	All objects are read-only.
ipIfStatsTable	1.3.6.1.2.1.4.31.3	IPv4 and IPv6	Not supported.
ipAddressPrefixTable	1.3.6.1.2.1.4.32	IPv4 and IPv6	All objects are read-only.
ipAddressTable	1.3.6.1.2.1.4.34	IPv4 and IPv6	All objects are read-only.
ipNetToPhysicalTable <b>NOTE:</b> Only ARP entries that are currently being used are included in the ARP table.	1.3.6.1.2.1.4.35	IPv4 and IPv6	Only the following objects have read-create access: <ul style="list-style-type: none"> <li>• ipNetToPhysicalPhysAddress</li> <li>• ipNetToPhysicalType</li> <li>• ipNetToPhysicalRowStatus</li> </ul> All other objects are read-only.
ipv6ScopeZoneIndexTable	1.3.6.1.2.1.4.36	IPv6	All objects are read-only
ipDefaultRouterTable	1.3.6.1.2.1.4.37	IPv4 and IPv6	All objects are read-only.

Object group name	Object identifier	Supported IP version	Access
ipv6RouterAdvertTable	1.3.6.1.2.1.4.39	IPv6	Only the following objects have read-write access; all others are read-only: <ul style="list-style-type: none"> <li>• ipv6RouterAdvertSendAdverts</li> <li>• ipv6RouterAdvertManagedFlag</li> <li>• ipv6RouterAdvertOtherConfigFlag</li> <li>• ipv6RouterAdvertReachableTime</li> <li>• ipv6RouterAdvertRetransmitTime</li> <li>• ipv6RouterAdvertCurHopLimit</li> <li>• ipv6RouterAdvertDefaultLifetime</li> </ul>
icmpStatsTable	1.3.6.1.2.1.5.29	IPv4 and IPv6	All objects are read-only.
icmpMsgStatsTable	1.3.6.1.2.1.5.30	IPv4 and IPv6	All objects are read-only.

## RFC 4444: Management Information Base for Intermediate System to Intermediate System (IS-IS)

This RFC 4444, Management Information Base for Intermediate System to Intermediate System (IS-IS) is supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

### Scalar isisSys objects

The following scalar objects are supported in the Unified IP MIB; however, only read-only access is provided.

Object group name	Object identifier	Supported?	Notes
isisSysVersion	1.3.6.1.2.1.138.1.1.1.1	Yes	Always returns 1.
isisSysLevelType	1.3.6.1.2.1.138.1.1.1.2	Yes	<ul style="list-style-type: none"> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level 1 and 2(3)</li> </ul>
isisSysID	1.3.6.1.2.1.138.1.1.1.3	Yes	-
isisSysMaxPathSplits	1.3.6.1.2.1.138.1.1.1.4	Yes	-
isisSysMaxLSPGenInt	1.3.6.1.2.1.138.1.1.1.5	Yes	-
isisSysPollESHelloRate	1.3.6.1.2.1.138.1.1.1.6	No	-
isisSysWaitTime	1.3.6.1.2.1.138.1.1.1.7	No	-
isisSysAdminState	1.3.6.1.2.1.138.1.1.1.8	Yes	<ul style="list-style-type: none"> <li>• on(1)</li> <li>• off(2)</li> </ul>
isisSysL2toL1Leaking	1.3.6.1.2.1.138.1.1.1.9	Yes	-
isisSysMaxAge	1.3.6.1.2.1.138.1.1.1.10	Yes	-
isisSysReceiveLSPBufferSize	1.3.6.1.2.1.138.1.1.1.11	Yes	-

Object group name	Object identifier	Supported?	Notes
isisSysProtSupported	1.3.6.1.2.1.138.1.1.1.12	Yes	BITS: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul>
isisSysNotificationEnable	1.3.6.1.2.1.138.1.1.1.13	Yes	-

## Supported tables in RFC 4444

The following tables in RFC 4444 are supported; however, only read-only access is allowed.

### NOTE

Tables in RFC 4444 that are not listed in the table below are not supported. For example, the isisRATable is not supported.

Object group name	Object identifier	Comments
isisManAreaAddrTable	1.3.6.1.2.1.138.1.1.2	-
isisAreaAddrTable	1.3.6.1.2.1.138.1.1.3	-
isisSummAddrTable	1.3.6.1.2.1.138.1.1.4	-
isisRedistributeAddrTable	1.3.6.1.2.1.138.1.1.5	-
isisRouterTable	1.3.6.1.2.1.138.1.1.6	-
isisSysLevelTable	1.3.6.1.2.1.138.1.2.1	-
isisCircTable	1.3.6.1.2.1.138.1.3.2	The following objects from this table are not supported: <ul style="list-style-type: none"> <li>• isisCircMeshGroupEnabled will return INACTIVE.</li> <li>• isisCircMeshGroup will return zero (0).</li> </ul> Also, the object isisCirc3WayEnabled is always ON for Pt 2 Pt.
isisCircLevelTable	1.3.6.1.2.1.138.1.4.1	-
isisSystemCounterTable	1.3.6.1.2.1.138.1.5.1	-
isisCircuitCounterTable	1.3.6.1.2.1.138.1.5.2	-
isisPacketCounterTable	1.3.6.1.2.1.138.1.5.3	-
isisIsAdjTable	1.3.6.1.2.1.138.1.6.1	-
isisIsAdjAreaAddrTable	1.3.6.1.2.1.138.1.6.2	-
isisIsAdjIPAddrTable	1.3.6.1.2.1.138.1.6.3	-
isisIsAdjProtSuppTable	1.3.6.1.2.1.138.1.6.4	-
isisIPRATable	1.3.6.1.2.1.138.1.8.1	-
isisLSPSummaryTable	1.3.6.1.2.1.138.1.9.1	-
isisLSPTLVTable	1.3.6.1.2.1.138.1.9.2	-
isisNOTIFICATION	1.3.6.1.2.1.138.1.10	-

## Notifications

IS-IS notification is enabled by default. To disable notification, issue the **no snmp-server enable traps isis** command at the device CLI. Use **snmp-server enable traps isis** command to re-enable notification.

[Table 3](#) lists the notifications in RFC 4444 that are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

### NOTE

Only one IS-IS trap is generated for each notification type within a 60-second (1 minute) period. For example, if several authentication failure notification types occur within a 60-second period, only one trap is generated for the authentication failure notification type. This duration is different from what is specified in RFC 4444.

---

**TABLE 3** Supported RFC 4444 notifications

Object group name	Object identifier
isisDatabaseOverload	1.3.6.1.2.1.138.1.10.1
isisAttemptToExceedMaxSequence	1.3.6.1.2.1.138.1.10.4
isisIDLenMismatch	1.3.6.1.2.1.138.1.10.5
isisMaxAreaAddressesMismatch	1.3.6.1.2.1.138.1.10.6
isisOwnLSPPurge	1.3.6.1.2.1.138.1.10.7
isisSequenceNumberSkip	1.3.6.1.2.1.138.1.10.8
isisAuthenticationFailure	1.3.6.1.2.1.138.1.10.10
isisAreaMismatch	1.3.6.1.2.1.138.1.10.12
isisAdjacencyChange	1.3.6.1.2.1.138.1.10.17
isisLSPErrorDetected	1.3.6.1.2.1.138.1.10.18

[Table 4](#) lists the notifications in RFC 4444 that are not supported.

**TABLE 4** Unsupported RFC 4444 notifications

Object group name	Object identifier
isisManualAddressDrops	1.3.6.1.2.1.138.1.10.2
isisCorruptedLSPDetected	1.3.6.1.2.1.138.1.10.3
isisAuthenticationTypeFailure	1.3.6.1.2.1.138.1.10.9
isisVersionSkew	1.3.6.1.2.1.138.1.10.11
isisRejectedAdjacency	1.3.6.1.2.1.138.1.10.13
isisLSPTooLargeToPropagate	1.3.6.1.2.1.138.1.10.14
isisOrigLSPBufferSizeMismatch	1.3.6.1.2.1.138.1.10.15
isisProtocolsSupportedMismatch	1.3.6.1.2.1.138.1.10.16

## RFC 4807: IPsec Security Policy Database Configuration MIB

RFC 4807 is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

### NOTE

Only read-only access is available for the objects.

---

### spdLocalConfigObjects

The following table lists the IPsec Security Policy Database (SPD) local configuration objects.

Object	Object Identifier
spdIngressPolicyGroupName	1.3.6.1.2.1.153.1.1.1
spdEgressPolicyGroupName	1.3.6.1.2.1.153.1.1.2

### spdEndpointToGroupTable

The following table lists the SPD endpoint to group table objects.

Object group name	Object identifier	Access
spdEndGroupDirection	1.3.6.1.2.1.153.1.2.1.1	<ul style="list-style-type: none"> <li>Ingress/Inbound(1)</li> <li>Egress/Outbound(2)</li> </ul>
spdEndGroupInterface	1.3.6.1.2.1.153.1.2.1.2	Interface index
spdEndGroupName	1.3.6.1.2.1.153.1.2.1.3	<ul style="list-style-type: none"> <li>The group name is derived from joining multiple strings of the <i>vrf-id:ifIndex:ifDirection:Encap:SPI:AuthAlg:EncryptAlg</i> IPsec data.</li> <li>The maximum of 32 characters is allowed in a group name.</li> </ul>
spdEndGroupLastChanged	1.3.6.1.2.1.153.1.2.1.4	Always returns 0.
spdEndGroupStorageType	1.3.6.1.2.1.153.1.2.1.5	Always returns volatile(2).
spdEndGroupRowStatus	1.3.6.1.2.1.153.1.2.1.6	Always returns active(1).

## spdGroupContentsTable

The following table lists the SPD group contents table objects.

Object group name	Object identifier	Access
spdGroupContName	1.3.6.1.2.1.153.1.3.1.1	<ul style="list-style-type: none"> <li>The group name is derived from joining multiple strings of the <i>vrf-id:ifIndex:ifDirection:Encap:SPI:AuthAlg:EncryptAlg</i> IPsec data.</li> <li>The maximum of 32 characters is allowed in a group name.</li> <li>The index is the string name returned from querying the <i>spdEndpointToGroupTable</i> and <i>spdEndGroupName</i> field.</li> </ul>
spdGroupContPriority	1.3.6.1.2.1.153.1.3.1.2	The priority number is used for representing Accept(1) and Drop(65535) rules.
spdGroupContFilter	1.3.6.1.2.1.153.1.3.1.3	Always returns <i>spdTrueFilter</i> instance.
spdGroupContComponentType	1.3.6.1.2.1.153.1.3.1.4	Always returns rule(2).
spdGroupContComponentName	1.3.6.1.2.1.153.1.3.1.5	<ul style="list-style-type: none"> <li>Returns a rule name that is used as an index to <i>spdRuleDefinitionTable</i> to find the <i>FilterAction</i> associated with this policy group.</li> <li>The rule name is derived from joining multiple strings of the <i>vrf-id:ifIndex:ifDirection:priority</i> IPsec data.</li> <li>The maximum of 32 characters is allowed in a rule name.</li> </ul>
spdGroupContLastChanged	1.3.6.1.2.1.153.1.3.1.6	Always returns 0.
spdGroupContStorageType	1.3.6.1.2.1.153.1.3.1.7	Always returns <i>volatile(2)</i> .
spdGroupContRowStatus	1.3.6.1.2.1.153.1.3.1.8	Always returns <i>active(1)</i> .

## spdRuleDefinitionTable

The following table lists the SPD rule definition table objects.

Object group name	Object identifier	Access
spdRuleDefName	1.3.6.1.2.1.153.1.4.1.1	<ul style="list-style-type: none"> <li>The index is the string name derived from querying the <i>spdGroupContentsTable</i> and <i>spdGroupContComponentName</i> field.</li> <li>The rule name is derived from joining multiple strings of the <i>vrf-id:ifIndex:ifDirection:priority</i> IPsec data.</li> </ul>
spdRuleDefDescription	1.3.6.1.2.1.153.1.4.1.2	A user-defined string description of the rule.

Object group name	Object identifier	Access
spdRuleDefFilter	1.3.6.1.2.1.153.1.4.1.3	The field points to an entry of “diffServMultiFieldClfrTable” of the Differentiated Services MIB.
spdRuleDefFilterNegated	1.3.6.1.2.1.153.1.4.1.4	Always returns false(2).
spdRuleDefAction	1.3.6.1.2.1.153.1.4.1.5	The field points to a static action, either spdDropAction or spdAcceptAction.
spdRuleDefAdminStatus	1.3.6.1.2.1.153.1.4.1.6	Always returns enabled(1).
spdRuleDefLastChanged	1.3.6.1.2.1.153.1.4.1.7	Always returns 0.
spdRuleDefStorageType	1.3.6.1.2.1.153.1.4.1.8	Always returns volatile(2).
spdRuleDefRowStatus	1.3.6.1.2.1.153.1.4.1.9	Always returns active(1).

The tables spdCompoundFilterTable, spdSubfiltersTable, spdIpOffsetFilterTable, spdTimeFilterTable, spdIpsoHeaderFilterTable, spdCompoundActionTable, and spdSubactionsTable are not supported.

The following tables of scalar objects are supported, except the scalar object diffServMultiFieldClfrNextFree.

## spdStaticFilters

The following table lists the SPD static filter scalar object.

Object	Object Identifier	Access
spdTrueFilterInstance	1.3.6.1.2.1.153.1.7.1.0	Always true(1).

## spdStaticActions

The following table lists the SPD static actions scalar objects.

Object	Object Identifier	Access
spdDropAction	1.3.6.1.2.1.153.1.13.1	Indicates that a packet must be dropped and no action or packet logging is done.
spdDropActionLog	1.3.6.1.2.1.153.1.13.2	Indicates that a packet must be dropped and an action or packet logging is required.
spdAcceptAction	1.3.6.1.2.1.153.1.13.3	Indicates that a packet must be accepted (or passed-through) and no action or packet logging is done.
spdAcceptActionLog	1.3.6.1.2.1.153.1.13.4	Indicates that a packet must be accepted (or passed-through) and an action or packet logging is required.

## IEEE8021-CFM-MIB

The following tables in the IEEE8021-CFM-MIB are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

The following scalars are supported, but read-only access is available:

- dot1agCfmDefaultMdDefLevel (OID: 1.3.111.2.802.1.1.8.1.2.1) - This object always returns 0.
- dot1agCfmDefaultMdDefMhfCreation (OID: 1.3.111.2.802.1.1.8.1.2.2) - This object always returns defMHFdefault(2).
- dot1agCfmDefaultMdDefIdPermission (OID: 1.3.111.2.802.1.1.8.1.2.3) - This object always returns sendIdNone(1).

The following tables are supported, but read-only access for these tables is available at this time:

- dot1agCfmMdTable
- dot1agCfmMaNetTable
- dot1agCfmMaCompTable
- dot1agCfmMaMepListTable
- dot1agCfmMepTable
- dot1agCfmLtrTable
- dot1agCfmMepDbTable

Other tables or the dot1agCfmFaultAlarm notification are not supported.

### dot1agCfmMdTable

The dot1agCfmMdTable is the Maintenance Domain table. Each row in the domain represents a different Maintenance Domain. It is indexed by the dot1agCfmMdIndex object. Only read-only access is available for the objects listed in the below table.

Object group name	Type	Object identifier	Comments
dot1agCfmMdIndex	Unsigned32	1.3.111.2.802.1.1.8.1.5.2.1.1	Index variable. Supported.
dot1agCfmMdFormat	dot1agCfmMaintDomainName Type	1.3.111.2.802.1.1.8.1.5.2.1.2	Supported.
dot1agCfmMdName	dot1agCfmMaintDomainName	1.3.111.2.802.1.1.8.1.5.2.1.3	Supported.
dot1agCfmMdMdLevel	dot1agCfmMDLevel	1.3.111.2.802.1.1.8.1.5.2.1.4	Supported.
dot1agCfmMdMhfCreation	dot1agCfmMhfCreation	1.3.111.2.802.1.1.8.1.5.2.1.5	Supported.
dot1agCfmMdMhfIdPermission	dot1agCfmIdPermission	1.3.111.2.802.1.1.8.1.5.2.1.6	Always returns sendIdNone(1).
dot1agCfmMdMaNextIndex	dot1agCfmIndexIntegerNextFree	1.3.111.2.802.1.1.8.1.5.2.1.7	Supported.
dot1agCfmMdRowStatus	RowStatus	1.3.111.2.802.1.1.8.1.5.2.1.8	Always returns active(1).



## dot1agCfmMaNetTable

Each row in the dot1agCfmMaNetTable represents an Maintenance Association (MA), which is a set of maintenance association end points (MEPs). Each MEP is configured with a single service instance. It is indexed by the dot1agCfmMdIndex and dot1agCfmMaIndex objects.

Only read-only access is available for these objects.

Object group name	Type	Object identifier	Comments
dot1agCfmMaIndex	Unsigned32	1.3.111.2.802.1.1.8.1.6.1.1.1	Index variable. Supported.
dot1agCfmMaNetFormat	dot1agCfmMaintAssocNameType	1.3.111.2.802.1.1.8.1.6.1.1.2	Supported.
dot1agCfmMaNetName	dot1agCfmMaintAssocName	1.3.111.2.802.1.1.8.1.6.1.1.3	Supported.
dot1agCfmMaNetCcmInterval	dot1agCfmCcmInterval	1.3.111.2.802.1.1.8.1.6.1.1.4	Supported.
dot1agCfmMaNetRowStatus	RowStatus	1.3.111.2.802.1.1.8.1.6.1.1.5	Always returns active(1).

## dot1agCfmMaCompTable

The dot1agCfmMaCompTable is the MA component table. Each row in the table represents an MA, which is a set of MEPs. Each MEP is configured with a single service instance. It is indexed by dot1agCfmMaComponentId, dot1agCfmMdIndex, and dot1agCfmMaIndex. Only read-only access is available for this table.

Object group name	Type	Object identifier	Comments
ieee8021CfmMaComponentId	ieee8021PbbComponentIdentifierTC	1.3.111.2.802.1.1.8.1.6.4.1.1	Index variable. Supported.
ieee8021CfmMaCompPrimarySelectorType	Integer: <ul style="list-style-type: none"> <li>vlandid(1)</li> <li>isid(2)</li> </ul>	1.3.111.2.802.1.1.8.1.6.4.1.2	Supported.
ieee8021CfmMaCompPrimarySelectorOrNone	ieee8021ServiceSelectorValueOrNone	1.3.111.2.802.1.1.8.1.6.4.1.3	Supported.
ieee8021CfmMaCompMhfCreation	dot1agCfmMhfCreation	1.3.111.2.802.1.1.8.1.6.4.1.4	Supported.
ieee8021CfmMaCompIdPermission	dot1agCfmIdPermission	1.3.111.2.802.1.1.8.1.6.4.1.5	Always returns sendIdNone(1).
ieee8021CfmMaCompNumberOfVids	Unsigned32	1.3.111.2.802.1.1.8.1.6.4.1.6	Supported.
ieee8021CfmMaCompRowStatus	RowStatus	1.3.111.2.802.1.1.8.1.6.4.1.7	Always return active(1).

## dot1agCfmMaMepListTable

The dot1agCfmMaMepListTable contains the list of known MEPs for a given MA. It is indexed by dot1agCfmMdIndex, dot1agCfmMaIndex, and dot1agCfmMaMepListIdentifier.

Object group name	Type	Object identifier	Comments
dot1agCfmMaMepListIdentifier	dot1agCfmMepId	1.3.111.2.802.1.1.8.1.6.3.1.1	Index variable. Supported.
dot1agCfmMaMepListRowStatus	RowStatus	1.3.111.2.802.1.1.8.1.6.3.1.2	Always returns active(1).

## dot1agCfmMepTable

The dot1agCfmMepTable is the Maintenance Association End Point (MEP) table. Each row in the table represents a different MEP. It is indexed by dot1agCfmMdIndex, dot1agCfmMaIndex, and dot1agCfmMepIdentifier.

Unless otherwise noted, all objects have read-only access.

Object group name	Type	Object identifier	Comments
dot1agCfmMepIdentifier	dot1agCfmMepId	1.3.111.2.802.1.1.8.1.7.1.1.1	Index variable. Supported. Read-only.
dot1agCfmMepIfIndex	interfaceIndexOrZero	1.3.111.2.802.1.1.8.1.7.1.1.2	Supported. Read-only.
dot1agCfmMepDirection	dot1agCfmMpDirection	1.3.111.2.802.1.1.8.1.7.1.1.3	Supported. Read-only.
dot1agCfmMepPrimaryVid	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.4	Always returns 0. Read-only.
dot1agCfmMepActive	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.5	Supported. Read-only.
dot1agCfmMepFngState	dot1agCfmFngState	1.3.111.2.802.1.1.8.1.7.1.1.6	Supported. Read-only.
dot1agCfmMepCciEnabled	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.7	Supported. Read-only.
dot1agCfmMepCcmLtmPriority	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.8	Supported. Read-only.
dot1agCfmMepMacAddress	MacAddress	1.3.111.2.802.1.1.8.1.7.1.1.9	Supported. Read-only.
dot1agCfmMepLowPrDef	dot1agCfmLowestAlarmPri	1.3.111.2.802.1.1.8.1.7.1.1.10	Supported. Read-only.
dot1agCfmMepFngAlarmTime	TimeInterval	1.3.111.2.802.1.1.8.1.7.1.1.11	Supported. Read-only.
dot1agCfmMepFngResetTime	TimeInterval	1.3.111.2.802.1.1.8.1.7.1.1.12	Supported. Read-only.
dot1agCfmMepHighestPrDefect	dot1agCfmHighestDefectPri	1.3.111.2.802.1.1.8.1.7.1.1.13	Supported. Read-only.
dot1agCfmMepDefects	dot1agCfmMepDefects	1.3.111.2.802.1.1.8.1.7.1.1.14	Supported. Read-only.
dot1agCfmMepErrorCcmLastFailure	Octet String	1.3.111.2.802.1.1.8.1.7.1.1.15	Supported. Read-only.

Object group name	Type	Object identifier	Comments
dot1agCfmMepXconCcmLastFailure	Octet String	1.3.111.2.802.1.1.8.1.7.1.1.16	Supported. Read-only.
dot1agCfmMepCcmSequenceErrors	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.17	Supported. Read-only.
dot1agCfmMepCciSentCcms	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.18	Supported. Read-only.
dot1agCfmMepNextLbmTransId	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.19	Supported. Read-only.
dot1agCfmMepLbrIn	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.20	Supported. Read-only.
dot1agCfmMepLbrInOutOfOrder	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.21	Supported. Read-only.
dot1agCfmMepLbrBadMsdu	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.22	Always returns 0. Read-only.
dot1agCfmMepLtmNextSeqNumber	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.23	Supported. Read-only.
dot1agCfmMepUnexplTrIn	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.24	Supported. Read-only.
dot1agCfmMepLbrOut	Counter32	1.3.111.2.802.1.1.8.1.7.1.1.25	Supported. Read-only.
dot1agCfmMepTransmitLbmStatus	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.26	Supported. Read-only.
dot1agCfmMepTransmitLbmDestMacAddress	MacAddress	1.3.111.2.802.1.1.8.1.7.1.1.27	Supported. Read/write.
dot1agCfmMepTransmitLbmDestMepId	dot1agCfmMepId OrZero	1.3.111.2.802.1.1.8.1.7.1.1.28	Supported. Read-only.
dot1agCfmMepTransmitLbmDestIsMepId	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.29	Supported. Read-write
dot1agCfmMepTransmitLbmMessages	Integer32	1.3.111.2.802.1.1.8.1.7.1.1.30	Supported. Read/write.
dot1agCfmMepTransmitLbmDataTlv	Octet String	1.3.111.2.802.1.1.8.1.7.1.1.31	Always returns Null string. Read-only.
dot1agCfmMepTransmitLbmVlanPriority	Integer32	1.3.111.2.802.1.1.8.1.7.1.1.32	Supported. Read-only.
dot1agCfmMepTransmitLbmVlanDropEnabled	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.33	Always returns false(2). Read-only.
dot1agCfmMepTransmitLbmResultOK	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.34	Supported. Read-only.
dot1agCfmMepTransmitLbmSeqNumber	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.35	Supported. Read-only.
dot1agCfmMepTransmitLtmStatus	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.36	Supported. Read/write.

Object group name	Type	Object identifier	Comments
dot1agCfmMepTransmitLtmFlags	BITS	1.3.111.2.802.1.1.8.1.7.1.1.37	Always returns 0. Read-write.
dot1agCfmMepTransmitLtmTargetMacAddress	MacAddress	1.3.111.2.802.1.1.8.1.7.1.1.38	Supported. Read/write.
dot1agCfmMepTransmitLtmTargetMepId	dot1agCfmMepIdOrZero	1.3.111.2.802.1.1.8.1.7.1.1.39	Supported. Read/write.
dot1agCfmMepTransmitLtmTargetIsMepId	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.40	Supported. Read/write.
dot1agCfmMepTransmitLtmTtl	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.41	Supported. Read/write.
dot1agCfmMepTransmitLtmResult	TruthValue	1.3.111.2.802.1.1.8.1.7.1.1.42	Supported.
dot1agCfmMepTransmitLtmSeqNumber	Unsigned32	1.3.111.2.802.1.1.8.1.7.1.1.43	Supported. Read-only.
dot1agCfmMepTransmitLtmEgressIdentifier	Octet String	1.3.111.2.802.1.1.8.1.7.1.1.44	Supported. Read-only.
dot1agCfmMepRowStatus	RowStatus	1.3.111.2.802.1.1.8.1.7.1.1.45	Always returns active(1). Read-only.

### dot1agCfmLtrTable

The dot1agCfmLtrTable extends the MEP table and contains a list of Linktrace replies received by a specific MEP in response to a Linktrace message. It is indexed by dot1agCfmMdIndex, dot1agCfmMaIndex, dot1agCfmMepIdentifier, dot1agCfmLtrSeqNumber, and dot1agCfmLtrReceiveOrder.

Only one Linktrace number sequence, which is the last one sent, is supported in this table. Only read-only access is available for this table.

Object group name	Type	Object identifier	Comments
dot1agCfmLtrSeqNumber	Unsigned32	1.3.111.2.802.1.1.8.1.7.2.1.1	Supported.
dot1agCfmLtrReceiveOrder	Unsigned32	1.3.111.2.802.1.1.8.1.7.2.1.2	Supported.
dot1agCfmLtrTtl	Unsigned32	1.3.111.2.802.1.1.8.1.7.2.1.3	Supported.
dot1agCfmLtrForwarded	TruthValue	1.3.111.2.802.1.1.8.1.7.2.1.4	Supported.
dot1agCfmLtrTerminalMep	TruthValue	1.3.111.2.802.1.1.8.1.7.2.1.5	Supported.
dot1agCfmLtrLastEgressIdentifier	Octet String	1.3.111.2.802.1.1.8.1.7.2.1.6	Supported.
dot1agCfmLtrNextEgressIdentifier	Octet String	1.3.111.2.802.1.1.8.1.7.2.1.7	Supported.
dot1agCfmLtrRelay	dot1agCfmRelayActionFieldValue	1.3.111.2.802.1.1.8.1.7.2.1.8	Supported.
dot1agCfmLtrChassisIdSubtype	IldpChassisIdSubtype	1.3.111.2.802.1.1.8.1.7.2.1.9	Supported.
dot1agCfmLtrChassisId	IldpChassisId	1.3.111.2.802.1.1.8.1.7.2.1.10	Always returns a NULL string.

Object group name	Type	Object identifier	Comments
dot1agCfmLtrManAddressDomain	TDomain	1.3.111.2.802.1.1.8.1.7.2.1.11	Always returns {0.0}.
dot1agCfmLtrManAddress	TAddress	1.3.111.2.802.1.1.8.1.7.2.1.12	Always returns a NULL string.
dot1agCfmLtrIngress	dot1agCfmIngressActionFieldValue	1.3.111.2.802.1.1.8.1.7.2.1.13	Supported.
dot1agCfmLtrIngressMac	MacAddress	1.3.111.2.802.1.1.8.1.7.2.1.14	Supported.
dot1agCfmLtrIngressPortIdSubtype	IldpPortIdSubtype	1.3.111.2.802.1.1.8.1.7.2.1.15	Supported.
dot1agCfmLtrIngressPortId	dot1agCfmEgressActionFieldValue	1.3.111.2.802.1.1.8.1.7.2.1.16	Supported.
dot1agCfmLtrEgress	dot1agCfmEgressActionFieldValue	1.3.111.2.802.1.1.8.1.7.2.1.17	Supported.
dot1agCfmLtrEgressMac	MacAddress	1.3.111.2.802.1.1.8.1.7.2.1.18	Supported.
dot1agCfmLtrEgressPortIdSubtype	IldpPortIdSubtype	1.3.111.2.802.1.1.8.1.7.2.1.19	Supported.
dot1agCfmLtrEgressPortId	IldpPortId	1.3.111.2.802.1.1.8.1.7.2.1.20	Supported.
dot1agCfmLtrOrganizationSpecificTlv	Octet String	1.3.111.2.802.1.1.8.1.7.2.1.21	Always returns a NULL string.

## dot1agCfmMepDbTable

The dot1agCfmMepDbTable is the MEP Database. This database is maintained by every MEP. It maintains the information received about other MEPs in the Maintenance Domain. It is indexed by dot1agCfmMdIndex, dot1agCfmMaIndex, dot1agCfmMepIdentifier, and dot1agCfmMepDbRMepIdentifier. Only read-only access is available.

Object group name	Type	Object identifier	Comments
dot1agCfmMepDbRMepIdentifier	dot1agCfmMepId	1.3.111.2.802.1.1.8.1.7.3.1.1	Supported.
dot1agCfmMepDbRMepState	dot1agCfmRemoteMepState	1.3.111.2.802.1.1.8.1.7.3.1.2	Supported.
dot1agCfmMepDbRMepFailedOkTime	TimeStamp	1.3.111.2.802.1.1.8.1.7.3.1.3	Supported.
dot1agCfmMepDbMacAddress	MacAddress	1.3.111.2.802.1.1.8.1.7.3.1.4	Supported.
dot1agCfmMepDbRdi	TruthValue	1.3.111.2.802.1.1.8.1.7.3.1.5	Supported.
dot1agCfmMepDbPortStatusTlv	dot1agCfmPortStatus	1.3.111.2.802.1.1.8.1.7.3.1.6	Supported.
dot1agCfmMepDbInterfaceStatusTlv	dot1agCfmInterfaceStatus	1.3.111.2.802.1.1.8.1.7.3.1.7	Supported.
dot1agCfmMepDbChassisIdSubtype	IldpChassisIdSubtype	1.3.111.2.802.1.1.8.1.7.3.1.8	Supported.
dot1agCfmMepDbChassisId	IldpChassisId	1.3.111.2.802.1.1.8.1.7.3.1.9	Always returns a Null string.

Object group name	Type	Object identifier	Comments
dot1agCfmMepDbManAddressDo main	TDomain	1.3.111.2.802.1.1.8.1.7.3.1.10	Always returns {0,0}.
dot1agCfmMepDbManAddress	TAddress	1.3.111.2.802.1.1.8.1.7.3.1.11	Always returns a Null string.

## LLDP-MIB

The following tables in the LLDP-MIB are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

- IldpPortConfigTable
- IldpConfigManAddrTable
- Ildpstatistics
- IldpStatsTxPortTable
- IldpStatsRxPortTable
- IldpLocalSystemData
- IldpLocPortTable
- IldpLocManAddrTable
- IldpRemTable
- IldpRemManAddrTable
- IldpRemUnknownTLVTable
- IldpRemOrgDefInfoTable

### IldpPortConfigTable

The following table controls the LLDP frame transmission on the individual ports.

Object	Object identifier	Supported?
IldpPortConfigPortNum	1.0.8802.1.1.2.1.1.6.1.1	Yes
IldpPortConfigAdminStatus	1.0.8802.1.1.2.1.1.6.1.2	Yes
IldpPortConfigNotificationEnable	1.0.8802.1.1.2.1.1.6.1.3	Yes
IldpPortConfigTLVsTxEnable	1.0.8802.1.1.2.1.1.6.1.4	Yes

### IldpConfigManAddrTable

The following table controls the selection of LLDP management address TLV instances to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpConfigManAddrPortsTxEnable	1.0.8802.1.1.2.1.1.7.1.1	Yes

## Ildpstatistics

The following table lists the LLDP statistics group objects.

Object	Object identifier	Supported?
IldpStatsRemTablesLastChangeTime	1.0.8802.1.1.2.1.2.1	Yes
IldpStatsRemTablesInserts	1.0.8802.1.1.2.1.2.2	Yes
IldpStatsRemTablesDeletes	1.0.8802.1.1.2.1.2.3	Yes
IldpStatsRemTablesDrops	1.0.8802.1.1.2.1.2.4	Yes
IldpStatsRemTablesAgeouts	1.0.8802.1.1.2.1.2.5	Yes

## IldpStatsTxPortTable

The following table contains LLDP transmission statistics for the individual ports.

Object	Object identifier	Supported?
IldpStatsTxPortNum	1.0.8802.1.1.2.1.2.6.1.1	Yes
IldpStatsTxPortFramesTotal	1.0.8802.1.1.2.1.2.6.1.2	Yes

## IldpStatsRxPortTable

The following table contains LLDP reception statistics for the individual ports.

Object	Object identifier	Supported?
IldpStatsRxPortNum	1.0.8802.1.1.2.1.2.7.1.1	Yes
IldpStatsRxPortFramesDiscardedTotal	1.0.8802.1.1.2.1.2.7.1.2	Yes
IldpStatsRxPortFramesErrors	1.0.8802.1.1.2.1.2.7.1.3	Yes
IldpStatsRxPortFramesTotal	1.0.8802.1.1.2.1.2.7.1.4	Yes
IldpStatsRxPortTLVsDiscardedTotal	1.0.8802.1.1.2.1.2.7.1.5	Yes
IldpStatsRxPortTLVsUnrecognizedTotal	1.0.8802.1.1.2.1.2.7.1.6	Yes
IldpStatsRxPortAgeoutsTotal	1.0.8802.1.1.2.1.2.7.1.7	Yes

## IldpLocalSystemData

The following table lists the LLDP local system data objects.

Object	Object identifier	Supported?
IldpLocChassisIdSubtype	1.0.8802.1.1.2.1.3.1	Yes
IldpLocChassisId	1.0.8802.1.1.2.1.3.2	Yes
IldpLocSysName	1.0.8802.1.1.2.1.3.3	Yes
IldpLocSysDesc	1.0.8802.1.1.2.1.3.4	Yes

Object	Object identifier	Supported?
IldpLocSysCapSupported	1.0.8802.1.1.2.1.3.5	Yes
IldpLocSysCapEnabled	1.0.8802.1.1.2.1.3.6	Yes

### IldpLocPortTable

The following table contains one or more rows per-port information associated with the local system known to the agent.

Object	Object identifier	Supported?
IldpLocPortNum	1.0.8802.1.1.2.1.3.7.1.1	Yes
IldpLocPortIdSubtype	1.0.8802.1.1.2.1.3.7.1.2	Yes
IldpLocPortId	1.0.8802.1.1.2.1.3.7.1.3	Yes
IldpLocPortDesc	1.0.8802.1.1.2.1.3.7.1.4	Yes

### IldpLocManAddrTable

The following table contains management address information on the local system known to the agent.

Object	Object identifier	Supported?
IldpLocManAddrSubtype	1.0.8802.1.1.2.1.3.8.1.1	Yes
IldpLocManAddr	1.0.8802.1.1.2.1.3.8.1.2	Yes
IldpLocManAddrLen	1.0.8802.1.1.2.1.3.8.1.3	Yes
IldpLocManAddrIfSubtype	1.0.8802.1.1.2.1.3.8.1.4	Yes
IldpLocManAddrIfId	1.0.8802.1.1.2.1.3.8.1.5	Yes
IldpLocManAddrOID	1.0.8802.1.1.2.1.3.8.1.6	Yes

### IldpRemTable

The following table contains one or more rows per-physical network connection known to the agent.

Object	Object identifier	Supported?
IldpRemTimeMark	1.0.8802.1.1.2.1.4.1.1.1	Yes
IldpRemLocalPortNum	1.0.8802.1.1.2.1.4.1.1.2	Yes
IldpRemIndex	1.0.8802.1.1.2.1.4.1.1.3	Yes
IldpRemChassisIdSubtype	1.0.8802.1.1.2.1.4.1.1.4	Yes
IldpRemChassisId	1.0.8802.1.1.2.1.4.1.1.5	Yes
IldpRemPortIdSubtype	1.0.8802.1.1.2.1.4.1.1.6	Yes
IldpRemPortId	1.0.8802.1.1.2.1.4.1.1.7	Yes
IldpRemPortDesc	1.0.8802.1.1.2.1.4.1.1.8	Yes



Object	Object identifier	Supported?
IldpRemSysName	1.0.8802.1.1.2.1.4.1.1.9	Yes
IldpRemSysDesc	1.0.8802.1.1.2.1.4.1.1.10	Yes
IldpRemSysCapSupported	1.0.8802.1.1.2.1.4.1.1.11	Yes
IldpRemSysCapEnabled	1.0.8802.1.1.2.1.4.1.1.12	Yes

## IldpRemManAddrTable

The following table contains one or more rows per-management address information on the remote system learned on a particular port contained in the local chassis known to the agent.

Object	Object identifier	Supported?
IldpRemManAddrSubtype	1.0.8802.1.1.2.1.4.2.1.1	Yes
IldpRemManAddr	1.0.8802.1.1.2.1.4.2.1.2	Yes
IldpRemManAddrRfSubtype	1.0.8802.1.1.2.1.4.2.1.3	Yes
IldpRemManAddrRfId	1.0.8802.1.1.2.1.4.2.1.4	Yes
IldpRemManAddrOID	1.0.8802.1.1.2.1.4.2.1.5	Yes

## IldpRemUnknownTLVTable

The following table contains information about an incoming TLV that is not recognized by the receiving LLDP agent.

Object	Object identifier	Supported?
IldpRemUnknownTLVType	1.0.8802.1.1.2.1.4.3.1.1	Yes
IldpRemUnknownTLVInfo	1.0.8802.1.1.2.1.4.3.1.2	Yes

## IldpRemOrgDefInfoTable

The following table contains one or more rows per physical network connection that advertises the organizationally-defined information.

Object	Object identifier	Supported?
IldpRemOrgDefInfoOUI	1.0.8802.1.1.2.1.4.4.1.1	Yes
IldpRemOrgDefInfoSubtype	1.0.8802.1.1.2.1.4.4.1.2	Yes
IldpRemOrgDefInfoIndex	1.0.8802.1.1.2.1.4.4.1.3	Yes
IldpRemOrgDefInfo	1.0.8802.1.1.2.1.4.4.1.4	Yes

## LLDP-EXT-DOT1-MIB

The following tables in the LLDP-EXT-DOT1-MIB are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

- IldpXdot1ConfigPortVlanTable
- IldpXdot1ConfigVlanNameTable
- IldpXdot1ConfigProtoVlanTable
- IldpXdot1ConfigProtocolTable
- IldpXdot1LocTable
- IldpXdot1LocProtoVlanTable
- IldpXdot1LocVlanNameTable
- IldpXdot1LocProtocolTable
- IldpXdot1RemTable
- IldpXdot1RemProtoVlanTable
- IldpXdot1RemVlanNameTable
- IldpXdot1RemProtocolTable

### IldpXdot1ConfigPortVlanTable

The following table lists the object that controls the selection of LLDP Port VLAN-ID TLVs to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpXdot1ConfigPortVlanTxEnable	1.0.8802.1.1.2.1.5.32962.1.1.1.1	Yes

### IldpXdot1ConfigVlanNameTable

The following table lists the object that controls the selection of LLDP VLAN name TLV instances to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpXdot1ConfigVlanNameTxEnable	1.0.8802.1.1.2.1.5.32962.1.1.2.1	Yes

### IldpXdot1ConfigProtoVlanTable

The following table lists the object that controls selection of LLDP Port and Protocol VLAN-ID TLV instances to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpXdot1ConfigProtoVlanTxEnable	1.0.8802.1.1.2.1.5.32962.1.1.3.1	Yes

## IldpXdot1ConfigProtocolTable

The following table lists the object that controls the selection of LLDP TLV instances to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpXdot1ConfigProtocolTxEnable	1.0.8802.1.1.2.1.5.32962.1.1.4. 1.1	Yes

## IldpXdot1LocTable

The following table contains one row per port for IEEE 802.1 organizationally-defined LLDP extension on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot1LocPortVlanId	1.0.8802.1.1.2.1.5.32962.1.2.1. 1.1	Yes

## IldpXdot1LocProtoVlanTable

The following table contains one or more rows per-port and per-protocol VLAN information about the local system.

Object	Object identifier	Supported?
IldpXdot1LocProtoVlanId	1.0.8802.1.1.2.1.5.32962.1.2.2. 1.1	Yes
IldpXdot1LocProtoVlanSupported	1.0.8802.1.1.2.1.5.32962.1.2.2. 1.2	Yes
IldpXdot1LocProtoVlanEnabled	1.0.8802.1.1.2.1.5.32962.1.2.2. 1.3	Yes

## IldpXdot1LocVlanNameTable

The following table contains one or more rows per IEEE 802.1Q VLAN name information on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot1LocVlanId	1.0.8802.1.1.2.1.5.32962.1.2.3. 1.1	Yes
IldpXdot1LocVlanName	1.0.8802.1.1.2.1.5.32962.1.2.3. 1.2	Yes

## IldpXdot1LocProtocolTable

The following table contains one or more rows per-protocol identity information on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot1LocProtocolIndex	1.0.8802.1.1.2.1.5.32962.1.2.4.1.1	Yes
IldpXdot1LocProtocolId	1.0.8802.1.1.2.1.5.32962.1.2.4.1.2	Yes

### IldpXdot1RemTable

The following table contains one or more rows per-physical network connection known to the agent.

Object	Object identifier	Supported?
IldpXdot1RemPortVlanId	1.0.8802.1.1.2.1.5.32962.1.3.1.1.1	Yes

### IldpXdot1RemProtoVlanTable

The following table contains one or more rows per-port and per-protocol VLAN information about the remote system received on the particular port.

Object	Object identifier	Supported?
IldpXdot1RemProtoVlanId	1.0.8802.1.1.2.1.5.32962.1.3.2.1.1	Yes
IldpXdot1RemProtoVlanSupported	1.0.8802.1.1.2.1.5.32962.1.3.2.1.2	Yes
IldpXdot1RemProtoVlanEnabled	1.0.8802.1.1.2.1.5.32962.1.3.2.1.3	Yes

### IldpXdot1RemVlanNameTable

The following table contains one or more rows per IEEE 802.1Q VLAN name information about the remote system received on the particular port.

Object	Object identifier	Supported?
IldpXdot1RemVlanId	1.0.8802.1.1.2.1.5.32962.1.3.3.1.1	Yes
IldpXdot1RemVlanName	1.0.8802.1.1.2.1.5.32962.1.3.3.1.2	Yes

### IldpXdot1RemProtocolTable

The following table contains one or more rows per protocol information about the remote system received on the particular port.

Object	Object identifier	Supported?
IldpXdot1RemProtocollIndex	1.0.8802.1.1.2.1.5.32962.1.3.4.1.1	Yes
IldpXdot1RemProtocollId	1.0.8802.1.1.2.1.5.32962.1.3.4.1.2	Yes

## LLDP-EXT-DOT3-MIB

The following tables in the LLDP-EXT-DOT3-MIB are supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

- IldpXdot3PortConfigTable
- IldpXdot3LocPortTable
- IldpXdot3LocPowerTable
- IldpXdot3LocLinkAggTable
- IldpXdot3LocMaxFrameSizeTable
- IldpXdot3RemPortTable
- IldpXdot3RemPowerTable
- IldpXdot3RemLinkAggTable
- IldpXdot3RemMaxFrameSizeTable

### IldpXdot3PortConfigTable

The following table lists the objects that controls the selection of LLDP TLVs to be transmitted on the individual ports.

Object	Object identifier	Supported?
IldpXdot3PortConfigTLVsTxEnable	1.0.8802.1.1.2.1.5.4623.1.1.1.1.1	Yes

### IldpXdot3LocPortTable

The following table contains one row per port of Ethernet port information (as part of the LLDP 802.3 organizational extension) on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot3LocPortAutoNegSupported	1.0.8802.1.1.2.1.5.4623.1.2.1.1.1	Yes
IldpXdot3LocPortAutoNegEnabled	1.0.8802.1.1.2.1.5.4623.1.2.1.1.2	Yes
IldpXdot3LocPortAutoNegAdvertisedCap	1.0.8802.1.1.2.1.5.4623.1.2.1.1.3	Yes
IldpXdot3LocPortOperMauType	1.0.8802.1.1.2.1.5.4623.1.2.1.1.4	Yes

## IldpXdot3LocPowerTable

The following table contains one row per port of power Ethernet information (as part of the LLDP 802.3 organizational extension) on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot3LocPowerPortClass	1.0.8802.1.1.2.1.5.4623.1.2.2.1.1	Yes
IldpXdot3LocPowerMDISupported	1.0.8802.1.1.2.1.5.4623.1.2.2.1.2	Yes
IldpXdot3LocPowerMDIEnabled	1.0.8802.1.1.2.1.5.4623.1.2.2.1.3	Yes
IldpXdot3LocPowerPairControlable	1.0.8802.1.1.2.1.5.4623.1.2.2.1.4	Yes
IldpXdot3LocPowerPairs	1.0.8802.1.1.2.1.5.4623.1.2.2.1.5	Yes
IldpXdot3LocPowerClass	1.0.8802.1.1.2.1.5.4623.1.2.2.1.6	Yes

## IldpXdot3LocLinkAggTable

The following table contains one row per port of link aggregation information (as part of the LLDP 802.3 organizational extension) on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot3LocLinkAggStatus	1.0.8802.1.1.2.1.5.4623.1.2.3.1.1	Yes
IldpXdot3LocLinkAggPortId	1.0.8802.1.1.2.1.5.4623.1.2.3.1.2	Yes

## IldpXdot3LocMaxFrameSizeTable

The following table contains one row per port of maximum frame size information (as part of the LLDP 802.3 organizational extension) on the local system known to the agent.

Object	Object identifier	Supported?
IldpXdot3LocMaxFrameSize	1.0.8802.1.1.2.1.5.4623.1.2.4.1.1	Yes

## IldpXdot3RemPortTable

The following table contains Ethernet port information (as part of the LLDP 802.3 organizational extension) of the remote system.

Object	Object identifier	Supported?
IldpXdot3RemPortAutoNegSupported	1.0.8802.1.1.2.1.5.4623.1.3.1.1.1	Yes
IldpXdot3RemPortAutoNegEnabled	1.0.8802.1.1.2.1.5.4623.1.3.1.1.2	Yes
IldpXdot3RemPortAutoNegAdvertisedCap	1.0.8802.1.1.2.1.5.4623.1.3.1.1.3	Yes
IldpXdot3RemPortOperMauType	1.0.8802.1.1.2.1.5.4623.1.3.1.1.4	Yes

## IldpXdot3RemPowerTable

The following table contains Ethernet power information (as part of the LLDP 802.3 organizational extension) of the remote system.

Object	Object identifier	Supported?
IldpXdot3RemPowerPortClass	1.0.8802.1.1.2.1.5.4623.1.3.2.1.1	Yes
IldpXdot3RemPowerMDISupported	1.0.8802.1.1.2.1.5.4623.1.3.2.1.2	Yes
IldpXdot3RemPowerMDIEnabled	1.0.8802.1.1.2.1.5.4623.1.3.2.1.3	Yes
IldpXdot3RemPowerPairControlable	1.0.8802.1.1.2.1.5.4623.1.3.2.1.4	Yes
IldpXdot3RemPowerPairs	1.0.8802.1.1.2.1.5.4623.1.3.2.1.5	Yes
IldpXdot3RemPowerClass	1.0.8802.1.1.2.1.5.4623.1.3.2.1.6	Yes

## IldpXdot3RemLinkAggTable

The following table contains port link aggregation information (as part of the LLDP 802.3 organizational extension) of the remote system.

Object	Object identifier	Supported?
IldpXdot3RemLinkAggStatus	1.0.8802.1.1.2.1.5.4623.1.3.3.1.1	Yes
IldpXdot3RemLinkAggPortId	1.0.8802.1.1.2.1.5.4623.1.3.3.1.2	Yes

## IldpXdot3RemMaxFrameSizeTable

The table contains one row per port of maximum frame size information (as part of the LLDP 802.3 organizational extension) of the remote system.

Object	Object identifier	Supported?
IldpXdot3RemMaxFrameSize	1.0.8802.1.1.2.1.5.4623.1.3.4.1.1	Yes

## 2 Supported Standard MIBs



## Registration MIB Definition

---

This section describes the Registration objects that identify the Foundry product that is being managed. The following table presents the objects for product registration. The sysOID will return one of these values.

Object name and identifier	Description
snFIWGSwitch brcdIp.1.3.1.1	Stackable FastIron Workgroup Switch
snFIBBSwitch brcdIp.1.3.1.2	Stackable FastIron Backbone Switch
snNIRouter brcdIp.1.3.2.1	Stackable NetIron Router
snSI brcdIp.1.3.3.1	Stackable ServerIron
snSIXL brcdIp.1.3.3.2	Stackable ServerIronXL
snSIXLTCS brcdIp.1.3.3.3	Stackable ServerIronXL TCS
snTISwitch brcdIp.1.3.4.1	Stackable Turbolron Switch
snTIRouter brcdIp.1.3.4.2	Stackable Turbolron Router
snT8Switch brcdIp.1.3.5.1	Stackable Turbolron/8 Switch
snT8Router brcdIp.1.3.5.2	Stackable Turbolron/8 Router
snT8SI brcdIp.1.3.5.3	Stackable ServerIronXL
snT8SIXLG brcdIp.1.3.5.4	Stackable ServerIronXLG
snBI4000Switch brcdIp.1.3.6.1	BigIron 4000 Switch
snBI4000Router brcdIp.1.3.6.2	BigIron 4000 Router
snBI4000SI brcdIp.1.3.6.3	BigServerIron, 4-slot
snBI8000Switch brcdIp.1.3.7.1	BigIron 8000 Switch
snBI8000Router brcdIp.1.3.7.2	BigIron 8000 Router

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snBI8000SI brcdIp.1.3.7.3	BigServerIron
snFI2Switch brcdIp.1.3.8.1	FastIron II Switch
snFI2Router brcdIp.1.3.8.2	FastIron II Router
snFI2PlusSwitch brcdIp.1.3.9.1	FastIron II Plus Switch
snFI2PlusRouter brcdIp.1.3.9.2	FastIron II Plus Router
snNI400Router brcdIp.1.3.10.1	NetIron Router
snNI800Router brcdIp.1.3.11.1	NetIron 800 Router
snFI2GCSwitch brcdIp.1.3.12.1	FastIron II GC Switch
snFI2GCRouter brcdIp.1.3.12.2	FastIron II GC Router
snFI2PlusGCSwitch brcdIp.1.3.13.1	FastIron II Plus GC Switch
snFI2PlusGCRouter brcdIp.1.3.13.2	FastIron II Plus GC Router
snBigIron15000 brcdIp.1.3.14.1	BigIron 15000 Switch
snBI15000Router brcdIp.1.3.14.2	BigIron 15000 Router
snBI15000SI brcdIp.1.3.14.3	BigIron 15000 ServerIron for M2-M4 modules running the BS2 ServerIron code
snNI1500Router brcdIp.1.3.15.1	NetIron 1500 Router
snFI3Switch brcdIp.1.3.16.1	FastIron III Switch
snFI3Router brcdIp.1.3.16.2	FastIron III Router
snFI3GCSwitch brcdIp.1.3.17.1	FastIron III GC Switch
snFI3GCRouter brcdIp.1.3.17.2	FastIron III GC Router
snSI400Switch brcdIp.1.3.18.1	ServerIron 400 Switch
snSI400Router brcdIp.1.3.18.2	ServerIron 400 Router

<b>Object name and identifier</b>	<b>Description</b>
snSI800Switch brcdIp.1.3.19.1	ServerIron 800 Switch
snSI800Router brcdIp.1.3.19.2	ServerIron 800 Router
sn4802Switch brcdIp.1.3.21.1	Stackable 4802 Switch
sn4802Router brcdIp.1.3.21.2	Stackable 4802 Router
sn4802SI brcdIp.1.3.21.3	Stackable 4802 ServerIron
snFI400Switch brcdIp.1.3.22.1	FastIron 400 Switch
snFI400Router brcdIp.1.3.22.2	FastIron 400 Router
snFI800Switch brcdIp.1.3.23.1	FastIron 800 Switch
snFI800Router brcdIp.1.3.23.2	FastIron 800 Router
snFI1500Switch brcdIp.1.3.24.1	FastIron 1500 Switch
snFI1500Router brcdIp.1.3.24.2	FastIron 1500 Router
snFES2402Switch brcdIp.1.3.25.1	FastIron Edge Switch 2402 Switch
snFES2402Router brcdIp.1.3.25.2	FastIron Edge Switch 2402 Router
snFES4802Switch brcdIp.1.3.26.1	FastIron Edge Switch 4802 Switch
snFES4802Router brcdIp.1.3.26.2	FastIron Edge Switch 4802 Router
snFES9604Switch brcdIp.1.3.27.1	FastIron Edge Switch 9604 Switch
snFES9604Router brcdIp.1.3.27.2	FastIron Edge Switch 9604 Router
snFES12GCFSwitch brcdIp.1.3.28.1	FastIron Edge Switch 12GCF Switch
snFES12GCFRouter brcdIp.1.3.28.2	FastIron Edge Switch 12GCF Router
snFES2402POESwitch brcdIp.1.3.29.1	FastIron Edge Switch 2402 Power Over Ethernet Switch
snFES2402POERouter brcdIp.1.3.29.2	FastIron Edge Switch 2402 Power Over Ethernet Router

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFES4802POESwitch brcdIp.1.3.30.1	FastIron Edge Switch 4802 Power Over Ethernet Switch
snFES4802POERouter brcdIp.1.3.30.2	FastIron Edge Switch 4802 Power Over Ethernet Router
snNI4802Switch brcdIp.1.3.31.1	NetIron 4802 Switch
snNI4802Router brcdIp.1.3.31.2	NetIron 4802 Router
snBIMG8Switch brcdIp.1.3.32.1	BigIron MG8 Switch
snBIMG8Router brcdIp.1.3.32.2	BigIron MG8 Router
snNI40GRouter brcdIp.1.3.33.2	NetIron 40G Router
snFESX424Switch brcdIp.1.3.34.1.1.1.1	FastIron Edge Switch X Series 424 Switch
snFESX424Router brcdIp.1.3.34.1.1.1.2	FastIron Edge Switch X Series 424 Router
snFESX424PremSwitch brcdIp.1.3.34.1.1.2.1	FastIron Edge Switch X Series 424 Premium Switch
snFESX424PremRouter brcdIp.1.3.34.1.1.2.2	FastIron Edge Switch X Series 424 Premium Router
snFESX424Plus1XGSwitch brcdIp.1.3.34.1.2.1.1	FastIron Edge Switch X Series 424 Plus 1XG Switch
snFESX424Plus1XGRouter brcdIp.1.3.34.1.2.1.2	FastIron Edge Switch X Series 424 Plus 1XG Router
snFESX424Plus1XGPremSwitch brcdIp.1.3.34.1.2.2.1	FastIron Edge Switch X Series 424 Plus 1XG Premium Switch
snFESX424Plus1XGPremRouter brcdIp.1.3.34.1.2.2.2	FastIron Edge Switch X Series 424 Plus 1XG Premium Router
snFESX424Plus2XGSwitch brcdIp.1.3.34.1.3.1.1	FastIron Edge Switch X Series 424 Plus 2XG Switch
snFESX424Plus2XGRouter brcdIp.1.3.34.1.3.1.2	FastIron Edge Switch X Series 424 Plus 2XG Router
snFESX424Plus2XGPremSwitch brcdIp.1.3.34.1.3.2.1	FastIron Edge Switch X Series 424 Plus 2XG Premium Switch
snFESX424Plus2XGPremRouter brcdIp.1.3.34.1.3.2.2	FastIron Edge Switch X Series 424 Plus 2XG Premium Router
snFESX448Switch brcdIp.1.3.34.2.1.1.1	FastIron Edge Switch X Series 448 Switch
snFESX448Router brcdIp.1.3.34.2.1.1.2	FastIron Edge Switch X Series 448 Router

<b>Object name and identifier</b>	<b>Description</b>
snFESX448PremSwitch brcdIp.1.3.34.2.1.2.1	FastIron Edge Switch X Series 448 Premium Switch
snFESX448PremRouter brcdIp.1.3.34.2.1.2.2	FastIron Edge Switch X Series 448 Premium Router
snFESX448Plus1XGSwitch brcdIp.1.3.34.2.2.1.1	FastIron Edge Switch X Series 448 Plus 1XG Switch
snFESX448Plus1XGRouter brcdIp.1.3.34.2.2.1.2	FastIron Edge Switch X Series 448 Plus 1XG Router
snFESX448Plus1XGPremSwitch brcdIp.1.3.34.2.2.2.1	FastIron Edge Switch X Series 448 Plus 1XG Premium Switch
snFESX448Plus1XGPremRouter brcdIp.1.3.34.2.2.2.2	FastIron Edge Switch X Series 448 Plus 1XG Premium Router
snFESX448Plus2XGSwitch brcdIp.1.3.34.2.3.1.1	FastIron Edge Switch X Series 448 Plus 2XG Switch
snFESX448Plus2XGRouter brcdIp.1.3.34.2.3.1.2	FastIron Edge Switch X Series 448 Plus 2XG Router
snFESX448Plus2XGPremSwitch brcdIp.1.3.34.2.3.2.1	FastIron Edge Switch X Series 448 Plus 2XG Premium Switch
snFESX448Plus2XGPremRouter brcdIp.1.3.34.2.3.2.2	FastIron Edge Switch X Series 448 Plus 2XG Premium Router
snFESX424FiberSwitch brcdIp.1.3.34.3.1.1.1	FastIron Edge Switch X Series 424 Fiber Switch
snFESX424FiberRouter brcdIp.1.3.34.3.1.1.2	FastIron Edge Switch X Series 424 Fiber Router
snFESX424FiberPremSwitch brcdIp.1.3.34.3.1.2.1	FastIron Edge Switch X Series 424 Fiber Premium Switch
snFESX424FiberPremRouter brcdIp.1.3.34.3.1.2.2	FastIron Edge Switch X Series 424 Fiber Premium Router
snFESX424FiberPlus1XGSwitch brcdIp.1.3.34.3.2.1.1	FastIron Edge Switch X Series 424 Fiber plus 1, 10 Gb port Switch
snFESX424FiberPlus1XGRouter brcdIp.1.3.34.3.2.1.2	FastIron Edge Switch X Series 424 Fiber plus 1, 10 Gb port Router
snFESX424FiberPlus1XGPremSwitch brcdIp.1.3.34.3.2.2.1	FastIron Edge Switch X Series 424 Fiber plus 1, 10 Gb port Premium Switch
snFESX424FiberPlus1XGPremRouter brcdIp.1.3.34.3.2.2.2	FastIron Edge Switch X Series 424 Fiber plus 1, 10 Gb port Premium Router
snFESX424FiberPlus2XGSwitch brcdIp.1.3.34.3.3.1.1	FastIron Edge Switch X Series 424 Fiber plus 2, 10 Gb ports Switch
snFESX424FiberPlus2XGRouter brcdIp.1.3.34.3.3.1.2	FastIron Edge Switch X Series 424 Fiber plus 2, 10 Gb ports Router

### 3 Registration MIB Definition

Object name and identifier	Description
snFESX424FiberPlus2XGPremSwitch brcdIp.1.3.34.3.3.2.1	FastIron Edge Switch X Series 424 Fiber plus 2, 10 Gb ports Premium Switch
snFESX424FiberPlus2XGPremRouter brcdIp.1.3.34.3.3.2.2	FastIron Edge Switch X Series 424 Fiber plus 2, 10 Gb ports Premium Router
snFESX448FiberSwitch brcdIp.1.3.34.4.1.1.1	FastIron Edge Switch X Series 448 Fiber Switch
snFESX448FiberRouter brcdIp.1.3.34.4.1.1.2	FastIron Edge Switch X Series 448 Fiber Router
snFESX448FiberPremSwitch brcdIp.1.3.34.4.1.2.1	FastIron Edge Switch X Series 448 Fiber Premium Switch
snFESX448FiberPremRouter brcdIp.1.3.34.4.1.2.2	FastIron Edge Switch X Series 448 Fiber Premium Router
snFESX448FiberPlus1XGSwitch brcdIp.1.3.34.4.2.1.1	FastIron Edge Switch X Series 448 Fiber plus 1, 10 Gb port Switch
snFESX448FiberPlus1XGRouter brcdIp.1.3.34.4.2.1.2	FastIron Edge Switch X Series 448 Fiber plus 1, 10 Gb port Router
snFESX448FiberPlus1XGPremSwitch brcdIp.1.3.34.4.2.2.1	FastIron Edge Switch X Series 448 Fiber plus 1, 10 Gb port Premium Switch
snFESX448FiberPlus1XGPremRouter brcdIp.1.3.34.4.2.2.2	FastIron Edge Switch X Series 448 Fiber plus 1, 10 Gb port Premium Router
snFESX448FiberPlus2XGSwitch brcdIp.1.3.34.4.3.1.1	FastIron Edge Switch X Series 448 Fiber plus 2, 10 Gb ports Switch
snFESX448FiberPlus2XGRouter brcdIp.1.3.34.4.3.1.2	FastIron Edge Switch X Series 448 Fiber plus 2, 10 Gb ports Router
snFESX448FiberPlus2XGPremSwitch brcdIp.1.3.34.4.3.2.1	FastIron Edge Switch X Series 448 Fiber plus 2, 10 Gb ports Premium Switch
snFESX448FiberPlus2XGPremRouter brcdIp.1.3.34.4.3.2.2	FastIron Edge Switch X Series 448 Fiber plus 2, 10 Gb ports Premium Router
snFESX424POESwitch brcdIp.1.3.34.5.1.1.1	FastIron Edge Switch X Series 424 POE Switch
snFESX424POERouter brcdIp.1.3.34.5.1.1.2	FastIron Edge Switch X Series 424 POE Router
snFESX424POEPremSwitch brcdIp.1.3.34.5.1.2.1	FastIron Edge Switch X Series 424 POE Premium Switch
snFESX424POEPremRouter brcdIp.1.3.34.5.1.2.2	FastIron Edge Switch X Series 424 POE Premium Router
snFESX424POEPrem6Router brcdIp.1.3.34.5.1.2.3	FastIron Edge Switch X Series 424 POE PREM6 Router

Object name and identifier	Description
snFESX424POEPlus1XGSwitch brcdIp.1.3.34.5.2.1.1	FastIron Edge Switch X Series 424 POE plus 1, 10 Gb port Switch
snFESX424POEPlus1XGRouter brcdIp.1.3.34.5.2.1.2	FastIron Edge Switch X Series 424 POE plus 1, 10 Gb port Router
snFESX424POEPlus1XGPremSwitch brcdIp.1.3.34.5.2.2.1	FastIron Edge Switch X Series 424 POE plus 1, 10 Gb port Premium Switch
snFESX424POEPlus1XGPremRouter brcdIp.1.3.34.5.2.2.2	FastIron Edge Switch X Series 424 POE plus 1, 10 Gb port Premium Router
snFESX424POEPlus2XGSwitch brcdIp.1.3.34.5.3.1.1	FastIron Edge Switch X Series 424 POE plus 2, 10 Gb ports Switch
snFESX424POEPlus2XGRouter brcdIp.1.3.34.5.3.1.2	FastIron Edge Switch X Series 424 POE plus 2, 10 Gb ports Router
snFESX424POEPlus2XGPremSwitch brcdIp.1.3.34.5.3.2.1	FastIron Edge Switch X Series 424 POE plus 2, 10 Gb ports Premium Switch
snFESX424POEPlus2XGPremRouter brcdIp.1.3.34.5.3.2.2	FastIron Edge Switch X Series 424 POE plus 2, 10 Gb ports Premium Router
snFESX624Switch brcdIp.1.3.34.6.1.1.1	FastIron Edge Switch X Series 624 Switch
snFESX624Router brcdIp.1.3.34.6.1.1.2	FastIron Edge Switch X Series 624 Router
snFESX624PremSwitch brcdIp.1.3.34.6.1.2.1	FastIron Edge Switch X Series 624 Premium Switch
snFESX624PremRouter brcdIp.1.3.34.6.1.2.2	FastIron Edge Switch X Series 624 Premium Router
snFESX624Prem6Router brcdIp.1.3.34.6.1.2.3	FastIron Edge Switch X Series 624 PREM6 Router
snFESX624Plus1XGSwitch brcdIp.1.3.34.6.2.1.1	FastIron Edge Switch X Series 624 plus 1, 10 Gb port Switch
snFESX624Plus1XGRouter brcdIp.1.3.34.6.2.1.2	FastIron Edge Switch X Series 624 plus 1, 10 Gb port Router
snFESX624Plus1XGPremSwitch brcdIp.1.3.34.6.2.2.1	FastIron Edge Switch X Series 624 plus 1, 10 Gb port Premium Switch
snFESX624Plus1XGPremRouter brcdIp.1.3.34.6.2.2.2	FastIron Edge Switch X Series 624 plus 1, 10 Gb port Premium Router
snFESX624Plus1XGPrem6Router brcdIp.1.3.34.6.2.2.3	FastIron Edge Switch X Series 624 plus 1, 10 Gb port PREM6 Router
snFESX624Plus2XGSwitch brcdIp.1.3.34.6.3.1.1	FastIron Edge Switch X Series 624 plus 2, 10 Gb ports Switch
snFESX624Plus2XGRouter brcdIp.1.3.34.6.3.1.2	FastIron Edge Switch X Series 624 plus 2, 10 Gb ports Router

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFESX624Plus2XGPremSwitch brcdIp.1.3.34.6.3.2.1	FastIron Edge Switch X Series 624 plus 2, 10 Gb ports Premium Switch
snFESX624Plus2XGPremRouter brcdIp.1.3.34.6.3.2.2	FastIron Edge Switch X Series 624 plus 2, 10 Gb ports Premium Router
snFESX624Plus2XGPrem6Router brcdIp.1.3.34.6.3.2.3	FastIron Edge Switch X Series 624 plus 2, 10 Gb ports PREM6 Router
snFESX648PremSwitch brcdIp.1.3.34.7.1.2.1	FastIron Edge Switch X Series 648 Premium Switch
snFESX648PremRouter brcdIp.1.3.34.7.1.2.2	FastIron Edge Switch X Series 648 Premium Router
snFESX648Prem6Router brcdIp.1.3.34.7.1.2.3	FastIron Edge Switch X Series 648 PREM6 Router
snFESX648Plus1XGSwitch brcdIp.1.3.34.7.2.1.1	FastIron Edge Switch X Series 648 plus 1, 10 Gb port Switch
snFESX648Plus1XGRouter brcdIp.1.3.34.7.2.1.2	FastIron Edge Switch X Series 648 plus 1, 10 Gb port Router
snFESX648Plus1XGPremSwitch brcdIp.1.3.34.7.2.2.1	FastIron Edge Switch X Series 648 plus 1, 10 Gb port Premium Switch
snFESX648Plus1XGPremRouter brcdIp.1.3.34.7.2.2.2	FastIron Edge Switch X Series 648 plus 1, 10 Gb port Premium Router
snFESX648Plus1XGPrem6Router brcdIp.1.3.34.7.2.2.3	FastIron Edge Switch X Series 648 plus 1, 10 Gb port PREM6 Router
snFESX648Plus2XGSwitch brcdIp.1.3.34.7.3.1.1	FastIron Edge Switch X Series 648 plus 2, 10 Gb ports Switch
snFESX648Plus2XGRouter brcdIp.1.3.34.7.3.1.2	FastIron Edge Switch X Series 648 plus 2, 10 Gb ports Router
snFESX648Plus2XGPremSwitch brcdIp.1.3.34.7.3.2.1	FastIron Edge Switch X Series 648 plus 2, 10 Gb ports Premium Switch
snFESX648Plus2XGPremRouter brcdIp.1.3.34.7.3.2.2	FastIron Edge Switch X Series 648 plus 2, 10 Gb ports Premium Router
snFESX648Plus2XGPrem6Router brcdIp.1.3.34.7.3.2.3	FastIron Edge Switch X Series 648 plus 2, 10 Gb ports PREM6 Router
snFESX624FiberSwitch brcdIp.1.3.34.8.1.1.1	FastIron Edge Switch X Series 624 Fiber Switch
snFESX624FiberRouter brcdIp.1.3.34.8.1.1.2	FastIron Edge Switch X Series 624 Fiber Router
snFESX624FiberPremSwitch brcdIp.1.3.34.8.1.2.1	FastIron Edge Switch X Series 624 Fiber Premium Switch
snFESX624FiberPremRouter brcdIp.1.3.34.8.1.2.2	FastIron Edge Switch X Series 624 Fiber Premium Router
snFESX624FiberPrem6Router brcdIp.1.3.34.8.1.2.3	FastIron Edge Switch X Series 624 Fiber PREM6 Router



Object name and identifier	Description
snFESX624FiberPlus1XGSwitch brcdIp.1.3.34.8.2.1.1	FastIron Edge Switch X Series 624 Fiber plus 1, 10 Gb port Switch
snFESX624FiberPlus1XGRouter brcdIp.1.3.34.8.2.1.2	FastIron Edge Switch X Series 624 Fiber plus 1, 10 Gb port Router
snFESX624FiberPlus1XGPremSwitch brcdIp.1.3.34.8.2.2.1	FastIron Edge Switch X Series 624 Fiber plus 1, 10 Gb port Premium Switch
snFESX624FiberPlus1XGPremRouter brcdIp.1.3.34.8.2.2.2	FastIron Edge Switch X Series 624 Fiber plus 1, 10 Gb port Premium Router
snFESX624FiberPlus1XGPrem6Router brcdIp.1.3.34.8.2.2.3	FastIron Edge Switch X Series 624 Fiber plus 1, 10 Gb port PREM6 Router
snFESX624FiberPlus2XGSwitch brcdIp.1.3.34.8.3.1.1	FastIron Edge Switch X Series 624 Fiber plus 2, 10 Gb ports Switch
snFESX624FiberPlus2XGRouter brcdIp.1.3.34.8.3.1.2	FastIron Edge Switch X Series 624 Fiber plus 2, 10 Gb ports Router
snFESX624FiberPlus2XGPremSwitch brcdIp.1.3.34.8.3.2.1	FastIron Edge Switch X Series 624 Fiber plus 2, 10 Gb ports Premium Switch
snFESX624FiberPlus2XGPremRouter brcdIp.1.3.34.8.3.2.2	FastIron Edge Switch X Series 624 Fiber plus 2, 10 Gb ports Premium Router
snFESX624FiberPlus2XGPrem6Router brcdIp.1.3.34.8.3.2.3	FastIron Edge Switch X Series 624 Fiber plus 2, 10 Gb ports PREM6 Router
snFESX648FiberSwitch brcdIp.1.3.34.9.1.1.1	FastIron Edge Switch X Series 648 Fiber Switch
snFESX648FiberRouter brcdIp.1.3.34.9.1.1.2	FastIron Edge Switch X Series 648 Fiber Router
snFESX648FiberPremSwitch brcdIp.1.3.34.9.1.2.1	FastIron Edge Switch X Series 648 Fiber Premium Switch
snFESX648FiberPremRouter brcdIp.1.3.34.9.1.2.2	FastIron Edge Switch X Series 648 Fiber Premium Router
snFESX648FiberPrem6Router brcdIp.1.3.34.9.1.2.3	FastIron Edge Switch X Series 648 Fiber PREM6 Router
snFESX648FiberPlus1XGSwitch brcdIp.1.3.34.9.2.1.1	FastIron Edge Switch X Series 648 Fiber plus 1, 10 Gb port Switch
snFESX648FiberPlus1XGRouter brcdIp.1.3.34.9.2.1.2	FastIron Edge Switch X Series 648 Fiber plus 1, 10 Gb port Router
snFESX648FiberPlus1XGPremSwitch brcdIp.1.3.34.9.2.2.1	FastIron Edge Switch X Series 648 Fiber plus 1, 10 Gb port Premium Switch

### 3 Registration MIB Definition

Object name and identifier	Description
snFESX648FiberPlus1XGPremRouter brcdIp.1.3.34.9.2.2.2	FastIron Edge Switch X Series 648 Fiber plus 1, 10 Gb port Premium Router
snFESX648FiberPlus1XGPrem6Router brcdIp.1.3.34.9.2.2.3	FastIron Edge Switch X Series 648 Fiber plus 1, 10 Gb port PREM6 Router
snFESX648FiberPlus2XGSwitch brcdIp.1.3.34.9.3.1.1	FastIron Edge Switch X Series 648 Fiber plus 2, 10 Gb ports Switch
snFESX648FiberPlus2XGRouter brcdIp.1.3.34.9.3.1.2	FastIron Edge Switch X Series 648 Fiber plus 2, 10 Gb ports Router
snFESX648FiberPlus2XGPremSwitch brcdIp.1.3.34.9.3.2.1	FastIron Edge Switch X Series 648 Fiber plus 2, 10 Gb ports Premium Switch
snFESX648FiberPlus2XGPremRouter brcdIp.1.3.34.9.3.2.2	FastIron Edge Switch X Series 648 Fiber plus 2, 10 Gb ports Premium Router
snFESX648FiberPlus2XGPrem6Router brcdIp.1.3.34.9.3.2.3	FastIron Edge Switch X Series 648 Fiber plus 2, 10 Gb ports PREM6 Router
snFESX624POESwitch brcdIp.1.3.34.10.1.1.1	FastIron Edge Switch X Series 624 POE Switch
snFESX624POERouter brcdIp.1.3.34.10.1.1.2	FastIron Edge Switch X Series 624 POE Router
snFESX624POEPremSwitch brcdIp.1.3.34.10.1.2.1	FastIron Edge Switch X Series 624 POE Premium Switch
snFESX624POEPremRouter brcdIp.1.3.34.10.1.2.2	FastIron Edge Switch X Series 624 POE Premium Router
snFESX624POEPrem6Router brcdIp.1.3.34.10.1.2.3	FastIron Edge Switch X Series 624 POE PREM6 Router
snFESX624POEPlus1XGSwitch brcdIp.1.3.34.10.2.1.1	FastIron Edge Switch X Series 624 POE plus 1, 10 Gb port Switch
snFESX624POEPlus1XGRouter brcdIp.1.3.34.10.2.1.2	FastIron Edge Switch X Series 624 POE plus 1, 10 Gb port Router
snFESX624POEPlus1XGPremSwitch brcdIp.1.3.34.10.2.2.1	FastIron Edge Switch X Series 624 POE plus 1, 10 Gb port Premium Switch
snFESX624POEPlus1XGPremRouter brcdIp.1.3.34.10.2.2.2	FastIron Edge Switch X Series 624 POE plus 1, 10 Gb port Premium Router
snFESX624POEPlus1XGPrem6Router brcdIp.1.3.34.10.2.2.3	FastIron Edge Switch X Series 624 POE plus 1, 10 Gb port PREM6 Router
snFESX624POEPlus2XGSwitch brcdIp.1.3.34.10.3.1.1	FastIron Edge Switch X Series 624 POE plus 2, 10 Gb ports Switch

Object name and identifier	Description
snFESX624POEPlus2XGRouter brcdIp.1.3.34.10.3.1.2	FastIron Edge Switch X Series 624 POE plus 2, 10 Gb ports Router
snFESX624POEPlus2XGPremSwitch brcdIp.1.3.34.10.3.2.1	FastIron Edge Switch X Series 624 POE plus 2, 10 Gb ports Premium Switch
snFESX624POEPlus2XGPremRouter brcdIp.1.3.34.10.3.2.2	FastIron Edge Switch X Series 624 POE plus 2, 10 Gb ports Premium Router
snFESX624POEPlus2XGPrem6Router brcdIp.1.3.34.10.3.2.3	FastIron Edge Switch X Series 624 POE plus 2, 10 Gb ports PREM6 Router
snFESX624ESwitch brcdIp.1.3.34.11.1.1.1	FastIron Edge Switch X Series 624E Switch
snFESX624ERouter brcdIp.1.3.34.11.1.1.2	FastIron Edge Switch X Series 624E Router
snFESX624EPremSwitch brcdIp.1.3.34.11.1.2.1	FastIron Edge Switch X Series 624E Premium Switch
snFESX624EPremRouter brcdIp.1.3.34.11.1.2.2	FastIron Edge Switch X Series 624E Premium Router
snFESX624EPrem6Router brcdIp.1.3.34.11.1.2.3	FastIron Edge Switch X Series 624E PREM6 Router
snFESX624EPlus1XGSwitch brcdIp.1.3.34.11.2.1.1	FastIron Edge Switch X Series 624E plus 1, 10 Gb port Switch
snFESX624EPlus1XGRouter brcdIp.1.3.34.11.2.1.2	FastIron Edge Switch X Series 624E plus 1, 10 Gb port Router
snFESX624EPlus1XGPremSwitch brcdIp.1.3.34.11.2.2.1	FastIron Edge Switch X Series 624E plus 1, 10 Gb port Premium Switch
snFESX624EPlus1XGPremRouter brcdIp.1.3.34.11.2.2.2	FastIron Edge Switch X Series 624E plus 1, 10 Gb port Premium Router
snFESX624EPlus1XGPrem6Router brcdIp.1.3.34.11.2.2.3	FastIron Edge Switch X Series 624E plus 1, 10 Gb port PREM6 Router
snFESX624EPlus2XGSwitch brcdIp.1.3.34.11.3.1.1	FastIron Edge Switch X Series 624E plus 2, 10 Gb ports Switch
snFESX624EPlus2XGRouter brcdIp.1.3.34.11.3.1.2	FastIron Edge Switch X Series 624E plus 2, 10 Gb ports Router
snFESX624EPlus2XGPremSwitch brcdIp.1.3.34.11.3.2.1	FastIron Edge Switch X Series 624E plus 2, 10 Gb ports Premium Switch
snFESX624EPlus2XGPremRouter brcdIp.1.3.34.11.3.2.2	FastIron Edge Switch X Series 624E plus 2, 10 Gb ports Premium Router
snFESX624EPlus2XGPrem6Router brcdIp.1.3.34.11.3.2.3	FastIron Edge Switch X Series 624E plus 2, 10 Gb ports PREM6 Router
snFESX624EFiberSwitch brcdIp.1.3.34.12.1.1.1	FastIron Edge Switch X Series 624E Fiber Switch

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFESX624EFiberRouter brcdIp.1.3.34.12.1.1.2	FastIron Edge Switch X Series 624E Fiber Router
snFESX624EFiberPremSwitch brcdIp.1.3.34.12.1.2.1	FastIron Edge Switch X Series 624E Fiber Premium Switch
snFESX624EFiberPremRouter brcdIp.1.3.34.12.1.2.2	FastIron Edge Switch X Series 624E Fiber Premium Router
snFESX624EFiberPrem6Router brcdIp.1.3.34.12.1.2.3	FastIron Edge Switch X Series 624E Fiber PREM6 Router
snFESX624EFiberPlus1XGSwitch brcdIp.1.3.34.12.2.1.1	FastIron Edge Switch X Series 624E Fiber plus 1, 10 Gb port Switch
snFESX624EFiberPlus1XGRouter brcdIp.1.3.34.12.2.1.2	FastIron Edge Switch X Series 624E Fiber plus 1, 10 Gb port Router
snFESX624EFiberPlus1XGPremSwitch brcdIp.1.3.34.12.2.2.1	FastIron Edge Switch X Series 624E Fiber plus 1, 10 Gb port Premium Switch
snFESX624EFiberPlus1XGPremRouter brcdIp.1.3.34.12.2.2.2	FastIron Edge Switch X Series 624E Fiber plus 1, 10 Gb port Premium Router
snFESX624EFiberPlus1XGPrem6Router brcdIp.1.3.34.12.2.2.3	FastIron Edge Switch X Series 624E Fiber plus 1, 10 Gb port PREM6 Router
snFESX624EFiberPlus2XGSwitch brcdIp.1.3.34.12.3.1.1	FastIron Edge Switch X Series 624E Fiber plus 2, 10 Gb ports Switch
snFESX624EFiberPlus2XGRouter brcdIp.1.3.34.12.3.1.2	FastIron Edge Switch X Series 624E Fiber plus 2, 10 Gb ports Router
snFESX624EFiberPlus2XGPremSwitch brcdIp.1.3.34.12.3.2.1	FastIron Edge Switch X Series 624E Fiber plus 2, 10 Gb ports Premium Switch
snFESX624EFiberPlus2XGPremRouter brcdIp.1.3.34.12.3.2.2	FastIron Edge Switch X Series 624E Fiber plus 2, 10 Gb ports Premium Router
snFESX624EFiberPlus2XGPrem6Router brcdIp.1.3.34.12.3.2.3	FastIron Edge Switch X Series 624E Fiber plus 2, 10 Gb ports PREM6 Router
snFESX648ESwitch brcdIp.1.3.34.13.1.1.1	FastIron Edge Switch X Series 648E Switch
snFESX648ERouter brcdIp.1.3.34.13.1.1.2	FastIron Edge Switch X Series 648E Router
snFESX648EPremSwitch brcdIp.1.3.34.13.1.2.1	FastIron Edge Switch X Series 648E Premium Switch
snFESX648EPremRouter brcdIp.1.3.34.13.1.2.2	FastIron Edge Switch X Series 648E Premium Router
snFESX648EPrem6Router brcdIp.1.3.34.13.1.2.3	FastIron Edge Switch X Series 648E PREM6 Router

<b>Object name and identifier</b>	<b>Description</b>
snFESX648EPlus1XGSwitch brcdIp.1.3.34.13.2.1.1	FastIron Edge Switch X Series 648E plus 1, 10 Gb port Switch
snFESX648EPlus1XGRouter brcdIp.1.3.34.13.2.1.2	FastIron Edge Switch X Series 648E plus 1, 10 Gb port Router
snFESX648EPlus1XGPremSwitch brcdIp.1.3.34.13.2.2.1	FastIron Edge Switch X Series 648E plus 1, 10 Gb port Premium Switch
snFESX648EPlus1XGPremRouter brcdIp.1.3.34.13.2.2.2	FastIron Edge Switch X Series 648E plus 1, 10 Gb port Premium Router
snFESX648EPlus1XGPrem6Router brcdIp.1.3.34.13.2.2.3	FastIron Edge Switch X Series 648E plus 1, 10 Gb port PREM6 Router
snFESX648EPlus2XGSwitch brcdIp.1.3.34.13.3.1.1	FastIron Edge Switch X Series 648E plus 2, 10 Gb ports Switch
snFESX648EPlus2XGRouter brcdIp.1.3.34.13.3.1.2	FastIron Edge Switch X Series 648E plus 2, 10 Gb ports Router
snFESX648EPlus2XGPremSwitch brcdIp.1.3.34.13.3.2.1	FastIron Edge Switch X Series 648E plus 2, 10 Gb ports Premium Switch
snFESX648EPlus2XGPremRouter brcdIp.1.3.34.13.3.2.2	FastIron Edge Switch X Series 648E plus 2, 10 Gb ports Premium Router
snFESX648EPlus2XGPrem6Router brcdIp.1.3.34.13.3.2.3	FastIron Edge Switch X Series 648E plus 2, 10 Gb ports PREM6 Router
snFWSX424Switch brcdIp.1.3.35.1.1.1.1	FastIron Workgroup Switch X Series (FWSX) 424 Switch
snFWSX424Router brcdIp.1.3.35.1.1.1.2	FastIron Workgroup Switch X Series (FWSX) 424 Router
snFWSX424Plus1XGSwitch brcdIp.1.3.35.1.2.1.1	FastIron Workgroup Switch X Series (FWSX) 424 plus 1, 10 Gb port Switch
snFWSX424Plus1XGRouter brcdIp.1.3.35.1.2.1.2	FastIron Workgroup Switch X Series (FWSX) 424 plus 1, 10 Gb port Router
snFWSX424Plus2XGSwitch brcdIp.1.3.35.1.3.1.1	FastIron Workgroup Switch X Series (FWSX) 424 plus 2, 10 Gb ports Switch
snFWSX424Plus2XGRouter brcdIp.1.3.35.1.3.1.2	FastIron Workgroup Switch X Series (FWSX) 424 plus 2, 10 Gb ports Router
snFWSX448Switch brcdIp.1.3.35.2.1.1.1	FastIron Workgroup Switch X Series (FWSX) 448 Switch
snFWSX448Router brcdIp.1.3.35.2.1.1.2	FastIron Workgroup Switch X Series (FWSX) 448 Router
snFWSX448Plus1XGSwitch brcdIp.1.3.35.2.2.1.1	FastIron Workgroup Switch X Series (FWSX) 448 plus 1, 10 Gb port Switch
snFWSX448Plus1XGRouter brcdIp.1.3.35.2.2.1.2	FastIron Workgroup Switch X Series (FWSX) 448 plus 1, 10 Gb port Router
snFWSX448Plus2XGSwitch brcdIp.1.3.35.2.3.1.1	FastIron Workgroup Switch X Series (FWSX) 448 plus 2 , 10 Gb ports Switch

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFWSX448Plus2XGRouter brcdIp.1.3.35.2.3.1.2	FastIron Workgroup Switch X Series (FWSX) 448 plus 2, 10 Gb ports Router
snFastIronSuperXSwitch brcdIp.1.3.36.1.1	FastIron SuperX Switch
snFastIronSuperXRouter brcdIp.1.3.36.1.2	FastIron SuperX Router
snFastIronSuperXBaseL3Switch brcdIp.1.3.36.1.3	FastIron SuperX Base Layer 3 Switch
snFastIronSuperXPremSwitch brcdIp.1.3.36.2.1	FastIron SuperX Premium Switch
snFastIronSuperXPremRouter brcdIp.1.3.36.2.2	FastIron SuperX Premium Router
snFastIronSuperXPremBaseL3Switch brcdIp.1.3.36.2.3	FastIron SuperX Premium Base Layer 3 Switch
snFastIronSuperX800Switch brcdIp.1.3.36.3.1	FastIron SuperX 800 Switch
snFastIronSuperX800Router brcdIp.1.3.36.3.2	FastIron SuperX 800 Router
snFastIronSuperX800BaseL3Switch brcdIp.1.3.36.3.3	FastIron SuperX 800 Base Layer 3 Switch
snFastIronSuperX800PremSwitch brcdIp.1.3.36.4.1	FastIron SuperX 800 Premium Switch
snFastIronSuperX800PremRouter brcdIp.1.3.36.4.2	FastIron SuperX 800 Premium Router
snFastIronSuperX800PremBaseL3Switch brcdIp.1.3.36.4.3	FastIron SuperX 800 Premium Base Layer 3 Switch
snFastIronSuperX1600Switch brcdIp.1.3.36.5.1	FastIron SuperX 1600 Switch
snFastIronSuperX1600Router brcdIp.1.3.36.5.2	FastIron SuperX 1600 Router
snFastIronSuperX1600BaseL3Switch brcdIp.1.3.36.5.3	FastIron SuperX 1600 Base Layer 3 Switch
snFastIronSuperX1600PremSwitch brcdIp.1.3.36.6.1	FastIron SuperX 1600 Premium Switch
snFastIronSuperX1600PremRouter brcdIp.1.3.36.6.2	FastIron SuperX 1600 Premium Router
snFastIronSuperX1600PremBaseL3Switch brcdIp.1.3.36.6.3	FastIron SuperX 1600 Premium Base Layer 3 Switch

<b>Object name and identifier</b>	<b>Description</b>
snFastIronSuperXV6Switch brcdIp.1.3.36.7.1	FastIron SuperX IPv6 Switch
snFastIronSuperXV6Router brcdIp.1.3.36.7.2	FastIron SuperX IPv6 Router
snFastIronSuperXV6BaseL3Switch brcdIp.1.3.36.7.3	FastIron SuperX IPv6 Base Layer 3 Switch
snFastIronSuperXV6PremSwitch brcdIp.1.3.36.8.1	FastIron SuperX IPv6 Premium Switch
snFastIronSuperXV6PremRouter brcdIp.1.3.36.8.2	FastIron SuperX IPv6 Premium Router
snFastIronSuperXV6PremBaseL3Switch brcdIp.1.3.36.8.3	FastIron SuperX IPv6 Premium Base Layer 3 Switch
snFastIronSuperXV6Prem6Router brcdIp.1.3.36.8.4	FastIron SuperX IPv6 PREM6 Router
snFastIronSuperX800V6Switch brcdIp.1.3.36.9.1	FastIron SuperX 800 IPv6 Switch
snFastIronSuperX800V6Router brcdIp.1.3.36.9.2	FastIron SuperX 800 IPv6 Router
snFastIronSuperX800V6BaseL3Switch brcdIp.1.3.36.9.3	FastIron SuperX 800 IPv6 Base Layer 3 Switch
snFastIronSuperX800V6PremSwitch brcdIp.1.3.36.10.1	FastIron SuperX 800 IPv6 Premium Switch
snFastIronSuperX800V6PremRouter brcdIp.1.3.36.10.2	FastIron SuperX 800 IPv6 Premium Router
snFastIronSuperX800V6PremBaseL3Switch brcdIp.1.3.36.10.3	FastIron SuperX 800 IPv6 Premium Base Layer 3 Switch
snFastIronSuperX800V6Prem6Router brcdIp.1.3.36.10.4	FastIron SuperX 800 IPv6 PREM6 Router
snFastIronSuperX1600V6Switch brcdIp.1.3.36.11.1	FastIron SuperX 1600 IPv6 Switch
snFastIronSuperX1600V6Router brcdIp.1.3.36.11.2	FastIron SuperX 1600 IPv6 Router
snFastIronSuperX1600V6BaseL3Switch brcdIp.1.3.36.11.3	FastIron SuperX 1600 IPv6 Base Layer 3 Switch
snFastIronSuperX1600V6PremSwitch brcdIp.1.3.36.12.1	FastIron SuperX 1600 IPv6 Premium Switch

### 3 Registration MIB Definition

Object name and identifier	Description
snFastIronSuperX1600V6PremRouter brcdIp.1.3.36.12.2	FastIron SuperX 1600 IPv6 Premium Router
snFastIronSuperX1600V6PremBaseL3Switch brcdIp.1.3.36.12.3	FastIron SuperX 1600 IPv6 Premium Base Layer 3 Switch
snFastIronSuperX1600V6Prem6Router brcdIp.1.3.36.12.4	FastIron SuperX 1600 IPv6 PREM6 Router
snBigIronSuperXFamily brcdIp.1.3.37	BigIron SuperX Family
snBigIronSuperX brcdIp.1.3.37.1	BigIron SuperX
snBigIronSuperXSwitch brcdIp.1.3.37.1.1	BigIron SuperX Switch
snBigIronSuperXRouter brcdIp.1.3.37.1.2	BigIron SuperX Router
snBigIronSuperXBaseL3Switch brcdIp.1.3.37.1.3	BigIron SuperX Base Layer 3 Switch
snTurbolronSuperXFamily brcdIp.1.3.38	Turbolron SuperX Family
snTurbolronSuperX brcdIp.1.3.38.1	Turbolron SuperX
snTurbolronSuperXSwitch brcdIp.1.3.38.1.1	Turbolron SuperX Switch
snTurbolronSuperXRouter brcdIp.1.3.38.1.2	Turbolron SuperX Router
snTurbolronSuperXBaseL3Switch brcdIp.1.3.38.1.3	Turbolron SuperX Base Layer 3 Switch
snTurbolronSuperXPrem brcdIp.1.3.38.2	Turbolron SuperX Premium
snTurbolronSuperXPremSwitch brcdIp.1.3.38.2.1	Turbolron SuperX Premium Switch
snTurbolronSuperXPremRouter brcdIp.1.3.38.2.2	Turbolron SuperX Premium Router
snTurbolronSuperXPremBaseL3Switch brcdIp.1.3.38.2.3	Turbolron SuperX Premium Base Layer 3 Switch
snIMRFamily brcdIp.1.3.39	IMR Family
snNetIronIMR brcdIp.1.3.39.1	NetIron IMR 640 Family
snNIIMRRouter brcdIp.1.3.39.1.2	NetIron IMR 640 Router



<b>Object name and identifier</b>	<b>Description</b>
snBIRX16Switch brcdIp.1.3.40.1.1	BigIron RX-16 Switch
snBIRX16Router brcdIp.1.3.40.1.2	BigIron RX-16 Router
snBIRX8Switch brcdIp.1.3.40.2.1	BigIron RX-8 Switch
snBIRX8Router brcdIp.1.3.40.2.2	BigIron RX-8 Router
snBIRX4Switch brcdIp.1.3.40.3.1	BigIron RX-4 Switch
snBIRX4Router brcdIp.1.3.40.3.2	BigIron RX-4 Router
snBIRx32Router brcdIp.1.3.40.4.2	BigIron RX-32 Router
snNetIronXMR16000 brcdIp.1.3.41.1	NetIron XMR-16000 Family
snNIXMR16000Router brcdIp.1.3.41.1.2	NetIron XMR-16000 Router
snNetIronXMR8000 brcdIp.1.3.41.2	NetIron XMR-8000 Family
snNIXMR8000Router brcdIp.1.3.41.2.2	NetIron XMR-8000 Router
snNetIronXMR4000 brcdIp.1.3.41.3	NetIron XMR-4000 Family
snNIXMR4000Router brcdIp.1.3.41.3.2	NetIron XMR-4000 Router
snNetIronXMR32000 brcdIp.1.3.41.4	NetIron XMR-32000 Family
snNetIronXMR32000Router brcdIp.1.3.41.4.2	NetIron XMR-32000 Router
snSecureIronFamily brcdIp.1.3.42	SecureIron Product Family
snSecureIronLSFamily brcdIp.1.3.42.9	SecureIron LS Product Family
snSecureIronLS100 brcdIp.1.3.42.9.1	SecureIron LS 100 Group
snSecureIronLS100Switch brcdIp.1.3.42.9.1.1	SecureIron LS 100 Switch
snSecureIronLS100Router brcdIp.1.3.42.9.1.2	SecureIron LS 100 Router
snSecureIronLS300 brcdIp.1.3.42.9.2	SecureIron LS 300 Group

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snSecureIronLS300Switch brcdIp.1.3.42.9.2.1	SecureIron LS 300 Switch
snSecureIronLS300Router brcdIp.1.3.42.9.2.2	SecureIron LS 300 Router
snSecureIronTMFamily brcdIp.1.3.42.10	SecureIron TM Product Family
snSecureIronTM100 brcdIp.1.3.42.10.1	SecureIron TM 100 Group
snSecureIronTM100Switch brcdIp.1.3.42.10.1.1	SecureIron TM 100 Switch
snSecureIronTM100Router brcdIp.1.3.42.10.1.2	SecureIron TM 100 Router
snSecureIronTM300 brcdIp.1.3.42.10.2	SecureIron TM 300 Group
snSecureIronTM300Switch brcdIp.1.3.42.10.2.1	SecureIron TM 300 Switch
snSecureIronTM300Router brcdIp.1.3.42.10.2.2	SecureIron TM 300 Router
snNetIronMLX16Router brcdIp.1.3.44.1.2	Brocade NetIron MLX-16 Router
snNetIronMLX8Router brcdIp.1.3.44.2.2	Brocade NetIron MLX-8 Router
snNetIronMLX4Router brcdIp.1.3.44.3.2	Brocade NetIron MLX-4 Router
snNetIronMLX-32Router brcdIp.1.3.44.4	Brocade NetIron MLX-32 Router
snFGSFamily brcdIp.1.3.45	FastIron GS Series Family
snFGS624Family brcdIp.1.3.45.1	FastIron GS624 Series Family
snFGS624PBaseFamily brcdIp.1.3.45.1.1	FastIron GS624P Base Series Family
snFGS624P brcdIp.1.3.45.1.1.1	FastIron GS Switch (FGS) 24-port 10/100/1000 POE-Ready
snFGS624PSwitch brcdIp.1.3.45.1.1.1.1	FastIron GS624P Switch
snFGS624PRouter brcdIp.1.3.45.1.1.1.2	FastIron GS624P Router
snFGS624XGPFamily brcdIp.1.3.45.1.2	FastIron GS624XGP Series Family
snFGS624XGP brcdIp.1.3.45.1.2.1	FastIron GS Switch (FGS) 24-port 10/100/1000 POE-Ready +1, 10 Gb

<b>Object name and identifier</b>	<b>Description</b>
snFGS624XGPSwitch brcdIp.1.2.45.1.2.1.1	FastIron GS624XGP Switch
snFGS624XGPRouter brcdIp.1.3.45.1.2.1.2	FastIron GS624XGP Router
snFGS624PPOEFamily brcdIp.1.3.45.1.3	FastIron GS624PPOE Series Family
snFGS624PPOE brcdIp.1.3.45.1.3.1	FastIron GS Switch (FGS) 24-port 10/100/1000 POE
snFGS624PPOESwitch brcdIp.1.3.45.1.3.1.1	FastIron GS624PPOE Switch
snFGS624PPOERouter brcdIp.1.3.45.1.3.1.2	FastIron GS624PPOE Router
snFGS624XGPPPOEFamily brcdIp.1.2.45.1.4	FastIron GS624XGPPPOE Series Family
snFGS624XGPPPOE brcdIp.1.3.45.1.4.1	FastIron GS624XGPPPOE Switch (FGS) 24-port 10/100/1000 POE +1, 10 Gb
snFGS624XGPPPOESwitch brcdIp.1.3.45.1.4.1.1	FastIron GS624XGPPPOE Switch
snFGS624XGPPPOERouter brcdIp.1.3.45.1.4.1.2	FastIron GS624XGPPPOE Router
snFGS648Family brcdIp.1.3.45.2	FastIron GS648 Series Family
snFGS648PBaseFamily brcdIp.1.3.45.2.1	FastIron GS648P Base Family
snFGS648P brcdIp.1.3.45.2.1.1	FastIron GS Switch (FGS) 48-port 10/100/1000 POE ready
snFGS648PSwitch brcdIp.1.3.45.2.1.1.1	FastIron GS648P Switch
snFGS648PRouter brcdIp.1.3.45.2.1.1.2	FastIron GS648P Router
snFSG648PPOEFamily brcdIp.1.3.45.2.2	FastIron GS648P POE Series Family
snFGS648PPOE brcdIp.1.3.45.2.2.1	FastIron GS648 Switch (FGS) 48-port 10/100/1000 POE
snFGS648PPOESwitch brcdIp.1.3.45.2.2.1.1	FastIron GS648PPOE Switch
snFGS648PPOERouter brcdIp.1.3.45.2.2.1.2	FastIron GS648PPOE Router
snFLSFamily brcdIp.1.3.46	FastIron LS Series Family
snFLS624Family brcdIp.1.3.46.1	FastIron LS624 Family

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFLS624BaseFamily brcdIp.1.3.46.1.1	FastIron LS624 Base Family
snFLS624 brcdIp.1.3.46.1.1.1	FastIron LS Switch (FLS) 24-port 10/100/1000
serverIronAdx1000Ssl brcdIp.1.3.47.13	ServerIron ADX 1000 SSL series
serverIronAdx1000SslSwitch brcdIp.1.3.47.13.1	ServerIron ADX 1000 SSL Switch
serverIronAdx1000SslRouter brcdIp.1.3.47.13.2	ServerIron ADX 1000 SSL Router
serverIronAdx4000Ssl brcdIp.1.3.47.15	ServerIron ADX 4000 SSL series
serverIronAdx4000SslSwitch brcdIp.1.3.47.15.1	ServerIron ADX 4000 SSL Switch
serverIronAdx4000SslRouter brcdIp.1.3.47.15.2	ServerIron ADX 4000 SSL Router
serverIronAdx8000Ssl brcdIp.1.3.47.17	ServerIron ADX 8000 SSL series
serverIronAdx8000SslSwitch brcdIp.1.3.47.17.1	ServerIron ADX 8000 SSL Switch
serverIronAdx8000SslRouter brcdIp.1.3.47.17.2	ServerIron ADX 8000 SSL Router
serverIronAdx10000 brcdIp.1.3.47.18	ServerIron ADX 10000 series
serverIronAdx10000Switch brcdIp.1.3.47.18.1	ServerIron ADX 10000 Switch
serverIronAdx10000Router brcdIp.1.3.47.18.2	ServerIron ADX 10000 Router
serverIronAdx10000Ssl brcdIp.1.3.47.19	ServerIron ADX 10000 SSL series
serverIronAdx10000SslSwitch brcdIp.1.3.47.19.1	ServerIron ADX 10000 SSL Switch
serverIronAdx10000SslRouter brcdIp.1.3.47.19.2	ServerIron ADX 10000 SSL Router
snFastIronStack brcdIp.1.3.48.1	FastIron stack family
snFastIronStackSwitch brcdIp.1.3.48.1.1	FGS or FLS switch in a stack
snFastIronStackRouter brcdIp.1.3.48.1.2	FGS or FLS router in a stack
snFastIronStackFCX brcdIp.1.3.48.2	Brocade FCX Switch Family in a stack

<b>Object name and identifier</b>	<b>Description</b>
snFastIronStackFCXSwitch brcdIp.1.3.48.2.1	Brocade FCX Switch in a stack
snFastIronStackFCXBaseL3Router brcdIp.1.3.48.2.2	Brocade FCX Base Layer 3 Router in a stack
snFastIronStackFCXRouter brcdIp.1.3.48.2.3	Brocade FCX Router in a stack
snFastIronStackFCXAdvRouter brcdIp.1.3.48.2.4	Brocade FCX Advanced Premium Router in a stack
snFastIronStackICX6610 brcdIp.1.3.48.3	Brocade FCX 6610 Stack Family
snFastIronStackICX6610Switch brcdIp.1.3.48.3.1	Brocade FCX 6610 Stack Switch
snFastIronStackICX6610BaseL3Router brcdIp.1.3.48.3.2	Brocade FCX 6610 Stack Base Layer 3 Router
snFastIronStackICX6610Router brcdIp.1.3.48.3.3	Brocade FCX 6610 Stack Router
snFastIronStackICX6610PRouter brcdIp.1.3.48.3.4	Brocade FCX 6610 Stack Premium Router
snFastIronStackICX6610ARouter brcdIp.1.3.48.3.5	Brocade FCX 6610 Stack Advance Router
snCes2024F brcdIp.1.3.49.1	Brocade NetIron CES 2024F Switch
snCes2024C brcdIp.1.3.49.2	Brocade NetIron CES 2024C Switch
snCes2048F brcdIp.1.3.49.3	Brocade NetIron CES 2048F Switch
snCes2048C brcdIp.1.3.49.4	Brocade NetIron CES 2048C Switch
snCes2048FX brcdIp.1.3.49.5	Brocade NetIron CES 2048FX Switch
snCes2048CX brcdIp.1.3.49.6	Brocade NetIron CES 2048CX Switch
snCer2024F brcdIp.1.3.51.1	Brocade NetIron CER 2024F Switch
snCer2024C brcdIp.1.3.51.2	Brocade NetIron CER 2024C Switch
snCer2048F brcdIp.1.3.51.3	Brocade NetIron CER 2048F Switch
snCer2048C brcdIp.1.3.51.4	Brocade NetIron CER 2048C Switch
snCer2048FX brcdIp.1.3.51.5	Brocade NetIron CER 2048FX Switch

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snCer2048CX brcdIp.1.3.51.6	Brocade NetIron CER 2048CX Switch
snFWS624 brcdIp.1.3.52.1.1.1	FastIron WS Switches (FWS) 24-port 10/100
snFWS624Switch brcdIp.1.3.52.1.1.1.1	FWS624 Switch
snFWS624BaseL3Router brcdIp.1.3.52.1.1.1.2	FWS624 Base Layer 3 Router
snFWS624EdgePremRouter brcdIp.1.3.52.1.1.1.3	FWS624 Edge Prem Router
snFWS624G brcdIp.1.3.52.1.2.1	FastIron WS Switch (FWS) 24-port 10/100/1000
snFWS624GSwitch brcdIp.1.3.52.1.2.1.1	FWS624G Switch
snFWS624GBaseL3Router brcdIp.1.3.52.1.2.1.2	FWS624G Base Layer 3 Router
snFWS624GEdgePremRouter brcdIp.1.3.52.1.2.1.3	FWS624G Edge Prem Router
snFWS648 brcdIp.1.3.52.2.1.1	FastIron WS Switch (FWS) 48-port 10/100 POE Ready
snFWS648Switch brcdIp.1.3.52.2.1.1.1	FWS648 Switch
snFWS648BaseL3Router brcdIp.1.3.52.2.1.1.2	FWS648 Base Layer 3 Router
snFWS648EdgePremRouter brcdIp.1.3.52.2.1.1.3	FWS648 Edge Prem Router
snFWS648G brcdIp.1.3.52.2.2.1	FastIron WS Switch (FWS) 48-port 10/100/1000 POE Ready
snFWS648GSwitch brcdIp.1.3.52.2.2.1.1	FWS648G Switch
snFWS648GBaseL3Router brcdIp.1.3.52.2.2.1.2	FWS648G Base Layer 3 Router
snFWS648GEdgePremRouter brcdIp.1.3.52.2.2.1.3	FWS648G Edge Prem Router
snTurbolron2 brcdIp.1.3.53	Turbolron(TOR) Family
snTI2X24Family brcdIp.1.3.53.1	TOR 24X
snTI2X24Switch brcdIp.1.3.53.1.1	TOR 24X Switch
snTI2X24Router brcdIp.1.3.53.1.2	TOR 24X Router

<b>Object name and identifier</b>	<b>Description</b>
snTI2X48Family brcdIp.1.3.53.2	TOR 48X
snTI2X48Switch brcdIp.1.3.53.2.1	TOR 48X Switch
snTI2X48Router brcdIp.1.3.53.2.2	TOR 48X Router
snFCXFamily brcdIp.1.3.54	Brocade FCX Family
snFCX624Family brcdIp.1.3.54.1	Brocade FCX 624 Family
snFCX624BaseFamily brcdIp.1.3.54.1.1	Brocade FCX 624 Base Family
snFCX624S brcdIp.1.3.54.1.1.1	Brocade FCX 624S
snFCX624SSwitch brcdIp.1.3.54.1.1.1.1	Brocade FCX 624S Switch
snFCX624SBaseL3Router brcdIp.1.3.54.1.1.1.2	Brocade FCX 624S Base Layer 3 Router
snFCX624SRouter brcdIp.1.3.54.1.1.1.3	Brocade FCX 624S Router
snFCX624SAdvRouter brcdIp.1.3.54.1.1.1.4	Brocade FCX 624S Advanced Router
snFCX624SHPOEFamily brcdIp.1.3.54.1.2	Brocade FCX 624S HPOE Family
snFCX624SHPOE brcdIp.1.3.54.1.2.1	Brocade FCX 624S HPOE
snFCX624SHPOESwitch brcdIp.1.3.54.1.2.1.1	Brocade FCX 624S HPOE Switch
snFCX624SHPOEBaseL3Router brcdIp.1.3.54.1.2.1.2	Brocade FCX 624S HPOE Base Layer 3 Router
snFCX624SHPOERouter brcdIp.1.3.54.1.2.1.3	Brocade FCX 624S HPOE Router
snFCX624SHPOEAdvRouter brcdIp.1.3.54.1.2.1.4	Brocade FCX 624S HPOE Advanced Router
snFCX624SFFamily brcdIp.1.3.54.1.3	FastIron 624S-F Family
snFCX624SF brcdIp.1.3.54.1.3.1	FastIron 624S-F
snFCX624SFSwitch brcdIp.1.3.54.1.3.1.1	FastIron 624S-F Switch
snFCX624SFBBaseL3Router brcdIp.1.3.54.1.3.1.2	FastIron 624S-F Base Layer 3 Router

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snFCX624SFRouter brcdIp.1.3.54.1.3.1.3	FastIron 624S-F Router
snFCX624SFAdvRouter brcdIp.1.3.54.1.3.1.4	FastIron 624S-F Advanced Router
snFCX624BaseFamily brcdIp.1.3.54.1.4	FastIron 24-port 10/100/1000 FCX624-E and FCX624-I Base Family
snFCX624 brcdIp.1.3.54.1.4.1	Brocade FCX Switch(FCX) 24-port 10/100/1000
snFCX624Switch brcdIp.1.3.54.1.4.1.1	Brocade FCX624 Switch
snFCX624Basel3Router brcdIp.1.3.54.1.4.1.2	Brocade FCX624 Base Layer 3 Router
snFCX624Router brcdIp.1.3.54.1.4.1.3	Brocade FCX624 Premium Router
snFCX624AdvRouter brcdIp.1.3.54.1.4.1.4	Brocade FCX624 Advanced Premium Router (BGP)
snFCX648Family brcdIp.1.3.54.2	Brocade FCX 648 Family
snFCX648SBaseFamily brcdIp.1.3.54.2.1	Brocade FCX 648S Base Family
snFCX648S brcdIp.1.3.54.2.1.1	Brocade FCX 648S
snFCX648SSwitch brcdIp.1.3.54.2.1.1.1	Brocade FCX 648S Switch
snFCX648SBasel3Router brcdIp.1.3.54.2.1.1.2	Brocade FCX 648S Base Layer 3 Router
snFCX648SRouter brcdIp.1.3.54.2.1.1.3	Brocade FCX 648S Router
snFCX648SAdvRouter brcdIp.1.3.54.2.1.1.4	Brocade FCX 648S Advanced Router
snFCX648SHPOEFamily brcdIp.1.3.54.2.2	Brocade FCX 648S HPOE Family
snFCX648SHPOE brcdIp.1.3.54.2.2.1	Brocade FCX 648S HPOE
snFCX648SHPOESwitch brcdIp.1.3.54.2.2.1.1	Brocade FCX 648S HPOE Switch
snFCX648SHPOEBasel3Router brcdIp.1.3.54.2.2.1.2	Brocade FCX 648S HPOE Base Layer 3 Router
snFCX648SHPOERouter brcdIp.1.3.54.2.2.1.3	Brocade FCX 648S HPOE Router
snFCX648SHPOEAdvRouter brcdIp.1.3.54.2.2.1.4	Brocade FCX 648S HPOE Advanced Router



<b>Object name and identifier</b>	<b>Description</b>
snFCX648BaseFamily brcdIp.1.3.54.2.4	Brocade FCX Switch Base family Switch
snFCX648 brcdIp.1.3.54.2.4.1	Brocade FCX Switch (FCX) 48-port 10/100/1000
snFCX648Switch brcdIp.1.3.54.2.4.1.1	Brocade FCX 648 Switch
snFCX648BaseL3Router brcdIp.1.3.54.2.4.1.2	Brocade FCX 648 Base Layer 3 Router
snFCX648Router brcdIp.1.3.54.2.4.1.3	Brocade FCX 648 Premium Router
snFCX648AdvRouter brcdIp.1.3.54.2.4.1.4	Brocade FCX 648 Advanced Premium Router (BGP)
snICX6610Family brcdIp.1.3.56	Brocade ICX 6610 family
snICX661024Family brcdIp.1.3.56.1	Brocade ICX 6610 24-port family
snICX661024BaseFamily brcdIp.1.3.56.1.1	Brocade ICX 6610 Switch 24-port
snICX661024 brcdIp.1.3.56.1.1.1	Brocade ICX 6610 24-port
snICX661024Switch brcdIp.1.3.56.1.1.1.1	Brocade ICX 6610 24-port Switch
snICX661024BaseL3Router brcdIp.1.3.56.1.1.1.2	Brocade ICX 6610 24-port Base Layer 3 Router
snICX661024Router brcdIp.1.3.56.1.1.1.3	Brocade ICX 6610 24-port Base Router
snICX661024PRouter brcdIp.1.3.56.1.1.1.4	Brocade ICX 6610 24-port Premium Router
snICX661024ARouter brcdIp.1.3.56.1.1.1.5	Brocade ICX 6610 24-port Advanced Router
snICX661024HPOEFamily brcdIp.1.3.56.1.2	Brocade ICX 6610 24-port HPOE family
snICX661024HPOE brcdIp.1.3.56.1.2.1	Brocade ICX 6610 Switch (ICX6610) 24-port HPOE
snICX661024HPOESwitch brcdIp.1.3.56.1.2.1.1	Brocade ICX 6610 24-HPOE Switch
snICX661024HPOEBaseL3Router brcdIp.1.3.56.1.2.1.2	Brocade ICX 6610 24-HPOE Base Layer 3 Router
snICX661024HPOERouter brcdIp.1.3.56.1.2.1.3	Brocade ICX 6610 24-HPOE Base Router
snICX661024HPOEPRouter brcdIp.1.3.56.1.2.1.4	Brocade ICX 6610 24-HPOE Premium Router

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snICX661024HPOEARouter brcdIp.1.3.56.1.2.1.5	Brocade ICX 6610 24-HPOE Advanced Router
snICX661024FFamily brcdIp.1.3.56.1.3	Brocade ICX 6610 24F family
snICX661024F brcdIp.1.3.56.1.3.1	Brocade ICX 6610 Switch (ICX6610-F) 24-port fiber
snICX661024FSwitch brcdIp.1.3.56.1.3.1.1	Brocade ICX 6610 24F Switch
snICX661024FBaseL3Router brcdIp.1.3.56.1.3.1.2	Brocade ICX 6610 24F Base Layer 3 Router
snICX661024FRouter brcdIp.1.3.56.1.3.1.3	Brocade ICX 6610 24F Base Router
snICX661024FPRouter brcdIp.1.3.56.1.3.1.4	Brocade ICX 6610 24F Premium Router
snICX661024FARouter brcdIp.1.3.56.1.3.1.5	Brocade ICX 6610 24F Advanced Router
snICX661048Family brcdIp.1.3.56.2	Brocade ICX 6610 48-port family
snICX661048BaseFamily brcdIp.1.3.56.2.1	Brocade ICX 6610 48-port Base family
snICX661048 brcdIp.1.3.56.2.1.1	Brocade ICX 6610 Switch (ICX6610) 48-port
snICX661048Switch brcdIp.1.3.56.2.1.1.1	Brocade ICX 6610 48 Switch
snICX661048BaseL3Router brcdIp.1.3.56.2.1.1.2	Brocade ICX 6610 48 Base Layer 3 Router
snICX661048Router brcdIp.1.3.56.2.1.1.3	Brocade ICX 6610 48 Base Router
snICX661048PRouter brcdIp.1.3.56.2.1.1.4	Brocade ICX 6610 48 Premium Router
snICX661048ARouter brcdIp.1.3.56.2.1.1.5	Brocade ICX 6610 48 Advanced Router
snICX661048HPOEFamily brcdIp.1.3.56.2.2	Brocade ICX 6610 48-HPOE family
snICX661048HPOE brcdIp.1.3.56.2.2.1	Brocade ICX 6610 Switch (ICX6610) 48-port HPOE
snICX661048HPOESwitch brcdIp.1.3.56.2.2.1.1	Brocade ICX 6610 48-HPOE Switch
snICX661048HPOEBaseL3Router brcdIp.1.3.56.2.2.1.2	Brocade ICX 6610 48-HPOE Base Layer 3 Router
snICX661048HPOERouter brcdIp.1.3.56.2.2.1.3	Brocade ICX 6610 48-HPOE Base Router

<b>Object name and identifier</b>	<b>Description</b>
snICX661048HPOEPRouter brcdIp.1.3.56.2.2.1.4	Brocade ICX 6610 48-HPOE Premium Router
snICX661048HPOEARouter brcdIp.1.3.56.2.2.1.5	Brocade ICX 6610 48-HPOE Advanced Router
snICX6430Family brcdIp.1.3.57	Brocade ICX 6430 Series Family
snICX643024Family brcdIp.1.3.57.1	Brocade ICX 6430 24-port Family
snICX643024BaseFamily brcdIp.1.3.57.1.1	Brocade ICX 6430 24-port Base Family
snICX643024 brcdIp.1.3.57.1.1.1	Brocade ICX 6430 24-port (10/100/1G w/4x1G)
snICX643024Switch brcdIp.1.3.57.1.1.1.1	Brocade ICX 6430 24-port Switch
snICX643024HPOEFamily brcdIp.1.3.57.1.2	Brocade ICX 6430 24-JHPOE Family
snICX643024HPOE brcdIp.1.3.57.1.2.1	Brocade ICX 6430 24-port HPOE (10/100/1G w/4x1G)
snICX643024HPOESwitch brcdIp.1.3.57.1.2.1.1	Brocade ICX 6430 24-HPOE Switch
snICX643048Family brcdIp.1.3.57.2	Brocade ICX 6430 48-port Family
snICX643048BaseFamily brcdIp.1.3.57.2.1	Brocade ICX 6430 48-port Base Family
snICX643048 brcdIp.1.3.57.2.1.1	Brocade ICX 6430 48-port (10/100/1G w/4x1G)
snICX643048Switch brcdIp.1.3.57.2.1.1.1	Brocade ICX 6430 48-port Switch
snICX643048HPOEFamily brcdIp.1.3.57.2.2	Brocade ICX 6430 48-HPOE Family
snICX643048HPOE brcdIp.1.3.57.2.2.1	Brocade ICX 6430 48-port HPOE (10/100/1G w/4x1G)
snICX643048HPOESwitch brcdIp.1.3.57.2.2.1.1	Brocade ICX 6430 48-HPOE Switch
snICX6450Family brcdIp.1.3.58	Brocade FCX 6450 series Family
snICX645024Family brcdIp.1.3.58.1	Brocade FCX 6450 24-port Family
snICX645024BaseFamily brcdIp.1.3.58.1.1	Brocade FCX 6450 24-port Base Family
snICX645024 brcdIp.1.3.58.1.1.1	Brocade ICX 6450 24-port (10/100/1G w/4x1/10G)

### 3 Registration MIB Definition

<b>Object name and identifier</b>	<b>Description</b>
snICX645024Switch brcdIp.1.3.58.1.1.1.1	Brocade ICX 6450 24 Switch
snICX645024BaseL3Router brcdIp.1.3.58.1.1.1.2	Brocade ICX 6450 24 Base Layer 3 Router
snICX645024Router brcdIp.1.3.58.1.1.1.3	Brocade ICX 6450 24 Base Router
snICX645024PRouter brcdIp.1.3.58.1.1.1.4	Brocade ICX 6450 24 Premium Router
snICX645024HPOEFamily brcdIp.1.3.58.1.2	Brocade ICX 6450 24-HPOE Family
snICX645024HPOE brcdIp.1.3.58.1.2.1	Brocade ICX 6450 24-port HPOE (10/100/1G w/4x1/10G)
snICX645024HPOESwitch brcdIp.1.3.58.1.2.1.1	Brocade ICX 6450 24-HPOE Switch
snICX645024HPOEBaseL3Router brcdIp.1.3.58.1.2.1.2	Brocade ICX 6450 24-HPOE Base Layer 3 Router
snICX645024HPOERouter brcdIp.1.3.58.1.2.1.3	Brocade ICX 6450 24-HPOE Base Router
snICX645024HPOEPRouter brcdIp.1.3.58.1.2.1.4	Brocade ICX 6450 24-HPOE Premium Router
snICX645048Family brcdIp.1.3.58.2	Brocade ICX 6450 48-port Family
snICX645048BaseFamily brcdIp.1.3.58.2.1	Brocade ICX 6450 48-port Base Family
snICX645048 brcdIp.1.3.58.2.1.1	Brocade ICX 6450 48-port (10/100/1G w/4x1/10G)
snICX645048Switch brcdIp.1.3.58.2.1.1.1	Brocade ICX 6430 48 Switch
snICX645048BaseL3Router brcdIp.1.3.58.2.1.1.2	Brocade ICX 6450 48 Base Layer 3 Router
snICX645048Router brcdIp.1.3.58.2.1.1.3	Brocade ICX 6450 48 Base Router
snICX645048PRouter brcdIp.1.3.58.2.1.1.4	Brocade ICX 6450 48 Premium Router
snICX645048HPOEFamily brcdIp.1.3.58.2.2	Brocade ICX 6450 48-HPOE Family
snICX645048HPOE brcdIp.1.3.58.2.2.1	Brocade ICX 6430 48-port HPOE (10/100/1G w/4x1/10G)
snICX645048HPOESwitch brcdIp.1.3.58.2.2.1.1	Brocade ICX 6450 48-HPOE Switch
snICX645048HPOEBaseL3Router brcdIp.1.3.58.2.2.1.2	Brocade ICX 6450 48-HPOE Base Layer 3 Router

<b>Object name and identifier</b>	<b>Description</b>
snlCX645048HPOERouter brcdIp.1.3.58.2.2.1.3	Brocade ICX 6450 48-HPOE Base Router
snlCX645048HPOEPRouter brcdIp.1.3.58.2.2.1.4	Brocade ICX 6450 48-HPOE Premium Router
edgelron brcdIp.1.4	Edgelron
adjourning brcdIp.1.4.1	Edgelron MIB
edgelronType2 brcdIp.1.5	Edgelron Type 2
edgelronType2Mib brcdIp.1.5.1	Edgelron Type 2 MIB
wirelessAp brcdIp.1.6	Iron Point 200 Access Point
wireless Probe brcdIp.1.7	Iron Point 200 Sensor
access Iron brcdIp.1.8	Access Iron
vendors brcdIp.2	Vendors
digitalChina brcdIp.2.1	Digital China
dcrs7504Switch brcdIp.2.1.1.1	DCRS 7504 Switch
dcrs7504Router brcdIp.2.1.1.2	DCRS 7504 Router
dcrs7508Switch brcdIp.2.1.2.1	DCRS 7508 Switch
dcrs7508Router brcdIp.2.1.2.2	DCRS 7508 Router
dcrs7515Switch brcdIp.2.1.3.1	DCRS 7515 Switch
dcrs7515Router brcdIp.2.1.3.2	DCRS 7515 Router

### 3 Registration MIB Definition

# Agent MIB Definition

---

## In this chapter

- General chassis information..... 109
- Fan status ..... 110
- Flash card..... 115
- Power supply table ..... 117
- Stacking power supply table..... 118
- Fan table ..... 118
- Stacking fan table ..... 119
- Stacking chassis unit information ..... 119

## General chassis information

The following objects apply to all devices.

Name, OID, and syntax	Access	Description
snChasType brcdIp.1.1.1.1.1 Syntax: DisplayString	Read-only	Shows the type of device being managed. This object can have up to 128 characters. Possible value: 1
<b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.		
snChasSerNum brcdIp.1.1.1.1.2 Syntax: DisplayString	Read-only	Shows the serial number of the chassis stored in the EEPROM of the device. This is not the serial number on the label of the device. If the chassis serial number is available, it is the lowest three octets of the lowest MAC address in the device. For example, if the lowest MAC address is 00e0 52a9 2b20, then the serial number of the chassis is a92b20. If the serial number is unknown or unavailable, then the value is a null string. This object can have up to 128 characters.

## Fan status

Name, OID, and syntax	Access	Description																
snChasFanStatus brcdIp.1.1.1.1.4 Syntax: Integer32	Read-only	Shows the status of fans in stackable products. There are six fans per device. This is a packed bit string. Each bit shows one of the following values: <ul style="list-style-type: none"> <li>• 0 – Fan failure.</li> <li>• 1 – Fan is operational</li> </ul> The following shows the meaning of each bit: <table border="1"> <thead> <tr> <th>Bit position</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>6 – 31</td> <td>Reserved</td> </tr> <tr> <td>5</td> <td>Fan6 status</td> </tr> <tr> <td>4</td> <td>Fan5 status</td> </tr> <tr> <td>3</td> <td>Fan4 status</td> </tr> <tr> <td>2</td> <td>Fan3 status</td> </tr> <tr> <td>1</td> <td>Fan2 status</td> </tr> <tr> <td>0</td> <td>Fan1 status</td> </tr> </tbody> </table> (Bit 0 is the least significant bit.)	Bit position	Meaning	6 – 31	Reserved	5	Fan6 status	4	Fan5 status	3	Fan4 status	2	Fan3 status	1	Fan2 status	0	Fan1 status
Bit position	Meaning																	
6 – 31	Reserved																	
5	Fan6 status																	
4	Fan5 status																	
3	Fan4 status																	
2	Fan3 status																	
1	Fan2 status																	
0	Fan1 status																	
snChasMainBrdDescription brcdIp.1.1.1.1.5 Syntax: DisplayString <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the main board. This object can have up to 128 characters.																
snChasMainPortTotal brcdIp.1.1.1.1.6 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the total number of ports on the main board. Valid values: 1 – 24																



Name, OID, and syntax	Access	Description
snChasExpBrdDescription brcdIp.1.1.1.1.7 Syntax: DisplayString <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the description of the expansion board. This object can have up to 128 characters.
snChasExpPortTotal brcdIp.1.1.1.1.8 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the total number of ports on the expansion board. Valid values: 1 – 24
snChasStatusLeds brcdIp.1.1.1.1.9 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	This object is replaced by the object snAgentBrdStatusLedString. This status LED on the front panel of a device shows the status of the link. It is represented by one bit. There can be up to 32 bits per slot. Status can be one of the following: <ul style="list-style-type: none"> <li>• 0 – Link off</li> <li>• 1 – Link on</li> </ul>
snChasTrafficLeds brcdIp.1.1.1.1.10 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	This object is replaced by the object snAgentBrdTrafficLedString. This traffic LED on the front panel of a device shows the traffic status. It is represented by one bit. There can be up to 32 bits per slot. Status can be one of the following: <ul style="list-style-type: none"> <li>• 0 – No traffic</li> <li>• 1 – Traffic is flowing</li> </ul>

Name, OID, and syntax	Access	Description
snChasMediaLeds brcdIp.1.1.1.1.11 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	This object is replaced by the object snAgentBrdMediaLedString. It is represented by one bit. There can be up to 32 bits per slot. Status can be one of the following: <ul style="list-style-type: none"> <li>• 0 – Half-duplex</li> <li>• 1 – Full-duplex</li> </ul>
snChasEnablePwrSupplyTrap brcdIp.1.1.1.1.12 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate power supply failure traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)
snChasMainBrdId brcdIp.1.1.1.1.13 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, Brocade NetIron CER series and on the FastIron devices.	Read-only	Applies to all stackable products. It identifies the main board. This is an encoded octet string. Each octet provides the following information: <p><b>Octet 0</b> – Identifies the format of this octet string.</p> <p>Octets 1 and 2:</p> <p>If Octet 0 has a value of 1, then:</p> <p><b>Octet 1</b> – Product type:</p> <ul style="list-style-type: none"> <li>• FIWG – 0x57</li> <li>• FIBB – 0x42</li> <li>• FIMLS – 0x4D</li> <li>• NI – 0x4E</li> <li>• TI – 0x54</li> <li>• TIRT – 0x52</li> </ul> <p><b>Octet 2</b> – Board type:</p> <ul style="list-style-type: none"> <li>• POWERPC – 1</li> <li>• ALPHA – 2</li> </ul> <p>The length of the octet string is 27.</p> <p>If Octet 0 has a value of 2, then:</p> <p><b>Octet 1</b> – Product type:</p> <ul style="list-style-type: none"> <li>• BI_WG – 0x57</li> <li>• BI_BB – 0x42</li> <li>• BI_NI – 0x4E</li> <li>• NI_M4 – 0x4D</li> <li>• BI_SLB – 0x53</li> </ul> <p><b>Octet 2</b> – Module type:</p> <ul style="list-style-type: none"> <li>• MASTER_FIBER_8G – 0x0</li> <li>• MASTER_FIBER_4G – 0x1</li> <li>• MASTER_COPPER_16 – 0x2</li> <li>• FI_MASTER_FIBER_2G – 0x4</li> <li>• FI_MASTER_FIBER_4G – 0x5</li> <li>• MASTER_COPPER_8G – 0x6</li> <li>• FI_MASTER_FIBER_8G – 0x7</li> </ul>

Name, OID, and syntax	Access	Description
snChasMainBrdId (continued)		<p><b>Octet 2</b> – Module type (continued):</p> <ul style="list-style-type: none"> <li>• MASTER_COPPER_12_2 – 0x9</li> <li>• MASTER_FIBER_2G – 0x12</li> <li>• MASTER_FIBER_0G – 0x14</li> <li>• FI_MASTER_COPPER_8G – 0x1D</li> <li>• FI_MASTER_COPPER_4G – 0x1F</li> <li>• FI_MASTER_COPPER_2G – 0x20</li> <li>• MASTER_COPPER_4G – 0x21</li> <li>• MASTER_COPPER_2G – 0x22</li> <li>• MASTER_M4_8G – 0x23</li> <li>• MASTER_M4_4G – 0x24</li> <li>• MASTER_M4_0G – 0x26</li> </ul> <p>The length of the octet string is 28.</p> <p><b>Octet 3</b> – Processor type (both format version 1 and 2):</p> <ul style="list-style-type: none"> <li>• PVR_M603 – 3</li> <li>• PVR_M604 – 4</li> <li>• PVR_M603E – 6</li> <li>• PVR_M603EV – 7</li> <li>• PVR_M604E – 9</li> </ul> <p><b>Octet 4 to Octet 5</b> – Processor speed in MHz (both format version 1 and 2)</p> <p><b>Octet 6</b> – MAC type:</p> <ul style="list-style-type: none"> <li>• MAC_NONE – 0</li> <li>• MAC_SEEQ_10_100 – 1</li> <li>• MAC_DEC_10_100 – 2</li> <li>• PHY_ICS – 3</li> <li>• MAC_XIOGMAC_1000 – 4</li> <li>• MAC_SEEQ_1000 – 5</li> <li>• MAC_GMAC_1000 – 6</li> <li>• MAC_VLSI_1000 – 7</li> </ul> <p><b>Octet 7</b> – PHY type (both format version 1 and 2):</p> <ul style="list-style-type: none"> <li>• PHY_NONE – 0</li> <li>• PHY_QSI – 1</li> <li>• PHY_BROADCOM – 2</li> <li>• PHY_ICS – 3</li> <li>• PHY_NATIONAL – 4</li> <li>• PHY_LEVEL1 – 6</li> <li>• PHY_LEVEL16 – 7</li> <li>• PHY_LEVEL24 – 8</li> </ul> <p><b>Octet 8</b> – Port type:</p> <ul style="list-style-type: none"> <li>• COPPER – 0</li> <li>• FIBER – 1</li> </ul> <p><b>Octet 9</b> – Fiber port type (both format version 1 and 2):</p> <ul style="list-style-type: none"> <li>• NONFIBER – 0</li> <li>• SX_FIBER – 1</li> <li>• LX_FIBER – 2</li> <li>• LHX_FIBER – 3</li> <li>• LX_SX_FIBER – 4</li> <li>• LHB_FIBER – 5</li> </ul>

## 4 Agent MIB Definition

Name, OID, and syntax	Access	Description
snChasMainBrdId (continued)		<p><b>Octet 10 to Octet 13</b> – DRAM size in KBytes (both format version 1 and 2)</p> <p><b>Octet 14 to Octet 17</b> – Boot flash size in KBytes (both format version 1 and 2)</p> <p><b>Octet 18 to Octet 21</b> – Code flash size in KBytes (both format version 1 and 2)</p> <p><b>Octet 22 to Octet 27</b> – Serial number (both format version 1 and 2)</p> <p><b>Octet 28</b> – Chassis backplane type (format version 1 only): This octet applies only if Octet 0 is equal to 1.</p> <ul style="list-style-type: none"> <li>chassis4000 – 0x00</li> <li>chassis8000 – 0x04</li> <li>chassis15000 – 0x05</li> <li>Turbo8 – 0x07 (stack2)</li> <li>FastIron2 – 0x06 (stack1)</li> </ul>
snChasExpBrdId brcdIp.1.1.1.1.14 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices and on the FastIron devices.	Read-only	<p>It identifies the expansion board; the board that attaches to the main board. This is an encoded octet string. Each octet provides the following information:</p> <p><b>Octet 0</b> – Identifies the format of this octet string.</p> <p><b>Octet 1</b> – Expansion board type:</p> <ul style="list-style-type: none"> <li>HUNDRED_MEG_1PORT – 1</li> <li>HUNDRED_MEG_2PORT – 2</li> <li>HUNDRED_MEG_1PORT_COPPER – 3</li> <li>HUNDRED_MEG_2PORT_COPPER – 4</li> <li>HUNDRED_MEG_2PORT_LX – 5</li> <li>GIGA_1PORT – 8, GIGA_2PORT – 9</li> </ul> <p><b>Octet 2</b> – Fiber port type:</p> <ul style="list-style-type: none"> <li>NONFIBER – 0</li> <li>SX_FIBER – 1</li> <li>LX_FIBER – 2</li> <li>LHX_FIBER – 3</li> <li>LX_SX_FIBER – 4</li> </ul>
snChasSpeedLeds brcdIp.1.1.1.1.15 Syntax: Integer	Read-only	<p>Applies to devices that have an LED for media speed. This object is replaced by the object snAgentBrdSpeedLedString.</p> <p>It is represented by one bit. There can be up to 32 bits per slot. Status can be one of the following:</p> <ul style="list-style-type: none"> <li>0 – 10 Mbit</li> <li>1 – 100 Mbit</li> </ul>
snChasEnableFanTrap brcdIp.1.1.1.1.16 Syntax: Integer	Read-write	<p>For chassis devices only.</p> <p>Indicates if the SNMP agent process has been enabled to generate fan failure traps:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snChasIdNumber brcdIp.1.1.1.1.17 Syntax: DisplayString	Read-only	<p>Shows the chassis identity number. This is used by inventory control. This is not the number on the label of the device.</p> <p>By default, this object displays a null string. This object can have up to 64 characters.</p>

Name, OID, and syntax	Access	Description
snChasActualTemperature brcdIp.1.1.1.1.18 Syntax: Integer	Read-only	Applies only to management modules with temperature sensors. Shows the temperature of the chassis. Each unit is 0.5° Celsius. <b>NOTE:</b> If you are comparing this value to the value you get when you enter a <b>show chassis</b> command on the CLI, divide this value by 2. The result is the actual temperature you see in the CLI. This was done intentionally to represent tenth decimal values in SNMP, as SNMP can only report INTEGER values. Valid values: 110 – 250
snChasWarningTemperature brcdIp.1.1.1.1.19 Syntax: Integer	Read/write	Applies only to management modules with temperature sensors. Shows the threshold for the warning temperature. When the actual temperature exceeds this value, the switch sends a temperature warning trap. Each unit is 0.5° Celsius. Valid values: 0 – 250 <b>NOTE:</b> If you compare the value with the value while entering the <b>show chassis</b> command and divide the value by 2. The result is the warning (or shutdown) temperature. This is done intentionally to represent the tenth decimal values in the SNMP, as the SNMP can only report the INTEGER values.
snChasShutdownTemperature brcdIp.1.1.1.1.20 Syntax: Integer	Read/write	Applies only to management modules with temperature sensors. Shows the temperature threshold that triggers the device to shut down. When the actual temperature exceeds this value, the switch shuts down a portion of the hardware to cool down the device. Each unit is 0.5° Celsius. Valid values: 0 – 250 <b>NOTE:</b> If you compare the value with the value while entering the <b>show chassis</b> command and divide the value by 2. The result is the warning (or shutdown) temperature. This is done intentionally to represent the tenth decimal values in the SNMP, as the SNMP can only report the INTEGER values.
snChasEnableTempWarnTrap brcdIp.1.1.1.1.21 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate temperature warning traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)

## Flash card

The following objects manage the flash cards in all the devices.

## 4 Agent MIB Definition

Name, OID, and syntax	Access	Description
snChasFlashCard brcdIp.1.1.1.1.22 Syntax: Integer32	Read-only	<p>Applies only to M4 management modules. This object is a bit array that contains the flash card status.</p> <p>This is a packed bit string. The status of each flash card is encoded into one bit. There can be up to two flash cards.</p> <p>The bits are:</p> <ul style="list-style-type: none"> <li>• 2 to 31 – Reserved</li> <li>• 1 – Flash card 2 status</li> <li>• 0 – Flash card 1 status</li> </ul> <p>(Bit 0 is the least significant bit.)</p> <p>Flash card status can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Flash card is absent</li> <li>• 1 – Flash card is present</li> </ul>
snChasFlashCardLeds brcdIp.1.1.1.1.23 Syntax: Integer32	Read-only	<p>Shows the status of LEDs on a flash card. Each bit shows one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Flash card is off</li> <li>• 1 – Flash card is on</li> </ul>
snChasNumSlots brcdIp.1.1.1.1.24 Syntax: Integer32	Read-only	Shows the number of slots in the chassis.
snChasArchitectureType brcdIp.1.1.1.1.25 Syntax: Integer	Read-only	<p>Shows the architecture type:</p> <ul style="list-style-type: none"> <li>• stackable(1) - old stackable</li> <li>• bigIron(2)</li> <li>• terathon(3)</li> <li>• fifthGen(4)</li> </ul>
snChasProductType brcdIp.1.1.1.1.26 Syntax: Integer	Read-only	<p>Shows the product type. The following shows the meaning of each bit:</p> <ul style="list-style-type: none"> <li>• invalid(0)</li> <li>• BigIron MG8(1)</li> <li>• NetIron 40G(2)</li> <li>• NetIron IMR 640(3)</li> <li>• BigIron RX 800(4)</li> <li>• Brocade NetIron XMR router 16000(5)</li> <li>• BigIron RX 400(6)</li> <li>• Brocade NetIron XMR router 8000(7)</li> <li>• BigIron RX 200(8)</li> <li>• Brocade NetIron XMR router 4000(9)</li> <li>• Brocade MLX router-32(13)</li> <li>• Brocade NetIron XMR router 32000(14)</li> <li>• BigIron RX-32(15)</li> <li>• niCES2000Series(16)</li> <li>• niCER2000Series(17)</li> <li>• brMlxESlot4(18) - This value is supported only on the Brocade NetIron devices.</li> <li>• brMlxESlot8(19) - This value is supported only on the Brocade NetIron devices.</li> <li>• brMlxESlot16(20) - This value is supported only on the BrocadeNetIron devices.</li> <li>• brMlxESlot32(21) - This value is supported only on the Brocade NetIron devices.</li> </ul>

Name, OID, and syntax	Access	Description
snChasSystemMode brcdIp.1.1.1.1.27 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade FastIron devices.	Read-only	This object displays the mode of the Brocade MLXe router, Brocade NetIron XMR, or Brocade MLX device. It returns one of the following values: <ul style="list-style-type: none"> <li>xmr(1)</li> <li>mlx(2)</li> </ul> Values are returned as follows: <ul style="list-style-type: none"> <li>If snChasProductType is niXmr4000, niXmr8000, niXmr160000, or niXmr32000, then this object returns xmr(1).</li> <li>if snChasProductType is niMlx4, niMlx8, niMlx16, or niMlx32 then this object returns mlx(2).</li> <li>If snChasProductType is brMlxE4, brMlxE8, brMlxE16, or brMlxE32 this object returns either xmr(1) or mlx(2) depending on the mode of the system.</li> </ul>
snChasFactoryPartNumber brcdIp.1.1.1.1.28 Syntax: DisplayString <b>NOTE:</b> This object is not supported on the Brocade FastIron devices.	Read-only	This object displays the factory part number assigned by the manufacturer.
snChasFactorySerialNumber brcdIp.1.1.1.1.29 Syntax: DisplayString <b>NOTE:</b> This object is not supported on the Brocade FastIron devices.	Read-only	This object displays the factory serial number assigned by the manufacturer.

## Power supply table

The following table applies to the power supply in all products.

Name, OID, and syntax	Access	Description
snChasPwrSupplyTable brcdIp.1.1.1.2.1	None	A table containing power supply information. Only installed power supplies appear in the table.
snChasPwrSupplyIndex brcdIp.1.1.1.2.1.1.1 Syntax: Integer32	Read-only	The index to the power supply table.
snChasPwrSupplyDescription brcdIp.1.1.1.2.1.1.2 Syntax: DisplayString	Read-only	The power supply description. For example, you may see the description, "right side power supply". This object can have up to 128 characters.
snChasPwrSupplyOperStatus brcdIp.1.1.1.2.1.1.3 Syntax: Integer	Read-only	The status of the power supply: <ul style="list-style-type: none"> <li>other(1) – Status is neither normal(2) or failure(3). This value is not used for stackables including FastIron 4802.</li> <li>normal(2)</li> <li>failure(3)</li> </ul>

## Stacking power supply table

The following table shows the status of a power supply on devices that support the stacking functionality.

---

### NOTE

The objects in the table below are not supported on the NetIron and the FastIron SX devices.

---

Name, OID, and syntax	Access	Description
snChasPwrSupply2Table brcdIp.1.1.1.2.2	None	A table of power supply information for each unit. Only an installed power supply is displayed in a table row.
snChasPwrSupply2Unit brcdIp.1.1.1.2.2.1.1 Syntax: Integer	Read-only	The index to the power supply table.
snChasPwrSupply2Index brcdIp.1.1.1.2.2.1.2 Syntax: Integer	Read-only	The index to the power supply table that identifies the power supply unit.
snChasPwrSupply2Description brcdIp.1.1.1.2.2.1.3 Syntax: DisplayString	Read-only	The power supply description string. This description can have up to 128 characters.
snChasPwrSupply2OperStatus brcdIp.1.1.1.2.2.1.4 Syntax: Integer	Read-only	The power supply operation status: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• normal(2)</li> <li>• failure(3)</li> </ul>

---

## Fan table

The following table applies to the fans in all devices, except for devices that support the stacking functionality.

Name, OID, and syntax	Access	Description
snChasFanTable brcdIp.1.1.1.3.1	None	A table containing fan information. Only installed fans appear in the table.
snChasFanIndex brcdIp.1.1.1.3.1.1.1 Syntax: Integer32	Read-only	The index to the fan table.
snChasFanDescription brcdIp.1.1.1.3.1.1.2 Syntax: DisplayString	Read-only	The fan description. For example, you may see the description "left side panel, back fan". This object can have up to 128 characters.
snChasFanOperStatus brcdIp.1.1.1.3.1.1.3 Syntax: Integer	Read-only	The status of the fan operation: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• normal(2)</li> <li>• failure(3)</li> </ul>

---



## Stacking fan table

The following table shows the fan status for devices that support the stacking functionality.

Name, OID, and syntax	Access	Description
snChasFan2Table brcdIp.1.1.1.3.2  <b>NOTE:</b> This object is not supported on the NetIron devices.	None	A table of fan information for each unit. Only an installed fan is displayed in a table row.
snChasFan2Unit brcdIp.1.1.1.3.2.1.1 Syntax: Integer	Read-only	The unit to the fan table.
snChasFan2Index brcdIp.1.1.1.3.2.1.2 Syntax: Integer	Read-only	The index to the fan table.
snChasFan2Description brcdIp.1.1.1.3.2.1.3 Syntax: DisplayString	Read-only	The fan description string. This description can have up to 128 characters.
snChasFan2OperStatus brcdIp.1.1.1.3.2.1.4 Syntax: Integer	Read-only	The fan operation status: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• normal(2)</li> <li>• failure(3)</li> </ul>

## Stacking chassis unit information

The following table manages the temperature for devices that supports the stacking functionality.

Name, OID, and syntax	Access	Description
snChasUnitTable brcdIp.1.1.1.4.1	None	A table of information for each unit in a stack. Only an active unit is displayed in a table row.
snChasUnitIndex brcdIp.1.1.1.4.1.1.1 Syntax: Integer32	Read-only	The index to the table.
snChasUnitSerNum brcdIp.1.1.1.4.1.1.2 Syntax: DisplayString	Read-only	The serial number of the unit. If the serial number is unknown or unavailable, then the value should be a zero length string. There can be up to 128 characters for the serial number.
snChasUnitNumSlots brcdIp.1.1.1.4.1.1.3 Syntax: Integer32	Read-only	Number of slots of the chassis for each unit.

## 4 Agent MIB Definition

Name, OID, and syntax	Access	Description
snChasUnitActualTemperature brcdIp.1.1.1.4.1.1.4 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Temperature of the chassis. Each unit is 0.5° Celsius. This object applies only to management modules with temperature sensors in hardware. For management modules without temperature sensors, it returns "no-such-name". Values are from -110 through 250° Celsius.
snChasUnitWarningTemperature brcdIp.1.1.1.4.1.1.5 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Actual temperature higher than the threshold value triggers the switch to send a temperature warning trap. Each unit is 0.5° Celsius. This object applies only to management modules with temperature sensors in hardware. For management modules without temperature sensors, it returns "no-such-name". Values are from 0 through 250° Celsius.
snChasUnitShutdownTemperature brcdIp.1.1.1.4.1.1.6 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Actual temperature higher than the threshold value will shut down a portion of the switch hardware to cool down the system. Each unit is 0.5° Celsius. This object applies only to management modules with temperature sensors in hardware. For management modules without temperature sensors, it returns "no-such-name". Values are from 0 through 250° Celsius.
snChasUnitPartNum brcdIp. 1.1.1.4.1.1.7 Syntax: DisplayString	Read-only	Indicates the part number of the chassis only for Brocade NetIron XMR, Brocade MLX, Brocade MLXe router devices. Nothing is displayed if the part number is unknown or unavailable.

# Agent Groups

---

## In this chapter

- Agent global group . . . . . 121
- Image and configuration file download and upload . . . . . 122
- Default gateway IP address . . . . . 126
- Usage notes on CPU utilization and system CPU utility table . . . . . 127
- Image version . . . . . 129
- Agent board table . . . . . 136
- Agent stacking board table . . . . . 144
- Trap receiver table . . . . . 147
- Boot sequence table . . . . . 148
- SP boot sequence table . . . . . 149
- Encoded octet strings table . . . . . 150

## Agent global group

The following objects allow you to reload the agent.

Name, OID, and syntax	Access	Description
snAgReload brcdIp.1.1.2.1.1 Syntax: Integer	Read-write	<p>Reboots the agent.</p> <p>The following values can only be read:</p> <ul style="list-style-type: none"> <li>• other(1) – Agent is in unknown or other state.</li> <li>• running(2) – Agent is running.</li> <li>• busy(4) – Reload is not allowed at this time as flash is busy.</li> </ul> <p>The following value can be written:</p> <ul style="list-style-type: none"> <li>• reset(3) – Do a hard reset.</li> </ul> <p>The agent returns a response before the action occurs. This object requires a password to be set for the snAgGblPassword object.</p>

Name, OID, and syntax	Access	Description
snAgEraseNVRAM brcdIp.1.1.2.1.2 Syntax: Integer	Read-write	Erases the NVRAM of the agent. This object can have one of the following values: <ul style="list-style-type: none"> <li>normal(1) – NVRAM is not being erased.</li> <li>error(2) – Either the erase operation failed or the flash memory is bad.</li> <li>erasing(4) – NVRAM is being erased. If the process starts, you cannot set this object to erase(3) until the process is finished and the value of this object is either normal(1) or error(2).</li> <li>busy(5) – Operation is not allowed at this time as flash is busy.</li> </ul> The following value can be written: <ul style="list-style-type: none"> <li>erase(3) – Erase operation.</li> </ul> The agent returns a response even before the erase operation is complete. The read values will be erased until the erase operation is finished. New erase requests will be rejected until an error(2) or normal(1) value is obtained.
snAgWriteNVRAM brcdIp.1.1.2.1.3 Syntax: Integer	Read-write	Saves all configuration information to NVRAM of the agent. The following values can only be read: <ul style="list-style-type: none"> <li>normal(1)</li> <li>error(2) – Operation failed or the flash is bad.</li> <li>writing(4) – Agent is writing to NVRAM flash.</li> <li>busy(5) – Operation is not allowed at this time as flash is busy.</li> </ul> The following value can be written: <ul style="list-style-type: none"> <li>write(3) – Write operation.</li> </ul> The agent returns a response even before the write operation is complete. The read values will be written until the write operation is finished. New write requests will be rejected until an error(2) or normal(1) value is obtained. This object requires a password to be set for the snAgGblPassword object.
snAgConfigFromNVRA M brcdIp.1.1.2.1.4 Syntax: Integer	None	Configures the switch from NVRAM of the agent. The following values can only be read: <ul style="list-style-type: none"> <li>normal(1)</li> <li>error(2) – Operation failed or the flash is bad.</li> <li>configing(4) – Configuring from NVRAM flash is in process.</li> <li>busy(5) – Operation is not allowed at this time as flash is busy.</li> </ul> The following value can be written: <ul style="list-style-type: none"> <li>config(3) – Do configuration.</li> </ul> The agent returns a response after configuration is done. This object requires a password to be set for the snAgGblPassword object. <b>NOTE:</b> The object snAgConfigFromNVRAM is obsolete and it is not supported on any of the NetIron and FastIron devices.

## Image and configuration file download and upload

The following objects manage file downloads and uploads. They are available in all devices.

When uploading or downloading configuration files to and from the TFTP server using SNMP, check for the following:

- If the SNMP password check is enabled on the device, the object must be sent with the following information in the same PDU as the TFTP objects:
  - If AAA is used for SNMP authentication and the authentication method is enable or line, then the value of snAgGlbPassword must be in cleartext format.
  - If AAA is used for SNMP authentication and the authentication method is local, RADIUS, Telnet, TACACS, or TACACS+, then the value of snAgGlbPassword must be in the <user> <password> format. The space between <user> and <password> is the delimiter.
  - If AAA is not used for authentication, then the value of snAgGlbPassword for the enable password must be in cleartext format.
- Make sure that the user has administrative access (privilege=0) on the device; otherwise, the user will not be able to upload files to the TFTP server.

**NOTE**

An atomic set of snAgImgLoad, snAgImgFname, snAgTftpServerAddrType and snAgTftpServerAddr is required for a successful download or upload.

Name, OID, and syntax	Access	Description
snAgTftpServerAddrType brcdIp.1.1.2.1.65 Syntax: IpAddress	Read-write	Shows the TFTP server IP address type. The supported address types are ipv4(1) and ipv6(2). The default address type is ipv4(1).
snAgTftpServerAddr brcdIp.1.1.2.1.66 Syntax: DisplayString	Read-write	Shows the TFTP server IP address.
snAgImgFname brcdIp.1.1.2.1.6 Syntax: DisplayString	Read-write	Shows the name of the image file, including path, that is currently associated with the system. When the object is not used, the value is blank. It can have up to 32 characters.

Name, OID, and syntax	Access	Description
snAglmgLoad brcdIp.1.1.2.1.7 Syntax: Integer	Read-write	<p>Downloads or uploads a new software image to the agent. Use one of the following values in an SNMP set:</p> <ul style="list-style-type: none"> <li>• uploadMPPPrimary(19) – Uploads the primary image from the management processor flash memory to the TFTP server.</li> <li>• downloadMPPPrimary(20) – Downloads the primary image from the TFTP server to management processor flash memory.</li> <li>• uploadMPSecondary(21) – Uploads the secondary image from the management processor flash memory to the TFTP server.</li> <li>• downloadMPSecondary(22) – Downloads the secondary image from the TFTP server to management processor flash memory.</li> <li>• downloadSPPPrimary(24) – Downloads the primary image from the TFTP server to secondary processor flash memory.</li> <li>• downloadSPSecondary(25) – Downloads the secondary image from the TFTP server to secondary processor flash memory.</li> <li>• uploadMPBootROM(26) – Uploads the Boot from the management processor flash memory to the TFTP server.</li> <li>• downloadMPBootROM(27) – Downloads the Boot from flash image from the TFTP server to management processor flash memory.</li> <li>• uploadMPBootTFTP(28) – Uploads the Boot from TFTP image from management processor flash memory to the TFTP server.</li> <li>• downloadMPBootTFTP(29) – Downloads the Boot from TFTP image from the TFTP server to management processor flash memory.</li> <li>• uploadMPMonitor(30) – Uploads the Monitor image from management processor flash memory to the TFTP server.</li> <li>• downloadMPMonitor(31) – Downloads the Monitor image from the TFTP server to management processor flash memory.</li> <li>• downloadSPBootROM(32) – Download the Boot image from the TFTP server to secondary processor flash memory .</li> </ul> <p>The following messages may be displayed:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• flashPrepareReadFailure(2)</li> <li>• flashReadError(3)</li> <li>• flashPrepareWriteFailure(4)</li> <li>• flashWriteError(5)</li> <li>• tftpTimeoutError(6)</li> <li>• tftpOutOfBufferSpace(7)</li> </ul>

Name, OID, and syntax	Access	Description
snAgImgLoad (continued)		<ul style="list-style-type: none"> <li>• tftpBusy(8)</li> <li>• tftpRemoteOtherErrors(9)</li> <li>• tftpRemoteNoFile(10)</li> <li>• tftpRemoteBadAccess(11)</li> <li>• tftpRemoteDiskFull(12)</li> <li>• tftpRemoteBadOperation(13)</li> <li>• tftpRemoteBadId(14)</li> <li>• tftpRemoteFileExists(15)</li> <li>• tftpRemoteNoUser(16)</li> <li>• operationError(17)</li> <li>• loading(18) – The operation is in process.</li> <li>• uploadMPPPrimary(19)</li> <li>• downloadMPPPrimary(20)</li> <li>• uploadMPSecondary(21)</li> <li>• downloadMPSecondary(22)</li> <li>• tftpWrongFileType(23)</li> <li>• downloadSPPPrimary(24)</li> <li>• downloadSPSecondary(25)</li> <li>• uploadMPBootROM(26)</li> <li>• downloadMPBootROM(27)</li> <li>• uploadMPBootTFTP(28)</li> <li>• downloadMPBootTFTP(29)</li> <li>• uploadMPMonitor(30)</li> <li>• downloadMPMonitor(31)</li> <li>• downloadSPBootROM(32)</li> </ul> <p>This object requires a password to be set for the snAgGblPassword object.</p>
snAgCfgFname brcdIp.1.1.2.1.8 Syntax: DisplayString	Read-write	Shows the name of the configuration file, including its path, currently associated with the system. If there are multiple configuration files, the names are separated by semicolons (;). This object can have up to 32 characters.
snAgCfgLoad brcdIp.1.1.2.1.9 Syntax: Integer	Read-write	Downloads or uploads a configuration file to the agent. Use one of the following values for an SNMP set: <ul style="list-style-type: none"> <li>• uploadFromFlashToServer(20) – Uploads the configuration file from the flash to the TFTP server.</li> <li>• downloadToFlashFromServer(21) – Downloads the configuration file from the TFTP server to flash.</li> <li>• uploadFromDramToServer(22) – Uploads the configuration file from the DRAM to the TFTP server.</li> <li>• downloadToDramFromServer(23) – Downloads the configuration file from the TFTP server to DRAM.</li> <li>• uploadFromFlashToNMS(24) – Uploads the configuration file from flash to the network management system.</li> <li>• downloadToFlashFromNMS(25) – Downloads the configuration file from the network management system to flash.</li> <li>• uploadFromDramToNMS(26) – Uploads the configuration file from DRAM to the network management system.</li> <li>• downloadToDramFromNMS(27) – Downloads the configuration file from the network management system to DRAM.</li> </ul>

Name, OID, and syntax	Access	Description
snAgCfgLoad (continued)		<p>The following values may be read:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• flashPrepareReadFailure(2)</li> <li>• flashReadError(3)</li> <li>• flashPrepareWriteFailure(4)</li> <li>• flashWriteError(5)</li> <li>• tftpTimeoutError(6)</li> <li>• tftpOutOfBufferSpace(7)</li> <li>• tftpBusy(8)</li> <li>• tftpRemoteOtherErrors(9)</li> <li>• tftpRemoteNoFile(10)</li> <li>• tftpRemoteBadAccess(11)</li> <li>• tftpRemoteDiskFull(12)</li> <li>• tftpRemoteBadOperation(13)</li> <li>• tftpRemoteBadId(14)</li> <li>• tftpRemoteFileExists(15)</li> <li>• tftpRemoteNoUser(16)</li> <li>• operationError(17)</li> <li>• loading(18)</li> <li>• tftpWrongFileType(29)</li> <li>• operationDoneWithNMS(28)</li> <li>• tftpWrongFileType(29)</li> <li>• downloadToDramFromServerOverwrite(30)</li> </ul> <p>The objects “snAgCfgFname” and “snAgTftpServerIp” are required to allow the download or upload process to occur. No write requests is allowed while a download or upload process is in progress.</p> <p>The snAgCfgEosTable objects must be sent along in one PDU for network management systems to recognize values from (24) to (27). A separate write memory using the CLI or an SNMP “set snAgWriteNVRAM” is required to save the configuration to NVRAM. This object requires a password to be set for the snAgGblPassword object.</p> <p><b>NOTE:</b> The snAgTftpServerIp object is deprecated by the snAgTftpServerAddrType object and the snAgTftpServerAddr object supports both IPv4 and IPv6.</p>

## Default gateway IP address

The following table lists the MIB object for the default gateway IP address.

Name, OID, and syntax	Access	Description
snAgDefGwayIp brcdIp.1.1.2.1.10 Syntax: Integer	Read-write	Shows the IP address of the default gateway router.

## Configuration notes

When using the snAgGblPassword object in a Set operation, the following must be considered:



The device always insist on a password to be part of snAgGblPassword object. You can override this requirement by entering the **no snmp-server pw-check** command.

By default, the object uses the value of the **enable super-user** password configured on the device as the default password. To allow a device to use other authentication schemes, use the **aaa authen snmp-server default enable | local | none** command.

The **enable** option instructs the device to use the configured enable super-user password. If the enable super-user password is missing, then the device checks for the if implicit TACACS+ enable password. The device stores a previous (unrelated to SNMP) implicit enable operation result and remembers the enable password that was approved by TACACS+. You can enter the following command to use this method.

```
SnmpSet(snAgGblPassword.0="<enable-password>", snAgEraseNVRAM.0=3)
```

The **local** option instructs the device to use a configured local username and password value. You can enter the following SNMP command to use this method.

```
SnmpSet(snAgGblPassword.0="<username> <password>", snAgEraseNVRAM.0=3)
```

The **none** option instructs the device to ignore the value of snAgGblPassword and the authentication check will always pass. You can enter the following SNMP command to use this method.

```
SnmpSet(snAgGblPassword.0="<anything here>", snAgEraseNVRAM.0=3)
```

```
aaa authentication login default TACACS+
aaa authentication enable default TACACS+
aaa authentication enable implicit-user
```

The snAgGblPassword object must be set for the following objects:

- snAgCfgLoad
- snAgImgLoad
- snAgConfigFromNVRAM
- snAgEraseNVRAM
- snAgWriteNVRAM
- snAgGblTelnetPassword
- snAgReload
- snAgSystemLog

## Usage notes on CPU utilization and system CPU utility table

There are three groups of CPU utilization MIB objects.

*Group A* consists of the following object and it is not to be used.

MIB object	OID
snAgGblCpuUtilData	brcdIp.1.1.2.1.35

The object in this group can display management module CPU utilization. The data it displays is from the last time that this object was read. If there is more than one management station reading the object, conflict occurs because every read resets the CPU utilization until the next read. It is recommended that this object not to be used.

*Group B* consists of the following objects.

MIB object	OID
snAgGblCpuUtil1SecAvg	brcdIp.1.1.2.1.50
snAgGblCpuUtil5SecAvg	brcdIp.1.1.2.1.51
snAgGblCpuUtil1MinAvg	brcdIp.1.1.2.1.52

Group B was created to resolve the multi-management stations issue of snAgGblCpuUtilData. These three objects are time-based. However, they only work for the management CPU utilization.

**NOTE**

The objects in Group B have been obsoleted on the Brocade NetIron XMR and Brocade MLX devices.

Use snAgentCpuUtilTable on the Brocade NetIron XMR and Brocade MLX devices.

Use snAgentCpuUtilTable if supported on a device instead of snAgGblCpuUtil1SecAvg, snAgGblCpuUtil5SecAvg, and snAgGblCpuUtil1MinAvg.

Group C consists of the snAgentCpu table.

MIB object	OID
snAgentCpu	brcdIp.1.1.2.11
snAgentCpuUtilTable	brcdIp.1.1.2.11.1
snAgentCpuUtilEntry	brcdIp.1.1.2.11.1.1
snAgentCpuUtilSlotNum	brcdIp.1.1.2.11.1.1.1
snAgentCpuUtilCpuId	brcdIp.1.1.2.11.1.1.2
snAgentCpuUtilInterval	brcdIp.1.1.2.11.1.1.3
snAgentCpuUtilValue	brcdIp.1.1.2.11.1.1.4
<b>NOTE:</b> This object is deprecated for Brocade MLX, Brocade NetIron XMR, FastIron GS, and FastIron SX devices. It is not supported on the Brocade MLXe devices. Use the snAgentCpuUtilPercent and snAgentCpuUtil100thPercent objects for these devices.	
snAgentCpuUtilPercent	brcdIp.1.1.2.11.1.1.5
<b>NOTE:</b> This object is supported on Brocade MLX, Brocade NetIron XMR, FastIron GS, FastIron SX, as well as Brocade MLXe devices.	
snAgentCpuUtil100thPercent	brcdIp.1.1.2.11.1.1.6
<b>NOTE:</b> This object is supported on Brocade MLX, Brocade NetIron XMR, FastIron GS, FastIron SX, as well as Brocade MLXe devices.	

The snAgentCpu table was created because switch families evolved from a single-CPU system to a multi-CPU system and CPU utilization information to non-management CPUs is required.

## Image version

The following objects show information about software images in a device. These objects are available in all devices.

Name, OID, and syntax	Access	Description
snAgImgVer brcdIp.1.1.2.1.11 Syntax: DisplayString	Read-only	Shows the version of the running software. The software image file name is displayed in the following format: major.minor.maintenance[ letters ] It can have up to 32 characters.
snAgFlashImgVer brcdIp.1.1.2.1.12 Syntax: DisplayString	Read-only	Shows the version of the software image that has been saved in the local storage, such as the flash memory. The software image file name is displayed in the following format: major.minor.maintenance[ letters ] It can have up to 32 characters. If this file is unknown or not available, then this object displays a null string.
snAgGblflpAddr brcdIp.1.1.2.1.13 Syntax: Integer	Read-write	Shows the IP address of the interface.
snAgGblflpMask brcdIp.1.1.2.1.14 Syntax: Integer	Read-write	Shows the IP address mask of the interface.
snAgGblPassword brcdIp.1.1.2.1.15 Syntax: DisplayString	Read-write	Shows the system security access password, which is used only for an SNMP-Set. An SNMP-Get will return a zero string. If the <b>password-change any</b> command (the default) is configured on the device, then this object must be part of the SNMP Set operation on some critical SNMP objects. The value of this object depends on the authentication method for SNMP operation: <ul style="list-style-type: none"> <li>• If there is no AAA authentication configuration for SNMP, then this object will have the enable super-user password.</li> <li>• If AAA authentication for SNMP is configured and has the leading method as “enable” or “line”, this object will have the corresponding “enable” or “line” password.</li> <li>• If the switch has AAA authentication for SNMP operation, and the method specified is one of local, TACACS+, or RADIUS, this object will have the &lt;username&gt; &lt;password&gt; format with one space character between &lt;username&gt; and &lt;password&gt;.</li> </ul> The maximum size allows concatenation of 48 octets of username and 48 octets of password, with one blank character Refer to <a href="#">“Configuration notes”</a> for more details. Valid values: Up to 48 octets
snAgGblDataRetrieveMode brcdIp.1.1.2.1.19 Syntax: Integer	Read-write	Retrieves the VLAN Table and Port-STP Table data as indicated by the selected mode. The mode can be one of the following: <ul style="list-style-type: none"> <li>• nextbootCfg(0) – Retrieves the next boot configuration data.</li> <li>• operationalData(1) – Retrieves the current running data.</li> </ul> Default: nextbootCfg(0)

Name, OID, and syntax	Access	Description
snAgSystemLog brcdIp.1.1.2.1.20 Syntax: OCTET STRING	Read-write	<p>Indicates whether any network management system has login privileges. The agent allows only one network management system to be logged in.</p> <p>The value of this object consists of an octet string. The following four bytes contain a secret code.</p> <p>The value of the first byte can be one of the following:</p> <ul style="list-style-type: none"> <li>login(1) – Login for a network management system.</li> <li>heartbeat(2) – A value for the login NMS periodically to check in; otherwise, the Agent automatically sets this object to logout(3) after a timeout period.</li> <li>logout(3) – A value for an NMS to log out.</li> <li>changePassword(4) – A value for the login NMS to change the password, only if snAgGblPasswordChangeMode was configured to “anyMgmtEntity”.</li> <li>changeReadOnlyCommunity(5) – A value for the login NMS to change the read-only community string, only if snAgGblPasswordChangeMode was configured to “anyMgmtEntity”.</li> <li>changeReadWriteCommunity(6) – A value for the login NMS to change the read-write community string, only if snAgGblPasswordChangeMode was configured to “anyMgmtEntity”.</li> </ul> <p>This object requires a password to be set for the snAgGblPassword object.</p>
snAgGblEnableColdStartTr ap brcdIp.1.1.2.1.21 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent process has been enabled to generate cold start traps:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snAgGblEnableLinkUpTrap brcdIp.1.1.2.1.22 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent process has been enabled to generate link up traps:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snAgGblEnableLinkDownTr ap brcdIp.1.1.2.1.23 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent process has been enabled to generate link down traps:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>

Name, OID, and syntax	Access	Description
snAgGblPasswordChange Mode brcdIp.1.1.2.1.24 Syntax: Integer	Read-only	Specifies which management entity is allowed to change the “enable” password for the device. For security reasons, this object can only be modified using the device CLI. Valid values: <ul style="list-style-type: none"> <li>anyMgmtEntity(1) – Any SNMP management station, console command line interface, or Telnet command line interface can be used to change the password.</li> <li>consoleAndTelnet(2) – The password can be changed using the console command line interface or the Telnet command line interface.</li> <li>consoleOnly(3) – Only the console command line interface can be used.</li> <li>telnetOnly(4) – Only the Telnet command line interface can be used.</li> </ul> Default: consoleAndTelnet(2)
snAgGblReadOnlyCommunity brcdIp.1.1.2.1.25 Syntax: DisplayString	Read-write	Allows you to configure SNMP read-only community strings for the device. This object can be used in an SNMP-Set, but not an SNMP-Get. Get returns a blank. Valid values: Up to 32 characters <b>NOTE:</b> To use this object, make sure that "password-change any" has been configured in the device to allow passwords to be updated from SNMP or any method.
snAgGblReadWriteCommunity brcdIp.1.1.2.1.26 Syntax: DisplayString	Read-write	Allows you to configure SNMP read-write community strings for the device. This object can be used in an SNMP-Set, but not an SNMP-Get. Get will return a blank. Valid values: Up to 32 characters. <b>NOTE:</b> To use this object, make sure that "password-change any" has been configured in the device to allow passwords to be updated from SNMP or any method.
snAgGblCurrentSecurityLevel brcdIp.1.1.2.1.27 Syntax: Integer	Read-only	Represents the current login security level (0 through 5). Each level of security requires a password to permit users for different system configurations. Levels are defined in the “snAgGblLevelPasswordsMask” object.
snAgGblSecurityLevelSet brcdIp.1.1.2.1.28 Syntax: Integer	Read-write	Shows the security level required to set an “enable” password. This security level can be from 0 through 5.
snAgGblLevelPasswordsMask brcdIp.1.1.2.1.29 Syntax: Integer32	Read-only	Shows the bitmap of level passwords, which were successfully assigned to the system: <ul style="list-style-type: none"> <li>Bit 0 – Level 0 = admin</li> <li>Bit 4 – Level 4 = port configuration</li> <li>Bit 5 – Level 5 = read only</li> </ul>
snAgGblQueueOverflow brcdIp.1.1.2.1.30 Syntax: Integer	Read-only	The device queues are overflowing: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblBufferShortage brcdIp.1.1.2.1.31 Syntax: Integer	Read-only	There is a shortage in the device buffers: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblDmaFailure brcdIp.1.1.2.1.32 Syntax: Integer	Read-only	The device DMAs are in good condition: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>

Name, OID, and syntax	Access	Description
snAgGblResourceLowWarning brcdIp.1.1.2.1.33 Syntax: Integer	Read-only	The device has low resources available: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblExcessiveErrorWarning brcdIp.1.1.2.1.34 Syntax: Integer	Read-only	The device has excessive collision, FCS errors, alignment warnings, and other excessive warnings: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblCpuUtilData brcdIp.1.1.2.1.35 Syntax: Gauge	Read-only	The statistics collection of utilization of the CPU in the devices. Reading this object in the Brocade NetIron and FastIron devices will reset all the counters. Therefore, it is not required to set the object to snAgGblUtilCollect.
snAgGblCpuUtilCollect brcdIp.1.1.2.1.36 Syntax: Integer	Read-write	Enables or disables the collection of CPU utilization statistics in a device. This can be one of the following: <ul style="list-style-type: none"> <li>enable(1)</li> <li>disable(0)</li> </ul>
snAgGblTelnetTimeout brcdIp.1.1.2.1.37 Syntax: Integer32	Read-write	Shows how many minutes a Telnet session can remain idle before it times out. Each value unit is one minute. The value of this object can be up to 240 minutes. A value of 0 means that the Telnet session never times out.
snAgGblEnableWebMgmt brcdIp.1.1.2.1.38 Syntax: Integer	Read-write	Enables or disables access to the device from the Web Management Interface: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>
snAgGblSecurityLevelBinding brcdIp.1.1.2.1.39 Syntax: Integer32	Read-only	After a network management system logs in to a device with a user ID and password, the privilege level assigned to that system is saved in this object. The privilege level can be one of the following: <ul style="list-style-type: none"> <li>Bit 0 – Level 0 = admin</li> <li>Bit 4 – Level 4 = port configuration</li> <li>Bit 5 – Level 5 = read only</li> <li>255 – Invalid binding</li> </ul>
snAgGblEnableSLB brcdIp.1.1.2.1.40 Syntax: Integer	Read-only	Enables or disables Server Load Balancing: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>

Name, OID, and syntax	Access	Description
snAgSoftwareFeature brcdIp.1.1.2.1.41 Syntax: OCTET STRING	Read-only	<p>Contains a bit string representing the software feature of the running software image. Each bit can have one of the following values:</p> <ul style="list-style-type: none"> <li>• 0 – The feature is not available</li> <li>• 1 – The feature is available</li> </ul> <p>Bit 0 is the least significant bit of an octet, and bit 7 is the most significant bit of an octet:</p> <ul style="list-style-type: none"> <li>• Octet 0, bit 0 – RMON</li> <li>• Octet 0, bit 1 – IPX switching</li> <li>• Octet 0, bit 2 – Server Load Balancing</li> <li>• Octet 0, bit 3 – Layer 3 filter in switch</li> <li>• Octet 0, bit 4 – IPX routing</li> <li>• Octet 0, bit 5 – AppleTalk routing</li> <li>• Octet 0, bit 6 – IP multicast routing</li> <li>• Octet 0, bit 7 – Local access control</li> <li>• Octet 1, bit 0 – BGP routing</li> <li>• Octet 1, bit 1 – Loopback interface</li> <li>• Octet 1, bit 2 – BigIron multi-management module</li> <li>• Octet 1, bit 3 – BigIron SYSIF II</li> <li>• Octet 1, bit 4 – BigIron POS support</li> <li>• Octet 1, bit 5 – AppleTalk cable VLAN</li> <li>• Octet 1, bit 6 – 64 subnet</li> <li>• Octet 1, bit 7 – multi-slot trunk</li> <li>• Octet 2, bit 0 – TACACS</li> <li>• Octet 2, bit 1 – Gigabit Ethernet port auto-negotiation mode</li> <li>• Octet 2, bit 2 – FSRP</li> <li>• Octet 2, bit 3 – Exodus requested OSPF enhancement</li> <li>• Octet 2, bit 4 – OSPF NSSA</li> <li>• Octet 2, bit 5 – POS</li> <li>• Octet 2, bit 6 – QoS</li> <li>• Octet 2, bit 7 – Single Span</li> <li>• Octet 3, bit 0 – Fast Span</li> <li>• Octet 3, bit 1 – Base Layer 3</li> <li>• Octet 3, bit 2 – Static log buffer</li> <li>• Octet 3, bit 3 – Layer 2 POS</li> <li>• Octet 3, bit 4 – BI15K</li> <li>• Octet 3, bit 5 – Layer 2 ATM</li> <li>• Octet 3, bit 6 – ATM</li> <li>• Octet 3, bit 7 – NETFLOW</li> </ul>

Name, OID, and syntax	Access	Description
snAgSoftwareFeature (continued)		<ul style="list-style-type: none"> <li>• Octet 4, bit 0 – SFLOW</li> <li>• Octet 4, bit 1 – GVRP</li> <li>• Octet 4, bit 2 – GARP</li> <li>• Octet 4, bit 3 – Dynamic trunk</li> <li>• Octet 4, bit 4 – IGC 8G</li> <li>• Octet 4, bit 5 – Rate limit</li> <li>• Octet 4, bit 6 – IPC rate limit</li> <li>• Octet 4, bit 7 – MPLS</li> <li>• Octet 5, bit 0 – IS-IS</li> <li>• Octet 5, bit 1 – Link aggregation</li> <li>• Octet 5, bit 2 – Port dual mode</li> <li>• Octet 5, bit 3 – Private VLAN</li> <li>• Octet 5, bit 4 – MBGP</li> <li>• Octet 5, bit 5 – IPV6 protocol VLAN</li> <li>• Octet 5, bit 6 – X10G</li> <li>• Octet 5, bit 7 – FastIron Edge switch/router</li> <li>• Octet 6, bit 0 – FDP</li> <li>• Octet 6, bit 1 – Port tag</li> <li>• Octet 6, bit 2 – Wireless capable</li> <li>• Octet 6, bit 3 – snSwPortVlanId object has changed from read-only to read-write</li> <li>• Octet 6, bit 4 – LLDP</li> </ul> <p>Additional bits are added for new features. Check the MIB file for the software version you are running.</p>
snAgGblEnableModuleInser tedTrap brcdIp.1.1.2.1.42 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent process has been enabled to generate traps for hardware modules that have been inserted in the chassis:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snAgGblEnableModuleRe movedTrap brcdIp.1.1.2.1.43 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent process has been enabled to generate traps for hardware modules that have been removed from the chassis:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snAgGblEnableTelnetServ er brcdIp.1.1.2.1.45 Syntax: Integer	Read-write	<p>Enables or disables the Telnet server in a device:</p> <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> <p>Default: enable(1)</p>
snAgGblTelnetPassword brcdIp.1.1.2.1.46 Syntax: DisplayString	Read-write	<p>Contains the Telnet access password, which is only used with an SNMP-Set. An SNMP-Get produces a zero string. This object can have 48 characters.</p> <p>This object requires a password to be set for the snAgGblPassword object.</p>
snAgBuildDate brcdIp.1.1.2.1.47 Syntax: DisplayString	Read-only	<p>Shows the date when the software was built. It can display up to 32 characters.</p>
snAgBuildtime brcdIp.1.1.2.1.48 Syntax: DisplayString	Read-only	<p>Shows the time when the software was built. It can display up to 32 characters.</p>



Name, OID, and syntax	Access	Description
snAgBuildVer brcdIp.1.1.2.1.49 Syntax: DisplayString	Read-only	Shows the image label of the software. It can display up to 32 characters.
snAgGblCpuUtil1SecAvg brcdIp.1.1.2.1.50 Syntax: Gauge32	Read-only	Shows CPU utilization every second. Use snAgentCpuUtilTable on the devices.
snAgGblCpuUtil5SecAvg brcdIp.1.1.2.1.51 Syntax: Gauge32	Read-only	Shows CPU utilization every five seconds. Use snAgentCpuUtilTable on the devices.
snAgGblCpuUtil1MinAvg brcdIp.1.1.2.1.52 Syntax: Gauge32	Read-only	Shows CPU utilization every minute. Use snAgentCpuUtilTable on the devices.
snAgGblDynMemUtil brcdIp.1.1.2.1.53 Syntax: Gauge32	Read-only	Shows the system dynamic memory utilization of the device in percentage units. <b>NOTE:</b> On Brocade NetIron devices, use the snAgentBrdMemoryUtil100thPercent object.
snAgGblDynMemTotal brcdIp.1.1.2.1.54 Syntax: Integer32	Read-only	Shows the total amount of system dynamic memory available in a device in number of bytes. <b>NOTE:</b> On Brocade NetIron devices, use the snAgentBrdMemoryTotal object.
snAgGblDynMemFree brcdIp.1.1.2.1.55 Syntax: Gauge32	Read-only	Shows the amount of system dynamic memory that is currently available in a device in number of bytes. <b>NOTE:</b> On Brocade NetIron devices, use the snAgentBrdMemoryAvailable object.
snAgImgLoadSPModuleType brcdIp.1.1.2.1.56 Syntax: Integer	Read-write	Shows the switch processor module type that receives the downloaded image: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• vm1(2)</li> <li>• pos12(3)</li> <li>• pos48(4)</li> <li>• atm(5)</li> <li>• gignpa(6)</li> <li>• lp(7)</li> </ul>
snAgImgLoadSPModuleNumber brcdIp.1.1.2.1.57 Syntax: Integer32	Read-write	Shows the slot number of a switch processor module that receives the downloaded image. Setting this object to zero (0) means that the switch processor modules receives the image.
snAgTrapHoldTime brcdIp.1.1.2.1.58 Syntax: Integer	Read-write	The number of seconds that traps will be held during device initialization. Traps are buffered while the device is initialized; they are sent when the device is back online. Valid value: 1 - 600
snAgSFlowSourceInterface brcdIp.1.1.2.1.59 Syntax: InterfaceIndex	Read-write	Identifies the source interface for sFlow packets sent by the device that is running sFlow Export. Use the ifIndex value for this object to specify the source interface to be used. The interface should have an IP address configured for sFlow. A value of zero (0) indicates that a source interface has not been configured for sFlow. Port 65534 is used to specify a null port.

Name, OID, and syntax	Access	Description
snAgGblTelnetLoginTimeout brcdIp.1.1.2.1.60 Syntax: Integer	Read-write	Indicates how many minutes you have to log in before Telnet is disconnected. Valid values: 1 – 10 minutes Default: 1 minute
snAgGblBannerExec brcdIp.1.1.2.1.61 Syntax: DisplayString	Read-write	Enter a message that will be displayed when a user enters the Privileged EXEC CLI level of a device. Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line. Leave this object blank if no message is to be displayed.
snAgGblBannerIncoming brcdIp.1.1.2.1.62 Syntax: DisplayString	Read-write	Enter a message that will be displayed on the console when a user establishes a Telnet session. This message includes the location where the user is connecting from and displays a text message that can be configured. Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line. Leave this object blank if no message is to be displayed.
snAgGblBannerMotd brcdIp.1.1.2.1.63 Syntax: DisplayString	Read-write	Enter the message of the day that is displayed on a user's terminal when the user establishes a Telnet CLI session. Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line. Leave this object blank if no message is to be displayed.
snAgWebMgmtServerTcpPort brcdIp.1.1.2.1.64 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	This object allows you to specify which TCP port will be used for the Web Management Interface. Also, Element Manager of Brocade Network Advisor will query the device for this port number before it sends HTTP packets to the device. Enter a number from 1 through 65535.
snAgGblDeleteFirstBeforeDownload brcdIp.1.1.2.1.67 Syntax: TruthVal <b>NOTE:</b> This object is not supported on the Brocade FastIron devices.	Read-write	When set to true, deletes the existing target file on the Management module flash. This object can be set to true only when the snAgImgLoad is set to downloadMPPPrimary(20), downloadMPSecondary(22), downloadSPPrimary(24), downloadSPSecondary(25), or downloadMPMonitor(31) in the same SNMP set request PDU. This object is reset to false after successful or unsuccessful download of specified file to flash. Reading this object returns false(2).

## Agent board table

The agent board table provides information about the boards. It contains the board ID, board status, LEDs, status, and other information about the main and expansion boards.

**NOTE**

The new MP card MR2 supports some of the objects in the Agent board table. Also, the MP-MR2 is supported only on the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snAgentBrdTable brcdIp.1.1.2.2.1	None	A table of each physical board information.
snAgentBrdIndex brcdIp.1.1.2.2.1.1.1 Syntax: Integer32	Read-only	The index to the agent board table. Valid values: 1 - 32
snAgentBrdMainBrdDescription brcdIp.1.1.2.2.1.1.2 Syntax: DisplayString	Read-only	Contains the main board description. This object can have up to 128 characters. <b>NOTE:</b> This object returns the description for the BR-MLX-10Gx8-X 8-port 10GbE (X) Module for Brocade NetIron XMR and BR-X-100Gx2 2-port 100GbE Module for Brocade NetIron XMR and Brocade MLX series devices.
snAgentBrdMainBrdId brcdIp.1.1.2.2.1.1.3 Syntax: OCTET STRING	Read-only	The main board identifier, which can uniquely identify a board type. It is an encoded octet string. The octets in the string provide the following information: <b>Octet 0</b> - Identifies the format of this object's octet string. If the format version has a value of 2, the octets after the version octet have the following meaning: <b>Octet 1</b> - Product type: <ul style="list-style-type: none"> <li>• BI_WG - 0x57</li> <li>• BI_BB - 0x42</li> <li>• BI_NI - 0x4E</li> <li>• BI_NI2 - 0x32</li> <li>• NI_M4 - 0x4D</li> <li>• BI_SLB - 0x53</li> </ul> <b>Octet 2</b> - Module type: <ul style="list-style-type: none"> <li>• MASTER_FIBER_8G - 0x0</li> <li>• MASTER_FIBER_4G - 0x1</li> <li>• MASTER_COPPER_16 - 0x2</li> <li>• SLAVE_FIBER_4G - 0x3</li> <li>• FI_MASTER_FIBER_2G - 0x4</li> <li>• FI_MASTER_FIBER_4G - 0x5</li> <li>• MASTER_COPPER_8G - 0x6</li> <li>• FI_MASTER_FIBER_8G - 0x7</li> <li>• SLAVE_FIBER_8G - 0x8</li> <li>• MASTER_COPPER_12_2 - 0x9</li> <li>• SLAVE_COPPER_24 - 0xA</li> <li>• FI_SLAVE_COPPER_24 - 0xB</li> <li>• SLAVE_100FX_16 - 0xC</li> <li>• SLAVE_100FX_8 - 0xD</li> <li>• SLAVE_COPPER_8G - 0xE</li> <li>• SLAVE_COPPER_16_2 - 0xF</li> <li>• STACK_FIBER_8G - 0x10</li> <li>• STACK_COPPER_8G - 0x11</li> <li>• MASTER_FIBER_2G - 0x12</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrdMainBrdd (continued)		<ul style="list-style-type: none"> <li>• SLAVE_100FX_24 - 0x13</li> <li>• MASTER_FIBER_0G - 0x14</li> <li>• POS_622M - 0x15</li> <li>• POS_155M - 0x16</li> <li>• SLAVE_FIBER_2G - 0x17</li> <li>• SLAVE_COPPER_2G - 0x18</li> <li>• FI_SLAVE_FIBER_2G - 0x19</li> <li>• FI_SLAVE_FIBER_4G - 0x1A</li> <li>• FI_SLAVE_FIBER_8G - 0x1B</li> <li>• FI_SLAVE_COPPER_8G - 0x1C</li> <li>• FI_MASTER_COPPER_8G - 0x1D</li> <li>• POS_155M2P - 0x1E</li> <li>• FI_MASTER_COPPER_4G - 0x1F</li> <li>• FI_MASTER_COPPER_2G - 0x20</li> <li>• MASTER_COPPER_4G - 0x21</li> <li>• MASTER_COPPER_2G - 0x22</li> <li>• MASTER_M4_8G - 0x23</li> <li>• MASTER_M4_4G - 0x24</li> <li>• MASTER_M4_2G - 0x25</li> <li>• MASTER_M4_0G - 0x26</li> <li>• MASTER_M5_0G - 0x27</li> <li>• POS_2488M - 0x28</li> <li>• SLAVE_M5_0G - 0x29</li> <li>• POS_N2488M - 0x2A</li> <li>• STACK_IPC_48_2 - 0x2B</li> <li>• SLAVE_NPA_FIBER_4G - 0x2C</li> <li>• ATM_2PORT - 0x2D</li> <li>• ATM_4PORT - 0x2E</li> <li>• SLAVE_FIBER_10G - 0x2F</li> <li>• STACK_FES_48_2 - 0x30</li> <li>• STACK_FES_24_2 - 0x31</li> <li>• STACK_FES_96_4 - 0x32</li> <li>• STACK_FES_12G - 0x33</li> <li>• STACK_FESX_24G - 0x34</li> <li>• STACK_FESX_24_2_G - 0x35</li> <li>• STACK_FESX_24_1_G - 0x36</li> <li>• STACK_FESX_48G - 0x37</li> <li>• STACK_FESX_48_2_G - 0x38</li> <li>• STACK_FESX_48_1_G - 0x39</li> <li>• SUPERX_FI_MGMT - 0x40</li> <li>• SUPERX_FI_2P10G - 0x41</li> <li>• SUPERX_FI_24GC - 0x42</li> <li>• SUPERX_FI_24GF - 0x43</li> <li>• SUPERX_FI_2P10G_WAN - 0x44</li> <li>• SUPERX_FI_MGMT_II - 0x4a</li> <li>• SLAVE_JC_48E - 0xC3</li> <li>• SLAVE_JC_48T - 0xC4</li> <li>• MASTER_JC_M4_8G - 0xC5</li> <li>• SLAVE_JC_8G - 0xC6</li> <li>• SLAVE_JC_B16GF - 0xC8</li> <li>• MASTER_JC_B2404 - 0xC9</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrdMainBrdId (continued)		<ul style="list-style-type: none"> <li>• SLAVE_JC_B16GC - 0xCA</li> <li>• SLAVE_JC_B24FX - 0xCE</li> </ul> <p><b>Octet 3</b> - Processor type:</p> <ul style="list-style-type: none"> <li>• PVR_M603 - 3</li> <li>• PVR_M604 - 4</li> <li>• PVR_M603E - 6</li> <li>• PVR_M603EV - 7</li> <li>• PVR_M750 - 8</li> <li>• PVR_M604E - 9</li> <li>• PVR_M8245 - 81</li> </ul> <p><b>Octet 4 to Octet 5</b> - Processor speed in MHz</p> <p><b>Octet 6</b> - MAC type:</p> <ul style="list-style-type: none"> <li>• MAC_None - 0</li> <li>• MAC_SEEQ_10_100 - 1</li> <li>• MAC_DEC_10_100 - 2</li> <li>• MAC_3COM_10_100 - 3</li> <li>• MAC_X10GMAC_10000 - 4</li> <li>• MAC_SEEQ_1000 - 5</li> <li>• MAC_GMAC_1000 - 6</li> <li>• MAC_VLSI_1000 - 7</li> </ul> <p><b>Octet 7</b> - PHY type:</p> <ul style="list-style-type: none"> <li>• PHY_NONE - 0</li> <li>• PHY_QSI - 1</li> <li>• PHY_BROADCOM - 2</li> <li>• PHY_ICS - 3</li> <li>• PHY_NATIONAL - 4</li> <li>• PHY_LEVEL1 - 6</li> <li>• PHY_BROADCOM_10_100 - 7</li> <li>• PHY_LEVEL24 - 8</li> <li>• PHY_BROADCOM_10000 - 9</li> <li>• PHY_3COM_10_100 - 9 (for others)</li> </ul> <p><b>Octet 8</b> - Port type:</p> <ul style="list-style-type: none"> <li>• COPPER - 0</li> <li>• FIBER - 1</li> </ul> <p><b>Octet 9</b> - Fiber port type:</p> <ul style="list-style-type: none"> <li>• NONFIBER - 0</li> <li>• SX_FIBER - 1</li> <li>• LX_FIBER - 2</li> <li>• LHX_FIBER - 3</li> <li>• LX_SX_FIBER=4</li> <li>• LHB_FIBER=5</li> </ul> <p><b>Octet 10 to Octet 13</b> - Size of DRAM in Kilobytes</p> <p><b>Octet 14 to Octet 17</b> - Size of boot flash in Kilobytes</p> <p><b>Octet 18 to Octet 21</b> - Size of code flash in Kilobytes</p> <p><b>Octet 22 to Octet 27</b> - Serial number</p> <p><b>Octet 28</b> - Chassis backplane type:</p> <ul style="list-style-type: none"> <li>• chassis4000 = 0x00</li> <li>• chassis8000 = 0x02</li> <li>• chassis15000 = 0x01</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrdMainBrdId (continued)		<ul style="list-style-type: none"> <li>chassisFISX = 0x04</li> <li>Turbo8 = 0x07 (stack2)</li> <li>FastIron2 = 0x06 (stack1)</li> </ul>
snAgentBrdMainPortTotal brcdIp.1.1.2.2.1.1.4 Syntax: Integer32	Read-only	Shows the total number of ports on the main board.
snAgentBrdExpBrdDescription brcdIp.1.1.2.2.1.1.5 Syntax: DisplayString	Read-only	Contains the expansion board description string. Expansion boards are those boards attached to the main board. This object can have up to 128 characters.
<b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.		
snAgentBrdExpBrdId brcdIp.1.1.2.2.1.1.6 Syntax: OCTET STRING	Read-only	<p>The expansion board identifier. Expansion boards are those boards attached to the main board. It is an encoded octet string with the following meaning:</p> <p><b>Octet 0</b> – Identifies the format of this string. This octet has a value of 1.</p> <p><b>Octet 1</b> – Expansion board type:</p> <ul style="list-style-type: none"> <li>HUNDRED_MEG_1PORT – 1</li> <li>HUNDRED_MEG_2PORT – 2</li> <li>HUNDRED_MEG_1PORT_COPPER – 3</li> <li>HUNDRED_MEG_2PORT_COPPER – 4</li> <li>HUNDRED_MEG_2PORT_LX – 5</li> <li>GIGA_1PORT – 8</li> <li>GIGA_2PORT – 9</li> </ul> <p><b>Octet 2</b> – Fiber port type:</p> <ul style="list-style-type: none"> <li>NONFIBER – 0</li> <li>SX_FIBER – 1</li> <li>LX_FIBER – 2</li> <li>LHX_FIBER – 3</li> <li>LX_SX_FIBER – 4</li> <li>LHB_FIBER – 5</li> </ul>
<b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.		
snAgentBrdExpPortTotal brcdIp.1.1.2.2.1.1.7 Syntax: Integer	Read-only	Shows the total number of ports for the expansion board.
<b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.		

Name, OID, and syntax	Access	Description
snAgentBrdStatusLeds brcdIp.1.1.2.2.1.1.8 Syntax: Integer32	Read-only	The object is replaced by the object snAgentBrdStatusLedString. The value of this LED can be one of the following: <ul style="list-style-type: none"> <li>0 – off (Link off)</li> <li>1 – on (Link on)</li> </ul>
snAgentBrdTrafficLeds brcdIp.1.1.2.2.1.1.9 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	The object is replaced by the object snAgentBrdTrafficLedString. The value of this LED can be one of the following: <ul style="list-style-type: none"> <li>0 – off (No traffic)</li> <li>1 – on (Traffic is flowing)</li> </ul>
snAgentBrdMediaLeds brcdIp.1.1.2.2.1.1.10 Syntax: Integer32	Read-only	Applies to devices that have an LED for media type, but this object has been replaced by the object snAgentBrdMediaLedString. The value of this LED can be one of the following: <ul style="list-style-type: none"> <li>0 – Half-duplex</li> <li>1 – Full-duplex</li> </ul>
snAgentBrdSpeedLeds brcdIp.1.1.2.2.1.1.11 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Applies to devices that have an LED for board speed. This object has been replaced by the object snAgentBrdSpeedLedString. The value of this LED can be one of the following: <ul style="list-style-type: none"> <li>0 – 10 Mbit</li> <li>1 – 100Mbit</li> </ul>
snAgentBrdModuleStatus brcdIp.1.1.2.2.1.1.12 Syntax: Integer	Read-only	Shows the status of a module: <ul style="list-style-type: none"> <li>moduleEmpty(0) – The slot of the chassis is empty.</li> <li>moduleGoingDown(2) – The module is going down.</li> <li>moduleRejected(3) – The module is being rejected due to a wrong configuration.</li> <li>moduleBad(4) – The module hardware is bad.</li> <li>moduleConfigured(8) – The module is configured (stacking).</li> <li>moduleComingUp(9) – The module is in power-up cycle.</li> <li>moduleRunning(10) – The module is running.</li> <li>moduleBlocked(11) – The module is blocked for full height card.</li> </ul> By default, this mode is set to notActivated(0).
snAgentBrdRedundantStatus brcdIp.1.1.2.2.1.1.13 Syntax: Integer	Read-only	Shows the status of the redundant module. Non-management modules always return other(1). The management module returns the rest of the states: <ul style="list-style-type: none"> <li>other(1)</li> <li>active(2)</li> <li>standby(3)</li> <li>crashed(4)</li> <li>comingUp(5)</li> </ul>

Name, OID, and syntax	Access	Description
<p>snAgentBrdAlarmLeds brcdIp.1.1.2.2.1.1.14 Syntax: Integer</p> <p><b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.</p>	Read-only	<p>Applies to devices with an alarm LED. This object has been replaced by the object snAgentBrdAlarmLedString. The value of this LED can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – No alarm</li> <li>• 1 – Alarm</li> </ul>
<p>snAgentBrdTxTrafficLeds brcdIp.1.1.2.2.1.1.15 Syntax: Integer</p> <p><b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.</p>	Read-only	<p>Applies only to POS modules that have an LED. This object has been replaced by the object snAgentBrdTxTrafficLedString. The value of this LED can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – No transmit traffic</li> <li>• 1 – Transmit traffic</li> </ul>
<p>snAgentBrdRxTrafficLeds brcdIp.1.1.2.2.1.1.16 Syntax: Integer</p> <p><b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.</p>	Read-only	<p>Applies only to POS modules that have an LED for transmit traffic, but this object has been replaced by the object snAgentBrdRxTrafficLedString. The value of this LED can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – off (Not receive traffic)</li> <li>• 1 – on (Receive traffic)</li> </ul>
<p>snAgentBrdStatusLedString brcdIp.1.1.2.2.1.1.17 Syntax: OCTET STRING</p>	Read-only	<p>The object contains an octet string that shows the value of the status of the link LED on the front panel. Each LED is encoded into 1 bit for each switch port.. The value of each bit can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Link is off</li> <li>• 1 – Link is on</li> </ul>
<p>snAgentBrdTrafficLedString brcdIp.1.1.2.2.1.1.18 Syntax: OCTET STRING</p>	Read-only	<p>A bit array that contains the value of the front panel traffic LEDs. This is a packed bit string; each LED is encoded into 1 bit for each switch port. The value of each bit can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – No traffic</li> <li>• 1 – Traffic is flowing</li> </ul>



Name, OID, and syntax	Access	Description
snAgentBrdMediaLedString brcdIp.1.1.2.2.1.1.19 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Applies to devices with an LED for media type. It contains an octet string with 64-bits per slot. The value of each bit can be one of the following: <ul style="list-style-type: none"> <li>• 0 – Half-duplex</li> <li>• 1 – Full-duplex</li> </ul>
snAgentBrdSpeedLedString brcdIp.1.1.2.2.1.1.20 Syntax: OCTET STRING	Read-only	Applies to devices that have an LED for traffic speed. Contains an octet string with 64-bits per slot. The value of each bit can be one of the following: <ul style="list-style-type: none"> <li>• 0 – 10 Mbit</li> <li>• 1 – 100 Mbit</li> </ul>
snAgentBrdAlarmLedString brcdIp.1.1.2.2.1.1.21 Syntax: OCTET STRING	Read-only	Applies to devices that have an alarm LED. Contains an octet string with 64-bits per slot. The value of each bit can be one of the following: <ul style="list-style-type: none"> <li>• 0 – No alarm</li> <li>• 1 – Alarm</li> </ul>
snAgentBrdTxTrafficLedString brcdIp.1.1.2.2.1.1.22 Syntax: OCTET STRING	Read-only	Applies only to POS modules. Contains an octet string with 64-bits per slot. The value of each bit can be one of the following: <ul style="list-style-type: none"> <li>• 0 – No transmit traffic</li> <li>• 1 – Transmit traffic</li> </ul>
snAgentBrdRxTrafficLedString brcdIp.1.1.2.2.1.1.23 Syntax: OCTET STRING	Read-only	Applies only to POS modules. Contains an octet string with 64-bits per slot. The value of each bit can be one of the following: <ul style="list-style-type: none"> <li>• 0 – No receive traffic</li> <li>• 1 – Receive traffic</li> </ul>
snAgentBrdMemoryTotal brcdIp.1.1.2.2.1.1.24 Syntax: CounterBasedGauge64	Read-only	Shows the total memory in bytes within this module.
snAgentBrdMemoryAvailable brcdIp.1.1.2.2.1.1.25 Syntax: CounterBasedGauge64	Read-only	Shows the available total memory in bytes within this module.
snAgentBrdSerialNumber brcdIp.1.1.2.2.1.1.26 Syntax: DisplayString	Read-only	Indicates the serial number of the board only for Brocade NetIron XMR, Brocade MLX, and Brocade MLXe router devices. No string is displayed if the serial number has not been programmed in the EEPROM or the module does not support a serial number.
snAgentBrdPartNumber brcdIp.1.1.2.2.1.1.27 Syntax: DisplayString	Read-only	Indicates the part number of the board only for Brocade NetIron XMR, Brocade MLX, and Brocade MLXe router devices. Nothing is displayed if the part number has not been programmed in the EEPROM or the module does not support a part number.
snAgentBrdMemoryUtil100thPercent brcdIp.1.1.2.2.1.1.28 Syntax: Unsigned32	Read-only	Indicates the dynamic memory that is currently utilized within this module, in units of one-hundredth of a percent.

## Agent stacking board table

The following table provides information on boards in a stacking device.

Name, OID, and syntax	Access	Description
snAgentBrd2Table brcdIp.1.1.2.2.2 Syntax: SEQUENCE OF SnAgentBrd2Entry	None	A table of physical board information for each unit.
snAgentBrd2Unit brcdIp.1.1.2.2.2.1.1 Syntax: Integer	Read-only	The index to the agent module table.
snAgentBrd2Slot brcdIp.1.1.2.2.2.1.2 Syntax: Integer	Read-only	The index to the agent module table.
snAgentBrd2MainBrdDes cription brcdIp.1.1.2.2.2.1.3 Syntax: DisplayString	Read-only	The main board description string. The size of the string can be from 0 through 128.
snAgentBrd2MainBrdId brcdIp.1.1.2.2.2.1.4 Syntax: OCTET STRING	Read-only	<p>The main board identifier, which can uniquely identify a board type. It is an encoded octet string. The octets in the string provide the following information:</p> <p><b>Octet 0</b> – Identifies the format of this object's octet string. If the format version has a value of 2, the octets after the version octet have the following meaning:</p> <p><b>Octet 1</b> – Product type:</p> <ul style="list-style-type: none"> <li>• BI_WG – 0x57</li> <li>• BI_BB – 0x42</li> <li>• BI_NI – 0x4E</li> <li>• BI_NI2 – 0x32</li> <li>• NI_M4 – 0x4D</li> <li>• BI_SLB – 0x53</li> </ul> <p><b>Octet 2</b> – Module type:</p> <ul style="list-style-type: none"> <li>• MASTER_FIBER_8G – 0x0</li> <li>• MASTER_FIBER_4G – 0x1</li> <li>• MASTER_COPPER_16 – 0x2</li> <li>• SLAVE_FIBER_4G – 0x3</li> <li>• FI_MASTER_FIBER_2G – 0x4</li> <li>• FI_MASTER_FIBER_4G – 0x5</li> <li>• MASTER_COPPER_8G – 0x6</li> <li>• FI_MASTER_FIBER_8G – 0x7</li> <li>• SLAVE_FIBER_8G – 0x8</li> <li>• MASTER_COPPER_12_2 – 0x9</li> <li>• SLAVE_COPPER_24 – 0xA</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrd2MainBrdId (continued)		<ul style="list-style-type: none"> <li>• FI_SLAVE_COPPER_24 - 0xB</li> <li>• SLAVE_100FX_16 - 0xC</li> <li>• SLAVE_100FX_8 - 0xD</li> <li>• SLAVE_COPPER_8G - 0xE</li> <li>• SLAVE_COPPER_16_2 - 0xF</li> <li>• STACK_FIBER_8G - 0x10</li> <li>• STACK_COPPER_8G - 0x11</li> <li>• MASTER_FIBER_2G - 0x12</li> <li>• SLAVE_100FX_24 - 0x13</li> <li>• MASTER_FIBER_0G - 0x14</li> <li>• POS_622M - 0x15</li> <li>• POS_155M - 0x16</li> <li>• SLAVE_FIBER_2G - 0x17</li> <li>• SLAVE_COPPER_2G - 0x18</li> <li>• FI_SLAVE_FIBER_2G - 0x19</li> <li>• FI_SLAVE_FIBER_4G - 0x1A</li> <li>• FI_SLAVE_FIBER_8G - 0x1B</li> <li>• FI_SLAVE_COPPER_8G - 0x1C</li> <li>• FI_MASTER_COPPER_8G - 0x1D</li> <li>• POS_155M2P - 0x1E</li> <li>• FI_MASTER_COPPER_4G - 0x1F</li> <li>• FI_MASTER_COPPER_2G - 0x20</li> <li>• MASTER_COPPER_4G - 0x21</li> <li>• MASTER_COPPER_2G - 0x22</li> <li>• MASTER_M4_8G - 0x23</li> <li>• MASTER_M4_4G - 0x24</li> <li>• MASTER_M4_2G - 0x25</li> <li>• MASTER_M4_0G - 0x26</li> <li>• MASTER_M5_0G - 0x27</li> <li>• POS_2488M - 0x28</li> <li>• SLAVE_M5_0G - 0x29</li> <li>• POS_N2488M - 0x2A</li> <li>• STACK_IPC_48_2 - 0x2B</li> <li>• SLAVE_NPA_FIBER_4G - 0x2C</li> <li>• ATM_2PORT - 0x2D</li> <li>• ATM_4PORT - 0x2E</li> <li>• SLAVE_FIBER_10G - 0x2F</li> <li>• STACK_FES_48_2 - 0x30</li> <li>• STACK_FES_24_2 - 0x31</li> <li>• STACK_FES_96_4 - 0x32</li> <li>• STACK_FES_12G - 0x33</li> <li>• STACK_FESX_24G - 0x34</li> <li>• STACK_FESX_24_2_G - 0x35</li> <li>• STACK_FESX_24_1_G - 0x36</li> <li>• STACK_FESX_48G - 0x37</li> <li>• STACK_FESX_48_2_G - 0x38</li> <li>• STACK_FESX_48_1_G - 0x39</li> <li>• SUPERX_FI_MGMT - 0x40</li> <li>• SUPERX_FI_2P10G - 0x41</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrd2MainBrdId (continued)		<ul style="list-style-type: none"> <li>• SUPERX_FI_24GC - 0x42</li> <li>• SUPERX_FI_24GF - 0x43</li> <li>• SUPERX_FI_2P10G_WAN - 0x44</li> <li>• SUPERX_FI_MGMT_II - 0x4a</li> <li>• SLAVE_JC_48E - 0xC3</li> <li>• SLAVE_JC_48T - 0xC4</li> <li>• MASTER_JC_M4_8G - 0xC5</li> <li>• SLAVE_JC_8G - 0xC6</li> <li>• SLAVE_JC_B16GF - 0xC8</li> <li>• MASTER_JC_B2404 - 0xC9</li> <li>• SLAVE_JC_B16GC - 0xCA</li> </ul> <p><b>Octet 3</b> - Processor type:</p> <ul style="list-style-type: none"> <li>• PVR_M603 - 3</li> <li>• PVR_M604 - 4</li> <li>• PVR_M603E - 6</li> <li>• PVR_M603EV - 7</li> <li>• PVR_M750 - 8</li> <li>• PVR_M604E - 9</li> <li>• PVR_M8245 - 81</li> </ul> <p><b>Octet 4 to Octet 5</b> - Processor speed in MHz.</p> <p><b>Octet 6</b> - MAC type:</p> <ul style="list-style-type: none"> <li>• MAC_None - 0</li> <li>• MAC_SEEQ_10_100 - 1</li> <li>• MAC_DEC_10_100 - 2</li> <li>• MAC_3COM_10_100 - 3</li> <li>• MAC_X10GMAC_10000 - 4</li> <li>• MAC_SEEQ_1000 - 5</li> <li>• MAC_GMAC_1000 - 6</li> <li>• MAC_VLSI_1000 - 7</li> </ul> <p><b>Octet 7</b> - PHY type:</p> <ul style="list-style-type: none"> <li>• PHY_NONE - 0</li> <li>• PHY_QSI - 1</li> <li>• PHY_BROADCOM - 2</li> <li>• PHY_ICS - 3</li> <li>• PHY_NATIONAL - 4</li> <li>• PHY_LEVEL1 - 6</li> <li>• PHY_BROADCOM_10_100 - 7</li> <li>• PHY_LEVEL24 - 8</li> <li>• PHY_BROADCOM_10000 - 9</li> <li>• PHY_3COM_10_100 - 9</li> </ul> <p><b>Octet 8</b> - Port type:</p> <ul style="list-style-type: none"> <li>• COPPER - 0</li> <li>• FIBER - 1</li> </ul> <p><b>Octet 9</b> - Fiber port type:</p> <ul style="list-style-type: none"> <li>• NONFIBER - 0</li> <li>• SX_FIBER - 1</li> <li>• LX_FIBER - 2</li> <li>• LHX_FIBER - 3</li> </ul>

Name, OID, and syntax	Access	Description
snAgentBrd2MainBrdId (continued)		<ul style="list-style-type: none"> <li>LX_SX_FIBER=4</li> <li>LHB_FIBER=5</li> </ul> <p><b>Octet 10 to Octet 13</b> – Size of DRAM in Kilobytes.  <b>Octet 14 to Octet 17</b> – Size of boot flash in Kilobytes.  <b>Octet 18 to Octet 21</b> – Size of code flash in Kilobytes.  <b>Octet 22 to Octet 27</b> – Serial number.  <b>Octet 28</b> – Chassis backplane type:</p> <ul style="list-style-type: none"> <li>chassis4000 – 0x00</li> <li>chassis8000 – 0x02</li> <li>chassis15000 – 0x01</li> <li>chassisFISX – 0x04</li> <li>Turbo8 – 0x07 (stack2)</li> <li>FastIron2 – 0x06 (stack1)</li> </ul>
snAgentBrd2MainPortTotal brcdIp.1.1.2.2.2.1.5 Syntax: Integer	Read-only	The total number of ports for the main board.
snAgentBrd2ModuleStatus brcdIp.1.1.2.2.2.1.6 Syntax: Integer	Read-only	Shows the status of the module. The following are the status of the module: <ul style="list-style-type: none"> <li>moduleEmpty(0) – The slot of the chassis is empty.</li> <li>moduleGoingDown(2) – The module is going down.</li> <li>moduleRejected(3) – The module is being rejected due to wrong configuration.</li> <li>moduleBad(4) – The module hardware is bad.</li> <li>moduleConfigured(8) – The module is configured (stacking).</li> <li>moduleComingUp(9) – The module is in power-up cycle.</li> <li>moduleRunning(10) – The module is running.</li> <li>moduleBlocked(11) – The module is blocked for full height card.</li> </ul> By default, this mode is set to notActivated(0).
snAgentBrd2RedundantStatus brcdIp.1.1.2.2.2.1.7 Syntax: Integer	Read-only	The status of a redundant module. Non-management modules always return other(1). Management modules return the other states: <ul style="list-style-type: none"> <li>other(1)</li> <li>active(2)</li> <li>standby(3)</li> <li>crashed(4)</li> <li>comingUp(5)</li> </ul>

## Trap receiver table

The trap receiver table allows you to configure trap receivers on IPv4 devices.

### NOTE

To delete a trap receiver, the agent needs the following varbinds in the setRequest PDU: snAgTrpRcvrIpAddr, snAgTrpRcvrCommunityOrSecurityName, and snAgTrpRcvrStatus. The snAgTrpRcvrStatus object must be set to delete(3).

Name, OID, and syntax	Access	Description
snAgTrpRcvrTable brcdIp.1.1.2.3.1 Syntax: SEQUENCE OF SnAgTrpRcvrEntry	None	The trap receiver table.
snAgTrpRcvrIndex brcdIp.1.1.2.3.1.1.1 Syntax: Integer	Read-only	Shows the index in the trap receiver table. Valid values: 1 – 10
snAgTrpRcvrIpAddr brcdIp.1.1.2.3.1.1.2 Syntax: IpAddress	Read-write	Indicates the IP address of the SNMP manager that will receive the trap.
snAgTrpRcvrCommunityOrSecurityName brcdIp.1.1.2.3.1.1.3 Syntax: OCTET STRING	Read-write	Indicates the community string to use to access the trap receiver. This object can have up to 32 octets.
snAgTrpRcvrStatus brcdIp.1.1.2.3.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following are the values: <ul style="list-style-type: none"> <li>ignore(5) – Do not send traps to this entry at this time.</li> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> </ul> If the row exists, then a SET with a value of create(5) returns error "badValue". Deleted rows are deleted immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>other(1) – Some other case.</li> <li>valid(2) – Row exists and is valid.</li> <li>ignore(5) – Do not send traps to this entry at this time.</li> </ul>
snAgTrpRcvrUDPPort brcdIp.1.1.2.3.1.1.5 Syntax: Integer	Read-write	Indicates the UDP port number of the trap receiver. Valid values: 0 – 65535 Default: 162
snAgTrpRcvrSecurityModel brcdIp.1.1.2.3.1.1.6 Syntax: Integer	Read-write	Allows configuration of security model (v1, v2c, or 3).
snAgTrpRcvrSecurityLevel brcdIp.1.1.2.3.1.1.7 Syntax: Integer	Read-write	Allows configuration of the security level (noauth, auth, or auth+priv).

## Boot sequence table

The boot sequence table shows a list of software image loads. The images are in the sequence that will be used at boot up. When the devices are booted, the first image in the table will be loaded into the device. If that software image fails, the second image will be tried. The process continues until a successful load is completed.

The boot sequence table is available in all devices. The combination of all the objects in this table must be unique. Duplicate instructions are rejected.

**NOTE**

Ensure that each entry is unique. It is possible to create entries with the same instructions by creating a new sequence index. Duplicate instructions may cause loops.

Name, OID, and syntax	Access	Description
snAgBootSeqTable brcdIp.1.1.2.4.1	None	Identifies the boot sequence table.
snAgBootSeqIndex brcdIp.1.1.2.4.1.1.1 Syntax: Integer	Read-only	The index to the boot sequence table.
snAgBootSeqInstruction brcdIp.1.1.2.4.1.1.2 Syntax: Integer	Read-write	Shows the image from which the device will boot: <ul style="list-style-type: none"> <li>fromPrimaryFlash(1)</li> <li>fromSecondaryFlash(2)</li> <li>fromTftpServer(3)</li> <li>fromBootpServer(4)</li> </ul>
snAgBootSeqIpAddr brcdIp.1.1.2.4.1.1.3 Syntax: IpAddress	Read-write	If the object “snAgBootSeqInstruction” is set to “fromTftpServer”, this object shows the IP address of the TFTP server that contains the image that will be used in the boot.
snAgBootSeqFilename brcdIp.1.1.2.4.1.1.4 Syntax: DisplayString	Read-write	Shows the name of the image filename on the TFTP server that will be used in the boot. This object applies only if the object “snAgBootSeqInstruction” is set to “fromTftpServer”. This object can have up to 32 characters.
snAgBootSeqRowStatus brcdIp.1.1.2.4.1.1.5 Syntax: Integer	Read-write	Creates or deletes an entry in the boot sequence table: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## SP boot sequence table

Name, OID, and syntax	Access	Description
snAgSpBootSeqTable brcdIp.1.1.2.4.2	None	Identifies the SP boot sequence table.
snAgSpBootSeqSpNumber brcdIp.1.1.2.4.2.1.1	None	The slot number of a switch processor module for which this boot sequence applies. Setting value 0 applies to all SP modules. Index 0 is valid only for setting to simplify the set operation for all the modules.
snAgSpBootSeqIndex brcdIp.1.1.2.4.2.1.2 Syntax: Integer	None	The index to the boot sequence table.

Name, OID, and syntax	Access	Description
snAgSpBootSeqInstruction brcdIp.1.1.2.4.2.1.3 Syntax: Integer	Read-write	Shows the image from which the device will boot: <ul style="list-style-type: none"> <li>fromSpPrimaryFlash(1)</li> <li>fromSpSecondaryFlash(2)</li> <li>fromMpPrimaryFlash(3)</li> <li>fromMpSecondaryFlash(4)</li> <li>fromPcmciaCard1(5)</li> <li>fromPcmciaCard2(6)</li> <li>fromTftpServer(7)</li> <li>interactively(8)</li> </ul>
snAgSpBootSeqIpAddr brcdIp.1.1.2.4.2.1.4 Syntax: IpAddress	Read-write	If the object <code>"snAgBootSeqInstruction"</code> is set to <code>"fromTftpServer"</code> , this object shows the IP address of the TFTP server that contains the image that will be used in the boot.
snAgSpBootSeqFilename brcdIp.1.1.2.4.2.1.5 Syntax: DisplayString	Read-write	Shows the name of the image filename on the TFTP server that will be used in the boot. This object applies only if the object <code>"snAgBootSeqInstruction"</code> is set to <code>"fromTftpServer"</code> . This object can have up to 32 characters.
snAgSpBootSeqRowStatus brcdIp.1.1.2.4.2.1.6 Syntax: Integer	Read-write	Creates or deletes an entry in the boot sequence table: <ul style="list-style-type: none"> <li>valid(1)</li> <li>delete(2)</li> <li>create(3)</li> </ul>

## Encoded octet strings table

Each row in the Encoded Octet Strings (EOS) table represents a fragmented configuration file data packet, including its checksum. An SNMP SET represents a configuration file download process, while an SNMP GET represents a configuration file upload.

This action occurs only if the SNMP-SET of snAgCfgLoad command is sent along with this table consecutively. Consecutive SETs are performed until the network management system has no more packets to send. Likewise, consecutive GETs are done until the agent has no more packets to send.

The applicable snAgCfgLoad command value is as follows:

- uploadFromFlashToNMS(23)
- downloadToFlashFromNMS(24)
- uploadFromDramToNMS(25)
- downloadToDramFromNMS(26)

### NOTE

This table is not supported on the Brocade MLXe, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.



<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snAgCfgEosTable brcdIp.1.1.2.5.1	None	The EOS table.
snAgCfgEosIndex brcdIp.1.1.2.5.1.1.1 Syntax: Integer32	Read-only	Each VLAN EOS buffer identifier has multiple VLAN table entries.
snAgCfgEosPacket brcdIp.1.1.2.5.1.1.2 Syntax: OCTET STRING	Read-write	An encoded octet string. On reads, it contains an integral number of configuration file data packets. The size of each encoded octet string is less than or equal to 1400 bytes. This object can contain up to 1000 octets.
snAgCfgEosChkSum brcdIp.1.1.2.5.1.1.3 Syntax: Integer32	Read-write	A checksum of each configuration file data packet.

# 5 Agent Groups

# Agent System Parameters

---

## In this chapter

- Agent system parameters configuration table ..... 153
- Configured module table. .... 154
- Configuration module table for stacking ..... 159
- Agent user access group. .... 163
- Agent user account table ..... 163
- System CPU utilization table. .... 165
- System process utilization table. .... 166
- Hardware integrated central buffer manager counter table ..... 167

## Agent system parameters configuration table

The agent system parameters configuration table presents the definition of the configuration system parameters. For example, the table may show the maximum number of VLANs a network can have.

Name, OID, and syntax	Access	Description
snAgentSysParaConfigTable brcdIp.1.1.2.7.1	None	The agent system parameters configuration table.
snAgentSysParaConfigIndex brcdIp.1.1.2.7.1.1.1 Syntax: Integer32	Read-only	The index to the agent system parameters configuration table.
snAgentSysParaConfigDescription brcdIp.1.1.2.7.1.1.2 Syntax: DisplayString	Read-only	The parameter description string. This object can have up to 32 characters.
snAgentSysParaConfigMin brcdIp.1.1.2.7.1.1.3 Syntax: Integer32	Read-only	The minimum value of this agent system parameter.
snAgentSysParaConfigMax brcdIp.1.1.2.7.1.1.4 Syntax: Integer32	Read-only	The maximum value of this agent system parameter.
snAgentSysParaConfigDefault brcdIp.1.1.2.7.1.1.5 Syntax: Integer32	Read-only	The default value of this agent system parameter.
snAgentSysParaConfigCurrent brcdIp.1.1.2.7.1.1.6 Syntax: Integer32	Read-write	The current configured value of this agent system parameter.

## Configured module table

The configured module table contains information about modules. It includes the object **snAgentConfigModuleSerialNumber**, which contains the serial number of Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

### NOTE

The snAgentConfigModuleType object has new values included to support the new version of MP card MR2 in the Configured module table. Also, the MP-MR2 is supported only on the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices.

---

Name, OID, and syntax	Access	Description
snAgentConfigModuleTable brcdIp.1.1.2.8.1	None	A table of information about each configured module.
snAgentConfigModuleIndex brcdIp.1.1.2.8.1.1.1 Syntax: Integer32	Read-only	The index to the agent configured module table.
snAgentConfigModuleType brcdIp.1.1.2.8.1.1.2 Syntax: Integer32	Read-write	The module type that has been configured for the device: <ul style="list-style-type: none"> <li>• bi8PortGigManagementModule(0)</li> <li>• bi4PortGigManagementModule(1)</li> <li>• bi16PortCopperManagementModule(2)</li> <li>• bi4PortGigModule(3)</li> <li>• fi2PortGigManagementModule(4)</li> <li>• fi4PortGigManagementModule(5)</li> <li>• bi8PortGigCopperManagementModule(6)</li> <li>• fi8PortGigManagementModule(7)</li> <li>• bi8PortGigModule(8)</li> <li>• bi12PortGigCopper2PortGigFiberManagement(9)</li> <li>• bi24PortCopperModule(10)</li> <li>• fi24PortCopperModule(11)</li> <li>• bi16Port100FXModule(12)</li> <li>• bi8Port100FXModule(13)</li> <li>• bi8PortGigCopperModule(14)</li> <li>• bi12PortGigCopper2PortGigFiber(15)</li> <li>• bi2PortGigManagementModule(18)</li> <li>• bi24Port100FXModule(19)</li> <li>• bi0PortManagementModule(20)</li> <li>• pos622MbsModule(21)</li> <li>• pos155MbsModule(22)</li> <li>• bi2PortGigModule(23)</li> <li>• bi2PortGigCopperModule(24)</li> <li>• fi2PortGigModule(25)</li> <li>• fi4PortGigModule(26)</li> <li>• fi8PortGigModule(27)</li> <li>• fi8PortGigCopperModule(28)</li> </ul>

Name, OID, and syntax	Access	Description
snAgentConfigModuleType (continued)		<ul style="list-style-type: none"> <li>• fi8PortGigCopperManagementModule(29)</li> <li>• pos155Mbs2PModule(30)</li> <li>• fi4PortGigCopperManagementModule(31)</li> <li>• fi2PortGigCopperManagementModule(32)</li> <li>• bi4PortGigCopperManagementModule(33)</li> <li>• bi2PortGigCopperManagementModule(34)</li> <li>• bi8PortGigM4ManagementModule(35)</li> <li>• bi4PortGigM4ManagementModule(36)</li> <li>• bi2PortGigM4ManagementModule(37)</li> <li>• bi0PortGigM4ManagementModule(38)</li> <li>• bi0PortWSMManagementModule(39)</li> <li>• biPos2Port2488MbsModule(40)</li> <li>• bi0PortWSMModule(41)</li> <li>• niPos2Port2488MbsModule(42)</li> <li>• ni4802(43)</li> <li>• bi4PortGigNPAModule(44)</li> <li>• biAtm2Port155MbsModule(45)</li> <li>• biAtm4Port155MbsModule(46)</li> <li>• bi1Port10GigModule(47)</li> <li>• fes4802Module(48)</li> <li>• fes2402Module(49)</li> <li>• fes9604Module(50)</li> <li>• fes12GigCopperAndGigFiberModule(51)</li> <li>• fesx24GigModule(52)</li> <li>• fesx24Gig2TenGigModule(53)</li> <li>• fesx24Gig1TenGigModule(54)</li> <li>• fesx48GigModule(55)</li> <li>• fesx48Gig2TenGigModule(56)</li> <li>• fesx48Gig1TenGigModule(57)</li> <li>• fesx24GigFiberGigCopperModule(112)</li> <li>• fesx24GigFiber2TenGigModule(113)</li> <li>• fesx24GigFiber1TenGigModule(114)</li> <li>• fgs24PortManagementModule(144)</li> <li>• fgs48PortManagementModule(145)</li> <li>• fgsXfp2Port10gModule(152)</li> <li>• fgsCx42Port10gModule(153)</li> <li>• fgsXfp1Cx41Port10gModule(154)</li> <li>• fgsXpf1Port10gModule(155)</li> <li>• fls24PortCopperBaseModule(160)</li> <li>• fls48PortCopperBaseModule(161)</li> <li>• flsXfp1Port10gModule(168)</li> <li>• flsCx41Port10gModule(169)</li> <li>• fcx624SBaseModule(176)</li> <li>• fcx648SBaseModule(177)</li> <li>• fcx624SPoeBaseModule(180)</li> <li>• fcx648SPoeBaseModule(181)</li> <li>• fcxXfp2Port10gModule(184)</li> <li>• fcxCx42Port16gModule(185)</li> <li>• fcx624SFBaseModule(192)</li> <li>• biFiJc48ePort100fxlpcModule(195)</li> </ul>

Name, OID, and syntax	Access	Description
snAgentConfigModuleType (continued)		<ul style="list-style-type: none"> <li>• biFjC48tPort100fxlpcModule(196)</li> <li>• biFjC8PortGigM4ManagementModule(197)</li> <li>• biFjC8PortGigGlcModule(198)</li> <li>• biFjC16PortGigGlcModule(200)</li> <li>• biJc24PortCopperlpc4GigGlcModule(201)</li> <li>• biJc16PortGigCopperlpcModule(202)</li> <li>• biFjC24Port100fxlpcModule(206)</li> <li>• bi2Port10GigModule(207)</li> <li>• biJc48tPortRJ210mpModule(208)</li> <li>• biJc48ePortRJ450mpModule(209)</li> <li>• biJc24PortlpcRJ45PoeModule(212)</li> <li>• biJc2PortGigGlcM4ManagementModule(214)</li> <li>• fdryBi4Port10GigModule(1048)</li> <li>• fdryBi40PortGigModule(1049)</li> <li>• fdryBi1Port100FXManagementModule(1050)</li> <li>• fdryBi2Port10GigModule(1051)</li> <li>• fdryBi40PortGigCopperModule(1052)</li> <li>• fdryBi60PortGigCopperModule(1053)</li> <li>• fdryBi4Port10GigHVModule(1054)</li> <li>• fdryBi2Port10GigHVModule(1055)</li> <li>• fdryBi8Port10GigHVModule(1056)</li> <li>• fdryBi40PortGigHVModule(1057)</li> <li>• fdryBi40PortGigCopperHVModule(1058)</li> <li>• fdryBi60PortGigCopperHVModule(1059)</li> <li>• fdryBi8Port10GigModule(1060)</li> <li>• fdryBi10PortGigHVModule(1061)</li> <li>• fdryBi20PortGigHVModule(1062)</li> <li>• fdryBi24PortGigModule(1063)</li> <li>• fdryBi24PortGigCopperModule(1064)</li> <li>• fdryBi48PortGigCopperModule(1065)</li> <li>• fdryBi24PortGigFiberModule(1066)</li> <li>• fdryBi16Port10GigModule(1067)</li> <li>• fdryNi4Port10GigSPModule(1075)</li> <li>• fdryNi40PortGigSPModule(1076)</li> <li>• fdryNi40PortGigCopperSPModule(1077)</li> <li>• fdryNi2Port10GigSPModule(1078)</li> <li>• fdryNi10PortGigSPModule(1079)</li> <li>• fdryNi20PortGigSPModule(1080)</li> <li>• fdryXmr4Port10GigSPModule(1081)</li> <li>• fdryXmr20PortGigSPModule(1082)</li> <li>• fdryXmr2Port10GigSPModule(1083)</li> <li>• fdryXmr20PortGigCopperSPModule(1084)</li> <li>• fdryXmr20PortGigFXSPModule(1085)</li> <li>• fdryNilmrMrManagementModule(1086)</li> <li>• fdryNiXmrMrManagementModule(1087)</li> <li>• fdryMlx4Port10GigSPModule(1088)</li> <li>• fdryMlx2Port10GigSPModule(1089)</li> <li>• fdryMlx20PortGigCopperSPModule(1090)</li> <li>• fdryMlx20PortGigFXSPModule(1091)</li> <li>• niMlx8Port10GigSPModule (1092)</li> </ul>

Name, OID, and syntax	Access	Description
snAgentConfigModuleType (continued)		<ul style="list-style-type: none"> <li>• niMlx4Port10GigXModule(1093) - This module is supported only on NetIron devices.</li> <li>• niMlx24PortGigCopperXModule(1094) - This module is supported only on NetIron devices.</li> <li>• niMlx24PortGigSfpXModule(1095) - This module is supported only on NetIron devices.</li> <li>• niCes24PortFiberModule(1096)</li> <li>• niCes24PortCopperModule(1097)</li> <li>• niCes2Port10GigModule(1098)</li> <li>• niCes48PortFiberModule(1099)</li> <li>• niCes48PortCopperModule(1100)</li> <li>• niCes48PortFiberWith2Port10GModule(1101)</li> <li>• niCes48PortCopperWith2Port10GModule(1102)</li> <li>• fdryMlx48PortGigMrj21SPModule(1103)</li> <li>• fdryXmr2PortOC192SPModule(1104)</li> <li>• fdryXmr1PortOC192SPModule(1105)</li> <li>• fdryXmr8PortOC48SPModule(1106)</li> <li>• fdryXmr4PortOC48SPModule(1107)</li> <li>• fdryXmr2PortOC48SPModule(1108)</li> <li>• fdryNiMlxMrManagementModule(1109)</li> <li>• niMlx8Port10GigMModule(1110) - This module is supported only on NetIron devices.</li> <li>• niMlx8Port10GigDModule(1111) - This module is supported only on NetIron devices.</li> <li>• brMlx8Port10GigXModule(1112) - This module is supported only on NetIron devices.</li> <li>• brMlx2Port100GigXModule(1113) - This module is supported only on NetIron devices.</li> <li>• brcdMlxMr2ManagementModule(1114) - This module is used only for BR-MLX-MR2-M board.</li> <li>• brcdXmrMr2ManagementModule(1115) - This module is used only for BR-MLX-MR2-X board.</li> <li>• brcdMlx32Mr2ManagementModule(1116) - This module is used only BR-MLX32-MR2-M board.</li> <li>• brcdXmr32Mr2ManagementModule(1117) - This module is used only BR-MLX32-MR2-X board.</li> <li>• brcdNiXmr32MrManagementModule(1118)</li> <li>• brcdNiMlx32MrManagementModule(1119)</li> <li>• fdrylxc6450624BaseModule(2032)</li> <li>• fdrylxc6450648BaseModule(2033)</li> <li>• fdrylxc6450624PoeBaseModule(2036)</li> <li>• fdrylxc6450648PoeBaseModule(2037)</li> <li>• fdrylxc6450sfp4Port40gModule(2040)</li> <li>• fdryFiv4Sx12ComboPortManagementModule(2064)</li> <li>• fdryFiv4Sx2Port10gModule(2065)</li> <li>• fdryFiv4Sx24PortGigCopperModule(2066)</li> <li>• fdryFiv4Sx24PortGigFiberModule(2067)</li> <li>• fdryFiv4Sx2Port10gLanWanModule(2068)</li> <li>• fdryFiv4Sx24Port100m1gFiberModule(2069)</li> <li>• fdryFiv4Sx12ComboPortManagement2Module(2074)</li> <li>• fdryFiv4Sx210gPortManagementModule(2080)</li> <li>• fdryFisx0PortManagementModule(2081)</li> <li>• fdryFiv4Sx4g4fPortManagementModule(2083)</li> <li>• fdryFiv6Sx12ComboPortManagementModule(2096)</li> </ul>

## 6 Agent System Parameters

Name, OID, and syntax	Access	Description
snAgentConfigModuleType (continued)		<ul style="list-style-type: none"> <li>fdryFiv6Sx24PortGigCopperModule(2098)</li> <li>fdryFiv6Sx2Port10gModule(2100)</li> <li>fdryFiv6Sx24Port100m1gFiberModule(2101)</li> <li>fdryFiv6Sx210gPortManagementModule(2102)</li> <li>fdryFiv6Sx48PortGigCopperPoeModule(2103)</li> <li>fdryFiv6Sx4g4fPortManagementModule(2104)</li> <li>fdryFiv6Sx12ComboPortManagement2Module(2105)</li> <li>fdryFiv6Sx48PortGigCopperModule(2106)</li> <li>fdryFws24PortCopperBaseModule(2224)</li> <li>fdryFws48PortCopperBaseModule(2225)</li> <li>fdryFws24GPortCopperBaseModule(2226)</li> <li>fdryFws48GPortCopperBaseModule(2227)</li> <li>fdryFcx624BaseModule(2208)</li> <li>fdryFcx648BaseModule(2209)</li> <li>fdryFcxSfpPlus4Port10gModule(2220)</li> <li>fdrylcx6610624BaseModule(2240)</li> <li>fdrylcx6610648BaseModule(2241)</li> <li>fdrylcx6610624PoeBaseModule(2244)</li> <li>fdrylcx6610648PoeBaseModule(2245)</li> <li>fdrylcx6610624FBaseModule(2246)</li> <li>fdrylcx6610DualMode8PortModule(2248)</li> <li>fdrylcx6610Qsfp10Port160gModule(2249)</li> </ul>
snAgentConfigModuleRowStatus brcdIp.1.1.2.8.1.1.3 Syntax: Integer	Read-write	To create or delete a configured module table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>
snAgentConfigModuleDescription brcdIp.1.1.2.8.1.1.4 Syntax: DisplayString	Read-only	The description of the configured module.
snAgentConfigModuleOperStatus brcdIp.1.1.2.8.1.1.5 Syntax: DisplayString	Read-only	The module operational status. A blank indicates that the physical module has not been inserted in the chassis.
snAgentConfigModuleSerialNumber brcdIp.1.1.2.8.1.1.6 Syntax: DisplayString <b>NOTE:</b> This object is not supported for Brocade NetIron XMR, Brocade MLX, and Brocade MLXe. Use the snAgentBrdSerialNumber in the snAgentBrdTable instead.	Read-only	The module serial number. A blank indicates that the serial number has not been programmed in the module's EEPROM or the serial number is not supported in the module. This object returns the device serial number.



Name, OID, and syntax	Access	Description
snAgentConfigModuleNumberOfPorts brcdIp.1.1.2.8.1.1.7 Syntax: Integer32	Read-only	The number of ports in the module.
snAgentConfigModuleMgmtModuleType brcdIp.1.1.2.8.1.1.8 Syntax: Integer	Read-only	The management module types: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• nonManagementModule(2)</li> <li>• unknownManagementModule(3)</li> <li>• m1ManagementModule(4)</li> <li>• m2ManagementModule(5)</li> <li>• m3ManagementModule(6)</li> <li>• m4ManagementModule(7)</li> <li>• m5ManagementModule(8)</li> <li>• jetcoreStackManagementModule(9)</li> <li>• muchoManagementModule(10)</li> <li>• rottweilerManagementModule(11)</li> <li>• fesXStackManagementModule(12)</li> <li>• fgsStackManagementModule(13)</li> </ul>
snAgentConfigModuleNumberOfCpus brcdIp.1.1.2.8.1.1.9 Syntax: Integer32	Read-only	The number of CPUs in the module.

## Configuration module table for stacking

The following table contains information about modules in a stacking device.

Name, OID, and syntax	Access	Description
snAgentConfigModuleTable brcdIp.1.1.2.8.2	None	A table of each configured stacking module information.
snAgentConfigModuleUnit brcdIp.1.1.2.8.2.1.1 Syntax: Integer	Read-only	The index to the configured stacking module table. Value can be from 1 through 8.
snAgentConfigModuleSlot brcdIp.1.1.2.8.2.1.2 Syntax: Integer	Read-only	The index to the agent configured module table. Value can be from 1 through 4.

## 6 Agent System Parameters

Name, OID, and syntax	Access	Description
snAgentConfigModuleType pe brcdIp.1.1.2.8.2.1.3 Syntax: Integer	Read-only	<p>The module type that has been configured for the device:</p> <ul style="list-style-type: none"> <li>• bi8PortGigManagementModule(0)</li> <li>• bi4PortGigManagementModule(1)</li> <li>• bi16PortCopperManagementModule(2)</li> <li>• bi4PortGigModule(3)</li> <li>• fi2PortGigManagementModule(4)</li> <li>• fi4PortGigManagementModule(5)</li> <li>• bi8PortGigCopperManagementModule(6)</li> <li>• fi8PortGigManagementModule(7)</li> <li>• bi8PortGigModule(8)</li> <li>• bi12PortGigCopper2PortGigFiberManagement(9)</li> <li>• bi24PortCopperModule(10)</li> <li>• fi24PortCopperModule(11)</li> <li>• bi16Port100FXModule(12)</li> <li>• bi8Port100FXModule(13)</li> <li>• bi8PortGigCopperModule(14)</li> <li>• bi12PortGigCopper2PortGigFiber(15)</li> <li>• bi2PortGigManagementModule(18)</li> <li>• bi24Port100FXModule(19)</li> <li>• bi0PortManagementModule(20)</li> <li>• pos622MbsModule(21)</li> <li>• pos155MbsModule(22)</li> <li>• bi2PortGigModule(23)</li> <li>• bi2PortGigCopperModule(24)</li> <li>• fi2PortGigModule(25)</li> <li>• fi4PortGigModule(26)</li> <li>• fi8PortGigModule(27)</li> <li>• fi8PortGigCopperModule(28)</li> <li>• fi8PortGigCopperManagementModule(29)</li> <li>• pos155Mbs2PModule(30)</li> <li>• fi4PortGigCopperManagementModule(31)</li> <li>• fi2PortGigCopperManagementModule(32)</li> <li>• bi4PortGigCopperManagementModule(33)</li> <li>• bi2PortGigCopperManagementModule(34)</li> <li>• bi8PortGigM4ManagementModule(35)</li> <li>• bi4PortGigM4ManagementModule(36)</li> <li>• bi2PortGigM4ManagementModule(37)</li> <li>• bi0PortGigM4ManagementModule(38)</li> </ul>

Name, OID, and syntax	Access	Description
snAgentConfigModule2Type pe (continued)		<ul style="list-style-type: none"> <li>• bi0PortWSMManagementModule(39)</li> <li>• biPos2Port2488MbsModule(40)</li> <li>• bi0PortWSModule(41)</li> <li>• niPos2Port2488MbsModule(42)</li> <li>• ni4802(43)</li> <li>• bi4PortGigNPAModule(44)</li> <li>• biAtm2Port155MbsModule(45)</li> <li>• biAtm4Port155MbsModule(46)</li> <li>• bi1Port10GigModule(47)</li> <li>• fes4802Module(48)</li> <li>• fes2402Module(49)</li> <li>• fes9604Module(50)</li> <li>• fes12GigCopperAndGigFiberModule(51)</li> <li>• fesx24GigModule(52)</li> <li>• fesx24Gig2TenGigModule(53)</li> <li>• fesx24Gig1TenGigModule(54)</li> <li>• fesx48GigModule(55)</li> <li>• fesx48Gig2TenGigModule(56)</li> <li>• fesx48Gig1TenGigModule(57)</li> <li>• superx12ComboPortManagementModule(64)</li> <li>• superx2PortTenGigModule(65)</li> <li>• superx24PortGigCopperModule(66)</li> <li>• superx24PortGigFiberModule(67)</li> <li>• superx2PortTenGigLanWanModule(68)</li> <li>• superx24Port100tx1PortGigFiberModule(69)</li> <li>• superx12ComboPortManagement2Module(74)</li> <li>• superxR2PortTenGigManagementModule(80)</li> <li>• superxRManagementModule(81)</li> <li>• fesx24GigFiberGigCopperModule(112)</li> <li>• fesx24GigFiber2TenGigModule(113)</li> <li>• fesx24GigFiber1TenGigModule(114)</li> <li>• biFiJc48ePort100fxlpcModule(195)</li> <li>• biFiJc48tPort100fxlpcModule(196)</li> <li>• biFiJc8PortGigM4ManagementModule(197)</li> <li>• biFiJc8PortGiglgcModule(198)</li> <li>• biFiJc16PortGiglgcModule(200)</li> <li>• biJc24PortCopperlpc4GiglgcModule(201)</li> <li>• biJc16PortGigCopperlgcModule(202)</li> <li>• biFiJc24Port100fxlpcModule(206)</li> <li>• bi2Port10GigModule(207)</li> <li>• biJc48tPortRJ210mpModule(208)</li> <li>• biJc48ePortRJ45OmpModule(209)</li> <li>• biJc24PortlpcRJ45PoeModule(212)</li> <li>• biJc2PortGiglgcM4ManagementModule(214)</li> </ul> <p>The FastIron devices supports the following module types:</p> <ul style="list-style-type: none"> <li>• fgs24PortManagementModule(144)</li> <li>• fgs48PortManagementModule(145)</li> <li>• fgsXfp2Port10gModule(152)</li> <li>• fgsCx42Port10gModule(153)</li> <li>• fgsXfp1Cx41Port10gModule(154)</li> </ul>

## 6 Agent System Parameters

Name, OID, and syntax	Access	Description
snAgentConfigModule2Type (continued)		<ul style="list-style-type: none"> <li>• fgsXfp1Port10gModule(155)</li> <li>• fls24PortCopperBaseModule(160)</li> <li>• fls48PortCopperBaseModule(161)</li> <li>• flsXfp1Port10gModule(168)</li> <li>• flsCx41Port10gModule(169)</li> <li>• fcx624SBaseModule(176)</li> <li>• fcx648SBaseModule(177)</li> <li>• fcx624SPoeBaseModule(180)</li> <li>• fcx648SPoeBaseModule(181)</li> <li>• fcxXfp2Port10gModule(184)</li> <li>• fcxCx42Port16gModule(185)</li> <li>• fcx624SFBaseModule(192)</li> <li>• fdryFcx624BaseModule(2208)</li> <li>• fdryFcx648BaseModule(2209)</li> <li>• fdryFcxSfpPlus4Port10gModule(2220)</li> <li>• fdryFws24PortCopperBaseModule(2224)</li> <li>• fdryFws48PortCopperBaseModule(2225)</li> <li>• fdryFws24GPortCopperBaseModule(2226)</li> <li>• fdryFws48GPortCopperBaseModule(2227)</li> <li>• fdrylxc6610624BaseModule(2240)</li> <li>• fdrylxc6610648BaseModule(2241)</li> <li>• fdrylxc6610624PoeBaseModule(2244)</li> <li>• fdrylxc6610648PoeBaseModule(2245)</li> <li>• fdrylxc6610624FBaseModule(2246)</li> <li>• fdrylxc6610DualMode8PortModule(2248)</li> <li>• fdrylxc6610Qsfp10Port160gModule(2249)</li> </ul>
snAgentConfigModule2RowStatus brcdIp.1.1.2.8.2.1.4 Syntax: Integer	Read-write	To create or delete a configured module table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>
snAgentConfigModule2Description brcdIp.1.1.2.8.2.1.5 Syntax: Integer	Read-only	A description of the configured module.
snAgentConfigModule2OperationalStatus brcdIp.1.1.2.8.2.1.6 Syntax: Integer	Read-only	The module operational status. A zero length string indicates that the physical module has not been inserted in the chassis.
snAgentConfigModule2SerialNumber brcdIp.1.1.2.8.2.1.7 Syntax: DisplayString	Read-only	The module serial number. A zero length string indicates that the module serial number EEPROM has not been programmed or the module does not support serial number EEPROM.
snAgentConfigModule2NumberOfPorts brcdIp.1.1.2.8.2.1.8 Syntax: Integer	Read-only	The number of ports on a module.

Name, OID, and syntax	Access	Description
snAgentConfigModule2MgmtModuleType brcdIp.1.1.2.8.2.1.9 Syntax: Integer	Read-only	The management module types: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• nonManagementModule(2)</li> <li>• unknownManagementModule(3)</li> <li>• m1ManagementModule(4)</li> <li>• m2ManagementModule(5)</li> <li>• m3ManagementModule(6)</li> <li>• m4ManagementModule(7)</li> <li>• m5ManagementModule(8)</li> <li>• jetcoreStackManagementModule(9)</li> <li>• muchoManagementModule(10)</li> <li>• rottweilerManagementModule(11)</li> <li>• fesXStackManagementModule(12)</li> <li>• fgsStackManagementModule(13)</li> </ul>
snAgentConfigModule2NumberOfCpus brcdIp.1.1.2.8.2.1.10 Syntax: Integer	Read-only	The number of CPUs on the module.

## Agent user access group

The agent user access group section presents the objects used to control user access to devices.

Name, OID, and syntax	Access	Description
snAgentUserMaxAccnt brcdIp.1.1.2.9.1.1 Syntax: Integer32	Read-only	Shows the maximum number of user accounts that can be configured on the device.

## Agent user account table

The objects in this table provide information about user accounts.

Name, OID, and syntax	Access	Description
snAgentUserAccntTable brcdIp.1.1.2.9.2	None	A table of user account information.
snAgentUserAccntName brcdIp.1.1.2.9.2.1.1 Syntax: DisplayString	Read-only	Displays the user name. This object can have up to 48 characters
snAgentUserAccntPassword brcdIp.1.1.2.9.2.1.2 Syntax: DisplayString	Read-write	Contains the user password. Valid values: Up to 48 characters
snAgentUserAccntEncryptCode brcdIp.1.1.2.9.2.1.3 Syntax: Integer32	Read-write	States the password encryption method code.

Name, OID, and syntax	Access	Description
snAgentUserAcctPrivilege brcdIp.1.1.2.9.2.1.4 Syntax: Integer32	Read-write	Shows the user privilege.
snAgentUserAcctRowStatus brcdIp.1.1.2.9.2.1.5 Syntax: Integer	Read-write	Creates, modifies, or deletes a user account table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> <li>• modify(5)</li> </ul>

## Agent redundant group

Use the following objects to manage redundant management groups.

### NOTE

The upgraded version of MP card MR2 supports all the objects in the Agent redundant group table. The MP-MR2 is supported only on the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices.

Name, OID, and syntax	Access	Description
snAgentRedunActiveMgmtMod brcdIp.1.1.2.10.1.1 Syntax: Integer32	Read-write	Shows the slot number of the active management module. Setting this object does not take effect immediately. You must save the configuration data to flash storage, then reboot the system before the new value takes effect. Setting a value of 0 requests the system to auto-select an active management module after power up. Default: 0
snAgentRedunSyncConfig brcdIp.1.1.2.10.1.2 Syntax: Integer32	Read-write	Shows how often the data in the active management module will be copied to the backup management module. The value for this object is in seconds. Setting this object to 0 disables the copy process. Setting it to a negative value starts the process immediately, but runs only once. Default: Every 10 seconds

Name, OID, and syntax	Access	Description
snAgentRedunBackupCopyBootCode brcdIp.1.1.2.10.1.3 Syntax: Integer	Read-write	If enabled, the backup management module copies the boot code of the active management module to its boot code flash storage after power up, and whenever the active management module's boot code is updated. The backup management module does not copy the boot code if it is identical to what is already in flash storage: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snAgentEnableMgmtModRedunStateChangeTrap brcdIp.1.1.2.10.1.4 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate management module redundancy state change traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)

Name, OID, and syntax	Access	Description
snAgentRedunBkupBootLoad brcdIp.1.1.2.10.1.5 Syntax: Integer	Read-write	Downloads a new boot code from boot flash storage of the active management module to the backup management module. In a set operation, enter the value downloadBackup(20) to download the boot code from the active management module to the backup management module. A set operation is rejected during a download until an error or normal state is reached. One of the following values is returned by a get operation: <ul style="list-style-type: none"> <li>normal(1) – No operation.</li> <li>operationError(17) – Error codes.</li> <li>downloadBackup(20) – Download boot code from active module to backup to the backup module.</li> </ul>
snAgentRedunSwitchOver brcdIp.1.1.2.10.1.6 Syntax: Integer	Read-write	Switches a backup management module to an active management module: <ul style="list-style-type: none"> <li>other(1)</li> <li>reset(2) – Resets the backup module to active.</li> </ul>

## System CPU utilization table

The objects in the following table are not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices. The objects are supported on the FastIron devices.

Name, OID, and syntax	Access	Description
snAgentCpuUtilTable brcdIp.1.1.2.11.1	None	The table to list utilization for all CPUs.
snAgentCpuUtilSlotNum brcdIp.1.1.2.11.1.1.1 Syntax: Integer32	Read-only	The slot number of the module that contains the CPU.
snAgentCpuUtilCpuId brcdIp.1.1.2.11.1.1.2 Syntax: Integer32	Read-only	The ID of the CPU: <ul style="list-style-type: none"> <li>For non-VM1/WSM management module, there is one CPU.</li> <li>For VM1/WSM, there is one management CPU and three slave CPUs. The management CPU could be turned off.</li> <li>For POS and ATM, there is no management CPU but two slave CPUs.</li> <li>The ID for the management CPU is 1. A value of 2 and greater identifies the slave CPUs.</li> </ul>
snAgentCpuUtilInterval brcdIp.1.1.2.11.1.1.3 Syntax: Integer32	Read-only	The value, in seconds, for this utilization. For both management and slave CPUs, utilizations for 1 sec, 5 sec, 60 sec, and 300 sec intervals are displayed.

Name, OID, and syntax	Access	Description
snAgentCpuUtilValue brcdIp.1.1.2.11.1.1.4 Syntax: Gauge32 <b>NOTE:</b> This object is not supported for Brocade NetIron XMR and Brocade MLX devices, FastIron GS, and FastIron SX. It is not supported on Brocade MLXe devices. Use the snAgentCpuUtilPercent and snAgentCpuUtil100thPercent objects instead.	Read-only	The statistical CPU utilization in units of one-hundredth of a percent.
snAgentCpuUtilPercent brcdIp.1.1.2.11.1.1.5 Syntax: Gauge32 <b>NOTE:</b> This is supported on Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices; FastIron GS and FastIron SX.	Read-only	The statistical CPU utilization in units of one percent.
snAgentCpuUtil100thPercent brcdIp.1.1.2.11.1.1.6 Syntax: Gauge32 <b>NOTE:</b> This is supported on Brocade NetIron XMR, Brocade MLXe, and Brocade MLX devices; FastIron GS and FastIron SX.	Read-only	The statistical CPU utilization in units of one-hundredth of a percent.

## System process utilization table

The following table lists CPU utilization and statistics for all CPU processes on the device. It is equivalent to the **show process cpu** command, which displays routing statistics for major protocols.



**NOTE**

The objects in the following table are not supported on the Brocade MLXe, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, Brocade NetIron CER series devices, and FastIron devices.

Name, OID, and syntax	Access	Description
snCpuProcessTable brcdIp.1.1.2.11.2	None	System process utilization table.
snCpuProcessName brcdIp.1.1.2.11.2.1.1 Syntax: DisplayString	Read-only	Name of the process.
snCpuProcess5SecUtil brcdIp.1.1.2.11.2.1.2 Syntax: Gauge	Read-only	Statistics collected during the last 5 seconds of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess1MinUtil brcdIp.1.1.2.11.2.1.3 Syntax: Gauge	Read-only	Statistics collected during the last 1 minute of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess5MinUtil brcdIp.1.1.2.11.2.1.4 Syntax: Gauge	Read-only	Statistics collected during the last 5 minutes of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess15MinUtil brcdIp.1.1.2.11.2.1.5 Syntax: Gauge	Read-only	Statistics collected during the last 15 minutes of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcessRuntime brcdIp.1.1.2.11.2.1.6 Syntax: Counter	Read-only	Process runtime in milliseconds.

## Hardware integrated central buffer manager counter table

The following table provides information for the Integrated Central Buffer Manager (ICBM).

**NOTE**

The objects in the following table are not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices, and FastIron devices.

Name, OID, and syntax	Access	Description
snAgentHwICBMCounterTable brcdIp.1.1.2.12.1	None	Table to list the ICBM counter values. This table is not supported on the 10G module.
snAgentHwICBMCounterSlot brcdIp.1.1.2.12.1.1.1 Syntax: Unsigned32	Read-only	The slot number where the ICBM resides.
snAgentHwICBMCounterDMA brcdIp.1.1.2.12.1.1.2 Syntax: Unsigned32	Read-only	DMA ID within a slot where the ICBM resides. This object is valid only for Jetcore modules. For non-Jetcore modules, this index is ignored by the agent. In this case, value 0 will be returned by the agent.

## 6 Agent System Parameters

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snAgentHwICBMCounterFreeDepth brcdIp.1.1.2.12.1.1.3 Syntax: Counter	Read-only	Current depth of the free queue for this ICBM.
snAgentHwICBMCounterWriteDrop brcdIp.1.1.2.12.1.1.4 Syntax: Counter	Read-only	Write sequencer drop count for this ICBM.
snAgentHwICBMCounterWriteInput brcdIp.1.1.2.12.1.1.5 Syntax: Counter	Read-only	Write sequencer input counter for this ICBM.
snAgentHwICBMCounterWriteOutput brcdIp.1.1.2.12.1.1.6 Syntax: Counter	Read-only	Write sequencer output counter for this ICBM.
snAgentHwICBMCounterReadInput brcdIp.1.1.2.12.1.1.7 Syntax: Counter	Read-only	Read sequencer input counter for this ICBM.
snAgentHwICBMCounterReadOutput brcdIp.1.1.2.12.1.1.8 Syntax: Counter	Read-only	Read sequencer output counter for this ICBM.

# Switch Group Configuration

## In this chapter

- [Switch group configuration](#) ..... 169

## Switch group configuration

The switch group configuration table is supported on the FastIron devices.

Name, OID, and syntax	Access	Description
snSwGroupOperMode brcdIp.1.1.3.1.1 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if switch ports have VLANs defined: <ul style="list-style-type: none"> <li>• noVlan(1) – All switch ports with no port VLANs and no tag assigned.</li> <li>• vlanByPort(2) – All switch ports with basic port-based VLANs.</li> </ul>
snSwGroupIpL3SwMode brcdIp.1.1.3.1.2 Syntax: Integer	Read-write	Indicates if the Layer 3 IP switch is enabled for the switch group: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwGroupIpMcastMode brcdIp.1.1.3.1.3 Syntax: Integer	Read-write	Indicates if the IP multicast pruning mode is enabled for the switch group: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwGroupDefaultCfgMode brcdIp.1.1.3.1.4 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if the switch group contains a default configuration. If the default configuration is overwritten, the state will change to non-default: <ul style="list-style-type: none"> <li>• default(1) – Has a default configuration.</li> <li>• nonDefault(2) – Has a non-default configuration.</li> </ul>

Name, OID, and syntax	Access	Description
snSwGroupSwitchAgeTime brcdIp.1.1.3.1.5 Syntax: Integer32	Read-write	Sets the aging period for ports on the device, defining how long a port address remains active in the address table. Valid values: 0 = no aging, or 67 – 65535 seconds Default: 300 seconds
snVlanGroupVlanCurEntry brcdIp.1.1.3.1.6 Syntax: Integer32	Read-only	Shows the number of VLANs that are currently configured.
snVlanGroupSetAllVlan brcdIp.1.1.3.1.7 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the VLAN index of a particular entry in snVlanByPortTable (snVlanByPortVlanIndex). All the attributes of the row except for PortMask will be used to set the same attributes for the entire VLAN group. VlanId and PortMask must be set for the particular entry prior to setting this object. Switch software will be based on this VLAN information to set the entire VLAN. <b>NOTE:</b> All the intended attributes of the given row of the table (given VLAN) must be set prior setting this object. When this object is set, Set-All-VLAN action takes place simultaneously. The previous setting is overwritten by the new one.
snSwPortSetAll brcdIp.1.1.3.1.8 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	The value of this object is the index number of the snSwPortInfoTable (snSwPortInfoPortIndex). The objects snSwPortInfoMonitorMode, snSwPortInfoTagType, snSwPortInfoChnMode, snSwPortInfoSpeed, snSwPortInfoAdminStatus are all the read-write attributes of that row of the table. They will be used to set the same attributes for all the ports in the system. <b>NOTE:</b> Before setting this object, all the intended attributes of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire port table. The previous setting will be overwritten by the new one.
snFdbTableCurEntry brcdIp.1.1.3.1.9 Syntax: Integer32	Read-only	Shows the total number of entries in the Filtering Database (FDB) that are configured currently.
snFdbTableStationFlush brcdIp.1.1.3.1.10 Syntax: Integer	Read-write	Shows the state of the flush operation for the FDB table. The following value can be written: <ul style="list-style-type: none"> <li>flush(3) – Perform the flush operation. After the flush operation starts, any new flush request is rejected until the operation is complete or failed.</li> </ul> The following values can only be read: <ul style="list-style-type: none"> <li>normal(1) – Normal state</li> <li>error(2) – Operation failed</li> <li>flushing(4) – Operation is in process</li> </ul>

Name, OID, and syntax	Access	Description
snPortStpSetAll brcdIp.1.1.3.1.11 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	The value of this object is 1, which means that Port STP <b>Set-all</b> command is invoked. The snPortStpPriority and snPortStpPathCost which are the read-write STP-related attributes of the first row of the table, will be used to set the same attributes for all the ports in the system. <b>NOTE:</b> Before setting this object, all the intended attributes of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire port table. The previous setting will be overwritten by the new one.
snSwProbePortNum brcdIp.1.1.3.1.12 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates which chassis port is assigned as the chassis switch probe port. That port operates as a traffic analyzer port. Only one port in the chassis or stackable switch can be assigned as the traffic analyzer port. The value of this object represents the following: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number</li> <li>• Bit 8 to bit 11 – Slot number</li> </ul>
snSw8021qTagMode brcdIp.1.1.3.1.13 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if IEEE802.1q has been enabled for the switch group: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snSwGlobalStpMode brcdIp.1.1.3.1.14 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates whether or not Spanning Tree System Global Mode has been enabled for the switch group: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

## 7 Switch Group Configuration

Name, OID, and syntax	Access	Description
snSwIpmcastQuerierMode brcdIp.1.1.3.1.15 Syntax: Integer	Read-write	The IP Multicast pruning mode is configured in either Non-Querier or Querier mode. <ul style="list-style-type: none"> <li>querier(1) – Send out host queries. (active)</li> <li>nonQuerier(2) – Do not send out host queries. (passive)</li> </ul> Default: querier(1)
snSwViolatorPortNumber brcdIp.1.1.3.1.17 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Indicates the port number of the switch or router that receives the violator packet. This number is included in the locked address violation trap. The value of this object contains the following: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number</li> <li>Bit 8 to bit 11 – Slot number (for chassis devices only)</li> </ul>
snSwViolatorMacAddress brcdIp.1.1.3.1.18 Syntax: MAC address	Read-only	Indicates the source MAC address of the violator packet received by the switch or router. This number is included in the locked address violation trap.
snVlanGroupVlanMaxEntry brcdIp.1.1.3.1.19 Syntax: Integer32	Read-write	Shows the maximum number of VLAN entries that can be configured. <b>NOTE:</b> This object is read-only on the Brocade NetIron devices. The SET request returns the error as not writable. Use the snAgentSysParaConfigEntry object, to set the maximum allowed VLAN.
snSwEosBufferSize brcdIp.1.1.3.1.20 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies buffer size for all the different EOS buffers.
snVlanByPortEntrySize brcdIp.1.1.3.1.21 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the size of each VLAN table entry.

Name, OID, and syntax	Access	Description
snSwPortEntrySize brcdIp.1.1.3.1.22 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the size of each port table entry.
snFdbStationEntrySize brcdIp.1.1.3.1.23 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the size of each FDB station table entry.
snPortStpEntrySize brcdIp.1.1.3.1.24 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the size of each port STP table entry.
snSwEnableBridgeNewRootTrap brcdIp.1.1.3.1.25 Syntax: Integer	Read-write	Indicates whether the SNMP agent process is permitted to generate bridge new root traps.
snSwEnableBridgeTopologyChangeTrap brcdIp.1.1.3.1.26 Syntax: Integer	Read-write	Indicates whether the SNMP agent process is permitted to generate bridge topology change traps.
snSwEnableLockedAddressViolationTrap brcdIp.1.1.3.1.27 Syntax: Integer	Read-write	Indicates whether the SNMP agent process is permitted to generate locked address violation traps.

Name, OID, and syntax	Access	Description
snSwIpxL3SwMode brcdIp.1.1.3.1.28 Syntax: Integer	Read-write	Indicates whether or not Layer 3 IPX switch mode is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snVlanByIpxSubnetMaxSubnets brcdIp.1.1.3.1.29 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of subnets for each IP VLAN.
snVlanByIpxNetMaxNetworks brcdIp.1.1.3.1.30 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of networks for each IPX VLAN.
snSwProtocolVlanMode brcdIp.1.1.3.1.31 Syntax: Integer	Read-write	Indicates whether or not protocol VLAN is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snMacStationVlanId brcdIp.1.1.3.1.32 Syntax: Integer	Read-write	Shows the MAC Station's VLAN ID index in the standard Forwarding Database for Transparent Bridge Table (dot1dTpFdbTable). Because the dot1dTpFdbTable index is the MAC address assigned to one of the ports in the bridge (VLAN) and each MAC address can be re-assigned to different ports belonging to different bridges (VLANs), the snMacStationVlanId can be used to specify which bridge (VLAN) MAC Station information of the dot1dTpFdbTable to retrieve. If you do not specify the VLAN ID in this MIB, the default VLAN (bridge) ID will be used when dot1dTpFdbTable is retrieved. Valid values: 1 – 4095
snSwClearCounters brcdIp.1.1.3.1.33 Syntax: Integer	Read-write	Clears software counters: <ul style="list-style-type: none"> <li>valid(0) – An SNMP-GET of this MIB shows that it is a valid command to use.</li> <li>clear(1) – Clear counter commands of the following counters: Dot3, MIB2, IP, and IPX counters for all ports.</li> </ul>



Name, OID, and syntax	Access	Description
snSw8021qTagType brcdIp.1.1.3.1.34 Syntax: Integer32	Read-write	Specifies the IEEE802.1q tag type that is embedded in the length or type field of an Ethernet packet. It specifies that the two octets after the length or type field in an Ethernet packet are the tag value. Default: 33024
snSwBroadcastLimit brcdIp.1.1.3.1.35 Syntax: Integer32	Read-write	Specifies the number of broadcast packets per second. This limits the number of broadcast packets to forward out of the switch ports. Setting this object to 0 disables the limitation check. Default: 0
snSwMaxMacFilterPerSystem brcdIp.1.1.3.1.36 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the maximum number of MAC filters per system in the MAC filter table.
snSwMaxMacFilterPerPort brcdIp.1.1.3.1.37 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Specifies the maximum number of MAC filters per port in the port MAC access filter table.
snSwDefaultVlanId brcdIp.1.1.3.1.38 Syntax: Integer	Read-write	Shows the VLAN ID of the default port VLAN. Valid values: 1 – 4095
snSwGlobalAutoNegotiate brcdIp.1.1.3.1.39 Syntax: Integer	Read-write	Applies only to Gigabit Ethernet ports. Specifies the negotiation mode of the port: <ul style="list-style-type: none"> <li>• disable(0) – All Gigabit Ethernet ports are in non negotiation mode.</li> <li>• enable(1) – All Gigabit Ethernet ports will start auto-negotiation indefinitely until they succeed.</li> <li>• negFullAuto(2) – All Gigabit Ethernet ports will start with auto-negotiation. If the negotiation fails, then they will automatically switch to non-negotiation mode. Gigabit Ethernet ports on all stackable products except for Turbolron/8 do not support negFullAuto(2).</li> <li>• other(3)</li> </ul> Default: negFullAuto(2)

## 7 Switch Group Configuration

Name, OID, and syntax	Access	Description
snSwQosMechanism brcdIp.1.1.3.1.40 Syntax: Integer	Read-write	Specifies the Quality of Service (QoS) mechanism: <ul style="list-style-type: none"> <li>• strict(0)</li> <li>• weighted(1)</li> </ul> Default: weighted(1)
snSwSingleStpMode brcdIp.1.1.3.1.41 Syntax: Integer	Read-write	Indicates if the Single Spanning Tree System Mode in the Switch Group is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snSwFastStpMode brcdIp.1.1.3.1.42 Syntax: Integer	Read-write	Indicates if Fast Spanning Tree System Mode in the Switch Group is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwViolatorIfIndex brcdIp.1.1.3.1.43 Syntax: Integer32	Read-only	The port number of the device that received a violator packet. This number is included in the locked address violator trap.
snSwSingleStpVlanId brcdIp.1.1.3.1.44 Syntax: Integer32	Read-only	The VLAN ID of the Single Spanning Tree VLAN if Single Spanning Tree was enabled. This object returns zero if Single Spanning Tree was disabled.

# Switch Port Information Group

## In this chapter

- [Switch port information. . . . .](#) 177

## Switch port information

The following table contains information about the switch port groups.

The snSwfInfoTable, which is indexed by ifIndex port format, replaces the snSwPortInfoTable, which is indexed by a proprietary port format.

### NOTE

The objects snSwfStatsInFrames through snSwfStatsOutKiloBitsPerSec use common application programming interface (API) for LP port statistics.

Name, OID, and syntax	Access	Description
snSwfInfoTable brcdIp.1.1.3.3.5	None	The switch port information table.
snSwfInfoPortNum brcdIp.1.1.3.3.5.1.1 Syntax: InterfaceIndex	Read-only	Shows the port or interface index.
snSwfInfoMonitorMode brcdIp.1.1.3.3.5.1.2 Syntax: Integer	Read-write	Indicates the method used to monitor traffic on a port: <ul style="list-style-type: none"> <li>disabled(0) – No traffic monitoring.</li> <li>input(1) – Traffic monitoring is activated on packets received.</li> <li>output(2) – Traffic monitoring is activated on packets transmitted.</li> <li>both(3) – Traffic monitoring is activated on packets received and transmitted.</li> </ul> Default: disabled(0) This object is replaced by snSwf2MirrorMode and snPortMonitorTable.
snSwfInfoMirrorPorts brcdIp.1.1.3.3.5.1.3 Syntax: Integer	Read-write	Contains a list of port or interface indexes (ifindex) that mirror this interface when monitoring is enabled.
snSwfInfoTagMode brcdIp.1.1.3.3.5.1.4 Syntax: Integer	Read-write	Indicates if the port has an 802.1q tag: <ul style="list-style-type: none"> <li>tagged(1) – Ports can have multiple VLAN IDs because these ports can be members of more than one VLAN.</li> <li>untagged(2) – There is only one VLAN ID per port.</li> <li>dual(3) - Dual mode is associated with a VLAN ID snSwfVlanId; dual mode with snSwfVlanId zero disables the dual mode.</li> </ul>

Name, OID, and syntax	Access	Description
snSwlInfoTagType brcdIp.1.1.3.3.5.1.5 Syntax: Integer32	Read-write	Indicates the IEEE802.1q tag type of an interface. The tag type is embedded in the two octets in the length or type field of an Ethernet packet. It specifies that the two octets after the length or type field in an Ethernet packet is the tag value. Default value: 33024
snSwlInfoChnMode brcdIp.1.1.3.3.5.1.6 Syntax: Integer	Read-write	Indicates if the port operates in half- or full-duplex mode: <ul style="list-style-type: none"> <li>• none(0) – This is not used.</li> <li>• halfDuplex(1) – Half-duplex mode. Available only for 10/100 Mbps ports.</li> <li>• fullDuplex(2) – Full-duplex mode. 100BaseFx, 1000BaseSx, and 1000BaseLx ports operate only at fullDuplex(2).</li> </ul> The read-back channel status from hardware are as follows: <ul style="list-style-type: none"> <li>• halfDuplex(1) – Half-duplex mode.</li> <li>• fullDuplex(2) – Full-duplex mode.</li> </ul> The port media type (expansion or regular) and port link type (trunk or feeder) determine the value of this object. The port cannot be set to half-duplex mode if the port connect mode is m200e(4). However, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of a cascade-connecting device.
snSwlInfoSpeed brcdIp.1.1.3.3.5.1.7 Syntax: Integer	Read-write	Indicates the speed configuration for a port: <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• sAutoSense(1) – Auto-sensing 10 or 100 Mbits.</li> <li>• s10M(2) – 10 Mbits per second.</li> <li>• s100M(3) – 100 Mbits per second.</li> <li>• s1G(4) – 1 Gbits per second.</li> <li>• s1GM(5) – 1 Gbits per second master.</li> <li>• s155M(6) – 155 Mbits per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10 Gbits per second.</li> <li>• s622M(8) – OC12 - 622 Mbits per second. (Brocade NetIron XMR, Brocade MLX, and Brocade MLXe router.)</li> <li>• s2488M(9) – OC48 - 2.488 Gbits per second. (Brocade NetIron XMR, Brocade MLX, and Brocade MLXe router.)</li> <li>• s9953M(10) – OC192 - 9.953 Gbits per second. (Brocade NetIron XMR router, Brocade MLX router, and Brocade MLXe router.)</li> <li>• s16G(11) - 16 Gbits per second.</li> <li>• s100G(12) - 100 Gbits per second.</li> <li>• s40G(13) - 40 Gbits per second.</li> </ul> The read-back hardware status are the following: <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• s10M(2) – 10 Mbits per second.</li> <li>• s100M(3) – 100 Mbits per second.</li> <li>• s1G(4) – 1G bits per second.</li> <li>• s1GM(5) - 1G bits per second master.</li> <li>• s155M(6) – 155 Mbits per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10 Gbits per second.</li> </ul>

Name, OID, and syntax	Access	Description
snSwifInfoSpeed (continued)		<ul style="list-style-type: none"> <li>s622M(8) – OC12 - 622 Mbits per second. (Brocade NetIron XMR router, Brocade MLX router, and Brocade MLXe router)</li> <li>s2488M(9) – OC48 - 2.488 Gbits per second. (Brocade NetIron XMR router, Brocade MLX router, and Brocade MLXe router)</li> <li>s9953M(10) – OC192 - 9.953 Gbits per second. (Brocade NetIron XMR router, Brocade MLX router, and Brocade MLXe router)</li> <li>s16G(11) - 16 Gbits per second.</li> <li>s40G(13) - 40 Gbits per second.</li> </ul> <p>The port media type (expansion or regular) and port link type (trunk or feeder) determine whether this object can be written and the valid values for this object. It is not allowed to change speed for trunk ports. For expansion ports, all of the above speeds can be set; however, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of a cascade-connecting device.</p>
snSwifInfoMediaType brcdIp.1.1.3.3.5.1.8 Syntax: Integer	Read-only	<p>Shows the media type for the port:</p> <ul style="list-style-type: none"> <li>other(1) – Other or unknown media.</li> <li>m100BaseTX(2) – 100 Mbits per second copper.</li> <li>m100BaseFX(3) – 100 Mbits per second fiber.</li> <li>m1000BaseFX(4) – 1 Gbits per second fiber.</li> <li>mT3(5) – 45 Mbits per second (T3).</li> <li>m155ATM(6) – 155 Mbits per second (ATM).</li> <li>m1000BaseTX(7) – 1 Gbits per second copper.</li> <li>m622ATM(8) – 622 Mbits per second (ATM).</li> <li>m155POS(9) – 155 Mbits per second (POS).</li> <li>m622POS(10) – 622 Mbits per second (POS).</li> <li>m2488POS(11) – 2488 Mbits per second (POS).</li> <li>m10000BaseFX(12) – 10 Gbits per second fiber.</li> <li>m9953POS(13) – 9953 Mbits per second (POS). (Brocade NetIron XMR router, Brocade MLX router, and Brocade MLXe router)</li> <li>m16GStacking(14) - 16 Gbits per second fiber.</li> <li>m100GBaseFX(15) - 100 Gbits per second fiber.</li> <li>m40GStacking(16) - 40 Gbits per second fiber.</li> </ul>
snSwifInfoConnectorType brcdIp.1.1.3.3.5.1.9 Syntax: Integer	Read-only	<p>Shows the type of connector that the port offers:</p> <ul style="list-style-type: none"> <li>other(1) – Other or unknown connector.</li> <li>copper(2) – Copper connector.</li> <li>fiber(3) – Fiber connector. This describes the physical connector type.</li> </ul>
snSwifInfoAdminStatus brcdIp.1.1.3.3.5.1.10 Syntax: Integer	Read-write	<p>Shows the desired state of all ports:</p> <ul style="list-style-type: none"> <li>up(1) – Ready to pass packets</li> <li>down(2)</li> <li>testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>
snSwifInfoLinkStatus brcdIp.1.1.3.3.5.1.11 Syntax: Integer	Read-only	<p>Shows the current operational state of the interface:</p> <ul style="list-style-type: none"> <li>up(1) – Ready to pass packets</li> <li>down(2)</li> <li>testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>

Name, OID, and syntax	Access	Description
snSwlInfoPortQos brcdIp.1.1.3.3.5.1.12 Syntax: Integer	Read-write	Indicates the Quality of Service (QoS) level selected for the port: <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>
snSwlInfoPhysAddress brcdIp.1.1.3.3.5.1.13 Syntax: Physical address	Read-only	Shows the physical address of the port.
snSwlLockAddressCount brcdIp.1.1.3.3.5.1.14 Syntax: Integer	Read-write	Indicates the number of source MAC addresses that are allowed on the interface. Valid values: 0 – 2048. The value 0 means an unlimited number of addresses are allowed. Default: 8
snSwlStpPortEnable brcdIp.1.1.3.3.5.1.15 Syntax: Integer	Read-write	Indicates if STP is enabled for the port: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snSwlDhcpGateListId brcdIp.1.1.3.3.5.1.16 Syntax: Integer	Read-write	Specifies the ID for a DHCP gateway list entry relative to this switch port. Valid values: 0 – 32. A value of 0 means that the ID is unassigned.
snSwlName brcdIp.1.1.3.3.5.1.17 Syntax: Display string	Read-write	Indicates the port name or description. This description may have been entered using the CLI. Valid values: Up to 32 characters for most devices. Up to 255 characters for Brocade MLXe router devices and other Brocade NetIron devices.
snSwlDescr brcdIp.1.1.3.3.5.1.18 Syntax: Display string	Read-only	A textual string containing the slot or port information about the interface.
snSwlInfoAutoNegotiate brcdIp.1.1.3.3.5.1.19 Syntax: Integer	Read-write	Applies only to Gigabit Ethernet ports. Indicates if auto-negotiation mode is enabled on the port: <ul style="list-style-type: none"> <li>disabled(0) – The port will be placed in non-negotiation mode.</li> <li>enabled(1) – The port will start auto-negotiation indefinitely until it succeeds.</li> <li>negFullAuto(2) – The port will start with auto-negotiation. If the negotiation fails, then it will automatically switch to non-negotiation mode. This option is not supported in stackable products with Gigabit Ethernet ports, except for Turbolron/8.</li> <li>global(3) – The port negotiation mode follows the value of snSwGlobalAutoNegotiate.</li> <li>other(4) – Non-Gigabit Ethernet port returns this value.</li> </ul> Default: global(3)
snSwlInfoFlowControl brcdIp.1.1.3.3.5.1.20 Syntax: Integer	Read-write	Indicates if port flow control is enabled: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul> Default: enabled(1)

Name, OID, and syntax	Access	Description
snSwIfInfoGigType brcdIp.1.1.3.3.5.1.21 Syntax: Integer	Read-only	<p>Applies only to Gigabit Ethernet ports.</p> <p>Shows the media type for the port:</p> <ul style="list-style-type: none"> <li>• m1000BaseSX(0) – 1-Gbps fiber, with a short wavelength transceiver</li> <li>• m1000BaseLX(1) – 1-Gbps fiber, with a long wavelength transceiver (3 km)</li> <li>• m1000BaseLH(2) – 1-Gbps fiber, with a special wavelength transceiver (50 km)</li> <li>• m1000BaseLHB(4) – 1-Gbps fiber, with a special wavelength transceiver (150 km)</li> <li>• m1000BaseTX(5) – 1-Gbps copper (100 m)</li> <li>• m10000BaseSR(6) – 10-Gbps fiber, with a short range wavelength transceiver (100 m)</li> <li>• m10000BaseLR(7) – 10-Gbps fiber, with a long range wavelength transceiver (10 km)</li> <li>• m10000BaseER(8) – 10-Gbps fiber, with a extended range wavelength transceiver (40 km)</li> <li>• sfpCWDM1470nm80Km(9) - 1-Gbps CWDM fiber, with a wavelength 1470nm, reach 80 kms</li> <li>• sfpCWDM1490nm80Km(10) - 1-Gbps CWDM fiber, with a wavelength 1490nm, reach 80 kms</li> <li>• sfpCWDM1510nm80Km(11) - 1-Gbps CWDM fiber, with a wavelength 1510nm, reach 80 kms</li> <li>• sfpCWDM1530nm80Km(12) - 1-Gbps CWDM fiber, with a wavelength 1530nm, reach 80 kms</li> <li>• sfpCWDM1550nm80Km(13) - 1-Gbps CWDM fiber, with a wavelength 1550nm, reach 80 kms</li> <li>• sfpCWDM1570nm80Km(14) - 1-Gbps CWDM fiber, with a wavelength 1570nm, reach 80 kms</li> <li>• sfpCWDM1590nm80Km(15) - 1-Gbps CWDM fiber, with a wavelength 1590nm, reach 80 kms</li> <li>• sfpCWDM1610nm80Km(16) - 1-Gbps CWDM fiber, with a wavelength 1610nm, reach 80 kms</li> <li>• sfpCWDM1470nm100Km(17) - 1-Gbps CWDM fiber, with a wavelength 1470nm, reach 100 kms</li> <li>• sfpCWDM1490nm100Km(18) - 1-Gbps CWDM fiber, with a wavelength 1490nm, reach 100 kms</li> <li>• sfpCWDM1510nm100Km(19) - 1-Gbps CWDM fiber, with a wavelength 1510nm, reach 100 kms</li> <li>• sfpCWDM1530nm100Km(20) - 1-Gbps CWDM fiber, with a wavelength 1530nm, reach 100 kms</li> <li>• sfpCWDM1550nm100Km(21) - 1-Gbps CWDM fiber, with a wavelength 1550nm, reach 100 kms</li> <li>• sfpCWDM1570nm100Km(22) - 1-Gbps CWDM fiber, with a wavelength 1570nm, reach 100 kms</li> <li>• sfpCWDM1590nm100Km(23) - 1-Gbps CWDM fiber, with a wavelength 1590nm, reach 100 kms</li> </ul>

Name, OID, and syntax	Access	Description
snSwIfInfoGigType (continued)		<ul style="list-style-type: none"> <li>• sfpCWDM1610nm100Km(24) - 1Gbps CWDM fiber, with a wavelength 1610nm, reach 100 kms</li> <li>• m1000BaseLHX(25) - 1Gbps fiber, with a special wavelength transceiver (150km)</li> <li>• m1000BaseLMC(35) - Link Media Copper</li> <li>• mXFP10000BaseSR(36) - 10GBASE fiber, 850nm serial pluggable XFP optic (LC), target range 300m over MMF</li> <li>• mXFP10000BaseLR(37) - 10GBASE fiber, 1310nm serial pluggable XFP optic (LC) for up to 10km over SMF</li> <li>• mXFP10000BaseER(38) - 10GBASE fiber, 1550nm serial pluggable XFP optic (LC) for up to 40km over SMF</li> <li>• mXFP10000BaseSW(39) - not used</li> <li>• mXFP10000BaseLW(40) - not used</li> <li>• mXFP10000BaseEW(41) - not used</li> <li>• mXFP10000BaseCX4(42) - 10GBASE-CX4, XFP module, 15m, CX4 connector</li> <li>• mXFP10000BaseZR(43) - 1550nm serial pluggable XFP optic (LC) for up to 80km over SMF</li> <li>• mXFP10000BaseZRD(44) - 10GBASE-ZR DWDM, XFP optic, 80km</li> <li>• mXFP10000BaseSRSW(46) - same as mXFP10000BaseSR(36)</li> <li>• mXFP10000BaseLRLW(47) - same as mXFP10000BaseLR(37)</li> <li>• mXFP10000BaseEREW(48) - same as mXFP10000BaseER(38)</li> <li>• mCFP100GBaseSR10(145) - 100GbE CFP optic (MPO 2x12), SR10, for distances up to 100m over MMF</li> <li>• mCFP100GBaseLR4(146) - 100GbE CFP optic (SC), LR4, for distances up to 10 km over SMF</li> <li>• mCFP100GBaseER4(147) - 100GbE CFP optic, ER4, for distances up to 40 km over SMF</li> <li>• mCFP100GBase10x10g2Km(148) - 100GbE CFP optic (LC), 10x10, for distances up to 2 km over SMF</li> <li>• mCFP100GBase10x10g10Km(149) - 100GbE CFP optic (LC), 10x10, for distances up to 10 km over SMF</li> <li>• notApplicable(255) - a non-gigabit port</li> </ul>
snSwIfFastSpanPortEnable brcdIp.1.1.3.3.5.1.22 Syntax: Integer	Read-write	<p>Indicates if fast span is enabled on the port:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwIfFastSpanUplinkEnable brcdIp.1.1.3.3.5.1.23 Syntax: Integer	Read-write	<p>Indicates if fast span uplink is enabled on the port:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwIfVlanId brcdIp.1.1.3.3.5.1.24 Syntax: Integer	Read-only	<p>Shows the ID of a VLAN of which this port is a member. Port must be untagged.</p> <p>Valid values: 0 – 4095; where 0 means an invalid VLAN ID value, which is returned for tagged ports. Reading is valid only for untagged and dual mode. Writing is valid for only dual mode.</p>



Name, OID, and syntax	Access	Description
snSwIfRouteOnly brcdIp.1.1.3.3.5.1.25 Syntax: Integer	Read-write	Indicates if Layer 2 switching is enabled on a routing switch port: <ul style="list-style-type: none"> <li>disabled(0) – Instructs the routing switch to perform routing first. If that fails, it performs switching.</li> <li>enabled(1) – Instructs the routing switch to perform routing only.</li> </ul> For a Layer 2 switching-only product, reading this object always returns "disabled". Writing "enabled" to this object takes no effect. Default: disabled(0)
snSwIfPresent brcdIp.1.1.3.3.5.1.26 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, and FastIron devices.	Read-only	Indicates if the mini-GBIC optic is absent or present: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snSwIfGBICStatus brcdIp.1.1.3.3.5.1.27 Syntax: Integer	Read-only	Indicates if the Gigabit port has a GBIC or miniGBIC port: <ul style="list-style-type: none"> <li>GBIC(1) – GBIC</li> <li>miniGBIC(2) – MiniGBIC</li> <li>empty(3) – GBIC is missing</li> <li>other(4) – Not a removable Gigabit port</li> </ul>
snSwIfLoadInterval brcdIp.1.1.3.3.5.1.28 Syntax: Integer	Read-write	Shows the number of seconds for which average port utilization should be calculated. Valid values: 30 – 300, in 30 second increments. Default: 300 seconds
snSwIfStatsInFrames brcdIp.1.1.3.3.5.1.29 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLX series, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of packets received on the interface.
snSwIfStatsOutFrames brcdIp.1.1.3.3.5.1.30 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of packets transmitted out of the interface.

Name, OID, and syntax	Access	Description
snSwlfStatsAlignErrors brcdIp.1.1.3.3.5.1.31 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of dot3StatsAlignmentErrors, which consists of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtained, are counted exclusively according to the error status presented to the LLC.
snSwlfStatsFCSErrors brcdIp.1.1.3.3.5.1.32 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of dot3StatsFCSErrors, which consists of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check. The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtained, are counted exclusively according to the error status presented to the LLC.
snSwlfStatsMultiColliFrames brcdIp.1.1.3.3.5.1.33 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of dot3StatsMultipleCollisionFrames, which consists of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. A frame that is counted by an instance of this object is also counted by the corresponding instance of ifOutUcastPkts, ifOutMulticastPkts, or ifOutBroadcastPkts and is not counted by the corresponding instance of the dot3StatsSingleCollisionFrames object.
snSwlfStatsTxColliFrames brcdIp.1.1.3.3.5.1.34 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. This count is a combination of the dot3StatsSingleCollisionFrames and dot3StatsMultipleCollisionFrames objects.

Name, OID, and syntax	Access	Description
snSwIfStatsRxCollisFrames brcdIp.1.1.3.3.5.1.35 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of successfully received frames on a particular interface for which transmission is inhibited by more than one collision.
snSwIfStatsFrameTooLongs brcdIp.1.1.3.3.5.1.36 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of dot3StatsFrameTooLongs, which consists of frames received on a particular interface that exceed the maximum permitted frame size.  The count represented by an instance of this object is incremented when the frameTooLong status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtained are counted exclusively according to the error status presented to the LLC.
snSwIfStatsFrameTooShorts brcdIp.1.1.3.3.5.1.37 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number frames received on a particular interface that are below the minimum permitted frame size.
snSwIfStatsInBcastFrames brcdIp.1.1.3.3.5.1.38 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-write	Shows the total number of broadcast packets received on the interface.

Name, OID, and syntax	Access	Description
snSwIfStatsOutBcastFrames brcdIp.1.1.3.3.5.1.39 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of broadcast packets transmitted out of the interface.
snSwIfStatsInMcastFrames brcdIp.1.1.3.3.5.1.40 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of multicast packets received on the interface.
snSwIfStatsOutMcastFrames brcdIp.1.1.3.3.5.1.41 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of multicast packets transmitted out of the interface.
snSwIfStatsInDiscard brcdIp.1.1.3.3.5.1.42 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of inbound packets that will be discarded even though they have no errors. These packets will be discarded to prevent them from being delivered to a higher-layer protocol. For example, packets may be discarded to free up buffer space.

Name, OID, and syntax	Access	Description
snSwifStatsOutDiscard brcdIp.1.1.3.3.5.1.43 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of outbound packets that will be discarded even though they contain no errors. For example, packets may be discarded to free up buffer space.
snSwifStatsMacStations brcdIp.1.1.3.3.5.1.44 Syntax: Integer32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of MAC Stations connected to the interface.
snSwifStatsLinkChange brcdIp.1.1.3.3.5.1.45 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of link state changes on the interface.
snSwifInOctets brcdIp.1.1.3.3.5.1.46 Syntax: Counter64 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of octets received on the interface, including framing characters. This object is a 64-bit counter of the ifInOctets object defined in RFC 1213. The octet string is in big-endian byte order. This object has eight octets.

Name, OID, and syntax	Access	Description
snSwifOutOctets brcdIp.1.1.3.3.5.1.47 Syntax: Counter64 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the total number of octets transmitted out of the interface, including framing characters. This object is a 64-bit counter of the ifOutOctets object, defined in RFC 1213. The octet string is in big-endian byte order. This object has eight octets.
snSwifStatsInBitsPerSec brcdIp.1.1.3.3.5.1.48 Syntax: Gauge32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of bits per second received on the interface over a five-minute interval.
snSwifStatsOutBitsPerSec brcdIp.1.1.3.3.5.1.49 Syntax: Gauge32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of bits per second transmitted out of the interface over a five-minute interval.
snSwifStatsInPktsPerSec brcdIp.1.1.3.3.5.1.50 Syntax: Gauge32 <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-only	Shows the number of packets per second received on the interface over a five-minute interval.

Name, OID, and syntax	Access	Description
snSwifStatsOutPktsPerSec brcdIp.1.1.3.3.5.1.51 Syntax: Gauge32	Read-only	Shows the number of packets per second transmitted out of the interface over a five-minute interval.
<p><b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.</p>		
snSwifStatsInUtilization brcdIp.1.1.3.3.5.1.52 Syntax: Integer	Read-only	Identifies the input network utilization in hundredths of a percent over a five-minute interval. Valid values: 0 – 10000
<p><b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.</p>		
snSwifStatsOutUtilization brcdIp.1.1.3.3.5.1.53 Syntax: Integer	Read-only	Shows the output network utilization in hundredths of a percent over a five-minute interval. Valid values: 0 – 10000
<p><b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.</p>		
<p><b>NOTE:</b> Ethernet devices must allow a minimum idle period between transmission of frames known as interframe gap (IFG) or interpacket gap (IPG). The gap provides a brief recovery time between frames to allow devices to prepare to receive the next frame. The minimum IFG is 96 bit times, which is 9.6 microseconds for 10 Mbps Ethernet, 960 nanoseconds for 100 Mbps Ethernet, and 96 nanoseconds for 1 Gbps Ethernet. In addition, to account for the bit rate on the port, port utilization should also account for the IFG, which normally is filtered by the packet synchronization circuitry.</p>		

Refer to the etherHistoryUtilization objects in the *RFC 1757: Remote Network Monitoring Management Information Base* for details.

Name, OID, and syntax	Access	Description
snSwifStatsInKiloBitsPerSec brcdIp.1.1.3.3.5.1.54 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, received on a 10 Gigabit or faster interface within a five-minute interval.
<b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.		
snSwifStatsOutKiloBitsPerSec brcdIp.1.1.3.3.5.1.55 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, transmitted from a 10 Gigabit or faster interface within a five-minute interval.
<b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.		
snSwifStatsInJumboFrames brcdIp.1.1.3.3.5.1.56 Syntax: Counter64	Read-only	The total number of jumbo packets received on the interface. This always returns 0 when applied to Brocade MLXe router, Brocade NetIron XMR, and Brocade MLX devices.
snSwifStatsOutJumboFrames brcdIp.1.1.3.3.5.1.57 Syntax: Counter64	Read-only	The total number of jumbo packets transmitted out of the interface. This always returns 0 when applied to Brocade MLXe router, Brocade NetIron XMR, and Brocade MLX devices.
snSwifSInfoMirrorMode brcdIp.1.1.3.3.5.1.58 Syntax: Integer	Read-only	Provides the mirror mode status as described: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul>
snSwifMacLearningDisable brcdIp.1.1.3.3.5.1.59 Syntax: TruthVal	Read-write	Displays the status of MAC learning on an Ethernet port. For POS ports, a Get operation will return the default value and a Set operation will return an error.



# Interface ID Registration Group

---

## In this chapter

- [Interface ID to ifIndex lookup table](#) ..... 191
- [ifIndex to interface ID lookup table](#) ..... 192
- [Interface ID2 to ifIndex lookup table](#) ..... 193
- [ifIndex to interface ID2 lookup table](#) ..... 194
- [ifIndex to optical parameters table](#) ..... 195
- [Optical lane monitoring table](#) ..... 196
- [Interface media information table](#) ..... 197
- [Loopback interface configuration table](#) ..... 197

The new MP card MR2 supports all the table objects in snInterfaceLookupTable, snIfIndexLookupTable, snInterfaceLookup2Table, and snIfIndexLookup2Table. The MP-MR2 is supported only on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices.

## Interface ID to ifIndex lookup table

Given an interface ID, the interface ID to ifIndex lookup table returns the ifIndex value. The table is useful for mapping a known interface to the corresponding ifIndex value. The contents of the interface ID to ifIndex lookup table can only be accessed using GET operations. Unlike other SNMP tables, this table does not support GET-NEXT operations. If you try to walk the table using GET-NEXT, no rows will be returned.

Name, OID, and syntax	Access	Description
snInterfaceLookupTable brcdIp.1.1.3.3.3	None	The Interface ID to ifIndex lookup table.
snInterfaceLookupInterfaceId brcdIp.1.1.3.3.3.1.1 Syntax: InterfaceId	Read-only	Shows the interface ID, which consists of the following: <b>Octet 0</b> – Port type, which can be one of the following: <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> </ul> These values applies to Brocade NetIron XMR, Brocade MLX, and to Brocade MLXe router devices. <ul style="list-style-type: none"> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> </ul>

Name, OID, and syntax	Access	Description
snInterfaceLookupInterfaceId (continued)		<ul style="list-style-type: none"> <li>9 – ATM PVC</li> <li>10 – Management</li> <li>11 – Trunk</li> <li>12 – IP Tunnel (for IP tunnels, except MPLS)</li> </ul> <p>This value also applies to 6 - 4 tunnels in the Brocade NetIron XMR, Brocade MLX, and to Brocade MLXe router devices.</p> <p><b>Octet 1</b></p> <ul style="list-style-type: none"> <li>If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the slot number of the device.</li> <li>If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <p><b>Octet 2</b> – If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the port number.</p> <p><b>Octet 3</b> – If the value of Octet 0 is 7 or 9, then this octet shows the ATM Subif number.</p> <p><b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number.</p> <p><b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.</p>
snInterfaceLookupIfIndex brcdIp.1.1.3.3.3.1.2 Syntax: Integer32	Read-only	Shows the interface in the ifIndex format.

## ifIndex to interface ID lookup table

The ifIndex to interface ID lookup table maps ifindex values to the interface ID lookup table. If the table provides an ifIndex, this table returns the interface ID value.

Name, OID, and syntax	Access	Description
snIfIndexLookupTable brcdIp.1.1.3.3.4	None	The ifIndex to interface ID lookup table.
snIfIndexLookupIfIndex brcdIp.1.1.3.3.4.1.1 Syntax: Integer32	Read-only	Shows the interface in the ifIndex format.

Name, OID, and syntax	Access	Description
snIfIndexLookupInterfaceId brcdIp.1.1.3.3.4.1.2 Syntax: InterfaceId	Read-only	<p>Shows the interface ID, which consists of the following:</p> <p><b>Octet 0</b> – Port type, which can be one of the following:</p> <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> <li>• 9 – ATM PVC</li> <li>• 10 – Management</li> <li>• 11 – Trunk</li> <li>• 12 – IP Tunnel (for IP tunnels, except MPLS)</li> </ul> <p>This value also applies to 6 - 4 tunnels in the Brocade NetIron devices,</p> <p><b>Octet 1</b></p> <ul style="list-style-type: none"> <li>• If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the slot number of the device.</li> <li>• If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>• If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>• If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <p><b>Octet 2</b> – If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the port number.</p> <p><b>Octet 3</b> – If the value of Octet 0 is 7 or 9, then this octet shows the ATM Subif number).</p> <p><b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number.</p> <p><b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.</p>

## Interface ID2 to ifIndex lookup table

The Interface ID2 to ifIndex lookup table is useful for mapping a known interface to the corresponding ifIndex value. If the provides an interface ID2, this table returns the ifIndex value.

### NOTE

The contents of the interface ID2 to ifIndex lookup table can only be accessed using GET operations. Unlike other SNMP tables, this table does not support GET-NEXT operations. If you try to walk the table using GET-NEXT, no rows will be returned.

Name, OID, and syntax	Access	Description
snInterfaceLookup2Table brcdIp.1.1.3.3.7	None	The Interface ID2 to ifIndex lookup table.

Name, OID, and syntax	Access	Description
snInterfaceLookup2Interfaceld brcdIp.1.1.3.3.7.1.1 Syntax: Interfaceld	Read-only	Shows the interface ID, which consists of the following: <b>Octet 0</b> – Port type, which can be one of the following: <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> </ul> The values 1 - 6 applies to Brocade NetIron XMR, Brocade MLX, and to Brocade MLXe router devices. <ul style="list-style-type: none"> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> <li>• 9 – ATM PVC</li> <li>• 10 – Management</li> <li>• 11 – Trunk</li> <li>• 12 – IP Tunnel (for IP tunnels, except MPLS)</li> </ul> The value also applies to 6 - 4 tunnels in Brocade NetIron XMR, Brocade MLX, and Brocade MLXe router devices. <b>Octet 1</b> <ul style="list-style-type: none"> <li>• If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the slot number of the device.</li> <li>• If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>• If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>• If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <b>Octet 2</b> – If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the port number. <b>Octet 3</b> – If the value of Octet 0 is 7 or 9, then this octet shows the ATM Subif number. <b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number. <b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.
snInterfaceLookup2IfIndex brcdIp.1.1.3.3.7.1.2 Syntax: Integer32	Read-only	Shows the interface in the ifIndex format.

## ifIndex to interface ID2 lookup table

The ifIndex to interface ID2 lookup table maps ifindex values to the Interface ID lookup table. If the provides an ifIndex, this table returns the interface ID value.

Name, OID, and syntax	Access	Description
snIfIndexLookup2Table brcdIp.1.1.3.3.8	None	The ifIndex to interface ID2 lookup table.

Name, OID, and syntax	Access	Description
snIfIndexLookup2IfIndex brcdIp.1.1.3.3.8.1.1 Syntax: Integer32	Read-only	Shows the interface in the ifIndex format.
snIfIndexLookup2InterfaceId brcdIp.1.1.3.3.8.1.2 Syntax: InterfaceId	Read-only	Shows the interface ID, which consists of the following: <b>Octet 0</b> – Port type, which can be one of the following: <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> </ul> The values 1 - 6 applies to Brocade NetIron devices. <ul style="list-style-type: none"> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> <li>• 9 – ATM PVC</li> <li>• 10 – Management</li> <li>• 11 – Trunk</li> <li>• 12 – IP Tunnel (for IP tunnels, except MPLS)</li> </ul> This value also applies to 6 - 4 tunnels in the Brocade NetIron devices, <b>Octet 1</b> <ul style="list-style-type: none"> <li>• If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the slot number of the device.</li> <li>• If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>• If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>• If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <b>Octet 2</b> – If the value of Octet 0 is 1, 2, 3, 7, or 9, then this octet shows the port number. <b>Octet 3</b> – If the value of Octet 0 is 7 or 9, then this octet shows the ATM Subif number. <b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number. <b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.

## ifIndex to optical parameters table

If the table provides an ifIndex, the ifIndex to optical parameters table returns the optical parameters for the ifIndex.

### NOTE

The following objects provide information for POS and Ethernet optical monitoring. They are equivalent to the output of the **show optics** command.

Name, OID, and syntax	Access	Description
snIfOpticalMonitoringInfoTable brcdIp.1.1.3.3.6	None	This table lists the instrumented parameters of all optical interfaces.

Name, OID, and syntax	Access	Description
snIfOpticalMonitoringTemperature brcdIp.1.1.3.3.6.1.1 Syntax: Display string	Read-only	This object holds the value of the transmitter laser diode temperature for the interface. This object indicates the health of the transmitter. The format is xxx.yyyy C (Celcius), followed by whether the measured value is normal, high or low alarm, or high or low warning. For 100G LR4 and LR10 optic, this object returns the average temperature for all the lanes.
snIfOpticalMonitoringTxPower brcdIp.1.1.3.3.6.1.2 Syntax: Display string	Read-only	This object holds the value of the transmitter optical signal power for the interface, measured in dBm, followed by whether this is a normal value, or high or low warning or alarm. For 100G LR4 and LR10 optic, this object returns the aggregated Tx power for all the lanes.
snIfOpticalMonitoringRxPower brcdIp.1.1.3.3.6.1.3 Syntax: Display string	Read-only	This object holds the value of the receiver optical signal power for the interface, measured in dBm, followed by whether this is a normal value, high or low warning, or alarm. For 100G LR4 and LR10 optic, this object returns the aggregated Rx power for all the lanes.
snIfOpticalMonitoringTxBiasCurrent brcdIp.1.1.3.3.6.1.4 Syntax: Display string	Read-only	The Tx bias current. It is measured in mA, and is followed by whether this is a normal value, high or low warning, or alarm. For 100G LR4 and LR10 optic, this object returns the aggregated Tx bias current for all the lanes.

## Optical lane monitoring table

The following table displays the optical parameters table per lane for a 100G LR4 and LR10 optic.

Name, OID, and syntax	Access	Description
snIfOpticalLaneMonitoringTable brcdIp.1.1.3.3.10	None	This table lists the instrumented parameters of all lanes within a 100G optic of type LR4 and LR10.
snIfOpticalLaneMonitoringLane brcdIp.1.1.3.3.10.1.1 Syntax: Unsigned32	None	This objects is the lane number of the 100G optic. An LR4 has 4-lanes per optic and LR10 has 10-lanes per optic.
snIfOpticalLaneMonitoringTemperature brcdIp.1.1.3.3.10.1.1 Syntax: DisplayString	Read-only	This object holds the value of the transmitter laser diode temperature for the lane in the interface. Indicates the health of the transmitter. The format is xxx.yyyy C (Celcius), followed by whether the measured value is normal, high/low alarm, or high/low warning.
snIfOpticalLaneMonitoringTxPower brcdIp.1.1.3.3.10.1.1 Syntax: DisplayString	Read-only	This object holds the value of the transmitter optical signal power for the lane in the interface, measured in dBm, followed by whether this is a this is a normal value, or high or low warning or alarm.

Name, OID, and syntax	Access	Description
snIfOpticalLaneMonitoringRx Power brcdIp.1.1.3.3.10.1.1 Syntax: DisplayString	Read-only	This object holds the value of the receiver optical signal power for the lane in the interface, measured in dBm, followed by whether this is a normal value, or high/low warning or alarm.
snIfOpticalLaneMonitoringTx BiasCurrent brcdIp.1.1.3.3.10.1.1 Syntax: DisplayString	Read-only	The Tx Bias Current. It is measured in mA, and is followed by whether this is a normal value, or high/low warning or alarm.

## Interface media information table

The following table shows the information of the media device installed in the physical ports.

These objects retrieve information from the output of the **show media** command.

Name, OID, and syntax	Access	Description
snIfMediaInfoTable brcdIp.1.1.3.3.9	None	The information of the media device (SFP/XFP/Copper) installed in the physical port. Only the ifIndices of Ethernet ports that are associated with the operational cards are included in this table.
snIfMediaType brcdIp.1.1.3.3.9.1.1 Syntax: Display string	Read-only	The type of the media installed in the physical port.
snIfMediaVendorName brcdIp.1.1.3.3.9.1.2 Syntax: Display string	Read-only	The media vendor name (full name of the corporation).
snIfMediaVersion brcdIp.1.1.3.3.9.1.3 Syntax: Display string	Read-only	The media vendor product version number.
snIfMediaPartNumber brcdIp.1.1.3.3.9.1.4 Syntax: Display string	Read-only	The media vendor part number.
snIfMediaSerialNumber brcdIp.1.1.3.3.9.1.5 Syntax: Display string	Read-only	The vendor serial number of the media device.

## Loopback interface configuration table

The following table lists the objects that are supported on the Brocade MLX, Brocade MLXe router, and Brocade NetIron XMR devices.

## 9 Interface ID Registration Group

Name, OID, and syntax	Access	Description
snLoopbackIntfConfigTable brcdIp.1.2.13.1	None	The loopback interface configuration table.
snLoopbackIntfConfigPortIndex brcdIp.1.2.13.1.1.1 Syntax: Integer	Read-only	Shows the port index for a loopback interface configuration entry. There can be up to eight entries in this table. Valid values: 1 - 8
snLoopbackIntfMode brcdIp.1.2.13.1.1.2 Syntax: Integer	Read-write	Indicates if loopback interface is enabled: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snLoopbackIntfRowStatus brcdIp.1.2.13.1.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written are: <ul style="list-style-type: none"><li>delete(3) – Deletes the row.</li><li>create(4) – Creates a new row.</li><li>modify(5) – Modifies an existing row.</li></ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"><li>noSuch(0) – No such row.</li><li>invalid(1) – Row is inoperative.</li><li>valid(2) – Row exists and is valid.</li></ul>



# CAM Statistics

## In this chapter

- IP CAM statistics table . . . . . 199
- CAM statistics table . . . . . 200
- CAM profile . . . . . 202
- CAM usage for Layer 3 traffic . . . . . 202
- CAM usage for Layer 2 traffic . . . . . 203
- CAM usage session table . . . . . 204
- CAM usage other table . . . . . 205

## IP CAM statistics table

The following table lists the CAM statistics for Layer 3. The objects in the table are the output for the **dm cam-stat ip** command.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snCAMIpStatTable brcdIp.1.1.2.12.2	None	IP CAM statistics table.
snCAMIpStatIfIndex brcdIp.1.1.2.12.2.1.1 Syntax: Unsigned32	Read-only	The ifIndex value of the local interface.
snCAMIpStatLevel brcdIp.1.1.2.12.2.1.2 Syntax: Unsigned32	Read-only	The level of CAM entry for that interface.
snCAMIpStatFreeEntries brcdIp.1.1.2.12.2.1.3 Syntax: Unsigned32	Read-only	Free entries in the IP CAM for that interface and level.
snCAMIpStatTotalEntries brcdIp.1.1.2.12.2.1.4 Syntax: Unsigned32	Read-only	Total entries in the IP CAM for that interface and level.

The output provides the following information:

- L3 L3 1 - 2047 (0x00001 - 0x007ff), free 2047 (0x007ff)
- L3 L2 2048 - 4095 (0x00800 - 0x00fff), free 2048 (0x00800)

- L3 4096 - 32767 (0x01000 - 0x07fff), free 28662 (0x06ff6)

Values are shared across the DMA. Also, if IP activity across DMAs is not different, some fields may show the same values.

## CAM statistics table

The following table shows CAM statistics for all master DMAs. The objects are equivalent to the **dm cam stat** <dma master num> command.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snCamStatTable brcdIp.1.1.2.12.3	None	CAM statistics table.
snCamStatDMAIdNumber brcdIp.1.1.2.12.3.1.1 Syntax: Unsigned32	Read-only	DMA ID number.
snCamStatDMAMasterNumber brcdIp.1.1.2.12.3.1.2 Syntax: Unsigned32	Read-only	DMA master for the DMA ID number.
snCamStatFreePool0Entries brcdIp.1.1.2.12.3.1.3 Syntax: Unsigned32	Read-only	CAM free pool0 entries.
snCamStatFreePool1Entries brcdIp.1.1.2.12.3.1.4 Syntax: Unsigned32	Read-only	CAM free pool1 entries.
snCamStatFreePool2Entries brcdIp.1.1.2.12.3.1.5 Syntax: Unsigned32	Read-only	CAM free pool2 entries.
snCamStatFreePool3Entries brcdIp.1.1.2.12.3.1.6 Syntax: Unsigned32	Read-only	CAM free pool3 entries.
snCamStatFreeL2Entries brcdIp.1.1.2.12.3.1.7 Syntax: Unsigned32	Read-only	CAM free Layer 2 entries
snCamStatFreeL2LowestSection brcdIp.1.1.2.12.3.1.8 Syntax: Unsigned32	Read-only	CAM free Layer 2 lowest section entries.
snCamStatHostLookupCount brcdIp.1.1.2.12.3.1.9 Syntax: Unsigned32	Read-only	CAM host lookup count for router.
snCamStatRouteLookupCount brcdIp.1.1.2.12.3.1.10 Syntax: Unsigned32	Read-only	CAM route lookup count for router.

Name, OID, and syntax	Access	Description
snCamStatLevel1 brcdIp.1.1.2.12.3.1.11 Syntax: Unsigned32	Read-only	CAM stat level 1 entries for router.
snCamStatLevel2 brcdIp.1.1.2.12.3.1.12 Syntax: Unsigned32	Read-only	CAM stat level 2 entries for router.
snCamStatLevel3 brcdIp.1.1.2.12.3.1.13 Syntax: Unsigned32	Read-only	CAM stat level 3 entries for router.
snCamStatMacFailCount brcdIp.1.1.2.12.3.1.14 Syntax: Unsigned32	Read-only	CAM MAC fail count.
snCamStatIPRouteFailCount brcdIp.1.1.2.12.3.1.15 Syntax: Counter	Read-only	CAM IP route fail count.
snCamStatIPSessionFailCount brcdIp.1.1.2.12.3.1.16 Syntax: Counter	Read-only	CAM IP session fail count.
snCamStatIPMCastFailCount brcdIp.1.1.2.12.3.1.17 Syntax: Counter	Read-only	CAM IP multicast fail count.
snCamStatL2SessionFailCount brcdIp.1.1.2.12.3.1.18 Syntax: Counter	Read-only	CAM Layer 2 session fail count.
snCamStatAddMACCount brcdIp.1.1.2.12.3.1.19 Syntax: Counter	Read-only	CAM add MAC count.
snCamStatAddVLANCount brcdIp.1.1.2.12.3.1.20 Syntax: Counter	Read-only	CAM add VLAN count.
snCamStatAddIPHostCount brcdIp.1.1.2.12.3.1.21 Syntax: Counter	Read-only	CAM add IP host count.
snCamStatAddIPRouteCount brcdIp.1.1.2.12.3.1.22 Syntax: Counter	Read-only	CAM add IP route count.
snCamStatAddIPSessionCount brcdIp.1.1.2.12.3.1.23 Syntax: Counter	Read-only	CAM add IP session count.
snCamStatAddIPMCastCount brcdIp.1.1.2.12.3.1.24 Syntax: Counter	Read-only	CAM add IP multicast count.
snCamStatAddL2SessionCount brcdIp.1.1.2.12.3.1.25 Syntax: Counter	Read-only	CAM add Layer 2 session count.

Name, OID, and syntax	Access	Description
snCamStatAddIPXCount brcdIp.1.1.2.12.3.1.26 Syntax: Counter	Read-only	CAM add IPX count.
snCamStatDeleteDMACamCount brcdIp.1.1.2.12.3.1.27 Syntax: Counter	Read-only	CAM delete DMA CAM count.

## CAM profile

The following object identifies CAM partition profiles. Each profile adjusts the partitions to optimize the device for corresponding applications.

Name, OID, and syntax	Access	Description
snCamProfile brcdIp.1.14.1.1.1.1 Syntax: Integer	Read-only	Identifies the CAM partition profile. Each profile adjusts the partitions to optimize the device for corresponding applications. Displays one of the following: <ul style="list-style-type: none"> <li>• default(1)</li> <li>• ipv4(2)</li> <li>• ipv4Ipv6(3)</li> <li>• ipv4Ipv62(4)</li> <li>• ipv4Vpls(5)</li> <li>• ipv4Vpn(6)</li> <li>• ipv6(7)</li> <li>• l2Metro(8)</li> <li>• l2Metro2(9)</li> <li>• mplsL3vpn(10)</li> <li>• mplsL3vpn2(11)</li> <li>• mplsVpls(12)</li> <li>• mplsVpls2(13)</li> <li>• mplsVpnVpls(14)</li> <li>• multiService(15)</li> <li>• multiService2(16)</li> <li>• multiService3(17)</li> <li>• multiService4(18)</li> </ul>

## CAM usage for Layer 3 traffic

The following table contains information about the CAM usage on the device by Layer 3 traffic.

Name, OID, and syntax	Access	Description
snCamUsageL3Table brcdIp.1.14.1.1.2.1	None	The CAM usage table for Layer 3 traffic.

Name, OID, and syntax	Access	Description
snCamUsageL3Slot brcdIp.1.14.1.1.2.1.1.1 Syntax: Unsigned32	None	A number that uniquely identifies an interface module on the device.
snCamUsageL3Processor brcdIp.1.14.1.1.2.1.1.2 Syntax: Unsigned32	None	A number which uniquely identifies the network processor of the interface module identified by the “snCamUsageL3Slot” object.
snCamUsageL3Type brcdIp.1.14.1.1.2.1.1.3 Syntax: Integer	None	Identifies the type of Layer 3 traffic passing through the network processor: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• ipv4vpn(3)</li> <li>• ipv6vpn(4)</li> </ul>
snCamUsageL3Supernet brcdIp.1.14.1.1.2.1.1.4 Syntax: Unsigned32	None	Identifies the supernet for the Layer 3 type traffic. It provides information for the longest match lookup. For example: <ul style="list-style-type: none"> <li>• 0 - All the bits of an IP address will be matched.</li> <li>• 1 - All but the lowest bit in an IP address will be matched.</li> </ul> Valid Values: <ul style="list-style-type: none"> <li>• IPv4 and IPv4VPN (0 - 32), where a value of 32 indicates the entry is the total of other supernets indexed by [0..31].</li> <li>• IPv6 (0 - 10), where a value of 10 indicates the entry is the total of other Supernets indexed by [0..9].</li> </ul>
snCamUsageL3Size brcdIp.1.14.1.1.2.1.1.5 Syntax: Unsigned32	Read-only	The effective CAM size by the Layer 3 traffic: <ul style="list-style-type: none"> <li>• IPv4 traffic - Each unit is 4 bytes.</li> <li>• IPv4vpn traffic - Each unit is 8 bytes.</li> <li>• IPv6 traffic - Each unit is 16 bytes.</li> </ul>
snCamUsageL3Free brcdIp.1.14.1.1.2.1.1.6 Syntax: Gauge32	Read-only	The amount of CAM currently available by the Layer 3 traffic entry: <ul style="list-style-type: none"> <li>• IPv4 traffic - each unit is 4 bytes.</li> <li>• IPv4vpn traffic - each unit is 8 bytes.</li> <li>• IPv6 traffic - each unit is 16 bytes.</li> </ul>
snCamUsageL3UsedPercent brcdIp.1.14.1.1.2.1.1.7 Syntax: Percent	Read-only	The percentage of CAM currently being used by the Layer 3 traffic.

## CAM usage for Layer 2 traffic

The following table contains information about the CAM usage on the device by Layer 2 traffic.

Name, OID, and syntax	Access	Description
snCamUsageL2Table brcdIp.1.14.1.1.2.2	None	The CAM usage table for Layer 2 traffic.
snCamUsageL2Slot brcdIp.1.14.1.1.2.2.1.1 Syntax: Unsigned32	None	A number that uniquely identifies an interface module on the device.

Name, OID, and syntax	Access	Description
snCamUsageL2Processor brcdIp.1.14.1.1.2.2.1.2 Syntax: Unsigned32	None	A number which uniquely identifies the network processor of the interface module identified by the “snCamUsageL2Slot” object.
snCamUsageL2Type brcdIp.1.14.1.1.2.2.1.3 Syntax: Integer	None	Identifies the type of Layer 2 traffic passing through the network processor: <ul style="list-style-type: none"> <li>• forwarding(1)</li> <li>• protocol(2)</li> <li>• flooding(3)</li> <li>• total(4)</li> </ul>
snCamUsageL2Size brcdIp.1.14.1.1.2.2.1.4 Syntax: Unsigned32	None	Indicates the effective CAM size for this Layer 2 traffic entry. Each unit is 8 bytes.
snCamUsageL2Free brcdIp.1.14.1.1.2.2.1.5 Syntax: Gauge32	Read-only	Shows the amount of CAM currently available for this Layer 2 traffic. Each unit is 8 bytes.
snCamUsageL2UsedPercent brcdIp.1.14.1.1.2.2.1.6 Syntax: Percent	Read-only	Shows the percentage of CAM currently being used for this Layer 2 traffic.

## CAM usage session table

The following table contains information about the CAM usage on the device by sessions traffic.

Name, OID, and syntax	Access	Description
snCamUsageSessionTable brcdIp.1.14.1.1.2.3	None	The CAM usage table for Layer 3 traffic.
snCamUsageSessionSlot brcdIp.1.14.1.1.2.3.1.1 Syntax: Unsigned32	None	A number that uniquely identifies an interface module on the device.
snCamUsageSessionProcessor brcdIp.1.14.1.1.2.3.1.2 Syntax: Unsigned32	None	A number which uniquely identifies the network processor on the interface module identified by the “snCamUsageSessionSlot” object.

Name, OID, and syntax	Access	Description
snCamUsageSessionType brcdIp.1.14.1.1.2.3.1.3 Syntax: Integer	None	Identifies the type of session: <ul style="list-style-type: none"> <li>• ipv4Multicast(1)</li> <li>• ipv4andMacReceiveAcl(2)</li> <li>• ipv4andMacRuleAcl(3)</li> <li>• ipv4andMacTotal(4)</li> <li>• ipv4andMacOut(5)</li> <li>• ipv6Multicast(6)</li> <li>• ipv6ReceiveAcl(7)</li> <li>• ipv6RuleAcl(8)</li> <li>• ipv6Total(9)</li> <li>• ipv6Out(10)</li> <li>• labelOut(11)</li> <li>• ipv4SrcGuardDenial(12)</li> <li>• ipv4SrcGuardPermit(13)</li> <li>• internalForwardingLookup(14)</li> </ul>
snCamUsageSessionSize brcdIp.1.14.1.1.2.3.1.4 Syntax: Unsigned32	Read-only	Identifies the effective CAM size for this session traffic entry: <ul style="list-style-type: none"> <li>• IPv4 sessions - Each unit is 16 bytes.</li> <li>• IPv6 sessions - Each unit is 64 bytes.</li> </ul>
snCamUsageSessionFree brcdIp.1.14.1.1.2.3.1.5 Syntax: Gauge32	Read-only	The amount of CAM currently available for this session: <ul style="list-style-type: none"> <li>• IPv4 sessions - Each unit is 16 bytes.</li> <li>• IPv6 sessions - Each unit is 64 bytes.</li> </ul>
snCamUsageSessionUsedPercent brcdIp.1.14.1.1.2.3.1.6 Syntax: Percent	Read-only	The percentage of CAM currently being used by this session.

## CAM usage other table

The following table contains information about the CAM usage on the device by traffic other than Layer 3, Layer 2, and Sessions.

Name, OID, and syntax	Access	Description
snCamUsageOtherTable brcdIp.1.14.1.1.2.4	None	CAM usage table for traffic types other than Layer 3, Layer 2, and Sessions traffic.
snCamUsageOtherSlot brcdIp.1.14.1.1.2.4.1.1 Syntax: Unsigned32	None	A number that uniquely identifies an interface module on the device.
snCamUsageOtherProcessor brcdIp.1.14.1.1.2.4.1.2 Syntax: Unsigned32	None	A number which uniquely identifies the network processor on the interface module identified by the <a href="#">"snCamUsageOtherSlot"</a> object.
snCamUsageOtherType brcdIp.1.14.1.1.2.4.1.3 Syntax: Integer	None	Identifies the traffic type: <ul style="list-style-type: none"> <li>• gre(1)</li> <li>• multicastVpls(2)</li> </ul>
snCamUsageOtherSize brcdIp.1.14.1.1.2.4.1.4 Syntax: Unsigned32	Read-only	Indicates the effective CAM size for this Other traffic type: <ul style="list-style-type: none"> <li>• GRE - Each unit is 8 bytes.</li> <li>• Multicast VPLS - Each unit is 16 bytes.</li> </ul>

## 10 CAM Statistics

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snCamUsageOtherFree brcdIp.1.14.1.1.2.4.1.5 Syntax: Gauge32	Read-only	Indicates the amount of CAM currently available to this traffic type: <ul style="list-style-type: none"><li>• GRE: each unit is 8 bytes</li><li>• Multicast VPLS: each unit is 16 bytes</li></ul>
snCamUsageOtherUsedPercent brcdIp.1.14.1.1.2.4.1.6 Syntax: Percent	Read-only	Indicates the percentage of CAM currently being used for this traffic type.



# System DRAM

---

## In this chapter

- System DRAM information group ..... 207
- System debug group ..... 207
- System temperature table ..... 209
- System temperature threshold table ..... 209
- System stacking temperature table ..... 210
- Software licensing ..... 210

## System DRAM information group

The system DRAM information group displays memory utilization statistics for protocols that use dynamic memory allocation. It shows the same information that the **show memory** command displays.

Name, OID, and syntax	Access	Description
snAgSystemDRAM brcdIp.1.1.2.12.4	None	The system DRAM information groups.
snAgSystemDRAMUtil brcdIp.1.1.2.12.4.1 Syntax: Integer	Read-only	The amount of system dynamic memory that is currently utilized, in percent. This object replaces “snAgGblDynMemUtil”.
snAgSystemDRAMTotal brcdIp.1.1.2.12.4.2 Syntax: Integer	Read-only	The total amount of system dynamic memory, in bytes. This object replaces “snAgGblDynMemTotal”.
snAgSystemDRAMFree brcdIp.1.1.2.12.4.3 Syntax: Integer	Read-only	The amount of free system dynamic memory, in bytes. This object replaces “snAgGblDynMemFree”.
snAgSystemDRAMForBGP brcdIp.1.1.2.12.4.4 Syntax: Integer	Read-only	The amount of free dynamic memory used by BGP, in bytes.
snAgSystemDRAMForOSPF brcdIp.1.1.2.12.4.5 Syntax: Integer	Read-only	The amount of free dynamic memory used by OSPF, in bytes.

## System debug group

The following objects are for debugging. They are equivalent to the **debug** command.

---

**NOTE**

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snAgSystemDebug brcdIp.1.1.2.12.5	None	The system debug group.
snAgSystemDebugTotalIn brcdIp.1.1.2.12.5.1 Syntax: Unsigned32	Read-only	Total incoming packet count. Sum of buffer manager and CPU read count.
snAgSystemDebugTotalOut brcdIp.1.1.2.12.5.2 Syntax: Unsigned32	Read-only	Total outgoing packet count.
snAgSystemDebugCpuQueueRead brcdIp.1.1.2.12.5.3 Syntax: Unsigned32	Read-only	CPU queue read count.
snAgSystemDebugDRAMBuffer brcdIp.1.1.2.12.5.4 Syntax: Unsigned32	Read-only	DRAM buffer count.
snAgSystemDebugBMBuffer brcdIp.1.1.2.12.5.5 Syntax: Unsigned32	Read-only	Buffer Manager (BM) buffer count.
snAgSystemDebugBMFreeBuffer brcdIp.1.1.2.12.5.6 Syntax: Unsigned32	Read-only	Free BM buffer count.
snAgSystemDebugBMFreeBufferMgmt brcdIp.1.1.2.12.5.7 Syntax: Unsigned32	Read-only	Free BM buffer management count.
snAgSystemDebugIpcGigLock brcdIp.1.1.2.12.5.8 Syntax: Unsigned32	Read-only	IPC gigabyte lock count.
snAgSystemDebugDRAMGetError brcdIp.1.1.2.12.5.9 Syntax: Unsigned32	Read-only	DRAM get error count.
snAgSystemDebugDRAMToBMCopyFail brcdIp.1.1.2.12.5.10 Syntax: Unsigned32	Read-only	DRAM to BM copy fail count.

---

## System temperature table

This section displays the SNMP MIB objects for temperature readings on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series, and on the FastIron devices.

For stacking devices, refer to “[System stacking temperature table](#)” on page 210. The system temperature table shows temperature reading information for each module’s temperature sensor.

Name, OID, and syntax	Access	Description
snAgentTempTable brcdIp.1.1.2.13.1	None	The table that displays the temperature reading for each module’s temperature sensor. Note that temperature readings are displayed only for those modules that have temperature sensors.
snAgentTempSlotNum brcdIp.1.1.2.13.1.1.1 Syntax: Integer32	None	The slot number of the module to which the temperature sensor is attached.
snAgentTempSensorId brcdIp.1.1.2.13.1.1.2 Syntax: Integer32	None	The identification number of the module’s temperature sensor. The following applies to the Management modules: <ul style="list-style-type: none"> <li>• Sensor 1 – The intake temperature.</li> <li>• Sensor 2 – The exhaust-side temperature.</li> </ul>
snAgentTempSensorDescr brcdIp.1.1.2.13.1.1.3 Syntax: Display string	Read-only	The description of the temperature sensor.
snAgentTempValue brcdIp.1.1.2.13.1.1.4 Syntax: Integer	Read-only	The temperature reading for the temperature sensor. This value is displayed in units of 0.5° Celsius. Valid values: 110 – 250

## System temperature threshold table

The following table lists the temperature levels of the fan settings.

### NOTE

The new MP card MR2 supports all the objects in the System temperature threshold table. The MP-MR2 is supported only on the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices.

Name, OID, and syntax	Access	Description
snAgentTempThresholdTable brcdIp.1.1.2.13.2	None	The table lists the temperature threshold levels for four speeds of fan settings: <ul style="list-style-type: none"> <li>• low</li> <li>• medium</li> <li>• medium-high</li> <li>• high</li> </ul>
snAgentTempThresholdModule brcdIp.1.1.2.13.2.1.1 Syntax: Integer	None	The module in the system for which threshold levels represented by this row are applicable.

Name, OID, and syntax	Access	Description
snAgentTempThresholdLevel brcdIp.1.1.2.13.2.1.2 Syntax: Integer	None	The temperature threshold level of the module for which threshold levels represented by this row are applicable.
snAgentTempThresholdHighValue brcdIp.1.1.2.13.2.1.3 Syntax: Integer	Read-write	The high value for the temperature threshold, above which the fans would need to operate at the next higher speed. If the value reaches more than the high threshold value for the 'high' level, the module will be shut down.
snAgentTempThresholdLowValue brcdIp.1.1.2.13.2.1.4 Syntax: Integer	Read-write	The low value for the temperature threshold, below which the fans would need to operate at the next lower speed. This value is not applicable for the 'low' level, as there are no more lower speeds.

## System stacking temperature table

The following table shows temperature information for a module's temperature sensor in the stacking devices.

Name, OID, and syntax	Access	Description
snAgentTemp2Table brcdIp.1.1.2.13.3	None	This table lists the temperatures of the modules in each unit. This table is applicable only to modules with temperature sensors.
snAgentTemp2UnitNum brcdIp.1.1.2.13.3.1.1 Syntax: Integer	None	The unit number of the module that contains the temperature sensor represented by this row.
snAgentTemp2SlotNum brcdIp.1.1.2.13.3.1.2 Syntax: Integer	None	The slot number of the module that contains the temperature sensor represented by this row.
snAgentTemp2SensorId brcdIp.1.1.2.13.3.1.3 Syntax: Integer	None	The temperature sensor ID of the member module that is represented by this row: For Brocade FastIron devices: <ul style="list-style-type: none"> <li>sensor# 1 - Intake Side Temperature</li> <li>sensor# 2 - Exhaust Side Temperature</li> </ul>
snAgentTemp2SensorDescr brcdIp.1.1.2.13.3.1.4 Syntax: DisplayString	Read-only	Description of the temperature sensor. This is the same as snAgentTempSensorId, which is in numeric format. It is used to traverse the temperature sensor table. The description provides the meaning and purpose of this sensor. There can be up to 128 characters in the description.
snAgentTemp2Value brcdIp.1.1.2.13.3.1.5 Syntax: Integer	Read-only	Temperature of the sensor represented by this row. Each unit is 0.5° Celsius. Valid values: 110° - 250° Celsius.

## Software licensing

The following table contains information about the software licenses configured on the device.

**NOTE**

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series and on the FastIron devices.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
fdryLicenseTable brcdIp.1.1.2.15.1	None	A list of licenses maintained by the license sub-system.
fdryLicensePackageName brcdIp.1.1.2.15.1.1.1 Syntax: DisplayString	None	The name of the package, whose license information, this entry displays.
fdryLicenseLid brcdIp.1.1.2.15.1.1.2 Syntax: DisplayString	None	The License ID (LID) of the chassis or the line module for which this entry displays license information.
fdryLicenseHash brcdIp.1.1.2.15.1.1.3 Syntax: DisplayString	None	A unique hash for identifying a license entry in the system. This helps traverse through the entries with the same package name and LID.
fdryLicenseType brcdIp.1.1.2.15.1.1.4 Syntax: Integer	Read-only	The type of the license, which can be either normal or trial.
fdryLicensePrecedence brcdIp.1.1.2.15.1.1.5 Syntax: Unsigned32	Read-only	Defines the priority of a particular trial license among those having the same package name and LID. This is primarily used for determining which license to use when there are many trial and normal licenses with the same package name and LID.
fdryLicenseTrialDays brcdIp.1.1.2.15.1.1.6 Syntax: Unsigned32	Read-only	The number of trial days for the license, if it is a trial license. Otherwise, the value has no meaning for normal licenses and read as 0 on a Get operation.
fdryLicenseTrialTimeElapsed brcdIp.1.1.2.15.1.1.7 Syntax: Unsigned32	Read-only	The cumulative number of hours used for this trial license. This counts all the usages of the trial license. For a normal license, this is 0.
fdryLicenseTrialTimeLeft brcdIp.1.1.2.15.1.1.8 Syntax: Unsigned32	Read-only	The number of hours left for the trial license. This is derived from the total number of hours and the cumulative number of hours used. For a normal license, this is 0.
fdryLicenseTrialState brcdIp.1.1.2.15.1.1.9 Syntax: Integer	Read-only	This indicates the state of the trial license: <ul style="list-style-type: none"> <li>• Invalid - The license is not valid.</li> <li>• Unused - The license is never used.</li> <li>• Active - The license has been used at least once.</li> <li>• Expired - The license has expired and can no longer be used.</li> </ul>
fdryLicenseVendorInfo brcdIp.1.1.2.15.1.1.10 Syntax: DisplayString	Read-only	This is the Brocade-specific package data which is an octet string. This contains encoded information of license-specific information such as package bit mask, number of ports and so on.
fdryLicenseSlot brcdIp.1.1.2.15.1.1.11 Syntax: Integer32	Read-only	This indicates the slot number of the module to which the license belongs.  There is a one-to-one mapping between LID and slot number, as each module has a unique LID and can be present in only one slot.
<b>NOTE:</b> This object is not supported on the Brocade FastIron devices		

## License information

The following object indicates the feature (license) installed on the device.

Name, OID, and syntax	Access	Description
fdryLicensedFeatureInfo brcdIp.1.1.2.15.2 Syntax: Bits <b>NOTE:</b> This object is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Indicates the feature or package for which the license has been enabled on the device: <ul style="list-style-type: none"> <li>ospf(0)</li> <li>isis(1)</li> <li>bgp(2)</li> <li>mpls(3)</li> </ul>

## Package upgrade operation

The following objects indicate the package upgrade process on all the Brocade NetIron devices.

Name, OID, and syntax	Access	Description
brcdSwPackageFname brcdIp.1.1.2.16.1.1.1 Syntax: DisplayString	Read-write	Specifies the name of the release package file or the manifest file, which includes the path that is currently associated with the system. When the object is not used, the value is a zero(0) length string.
brcdSwPackageLoad brcdIp.1.1.2.16.1.1.2 Syntax: Integer	Read-write	Specifies the action object to upgrade the system using a release package. The value none(1) specifies the system comes up and not used for SET request. The following values download the release package from a TFTP server and upgrade the system: <ul style="list-style-type: none"> <li>tftpToPrimary(2)—Installs both MP and LP application images to the primary code.</li> <li>tftpToSecondary(3)—Installs both MP and LP application images to the secondary code.</li> <li>tftpToMgmtModulePrimaryIntfModuleSecondary(4)—Installs an MP application image to the primary code and an LP application image to the secondary code.</li> <li>tftpToMgmtModuleSecondaryIntfModulePrimary(5)—Installs an MP application image to the secondary code and an LP application image to the primary code.</li> </ul>

Name, OID, and syntax	Access	Description
brcdSwPackageLoadStatus brcdIp.1.1.2.16.1.1.3 Syntax: Integer	Read-only	Indicates the progress of the upgrade operation. The operation starts with the “normal(1)” value when there is no outstanding upgrade process. When an upgrade process is initiated, the operation is transitioned to the “started(2)” value and proceeds further. When the upgrade process stops, whether the operation is successful or with errors, it returns to the “normal(1)” value. Finally, the brcdSwPackageLoadResultTable is populated with the summary of the upgrade process. <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• started(2)</li> <li>• internalError(3)</li> <li>• manifestFileDownloadError(4)</li> <li>• manifestFileValidationError(5)</li> <li>• downloadingManagementModuleBoot(6)</li> <li>• downloadingManagementModuleMonitor(7)</li> <li>• downloadingManagementModuleApplication(8)</li> <li>• downloadingInterfaceModuleBoot(9)</li> <li>• downloadingInterfaceModuleMonitor(10)</li> <li>• downloadingInterfaceModuleApplication(11)</li> <li>• downloadingInterfaceModuleFpga(12)</li> <li>• downloadingFpgaMBridge(13)</li> <li>• downloadingFpgaSBridge(14)</li> <li>• downloadingFpgaHBridge(15)</li> <li>• upgradingManagementModuleBoot(16)</li> <li>• upgradingManagementModuleMonitor(17)</li> <li>• upgradingManagementModuleApplication(18)</li> <li>• upgradingInterfaceModuleBoot(19)</li> <li>• upgradingInterfaceModuleMonitor(20)</li> <li>• upgradingInterfaceModuleApplication(21)</li> <li>• upgradingInterfaceModuleFpga(22)</li> <li>• upgradingFpgaMBridge(23)</li> <li>• upgradingFpgaSBridge(24)</li> <li>• upgradingFpgaHBridge(25)</li> </ul>
brcdSwPackageUpgradeAllImages brcdIp.1.1.2.16.1.1.4 Syntax: TruthVal	Read-write	Specifies all images upgrade. <ul style="list-style-type: none"> <li>• true(1) - The upgrade sequence includes MP and LP boot images and MP FPGA images (MBRIDGE/MBRIDGE32 and SBRIDGE/HSBRIDGE). For Brocade NetIron CES and Brocade NetIron CER series, the upgrade sequence includes only the boot images.</li> <li>• false(2) - Upgrades only MP and LP monitor images, MP and LP application images, and LP bundled FPGA images. For Brocade NetIron CES and Brocade NetIron CER series only the monitor, application, and FPGA images are upgraded. Returns false(2), for a read-only operation.</li> </ul> Default: false(2)

## Package upgrade result table

The following table contains the objects that indicate the summary of the last upgrade operation completed on the Brocade NetIron devices.

Name, OID, and syntax	Access	Description
brcdSwPackageLoadResultTable brcdIp.1.1.2.16.1.5	None	Contains the summary of the upgrade operation.
brcdSwPackageUpgradeResultIndex brcdIp.1.1.2.16.1.5.1.1 Syntax: Unsigned32	None	Specifies the sequential index or upgrade step.
brcdSwPackageUpgradeResultImageType brcdIp.1.1.2.16.1.5.1.2 Syntax: BrcdImageType	Read-only	Specifies the associated image type for the step of the upgrade process.
brcdSwPackageUpgradeResultStatus brcdIp.1.1.2.16.1.5.1.3 Syntax: Integer	Read-only	Indicates the upgrade status for the particular image upgrade.
brcdSwPackageUpgradeResultTimeStamp brcdIp.1.1.2.16.1.5.1.4 Syntax: TimeStamp	Read-only	Specifies the time stamp when the upgrade step is performed.
brcdSwPackageUpgradeResultDescription brcdIp.1.1.2.16.1.5.1.5 Syntax: DisplayString	Read-only	Contains the summary description for the particular image upgrade. <b>NOTE:</b> The result description is empty when brcdSwPackageLoadResultStatus is "ok".

## Interface module auto-upgrade objects

The following objects are for configuring the interface module auto-upgrade process for the Brocade NetIron devices.

Name, OID, and syntax	Access	Description
brcdSwIntfModAutoUpgradeMode brcdIp.1.1.2.16.1.2.1 Syntax: Integer	Read-write	Specifies the mode of an LP auto-upgrade. The following values can be written: <ul style="list-style-type: none"> <li>unknown(1)</li> <li>disabled(2)</li> <li>tftp(3)</li> <li>slot1(4)</li> <li>slot2(5)</li> </ul>
brcdSwIntfModAutoUpgradeTftpAddrType brcdIp.1.1.2.16.1.2.2 Syntax: InetAddressType	Read-write	Specifies the IP address type of a TFTP server. The following address types are supported: <ul style="list-style-type: none"> <li>ipv4(1)</li> <li>ipv6(2)</li> </ul>



Name, OID, and syntax	Access	Description
brcdSwIntfModAutoUpgradeTf tpAddr brcdIp.1.1.2.16.1.2.3 Syntax: InetAddress	Read-write	Specifies the IP address of a TFTP server for auto-upgrade.
brcdSwIntfModAutoUpgradeS rcPath brcdIp.1.1.2.16.1.2.4 Syntax: DisplayString	Read-write	Specifies the path to the topmost directory of the release package relative to the source.
brcdSwIntfModAutoUpgradeAl lImages brcdIp.1.1.2.16.1.2.5 Syntax: TruthValue	Read-write	Specifies all images upgrade. <ul style="list-style-type: none"> <li>• The upgrade sequence includes only the LP boot image, if set to true(1).</li> <li>• The default false(2), upgrades only the LP FPGA images.</li> </ul> Returns false(2), for a read-only operation.

## 11 System DRAM

# SNTP MIB Definition

## In this chapter

- [NTP general group](#) ..... 217
- [NTP server table \(IPv4\)](#) ..... 219
- [SNTP server table \(FastIron X series IPv6 devices\)](#) ..... 220

## NTP general group

You can configure Layer 2 and Layer 3 switches to consult SNTP servers for the current system time and date. As Layer 2 and Layer 3 switches do not retain time and date information across power cycles, using the SNTP feature alleviates the need to reconfigure time and date after a system reset.

The following objects provide information on the NTP server. These objects apply to all devices.

Name, OID, and syntax	Access	Description
snNTPGeneral brcdIp.1.1.3.11.1	None	Begins the NTP configuration objects.
snNTPPollInterval brcdIp.1.1.3.11.1.1 Syntax: Integer	Read-write	Specifies how often to poll the NTP server. Each unit is one second. Valid values: 1 – 65535 Default: 1800 seconds
<b>NOTE:</b> This MIB object is deprecated on the Brocade NetIron devices.		
snNTPTimeZone brcdIp.1.1.3.11.1.2 Syntax: Integer	Read-write	Time zone: <ul style="list-style-type: none"> <li>• alaska(0)</li> <li>• aleutian(1)</li> <li>• arizona(2)</li> <li>• central(3)</li> <li>• eastIndiana(4)</li> <li>• eastern(5)</li> <li>• hawaii(6)</li> <li>• michigan(7)</li> <li>• mountain(8)</li> <li>• pacific(9)</li> <li>• samoa(10)</li> <li>• gmtPlus1200(11)</li> <li>• gmtPlus1100(12)</li> <li>• gmtPlus1000(13)</li> <li>• gmtPlus0900(14)</li> </ul>

Name, OID, and syntax	Access	Description
snNTPTimeZone (continued)		<ul style="list-style-type: none"> <li>• gmtpPlus0800(15)</li> <li>• gmtpPlus0700(16)</li> <li>• gmtpPlus0600(17)</li> <li>• gmtpPlus0500(18)</li> <li>• gmtpPlus0400(19)</li> <li>• gmtpPlus0300(20)</li> <li>• gmtpPlus0200(21)</li> <li>• gmtpPlus0100(22)</li> <li>• gmtp(23) - default</li> <li>• gmtpMinus0100(24)</li> <li>• gmtpMinus0200(25)</li> <li>• gmtpMinus0300(26)</li> <li>• gmtpMinus0400(27)</li> <li>• gmtpMinus0500(28)</li> <li>• gmtpMinus0600(29)</li> <li>• gmtpMinus0700(30)</li> <li>• gmtpMinus0800(31)</li> <li>• gmtpMinus0900(32)</li> <li>• gmtpMinus1000(33)</li> <li>• gmtpMinus1100(34)</li> <li>• gmtpMinus1200(35)</li> <li>• gmtpPlus1130(36)</li> <li>• gmtpPlus1030(37)</li> <li>• gmtpPlus0930(38)</li> <li>• gmtpPlus0630(39)</li> <li>• gmtpPlus0530(40)</li> <li>• gmtpPlus0430(41)</li> <li>• gmtpPlus0330(42)</li> <li>• gmtpMinus0330(43)</li> <li>• gmtpMinus0830(44)</li> <li>• gmtpMinus0930(45)</li> </ul>
snNTPSummerTimeEnable brcdIp.1.1.3.11.1.3 Syntax: Integer	Read-write	<p>Indicates if daylight saving time is enabled:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1) – Enables daylight saving time starting at 02:00:00 on the first Sunday in April and ending at 02:00:00 in last Sunday in October.</li> </ul> <p>Default: disabled(0)</p>

Name, OID, and syntax	Access	Description
snNTPSystemClock brcdIp.1.1.3.11.1.4 Syntax: OCTET STRING	Read-write	Shows the format of the system clock: <ul style="list-style-type: none"> <li>• octet 0 – Seconds after the minute [0-60]</li> <li>• octet 1 – Minutes after the hour [0-59]</li> <li>• octet 2 – Hours since midnight [0-23]</li> <li>• octet 3 – Day of the month [1-31]</li> <li>• octet 4 – Months since January [0-11]</li> <li>• octet 5 – Years since 1900</li> <li>• octet 6 – Days since Sunday [0-6]</li> </ul> Octets 0 to 5 must have valid values and Octet 6 must be set to 0. To disable the system clock set all octets to zero.
snNTPSync brcdIp.1.1.3.11.1.5 Syntax: Integer <b>NOTE:</b> This MIB object is deprecated on the Brocade NetIron devices.	Read-write	Initiates the time synchronization to the NTP servers. For set operation, only "synchronize(2)" is accepted. For get operation, always return "other(1)".

## NTP server table (IPv4)

The following objects apply to all IPv4 devices. They provide information on the NTP server.

### NOTE

The following table is deprecated on the Brocade NetIron devices. For FastIron X Series devices, refer to [“SNTP server table \(FastIron X series IPv6 devices\)”](#).

Name, OID, and syntax	Access	Description
snNTPServerTable brcdIp.1.1.3.11.2	None	The NTP server table.
snNTPServerIp brcdIp.1.1.3.11.2.1.1 Syntax: IpAddress	Read-only	Shows the IP address of the NTP server.
snNTPServerVersion brcdIp.1.1.3.11.2.1.2 Syntax: Integer	Read-write	Shows the version in the NTP server. Default: 1
snNTPServerRowStatus brcdIp.1.1.3.11.2.1.3 Syntax: Integer	Read-write	Creates or deletes an NTP server table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## SNTP server table (FastIron X series IPv6 devices)

The following objects apply to FastIron X series IPv6 devices and it is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices. These objects provide information on the SNTP server.

---

### NOTE

Only in a specific configuration and with IPv4 SNTP servers, SNMP may stop working when the SNTP server table is viewed. If this occurs, add rfc4001-inetAddressMIB.mib or rfc4001.mib.

---

Name, OID, and syntax	Access	Description
fdrySntpServerTable brcdIp.1.1.7.1.1.1	None	The SNTP server table.
fdrySntpServerIndex brcdIp.1.1.7.1.1.1.1 Syntax: Unsigned32	None	The index to the SNTP server table. A maximum of three SNTP servers are supported.
fdrySntpServerAddrType brcdIp.1.1.7.1.1.1.2 Syntax: InetAddressType	Read-create	The SNTP server IP address type: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> <li>• Default: IPv4</li> </ul>
fdrySntpServerAddr brcdIp.1.1.7.1.1.1.3 Syntax: InetAddress	Read-create	The SNTP server IP address.
fdrySntpServerVersion brcdIp.1.1.7.1.1.1.4 Syntax: Integer32	Read-create	The SNTP server version.
fdrySntpServerRowStatus brcdIp.1.1.7.1.1.1.5 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in the table. When a row in the table is in active(1) state, no objects in that row can be modified except the object.

---

# DNS2 MIB Definition

---

## In this chapter

- [DNS table \(FastIron devices\) . . . . . 221](#)
- [DNS address table \(FastIron devices\) . . . . . 221](#)

## DNS table (FastIron devices)

The table lists the IPv4 and IPv6 DNS service names for FastIron devices.

Name, OID, and syntax	Access	Description
fdryDns2DomainNameTable brcdIp.1.1.3.34.1.1 Syntax: Sequence of FdryDns2DomainNameTable	None	The DNS name table.
fdryDns2DomainNameIndex brcdIp.1.1.3.34.1.1.1 Syntax: Unsigned32	None	The index to the DNS name table.
fdryDns2DomainNameAddrType brcdIp.1.1.3.34.1.1.1.2 Syntax: InetAddressType	Read-create	The DNS IP address type: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
fdryDns2DomainNameName brcdIp.1.1.3.34.1.1.1.3 Syntax: DisplayString	Read-create	The DNS domain name string.
fdryDns2DomainNameRowStatus brcdIp.1.1.3.34.1.1.1.4 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except for this object.

## DNS address table (FastIron devices)

The address table lists the IPv4 and IPv6 DNS addresses. These objects apply to FastIron devices.

### NOTE

The objects in the DNS server table are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## 13 DNS2 MIB Definition

Name, OID, and syntax	Access	Description
fdryDnsServerTable brcdIp.1.1.3.34.2.1 Syntax: FdryDnsServerTable	None	The DNS address list table that lists the IPv4 and IPv6 DNS addresses.
fdryDnsServerAddrType brcdIp.1.1.3.34.2.1.1.1 Syntax: InetAddressType	None	The DNS IP address type: <ul style="list-style-type: none"><li>• ipv4(1)</li><li>• ipv6(2)</li></ul> Default: ipv4(1)
fdryDnsServerIndex brcdIp.1.1.3.34.2.1.1.2 Syntax: Unsigned32	None	The index to the DNS address table. Up to four DNS IP addresses are supported for each IPv4 and IPv6 protocol.
fdryDnsServerAddr brcdIp.1.1.3.34.2.1.1.3 Syntax: InetAddress	Read-create	The DNS IP address.
fdryDnsServerRowStatus brcdIp.1.1.3.34.2.1.1.4 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except for this object.



## Trace route group

---

### In this chapter

• Trace route group . . . . .	223
• General trace route group . . . . .	223
• Trace route result table . . . . .	224
• IP forwarding cache table . . . . .	225
• IP AS-Path access list table . . . . .	226
• IP community list table . . . . .	227
• IP prefix list table . . . . .	228
• IP AS-Path access list string table . . . . .	230
• IP community list string table . . . . .	230

### Trace route group

This group uses the following method to detect routes used to reach a destination address.

1. The originating Layer 3 switch sends a probe packet (a UDP packet) to the destination address with a time-to-live (TTL) value of 1.
2. The first Layer 3 switch that receives this packet decrements the TTL, then drops the packet and returns a ICMP packet to the originator.
3. The originating Layer 3 switch records the route in the “`snRtIpTraceRouteResultTable`”.
4. The originating Layer 3 switch sends a probe packet (a UDP packet) to the destination address with a TTL value of 2.
5. The second Layer 3 switch that receives this packet decrements the TTL, then drops the packet and returns an ICMP packet to the originator.
6. The originating Layer 3 switch records the route in “`snRtIpTraceRouteResultTable`”.

This procedure is repeated until the destination is reached or the maximum TTL is reached.

### General trace route group

The following objects define the trace route probe packet.

## 14 Trace route group

Name, OID, and Syntax	Access	Description
snRtlpTraceRouteTargetAddr brcdIp.1.2.2.10.1.1 Syntax: IpAddress	Read-write	Shows the target IP address of the trace route.
snRtlpTraceRouteMinTtl brcdIp.1.2.2.10.1.2 Syntax: Integer	Read-write	Indicates the minimum TTL value carried in the first probe packet. Valid values: 1 – 255 minutes Default: 1 minute
snRtlpTraceRouteMaxTtl brcdIp.1.2.2.10.1.3 Syntax: Integer	Read-write	Indicates the maximum TTL value carried in the last probe packet. Valid values: 1 – 255 minutes. Default: 30 minutes
snRtlpTraceRouteTimeOut brcdIp.1.2.2.10.1.4 Syntax: Integer	Read-write	Indicates the number of seconds the Layer 3 switch waits for a response from the probe packet (i.e. the ICMP packet) before timing out. Valid values: 1 – 255 seconds. Default: 2 seconds
snRtlpTraceRouteControl brcdIp.1.2.2.10.1.5 Syntax: Integer	Read-write	Indicates the progress of the trace route: <ul style="list-style-type: none"> <li>start(1) – snRtlpTraceRouteDestAddr must have been initialized before start(1) can be written.</li> <li>abort(2) – Stops the current trace route operation.</li> <li>success(3) – The destination address is reached.</li> <li>failure(4) – Either the destination address is not reach, trace route times out, or the ending TTL is reached before the operation is completed.</li> <li>inProgress(5) – Trace route operation has started.</li> </ul> Only "start" and "abort" are writable values; whereas, "success", "failure" and "inProgress" are read-only (or returned) values. The " <a href="#">snRtlpTraceRouteResultTable</a> " on page 224 contains the routes and target addresses.

## Trace route result table

This table contains the routes and the target addresses used in the trace route operation to reach the destination address.

Name, OID, and Syntax	Access	Description
snRtlpTraceRouteResultTable brcdIp.1.2.2.10.2.1	None	The trace route results table.
snRtlpTraceRouteResultIndex brcdIp.1.2.2.10.2.1.1.1 Syntax: Integer32	Read-only	The index for an entry in the trace route results table.
snRtlpTraceRouteResultAdr brcdIp.1.2.2.10.2.1.1.2 Syntax: IpAddress	Read-only	Indicates the IP address of the Layer 3 switch or the target IP address of the Layer 3 switch.

Name, OID, and Syntax	Access	Description
snRtlpTraceRouteResultRoundTri pTime1 brcdIp.1.2.2.10.2.1.1.3 Syntax: Time ticks	Read-only	Shows the round trip time between the transmission of the first probe packet and the received response of the ICMP packet.
snRtlpTraceRouteResultRoundTri pTime2 brcdIp.1.2.2.10.2.1.1.4 Syntax: Time ticks	Read-only	Shows the round trip time between the transmission of the second probe and the received response of the ICMP packet.

## IP forwarding cache table

The IP forwarding cache provides a fast-path mechanism for forwarding IP packets. The cache contains entries for IP destinations.

Name, OID, and Syntax	Access	Description
snRtlpFwdCacheTable brcdIp.1.2.2.11	None	IP forwarding cache table.
snRtlpFwdCacheIndex brcdIp.1.2.2.11.1.1 Syntax: Integer32	Read-only	An index in the IP Forwarding Cache Table for this entry.
snRtlpFwdCacheIp brcdIp.1.2.2.11.1.2 Syntax: IpAddress	Read-only	Shows the IP address of a forwarding cache station.
snRtlpFwdCacheMac brcdIp.1.2.2.11.1.3 Syntax: OCTET STRING	Read-only	Shows the MAC address of a forwarding cache station. This object has six octets.
snRtlpFwdCacheNextHopIp brcdIp.1.2.2.11.1.4 Syntax: IpAddress	Read-only	Indicates the IP address of the Layer 3 switch for the next hop.
snRtlpFwdCacheOutgoingPort brcdIp.1.2.2.11.1.5 Syntax: Integer	Read-only	Specifies the outgoing port to which packets will be forwarded. Valid values: 0 – 3900. A value of zero indicates that there is no outgoing port for this entry. Non-zero value has the following meaning: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11 – Slot number.</li> </ul> For virtual Layer 3 switch interface, slot number is 15. Port number is the virtual Layer 3 switch port number, which is a value from 1 – 60.
snRtlpFwdCacheType brcdIp.1.2.2.11.1.6 Syntax: Integer	Read-only	Indicates the type of entry this is: <ul style="list-style-type: none"> <li>• dynamic(1)</li> <li>• permanent(2)</li> </ul>

## 14 Trace route group

Name, OID, and Syntax	Access	Description
snRtlpFwdCacheAction brcdIp.1.2.2.11.1.7 Syntax: Integer	Read-only	Indicates the action taken with this entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• forward(2)</li> <li>• forUs(3)</li> <li>• waitForArp(4)</li> <li>• complexFilter(5)</li> <li>• icmpDeny(6)</li> <li>• dropPacket(7)</li> </ul>
snRtlpFwdCacheFragCheck brcdIp.1.2.2.11.1.8 Syntax: Integer	Read-only	Indicates if fragmentation-needed is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p><b>NOTE:</b> Devices cannot forward the packet without fragmenting it.</p>
snRtlpFwdCacheSnapHdr brcdIp.1.2.2.11.1.9 Syntax: Integer	Read-only	Indicates if Ethernet SNAP (also called IEEE 802.3) encapsulation is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snRtlpFwdCacheVlanId brcdIp.1.2.2.11.1.10 Syntax: Integer32	Read-only	Shows the VLAN ID of an IP Forwarding Cache Table entry. A value of zero indicates that no VLAN is associated with this entry.
snRtlpFwdCacheOutgoingIf brcdIp.1.2.2.11.1.11 Syntax: Integer	Read-only	Shows the outgoing interface that will be used to forward packets. An value of zero indicates that no outgoing interface is associated with this entry.

## IP AS-Path access list table

The IP forwarding cache provides a fast-path mechanism for forwarding IP packets. The cache contains entries for IP destinations.

Name, OID, and Syntax	Access	Description
snIpAsPathAccessListTable brcdIp.1.2.2.12	None	The IP AS-Path access list table.
snIpAsPathAccessListIndex brcdIp.1.2.2.12.1.1 Syntax: Integer32	Read-only	The table index for a filter entry.
snIpAsPathAccessListSequence brcdIp.1.2.2.12.1.2 Syntax: Integer32	Read-write	The table sequence index for a filter entry.
snIpAsPathAccessListAction brcdIp.1.2.2.12.1.3 Syntax: Integer	Read-write	The action to take if the BGP address matches with this filter.

Name, OID, and Syntax	Access	Description
snIpAsPathAccessListRegEx pression brcdIp.1.2.2.12.1.4 Syntax: Octet String	Read-write	Autonomous system in the filter using a regular expression. Each character of the regular expression string is represented by one octet.
snIpAsPathAccessListRowSt atus brcdIp.1.2.2.12.1.5 Syntax: Integer	Read-write	This object is used to create and delete row in the table and control if they are used. The values that can be written are: <ul style="list-style-type: none"> <li>delete (3) - Deletes the row</li> <li>create (4) - Creates a new row</li> <li>modify (5) - Modifies an existing row</li> </ul> If the row exists, then a SET with value of create (4) returns error 'badvalue'. Deleted rows go away immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>nosuch (0) - No such row</li> <li>invalid (1) - Setting it to 'invalid' has the effect of rendering it inoperative</li> <li>valid (2) - The row exists and is valid</li> </ul>

## IP community list table

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and Syntax	Access	Description
snIpCommunityListTable brcdIp.1.2.2.13	None	The IP community list table.
snIpCommunityListIndex brcdIp.1.2.2.13.1.1 Syntax: Integer	Read-only	An index for an entry in the table.
snIpCommunityListSequence brcdIp.1.2.2.13.1.2 Syntax: Integer	Read-only	Identifies the sequence of this entry in this table.
snIpCommunityListAction brcdIp.1.2.2.13.1.3 Syntax: Integer	Read-write	Determines what action to take if the address in the packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpCommunityListCommNum brcdIp.1.2.2.13.1.4 Syntax: OCTET STRING	Read-write	Specifies the community number. This is a number from 1 to 0xFFFFFFFF. There are 20 numbers. Each number is represented by four octets.
snIpCommunityListInternet brcdIp.1.2.2.13.1.5 Syntax: Integer	Read-write	Indicates if the community is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snIpCommunityListNoAdvertise brcdIp.1.2.2.13.1.6 Syntax: Integer	Read-write	Indicates if routes will not be advertised to any internal or external peer: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>

## 14 Trace route group

Name, OID, and Syntax	Access	Description
snIpCommunityListNoExport brcdIp.1.2.2.13.1.7 Syntax: Integer	Read-write	Determines if the route will not be advertised to an EBGP peer: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpCommunityListRowStatus brcdIp.1.2.2.13.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row</li> <li>create(4) – Creates a new row</li> <li>modify(5) – Modifies an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snIpCommunityListLocalAs brcdIp.1.2.2.13.1.9 Syntax: Integer	Read-write	Indicates if this route will be sent to peers (advertised) in other sub-autonomous systems within the local confederation: <ul style="list-style-type: none"> <li>false(0) – Do not advertise this route to an external system.</li> <li>true(1) – Advertise this route.</li> </ul>

## IP prefix list table

An IP prefix list specifies a list of networks. When you apply an IP prefix list to a neighbor, the Layer 3 switch sends or receives only a route whose destination is in the IP prefix list. You can configure up to 100 prefix lists. The software interprets the prefix lists in sequential order, beginning with the lowest sequence number.

Name, OID, and Syntax	Access	Description
snIpPrefixListTable brcdIp.1.2.2.14	None	IP prefix list table.
snIpPrefixListName brcdIp.1.2.2.14.1.1 Syntax: OCTET STRING	Read-only	Specifies the name of the prefix list. This name can be used when applying the prefix list to a neighbor. It is an octet string; each character of the name is represented by one octet. There can be up to 32 octets for this name.
snIpPrefixListSequence brcdIp.1.2.2.14.1.2 Syntax: Integer32	Read-only	Shows the sequence of an entry in the table. There can be up to 100 prefix list entries. If a sequence number is not specified, then entries are numbered in increments of 5, beginning with prefix list entry 5. Incoming or outgoing routes are matched against the entries in the IP prefix list in numerical order, beginning with the lowest sequence number.
snIpPrefixListDesc brcdIp.1.2.2.14.1.3 Syntax: OCTET STRING	Read-write	Specifies the description of the prefix. This description is in an octet string; each character in the description is represented by one octet. There can be up to 80 octets in the description.
snIpPrefixListAction brcdIp.1.2.2.14.1.4 Syntax: Integer	Read-write	Indicates what to do with the route if it matches this entry: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snIpPrefixListAddr brcdIp.1.2.2.14.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the prefix.
snIpPrefixListMask brcdIp.1.2.2.14.1.6 Syntax: IpAddress <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the number of bits in the prefix network mask.
snIpPrefixListGeValue brcdIp.1.2.2.14.1.7 Syntax: Integer	Read-write	Specifies that the prefix is greater than the value of the <a href="#">"snIpPrefixListMask"</a> object. Valid values: 0 – 32
snIpPrefixListLeValue brcdIp.1.2.2.14.1.8 Syntax: Integer	Read-write	Specifies that the prefix is less than the value of the <a href="#">"snIpPrefixListMask"</a> object. Valid values: 0 – 32
<p><b>NOTE:</b> You can specify a range of length for prefixes that are more specific than the values for the <a href="#">"snIpPrefixListAddr"</a> and <a href="#">"snIpPrefixListMask"</a> objects. The <i>&lt;ge-value&gt;</i> or <i>&lt;le-value&gt;</i> you specify must meet the following condition:  <math>length &lt; ge\text{-}value \leq le\text{-}value \leq 32</math></p> <p>If a value for <a href="#">"snIpPrefixListGeValue"</a> is specified, then the mask-length range is from the value of <a href="#">"snIpPrefixListGeValue"</a> to 32.</p> <p>If a value for <a href="#">"snIpPrefixListLeValue"</a> is specified, then mask-length range is from length to the value of <a href="#">"snIpPrefixListLeValue"</a>.</p> <p>If no value is specified for either the less than or greater than objects, then routes must exactly match the prefixes on the list.</p>		
snIpPrefixListRowStatus brcdIp.1.2.2.14.1.9 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row</li> <li>create(4) – Creates a new row</li> <li>modify(5) – Modifies an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snIpPrefixListLength brcdIp.1.2.2.14.1.10 Syntax: Integer32	Read-write	The length of the IP prefix's mask.

## IP AS-Path access list string table

AS-Path is a list of the other ASs through which a route passes. BGP4 routers can use the AS-Path to detect and eliminate routing loops. The IP AS-Path access list string table contains filters that are used to deny or permit updates received from BGP4 neighbors.

Name, OID, and Syntax	Access	Description
snIpAsPathAccessListStringTable brcdIp.1.2.2.16	None	IP AS-Path access list string table.
snIpAsPathAccessListStringName brcdIp.1.2.2.16.1.1 Syntax: DisplayString	Read-only	An index for the entry in the table.
snIpAsPathAccessListStringSequence brcdIp.1.2.2.16.1.2 Syntax: Integer32	Read-only	The sequence index for this entry in this table.
snIpAsPathAccessListStringAction brcdIp.1.2.2.16.1.3 Syntax: Integer	Read-write	Determines what to do with the packet if its address matches this entry: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpAsPathAccessListStringRegularExpression brcdIp.1.2.2.16.1.4 Syntax: Integer	Read-write	Specifies the AS-Path information that will be permitted or denied. This object contains a regular expression. Each character of the regular expression string is represented by one octet.
snIpAsPathAccessListStringRowStatus brcdIp.1.2.2.16.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are <ul style="list-style-type: none"> <li>delete(3) – Deletes the row</li> <li>create(4) – Creates a new row</li> <li>modify(5) – Modifies an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are deleted immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IP community list string table

This table contains the list of community strings used.

Name, OID, and Syntax	Access	Description
snIpCommunityListStringTable brcdIp.1.2.2.17	None	IP community list string table.
snIpCommunityListStringName brcdIp.1.2.2.17.1.1 Syntax: OCTET STRING	Read-only	An index for an entry in the table. This object can have up to 32 octets.



Name, OID, and Syntax	Access	Description
snIpcCommunityListStringSequence brcdIp.1.2.2.17.1.2 Syntax: Integer32	Read-only	Indicates the sequence of this entry in the table.
snIpcCommunityListStringAction brcdIp.1.2.2.17.1.3 Syntax: Integer	Read-write	Indicates the action to take if the community string on the packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpcCommunityListStringCommunity brcdIp.1.2.2.17.1.4 Syntax: Integer	Read-write	Shows the community string's number, represented by four octets. This number can be from 1 to 0xFFFFFFFF. There can be up to 20 community string numbers.
snIpcCommunityListStringInternet brcdIp.1.2.2.17.1.5 Syntax: Integer	Read-write	Indicates if the community is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snIpcCommunityListStringNoAdvertise brcdIp.1.2.2.17.1.6 Syntax: Integer	Read-write	Indicates the community string will not be advertised to any internal or external peers: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpcCommunityListStringNoExport brcdIp.1.2.2.17.1.7 Syntax: Integer	Read-write	Indicates if this route is not advertised as an EBGp peer: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpcCommunityListStringRowStatus brcdIp.1.2.2.17.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) - Delete the row</li> <li>create(4) - Create a new row</li> <li>modify(5) - Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) - No such row</li> <li>invalid(1) - Row is inoperative</li> <li>valid(2) - Row exists and is valid</li> </ul>
snIpcCommunityListStringLocalAS brcdIp.1.2.2.17.1.9 Syntax: Integer	Read-write	Determines if this route will be sent to peers in other sub autonomous systems within the local confederation. Do not advertise this route to an external system.
snIpcCommunityListStringType brcdIp.1.2.2.17.1.10 Syntax: Integer	Read-write	Displays the type of the community list, whether standard or extended.
snIpcCommunityListStringRegExpr brcdIp.1.2.2.17.1.11 Syntax: DisplayString	Read-write	This will display the regular expression string for extended community list. This object returns the value NULL for standard community list.

## 14 Trace route group

# Power Over Ethernet MIB

## In this chapter

- [Power Over Ethernet global objects](#) ..... 233
- [Power Over Ethernet port table](#) ..... 233
- [Power over module table](#) ..... 234
- [POE unit table](#) ..... 235

## Power Over Ethernet global objects

The following objects apply globally to FastIron X Series Power Over Ethernet (POE) devices. The information in these objects is available in the output of the **show inline power** CLI command.

Name, OID, and syntax	Access	Description
snAgentPoeGblPowerCapacityTotal brcdIp.1.1.2.14.1.1 Syntax: Unsigned32	Read-only	This object shows the total inline power capacity available in the device. The inline power capacity is measured in milliwatts.
snAgentPoeGblPowerCapacityFree brcdIp.1.1.2.14.1.2 Syntax: Unsigned32	Read-only	This object shows the inline power capacity currently available in the device that is unallocated. The inline power capacity is measured in milliwatts.
snAgentPoeGblPowerAllocationsRequestsHonored brcdIp.1.1.2.14.1.3 Syntax: Unsigned32	Read-only	This object shows the number of times the inline power allocations requests were honored.

## Power Over Ethernet port table

The following table presents information about the FastIron X-Series POE ports.

Name, OID, and syntax	Access	Description
snAgentPoePortNumber brcdIp.1.1.2.14.2.2.1.1 Syntax: InterfaceIndex	Read-only	The port number in the ifIndex value.

Name, OID, and syntax	Access	Description
snAgentPoePortControl brcdIp.1.1.2.14.2.2.1.2 Syntax: Integer	Read-create	Powers on or off the inline power on a port. If a port does not have inline power capability, reading this object returns other(1). Valid values are: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• disable(2)</li> <li>• enable(3)</li> <li>• enableLegacyDevice(4)</li> </ul>
snAgentPoePortWattage brcdIp.1.1.2.14.2.2.1.3 Syntax: Integer32	Read-create	Adjusts the inline power wattage. Valid values are from 1000 through 15400(IEEE802_3AF)/30000(IEEE802_3AT). Each unit is in milliwatts. This object can only be set after snSwlfnLinePowerControl has been set to "enable(3)" or "enableLegacyDevice(4)". If a port does not have inline power capability, reading this object returns an undefined value.
snAgentPoePortClass brcdIp.1.1.2.14.2.2.1.4 Syntax: Integer32	Read-create	Adjusts the inline power class. Valid values are from 0 through 3(IEEE802_3AF)/4(IEEE802_3AT). This object can only be set after snSwlfnLinePowerControl has been set to "enable(3)" or "enableLegacyDevice(4)". If a port does not have inline power capability, reading this object returns an undefined value.
snAgentPoePortPriority brcdIp.1.1.2.14.2.2.1.5 Syntax: Integer	Read-create	Shows the inline power allocation priority for the power device: <ul style="list-style-type: none"> <li>• invalid(0) - Not a POE port</li> <li>• critical(1)</li> <li>• high(2)</li> <li>• low(3)</li> <li>• medium(4)</li> <li>• other(5)</li> </ul>
snAgentPoePortConsumed brcdIp.1.1.2.14.2.2.1.6 Syntax: Integer32	Read-only	Amount of inline power consumed by the port. Each unit is in milliwatts.
snAgentPoePortType brcdIp.1.1.2.14.2.2.1.7 Syntax: DisplayString	Read-only	Inline power device type: 802.3af, 802.3at, or legacy device.

## Power over module table

The following table shows the configuration of modules on the FastIron X series devices. The information in this table is available in the output of the **show module** CLI command.

Name, OID, and syntax	Access	Description
snAgentPoeModuleNumber brcdIp.1.1.2.14.3.1.1.1 Syntax: Unsigned32	Read-only	This object shows the POE module number.

Name, OID, and syntax	Access	Description
snAgentPoeModuleBudget brcdIp.1.1.2.14.3.1.1.2 Syntax: Unsigned32	Read-create	This object shows the module power budget in watts.
snAgentPoeModuleMaxPDTypeSupport brcdIp.1.1.2.14.3.1.1.3 Syntax: Integer <b>NOTE:</b> This object is supported only on the FastIron SuperX devices.	Read-only	This object shows the POE module type that is capable to support the Power Device (PD) type: <ul style="list-style-type: none"> <li>ieee802dot3af(0) = Supports only ieee802dot3af modules.</li> <li>ieee802dot3at(1) = Also called POE plus type. This module can support ieee802.3at and ieee802.3af.</li> </ul>

## POE unit table

The following table provides POE information for each unit on a stack. Only the unit that has POE capability is displayed in a table row. The information in these objects is available in the output of the **show inline power** CLI command for a POE device in a stack.

Name, OID, and syntax	Access	Description
snAgentPoeUnitTable brcdIp.1.1.2.14.4.1	None	POE unit table.
snAgentPoeUnitIndex brcdIp.1.1.2.14.4.1.1.1 Syntax: Unsigned32	Read-only	The index for the POE unit table.
snAgentPoeUnitPowerCapacityTotal brcdIp.1.1.2.14.4.1.1.2 Syntax: Unsigned32	Read-only	This object shows the total inline power capacity available on a device. Inline power capacity is measured in milliwatts.
snAgentPoeUnitPowerCapacityFree brcdIp.1.1.2.14.4.1.1.3 Syntax: Unsigned32	Read-only	This object shows the unallocated inline power capacity currently available on a device. Inline power capacity is measured in milliwatts.
snAgentPoeUnitPowerAllocationsRequestsHonored brcdIp.1.1.2.14.4.1.1.4 Syntax: Unsigned32	Read-only	This object shows number of times the inline power allocation requests were honored on the device.



# POS MIB Definition

## In this chapter

- [Packet port information table](#) ..... 237
- [POS MIB information table](#) ..... 241
- [POS PPP group](#) ..... 243
- [POS cHDLC group](#) ..... 244

## Packet port information table

Packet over SONET (POS) is the serial transmission of data over SONET frames through the use of the Point-to-Point Protocol (PPP). The POS modules allow direct connection to interfaces within SONET. POS is a transport technology that encapsulates packet data, such as an IP datagram, directly into SONET.

The POS modules are available on NetIron Internet Backbone routers and BigIron Layer 3 switches with redundant management modules.

The following table presents information about POS ports.

---

### NOTE

The following table is not supported on the Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

Name, OID, and syntax	Access	Description
snPOSInfoTable brcdIp.1.2.14.1.1	None	POS port information table.
snPOSInfoPortNum brcdIp.1.2.14.1.1.1.1 Syntax: Integer	Read-only	The chassis slot and port number: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number</li> <li>• Bit 8 to bit 11 – Slot number (for chassis devices only)</li> </ul>
snPOSIfIndex brcdIp.1.2.14.1.1.1.2 Syntax: Integer	Read-only	Identifies the instance of the ifIndex object as defined in RFC 1213 and RFC 1573.
snPOSDescr brcdIp.1.2.14.1.1.1.3 Syntax: DisplayString	Read-only	Description of the chassis slot and port.
snPOSName brcdIp.1.2.14.1.1.1.4 Syntax: DisplayString	Read-write	Name of the port. Valid values: Up to 255 characters

Name, OID, and syntax	Access	Description
snPOSInfoSpeed brcdIp.1.2.14.1.1.1.5 Syntax: Integer	Read-write	The bandwidth of the interface, which can be one of the following: <ul style="list-style-type: none"> <li>s155000(1) bps</li> <li>s622000(2) bps</li> <li>other(3)</li> <li>s2488000(4) bps</li> </ul>
snPOSInfoAdminStatus brcdIp.1.2.14.1.1.1.6 Syntax: Integer	Read-write	The desired state of the interface, which can be one of the following: <ul style="list-style-type: none"> <li>up(1) – The port is ready to pass packets.</li> <li>down(2) – The port is not ready to pass packets.</li> <li>testing(3) – The port is in test mode. No packets can be passed.</li> </ul>
snPOSInfoLinkStatus brcdIp.1.2.14.1.1.1.7 Syntax: Integer	Read-only	The current operational state of the link, which can be one of the following: <ul style="list-style-type: none"> <li>up(1) – The port is ready to pass packets.</li> <li>down(2) – The port is not ready to pass packets.</li> <li>testing(3) – The port is in test mode. No packets can be passed.</li> </ul>
snPOSInfoClock brcdIp.1.2.14.1.1.1.8 Syntax: Integer	Read-write	The clock source, which can be one of the following: <ul style="list-style-type: none"> <li>internal(1) – The interface is using the clock on the POS module.</li> <li>line(2) – The interface is using the clock source supplied on the network.</li> </ul> Default: internal(1)
snPOSInfoLoopBack brcdIp.1.2.14.1.1.1.9 Syntax: Integer	Read-write	The loopback state of the interface. The loopback state can be one of the following: <ul style="list-style-type: none"> <li>line(1) – The loopback path consists of both this POS interface and the POS interface at the remote end of the link. Use this mode to check the POS interface along the link.</li> <li>internal(2) – The loopback path consists only of the POS circuitry on this interface. Use this mode to check the POS circuitry.</li> <li>none(3) – The interface is not operating in loopback mode.</li> </ul>
snPOSInfoScrambleATM brcdIp.1.2.14.1.1.1.10 Syntax: Integer	Read-write	The state of the ATM scramble mode, which can be one of the following: <ul style="list-style-type: none"> <li>disabled(0) – Scrambling is disabled.</li> <li>enabled(1) – Scrambling of the Synchronous Payload Envelope (SPE) is enabled. Data in the SONET packet is scrambled for security.</li> </ul> Default: disabled(0)
snPOSInfoFraming brcdIp.1.2.14.1.1.1.11 Syntax: Integer	Read-write	The frame type used on the interface. The frame type can be one of the following: <ul style="list-style-type: none"> <li>sonet(1) – Synchronous Optical Network.</li> <li>sdh(2) – Synchronous Digital Hierarchy.</li> </ul> Default: sonet(1)
snPOSInfoCRC brcdIp.1.2.14.1.1.1.12 Syntax: Integer	Read-write	The length of the CRC field in packets transmitted on the interface. The length can be one of the following: <ul style="list-style-type: none"> <li>crc32bits(1) – The field is 8 bits long.</li> <li>crc16bits(2) – The field is 16 bits long.</li> </ul> Default: crc32bits(1)



Name, OID, and syntax	Access	Description
snPOSInfoKeepAlive brcdIp.1.2.14.1.1.1.13 Syntax: Integer	Read-write	The time interval when keepalive messages are sent. Default: 10 seconds
snPOSInfoFlagC2 brcdIp.1.2.14.1.1.1.14 Syntax: Integer	Read-write	The value of the c2 flag in the SONET headers of packets transmitted by the interface. The c2 flag identifies the payload type of the packets transmitted on this interface. Default: 0xcf, which means that the payload is SONET or SDH.
snPOSInfoFlagJ0 brcdIp.1.2.14.1.1.1.15 Syntax: Integer	Read-write	The value of the j0 flag in the SONET headers of packets transmitted by the interface. This flag sets the trace byte, which is used to trace the origin of an STS-1 frame on a SONET network. Default: 0xcc
snPOSInfoFlagH1 brcdIp.1.2.14.1.1.1.16 Syntax: Integer	Read-write	The value of the h1 flag in the SONET headers of packets transmitted by the interface. This flag sets the H1 pointer, which is used to indicate where the Synchronous Payload Envelope (SPE) starts within the packet. The SPE contains the packet's payload: <ul style="list-style-type: none"> <li>• 0x00 – The pointer for SONET frames.</li> <li>• 0x02 – The pointer for SDH frames.</li> </ul> Default: 0x00
snPOSStatsInFrames brcdIp.1.2.14.1.1.1.17 Syntax: Counter	Read-only	The total number of packets received on the interface.
snPOSStatsOutFrames brcdIp.1.2.14.1.1.1.18 Syntax: Counter	Read-only	The total number of packets transmitted out of the interface.
snPOSStatsAlignErrors brcdIp.1.2.14.1.1.1.19 Syntax: Counter	Read-only	The number of packets that contained frame alignment errors.
snPOSStatsFCSErrors brcdIp.1.2.14.1.1.1.20 Syntax: Counter	Read-only	The number of packets that contained Frame Check Sequence (FCS) errors.
snPOSStatsFrameTooLong s brcdIp.1.2.14.1.1.1.21 Syntax: Counter	Read-only	The number of packets that were longer than the configured MTU.
snPOSStatsFrameTooShort s brcdIp.1.2.14.1.1.1.22 Syntax: Counter	Read-only	The number of packets that were shorter than the minimum valid length.
snPOSStatsInDiscard brcdIp.1.2.14.1.1.1.23 Syntax: Counter	Read-only	The number of inbound packets that were discarded to prevent them from being delivered to a higher-layer protocol, even though no errors had been detected. For example, a packet may be discarded to free up buffer space.
snPOSStatsOutDiscard brcdIp.1.2.14.1.1.1.24 Syntax: Counter	Read-only	The number of outbound packets that were discarded to prevent them from being transmitted, even though they contain no errors. For example, a packet may be discarded to free up buffer space.

Name, OID, and syntax	Access	Description
snPOSInOctets brcdIp.1.2.14.1.1.1.25 Syntax: OCTET STRING	Read-only	The total number of packets in octets that were received on the interface, including framing characters. This object is a 64-bit counter of the ifInOctets object, defined in RFC 1213. The octet string is in big-endian byte order.
snPOSOutOctets brcdIp.1.2.14.1.1.1.26 Syntax: OCTET STRING	Read-only	The total number of packets in octets that were transmitted out of the interface, including framing characters. This object is a 64-bit counter of the ifOutOctets object, defined in RFC 1213. The octet string is in big-endian byte order.
snPOSStatsInBitsPerSec brcdIp.1.2.14.1.1.1.27 Syntax: Gauge	Read-only	The number of bits per second received on the interface over a five-minute interval.
snPOSStatsOutBitsPerSec brcdIp.1.2.14.1.1.1.28 Syntax: Gauge	Read-only	The number of bits per second transmitted out of the interface over a five-minute interval.
snPOSStatsInPktsPerSec brcdIp.1.2.14.1.1.1.29 Syntax: Gauge	Read-only	The number of packets per second received on the interface over a five-minute interval.
snPOSStatsOutPktsPerSec brcdIp.1.2.14.1.1.1.30 Syntax: Gauge	Read-only	The number of packets per second transmitted out of the interface over a five-minute interval.
snPOSStatsInUtilization brcdIp.1.2.14.1.1.1.31 Syntax: Integer	Read-only	The network utilization by incoming traffic in hundredths of a percent over a five-minute interval. <b>NOTE:</b> This object is not supported.
snPOSStatsOutUtilization brcdIp.1.2.14.1.1.1.32 Syntax: Integer	Read-only	The network utilization by outgoing traffic in hundredths of a percent over a five-minute interval. <b>NOTE:</b> This object is not supported.
snPOSTagType brcdIp.1.2.14.1.1.1.33 Syntax: Integer	Read-only	Shows whether or not the port has a VLAN tag: <ul style="list-style-type: none"> <li>tagged(1) – The port has a VLAN tag. This port can have multiple VLANs.</li> <li>untagged(2) – The port is not tagged.</li> </ul>
snPOSStatsB1 brcdIp.1.2.14.1.1.1.34 Syntax: Counter	Read-only	Shows the number of received frames that have parity errors at the section layer of the SONET link.
snPOSStatsB2 brcdIp.1.2.14.1.1.1.35 Syntax: Counter	Read-only	Shows the number of received frames that have parity errors at the line layer of the SONET link.
snPOSStatsB3 brcdIp.1.2.14.1.1.1.36 Syntax: Counter	Read-only	Shows the number of received frames that have parity errors at the path layer of the SONET link.
snPOSStatsAIS brcdIp.1.2.14.1.1.1.37 Syntax: Counter	Read-only	Shows the number of Alarm Indicator Signals (AISs) that were received by the interface.
snPOSStatsRDI brcdIp.1.2.14.1.1.1.38 Syntax: Counter	Read-only	Shows the number of Remote Defect Indicator (RDI) signals that were received by the interface.

Name, OID, and syntax	Access	Description
snPOSStatsLOP brcdIp.1.2.14.1.1.1.39 Syntax: Counter	Read-only	Indicates a loss of pointer (LOP) that results from an invalid path pointer or if an excessive number of new data flags have been enabled.
snPOSStatsLOF brcdIp.1.2.14.1.1.1.40 Syntax: Counter	Read-only	Shows how many times the interface experienced out of frame alignment problems, which is also called a loss of frame (LOF) condition.
snPOSStatsLOS brcdIp.1.2.14.1.1.1.41 Syntax: Counter	Read-only	Indicates the number of times the interface experienced a loss of signal (LOS). With LOS, incoming signals are all zeros during a 100 microsecond period.

## POS MIB information table

The following table presents information about the POS session.

Name, OID, and syntax	Access	Description
snPOSInfo2Table brcdIp.1.2.14.1.2	None	This object describes the POS MIB information table.
snPOSInfo2Clock brcdIp.1.2.14.1.2.1.1 Syntax: Integer	Read-write	This object describes the clock source for the POS interface: <ul style="list-style-type: none"> <li>internal(1) - Internal source.</li> <li>line(2) - Clocking is derived from the line.</li> </ul> Default Value: internal(1)
snPOSInfo2ScrambleATM brcdIp.1.2.14.1.2.1.2 Syntax: POSStatus	Read-write	ATM style scrambling for the POS interface: <ul style="list-style-type: none"> <li>disabled(0) - Scrambling is disabled.</li> <li>enabled(1) - Scrambling is enabled.</li> </ul> Default Value: disabled(0)
snPOSInfo2CRC brcdIp.1.2.14.1.2.1.3 Syntax: Integer	Read-write	Length of Cyclic Redundancy Check (CRC) on the POS interface: <ul style="list-style-type: none"> <li>crc32bits(1) - 32 bits</li> <li>crc16bits(2) - 16 buts</li> </ul> Default Value: crc32bits(1)
snPOSInfo2KeepAlive brcdIp.1.2.14.1.2.1.4 Syntax: Unsigned32	Read-write	This object describes the keepalive timer for the POS interface in seconds. Valid values: 0 - 65535 seconds Default: 10 seconds
snPOSInfo2FlagC2 brcdIp.1.2.14.1.2.1.5 Syntax: Unsigned32	Read-write	The C2 flag. Valid values: 0 - 255

Name, OID, and syntax	Access	Description
snPOSInfo2SSM brcdIp.1.2.14.1.2.1.6 Syntax: Integer	Read-write	<p>The Synchronization Status Message (SSM) is sent over the SONET/SDH line to tell the other end about the quality of the clock being sent over the line:</p> <ul style="list-style-type: none"> <li>t1 SonetPrimaryReferenceSource(1) - SONET Primary Reference Source</li> <li>t1 SonetTraceabilityUnknown(2) - SONET Traceability Unknown</li> <li>t1 SonetStratum2Traceable(3) - SONET Stratum 2 Traceable</li> <li>t1 SonetTransitNodeClock(4) - SONET Transit Node Clock</li> <li>t1 SonetStratum3eTraceable(5) - SONET Stratum 3e Traceable</li> <li>t1 SonetStratum3Traceable(6) - SONET Stratum 3 Traceable</li> <li>t1 SonetMinClockTraceable(7) - SONET Minimum Clock Traceable</li> <li>t1 SonetDus(8) - SONET Do not Use for Synchronization</li> <li>e1 SdhTraceabilityUnknown(9) - SDH Traceability Unknown</li> <li>e1 SdhSsmTransitNodeClock-g812(10) - SDH Transit Node Clock G812</li> <li>e1 SdhDus(11) - SDH Do not Use for Synchronization</li> <li>e1 SdhSsmPrimaryReferenceClock-g811(12) - SDH Primary Reference Clock G811</li> <li>e1 SdhSsmLocalG812(13) - SDH Local G812</li> <li>e1 SdhSsmSyncEquipmentTimingSource(14) - SDH Synchronization Equipment Timing Source</li> </ul> <p>Default: t1 SonetTraceabilityUnknown(2)</p>
snPOSInfo2Encapsulation brcdIp.1.2.14.1.2.1.7 Syntax: Integer	Read-write	<p>Layer 2 encapsulation on the POS interface:</p> <ul style="list-style-type: none"> <li>ppp(1) - Point to Point Protocol (PPP)</li> <li>chdlc(2) - Cisco High-level Data Link Control (cHDLC)</li> </ul>
snPOSInfo2AlarmMonitoring brcdIp.1.2.14.1.2.1.8 Syntax: Integer	Read-write	<p>Alarm monitoring on the POS interface:</p> <ul style="list-style-type: none"> <li>off(0) - Alarm monitoring is off.</li> <li>on(1) - Alarm monitoring is on.</li> </ul> <p>Default: on(1)</p>
snPOSInfo2OverheadJ0Expected Message brcdIp.1.2.14.1.2.1.9 Syntax: Octet String	Read-write	Overhead J0 expected message.
snPOSInfo2OverheadJ0TransmitM essage brcdIp.1.2.14.1.2.1.10 Syntax: Octet String	Read-write	Overhead J0 transmit message.
snPOSInfo2OverheadJ1Expected Message brcdIp.1.2.14.1.2.1.11 Syntax: Octet String	Read-write	Overhead J1expected message.

Name, OID, and syntax	Access	Description
snPOSInfo2OverheadJ1MessageLength brcdIp.1.2.14.1.2.1.12 Syntax: Integer	Read-write	Overhead J1 length of message: <ul style="list-style-type: none"> <li>• s16(16) - 16 bytes</li> <li>• s64(64) - 64 bytes</li> </ul> Default Value: s64(64)
snPOSInfo2OverheadJ1TransmitMessage brcdIp.1.2.14.1.2.1.13 Syntax: Octet String	Read-write	Overhead J1 transmit message.

## POS PPP group

If the [snPOSInfo2Encapsulation](#) object is set to Point to Point Protocol (PPP), the following table provides information on the states of various control protocols.

Name, OID, and syntax	Access	Description
snPOSPPPTable brcdIp.1.2.14.1.3	None	The POS PPP table.
snPOSPPP-LCP brcdIp.1.2.14.1.3.1 Syntax: DisplayString	Read-only	The PPP link control protocol state.
snPOSPPP-IPCP brcdIp.1.2.14.1.3.2 Syntax: DisplayString	Read-only	The PPP IP control protocol state.
snPOSPPP-IPv6CP brcdIp.1.2.14.1.3.3 Syntax: DisplayString	Read-only	The PPP IPv6 control protocol state.
snPOSPPP-OSINLCP brcdIp.1.2.14.1.3.4 Syntax: DisplayString	Read-only	The PPP OSI network layer control protocol state.
snPOSPPP-MPLSCP brcdIp.1.2.14.1.3.5 Syntax: DisplayString	Read-only	The PPP MPLS control protocol state.

## POS cHDLC group

If the [snPOSInfo2Encapsulation](#) object is set to Cisco High-level Data Link Control (cHDLC), the following table provides information on various cHDLC parameters.

Name, OID, and syntax	Access	Description
snPOScHDLCTable brcdIp.1.2.14.1.4	None	The POS cHDLC group table.
snPOScHDLCLineState brcdIp.1.2.14.1.4.1 Syntax: Integer	Read-only	The state of the POS cHDLC line: <ul style="list-style-type: none"> <li>• down(0)</li> <li>• up(1)</li> <li>• unknown(2)</li> </ul>
snPOScHDLCInLoopback brcdIp.1.2.14.1.4.2 Syntax: Integer	Read-only	Indicates if cHDLC in loopback is used: <ul style="list-style-type: none"> <li>• no(0)</li> <li>• yes(1)</li> <li>• unknown(2)</li> </ul>
snPOScHDLCMySeq brcdIp.1.2.14.1.4.3 Syntax: Unsigned32	Read-only	The cHDLC of the device's sequence number.
snPOScHDLCMySeqSeen brcdIp.1.2.14.1.4.4 Syntax: Unsigned32	Read-only	The cHDLC of the device's sequence number that is seen.
snPOScHDLCPeerSeqSeen brcdIp.1.2.14.1.4.5 Syntax: Unsigned32	Read-only	The cHDLC peer sequence number seen.
snPOScHDLCUniqueSent brcdIp.1.2.14.1.4.6 Syntax: Unsigned32	Read-only	The unique cHDLC sent.
snPOScHDLCUniqueReceived brcdIp.1.2.14.1.4.7 Syntax: Unsigned32	Read-only	The unique cHDLC received.

# Stackable Management Group

---

## In this chapter

- [General stackable management information . . . . .](#) 245
- [Stackable management secondary switch information . . . . .](#) 246

## General stackable management information

The objects in the following table provide information about the general stacking devices.

---

### NOTE

The objects in the following table are not supported on Brocade FCX, FastIron GS, and FastIron LS stacking devices.

---

Name, OID, and syntax	Access	Description
snStackPriSwitchMode brcdIp.1.1.5.1.1 Syntax: Integer	Read-write	The stackable management primary switch mode is either enabled or disabled. <ul style="list-style-type: none"> <li>• enabled(1) - Primary switch enabled.</li> <li>• disabled(0) - Primary switch disabled.</li> </ul> Default: disabled(0)
snStackMaxSecSwitch brcdIp.1.1.5.1.2 Syntax: Integer	Read-only	The maximum number of secondary switches are allowed in the stackable management group.
snStackTotalSecSwitch brcdIp.1.1.5.1.3 Syntax: Integer	Read-only	The total number of secondary switches currently connected to the stackable management group.
snStackSyncAllSecSwitch brcdIp.1.1.5.1.4 Syntax: Integer	Read-write	Synchronize all the secondary switches in the stackable management group with the following commands: <ul style="list-style-type: none"> <li>• device(2)</li> <li>• global(3)</li> <li>• local(4)</li> </ul> The return result of the previous commands is either: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• invalid(1)</li> </ul>

Name, OID, and syntax	Access	Description
snStackSmSlotIndex brcdIp.1.1.5.1.5 Syntax: Integer	Read-write	The slot 0 is the master slot and slots 1-8 are slaves. All the slot-based MIB data can be retrieved with respect to this slot index.
snStackFmpSetProcess brcdIp.1.1.5.1.6 Syntax: Integer	Read-only	The state of the FMT set process: <ul style="list-style-type: none"> <li>normal(0) - The set process is either in an idle state or FMP-SET-SUCCESS state.</li> <li>pending(1) - The pending process is waiting for the result of an FMP-SET.</li> <li>failure(2) - The failure result of an FMP-SET.</li> </ul>

## Stackable management secondary switch information

The objects in the following table provide stackable management secondary switch information.

### NOTE

The objects in the following table are not supported on Brocade FCX, FastIron GS, and FastIron LS stacking devices.

Name, OID, and syntax	Access	Description
snStackSecSwitchTable brcdIp.1.1.5.2.1	None	If snSwGroupOperMode is configured as basic mode, which is VLAN by Port, Layer 2 switching, then this table is valid. Each VLAN switch port could have a number of VLAN IDs.
snStackSecSwitchIndex brcdIp.1.1.5.2.1.1.1	Read-only	The secondary switch index must not be greater than snStackMaxSecSwitch.
snStackSecSwitchSlotId brcdIp.1.1.5.2.1.1.2	Read-write	The secondary switch slot ID must be set before the configuration command sent from the primary switch to the secondary switch either manually or automatically. Refer to the object snStackSecSwitchCfgCmd.
snStackSecSwitchPorts brcdIp.1.1.5.2.1.1.3	Read-only	The number of ports in this secondary switch.
snStackSecSwitchEnabled brcdIp.1.1.5.2.1.1.4	Read-write	The secondary switch has been selected to the stackable management group.
snStackSecSwitchAck brcdIp.1.1.5.2.1.1.5	Read-only	The secondary switch has sent a response to the primary switch.
snStackSecSwitchMacAddr brcdIp.1.1.5.2.1.1.6	Read-only	The secondary switch physical address. The physical address represents a MAC Station.



Name, OID, and syntax	Access	Description
snStackSecSwitchSyncCmd brcdIp.1.1.5.2.1.1.7	Read-write	Synchronize the secondary switches in the stackable management group with the following commands: <ul style="list-style-type: none"> <li>• device(2)</li> <li>• global(3)</li> <li>• local(4)</li> </ul> The return result of the previous commands is either: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• invalid(1)</li> </ul>
snStackSecSwitchIpAddress brcdIp.1.1.5.2.1.1.8	Read-write	The secondary switch IP address is used for the manual command of snStackSecSwitchCfgCmd.
snStackSecSwitchSubnetMask brcdIp.1.1.5.2.1.1.9	Read-write	The secondary switch IP subnet mask is used for the manual command of snStackSecSwitchCfgCmd.
snStackSecSwitchCfgCmd brcdIp.1.1.5.2.1.1.10	Read-write	snStackSecSwitchSlotId must be set before the configuration command sent from the primary switch to the secondary switch either manually or automatically: <ul style="list-style-type: none"> <li>• auto(2)</li> <li>• manual(3)</li> </ul> The return result of the previous commands is either: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• invalid(1)</li> </ul>

## 17 Stackable Management Group

# Stacking MIB Definition

## In this chapter

- [Global objects for stacking](#) ..... 249
- [Stacking configuration unit table](#) ..... 250
- [Stacking operation unit table](#) ..... 251

## Global objects for stacking

### NOTE

This chapter presents the MIB objects for devices that support the stacking functionality. They apply to the stacking devices, such as FGS-STK, FLS-STK, and Brocade FCX devices.

Name, OID, and syntax	Access	Description
snStackingGlobalConfigState brcdIp.1.1.3.31.1.1 Syntax: Integer	Read-write	Shows the state of the stacking feature: <ul style="list-style-type: none"> <li>• none(0) - Neutral</li> <li>• enabled(1) - Stacking is enabled and can send and receive packets.</li> <li>• disabled(2) - Stacking is disabled and cannot send or receive packets.</li> </ul>
snStackingGlobalMacAddress brcdIp.1.1.3.31.1.2 Syntax: MAC address	Read-write	Management MAC address of the stacking system. This is available so you can change the management MAC address of the stack for administrative purposes; however, it is strongly recommended that this command should be used with extreme caution to prevent duplicate MAC addresses. You must reboot the system before the new MAC address takes effect.  This object is mutually exclusive from enabling the persistent MAC timer.  Enter zero MAC addresses to remove the configured MAC address.
snStackingGlobalPersistentMacTimerState brcdIp.1.1.3.31.1.3 Syntax: Integer	Read-write	The configured persistent MAC timer state for the stacking feature: <ul style="list-style-type: none"> <li>• enabled(0) - The persistent MAC timer is active and configured. The persistent MAC timer is set as the default timer (60 minutes).</li> <li>• disabled(1) - Deactivate the persistent MAC timer. It will stop the use of persistent MAC addresses and use a new active stack unit's base MAC address.</li> </ul>

Name, OID, and syntax	Access	Description
snStackingGlobalPersistentMacTimer brcdIp.1.1.3.31.1.4 Syntax: Integer32	Read-write	Persistent MAC timer in minutes for the stacking system. This timer shows the number of minutes to retain the original active stack unit's base MAC address in case the active unit fails or is removed. This timer is triggered when a new active unit is elected. When the timer expires, the new active unit will change the stacking MAC address to its own base MAC address and advertise its own base MAC address to the management VLAN to update the ARP table of members. If you decide to use the new active unit's MAC address, you must enter this timer again to reactivate the persistent MAC address. Valid values are: <ul style="list-style-type: none"> <li>• 0 - Keep it forever</li> <li>• 5 to 3600 minutes</li> </ul> The default is 60 minutes.
snStackingGlobalTopology brcdIp.1.1.3.31.1.5 Syntax: Integer	Read-only	The topology of the stacking system: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• chain(2)</li> <li>• ring(3)</li> <li>• standalone(4)</li> </ul>
snStackingGlobalMode brcdIp.1.1.3.31.1.6 Syntax: Integer	Read-only	The stacking mode of the system: <ul style="list-style-type: none"> <li>• stackingMode - the system is installed with STK EEPROM represents it is in stacking mode.</li> <li>• nonStackingMode - the system is not installed with STK EEPROM represents it is not in stacking mode.</li> </ul>

## Stacking configuration unit table

Use the following table to display and configure stacking information for each unit.

Name, OID, and syntax	Access	Description
snStackingConfigUnitTable brcdIp.1.1.3.31.2.1	None	The stacking configuration table.
snStackingConfigUnitIndex brcdIp.1.1.3.31.2.1.1.1 Syntax: Integer	None	The ID of the unit in a stack.
snStackingConfigUnitPriority brcdIp.1.1.3.31.2.1.1.2 Syntax: Integer32	Read-write	The priority in active or backup election. Value can be from 0 through 255.
snStackingConfigUnitConfigStackPort brcdIp.1.1.3.31.2.1.1.3 Syntax: InterfaceIndex	Read-write	The IfIndex for the configured stacking port. If no stacking port is configured, this object displays zero and the first two 10 Gigabit ports as the default stacking ports. Enter zero to remove the configured stacking port.

Name, OID, and syntax	Access	Description
snStackingConfigUnitRowStatus brcdIp.1.1.3.31.2.1.1.4 Syntax: Integer	Read-write	This object is used to delete a row in the table and control if they are used. The following values can be written for a SET: <ul style="list-style-type: none"> <li>delete(3) - Deletes the row. Deleted rows are deleted immediately.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuchName - No such row</li> <li>other(1) - Some other cases</li> <li>valid(2) - The row exists and is valid</li> </ul>
snStackingConfigUnitType brcdIp.1.1.3.31.2.1.1.5 Syntax: DisplayString	Read-only	A description of the configured or active system type for each unit.
snStackingConfigUnitState brcdIp.1.1.3.31.2.1.1.6 Syntax: Integer	Read-only	The state of the unit: <ul style="list-style-type: none"> <li>local(1)</li> <li>remote(2)</li> <li>reserved(3)</li> <li>empty(4)</li> </ul>
snStackingConfigUnitStackPort1 brcdIp.1.1.3.31.2.1.1.7 Syntax: InterfaceIndex	Read-only	First stack port for each unit. It returns 0 if the stack port does not exist.
snStackingConfigUnitStackPort2 brcdIp.1.1.3.31.2.1.1.8 Syntax: InterfaceIndex or zero	Read-only	Second stack port for each unit. It returns 0 if the stack port does not exist.

## Stacking operation unit table

Use the following table to display information about the role and status of a unit in a stack.

Name, OID, and syntax	Access	Description
snStackingOperUnitTable brcdIp.1.1.3.31.2.2	None	Stacking operation unit table.
snStackingOperUnitIndex brcdIp.1.1.3.31.2.2.1.1 Syntax: Integer	None	ID of the unit in the stack.
snStackingOperUnitRole brcdIp.1.1.3.31.2.2.1.2 Syntax: Integer	Read-only	The role of the unit: <ul style="list-style-type: none"> <li>other(1)</li> <li>active(2)</li> <li>standby(3)</li> <li>member(4)</li> <li>standalone(5)</li> </ul>
snStackingOperUnitMac brcdIp.1.1.3.31.2.2.1.3 Syntax: MAC address	Read-only	The unit's MAC address.

Name, OID, and syntax	Access	Description
snStackingOperUnitPriority brcdlp.1.1.3.31.2.2.1.4 Syntax: Integer32	Read-only	The priority in active or backup election. Values can be from 0 through 255.
snStackingOperUnitState brcdlp.1.1.3.31.2.2.1.5 Syntax: Integer	Read-only	The state of the unit <ul style="list-style-type: none"> <li>• local(1)</li> <li>• remote(2)</li> <li>• reserved(3)</li> <li>• empty(4)</li> </ul>
snStackingOperUnitDescription brcdlp.1.1.3.31.2.2.1.6 Syntax: DisplayString	Read-only	Describes the stacking state of the unit. This object can display up to 128 characters.
snStackingOperUnitStackPort1 brcdlp.1.1.3.31.2.2.1.7 Syntax: InterfaceIndex or zero	Read-only	First stack port for the unit. It returns 0 if the stack port does not exist.
snStackingOperUnitStackPort1State brcdlp.1.1.3.31.2.2.1.8 Syntax: Integer	Read-only	The state of the first stack port state of a unit: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• up(2)</li> <li>• down(3)</li> </ul>
snStackingOperUnitStackPort2 brcdlp.1.1.3.31.2.2.1.9 Syntax: InterfaceIndex or zero	Read-only	Second stack port of a unit. It returns 0 if the stack port does not exist.
snStackingOperUnitStackPort2State brcdlp.1.1.3.31.2.2.1.10 Syntax: Integer	Read-only	The state of the second stack port state of a unit: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• up(2)</li> <li>• down(3)</li> </ul>
snStackingOperUnitNeighbor1 brcdlp.1.1.3.31.2.2.1.11 Syntax: Integer32	Read-only	The first stacking neighbor unit (left) number. If there is no neighbor unit, then it returns 0.
snStackingOperUnitNeighbor2 brcdlp.1.1.3.31.2.2.1.12 Syntax: Integer32	Read-only	The second stacking neighbor unit (right) number. If there is no neighbor unit, then it returns 0.
snStackingOperUnitImgVer brcdlp.1.1.3.31.2.2.1.13 Syntax: DisplayString	Read-only	The version of the software image running on the unit. This object can have up to 32 characters.
snStackingOperUnitBuildVer brcdlp.1.1.3.31.2.2.1.14 Syntax: DisplayString	Read-only	The version of the software build running on the unit. This object can have up to 32 characters.

# FDP MIB Defintions

## In this chapter

- [FDP interface table](#) ..... 253
- [FDP cache table](#) ..... 253
- [FDP global configuration objects](#) ..... 255
- [FDP cached address entry table](#) ..... 256

## FDP interface table

The Foundry Discovery Protocol (FDP) interface table shows whether or not the FDP is enabled on a physical interface. You can use the following table to disable or enable FDP on individual interfaces.

### NOTE

You cannot disable the Cisco Discovery Protocol (CDP) on individual interfaces.

Name, OID, and syntax	Access	Description
snFdpInterfaceTable brcdIp.1.1.3.20.1.1.1	None	The FDP interface table
snFdpInterfaceIfIndex brcdIp.1.1.3.20.1.1.1.1.1	None	Shows the ifIndex value of the local interface.
snFdpInterfaceEnable brcdIp.1.1.3.20.1.1.1.1.2 Syntax: Integer	Read-write	Determines if FDP is enabled on the interface: <ul style="list-style-type: none"> <li>• false(0) – FDP is disabled.</li> <li>• true(1) – FDP is enabled.</li> </ul> Default: true(1)
snFdpInterfaceCdpEnable brcdIp.1.1.3.20.1.1.1.1.3 Syntax: Integer	Read-write	Determines if CDP is enabled on the interface: <ul style="list-style-type: none"> <li>• false(0) – CDP is disabled.</li> <li>• true(1) – CDP is enabled.</li> </ul> Default: true(1)

## FDP cache table

Each entry in the FDP cache table contains information received from FDP or Cisco Discovery Protocol (CDP) on one interface of one device. The table is available if FDP or CDP is enabled globally. Entries appear when an FDP or CDP advertisement is received from a neighbor device. Entries are deleted when FDP or CDP is disabled on an interface or globally.

Name, OID, and syntax	Access	Description
snFdpCacheTable brcdIp.1.1.3.20.1.2.1	None	The FDP cache table.
snFdpCacheIfIndex brcdIp.1.1.3.20.1.2.1.1.1	None	Shows the ifIndex value of the local interface.
snFdpCacheDeviceIndex brcdIp.1.1.3.20.1.2.1.1.2 Syntax: Integer32	Read-only	A unique value for each device from which FDP or CDP messages are being received.
snFdpCacheDeviceId brcdIp.1.1.3.20.1.2.1.1.3 Syntax: DisplayString	Read-only	Shows a description for the device as reported in the most recent FDP or CDP message. A zero-length string indicates no Device-ID field (TLV) was reported in the most recent FDP or CDP message.
snFdpCacheAddressType brcdIp.1.1.3.20.1.2.1.1.4 Syntax: Integer	Read-only	Indicates the type of address contained in the "snFdpCacheAddress" object for this entry: <ul style="list-style-type: none"> <li>• ip(1)</li> <li>• ipx(2)</li> <li>• appletalk(3)</li> </ul>
snFdpCacheAddress brcdIp.1.1.3.20.1.2.1.1.5 Syntax: OCTET STRING	Read-only	Shows the network-layer address of the device's SNMP agent, as reported in the most recent FDP or CDP message. A device may have more than one address. This object shows the first address on the device. The format of this object depends on the value of the snFdpCacheAddressType object: <ul style="list-style-type: none"> <li>• ip(1) – 4 octets</li> <li>• ipx(2) – 10 octets: <ul style="list-style-type: none"> <li>- Octets 1-4 – Network number</li> <li>- Octets 5-10 – Host number</li> </ul> </li> <li>• appletalk(3) – 3 octets: <ul style="list-style-type: none"> <li>- Octets 1-2 – Network number</li> <li>- Octet 3 – Host number</li> </ul> </li> </ul>
snFdpCacheVersion brcdIp.1.1.3.20.1.2.1.1.6 Syntax: DisplayString	Read-only	Shows the software version running in the device as reported in the most recent FDP or CDP message.
snFdpCacheDevicePort brcdIp.1.1.3.20.1.2.1.1.7 Syntax: DisplayString	Read-only	Shows the port ID of the device as reported in the most recent FDP or CDP message. This will typically be the value of the ifName object. A zero-length string indicates no Port-ID field (TLV) was reported in the most recent FDP or CDP message.
snFdpCachePlatform brcdIp.1.1.3.20.1.2.1.1.8 Syntax: DisplayString	Read-only	Shows the device's hardware platform as reported in the most recent FDP or CDP message. A zero-length string indicates that no Platform field (TLV) was reported in the most recent FDP or CDP message.
snFdpCacheCapabilities brcdIp.1.1.3.20.1.2.1.1.9 Syntax: DisplayString	Read-only	Shows the device's functional capabilities as reported in the most recent FDP or CDP message.
snFdpCacheVendorId brcdIp.1.1.3.20.1.2.1.1.10 Syntax: Integer	Read-only	Indicates if FDP or CDP received the entry: <ul style="list-style-type: none"> <li>• fdp(1)</li> <li>• cdp(2)</li> </ul>



Name, OID, and syntax	Access	Description
snFdpCachelsAggregateVlan brcdIp.1.1.3.20.1.2.1.1.11 Syntax: Integer	Read-only	Indicates if this entry is from a neighbor device that is in an aggregated VLAN: <ul style="list-style-type: none"> <li>false(0) – It is not in an aggregated VLAN.</li> <li>true(1) – It is in an aggregate VLAN.</li> </ul>
snFdpCacheDeviceTagType brcdIp.1.1.3.20.1.2.1.1.12 Syntax: Integer	Read-only	Shows the tag type of the neighbor device that sent this entry.
snFdpCacheDevicePortVlan Mask brcdIp.1.1.3.20.1.2.1.1.13 Syntax: OCTET STRING	Read-only	Shows the port VLAN masks, in a 512-byte octet string, of the neighbor that sent this entry.
snFdpCachePortTagMode brcdIp.1.1.3.20.1.2.1.1.14 Syntax: Integer	Read-only	Shows the port tag mode on the neighbor device: <ul style="list-style-type: none"> <li>untagged(1)</li> <li>tagged(2)</li> <li>dual(3)</li> </ul>
snFdpCacheDefaultTrafficeVI anIdForDualMode brcdIp.1.1.3.20.1.2.1.1.15 Syntax: Integer32	Read-only	Shows the default traffic a VLAN ID for neighbor devices that have dual-mode ports.

## FDP global configuration objects

The following objects are used to configure FDP globally.

Name, OID, and syntax	Access	Description
snFdpGlobalRun brcdIp.1.1.3.20.1.3.1 Syntax: Integer	Read-write	Indicates if the FDP is enabled: <ul style="list-style-type: none"> <li>false(0) – FDP is disabled. FDP entries in snFdpCacheTable are deleted when FDP is disabled.</li> <li>true(1) – FDP is enabled. Enabling FDP automatically enables CDP globally.</li> </ul> Default: false(0)
snFdpGlobalMessageInterval brcdIp.1.1.3.20.1.3.2 Syntax: Integer	Read-write	Indicates the interval at which FDP messages are to be generated. Valid values: 5 – 900 seconds Default: 60 seconds
snFdpGlobalHoldTime brcdIp.1.1.3.20.1.3.3 Syntax: Integer	Read-write	Indicates how long the receiving device will hold FDP messages. Valid values: 10 – 255 seconds Default: 180 seconds
snFdpGlobalCdpRun brcdIp.1.1.3.20.1.3.4 Syntax: Integer	Read-write	Shows if the CDP is enabled: <ul style="list-style-type: none"> <li>false(0) – CDP is disabled. CDP entries in snFdpCacheTable are deleted when FDP is disabled.</li> <li>true(1) – CDP is enabled. Enabling CDP does not automatically enable FDP globally.</li> </ul> Default: false (0)

## FDP cached address entry table

The FDP cached address entry table shows all the cached addresses from which FDP or CDP messages are being received. The table is available if FDP or CDP is enabled globally.

Name, OID, and syntax	Access	Description
snFdpCachedAddressTable brcdIp.1.1.3.20.1.4.1	None	The FDP cached address entry table.
snFdpCachedAddrIfIndex brcdIp.1.1.3.20.1.4.1.1.1 Syntax: Integer	None	Shows the ifIndex value of the local interface.
snFdpCachedAddrDeviceIndex brcdIp.1.1.3.20.1.4.1.1.2 Syntax: Integer32	Read-only	Shows a unique value for each device from which FDP or CDP messages are being received.
snFdpCachedAddrDeviceAddressEntryIndex brcdIp.1.1.3.20.1.4.1.1.3 Syntax: Integer32	Read-only	Shows a unique value for each address on the device from which FDP or CDP messages are being received. A device may have several addresses. There will be one entry for each address.
snFdpCachedAddrType brcdIp.1.1.3.20.1.4.1.1.4 Syntax: Integer	Read-only	Indicates the type of address contained in the "snFdpCachedAddrValue" object for this entry: <ul style="list-style-type: none"> <li>• ip(1)</li> <li>• ipx(2)</li> <li>• appletalk(3)</li> </ul>
snFdpCachedAddrValue brcdIp.1.1.3.20.1.4.1.1.5 Syntax: OCTET STRING	Read-only	Indicates the network-layer address of the device's SNMP agent as reported in the most recent FDP or CDP message. The format of this object depends on the value of the snFdpCachedAddrValue object: <ul style="list-style-type: none"> <li>• ip(1) – 4 octets</li> <li>• ipx(2) – 10 octets: <ul style="list-style-type: none"> <li>- Octets 1-4 – Network number</li> <li>- Octets 5-10 – Host number</li> </ul> </li> <li>• appletalk(3) – 3 octets: <ul style="list-style-type: none"> <li>- Octets 1-2 – Network number</li> <li>- Octet 3 – Host number</li> </ul> </li> </ul>

# Network Processor MIB Definition

---

## In this chapter

- [NP statistics table](#) ..... 257
- [NP QoS statistics table](#) ..... 261

## NP statistics table

---

### NOTE

The MIB objects for various Network Processor (NP) statistics supported on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices. It is not supported on the Brocade NetIron CES and Brocade NetIron CER series devices.

---

The Network Processor statistics table displays information about the statistics on all the POS and Ethernet cards.

Use the **show np statistics** CLI command to show the Network Processor statistics.

Use the **clear np statistics** CLI command to clear both the CLI and SNMP statistics counters for the Network Processor. The **snmp-server preserve-statistics** CLI command does not preserve the Network Processor statistics.

---

Name, OID, and syntax	Access	Description
brcdNPStatsTable brcdIp.1.14.2.1.1	None	The Network Processor table.
brcdNPStatsIfIndex brcdIp.1.14.2.1.1.1 Syntax: InterfaceIndex	None	The interface index for the entry. This is applicable only for the interfaces that are physically present and operationally up.
brcdNPStatsRxRawGoodPkts brcdIp.1.14.2.1.1.2 Syntax: Counter 64	Read-only	Shows the number of good packets received from the MAC address.
brcdNPStatsRxForwardPkts brcdIp.1.14.2.1.1.3 Syntax: Counter 64	Read-only	Shows the number of packets forwarded by a packet evaluation engine on the ingress path.
brcdNPStatsRxDiscardPkts brcdIp.1.14.2.1.1.4 Syntax: Counter 64	Read-only	Shows the number of packets flagged for discard by a packet evaluation engine.
brcdNPStatsRxMiscPkts brcdIp.1.14.2.1.1.5 Syntax: Counter 64	Read-only	Shows the number of miscellaneous packets received.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
brcdNPStatsRxUnicastPkts brcdIp.1.14.2.1.1.6 Syntax: Counter 64	Read-only	Shows the number of unicast packets received.
brcdNPStatsRxBroadcastPkts brcdIp.1.14.2.1.1.7 Syntax: Counter 64	Read-only	Shows the number of broadcast packets received.
brcdNPStatsRxMulticastPkts brcdIp.1.14.2.1.1.8 Syntax: Counter 64	Read-only	Shows the number of multicast packets received.
brcdNPStatsRxSendtoTMPkts brcdIp.1.14.2.1.1.9 Syntax: Counter 64	Read-only	Shows the number of packets sent to the Traffic Manager (TM).
brcdNPStatsRxBadPkts brcdIp.1.14.2.1.1.10 Syntax: Counter 64	Read-only	Shows the number of bad packets received.
brcdNPStatsRxLookupUnavailable brcdIp.1.14.2.1.1.11 Syntax: Counter 64	Read-only	Shows the number of packets dropped due to unavailability of the CAM interface for packet lookups.
brcdNPStatsRxACLDrop brcdIp.1.14.2.1.1.12 Syntax: Counter 64	Read-only	Shows the number of ACL drops on the ingress path.
brcdNPStatsRxPriority0And1Drop brcdIp.1.14.2.1.1.13 Syntax: Counter 64	Read-only	Shows the number of packets dropped based on priority 0 and 1 on the ingress path.
brcdNPStatsRxPriority2And3Drop brcdIp.1.14.2.1.1.14 Syntax: Counter 64	Read-only	Shows the number of packets dropped based on priority 2 and 3 on the ingress path.
brcdNPStatsRxPriority4And5Drop brcdIp.1.14.2.1.1.15 Syntax: Counter 64	Read-only	Shows the number of packets dropped based on priority 4 and 5 on the ingress path.
brcdNPStatsRxPriority6And7Drop brcdIp.1.14.2.1.1.16 Syntax: Counter 64	Read-only	Shows the number of packets dropped based on priority 6 and 7 on the ingress path.
brcdNPStatsRxSuppressRPFDrop brcdIp.1.14.2.1.1.17 Syntax: Counter 64	Read-only	Shows the number of suppressed RPF drops on the ingress path due to ACL override.
brcdNPStatsRxRPFDrop brcdIp.1.14.2.1.1.18 Syntax: Counter 64	Read-only	Shows the number of RPF drops on the ingress path.
brcdNPStatsRxIPv4Pkts brcdIp.1.14.2.1.1.19 Syntax: Counter 64	Read-only	Shows the number of packets that have IPv4 EType (0x0800) and IP version (0x4).
brcdNPStatsRxIPv6Pkts brcdIp.1.14.2.1.1.20 Syntax: Counter 64	Read-only	Shows the number of packets that have IPv6 EType (0x86DD) and IP version (0x6).

Name, OID, and syntax	Access	Description
brcdNPStatsRxRouteOnlyDrop brcdIp.1.14.2.1.1.21 Syntax: Counter 64	Read-only	Shows the number of packets dropped due to the route-only configuration during MAC-DA processing.
brcdNPStatsRxIPv6SuppressRPFDrop brcdIp.1.14.2.1.1.22 Syntax: Counter 64	Read-only	Shows the number of suppressed IPv6 RPF drops on the ingress path due to ACL override.
brcdNPStatsRxIPv6RPFDropCount brcdIp.1.14.2.1.1.23 Syntax: Counter 64	Read-only	Shows the number of IPv6 RPF drops on the ingress path.
brcdNPStatsRxIPv4Bytes brcdIp.1.14.2.1.1.24 Syntax: Counter 64	Read-only	Shows the number of raw packet bytes (+FCS) that have IPv4 EType (0x0800) and IP version (0x4).
brcdNPStatsRxIPv6Bytes brcdIp.1.14.2.1.1.25 Syntax: Counter 64	Read-only	Shows the number of raw packet bytes (+FCS) that have IPv6 EType (0x86DD) and IP version (0x6).
brcdNPStatsRxPOSCtrlProtocolPkts brcdIp.1.14.2.1.1.26 Syntax: Counter 64	Read-only	Shows the number of control protocol packets received in the POS mode. <b>NOTE:</b> This object is supported only on the POS interfaces. For other interfaces, this object returns "0".
brcdNPStatsRxPOSLinkDrop brcdIp.1.14.2.1.1.27 Syntax: Counter 64	Read-only	Shows the number of packets dropped due to the link state in the POS mode. <b>NOTE:</b> This object is supported only on the POS interfaces. For other interfaces, this object returns "0".
brcdNPStatsRxRoutedPktsDrop brcdIp.1.14.2.1.1.28 Syntax: Counter 64	Read-only	Shows the number of IPv4 or IPv6 routed packets that are received and then dropped because the time-to-live (TTL) is "0" or routing is not enabled on the given virtual interface.
brcdNPStatsTxSentToMACPkts brcdIp.1.14.2.1.1.29 Syntax: Counter 64	Read-only	Shows the total number of packets sent to a MAC address for transmission.
brcdNPStatsTxRawGoodPkts brcdIp.1.14.2.1.1.30 Syntax: Counter 64	Read-only	Shows the total number of packets sent to egress processing logic that pass the initial length checks.
brcdNPStatsTxSrcPortSupressDrop brcdIp.1.14.2.1.1.31 Syntax: Counter 64	Read-only	Shows the number of packets dropped because of the suppression of the transmit source port.
brcdNPStatsTxBadPktCnt brcdIp.1.14.2.1.1.32 Syntax: Counter 64	Read-only	Shows the total number of packets dropped in egress logic that fail the initial length checks.
brcdNPStatsTxUnicastPkts brcdIp.1.14.2.1.1.33 Syntax: Counter 64	Read-only	Shows the number of unicast packets transmitted.
brcdNPStatsTxBroadcastPkts brcdIp.1.14.2.1.1.34 Syntax: Counter 64	Read-only	Shows the number of broadcast packets transmitted.

Name, OID, and syntax	Access	Description
brcdNPStatsTxMulticastPkts brcdIp.1.14.2.1.1.35 Syntax: Counter 64	Read-only	Shows the number of multicast packets transmitted.
brcdNPStatsTxReceiveFromTM brcdIp.1.14.2.1.1.36 Syntax: Counter 64	Read-only	Shows the number of packets received from the Traffic Manager (TM).
brcdNPStatsTxACLDrop brcdIp.1.14.2.1.1.37 Syntax: Counter 64	Read-only	Shows the number of packets dropped by the outbound ACL logic.
brcdNPStatsTxPFCMulticastDrop brcdIp.1.14.2.1.1.38 Syntax: Counter 64	Read-only	Shows the total number of multicast FID packets that have been dropped by egress logic that map to the egress queue that is in the paused state.  <b>NOTE:</b> This object is supported only on the NI-MLX-10Gx8-D 8-port 10GbE module and the NI-MLX-10Gx8-M 8-port 10GbE (M) module. Zero is returned for the other cards.
brcdNPStatsTxPFCMTUExceedDrop brcdIp.1.14.2.1.1.39 Syntax: Counter 64	Read-only	Shows the total number of packets dropped by egress logic that exceed the MTU of the egress queue.  <b>NOTE:</b> This object is supported only on the NI-MLX-10Gx8-D 8-port 10GbE module and the NI-MLX-10Gx8-M 8-port 10GbE (M) module. Zero is returned for the other cards.
brcdNPStatsTxPFCQMAPErrorDrop brcdIp.1.14.2.1.1.40 Syntax: Counter 64	Read-only	Shows the number of packets dropped by egress logic that do not match with any valid egress queue.  <b>NOTE:</b> This object is supported only on the NI-MLX-10Gx8-D 8-port 10GbE module and the NI-MLX-10Gx8-M 8-port 10GbE (M) module. Zero is returned for the other cards.
brcdNPStatsTxIPv4Pkts brcdIp.1.14.2.1.1.41 Syntax: Counter 64	Read-only	Shows the number of IPv4 packets transmitted from the port. The packets have IPv4 Etype (0x0800) and IP version (0x4).
brcdNPStatsTxIPv6Pkts brcdIp.1.14.2.1.1.42 Syntax: Counter 64	Read-only	Shows the number of IPv6 packets transmitted from the port. The packets have IPv6 Etype (0x86DD) and IP version (0x6).
brcdNPStatsTxIPv4Bytes brcdIp.1.14.2.1.1.43 Syntax: Counter 64	Read-only	Shows the number of packet bytes (+FCS) that have IPv4 EType (0x0800) and IP version (0x4).
brcdNPStatsTxIPv6Bytes brcdIp.1.14.2.1.1.44 Syntax: Counter 64	Read-only	Shows the number of packet bytes (+FCS) that have IPv6 EType (0x86DD) and IP version (0x6).

Name, OID, and syntax	Access	Description
brcdNPStatsTxCtrlProtocolPkts brcdIp.1.14.2.1.1.45 Syntax: Counter 64	Read-only	Shows the number of control protocol packets sent in the POS mode. <b>NOTE:</b> This object is supported only on the POS interfaces. For other interfaces, this object returns "0".
brcdNPStatsTxPOSLinkDrop brcdIp.1.14.2.1.1.46 Syntax: Counter 64	Read-only	Shows the number of packets dropped due to the link state in the POS mode. <b>NOTE:</b> This object is supported only on the POS interfaces. For other interfaces, this object returns "0".

## NP QoS statistics table

The brcdNPQosStatTable displays information of Network Processor (NP) QoS-related statistics per port for per priority.

By default, the SNMP support is disabled. It is recommended to use **enable-qos-statistics** command to enable Quality of Service (QoS) accounting and **snmp-server enable mib np-qos-stat** command to enable the SNMP support.

Use **clear np qos statistics [ ethernet <slot/port> | pos <slot/port> | slot <slot no> ]** and **clear np qos stats lag <lag\_name>** commands to clear all the CLI and SNMP statistics counters for the NP QoS statistics.

### NOTE

The MIB objects in the following table are read-only and support only SNMP GET, GET-NEXT, WALK, and GET-BULK requests.

The following table contains information of Network Processor QoS-related statistics supported on the Brocade NetIron XMR and Brocade MLX series devices and the table is not supported on the Brocade NetIron CES and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
brcdNPQosStatTable brcdIp.1.14.2.1.1.2	NA	The NP QoS statistics table.
brcdNPQosStatIfIndex brcdIp.1.14.2.1.1.2.1.1 Syntax: InterfaceIndex	Read-only	The ifindex of the interface. The table includes all the interfaces of the LP modules that are physically present and operationally up and it also includes all the deployed LAG interfaces.
brcdNPQosStatQosPriority brcdIp.1.14.2.1.1.2.1.2 Syntax: PriorityTC	Read-only	The QoS priority associated with the entry. This is a 1-based index. The priority0 maps to 1, priority1 maps to 2, and so on. The priority value equal to the nonPriority(128) is not applicable.
brcdNPQosStatIngressPkts brcdIp.1.14.2.1.1.2.1.3 Syntax: Counter 64	Read-only	The number of packets that has arrived on the specified interface with a DSCP, EXP, or PCP value equal to the value of the brcdNPQosStatQosPriority object.
brcdNPQosStatIngressBytes brcdIp.1.14.2.1.1.2.1.4 Syntax: Counter 64	Read-only	The number of bytes that has arrived on the specified interface with a DSCP, EXP, or PCP value in the packet equal to the value of the brcdNPQosStatQosPriority object.

Name, OID, and syntax	Access	Description
brcdNPQosStatEgressPkts brcdIp.1.14.2.1.1.2.1.5 Syntx: Counter 64	Read-only	The number of packets that has left the device on the specified interface with an internal priority value equal to the value of the brcdNPQosStatQosPriority object. The internal priority is dependent on the configuration, but in general it is a function of DSCP, EXP, or PCP.
brcdNPQosStatEgressBytes brcdIp.1.14.2.1.1.2.1.6 Syntx: Counter 64	Read-only	The number of bytes that has left the device on the specified interface with an internal priority value equal to the value of the brcdNPQosStatQosPriority object. The internal priority is dependent on the configuration, but in general it is a function of DSCP, EXP, or PCP.



# System Logging Group

---

## In this chapter

- Global system logging group objects ..... 263
- Dynamic system logging buffer table ..... 265
- Static system logging buffer table ..... 266
- System log server table ..... 267
- IPv4/IPv6 syslog server table ..... 268

## Global system logging group objects

The following objects are for global system logging processes for all devices.

Name, OID, and syntax	Access	Description
snAgSysLogGblEnable brcdIp.1.1.2.6.1.1 Syntax: Integer	Read-write	Enables or disables system logging. Set this object to one of the following values: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> Default: enable(1)
snAgSysLogGblBufferSize brcdIp.1.1.2.6.1.2 Syntax: Integer32	Read-write	Sets the number of dynamic system logging entries. Valid values: Up to 100 entries Default: 50 entries
snAgSysLogGblClear brcdIp.1.1.2.6.1.3 Syntax: Integer	Read-write	Clears the dynamic and static system log buffers. Set this object to one of the following values: <ul style="list-style-type: none"> <li>• normal(0) – System logs will not be cleared.</li> <li>• clearAll(1) – Clears both dynamic and static system log buffers.</li> <li>• clearDynamic(2) – Clears only the dynamic system log.</li> <li>• clearStatic(3) – Clears only the static system log.</li> </ul>

Name, OID, and syntax	Access	Description
snAgSysLogGblCriticalLevel brcdIp.1.1.2.6.1.4 Syntax: Integer32	Read-write	Filters and identifies the events that will be logged in the logging buffer. This object consists of 32 bits. The following shows the meaning of each bit: Bit   Meaning 8- 31 Reserved 7   Warning (warning conditions) 6   Notification (normal but significant conditions) 5   Informational (informational messages) 4   Error (error conditions) 2   Debugging (debugging messages) 1   Critical (critical conditions). Setting this bit to 1 tells the logging buffer to accept the corresponding event. 0   Alert (immediate action needed). Setting this bit to 0 makes the logging buffer reject the corresponding event. Default: 255
snAgSysLogGblLoggedCount brcdIp.1.1.2.6.1.5 Syntax: Counter32	Read-only	Shows the number events logged in the system logging buffer.
snAgSysLogGblDroppedCount brcdIp.1.1.2.6.1.6 Syntax: Counter32	Read-only	Shows the number of events dropped from the system logging buffer.
snAgSysLogGblFlushedCount brcdIp.1.1.2.6.1.7 Syntax: Counter32	Read-only	Shows the number of times that the system logging buffer was cleared.
snAgSysLogGblOverrunCount brcdIp.1.1.2.6.1.8 Syntax: Counter32	Read-only	Shows the number of times that the system logging buffer has wrapped around.
snAgSysLogGblServer brcdIp.1.1.2.6.1.9 Syntax: IpAddress	Read-write	IP address of syslog server.
<p><b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.</p>		

Name, OID, and syntax	Access	Description
snAgSysLogGblFacility brcdIp.1.1.2.6.1.10 Syntax: Integer	Read-write	Shows the facility code: <ul style="list-style-type: none"> <li>• kern(1)</li> <li>• user(2)</li> <li>• mail(3)</li> <li>• daemon(4)</li> <li>• auth(5)</li> <li>• syslog(6)</li> <li>• lpr(7)</li> <li>• news(8)</li> <li>• uucp(9)</li> <li>• sys9(10)</li> <li>• sys10(11)</li> <li>• sys11(12)</li> <li>• sys12(13)</li> <li>• sys13(14)</li> <li>• sys14(15)</li> <li>• cron(16)</li> <li>• local0(17)</li> <li>• local1(18)</li> <li>• local2(19)</li> <li>• local3(20)</li> <li>• local4(21)</li> <li>• local5(22)</li> <li>• local6(23)</li> <li>• local7(24)</li> </ul> Default: user(2)
snAgSysLogGblPersistenceEn able brcdIp.1.1.2.6.1.11 Syntax: Integer	Read-write	Enables or disables system logging persistence.
<b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.		

## Dynamic system logging buffer table

The following table applies to all devices. It contains the events logged in the dynamic system log. Events that are not logged in the static system log are logged in the dynamic system log.

Name, OID, and syntax	Access	Description
snAgSysLogBufferTable brcdIp.1.1.2.6.2	None	Dynamic system logging buffer table.
snAgSysLogBufferIndex brcdIp.1.1.2.6.2.1.1 Syntax: Integer32	Read-only	Shows the index to the dynamic system logging buffer table.
snAgSysLogBufferTimeSt amp brcdIp.1.1.2.6.2.1.2 Syntax: Time ticks	Read-only	Shows the time stamp for when the event is logged.
snAgSysLogBufferCriticalL evel brcdIp.1.1.2.6.2.1.3 Syntax: Integer	Read-only	The critical level of this event: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• alert(2)</li> <li>• critical(3)</li> <li>• debugging(4)</li> <li>• emergency(5)</li> <li>• error(6)</li> <li>• informational(7)</li> <li>• notification(8)</li> <li>• warning(9)</li> </ul>
snAgSysLogBufferMessag e brcdIp.1.1.2.6.2.1.4 Syntax: DisplayString	Read-only	Displays the system logging message.
snAgSysLogBufferCalTime Stamp brcdIp.1.1.2.6.2.1.5 Syntax: DisplayString	Read-only	Shows the time stamp when the event is logged. This object is used only if an external time source, such as an SNTP server, is configured. Otherwise, the value of this object is 0. This object returns a NULL terminated time stamp string if the system calendar time was set. It returns a blank if the system calendar time was not set.

## Static system logging buffer table

The following table applies to all devices. It contains the events logged in the static system log. The static system log receives power failures, fan failures, temperature warnings, or shutdown messages.

Name, OID, and syntax	Access	Description
snAgStaticSysLogBufferTable brcdIp.1.1.2.6.3	None	Static system logging buffer table.
snAgStaticSysLogBufferIndex brcdIp.1.1.2.6.3.1.1 Syntax: Integer	Read-only	The index to the static system logging buffer table.
snAgStaticSysLogBufferTimeSt amp brcdIp.1.1.2.6.3.1.2 Syntax: Time ticks	Read-only	A time stamp, in number of time ticks, when the event is logged.

Name, OID, and syntax	Access	Description
snAgStaticSysLogBufferCriticalLevel brcdIp.1.1.2.6.3.1.3 Syntax: Integer	Read-only	The critical level of this event: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• alert(2)</li> <li>• critical(3)</li> <li>• debugging(4)</li> <li>• emergency(5)</li> <li>• error(6)</li> <li>• informational(7)</li> <li>• notification(8)</li> <li>• warning(9)</li> </ul>
snAgStaticSysLogBufferMessage brcdIp.1.1.2.6.3.1.4 Syntax: DisplayString	Read-only	The system logging message.
snAgStaticSysLogBufferCalTimeStamp brcdIp.1.1.2.6.3.1.5 Syntax: DisplayString	Read-only	A time stamp when the event is logged. This object is used only if an external time source, such as an SNTP server, is configured. Otherwise, the value of this object is 0. If an SNTP server is used to maintain time, then this object adds the value of the snAgStaticSysLogBufferTimeStamp object to the SNTP base to calculate the absolute time. This object returns a NULL terminated time stamp string if the system calendar time was set. It returns a blank if the system calendar time was not set.

## System log server table

The system log (syslog) server table shows which server receives syslog messages. Every server in the table receives all syslog messages.

Name, OID, and syntax	Access	Description
snAgSysLogServerTable brcdIp.1.1.2.6.4	None	System log server table.
snAgSysLogServerIP brcdIp.1.1.2.6.4.1.1 Syntax: IpAddress	Read-write	IP address of system log server.
snAgSysLogServerUDPPort brcdIp.1.1.2.6.4.1.2 Syntax: Integer	Read-write	UDP port number of the syslog server. Valid values: 0 – 65535
snAgSysLogServerRowStatus brcdIp.1.1.2.6.4.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• other(1) – Other.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

## IPv4/IPv6 syslog server table

---

**NOTE**

The “snAgSysLogServerTable” is deprecated and is replaced by “brcdSysLogServerTable”.

---

Name, OID, and syntax	Access	Description
brcdSysLogServerTable brcdIp.1.1.11.1.1.1	Read-only	The IPv4/IPv6 system log server table.
brcdSysLogServerAddrType brcdIp.1.1.11.1.1.1.1 Syntax: InetAddressType	Read-only	The syslog server address type. The supported address types are ipv4(1) and ipv6(2).
brcdSysLogServerAddr brcdIp.1.1.11.1.1.1.1.2 Syntax: InetAddress	Read-only	An IP address of the syslog server.
brcdSysLogServerUDPPort brcdIp.1.1.11.1.1.1.1.3 Syntax: Unsigned32	Read-only	An UDP port number of the syslog server.
brcdSysLogServerOutPkts brcdIp.1.1.11.1.1.1.1.4 Syntax: Counter32	Read-only	The number of syslog packets sent to the syslog server.
brcdSysLogServerRowStatus brcdIp.1.1.11.1.1.1.1.5 Syntax: RowSts	Read-create	The row status of the syslog server. <ul style="list-style-type: none"> <li>• createAndGo(4) - Creates a new row.</li> <li>• destroy(6) - Removes a row.</li> </ul> The value active(1) is returned for GET and GET-NEXT requests.

---

# NetFlow and sFlow MIB

## In this chapter

- [NetFlow](#) ..... 269
- [sFlow](#) ..... 272

## NetFlow

The following objects provide configuration information on the NetFlow feature.

NetFlow collects information about the traffic that devices receive, then forwards and exports that information to a third-party collector. Third-party applications can then use the information to create reports, bill customers for network usage, and so on.

### Global NetFlow objects

Name, OID, and syntax	Access	Description
snNetFlowGblEnable brcdIp.1.1.3.18.1.1 Syntax: Integer	Read-write	Determines if NetFlow is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snNetFlowGblVersion brcdIp.1.1.3.18.1.2 Syntax: Integer	Read-write	Shows the NetFlow version. Default: Version 5
snNetFlowGblProtocolDis able brcdIp.1.1.3.18.1.3 Syntax: Integer32	Read-write	Indicates if TCP or UDP are disabled: <ul style="list-style-type: none"> <li>• Bit 0 – Disables the export of all protocols except UDP and TCP.</li> <li>• Bit 1 – Disables the export of TCP.</li> <li>• Bit 2 – Disables the export of UDP.</li> </ul> Default: Bit 0
snNetFlowGblActiveTime out brcdIp.1.1.3.18.1.4 Syntax: Integer32	Read-write	Specifies the maximum number of minutes that an active flow can be in the NetFlow cache. Valid values: 1 – 60 minutes Default: 60 minutes
snNetFlowGblInactiveTim eout brcdIp.1.1.3.18.1.5 Syntax: Integer32	Read-write	Specifies the maximum number of seconds that an inactive flow can be in the NetFlow cache. Valid values: 1 – 60 seconds Default: 60 seconds

### NetFlow collector table

The following table provides information about the NetFlow collector.

Collectors are where expired UPD packets from devices are sent.

Name, OID, and syntax	Access	Description
snNetFlowCollectorTable brcdIp.1.1.3.18.2	None	A table of NetFlow collector information.
snNetFlowCollectorIndex brcdIp.1.1.3.18.2.1.1 Syntax: Integer	Read-only	The index to the NetFlow collector table. Valid values: 1 – 10
snNetFlowCollectorIp brcdIp.1.1.3.18.2.1.2 Syntax: IpAddress	Read-write	Shows the IP address of the collector.
snNetFlowCollectorUdpPort brcdIp.1.1.3.18.2.1.3 Syntax: Integer32	Read-write	Shows the UDP port number of the collector.
snNetFlowCollectorSourceInterf ace brcdIp.1.1.3.18.2.1.4 Syntax: Integer	Read-write	Shows the source port for the NetFlow packets. Packets will be exported through this port: <ul style="list-style-type: none"> <li>• A valid port number – The port configured to be the source port.</li> <li>• 0 – No source port specified. The port connected to the collector is the source port.</li> </ul>
snNetFlowCollectorRowStatus brcdIp.1.1.3.18.2.1.5 Syntax: Integer	Read-write	Creates or deletes a NetFlow collector table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## NetFlow aggregation table

The following table provides information on the NetFlow aggregation schemes.

By default, NetFlow exports a separate flow for each unique set of flow information. To streamline data export, you can consolidate flows by creating aggregate caches that contain individual flows based on specific information in the flow.



Name, OID, and syntax	Access	Description
snNetFlowAggregationTable brcdIp.1.1.3.18.3	None	The NetFlow aggregation table
snNetFlowAggregationIndex brcdIp.1.1.3.18.3.1.1 Syntax: Integer	Read-only	Specifies what information is used to aggregate the flow: <ul style="list-style-type: none"> <li>as(1) – Autonomous system scheme uses the input and output interfaces and the source and destination BGP4 AS.</li> <li>protocolPort(2) – IP and application port source and destination IP, and source and destination TCP or UDP port numbers.</li> <li>destPrefix(3) – Destination prefix scheme uses output interface, destination network mask and prefix, and destination BGP4 AS.</li> <li>sourcePrefix(4) – Source prefix scheme uses the input interface, source network mask and prefix, and source BGP4 AS.</li> <li>prefix(5) – Source and destination prefix scheme uses the input and output interfaces, source and destination network masks and prefixes, and source and destination BGP4 AS.</li> </ul>
snNetFlowAggregationIp brcdIp.1.1.3.18.3.1.2 Syntax: IpAddress	Read-write	The IP address of the NetFlow aggregation collector.
snNetFlowAggregationUdpPort brcdIp.1.1.3.18.3.1.3 Syntax: Integer	Read-write	The UDP port of the NetFlow aggregation collector.
snNetFlowAggregationSourceInterface brcdIp.1.1.3.18.3.1.4 Syntax: Integer	Read-write	Shows the source port to export the NetFlow aggregation packets: <ul style="list-style-type: none"> <li>A valid port number – The port configured to be the source port.</li> <li>0 – No source port specified. The port connected to the collector is the source port.</li> </ul>
snNetFlowAggregationNumberOfCache Entries brcdIp.1.1.3.18.3.1.5 Syntax: Integer32	Read-write	Shows the maximum number of aggregated flows that the aggregation cache can contain.
snNetFlowAggregationActiveTimeout brcdIp.1.1.3.18.3.1.6 Syntax: Integer32	Read-write	Shows the maximum time in minutes that an active flow can remain in the NetFlow aggregation cache. Valid values: 1 – 60 minutes Default: 30 minutes
snNetFlowAggregationInactiveTimeout brcdIp.1.1.3.18.3.1.7 Syntax: Integer32	Read-write	Shows the maximum time in seconds that an inactive flow can remain in the NetFlow aggregation cache. The object can have a value from 10 through 600 seconds. Default: 15 seconds

Name, OID, and syntax	Access	Description
snNetFlowAggregationEnable brcdIp.1.1.3.18.3.1.8 Syntax: Integer	Read-write	Indicates if NetFlow aggregation for this aggregation scheme is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snNetFlowAggregationRowStatus brcdIp.1.1.3.18.3.1.9 Syntax: Integer	Read-write	Creates or deletes a NetFlow aggregation table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## NetFlow interface table

The following table contains information about the switching type in every NetFlow interface.

Name, OID, and syntax	Access	Description
snNetFlowIfTable brcdIp.1.1.3.18.4	None	Shows a list of interface entries. The number of entries is given by the value of ifNumber.
snNetFlowIfIndex brcdIp.1.1.3.18.4.1.1 Syntax: Integer	Read-only	Shows a unique value, greater than zero, for each interface. Valid values: 1 – 65536 It is recommended that values are assigned contiguously starting with 1. The value for each interface sub-layer must remain constant at least from one re-initialization of the entity's network management system to the next re-initialization.
snNetFlowIfFlowSwitching brcdIp.1.1.3.18.4.1.2 Syntax: Integer	Read-write	Indicates if flow switching in a particular interface is enabled: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>

## sFlow

This section presents the sFlow objects that are proprietary to products.

### sFlow collector table

Currently, RFC 3176 allows only one sFlow destination to be configured. To configure two or more destinations, use the following table.

Name, OID, and syntax	Access	Description
snSflowCollectorTable brcdIp.1.1.3.19.2	None	Table of sFlow collectors, beginning with the second collector. Configure the first sFlow collector using the sFlowCollectorAddress and sFlowCollectorPort objects in the RFC 3176 sFlowTable.
snSflowCollectorIndex brcdIp.1.1.3.19.2.1.1 Syntax: Integer32	Read-only	The index to the sFlow collector table.

Name, OID, and syntax	Access	Description
snSflowCollectorIP brcdIp.1.1.3.19.2.1.2 Syntax: IpAddress	Read-write	The IP address of the sFlow collector.
snSflowCollectorUDPPort brcdIp.1.1.3.19.2.1.3 Syntax: Integer32	Read-write	The number of the UDP port used by the sFlow collector.
snSflowCollectorRowStatus brcdIp.1.1.3.19. 2.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• other(1) – Some other case.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>



## VLAN Layer 2 Switch MIB Definition

### In this chapter

- VLAN by port information table. . . . . 275
- VLAN by port membership table. . . . . 279
- Port VLAN configuration table. . . . . 280
- VLAN by protocol configuration table. . . . . 283
- VLAN by IP subnet configuration table. . . . . 285
- VLAN by IPX network configuration table. . . . . 287
- VLAN by AppleTalk cable configuration table . . . . . 289
- VLAN extended statistics. . . . . 290

### VLAN by port information table

The following table applies to a Layer 2 device if the object snSwGroupOperMode is configured with a value of vlanByPort(2), allowing switch ports to be configured with a VLAN ID. Each VLAN switch port could have a number of VLAN IDs.

#### NOTE

The following table is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snVlanByPortTable brcdIp.1.1.3.2.1	None	The VLAN by port information table for Layer 2 Switches.
snVlanByPortEntry brcdIp.1.1.3.2.1.1	None	An entry in the VLAN by port information table.
snVlanByPortVlanIndex brcdIp.1.1.3.2.1.1.1 Syntax: Integer	Read-only	Shows the index to this table. The VLAN ID number must not be greater than the value of the object. Each VLAN identifier can be a member of multiple ports.
snVlanByPortVlanId brcdIp.1.1.3.2.1.1.2 Syntax: Integer	Read-write	The VLAN ID index to the table. Each VLAN identifier can be a member of multiple ports. Valid values: 1 – 4095
snVlanByPortPortMask brcdIp.1.1.3.2.1.1.3 Syntax: PortMask	Read-write	Shows the standalone switch VLAN port membership. This object was obsoleted for Chassis devices.

Name, OID, and syntax	Access	Description
snVlanByPortQos brcdIp.1.1.3.2.1.1.4 Syntax: Integer	Read-write	Shows the QoS settings for the following devices: Standalone: <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> </ul> BigIron <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>
snVlanByPortStpMode brcdIp.1.1.3.2.1.1.5 Syntax: Integer	Read-write	Indicates whether or not the Spanning Tree mode in the switch group is enabled: <ul style="list-style-type: none"> <li>disable(0) - No Spanning Tree</li> <li>enableStp(1) - Activate Spanning Tree</li> <li>enableRstp(2) - Activate Rapid Spanning Tree</li> </ul>
snVlanByPortStpPriority brcdIp.1.1.3.2.1.1.6 Syntax: Integer	Read-write	Shows the value of the dot1dStpPriority, which is the first two octets of the STP bridge ID. The STP bridge ID is eight octets long. This object contains the writable portion of the bridge ID. The last six octets are contained in the dot1dBaseBridgeAddress of the snVlanByPortBaseBridgeAddress object. Valid values: 1 – 65535
snVlanByPortStpGroupMaxAge brcdIp.1.1.3.2.1.1.7 Syntax: Integer	Read-write	Shows the value of dot1dStpBridgeMaxAge, which is the last six octets of the STP bridge ID. All bridges use this object for MaxAge when this bridge is acting as the root. <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeHelloTime in the “snVlanByPortStpGroupHelloTime” object. The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.) Valid values: 6 – 40
snVlanByPortStpGroupHelloTime brcdIp.1.1.3.2.1.1.8 Syntax: Integer	Read-write	Shows the value of the dot1dStpBridgeHelloTime, which is the value used by all bridges when this bridge is acting as the root. <b>NOTE:</b> The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad Value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.) Valid values: 1 – 10

Name, OID, and syntax	Access	Description
snVlanByPortStpGroupForwardDelay brcdIp.1.1.3.2.1.1.9 Syntax: Integer	Read-write	Shows the value of dot1dStpBridgeForwardDelay, which is the value used by all bridges for ForwardDelay when this bridge is acting as the root.  <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeMaxAge, which is in the "snVlanByPortStpGroupMaxAge" object. The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.)  Valid values: 2 -30
snVlanByPortRowStatus brcdIp.1.1.3.2.1.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) - Deletes the row.</li> <li>create(4) - Creates a new row.</li> <li>modify(5) - Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a bad value error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) - No such row.</li> <li>invalid(1) - Row is inoperative.</li> <li>valid(2) - Row exists and is valid.</li> </ul>
snVlanByPortOperState brcdIp.1.1.3.2.1.1.11 Syntax: Integer	Read-only	Activates the VLAN entry and sets it to running mode: <ul style="list-style-type: none"> <li>notActivated(0) - The VLAN entry is not activated and not in running mode.</li> <li>activated(1) - The VLAN entry is activated and in running mode.</li> </ul> Default: notActivated(0)
snVlanByPortBaseNumPorts brcdIp.1.1.3.2.1.1.12 Syntax: Integer32	Read-only	Indicates the number of ports controlled by this bridging entity.
snVlanByPortBaseType brcdIp.1.1.3.2.1.1.13 Syntax: Integer	Read-only	Indicates what type of bridging this bridge can perform. If a bridge is actually performing a certain type of bridging, this will be indicated by entries in the port table for the given type: <ul style="list-style-type: none"> <li>unknown(1)</li> <li>transparent-only(2)</li> <li>sourceroute-only(3)</li> <li>srt(4)</li> </ul>
snVlanByPortStpProtocolSpecification brcdIp.1.1.3.2.1.1.14 Syntax: Integer	Read-only	Shows what version of STP is being run: <ul style="list-style-type: none"> <li>unknown(1)</li> <li>decLb100(2) - Indicates the DEC LANbridge 100 Spanning Tree Protocol.</li> <li>ieee8021d(3) - Returns "ieee8021d(3)". If future versions of the IEEE Spanning Tree Protocol are released that are incompatible with the current version, a new value will be defined.</li> </ul>

Name, OID, and syntax	Access	Description
snVlanByPortStpMaxAge brcdIp.1.1.3.2.1.1.15 Syntax: Integer	Read-only	Shows the value of dot1dStpMaxAge, which is the maximum age that the STP information can exist before it is discarded. The STP information is the information learned from the network. The value of this object is in hundredths of a second, and is the actual value that this bridge is currently using. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpHelloTime brcdIp.1.1.3.2.1.1.16 Syntax: Timeout	Read-only	Shows the value of dot1dStpHelloTime, which is the interval between the transmission of configuration bridge PDUs by this node. This value applies to any port when it is the root of the spanning tree or is trying to become the root. This is the actual value that this bridge is currently using. This value is in hundredths of a second. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpHoldTime brcdIp.1.1.3.2.1.1.17 Syntax: Integer32	Read-only	Shows the value of dot1dStpHoldTime, which is the interval when no more than two configuration bridge PDUs can be transmitted by this node. The interval is in units of hundredths of a second. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpForwardDelay brcdIp.1.1.3.2.1.1.18 Syntax: Timeout	Read-only	Shows the value of dot1dStpForwardDelay, which is the time that controls how long a port stays in the listening and learning states as its spanning state moves towards the forwarding state. This value is also used when a topology change has been detected and is under way. The value is used to age all dynamic entries in the Forwarding Database. This value is the one that this bridge is currently using, in contrast to dot1dStpBridgeForwardDelay in the “snVlanByPortStpGroupForwardDelay” object, which is the value that this bridge and all others would start using when this bridge becomes the root. This time value is in hundredths of a second, (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpTimeSinceTopologyChange brcdIp.1.1.3.2.1.1.19 Syntax: Time ticks	Read-only	Shows the time since the last time the bridge detected a topology change. This time is in hundredths of a second.
snVlanByPortStpTopChanges brcdIp.1.1.3.2.1.1.20 Syntax: Counter32	Read-only	Shows the total number of topology changes detected by this bridge since the management entity was last reset or initialized.
snVlanByPortStpRootCost brcdIp.1.1.3.2.1.1.21 Syntax: Integer32	Read-only	Shows the value of dot1dStpRootCost, which is the cost of the path to the root as seen from this bridge. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpRootPort brcdIp.1.1.3.2.1.1.22 Syntax: Integer32	Read-only	Shows the value of dot1dStpRootPort, which is the number of the port that offers the lowest cost path from this bridge to the root bridge. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortStpDesignatedRoot brcdIp.1.1.3.2.1.1.23 Syntax: Bridgeld	Read-only	Shows the value of dot1dStpDesignatedRoot, which is the bridge ID of the root of the spanning tree as determined by STP as executed by this node. This value is used as the Root Identifier parameter in all configuration bridge PDUs originated by this node. (Refer to RFC 1493 Bridge MIB.)



Name, OID, and syntax	Access	Description
snVlanByPortBaseBridgeAddress brcdIp.1.1.3.2.1.1.24 Syntax: Bridgeld	Read-only	Indicates the value of the dot1dBaseBridgeAddress, which is the MAC address used by this bridge when it must be referred to in a unique fashion.  It is recommended that this is the smallest MAC address of all ports that belong to this bridge; however, it must be unique. When concatenated with dot1dStpPriority, a unique Bridge Identifier is formed, which is used in the STP.
snVlanByPortVlanName brcdIp.1.1.3.2.1.1.25 Syntax: DisplayString	Read-write	Indicates the name of the community string that is allowed to access the VLAN.  Valid values: Up to 32 characters
snVlanByPortRouterIntf brcdIp.1.1.3.2.1.1.26 Syntax: Integer32 <b>NOTE:</b> This object was deprecated on FastIron devices. It is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, or Brocade NetIron CER series devices. Use snVlanByPortCfgRouterIntf instead.	Read-write	This object is optional and applies only to routers. It shows the ID of the virtual interface of a router to the VLAN. If an SNMP-Get value is zero, then this object was not configured. Valid values: 1 – 60
snVlanByPortChassisPortMask brcdIp.1.1.3.2.1.1.27 Syntax: OCTET STRING	Read-write	The object is replaced by “snVlanByPortPortList”. It shows the VLAN switch port membership. This object has 32 octets.
snVlanByPortPortList brcdIp.1.1.3.2.1.1.28 Syntax: OCTET STRING	Read-write	Applies to all devices.

## VLAN by port membership table

The following table is the Port VLAN (Layer 2 VLAN) port membership table.

Name, OID, and syntax	Access	Description
snVlanByPortMemberTable brcdIp.1.1.3.2.6	None	This table is used to create or delete a port VLAN (Layer 2 VLAN) entry.
snVlanByPortMemberEntry brcdIp.1.1.3.2.6.1	None	An entry in the Port VLAN port membership table.
snVlanByPortMemberVlanId brcdIp.1.1.3.2.6.1.1 Syntax: Integer	Read-only	The VLAN identifier (VLAN ID). Valid values: 1 – 4095 VLAN IDs

Name, OID, and syntax	Access	Description
snVlanByPortMemberPortId brcdIp.1.1.3.2.6.1.2 Syntax: Integer	Read-only	The ifIndex that is a member of the port VLAN.
snVlanByPortMemberRowStatus brcdIp.1.1.3.2.6.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a bad value error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>other(1) – Some other case.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snVlanByPortMemberTagMode brcdIp.1.1.3.2.6.1.4 Syntax: Integer	Read-write	For a tagged or dual-mode port, there can be multiple VLANs per port. For an untagged port, there is only one VLAN ID per port. The values are: <ul style="list-style-type: none"> <li>tagged(1)</li> <li>untagged(2)</li> </ul>

## Port VLAN configuration table

Name, OID, and syntax	Access	Description
snVlanByPortCfgTable brcdIp.1.1.3.2.7	None	The Port VLAN (Layer 2 VLAN) configuration table.
snVlanByPortCfgEntry brcdIp.1.1.3.2.7.1	None	An entry of the port VLAN configuration table.
snVlanByPortCfgVlanId brcdIp.1.1.3.2.7.1.1 Syntax: Integer	Read-write	The VLAN ID index to this table. Each VLAN identifier can be a member of multiple ports. Valid values: 1 – 4095
snVlanByPortCfgQos brcdIp.1.1.3.2.7.1.2 Syntax: PortQosTC	Read-write	Shows the Quality of Service (QoS) settings for the devices. For Stackable devices, the values can be one of the following: <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> </ul> For Chassis devices, the value can be one of the following: <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> <li>invalid(127) - This value is used by CES or CER products to signify that no Quality of Service was specified for this VLAN.</li> </ul>

Name, OID, and syntax	Access	Description
snVlanByPortCfgStpMode brcdIp.1.1.3.2.7.1.3 Syntax: Integer	Read-write	Indicates whether or not Spanning Tree Protocol (STP) is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> The following values are supported on FastIron SuperX software releases: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enableStp(1)</li> <li>enableRstp(2)</li> </ul>
snVlanByPortCfgStpPriority brcdIp.1.1.3.2.7.1.4 Syntax: Integer	Read-write	Shows the value of the dot1dStpPriority, which is the first two octets of the STP or RSTP bridge ID. The STP and RSTP bridge IDs are eight octets long. This object contains the writable portion of the bridge ID. The last six octets are contained in the dot1dBaseBridgeAddress of the “snVlanByPortBaseBridgeAddress” object. Valid values: 1 – 65535
snVlanByPortCfgStpGroupMaxAge brcdIp.1.1.3.2.7.1.5 Syntax: Integer32	Read-write	Shows the value of dot1dStpBridgeMaxAge, which is the last six octets or the STP or RSTP bridge ID. All bridges use this object for MaxAge when this bridge is acting as the root. <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeHelloTime in the “snVlanByPortStpGroupHelloTime” object. The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.) Valid values: 6 – 40
snVlanByPortCfgStpGroupHelloTime brcdIp.1.1.3.2.7.1.6 Syntax: Integer	Read-write	Shows the value of dot1dStpBridgeHelloTime, which is the value used by all bridges when this bridge is acting as the root. <b>NOTE:</b> The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad Value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.) Valid values: 1 – 10
snVlanByPortCfgStpGroupForwardDelay brcdIp.1.1.3.2.7.1.7 Syntax: Integer32	Read-write	Shows the value of dot1dStpBridgeForwardDelay, which is the value used by all bridges for ForwardDelay when this bridge is acting as the root. <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeMaxAge, which is in the “snVlanByPortStpGroupMaxAge” object. The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a bad value error if a set is attempted to a value which is not a whole number of seconds. (Refer to RFC 1493 Bridge MIB.) Valid values: 2 – 30
snVlanByPortCfgBaseNumPorts brcdIp.1.1.3.2.7.1.8 Syntax: Integer32	Read-only	The number of ports controlled by this bridging entity.

Name, OID, and syntax	Access	Description
snVlanByPortCfgBaseType brcdIp.1.1.3.2.7.1.9 Syntax: Integer	Read-only	Indicates what type of bridging this bridge can perform. If a bridge is actually performing a certain type of bridging, this will be indicated by entries in the port table for the given type: <ul style="list-style-type: none"> <li>unknown(1)</li> <li>transparentOnly(2)</li> <li>sourcerouteOnly(3)</li> <li>srt(4)</li> </ul>
snVlanByPortCfgStpProtocolSpecification brcdIp.1.1.3.2.7.1.10 Syntax: Integer	Read-only	Shows what version of STP is being run: <ul style="list-style-type: none"> <li>unknown(1)</li> <li>decLb100(2) – Indicates the DEC LANbridge 100 Spanning Tree Protocol.</li> <li>ieee8021d(3) – IEEE 802.1d implementations will return this value. If future versions of the IEEE Spanning Tree Protocol are released that are incompatible with the current version, a new value will be defined.</li> </ul>
snVlanByPortCfgStpMaxAge brcdIp.1.1.3.2.7.1.11 Syntax: Integer	Read-only	Shows the value of dot1dStpMaxAge, which is the maximum age that the STP information can exist before it is discarded. The STP information is learned from the network. The value of this object is in hundredths of a second, and is the actual value that this bridge is currently using. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpHelloTime brcdIp.1.1.3.2.7.1.12 Syntax: Timeout	Read-only	Shows the value of dot1dStpHelloTime, which is the interval between the transmission of configuration bridge PDUs by this node. This value applies to any port when it is the root of the spanning tree or is trying to become the root. This is the actual value that this bridge is currently using. This value is in hundredths of a second. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpHoldTime brcdIp.1.1.3.2.7.1.13 Syntax: Integer32	Read-only	Shows the value of dot1dStpHoldTime, which is the interval when no more than two configuration bridge PDUs can be transmitted by this node. The interval is in units of hundredths of a second. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpForwardDelay brcdIp.1.1.3.2.7.1.14 Syntax: Timeout	Read-only	Shows the value of dot1dStpForwardDelay, which controls how fast a port changes its spanning state when moving towards the forwarding state. The value determines how long the port stays in each of the listening and learning states, which precede the forwarding state. This value is also used, when a topology change has been detected and is under way, to age all dynamic entries in the forwarding database. <b>NOTE:</b> This value is the one that this bridge is currently using in contrast to dot1dStpBridgeForwardDelay, which is the value that this bridge and all others would start using should this bridge become the root. This value is measured in hundredths of a second. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpTimeSinceTopologyChange brcdIp.1.1.3.2.7.1.15 Syntax: Time ticks	Read-only	Shows the time since the last topology change was detected by the bridge entity. This time is in hundredths of a second.

Name, OID, and syntax	Access	Description
snVlanByPortCfgStpTopChanges brcdIp.1.1.3.2.7.1.16 Syntax: Counter32	Read-only	Shows the total number of topology changes detected by this bridge since the management entity was last reset or initialized.
snVlanByPortCfgStpRootCost brcdIp.1.1.3.2.7.1.17 Syntax: Integer32	Read-only	Shows the value of dot1dStpRootCost, which is the cost of the path to the root as seen from this bridge. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpRootPort brcdIp.1.1.3.2.7.1.18 Syntax: Integer32	Read-only	Shows the value of dot1dStpRootPort, which is the port number of the port which offers the lowest cost path from this bridge to the root bridge. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgStpDesignatedRoot brcdIp.1.1.3.2.7.1.19 Syntax: BridgeId	Read-only	Shows the value of dot1dStpDesignatedRoot, which is the bridge identifier of the root of the spanning tree as determined by the Spanning Tree Protocol as executed by this node. This value is used as the root identifier parameter in all configuration bridge PDUs originated by this node. (Refer to RFC 1493 Bridge MIB.)
snVlanByPortCfgBaseBridgeAddress brcdIp.1.1.3.2.7.1.20 Syntax: MAC address	Read-only	Shows the MAC address used by this bridge when it must be referred to in a unique fashion. It is recommended that this be the numerically smallest MAC address of all ports that belong to this bridge; however, it is only required to be unique. When concatenated with dot1dStpPriority, a unique bridge identifier is formed, which is used in the Spanning Tree Protocol.
snVlanByPortCfgVlanName brcdIp.1.1.3.2.7.1.21 Syntax: DisplayString	Read-write	Shows the name of the VLAN community string. Valid values: Up to 32 characters
snVlanByPortCfgRouterIntf brcdIp.1.1.3.2.7.1.22 Syntax: Integer32	Read-write	This object is optional. It identifies the virtual interface for the router to the VLAN, and applies only to the router. If an SNMP-Get value is zero, that means this object was not configured.
snVlanByPortCfgRowStatus brcdIp.1.1.3.2.7.1.23 Syntax: Integer	Read-write	Deletes a VLAN entry.
snVlanByPortCfgStpVersion brcdIp.1.1.3.2.7.1.24 Syntax: Integer <b>NOTE:</b> This object is supported only on the FastIron SuperX devices.	Read-write	Shows the version of Spanning Tree Protocol the bridge is currently running: <ul style="list-style-type: none"> <li>• stpCompatible(0) – STP (IEEE 802.1D)</li> <li>• rstp(2) – RSTP (IEEE 802.1w)</li> </ul>
snVlanByPortCfgInOctets brcdIp.1.1.3.2.7.1.25 Syntax: Counter64	Read-only	The number of bytes received on this VLAN. This can be used as the per-VE counter, if there is one-to-one mapping for VLAN-VE.

## VLAN by protocol configuration table

The following table applies to protocol VLANs.

**NOTE**

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snVlanByProtocolTable brcdIp.1.1.3.2.2	None	The VLAN by protocol configuration table.
snVlanByProtocolEntry brcdIp.1.1.3.2.2.1	None	An entry in the VLAN by protocol configuration table.
snVlanByProtocolVlanId brcdIp.1.1.3.2.2.1.1	Read-only	Shows the VLAN ID index to both the VLAN by port information table and this table.
snVlanByProtocolIndex brcdIp.1.1.3.2.2.1.2 Syntax: Integer	Read-only	Shows the protocol used by this VLAN. The following IP/IPX protocols are used by VLANs in Layer 3 VLAN: <ul style="list-style-type: none"> <li>• IP(1)</li> <li>• IPX(2)</li> </ul> The following protocols are used in Layer 2 bridging: <ul style="list-style-type: none"> <li>• appleTalk(3)</li> <li>• decNet(4)</li> <li>• netBios(5)</li> <li>• others(6) – Other protocols that are defined here.</li> </ul>
snVlanByProtocolDynamic brcdIp.1.1.3.2.2.1.3 Syntax: Integer	Read-write	Applies only to switches. Indicates whether or not dynamic port inclusion is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snVlanByProtocolStaticMask brcdIp.1.1.3.2.2.1.4 Syntax: PortMask	Read-write	Indicates the standalone switch Protocol VLAN port membership (portmask) applied in static mode. This object was obsoleted for Chassis devices.
snVlanByProtocolExcludeMask brcdIp.1.1.3.2.2.1.5 Syntax: PortMask	Read-write	Indicates the standalone switch Protocol VLAN port membership (portmask) applied in exclusive mode. This object was obsoleted for Chassis devices.
snVlanByProtocolRouterIntf brcdIp.1.1.3.2.2.1.6 Syntax: Integer	Read-write	Applies to routers only and is optional. It shows the virtual interface of a router to the VLAN. This object is not configured if an SNMP-Get is equal to zero.
snVlanByProtocolRowStatus brcdIp.1.1.3.2.2.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

Name, OID, and syntax	Access	Description
snVlanByProtocolDynamicMask brcdIp.1.1.3.2.2.1.8 Syntax: PortMask	Read-only	Shows the portmask, which is the standalone switch Protocol VLAN active port membership. This object was obsoleted.
snVlanByProtocolChassisStaticMask brcdIp.1.1.3.2.2.1.9 Syntax: OCTET STRING	Read-write	This object has 32 octets. It has been obsoleted and replaced by the “snVlanByProtocolStaticPortList” object.
snVlanByProtocolChassisExcludeMask brcdIp.1.1.3.2.2.1.10 Syntax: OCTET STRING	Read-write	This object has 32 octets. It has been obsoleted and replaced by the “snVlanByProtocolExcludePortList” object.
snVlanByProtocolChassisDynamicMask brcdIp.1.1.3.2.2.1.11 Syntax: OCTET STRING	Read-write	This object has 32 octets. It has been obsoleted and replaced by the “snVlanByProtocolDynamicPortList” object.
snVlanByProtocolVlanName brcdIp.1.1.3.2.2.1.12 Syntax: DisplayString	Read-write	Shows the name of the community string that is allowed to access the VLAN. Valid values: Up to 32 characters
snVlanByProtocolStaticPortList brcdIp.1.1.3.2.2.1.13 Syntax: OCTET STRING	Read-write	This object is an index of ports that are configured to be members of the Protocol VLAN. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.
snVlanByProtocolExcludePortList brcdIp.1.1.3.2.2.1.14 Syntax: OCTET STRING	Read-write	This object is an index of ports that are excluded from port membership of the Protocol VLAN. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.
snVlanByProtocolDynamicPortList brcdIp.1.1.3.2.2.1.15 Syntax: OCTET STRING	Read-only	This object is an index of ports that can dynamically join the port membership of the Protocol VLAN. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.

## VLAN by IP subnet configuration table

The following table applies to protocol VLANs that use the IP routing protocol.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snVlanByIpSubnetTable brcdIp.1.1.3.2.3	None	The VLAN by IP subnet configuration table.
snVlanByIpSubnetEntry brcdIp.1.1.3.2.3.1	None	An entry in the VLAN by IP subnet configuration table.

Name, OID, and syntax	Access	Description
snVlanByIpSubnetVlanId brcdIp.1.1.3.2.3.1.1 Syntax: Integer	Read-only	Shows the VLAN ID index to both the VLAN by port information table and this table. Valid values: 1 - 4095
snVlanByIpSubnetIpAddress brcdIp.1.1.3.2.3.1.2 Syntax: IpAddress	Read-only	Shows the IP address for the subnet of the protocol-based IP VLAN.
snVlanByIpSubnetSubnetMask brcdIp.1.1.3.2.3.1.3 Syntax: IpAddress	Read-only	Subnet mask associated with the subnet IP address.
snVlanByIpSubnetDynamic brcdIp.1.1.3.2.3.1.4 Syntax: Integer	Read-write	Applies only to switches. Indicates whether or not dynamic port inclusion is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snVlanByIpSubnetStaticMask brcdIp.1.1.3.2.3.1.5 Syntax: PortMask	Read-write	Shows the port membership of the standalone switch VLAN by Subnet in static mode. This object was obsoleted.
snVlanByIpSubnetExcludeMask brcdIp.1.1.3.2.3.1.6 Syntax: PortMask	Read-write	Shows the port membership of the standalone switch VLAN by Subnet in exclusive mode. This object was obsoleted.
snVlanByIpSubnetRouterIntf brcdIp.1.1.3.2.3.1.7 Syntax: Integer	Read-write	Applies only to routers and is optional. It shows the virtual interface of a router to the VLAN. Valid values: 0 - 60. It is not configured if an SNMP-Get is equal to zero.
snVlanByIpSubnetRowStatus brcdIp.1.1.3.2.3.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) - Deletes the row.</li> <li>• create(4) - Creates a new row.</li> <li>• modify(5) - Modifies an existing row. If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) - No such row.</li> <li>• invalid(1) - Row is inoperative.</li> <li>• valid(2) - Row exists and is valid.</li> </ul>
snVlanByIpSubnetDynamicMask brcdIp.1.1.3.2.3.1.9 Syntax: PortMask	Read-only	Shows the standalone switch VLAN by subnet active port membership.
snVlanByIpSubnetChassisStaticMask brcdIp.1.1.3.2.3.1.10 Syntax: Octet string	Read-write	This object has 32 octets. It is replaced by the <a href="#">"snVlanByIpSubnetStaticPortList"</a> object. It shows the chassis VLAN by Subnet port membership applied in static mode.
snVlanByIpSubnetChassisExcludeMask brcdIp.1.1.3.2.3.1.11 Syntax: Octet string	Read-write	This object has 32 octets. It is replaced by the <a href="#">"snVlanByIpSubnetExcludePortList"</a> object. It shows the chassis VLAN by Subnet port membership applied in exclusive mode.
snVlanByIpSubnetChassisDynamicMask brcdIp.1.1.3.2.3.1.12 Syntax: Octet string	Read-write	This object has 32 octets. It is replaced by the <a href="#">"snVlanByIpSubnetDynamicPortList"</a> object. It shows the chassis VLAN by Subnet port membership applied in exclusive mode.



Name, OID, and syntax	Access	Description
snVlanByIpSubnetVlanName brcdIp.1.1.3.2.3.1.13 Syntax: Display string	Read-write	Shows the name of the community string that is allowed to access the VLAN. Valid values: Up to 32 characters
snVlanByIpSubnetStaticPortList brcdIp.1.1.3.2.3.1.14 Syntax: Octet string	Read-write	This object is an index of ports that are configured to be members of the VLAN by IP Subnet. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.
snVlanByIpSubnetExcludePortList brcdIp.1.1.3.2.3.1.15 Syntax: Octet string	Read-write	This object is an index of ports that are excluded from port membership of the VLAN by IP Subnet. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.
snVlanByIpSubnetDynamicPortList brcdIp.1.1.3.2.3.1.16 Syntax: Octet string	Read-only	This object is an index of ports that can dynamically join the port membership of the VLAN by IP Subnet. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.

## VLAN by IPX network configuration table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

The following table applies to protocol VLANs that use the IPX routing protocol. Unless otherwise stated in the object description, all objects in this table apply to all devices.

Name, OID, and syntax	Access	Description
snVlanByIpXNetTable brcdIp.1.1.3.2.4	None	The VLAN by IPX network number table.
snVlanByIpXNetVlanId brcdIp.1.1.3.2.4.1.1 Syntax: Integer	Read-only	The VLAN ID index to both the VLAN by port information table and this table. Valid values: 1 – 4095
snVlanByIpXNetNetworkNum brcdIp.1.1.3.2.4.1.2 Syntax: OCTET STRING	Read-only	Shows the IPX Network Number. This object has four octets.
snVlanByIpXNetFrameType brcdIp.1.1.3.2.4.1.3 Syntax: Integer	Read-only	Shows the frame type for the Layer 3 VLAN: <ul style="list-style-type: none"> <li>notApplicable(0) – If none of the following options is selected</li> <li>ipxEthernet8022(1)</li> <li>ipxEthernet8023(2)</li> <li>ipxEthernetII(3)</li> <li>ipxEthernetSnap(4)</li> </ul> Each IPX Network Number must be assigned with one unique Frame type; otherwise, an SNMP-SET error will be returned.
snVlanByIpXNetDynamic brcdIp.1.1.3.2.4.1.4 Syntax: Integer	Read-write	Applies only to switches. Indicates whether or not dynamic port inclusion is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and syntax	Access	Description
snVlanByIpxNetStaticMask brcdIp.1.1.3.2.4.1.5 Syntax: PortMask	Read-write	Shows the VLAN by IPX network port membership applied in static mode.
snVlanByIpxNetExcludeMask brcdIp.1.1.3.2.4.1.6 Syntax: PortMask	Read-write	Shows the VLAN by IPX network port membership applied in exclusive mode.
snVlanByIpxNetRouterIntf brcdIp.1.1.3.2.4.1.7 Syntax: Integer	Read-write	Applies only to routers and is optional. It shows the virtual interface of a router to the VLAN. Valid values: 0 – 60; however, this object is not configured if an SNMP-Get is equal to zero.
snVlanByIpxNetRowStatus brcdIp.1.1.3.2.4.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snVlanByIpxNetDynamicMask brcdIp.1.1.3.2.4.1.9 Syntax: PortMask	Read-only	Shows the VLAN by IPX network active port membership.
snVlanByIpxNetChassisStaticMask brcdIp.1.1.3.2.4.1.10 Syntax: OCTET STRING	Read-write	This object has 32 octets and it is replaced by <a href="#">"snVlanByIpxNetStaticPortList"</a> . Shows the chassis VLAN by IPX network port membership applied in static mode.
snVlanByIpxNetChassisExcludeMask brcdIp.1.1.3.2.4.1.11 Syntax: OCTET STRING	Read-write	This object has 32 octets and it is replaced by <a href="#">"snVlanByIpxNetExcludePortList"</a> . Shows the chassis VLAN by IPX network port membership applied in exclusive mode.
snVlanByIpxNetChassisDynamicMask brcdIp.1.1.3.2.4.1.12 Syntax: OCTET STRING	Read-only	This object has 32 octets and it is replaced by <a href="#">"snVlanByIpxNetDynamicPortList"</a> . Shows the chassis VLAN by IPX network port membership.
snVlanByIpxNetVlanName brcdIp.1.1.3.2.4.1.13 Syntax: DisplayString	Read-write	Shows the name of the community string that can access this VLAN. Valid values: Up to 32 characters
snVlanByIpxNetStaticPortList brcdIp.1.1.3.2.4.1.14 Syntax: OCTET STRING	Read-write	Lists the membership of a VLAN by IPX network. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.

Name, OID, and syntax	Access	Description
snVlanByIpxNetExcludePortList brcdIp.1.1.3.2.4.1.15 Syntax: OCTET STRING	Read-write	Lists the ports that are excluded from the VLAN by IPX network membership. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.
snVlanByIpxNetDynamicPortList brcdIp.1.1.3.2.4.1.16 Syntax: OCTET STRING	Read-only	Lists the ports that can dynamically join the membership of the VLAN by IPX network. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.

## VLAN by AppleTalk cable configuration table

The following table applies to protocol VLANs that use the AppleTalk routing protocol.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snVlanByATCableTable brcdIp.1.1.3.2.5	None	A table of VLAN by AppleTalk network number.
snVlanByATCableVlanId brcdIp.1.1.3.2.5.1.1 Syntax: Integer	Read-only	The VLAN ID of a port VLAN to which the AppleTalk cable VLAN attaches. Valid values: 1 – 4095
snVlanByATCableIndex brcdIp.1.1.3.2.5.1.2 Syntax: Integer	Read-only	The AppleTalk cable VLAN index number.
snVlanByATCableRouterIntf brcdIp.1.1.3.2.5.1.3 Syntax: Integer	Read-write	Shows the virtual interface of a router to the AppleTalk Cable VLAN. Valid values: 0 – 60; however, an SNMP-Get will equal zero if this object is not configured. Only router products accept the SNMP-SET operation.
snVlanByATCableRowStatus brcdIp.1.1.3.2.5.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletesthe row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snVlanByATCableChassisStaticMask brcdIp.1.1.3.2.5.1.5 Syntax: OCTET STRING	Read-write	This object is replaced by the " <a href="#">snVlanByATCableStaticPortList</a> " object. Shows a list of ports that are statically configured to become port members of a VLAN. It has 32 octets.

Name, OID, and syntax	Access	Description
snVlanByATCableVlanName brcdIp.1.1.3.2.5.1.6 Syntax: DisplayString	Read-write	Shows the community string that can access this VLAN. Valid values: Up to 32 characters
snVlanByATCableStaticPortList brcdIp.1.1.3.2.5.1.7 Syntax: OCTET STRING	Read-write	Shows a list of port indices that are configured to join membership of the AppleTalk Cable VLAN. Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the other 8 bits are the port number.

## VLAN extended statistics

This section describes the MIB objects for the Virtual Local Area Network (VLAN) extended statistics supported on G2 products of Brocade MLX series and Brocade NetIron XMR devices.

Use the **extended-counters priority** command to configure a module to enable per-VLAN or per-port, or priority accounting (or extended counters) that applies to both ingress and egress counters. Use the **extended-counters routed-switched** command to configure the system to count switched and routed packets separately. The default value or the **no** form of the command configures the system to count switched and routed packets combined. All the counters reset to “0” when the state is changed. Also, the current counters that reset to “0” maintain an aggregate count. For more information, refer *Brocade MLXe and NetIron Family Configuration Guide*.

### NOTE

The Layer 2 VPN counters apply only to switched packets.

The following table lists the objects of extended statistics for VLAN.

Name, OID, and syntax	Access	Description
brcdVlanExtStatsTable brcdIp.1.1.3.2.8	None	Table contains the extended statistics for VLAN ports of G2 cards. These statistics apply to Layer 2 VLANs as well as port VLANs that are associated to IP interfaces (physical or VE).
brcdVlanExtStatsVlanId brcdIp.1.1.3.2.8.1.1 Syntax: BrcdVlanIdTC	None	The VLAN identifier (VLAN ID).
brcdVlanExtStatsIfIndex brcdIp.1.1.3.2.8.1.2 Syntax: InterfaceIndex	None	The ifIndex of the port belonging to this VLAN.
brcdVlanExtStatsPriorityId brcdIp.1.1.3.2.8.1.3 Syntax: PortPriorityTC	None	Identifies the port QoS priority. The values 1 through 8 internally map to priorities 0 through 7. The value 128 refers to the aggregate count bucket.
brcdVlanExtStatsInSwitchedPkts brcdIp.1.1.3.2.8.1.4 Syntax: Counter64	Read-only	The number of packets received by this port classified as belonging to this VLAN for switched packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns “0”.

Name, OID, and syntax	Access	Description
brcdVlanExtStatsInRoutedPkts brcdIp.1.1.3.2.8.1.5 Syntax: Counter64	Read-only	The number of packets received by this port classified as belonging to this VLAN for routed packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsInPkts brcdIp.1.1.3.2.8.1.6 Syntax: Counter64	Read-only	The number of packets received by this port classified as belonging to this VLAN for both switched and routed packets.
brcdVlanExtStatsOutSwitchedPkts brcdIp.1.1.3.2.8.1.7 Syntax: Counter64	Read-only	The number of packets transmitted by this port classified as belonging to this VLAN for switched packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsOutRoutedPkts brcdIp.1.1.3.2.8.1.8 Syntax: Counter64	Read-only	The number of packets transmitted by this port classified as belonging to this VLAN for routed packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsOutPkts brcdIp.1.1.3.2.8.1.9 Syntax: Counter64	Read-only	The number of packets transmitted by this port classified as belonging to this VLAN for both switched and routed packets.
brcdVlanExtStatsInSwitchedOctets brcdIp.1.1.3.2.8.1.10 Syntax: Counter64	Read-only	The bytes count received by this port classified as belonging to this VLAN for switched packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsInRoutedOctets brcdIp.1.1.3.2.8.1.11 Syntax: Counter64	Read-only	The bytes count received by this port classified as belonging to this VLAN for routed packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsInOctets brcdIp.1.1.3.2.8.1.12 Syntax: Counter64	Read-only	The bytes count received by this port classified as belonging to this VLAN for both switched and routed packets.
brcdVlanExtStatsOutSwitchedOctets brcdIp.1.1.3.2.8.1.13 Syntax: Counter64	Read-only	The bytes count transmitted by this port classified as belonging to this VLAN for switched packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsOutRoutedOctets brcdIp.1.1.3.2.8.1.14 Syntax: Counter64	Read-only	The bytes count transmitted by this port classified as belonging to this VLAN for routed packets. The value is applicable only if the system is configured to separately count the two types of packets. Otherwise, it returns "0".
brcdVlanExtStatsOutOctets brcdIp.1.1.3.2.8.1.15 Syntax: Counter64	Read-only	The bytes count transmitted by this port classified as belonging to this VLAN for both switched and routed packets.

## VLAN extended statistics for VPLS

The following table contains information for the extended VLAN accounting that applies to the Virtual Private LAN Service (VPLS) endpoint attached to the Customer Edge (CE) device.

### NOTE

Use the **snmp-server disable mib** *<mib-table-keyword>* command to disable the SNMP support for the table and use the **no** form of the command to re-enable the support. The overall SNMP-WALK performance is increased when the SNMP support is disabled for the table.

Name, OID, and syntax	Access	Description
brcdVplsEndptVlanExtStatsTable brcdIp.1.2.15.2.2.4	None	This table contains the VLAN extended statistics for VPLS endpoints. For more information, refer to <a href="#">“VPLS endpoint2 table”</a> .
brcdVplsEndptVlanExtStatsPriorityId brcdIp.1.2.15.2.2.4.1.1 Syntax: PortPriorityTC	None	Identifies the port QoS priority. The values 1 through 8 internally map to priorities 0 through 7. The value 128 indicates that priority-level accounting is not enabled.
brcdVplsEndptVlanExtStatsInPkts brcdIp.1.2.15.2.2.4.1.2 Syntax: Counter64	Read-only	The number of valid frames received by this endpoint from the Customer Edge (CE).
brcdVplsEndptVlanExtStatsOutPkts brcdIp.1.2.15.2.2.4.1.3 Syntax: Counter64	Read-only	The number of valid frames transmitted by this endpoint to the Customer Edge (CE).
brcdVplsEndptVlanExtStatsInOctets brcdIp.1.2.15.2.2.4.1.4 Syntax: Counter64	Read-only	The bytes count received by this endpoint from the Customer Edge (CE).
brcdVplsEndptVlanExtStatsOutOctets brcdIp.1.2.15.2.2.4.1.5 Syntax: Counter64	Read-only	The bytes count transmitted by this endpoint to the Customer Edge (CE).

## VLAN extended statistics for VLL and VLL-local endpoints

The following table contains information for the extended VLAN accounting that applies to the Virtual Leased Line (VLL) and VLL-local endpoints attached to the Customer Edge (CE) device.

Name, OID, and syntax	Access	Description
brcdVllEndptVlanExtStatsTable brcdIp.1.2.15.2.1.2	None	This table contains the VLAN extended statistics for VLL endpoints. For more information, refer to <a href="#">“VLL endpoint table”</a> .
brcdVllEndptVlanExtStatsPriorityId brcdIp.1.2.15.2.1.2.1.1 Syntax: PortPriorityTC	None	Identifies the port QoS priority. The values 1 through 8 internally map to priorities 0 through 7. The value 128 indicates that the priority-level accounting is not enabled.
brcdVllEndptVlanExtStatsInPkts brcdIp.1.2.15.2.1.2.1.2 Syntax: Counter64	Read-only	The number of valid frames received by this endpoint from the Customer Edge (CE).

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
brcdVIIEndptVlanExtStatsOutPkts brcdIp.1.2.15.2.1.2.1.3 Syntax: Counter64	Read-only	The number of valid frames transmitted by this endpoint to the Customer Edge (CE).
brcdVIIEndptVlanExtStatsInOctets brcdIp.1.2.15.2.1.2.1.4 Syntax: Counter64	Read-only	The bytes count received by this endpoint from the Customer Edge (CE).
brcdVIIEndptVlanExtStatsOutOctets brcdIp.1.2.15.2.1.2.1.5 Syntax: Counter64	Read-only	The bytes count transmitted by this endpoint to the Customer Edge (CE).

## 23 VLAN Layer 2 Switch MIB Definition



# Forwarding Database Group

## In this chapter

- [Forwarding database static table information. . . . .](#) 295

## Forwarding database static table information

The following table contains the forwarding database information for each station known to the system. There is one entry per station.

Name, OID, and syntax	Access	Description
snFdbTable brcdIp.1.1.3.4.1	None	The forwarding database static table.
snFdbStationIndex brcdIp.1.1.3.4.1.1.1 Syntax: Integer	Read-only	Shows the FDB Station index to the FDB Station table.
snFdbStationAddr brcdIp.1.1.3.4.1.1.2 Syntax: Integer	Read-write	Shows the snFdb's physical address. The physical address represents a MAC Station.
snFdbStationPort brcdIp.1.1.3.4.1.1.3 Syntax: Integer32	Read-write	Indicates the station slot or port number: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11 – Slot number (slot for chassis only).</li> </ul>
<b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.		
snFdbVlanId brcdIp.1.1.3.4.1.1.4 Syntax: Integer	Read-write	Indicates the Station VLAN ID.

Name, OID, and syntax	Access	Description
snFdbStationQos brcdIp.1.1.3.4.1.1.5 Syntax: Integer	Read-write	Shows the Quality of Service (QoS) values for the station: For stackable stations, the values can be: <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> </ul> For chassis stations, the values can be: <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>
snFdbStationType brcdIp.1.1.3.4.1.1.6 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.	Read-write	Shows the station type: <ul style="list-style-type: none"> <li>notSupported(0) – A read-only value: this product does not support multilayer switching.</li> <li>host(1) – Any MAC station.</li> <li>router(2) – A router-typed station.</li> </ul>
snFdbRowStatus brcdIp.1.1.3.4.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snFdbStationIfindex brcdIp.1.1.3.4.1.1.8 Syntax: InterfaceIndex	Read-write	Station interface index number.

# Port STP Configuration Group

## In this chapter

- [Port STP configuration groups](#) ..... 297

## Port STP configuration groups

The Spanning Tree Protocol (STP) eliminates Layer 2 loops in networks by selectively blocking some ports and allowing other ports to forward traffic based on global (bridge) and local (port) parameters you can configure.

### Port STP table

The following table applies to all other FastIron and NetIron devices, except the FastIron X series. These devices use snIfStpTable. The snIfStpTable replaces snPortStpTable.

#### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snPortStpTable brcdIp.1.1.3.5.1	None	A specific snPortStpTable consists of a number of switch ports. This table only exists if “snVlanByPortTable” on page 275 exists and “snVlanByPortStpMode” on page 276 is enabled for each VLAN.
snPortStpVlanId brcdIp.1.1.3.5.1.1.1 Syntax: Integer	Read-only	Shows the VLAN ID of the VLAN switch community. Valid values: 1 – 65535
snPortStpPortNum brcdIp.1.1.3.5.1.1.2 Syntax: Integer32	Read-only	Shows the port number of the switch: <ul style="list-style-type: none"> <li>• Bit 0 to 7 – Port number.</li> <li>• Bit 8 to 11 – Slot number (slot for chassis only).</li> </ul>
snPortStpPortPriority brcdIp.1.1.3.5.1.1.3 Syntax: Integer	Read-write	Shows the value of the priority field, which is contained in the first (in network byte order) octet of the Port ID. The second octet of the Port ID is given by the value of dot1dStpPort. The two octets combine to form the identity of the root bridge in a spanning tree (instance of STP). The bridge with the lowest value has the highest priority and is the root. Valid values: 8 – 255

Name, OID, and syntax	Access	Description
snPortStpPathCost brcdIp.1.1.3.5.1.1.4 Syntax: Integer	Read-write	<p>Shows the value of the dot1dStpPortPathCost, which is the port's path cost to reach the root bridge. When selecting among multiple links to the root bridge, STP chooses the link with the lowest path cost and blocks the other paths.</p> <p>IEEE 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN.</p> <p>Writing a value of zero to this object sets the path cost to a default value which automatically changes according to port speed.</p> <p>Reading a value of zero indicates an unknown path cost because the port speed cannot be determined due to the speed auto sense that is currently in progress.</p> <p>Each port type has its own default STP path cost:</p> <ul style="list-style-type: none"> <li>• 10 Mbps – 100</li> <li>• 100 Mbps – 19</li> <li>• Gigabit – 4</li> </ul> <p>Valid values: 0 – 65535</p> <p><b>NOTE:</b> Over the value of 65535, this MIB stays at the upper value and the user should access which has a bigger upper range value.</p>
snPortStpOperState brcdIp.1.1.3.5.1.1.5 Syntax: Integer	Read-only	<p>Indicates if the port STP entry is activated and is in running mode:</p> <ul style="list-style-type: none"> <li>• notActivated(0)</li> <li>• activated(1)</li> </ul> <p>Default: notActivated(0)</p>
snPortStpPortEnable brcdIp.1.1.3.5.1.1.6 Syntax: Integer	None	<p>Indicates whether or not the port is enabled:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snPortStpPortForwardTransitions brcdIp.1.1.3.5.1.1.7 Syntax: Integer32	None	<p>Shows the number of times this port has transitioned from the Learning state to the Forwarding state.</p>

Name, OID, and syntax	Access	Description
snPortStpPortState brcdIp.1.1.3.5.1.1.8 Syntax: Integer	Read-only	Shows the port's current state as defined by application of the Spanning Tree Protocol. This state controls what action a port takes when it receives a frame: <ul style="list-style-type: none"> <li>disabled(1) – The port is not participating in STP. This can occur when the port is disconnected or STP is disabled on the port.</li> <li>blocking(2) – STP has blocked Layer 2 traffic on this port to prevent a loop. The device or VLAN can reach the root bridge using another port with the forwarding(5) state. When a port is in this state, the port does not transmit or receive user frames, but the port does continue to receive STP BPDUs.</li> <li>listening(3) – STP is responding to a topology change and this port is listening for a BPDU from neighboring bridges in order to determine the new topology. No user frames are transmitted or received during this state.</li> <li>learning(4) – The port has passed the listening state and will change to the blocking or forwarding state, depending on the results of STP's reconvergence. The port does not transmit or receive user frames during this state. However, the device can learn the MAC addresses of frames that the port receives during this state and make corresponding entries in the MAC table.</li> <li>forwarding(5) – STP is allowing the port to send and receive frames.</li> <li>broken(6) – Ports that are malfunctioning are placed into this state by the bridge.</li> </ul>
snPortStpPortDesignatedCost brcdIp.1.1.3.5.1.1.9 Syntax: Integer32	Read-only	The cost to the root bridge as advertised by the designated bridge that is connected to this port. If the designated bridge is the root bridge itself, then the cost is 0. The identity of the designated bridge is shown in the Design Bridge field. This value is compared to the Root Path Cost field in the received bridge PDUs.
snPortStpPortDesignatedRoot brcdIp.1.1.3.5.1.1.10 Syntax: BridgeId	Read-only	The root bridge as recognized on this port. The value is the same as the root bridge ID listed in the Root ID field. Shows the unique ID of the root bridge. The root bridge is recorded as the root in the configuration BPDUs, which are transmitted by the designated bridge for the segment to which the port is attached.
snPortStpPortDesignatedBridge brcdIp.1.1.3.5.1.1.11 Syntax: BridgeId	Read-only	Shows the ID of the designated bridge. The designated bridge is the device that connects the network segment to the root bridge.
snPortStpPortDesignatedPort brcdIp.1.1.3.5.1.1.12 Syntax: OCTET STRING	Read-only	Shows the ID of the port on the designated bridge that connects to the root bridge on the network. This object has two octets.
snPortStpPortAdminRstp brcdIp.1.1.3.5.1.1.13 Syntax: Integer	Read-write	Enables or disables RSTP of a port which is a member of a VLAN. If the VLAN is not operating in RSTP, this object will return FALSE(2) and this object is not writable.

Name, OID, and syntax	Access	Description
snPortStpPortProtocolMigration brcdIp.1.1.3.5.1.1.14 Syntax: Integer	Read-write	When operating in RSTP (version 2) mode, writing TRUE(1) to this object forces this port to transmit RSTP BPDUs. Any other operation on this object has no effect and it always returns FALSE(2) when read.
snPortStpPortAdminEdgePort brcdIp.1.1.3.5.1.1.15 Syntax: Integer	Read-write	The administrative value of the Edge Port parameter. A value of TRUE(1) indicates that this port should be assumed as an edge port and a value of FALSE(2) indicates that this port should be assumed as a non-edge port.
snPortStpPortAdminPointToPoint brcdIp.1.1.3.5.1.1.16 Syntax: Integer	Read-write	The administrative point-to-point status of the LAN segment attached to this port. A value of TRUE(1) indicates that this port should always be treated as if it is connected to a point-to-point link. A value of FALSE(2) indicates that this port should be treated as having a shared media connection.

## STP table

### NOTE

The snPortStpTable was deprecated. It has been replaced by snIfStpTable.

Name, OID, and syntax	Access	Description
snIfStpTable brcdIp.1.1.3.5.2	None	A specific snIfStpTable consists of a number of switch ports. This table exists only if snVlanByPortCfgTable exists and snVlanByPortCfgStpMode is enabled for each VLAN.
snIfStpVlanId brcdIp.1.1.3.5.2.1.1 Syntax: Integer	Read-only	Shows the VLAN ID of the VLAN switch community. Valid values: 1 – 65535
snIfStpPortNum brcdIp.1.1.3.5.2.1.2 Syntax: InterfaceIndex	Read-only	Shows the port number of the switch that has the ifIndex value.
snIfStpPortPriority brcdIp.1.1.3.5.2.1.3 Syntax: Integer	Read-write	Shows the value of the priority field, which is contained in the first (in network byte order) octet of the (2 octet long) Port ID. The second octet of the Port ID is given by the value of dot1dStpPort. The two octets combine to form the identity of the root bridge in a spanning tree (instance of STP). The bridge with the lowest value has the highest priority and is the root. Valid values: 0 – 255
snIfStpCfgPathCost brcdIp.1.1.3.5.2.1.4 Syntax: Integer	Read-write	Shows the value of the dot1dStpPortPathCost, which is the port's path cost of paths towards the spanning tree root which include this port. 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN. Writing value zero to this object sets the path cost to a default value which automatically changes according to port speed. Valid values: 0 – 200000000
snIfStpOperState brcdIp.1.1.3.5.2.1.5 Syntax: Integer	Read-only	Indicates if the port STP entry is activated and is in running mode: <ul style="list-style-type: none"> <li>notActivated(0)</li> <li>activated(1)</li> </ul> Default: notActivated(0)

Name, OID, and syntax	Access	Description
snIfStpPortState brcdIp.1.1.3.5.2.1.8 Syntax: Integer	Read-only	Shows the port's current state as defined by application of the Spanning Tree Protocol. This state controls what action a port takes when it receives a frame: <ul style="list-style-type: none"> <li>disabled(1) – The port is not participating in STP. This can occur when the port is disconnected or STP is disabled on the port.</li> <li>blocking(2) – STP has blocked Layer 2 traffic on this port to prevent a loop. The device or VLAN can reach the root bridge using another port with the forwarding(5) state. When a port is in this state, the port does not transmit or receive user frames, but the port does continue to receive STP BPDUs.</li> <li>listening(3) – STP is responding to a topology change and this port is listening for a BPDU from neighboring bridges in order to determine the new topology. No user frames are transmitted or received during this state.</li> <li>learning(4) – The port has passed the listening state and will change to the blocking or forwarding state, depending on the results of STP's reconvergence. The port does not transmit or receive user frames during this state. However, the device can learn the MAC addresses of frames that the port receives during this state and make corresponding entries in the MAC table.</li> <li>forwarding(5) – STP is allowing the port to send and receive frames.</li> <li>broken(6) – Ports that are malfunctioning are placed into this state by the bridge.</li> <li>preforwarding(7)</li> </ul>
snIfStpPortDesignatedCost brcdIp.1.1.3.5.2.1.9 Syntax: Integer32	Read-only	The cost to the root bridge as advertised by the designated bridge that is connected to this port. This value is compared to the Root Path Cost field in received bridge PDUs.
snIfStpPortDesignatedRoot brcdIp.1.1.3.5.2.1.10 Syntax: BridgedId	Read-only	Shows the unique ID of the root bridge. The root bridge is recorded as the root in the configuration BPDUs, which are transmitted by the designated bridge for the segment to which the port is attached.
snIfStpPortDesignatedBridge brcdIp.1.1.3.5.2.1.11 Syntax: BridgedId	Read-only	Shows the ID of the designated bridge. The designated bridge is the device that connects the network segment to the root bridge.
snIfStpPortDesignatedPort brcdIp.1.1.3.5.2.1.12 Syntax: OCTET STRING	Read-only	Shows the ID of the port on the designated bridge that connects to the root bridge on the network. This object has two octets.
snIfStpPortAdminRstp brcdIp.1.1.3.5.2.1.13 Syntax: TruthVal	Read-write	Enables or disables RSTP of a port which is a member of a VLAN. If the VLAN is not operating in RSTP, this object will return FALSE(2) and this object is not writable.
snIfStpPortProtocolMigration brcdIp.1.1.3.5.2.1.14 Syntax: TruthVal	Read-write	When operating in RSTP (version 2) mode, writing TRUE(1) to this object forces this port to transmit RSTP BPDUs. Any other operation on this object has no effect and it always returns FALSE(2) when read.
snIfStpPortAdminEdgePort brcdIp.1.1.3.5.2.1.15 Syntax: TruthVal	Read-write	The administrative value of the edge port parameter. A value of TRUE(1) indicates that this port should be assumed as an edge port and a value of FALSE(2) indicates that this port should be assumed as a non-edge port.

Name, OID, and syntax	Access	Description
snIfStpPortAdminPointToPoint brcdIp.1.1.3.5.2.1.16 Syntax: TruthVal	Read-write	The administrative point-to-point status of the LAN segment attached to this port. A value of TRUE(1) indicates that this port should always be treated as if it is connected to a point-to-point link. A value of FALSE(2) indicates that this port should be treated as having a shared media connection.
snIfStpOperPathCost brcdIp.1.1.3.5.2.1.17 Syntax: Integer	Read-only	Shows the value of dot1dStpPortPathCost, which is the port's path cost of paths towards the spanning tree root which include this port. 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN. Reading value zero indicates an unknown path cost value because the port speed cannot be determined due to the speed auto sense in progress or the port link is down. Valid values: 0 – 200000000.
snIfStpPortRole brcdIp.1.1.3.5.2.1.18 Syntax: Integer	Read-only	The STP or RSTP port role: <ul style="list-style-type: none"> <li>• unknown(0)</li> <li>• alternate(1)</li> <li>• root(2)</li> <li>• designated(3)</li> <li>• backupRole(4)</li> <li>• disabledRole(5)</li> </ul>
snIfStpBPDUTransmitted brcdIp.1.1.3.5.2.1.19 Syntax: Counter32	Read-only	The STP or RSTP bridge protocol unit transmitted counter.
snIfStpBPDUReceived brcdIp.1.1.3.5.2.1.20 Syntax: Counter32	Read-only	The STP or RSTP bridge protocol unit received counter.
snIfRstpConfigBPDUReceived brcdIp.1.1.3.5.2.1.21 Syntax: Counter32	Read-only	The RSTP configuration bridge protocol unit received counter.
snIfRstpTCNBPDUReceived brcdIp.1.1.3.5.2.1.22 Syntax: Counter32	Read-only	The RSTP topology change notification bridge protocol unit received counter.
snIfRstpConfigBPDUTransmitted brcdIp.1.1.3.5.2.1.23 Syntax: Counter32	Read-only	The RSTP configuration bridge protocol unit transmitted counter.
snIfRstpTCNBPDUTransmitted brcdIp.1.1.3.5.2.1.24 Syntax: Counter32	Read-only	The RSTP topology change notification bridge protocol unit transmitted counter.



# MRP MIB Definition

## In this chapter

- [MRP table](#) ..... 303

## MRP table

The following table contains information about Metro Ring Protocol (MRP) MIB objects.

Name, OID, and syntax	Access	Description
snMetroRingTable brcdIp.1.1.3.29.2.1	None	The MRP table.
snMetroRingVlanId brcdIp.1.1.3.29.2.1.1.1 Syntax: Integer32	None	Identifies a VLAN that controls the metro ring.
snMetroRingId brcdIp.1.1.3.29.2.1.1.2 Syntax: Integer32	None	The metro ring identifier.
snMetroRingConfigState brcdIp.1.1.3.29.2.1.1.3 Syntax: Integer	Read-write	The state of the metro ring.
snMetroRingRole brcdIp.1.1.3.29.2.1.1.4 Syntax: Integer	Read-write	Shows the metro ring role: <ul style="list-style-type: none"> <li>• other(1) - None of the cases below.</li> <li>• master(2) - Device which originates RHP packets.</li> <li>• member(3) - Device which forwards RHP packets.</li> </ul>
snMetroRingHelloTime brcdIp.1.1.3.29.2.1.1.5 Syntax: Integer32	Read-write	The time interval to periodically transmit Ring Health Protocol (RHP) in milliseconds.
snMetroRingPreforwardingTime brcdIp.1.1.3.29.2.1.1.6 Syntax: Integer32	Read-write	The time interval that a metro ring stays in the preforwarding state before changing to the forwarding state (in milliseconds).
snMetroRingPort1 brcdIp.1.1.3.29.2.1.1.7 Syntax: InterfaceIndex	Read-write	The ifIndex value of port 1 to configure into the metro ring.
snMetroRingPort2 brcdIp.1.1.3.29.2.1.1.8 Syntax: InterfaceIndex	Read-write	The ifIndex value of port 2 to configure into the metro ring.
snMetroRingName brcdIp.1.1.3.29.2.1.1.9 Syntax: DisplayString	Read-write	The description of the metro ring.

Name, OID, and syntax	Access	Description
snMetroRingRowStatus brcdIp.1.1.3.29.2.1.1.10 Syntax: Integer	Read-write	Creates and deletes rows in the table, and controls whether they are used. Values are: <ul style="list-style-type: none"> <li>delete(3) - Deletes a row.</li> <li>create(4) - Creates a new row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows disappear immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuchName - No such row</li> <li>other(1) - Some other cases.</li> <li>valid(2) - The row exists and is valid.</li> </ul>
snMetroRingOperState brcdIp.1.1.3.29.2.1.1.11 Syntax: Integer	Read-only	Shows the metro ring operational state. Valid values: other(1), enabled(2), disabled(3)
snMetroRingTopoGroupId brcdIp.1.1.3.29.2.1.1.12 Syntax: Integer32	Read-only	The ID of the topology group that controls the metro ring.
snMetroRingRHPTxmitted brcdIp.1.1.3.29.2.1.1.13 Syntax: Counter32	Read-only	The Ring Health Protocol (RHP) transmitted counter.
snMetroRingRHPReceived brcdIp.1.1.3.29.2.1.1.14 Syntax: Counter32	Read-only	The Ring Health Protocol (RHP) received counter.
snMetroRingStateChanged brcdIp.1.1.3.29.2.1.1.15 Syntax: Counter32	Read-only	The counter for the number of times the ring state has changed.
snMetroRingTCRBPDUReceived brcdIp.1.1.3.29.2.1.1.16 Syntax: Counter32	Read-only	The topology change protocol received counter.
snMetroRingPriPort brcdIp.1.1.3.29.2.1.1.17 Syntax: InterfaceIndex	Read-only	The ifIndex value of the primary port.
snMetroRingSecPort brcdIp.1.1.3.29.2.1.1.18 Syntax: InterfaceIndex	Read-only	The ifIndex value of the secondary port.
snMetroRingPriPortState brcdIp.1.1.3.29.2.1.1.19 Syntax: Integer	Read-only	The state of the metro ring primary port: <ul style="list-style-type: none"> <li>other(1) - None of the cases below.</li> <li>preforwarding(2) - Port transmits RHP packets; port does not transmit data packets.</li> <li>forwarding(3) - Port transmits RHP and data packets.</li> <li>blocking(4) - Port receives RHP packets; does not receive data packets.</li> <li>disabled(5) - Port is disabled from the metro ring.</li> </ul>

Name, OID, and syntax	Access	Description
snMetroRingSecPortState brcdIp.1.1.3.29.2.1.1.20 Syntax: Integer	Read-only	The state of the metro ring secondary port: <ul style="list-style-type: none"> <li>• other(1) - None of the cases below.</li> <li>• preforwarding(2) - Port transmits RHP packets; port does not transmit data packets.</li> <li>• forwarding(3) - Port transmits RHP and data packets.</li> <li>• blocking(4) - Port receives RHP packets; does not receive data packets.</li> <li>• disabled(5) - Port is disabled from the metro ring.</li> </ul>
snMetroRingPriPortType brcdIp.1.1.3.29.2.1.1.21 Syntax: Integer	Read-only	The metro ring primary port type: <ul style="list-style-type: none"> <li>• other(1) - None of the cases below.</li> <li>• regular(2) - Port is configured to operate on a single ring.</li> <li>• tunnel(3) - Port is configured to operate on multiple rings.</li> </ul>
snMetroRingSecPortType brcdIp.1.1.3.29.2.1.1.22 Syntax: Integer	Read-only	The metro ring secondary port type: <ul style="list-style-type: none"> <li>• other(1) - None of the cases below.</li> <li>• regular(2) - Port is configured to operate on a single ring.</li> <li>• tunnel(3) - Port is configured to operate on multiple rings.</li> </ul>
snMetroRingPriPortActivePort brcdIp.1.1.3.29.2.1.1.23 Syntax: InterfaceIndex	Read-only	The ifIndex value of the active primary port.
snMetroRingSecPortActivePort brcdIp.1.1.3.29.2.1.1.24 Syntax: InterfaceIndex	Read-only	The ifIndex value of the active secondary port.



# Trunk Port Configuration Group

---

## In this chapter

- [Trunk port configuration group](#) ..... 307
- [Multi-slot trunk port table](#) ..... 307
- [Switch configuration summary group](#) ..... 308

## Trunk port configuration group

The trunk group feature allows you to manually configure multiple high-speed, load-sharing links between two switches or routers or between a switch and router and a server.

---

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

The following objects contain configuration of trunk port memberships.

Name, OID, and syntax	Access	Description
snTrunkTable brcdIp.1.1.3.6.1	None	The trunk port table. A specific snTrunkTable consists of a number of trunk port masks.
snTrunkIndex brcdIp.1.1.3.6.1.1.1 Syntax: Integer32	Read-only	Shows the number of the trunk port entries that can be configured. Valid values: 1 – 64
snTrunkPortMask brcdIp.1.1.3.6.1.1.2 Syntax: PortMask	Read-write	Shows the trunk port membership of the switch.
snTrunkType brcdIp.1.1.3.6.1.1.3 Syntax: Integer	Read-write	Indicates if the trunk port is connected to a switch or a server: <ul style="list-style-type: none"> <li>• switch(1)</li> <li>• server(2)</li> </ul>

---

## Multi-slot trunk port table

---

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

The following table applies to multi-slot trunk ports. The objects show the ports that are members of a trunk group and they apply to all devices unless otherwise specified in their descriptions.

Name, OID, and syntax	Access	Description
snMSTrunkTable brcdIp.1.1.3.6.2	None	The multi-slot trunk port configuration table.
snMSTrunkPortIndex brcdIp.1.1.3.6.2.1.1 Syntax: Integer32	Read-only	Identifies the port that is the primary port of a trunk group. For a module with Gigabit ports, the primary port is port 1, 3, 5, or 7. For a module with 10/100 ports, the primary port is port 1, 5, 9, 13, 17, or 21.
snMSTrunkPortList brcdIp.1.1.3.6.2.1.2 Syntax: OCTET STRING	Read-write	Contains a list of port indices that are members of a trunk group. Each port index is a 16-bit integer in big-endian order. The first port index must be the index of the primary port.
snMSTrunkType brcdIp.1.1.3.6.2.1.3 Syntax: Integer	Read-write	Specifies if the ports are connected to a switch or a server: <ul style="list-style-type: none"> <li>• switch(1)</li> <li>• server(2)</li> </ul>
snMSTrunkRowStatus brcdIp.1.1.3.6.2.1.4 Syntax: Integer	Read-write	Creates, deletes, or modifies an entry in this table: <ul style="list-style-type: none"> <li>• invalid(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> <li>• modify(5)</li> </ul>

The following table contains the objects for multi-slot trunk port configuration iftable.

Name, OID, and syntax	Access	Description
snMSTrunkIfTable brcdIp.1.1.3.6.3	None	The multi-slot trunk port configuration iftable.
snMSTrunkIfIndex brcdIp.1.1.3.6.3.1.1 Syntax: Integer32	Read-only	Identifies the port that is the primary port (IfIndex) of a trunk group. For a module with Gigabit ports, the primary port is port 1, 3, 5, or 7. For a module with 10/100 ports, the primary port is port 1, 5, 9, 13, 17, or 21.
snMSTrunkIfList brcdIp.1.1.3.6.3.1.2 Syntax: OCTET STRING	Read-write	Contains a list of port indices that are members of a trunk group. Each port index is a 16-bit integer in big-endian order. The first port index must be the index of the primary port (ifindex).
snMSTrunkIfType brcdIp.1.1.3.6.3.1.3 Syntax: Integer	Read-write	Specifies if the ports are connected to a switch or a server: <ul style="list-style-type: none"> <li>• switch(1)</li> <li>• server(2)</li> </ul>
snMSTrunkIfRowStatus brcdIp.1.1.3.6.3.1.4 Syntax: Integer	Read-write	Creates, deletes, or modifies an entry: <ul style="list-style-type: none"> <li>• invalid(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> <li>• modify(5)</li> </ul>

## Switch configuration summary group

The following object applies to all devices.

---

Name, OID, and syntax	Access	Description
snSwSummaryMode brcdIp.1.1.3.7.1 Syntax: Integer	Read-write	Indicates whether or not the switch configuration summary is enabled: <ul style="list-style-type: none"><li data-bbox="786 331 943 359">• disabled(0)</li><li data-bbox="786 363 943 390">• enabled(1)</li></ul> Default: disabled(0)
<b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.		

---

## 27 Trunk Port Configuration Group



# RADIUS Group

## In this chapter

- [RADIUS general group](#) . . . . . 311
- [RADIUS server table \(IPv4\)](#) . . . . . 313
- [RADIUS server table \(FastIron X series IPv6 devices\)](#) . . . . . 314

## RADIUS general group

You can use a Remote Authentication Dial In User Service (RADIUS) server to secure the following types of access to the switch or router:

- Telnet access
- SSH access
- Web management access
- Access to the Privileged EXEC level and CONFIG level of the CLI

The following objects provide information on RADIUS authentication and apply to all devices.

Name, OID, and syntax	Access	Description
snRadiusSNMPAccess brcdIp.1.1.3.12.1.1 Syntax: Integer	Read-only	Indicates if the RADIUS group MIB objects can be accessed by an SNMP manager: <ul style="list-style-type: none"> <li>• disabled(0) – All RADIUS group MIB objects return a “general error”.</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snRadiusEnableTelnetAuth brcdIp.1.1.3.12.1.2 Syntax: Integer	Read-write	Indicates if Telnet authentication as specified by the “snRadiusLoginMethod” object is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snRadiusRetransmit brcdIp.1.1.3.12.1.3 Syntax: Integer	Read-write	Indicates the number of authentication query retransmissions that can be sent to the RADIUS server. Valid values: 0 – 5 Default: 3
snRadiusTimeOut brcdIp.1.1.3.12.1.4 Syntax: Integer	Read-write	Specifies the number of seconds to wait for an authentication reply from the RADIUS server. Each unit is one second. Valid values: 0 – 60 Default: 3
snRadiusDeadTime brcdIp.1.1.3.12.1.5 Syntax: Integer	Read-write	Specifies the RADIUS server dead time. Each unit is one minute. Valid values: 0 – 5 Default: 3

Name, OID, and syntax	Access	Description
snRadiusKey brcdIp.1.1.3.12.1.6 Syntax: DisplayString	Read-write	Shows the authentication key as encrypted text. This object can have up to 64 characters. A write operation can only be done if the SET request uses SNMPv3 with data encrypted using a privacy key.
snRadiusLoginMethod brcdIp.1.1.3.12.1.7 Syntax: OCTET STRING	Read-write	Shows the sequence of authentication methods for the RADIUS server. Each octet represents a method for authenticating the user at login. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface.</li> <li>radius(2) – Authenticate by requesting the RADIUS server.</li> <li>local(3) – Authenticate by local user account table.</li> <li>line(4) – Authenticate by the Telnet password.</li> <li>tacplus(5) – Authenticate by requesting the TACACS Plus server.</li> <li>none(6) – Do not authenticate.</li> <li>tacacs(7) – Authenticate by requesting the TACACS server.</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.
snRadiusEnableMethod brcdIp.1.1.3.12.1.8 Syntax: OCTET STRING	Read-write	Shows the sequence of authentication methods for the RADIUS server. Each octet represents a method for authenticating the user after login, as the user enters the privilege mode of the command line interface. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface.</li> <li>radius(2) – Authenticate by requesting the RADIUS server.</li> <li>local(3) – Authenticate by local user account table.</li> <li>line(4) – Authenticate by the Telnet password.</li> <li>tacplus(5) – Authenticate by requesting the TACACS Plus server.</li> <li>none(6) – Do not authenticate.</li> <li>tacacs(7) – Authenticate by requesting the TACACS server.</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.
snRadiusWebServerMethod brcdIp.1.1.3.12.1.9 Syntax: OCTET STRING	Read-write	Shows the sequence of authentication methods. Each octet represents a method for authenticating the user who is accessing the Web server. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface.</li> <li>radius(2) – Authenticate by requesting the RADIUS server.</li> <li>local(3) – Authenticate by local user account table.</li> <li>line(4) – Authenticate by the Telnet password.</li> <li>tacplus(5) – Authenticate by requesting the TACACS Plus server.</li> <li>none(6) – Do not authenticate.</li> <li>tacacs(7) – Authenticate by requesting the TACACS server.</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.

Name, OID, and syntax	Access	Description
snRadiusSNMPServerMethod brcdIp.1.1.3.12.1.10 Syntax: OCTET STRING	Read-write	Shows the sequence of authentication methods. Each octet represents a method to authenticate the user who is accessing the SNMP server. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface.</li> <li>radius(2) – Authenticate by requesting the RADIUS server.</li> <li>local(3) – Authenticate by local user account table.</li> <li>line(4) – Authenticate by the Telnet password.</li> <li>tacplus(5) – Authenticate by requesting the TACACS Plus server.</li> <li>none(6) – Do not authenticate.</li> <li>tacacs(7) – Authenticate by requesting the TACACS server.</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.

## RADIUS server table (IPv4)

The following objects provide information on the RADIUS server and they apply to all IPv4 devices.

### NOTE

For FastIron X series IPv6 devices, refer to [“RADIUS server table \(FastIron X series IPv6 devices\)”](#).

Name, OID, and syntax	Access	Description
snRadiusServerTable brcdIp.1.1.3.12.2	None	RADIUS server table.
snRadiusServerIp brcdIp.1.1.3.12.2.1.1 Syntax: IpAddress	Read-only	Shows the RADIUS server IP address.
snRadiusServerAuthPort brcdIp.1.1.3.12.2.1.2 Syntax: Integer32	Read-write	Shows the UDP port number for authentication. Default: 1812
snRadiusServerAcctPort brcdIp.1.1.3.12.2.1.3 Syntax: Integer32	Read-write	Shows the UDP port number used for accounting. Default: 1813
snRadiusServerRowStatus brcdIp.1.1.3.12.2.1.4 Syntax: Integer	Read-write	Creates or deletes a RADIUS server table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>
snRadiusServerRowKey brcdIp.1.1.3.12.2.1.5 Syntax: DisplayString	Read-write	Shows the authentication key, displayed as encrypted text. Valid values: Up to 64 characters
snRadiusServerUsage brcdIp.1.1.3.12.2.1.6 Syntax: Integer	Read-write	Allows this server to be dedicated for a particular AAA activity: <ul style="list-style-type: none"> <li>default(1)</li> <li>authenticationOnly(2)</li> <li>authorizationOnly(3)</li> <li>accountingOnly(4)</li> </ul>

## RADIUS server table (FastIron X series IPv6 devices)

The following objects provide information on the RADIUS server. They apply to FastIron X series IPv6 devices.

---

### NOTE

The following table is not supported on the Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

Name, OID, and syntax	Access	Description
fdryRadiusServerTable brcdIp.1.1.8.1.1.1	None	RADIUS server table listing the RADIUS authentication servers.
fdryRadiusServerIndex brcdIp.1.1.8.1.1.1.1 Syntax: Unsigned32	None	The index to the RADIUS server table. A maximum of eight RADIUS servers are supported.
fdryRadiusServerAddrType brcdIp.1.1.8.1.1.1.2 Syntax: InetAddressType	Read-create	The RADIUS server IP address type. Supported types are: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
fdryRadiusServerAddr brcdIp.1.1.8.1.1.1.3 Syntax: InetAddress	Read-create	The RADIUS server IP address.
fdryRadiusServerAuthPort brcdIp.1.1.8.1.1.1.4 Syntax: Unsigned32	Read-create	The authentication UDP port number. Default: 1645
fdryRadiusServerAcctPort brcdIp.1.1.8.1.1.1.5 Syntax: Unsigned32	Read-create	The account UDP port number. Default: 1646
fdryRadiusServerRowKey brcdIp.1.1.8.1.1.1.6 Syntax: DisplayString	Read-create	The authentication key displayed as encrypted text. Valid values: Up to 32 characters
fdryRadiusServerUsage brcdIp.1.1.8.1.1.1.7 Syntax: ServerUsage	Read-create	Allows this server to be dedicated for a particular AAA activity.
fdryRadiusServerRowStatus brcdIp.1.1.8.1.1.1.8 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in the active(1) state, no objects in that row can be modified except this object.

---

# TACACS Group

---

## In this chapter

- TACACS general MIBs ..... 315
- TACACS server table (IPv4) ..... 316
- TACACS server table (FastIron X series IPv6 devices) ..... 316

## TACACS general MIBs

The Terminal Access Controller Access Control System (TACACS) or security protocols can be used to authenticate the following types of access to devices:

- Telnet access
- SSH access
- Access to management functions
- Web management access
- Access to the Privileged EXEC level and CONFIG level of the CLI

The TACACS and protocols define how authentication, authorization, and accounting (AAA) information is sent between a device and an authentication database on a TACACS server.

The following objects provide information on TACACS authentication and apply to all devices.

Name, OID, and syntax	Access	Description
snTacacsRetransmit brcdIp.1.1.3.13.1.1 Syntax: Integer	Read-write	Shows the number of authentication query retransmissions to the TACACS server. Valid values: 0 – 5 Default: 3
snTacacsTimeOut brcdIp.1.1.3.13.1.2 Syntax: Integer	Read-write	Specifies how many seconds to wait for an authentication reply from the TACACS server. Valid values: 0 – 15 Default: 3 seconds
snTacacsDeadTime brcdIp.1.1.3.13.1.3 Syntax: Integer	Read-write	Specifies the TACACS server dead time in minutes. Valid values: 0 – 5 Default: 3 minutes

Name, OID, and syntax	Access	Description
snTacacsKey brcdIp.1.1.3.13.1.4 Syntax: DisplayString	Read-write	Authentication key displayed as encrypted text. Valid values: Up to 64 characters A write operation can only be done if the SET request uses SNMPv3 with data encrypted using a privacy key.
snTacacsSNMPAccess brcdIp.1.1.3.13.1.5 Syntax: Integer	Read-only	Indicates whether the TACACS group MIB objects can be accessed by an SNMP manager: <ul style="list-style-type: none"> <li>disabled(0) – All TACACS group MIB objects return "general error".</li> <li>enabled(1)</li> </ul> Default: disabled(0)

## TACACS server table (IPv4)

The following objects provide information on the TACACS server. They apply to all IPv4 devices.

### NOTE

For FastIron IPv6 devices, refer to [“TACACS server table \(FastIron X series IPv6 devices\)”](#) on page 316.

Name, OID, and syntax	Access	Description
snTacacsServerTable brcdIp.1.1.3.13.2	None	TACACS server table.
snTacacsServerIp brcdIp.1.1.3.13.2.1.1 Syntax: IpAddress	Read-only	Shows the TACACS server IP address.
snTacacsServerAuthPort brcdIp.1.1.3.13.2.1.2 Syntax: Integer32	Read-write	Specifies the UDP port used for authentication. Default: 49
snTacacsServerRowStatus brcdIp.1.1.3.13.2.1.3 Syntax: Integer	Read-write	Creates or deletes a TACACS server table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>
snTacacsServerRowKey brcdIp.1.1.3.13.2.1.4 Syntax: DisplayString	Read-write	Authentication key displayed as encrypted text. Valid values: Up to 64 characters
snTacacsServerUsage brcdIp.1.1.3.13.2.1.5 Syntax: Integer	Read-write	Allows this server to be dedicated to a particular AAA activity: <ul style="list-style-type: none"> <li>default(1)</li> <li>authenticationOnly(2)</li> <li>authorizationOnly(3)</li> <li>accountingOnly(4)</li> </ul>

## TACACS server table (FastIron X series IPv6 devices)

The following objects provide information on the TACACS server. These objects apply to FastIron X series IPv6 devices.

**NOTE**

The following table is not supported on the Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
fdryTacacsServerTable brcdIp.1.1.9.1.1.1	None	The TACACS server table listing the TACACS authentication servers.
fdryTacacsServerIndex brcdIp.1.1.9.1.1.1.1 Syntax: Unsigned32	None	The index to the TACACS server table. The maximum of eight TACACS servers are supported.
fdryTacacsServerAddrType brcdIp.1.1.9.1.1.1.2 Syntax: InetAddrstype	Read-create	The TACACS server IP address type: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
fdryTacacsServerAddr brcdIp.1.1.9.1.1.1.3 Syntax: Inetaddress	Read-create	The TACACS server IP address.
fdryTacacsServerAuthPort brcdIp.1.1.9.1.1.1.4 Syntax: Unsigned32	Read-create	The UDP port used for authentication. Default: 49
fdryTacacsServerRowKey brcdIp.1.1.9.1.1.1.5 Syntax: DisplayString	Read-create	The authentication key displayed as encrypted text. Valid values: Up to 32 characters
fdryTacacsServerUsage brcdIp.1.1.9.1.1.1.6 Syntax: ServerUsage	Read-create	Allows this server to be dedicated to a particular AAA activity: Default: default
fdryTacacsServerRowStatus brcdIp.1.1.9.1.1.1.7 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except this object.





# 802.1X Authentication MIB

## In this chapter

- [802.1X authentication scalar group types](#) ..... 319
- [802.1X port statistics table](#) ..... 321
- [802.1X port configuration table](#) ..... 322
- [802.1x port state table](#) ..... 322
- [802.1X MAC sessions table](#) ..... 323
- [802.1x authentication global administration](#) ..... 324

## 802.1X authentication scalar group types

The 802.1X authentication scalar group provides information that is displayed in the outputs of the following CLI commands:

- `show dot1x`
- `show dot1x configuration all`
- `show dot1x configuration ethernet <port>`

### NOTE

The following sections present the SNMP MIB objects for 802.1X authentication. These MIB objects are supported on the FastIron LS, FastIron GS, Brocade FCX, FastIron SX, and FastIron WS devices.

Name, OID, and syntax	Access	Description
brcdDot1xAuthGlobalConfigQ uietperiod brcdIp.1.1.3.38.1.1 Syntax: Unsigned32	Read-write	If the Brocade device is unable to authenticate a client, this object shows the amount of time, in seconds, the Brocade device waits before it retries to authenticate that client. The allowed range is from 1 through 4294967294. Default: 60 seconds
brcdDot1xAuthGlobalConfigT xPeriod brcdIp.1.1.3.38.1.2 Syntax: Unsigned32	Read-write	When a client does not return an Extensible Authentication Protocol (EAP) response or identity frame, this object shows the amount of time, in seconds, the Brocade device waits before retransmitting the EAP-request or identity frame to the client. The allowed range is from 1 through 4294967294. Default: 30 seconds
brcdDot1xAuthGlobalConfigS uppTimeOut brcdIp.1.1.3.38.1.3 Syntax: Unsigned32	Read-write	When a supplicant (client) does not respond to an EAP-request frame, this object shows the amount of time, in seconds, before the Brocade device retransmits the frame. The allowed range is from 1 through 4294967294. Default: 30 seconds

Name, OID, and syntax	Access	Description
brcdDot1xAuthGlobalConfigAuthServerTimeOut brcdIp.1.1.3.38.1.4 Syntax: Unsigned32	Read-write	When the authentication server (RADIUS) does not respond to a message sent from the client, this object shows the amount of time, in seconds, before the Brocade device retransmits the message. The allowed range is from 1 through 4294967294. Default: 30 seconds
brcdDot1xAuthGlobalConfigMaxReq brcdIp.1.1.3.38.1.5 Syntax: Unsigned32	Read-write	The number of times the Brocade device retransmits an EAP-request or identity request frame if it does not receive an EAP-response or identity response frame from a client. Default: 2 times
brcdDot1xAuthGlobalConfigReAuthMax brcdIp.1.1.3.38.1.6 Syntax: Unsigned32	Read-write	The number of reauthentication attempts that are permitted before the port becomes unauthorized. Default: 2 times
brcdDot1xAuthGlobalConfigReAuthPeriod brcdIp.1.1.3.38.1.7 Syntax: Unsigned32	Read-write	How often (number of seconds) the device automatically reauthenticates clients when periodic reauthentication is enabled. The allowed range is from 1 through 4294967294. Default: 3600 seconds
brcdDot1xAuthGlobalConfigProtocolVersion brcdIp.1.1.3.38.1.8 Syntax: Unsigned32	Read-only	The EAP protocol version.
brcdDot1xAuthGlobalConfigTotalPortsEnabled brcdIp.1.1.3.38.1.9 Syntax: Unsigned32	Read-only	The total number of ports that have 802.1x enabled.
brcdDot1xAuthGlobalConfigReAuthStatus brcdIp.1.1.3.38.1.10 Syntax: EnabledStatus	Read-write	Enables or disables reauthentication globally. Default: disabled
brcdDot1xAuthGlobalConfigMaxSessionMaxAge brcdIp.1.1.3.38.1.11 Syntax: Unsigned32	Read-write	The maximum age of the 802.1x MAC session. A value from 0 through 65535.
brcdDot1xAuthGlobalConfigNoAgingDeniedSessions brcdIp.1.1.3.38.1.12 Syntax: EnabledStatus	Read-write	Enables or disables <b>mac-session-no aging</b> for denied sessions. Default: disabled
brcdDot1xAuthGlobalConfigNoAgingPermittedSessions brcdIp.1.1.3.38.1.13 Syntax: EnabledStatus	Read-write	Enables or disables <b>mac-session-no aging</b> for permitted sessions. Default: disabled
brcdDot1xAuthGlobalConfigAuthFailAction brcdIp.1.1.3.38.1.14 Syntax: Integer	Read-write	Configures the action to take when the authentication fails: <ul style="list-style-type: none"> <li>• blockTraffic(1)</li> <li>• restrictedVlan(2)</li> </ul>

## 802.1X port statistics table

The following table contains Extensible Authentication Protocol (EAP) information specific to interfaces. EAP is an authentication framework that provides common functions and negotiation of authentication methods called EAP methods (for example, EAP-MD5, EAP-TLS, and EAP-GTC). The statistics provided in this table are equivalent to those provided in the output of the following commands:

- **show dot1x statistics ethernet <port>**
- **show dot1x statistics all**

Name, OID, and syntax	Access	Description
brcdDot1xAuthPortStatRx EAPFrames brcdIp.1.1.3.38.2.1.1.1 Syntax: Counter32	Read-only	The total number of EAP over LAN (EAPOL) frames received on the port. The frames received include EAP frames.
brcdDot1xAuthPortStatTx EAPFrames brcdIp.1.1.3.38.2.1.1.2 Syntax: Counter32	Read-only	The number of EAPOL frames transmitted on the port.
brcdDot1xAuthPortStatRx EAPStartFrames brcdIp.1.1.3.38.2.1.1.3 Syntax: Counter32	Read-only	The number of EAPOL-Start frames received on the port.
brcdDot1xAuthPortStatRx EAPLogOffFrames brcdIp.1.1.3.38.2.1.1.4 Syntax: Counter32	Read-only	The number of EAPOL-Logoff frames received on the port.
brcdDot1xAuthPortStatRx EAPRespIdFrames brcdIp.1.1.3.38.2.1.1.5 Syntax: Counter32	Read-only	The number of EAP frames other than response or identity frames received on the port.
brcdDot1xAuthPortStatTx EAPReqIdFrames brcdIp.1.1.3.38.2.1.1.6 Syntax: Counter32	Read-only	The number of EAP-request or -identity frames transmitted on the port.
brcdDot1xAuthPortStatRx EAPInvalidFrames brcdIp.1.1.3.38.2.1.1.7 Syntax: Counter32	Read-only	The number of invalid EAPOL frames received on the port.
brcdDot1xAuthPortStatEA PLastFrameVersionRx brcdIp.1.1.3.38.2.1.1.8 Syntax: Unsigned32	Read-only	The version of the last EAP frame received.
brcdDot1xAuthPortStatRx EAPRespOrIdFrames brcdIp.1.1.3.38.2.1.1.9 Syntax: Counter32	Read-only	The number of received EAP response or identity frames on the port.

Name, OID, and syntax	Access	Description
brcdDot1xAuthPortStatRxLengthErrorFrame brcdIp.1.1.3.38.2.1.1.10 Syntax: Integer32	Read-only	The length of the EAP error frame received.
brcdDot1xAuthPortStatTxRequestFrames brcdIp.1.1.3.38.2.1.1.11 Syntax: Counter32	Read-only	The number of transmitted EAP request frames on the port.
brcdDot1xAuthPortStatLastEAPFrameSource brcdIp.1.1.3.38.2.1.1.12 Syntax: MacAddress	Read-only	The MAC address of the source from which the last EAP frame was received.

## 802.1X port configuration table

The following table contains configuration parameters specific to interfaces. The information in this table is equivalent to the output of the following CLI commands:

- **show dot1x port-control auto**
- **show dot1x port-control force-authorized**
- **show dot1x port-control force-unauthorized**
- **show dot1x configuration ethernet <port>**

Name, OID, and syntax	Access	Description
brcdDot1xAuthPortConfigPortControl brcdIp.1.1.3.38.3.1.1.1 Syntax: Integer	Read-write	The control type configured for the interface: <ul style="list-style-type: none"> <li>• forceUnauthorized(1) - The controlled port is placed unconditionally in the unauthorized state.</li> <li>• controlauto(2) - The controlled port is unauthorized until authentication takes place between the client and the RADIUS server.</li> <li>• forceAuthorized(3) - The controlled port is placed unconditionally in the authorized state.</li> </ul>
brcdDot1xAuthPortConfigFilterStrictSec brcdIp.1.1.3.38.3.1.1.2 Syntax: EnabledStatus	Read-write	Enables or disables filter strict security on the interface: <ul style="list-style-type: none"> <li>• enabled(1)</li> <li>• disabled(2)</li> </ul>
brcdDot1xAuthPortConfigDot1xOnPort brcdIp.1.1.3.38.3.1.1.3 Syntax: EnabledStatus	Read-write	Enables or disables 802.1x on an interface.

## 802.1x port state table

The following table contains the port-specific parameters indicating the dynamic state that the interface is in. The information in this table is equivalent to the information in the output of the **show dot1x configuration <port>** command.

Name, OID, and syntax	Access	Description
brcdDot1xAuthPortStateMacSessions brcdIp.1.1.3.38.4.1.1.1 Syntax: Unsigned32	Read-only	Number of 802.1x MAC sessions per port.
brcdDot1xAuthPortStateAuthMacSessions brcdIp.1.1.3.38.4.1.1.2 Syntax: Unsigned32	Read-only	Number of authorized MAC sessions per port.
brcdDot1xAuthPortStateOriginalPVID brcdIp.1.1.3.38.4.1.1.3 Syntax: Unsigned32	Read-only	The PVID (port's default VLAN ID) that was originally configured on the port (not dynamically assigned).
brcdDot1xAuthPortStatePVIDMacTotal brcdIp.1.1.3.38.4.1.1.4 Syntax: Unsigned32	Read-only	The number of devices transmitting untagged traffic on the port's PVID.
brcdDot1xAuthPortStatePVIDMacAuthorized brcdIp.1.1.3.38.4.1.1.5 Syntax: Unsigned32	Read-only	The number of devices transmitting untagged traffic on the port's PVID as a result of dynamic VLAN assignment.
brcdDot1xAuthPortStatePortVlanState brcdIp.1.1.3.38.4.1.1.6 Syntax: Integer	Read-only	The current VLAN state the port is in: <ul style="list-style-type: none"> <li>radius(1) - The port PVID was dynamically assigned by a RADIUS server.</li> <li>restricted(2) - The port PVID is the restricted VLAN.</li> <li>normal(3) - The port PVID is not set by a RADIUS server, nor is it the restricted VLAN.</li> </ul>
brcdDot1xAuthPortStatePVID brcdIp.1.1.3.38.4.1.1.7 Syntax: Unsigned32	Read-only	The 802.1X authentication default port VLAN ID.
brcdDot1xAuthPortStateRestrictedPVID brcdIp.1.1.3.38.4.1.1.8 Syntax: Unsigned32	Read-only	The restricted PVID.
brcdDot1xAuthPortStateRadiusAssignPVID brcdIp.1.1.3.38.4.1.1.9 Syntax: Unsigned32	Read-only	The RADIUS- assigned PVID.

## 802.1X MAC sessions table

The following table contains information about the 802.1X MAC sessions. The information in this table is equivalent to the information in the output of the following CLI commands:

- **show dot1x mac-sessions**
- **show dot1x mac-sessions ip-address**

Name, OID, and syntax	Access	Description
brcdDot1xAuthMacSessionAuthMac brcdIp.1.1.3.38.5.1.1.1 Syntax: MacAddress	NA	MAC address of the client, which represents the user name used for RADIUS authentication.
brcdDot1xAuthMacSessionUserName brcdIp.1.1.3.38.5.1.1.2 Syntax: SnmpAdminString	Read-only	User name of the 802.1x MAC session.
brcdDot1xAuthMacSessionIncomingVlanId brcdIp.1.1.3.38.5.1.1.3 Syntax: VlanId	Read-only	Incoming VLAN ID.
brcdDot1xAuthMacSessionCurrentVlanId brcdIp.1.1.3.38.5.1.1.4 Syntax: VlanId	Read-only	The VLAN to which the port is currently assigned.
brcdDot1xAuthMacSessionAccessStatus brcdIp.1.1.3.38.5.1.1.5 Syntax: Integer	Read-only	Authentication state of the 802.1X MAC session: <ul style="list-style-type: none"> <li>• permit(1)</li> <li>• blocked(2)</li> <li>• restrict(3)</li> <li>• init(4)</li> </ul>
brcdDot1xAuthMacSessionMaxAge brcdIp.1.1.3.38.5.1.1.6 Syntax: Unsigned32	Read-only	Maximum age of the MAC session in which the MAC address is authenticated.
brcdDot1xAuthMacSessionAddrType brcdIp.1.1.3.38.5.1.1.7 Syntax: InetAddressType	Read-only	IP address type of the client (supplicant): <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
brcdDot1xAuthMacSessionIpAddr brcdIp.1.1.3.38.5.1.1.8 Syntax: InetAddress	Read-only	The IP address of the client.
brcdDot1xAuthMacSessionAging brcdIp.1.1.3.38.5.1.1.9 Syntax: Integer	Read-only	The type of aging being performed: <ul style="list-style-type: none"> <li>• software(1)</li> <li>• hardware(2)</li> <li>• ena(3) - Aging has not started.</li> <li>• notapplicable(4) - Fake 802.1x MAC session.</li> </ul>

## 802.1x authentication global administration

The following scalar object enables or disables 802.1X authentication globally.

---

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
brcdDot1xAuthGlobalAdm inConfigStatus brcdIp.1.1.3.38.6.1 Syntax: EnabledStatus	Read-write	Enables or disables 802.1x authentication globally. Default: disabled

---





# DHCP Gateway List

---

## In this chapter

- DHCP gateway list table ..... 327
- DNS group (IPv4) ..... 327

## DHCP gateway list table

The following objects provide information on Dynamic Host Configuration Protocol (DHCP) gateways.

Name, OID, and syntax	Access	Description
snDhcpGatewayListTable brcdIp.1.1.3.8.1	None	A table of DHCP gateway addresses.
snDhcpGatewayListId brcdIp.1.1.3.8.1.1.1 Syntax: Integer	Read-only	Shows the ID for a DHCP gateway. Valid values: 1 – 32
snDhcpGatewayListAddrList brcdIp.1.1.3.8.1.1.2 Syntax: OCTET STRING	Read-write	Lists the DHCP gateway addresses in each DHCP gateway list. This list contains 1 to 8 IP addresses represented by octet strings. This object can have 4 to 32 octets.
snDhcpGatewayListRowStatus brcdIp.1.1.3.8.1.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row.</li> <li>• create(4) – Create a new row.</li> <li>• modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

## DNS group (IPv4)

The Domain Name System (DNS) resolver feature allows you to use a host name to perform Telnet, ping, and traceroute. You can also define a DNS domain on a Layer 2 Switch or Layer 3 switch and thereby recognize all hosts within that domain.

The following objects provide information on DNS. They apply to all IPv4 devices.

Name, OID, and syntax	Access	Description
snDnsDomainName brcdIp.1.1.3.9.1 Syntax: DisplayString	Read-write	Shows the DNS domain name. This object can have up to 80 characters.
snDnsGatewayIpAddrList brcdIp.1.1.3.9.2 Syntax: OCTET STRING	Read-write	Shows the DNS gateway IP addresses. This list contains up to four IP addresses, represented by octet strings. This object has 16 octets.

## IPv4 and IPv6 MIB table for DNS servers

The DNS address table lists the IPv4 and IPv6 DNS addresses. These objects apply to FastIron devices.

### NOTE

The snDnsDomainName and snDnsGatewayIpAddrList tables have been deprecated and replaced by fdryDnsDomainNameTable and fdryDnsServerAddressTable respectively.

The fdryDnsDomainNameTable and fdryDnsServerAddressTable combine IPv4 and IPv6 DNS Servers.

Name, OID, and syntax	Access	Description
fdryDnsServerTable brcdIp.1.1.3.34.2.1	None	The DNS address list table that lists the IPv4 and IPv6 DNS addresses.
fdryDnsServerAddrType brcdIp.1.1.3.34.2.1.1.1 Syntax: InetAddressType	None	The DNS IP address type: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
fdryDnsServerIndex brcdIp.1.1.3.34.2.1.1.2 Syntax: Unsigned32	None	The index to the DNS address table. Up to four DNS IP addresses are supported for each protocol (IPv4 and IPv6 ).
fdryDnsServerAddr brcdIp.1.1.3.34.2.1.1.3 Syntax: InetAddress	Read-create	The DNS IP address.
fdryDnsServerRowStatus brcdIp.1.1.3.34.2.1.1.4 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except for this object.

# MAC Filters

---

## In this chapter

- [MAC filters](#) ..... 329
- [MAC filter table](#) ..... 329
- [MAC filter port access table](#) ..... 330

## MAC filters

MAC layer filtering enables you to build access lists based on MAC layer headers in the Ethernet or IEEE 802.3 frame. You can filter on the source and destination MAC addresses as well as other information, such as the EtherType, LLC1 DSAP or SSAP numbers, and a SNAP EtherType. The filters apply to incoming traffic only.

---

### NOTE

MAC filter MIB objects are not supported on the Brocade NetIron XMR and Brocade MLX series devices.

---

## MAC filter table

The objects in the following table provide information on MAC filters.

Name, OID, and syntax	Access	Description
snMacFilterTable brcdIp.1.1.3.10.1	None	The MAC filter table.
snMacFilterIndex brcdIp.1.1.3.10.1.1.1 Syntax: Integer32	Read-only	The table index for a filter entry.
snMacFilterAction brcdIp.1.1.3.10.1.1.2 Syntax: Integer	Read-write	Indicates what action is to be taken if the MAC packet matches this filter: <ul style="list-style-type: none"> <li>• deny(0)</li> <li>• permit(1)</li> </ul>
snMacFilterSourceMac brcdIp.1.1.3.10.1.1.3 Syntax: MAC address	Read-write	Shows the source MAC address.
snMacFilterSourceMask brcdIp.1.1.3.10.1.1.4 Syntax: MAC address	Read-write	Shows the source MAC subnet mask.

Name, OID, and syntax	Access	Description
snMacFilterDestMac brcdIp.1.1.3.10.1.1.5 Syntax: MAC address	Read-write	Shows the destination MAC address.
snMacFilterDestMask brcdIp.1.1.3.10.1.1.6 Syntax: MAC address	Read-write	Shows the destination MAC subnet mask.
snMacFilterOperator brcdIp.1.1.3.10.1.1.7 Syntax: Integer	Read-write	Indicates the type of comparison to perform: <ul style="list-style-type: none"> <li>• equal(0)</li> <li>• notEqual(1)</li> <li>• less(2)</li> <li>• greater(3)</li> </ul>
snMacFilterFrameType brcdIp.1.1.3.10.1.1.8 Syntax: Integer	Read-write	Indicates the frame type: <ul style="list-style-type: none"> <li>• notUsed(0)</li> <li>• ethernet(1)</li> <li>• LLC(2)</li> <li>• snap(3)</li> </ul>
snMacFilterFrameTypeNum brcdIp.1.1.3.10.1.1.9 Syntax: Integer	Read-write	Shows the frame type number. Valid values: 0 – 65535 0 means that this object is not applicable.
snMacFilterRowStatus brcdIp.1.1.3.10.1.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row.</li> <li>• create(4) – Create a new row.</li> <li>• modify(5) – Modify an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

## MAC filter port access table

The following table shows information about the MAC filter port access.

### NOTE

The snMacFilterPortAccessTable is deprecated and it has been replaced by "[MAC filter ifaccess table](#)".

Name, OID, and syntax	Access	Description
snMacFilterPortAccessTable brcdIp.1.1.3.10.2	None	MAC filter port access table.
<b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.		
snMacFilterPortAccessPortIndex brcdIp.1.1.3.10.2.1.1 Syntax: Integer	Read-only	The port index. For FastIron and NetIron products, the port index value is from 1 through 42. For virtual router interfaces: <ul style="list-style-type: none"> <li>15 – Slot number</li> <li>1 through 60 – Virtual router port, which is the port number.</li> </ul>
snMacFilterPortAccessFilters brcdIp.1.1.3.10.2.1.2 Syntax: OCTET STRING	Read-write	Shows the filter numbers of the ports. The first octet corresponds to the first filter number, the second octet to the second filter number, and so on.
snMacFilterPortAccessRowStatus brcdIp.1.1.3.10.2.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## MAC filter ifaccess table

Name, OID, and syntax	Access	Description
snMacFilterIfAccessTable brcdIp.1.1.3.10.3	None	MAC filter port access table.
snMacFilterIfAccessPortIndex brcdIp.1.1.3.10.3.1.1 Syntax: InterfaceIndex	Read-only	The port or interface index.

Name, OID, and syntax	Access	Description
snMacFilterIfAccessFilters brcdIp.1.1.3.10.3.1.2 Syntax: OCTET STRING	Read-write	Shows the filter numbers of the ports. The first octet corresponds to the first filter number, the second octet to the second filter number, and so on.
snMacFilterIfAccessRowStatus brcdIp.1.1.3.10.3.1.3 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row.</li> <li>• create(4) – Create a new row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

# Port MAC Security

## In this chapter

- Port MAC security table . . . . . 333
- Port MAC security table . . . . . 333
- Port MAC security module statistics table . . . . . 334
- Port MAC security interface table . . . . . 335
- Port MAC security interface MAC table . . . . . 336
- Port MAC security autosave MAC table . . . . . 336
- Port MAC security global MIB group . . . . . 337
- Port monitor table . . . . . 337

Port MAC security MIBs are not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## Port MAC security table

The following table shows the same information as the **show port security mac** CLI command.

Name, OID, and syntax	Access	Description
snPortMacSecurityTable brcdIp.1.1.3.24.1.1.1	None	The port MAC security table.
snPortMacSecurityIfIndex brcdIp.1.1.3.24.1.1.1.1 Syntax: Unsigned32	Read-only	The ifIndex value (ID) of the Ethernet interface on which Port MAC security is enabled.
snPortMacSecurityResource brcdIp.1.1.3.24.1.1.1.2 Syntax: Integer	Read-only	Indicates how the MAC addresses on an interface are secured: <ul style="list-style-type: none"> <li>• local(1) – Local resource was used. The interface secures at least one secure MAC address entry. Each interface can store up to 64 local resources.</li> <li>• shared(2) – Shared resource was used. When an interface has secured enough MAC addresses to reach its limit for local resources, it can secure additional MAC addresses by using global or shared resources.</li> </ul>
snPortMacSecurityQueryIndex brcdIp.1.1.3.24.1.1.1.3 Syntax: Unsigned32	Read-only	An index for a MAC address entry that was secured for this interface.
snPortMacSecurityMAC brcdIp.1.1.3.24.1.1.1.4 Syntax: Integer	Read-only	The secured MAC address.

Name, OID, and syntax	Access	Description
snPortMacSecurityAgeLeft brcdIp.1.1.3.24.1.1.1.1.5 Syntax: Unsigned32	Read-only	The number of minutes the MAC address will remain secure. A value of 0 indicates no aging is in effect.
snPortMacSecurityShutdownStatus brcdIp.1.1.3.24.1.1.1.1.6 Syntax: Integer	Read-only	Indicates if the interface has been shut down due to a security violation: <ul style="list-style-type: none"> <li>up(1) – The port is up.</li> <li>down(2) – The port has been shut down.</li> </ul>
snPortMacSecurityShutdownTimeLeft brcdIp.1.1.3.24.1.1.1.1.7 Syntax: Unsigned32	Read-only	If the value of snPortMacSecurityShutdownStatus is down(2), this object shows the number of seconds before it is enabled again. If the value is up(1), this object shows 0.
snPortMacSecurityVlanId brcdIp.1.1.3.24.1.1.1.1.8 Syntax: Unsigned32	Read-only	Shows the VLAN membership of this interface. This object shows a value from 1 through 65535.

## Port MAC security module statistics table

The following table shows the same information as the **show port security statistics <module>** CLI command.

Name, OID, and syntax	Access	Description
snPortMacSecurityModuleStatisticsTable brcdIp.1.1.3.24.1.1.2	None	The port MAC security module statistics table that shows the port MAC security statistics for each module.
snPortMacSecurityModuleStatisticsSlotNum brcdIp.1.1.3.24.1.1.2.1.1 Syntax: Integer	Read-only	The slot number of the port MAC security module.
snPortMacSecurityModuleStatisticsTotalSecurityPorts brcdIp.1.1.3.24.1.1.2.1.2 Syntax: Unsigned32	Read-only	The total number of Ethernet interfaces on which MAC security is configured in this module.
snPortMacSecurityModuleStatisticsTotalSecureMACs brcdIp.1.1.3.24.1.1.2.1.3 Syntax: Unsigned32	Read-only	The total number of secure MAC addresses learned or configured in this module.
snPortMacSecurityModuleStatisticsTotalViolationCounts brcdIp.1.1.3.24.1.1.2.1.4 Syntax: Unsigned32	Read-only	The number of security violations that occurred in this module.
snPortMacSecurityModuleStatisticsTotalShutdownPorts brcdIp.1.1.3.24.1.1.2.1.5 Syntax: Unsigned32	Read-only	The number of Ethernet interfaces in this module that were shut down due to security violations.



## Port MAC security interface table

The following table shows the same information as the **show port security ethernet <slot/port>** CLI command.

Name, OID, and syntax	Access	Description
snPortMacSecurityIntfContentTable brcdIp.1.1.3.24.1.1.3	None	The port MAC security interface table that shows the port MAC security statistics for an Ethernet interface.
snPortMacSecurityIntfContentIfIndex x brcdIp.1.1.3.24.1.1.3.1.1 Syntax: InterfaceIndex	None	Shows the ifIndex value of the local interface.
snPortMacSecurityIntfContentSecurity brcdIp.1.1.3.24.1.1.3.1.2 Syntax: Integer	Read- write	Indicates whether MAC port security is enabled or disabled on this interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snPortMacSecurityIntfContentViolationType brcdIp.1.1.3.24.1.1.3.1.3 Syntax: Integer	Read-write	The port security violation type for this interface: <ul style="list-style-type: none"> <li>shutdown(0)</li> <li>restricted(1)</li> </ul>
snPortMacSecurityIntfContentShutdownTime brcdIp.1.1.3.24.1.1.3.1.4 Syntax: Unsigned32	Read-write	If snPortMacSecurityIntfContentViolationType is 0 (shutdown), this value indicates the number of seconds the interface shuts down when the violation occurs. If snPortMacSecurityIntfContentViolationType is 1 (restrict), this value will always be 0.
snPortMacSecurityIntfContentShutdownTimeLeft brcdIp.1.1.3.24.1.1.3.1.5 Syntax: Unsigned32	Read-only	If snPortMacSecurityIntfContentViolationType is 0 (shutdown), this value indicates the number of seconds before this interface will be re-enabled. If snPortMacSecurityIntfContentViolationType is 1 (restrict), this value will always be 0.
snPortMacSecurityIntfContentAgeOutTime brcdIp.1.1.3.24.1.1.3.1.6 Syntax: Unsigned32	Read-write	The amount of time, in minutes, the MAC addresses learned on this interface will remain secure. A value of 0 indicates no aging is in effect.
snPortMacSecurityIntfContentMaxLockedMacAllowed brcdIp.1.1.3.24.1.1.3.1.7 Syntax: Unsigned32	Read-write	The maximum number of secure MAC addresses that can be locked to this interface.
snPortMacSecurityIntfContentTotalMACs brcdIp.1.1.3.24.1.1.3.1.8 Syntax: Unsigned32	Read-only	The total number of secure MAC addresses that are locked to this interface.
snPortMacSecurityIntfContentViolationCounts brcdIp.1.1.3.24.1.1.3.1.9 Syntax: Unsigned32	Read-only	The total number of security violations that occurred on this interface.

## Port MAC security interface MAC table

The following table shows the same information as the **show port security mac ethernet** <slot/port> CLI command.

Name, OID, and syntax	Access	Description
snPortMacSecurityIntfMacTable brcdIp.1.1.3.24.1.1.4	None	The port MAC security interface MAC table that shows the port MAC security status for each Ethernet interface.
snPortMacSecurityIntfMacIfIndex brcdIp.1.1.3.24.1.1.4.1.1 Syntax: Integer	Read-only	Shows the ifIndex value of the local interface.
snPortMacSecurityIntfMacAddress brcdIp.1.1.3.24.1.1.4.1.2 Syntax: MAC Address	Read-only	The secure MAC addresses for this local Ethernet interface on which the secure MAC address is configured and learned. The maximum number of the secure MAC addresses is restricted by the object snPortMacSecurityIntfContentMaxLockedMacAllowed.
snPortMacSecurityIntfMacVlanId brcdIp.1.1.3.24.1.1.4.1.3 Syntax: Unsigned32	Read-write	The VLAN membership of this interface. A value of zero indicates it is not applicable.
snPortMacSecurityIntfMacRowStatus brcdIp.1.1.3.24.1.1.4.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Port MAC security autosave MAC table

The following table shows the same information as the **show port security autosave** CLI command.

Name, OID, and syntax	Access	Description
snPortMacSecurityAutosaveMacTable brcdIp.1.1.3.24.1.1.5	None	The port MAC security autosave MAC table that shows the secure MAC addresses that were saved automatically.
snPortMacSecurityAutosaveMacIfIndex brcdIp.1.1.3.24.1.1.5.1.1 Syntax: Integer32	Read-only	Shows the ifIndex value of the local interface.
snPortMacSecurityAutosaveMacResource brcdIp.1.1.3.24.1.1.5.1.2 Syntax: Integer32	Read-only	Indicates the resource used to autosave secure MAC addresses: <ul style="list-style-type: none"> <li>1 - Local</li> <li>2 - Shared</li> </ul>

Name, OID, and syntax	Access	Description
snPortMacSecurityAutosaveMacQueryIndex brcdIp.1.1.3.24.1.1.5.1.3 Syntax: Unsigned32	Read-only	The index entry within the given resource of the local interface on which MAC port security is autosaved.
snPortMacSecurityAutosaveMacAddress brcdIp.1.1.3.24.1.1.5.1.4 Syntax: MAC Address	Read-only	The secure MAC addresses for this local Ethernet interface on which the secure MAC address is autosaved.

## Port MAC security global MIB group

The following table shows the global MIBs for MAC port security.

Name, OID, and syntax	Access	Description
snPortMacGlobalSecurityFeature brcdIp.1.1.3.24.1.2.1 Syntax: Integer	Read-write	Indicates whether port security for this device is disabled or enabled: <ul style="list-style-type: none"> <li>0 - Disabled</li> <li>1 - Enabled</li> </ul>
snPortMacGlobalSecurityAgeOutTime brcdIp.1.1.3.24.1.2.2 Syntax: Unsigned32	Read-write	The amount of time, in minutes, the MAC addresses learned on this device will remain secure. A value of 0 indicates no aging is in effect.
snPortMacGlobalSecurityAutosave brcdIp.1.1.3.24.1.2.3 Syntax: Unsigned32	Read-write	The port security autosave value for this device.

## Port monitor table

The following table shows the status of port monitoring on an interface.

Name, OID, and syntax	Access	Description
snPortMonitorTable brcdIp.1.1.3.25.1	None	The port monitor table.

Name, OID, and syntax	Access	Description
snPortMonitorIfIndex brcdIp.1.1.3.25.1.1.1	None	Shows the ifIndex value of the local interface.
snPortMonitorMirrorList brcdIp.1.1.3.25.1.1.2 Syntax: DisplayString	Read-write	<p>Lists the monitoring status of each port.</p> <p>The values in this object are space delimited. They consist of a sequence of a port's ifIndex followed by the port's monitoring mode. Port monitoring mode can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Monitoring is off.</li> <li>• 1 – The port will monitor input traffic.</li> <li>• 2 – The port will monitor output traffic.</li> <li>• 3 – The port will monitor both input and output traffic.</li> </ul> <p>For example, you may see the following values: 65 2 66 1</p> <p>"65" may represent port 2/1 and "66" port 2/2.</p> <p>The entry means that port 2/1 is monitoring output traffic. Port 2/2 is monitoring input traffic.</p>

# MAC Authentication MIB Definition

## In this chapter

- [Multi-device port authentication](#) ..... 339
- [MAC clear interface multi-device port authentication objects](#) ..... 339
- [Multi-device port authentication objects](#) ..... 340
- [Multi-device port authentication clear sessions](#) ..... 340

## Multi-device port authentication

Multi-device port authentication is also known as MAC authentication. The following tables describe the multi-device port authentication MIB objects.

The following global objects are available for multi-device port authentication.

Name, OID, and syntax	Access	Description
snMacAuthClearGlobalCmd brcdIp.1.1.3.28.1.1 Syntax: Integer	Read-write	Clears MAC authentication on a global level: <ul style="list-style-type: none"> <li>• valid(0) - An SNMP-GET of this MIB shows that it is a valid command.</li> <li>• clear(1) - Represents a clear MAC authentication table for all ports.</li> </ul>
snMacAuthGlobalConfigState brcdIp.1.1.3.28.1.2 Syntax: Integer	Read-write	Enables or disables MAC authentication on a global level.

## MAC clear interface multi-device port authentication objects

The following clear interface objects are available for multi-device port authentication.

Name, OID, and syntax	Access	Description
snMacAuthClearIfCmdTable brcdIp.1.1.3.28.2	None	The status of clearing a MAC authentication entry for an interface.
snMacAuthClearIfCmdIndex brcdIp.1.1.3.28.2.1.1 Syntax: InterfaceIndex	None	The ifIndex value of the local interface on which a clear command is issued and monitored.
snMacAuthClearIfCmdAction brcdIp.1.1.3.28.2.1.2 Syntax: InterfaceIndex	Read-write	The action value of the local interface: <ul style="list-style-type: none"> <li>• valid(0) - An SNMP-GET of this command shows that it is valid.</li> <li>• clear(1) - Represents clearing a MAC authentication entry for an interface.</li> </ul>

## Multi-device port authentication objects

The following objects are available for multi-device port authentication.

Name, OID, and syntax	Access	Description
snMacAuthTable brcdIp.1.1.3.28.3	None	Displays the MAC authentication table.
snMacAuthIfIndex brcdIp.1.1.3.28.3.1.1 Syntax: InterfaceIndex	None	In order to identify a particular interface, this object identifies the instance of the ifIndex object, defined in RFC 2863.
snMacAuthVlanId brcdIp.1.1.3.28.3.1.2 Syntax: Integer	None	The ID of a VLAN of which the port is a member. The port must be untagged. For a tagged port that belongs to multiple VLANs, this object returns 0, which is an invalid VLAN ID value.
snMacAuthMac brcdIp.1.1.3.28.3.1.3 Syntax: MacAddress	None	MAC address to be authenticated.
snMacAuthState brcdIp.1.1.3.28.3.1.4 Syntax: Integer	Read-only	The state of MAC authentication.
snMacAuthTimeStamp brcdIp.1.1.3.28.3.1.5 Syntax: Object-Type	Read-only	Time stamp at which the MAC address was authenticated or failed to be authenticated.
snMacAuthAge brcdIp.1.1.3.28.3.1.6 Syntax: Integer	Read-only	Age of the MAC session in which the MAC address is authenticated.
snMacAuthDot1x brcdIp.1.1.3.28.3.1.7 Syntax: Integer	Read-only	Indicates whether dot1x is enabled or not.

## Multi-device port authentication clear sessions

The following clear sessions objects are available for multi-device port authentication.

Name, OID, and syntax	Access	Description
snMacAuthClearMacSessionTable brcdIp.1.1.3.28.4	None	The status of clearing a MAC session entry indexed by a MAC address.
snMacAuthClearMacSessionEntry brcdIp.1.1.3.28.4.1	None	An entry of clearing a MAC session entry indexed by a MAC address.
snMacAuthClearMacSessionIfIndex brcdIp.1.1.3.28.4.1.1 Syntax: InterfaceIndex	None	The ifIndex value of the local interface on which a clear command is issued and monitored.

Name, OID, and syntax	Access	Description
snMacAuthClearMacSessionMac brcdIp.1.1.3.28.4.1.2 Syntax: MacAddress	None	A MAC session entry indexed by a MAC address.
snMacAuthClearMacSessionAction brcdIp.1.1.3.28.4.1.3 Syntax: Integer	Read-write	The action value of the clear MAC session: <ul style="list-style-type: none"><li>• valid(0) - An SNMP-GET of this MIB shows that it is a valid command.</li><li>• clear(1) - Represents clearing a MAC session entry indexed by a MAC address.</li></ul>

## 34 MAC Authentication MIB Definition



# MAC VLAN MIB Definition

---

## In this chapter

- [MAC-based VLAN global scalar objects . . . . .](#) 343
- [MAC-based VLAN port table objects. . . . .](#) 343
- [MAC-based VLAN interface table objects. . . . .](#) 344
- [MAC-based VLAN table objects. . . . .](#) 344

## MAC-based VLAN global scalar objects

The following global scalar objects are available for MAC-based VLAN.

Name, OID, and syntax	Access	Description
fdryMacVlanGlobalClearOper brcdIp.1.1.3.32.1.1 Syntax: Integer	Read-write	The action value of the clear MAC session: <ul style="list-style-type: none"> <li>• valid(0) - This value is always returned when the variable is read.</li> <li>• clear(1) - Setting the variable to this value clears the operational MAC-based VLAN information for all ports.</li> </ul>
fdryMacVlanGlobalDynConfigSt ate brcdIp.1.1.3.32.1.2 Syntax: Integer	Read-write	Enables or disables MAC-based VLAN dynamic activation on the global level.

## MAC-based VLAN port table objects

The following objects are available for MAC-based VLAN port.

Name, OID, and syntax	Access	Description
fdryMacVlanPortMemberTable brcdIp.1.1.3.32.2.1	None	MAC-based VLAN port membership table.
fdryMacVlanPortMemberVlanI d brcdIp.1.1.3.32.2.1.1.1 Syntax: InterfaceIndex	None	The VLAN identifier.

Name, OID, and syntax	Access	Description
fdryMacVlanPortMemberPortId brcdIp.1.1.3.32.2.1.1.2 Syntax: Integer	None	The ifIndex of the port which is a member of the MAC-based VLAN.
fdryMacVlanPortMemberRowSt atus brcdIp.1.1.3.32.2.1.1.3 Syntax: RowSts	Read-write	This object is used to create and delete rows in the table.

## MAC-based VLAN interface table objects

The following objects are available for MAC-based VLAN interface.

Name, OID, and syntax	Access	Description
fdryMacVlanIfTable brcdIp.1.1.3.32.2.2	None	MAC-based VLAN interface table.
fdryMacVlanIfIndex brcdIp.1.1.3.32.2.2.1.1 Syntax: InterfaceIndex	None	The ifIndex of the interface which is a member of the MAC-based VLAN.
fdryMacVlanIfEnable brcdIp.1.1.3.32.2.2.1.2 Syntax: Integer	Read-write	The administrative status requested by management for MAC-based VLANs on this interface. The enabled(1) value indicates that MAC-based VLANs should be enabled on this interface. The disabled(2) value indicates that MAC-based VLANs are disabled on this interface.
fdryMacVlanIfMaxEntry brcdIp.1.1.3.32.2.2.1.3 Syntax: Integer32	Read-write	The maximum number of allowed and denied MAC addresses (static and dynamic) that can be learned on this interface. The value can be from 2 through 32. The default value is 2.
fdryMacVlanIfClearOper brcdIp.1.1.3.32.2.2.1.4 Syntax: Integer	Read-write	<ul style="list-style-type: none"> <li>valid(0) - This value is always returned when the variable is read.</li> <li>clear(1) - Setting the variable to this value clears the operational MAC-based VLAN information for a port.</li> </ul>
fdryMacVlanIfClearConfig brcdIp.1.1.3.32.2.2.1.5 Syntax: Integer	Read-write	<ul style="list-style-type: none"> <li>valid(0) - This value is always returned when the variable is read.</li> <li>clear(1) - Setting the variable to this value clears the configured MAC-based VLAN information for a port.</li> </ul>

## MAC-based VLAN table objects

The following objects are available for MAC-based VLAN.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
fdryMacBasedVlanTable brcdIp.1.1.3.32.2.3	None	MAC-based VLAN table.
fdryMacBasedVlanId brcdIp.1.1.3.32.2.3.1.1 Syntax: Integer	None	The VLAN ID for this entry.
fdryMacBasedVlanMac brcdIp.1.1.3.32.2.3.1.2 Syntax: MAC address	None	A host source MAC address to be authenticated.
fdryMacBasedVlanPriority brcdIp.1.1.3.32.2.3.1.3 Syntax: Integer32	Read-write	The priority of the source MAC address.
fdryMacBasedVlanRowStatus brcdIp.1.1.3.32.2.3.1.4 Syntax: RowSts	Read-write	This object is used to create and delete rows in the table.



# DHCP Snooping MIB Definition

## In this chapter

- [DHCP Snooping global scalar object](#) ..... 347
- [DHCP Snooping VLAN configuration table](#)..... 347
- [DHCP Snooping interface configuration table](#)..... 347
- [DHCP Snooping binding database table](#) ..... 348

## DHCP Snooping global scalar object

One scalar object can clear all entries in the DHCP binding database.

Name, OID, and syntax	Access	Description
fdryDhcpSnoopGlobalClearOper brcdIp.1.1.3.36.1.1. Syntax: ClearAction	Read-write	Determines if all entries in the DHCP database are cleared: <ul style="list-style-type: none"> <li>• valid(0) - This value is always returned when the variable is read.</li> <li>• clear(1) - Clears all entries in the DHCP binding database.</li> </ul>

## DHCP Snooping VLAN configuration table

The following table controls DHCP snooping per-VLAN configuration.

Name, OID, and syntax	Access	Description
fdryDhcpSnoopVlanConfigTable brcdIp.1.1.3.36.2.1	None	A table controls DHCP Snooping per VLAN. When a VLAN is created in a device supporting this table, a corresponding entry of this table is added.
fdryDhcpSnoopVlanVlanId brcdIp.1.1.3.36.2.1.1.1 Syntax: VlanIndex	None	This object indicates the VLAN number on which DHCP Snooping is configured.
fdryDhcpSnoopVlanDhcpSnoopEnable brcdIp.1.1.3.36.2.1.1.2 Syntax: TruthValue	Read-write	This object indicates whether DHCP Snooping is enabled in this VLAN. If set to "true", DHCP snooping is enabled. If set to "false" it is disabled.

## DHCP Snooping interface configuration table

The following objects is used to configure interface level DHCP Snooping.

Name, OID, and syntax	Access	Description
fdryDhcpSnoopIfConfigTable brcdIp.1.1.3.36.3.1	None	This table allows you to configure the trust state for DHCP Snooping at each physical interface.
fdryDhcpSnoopIfTrustValue brcdIp.1.1.3.36.3.1.1.1 Syntax: TruthValue	Read-write	DHCP packets received on this interface will be subjected to DHCP checks. This object indicates whether the interface is trusted for DHCP Snooping. If this object is set to "true", the interface is trusted. DHCP packets coming to this interface will be forwarded without checking. If this object is set to "false", the interface is not trusted.

## DHCP Snooping binding database table

The following table displays DHCP Snooping entries.

Name, OID, and syntax	Access	Description
fdryDhcpSnoopBindTable brcdIp.1.1.3.36.4.1	None	This table provides the information about the DHCP Snooping binding database learned by the device.
fdryDhcpSnoopBindIpAddress brcdIp.1.1.3.36.4.1.1.1 Syntax: IpAddress	None	The device IP address.
fdryDhcpSnoopBindMacAddress brcdIp.1.1.3.36.4.1.1.2 Syntax: MacAddress	Read-only	The device MAC address.
fdryDhcpSnoopBindType brcdIp.1.1.3.36.4.1.1.3 Syntax: ArpType	Read-only	The type of the ARP entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• static(2)</li> <li>• dynamic(3)</li> <li>• inspect(4)</li> <li>• dhcp(5)</li> <li>• dynamicDhcp(6)</li> <li>• staticDhcp(7)</li> <li>• host(8)</li> </ul>
fdryDhcpSnoopBindState brcdIp.1.1.3.36.4.1.1.4 Syntax: ArpState	Read-only	The state of the ARP entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• pending(3)</li> </ul>
fdryDhcpSnoopBindPort brcdIp.1.1.3.36.4.1.1.5 Syntax: DisplayString	Read-only	The port of the ARP entry.
fdryDhcpSnoopBindVlanId brcdIp.1.1.3.36.4.1.1.6 Syntax: VlanIndex	Read-only	This object indicates the VLAN number on which DHCP Snooping is configured.
fdryDhcpSnoopBindClearOper brcdIp.1.1.3.36.4.1.1.7 Syntax: ClearAction	Read-write	This object allows you to clear the entry from the DHCP binding database: <ul style="list-style-type: none"> <li>• valid(0) - Always returned when the variable is read.</li> <li>• clear(1) - Clears this entry in the DHCP binding database.</li> </ul>



## 36 DHCP Snooping MIB Definition



# IP Source Guard MIB Definition

---

## In this chapter

- [IP source guard interface configuration table . . . . .](#) 351
- [IP source guard per port per VLAN configuration table . . . . .](#) 351
- [IP source guard binding table . . . . .](#) 352

## IP source guard interface configuration table

The following objects are used to configure IP source guard on each interface.

Name, OID, and syntax	Access	Description
fdryIpSrcGuardIfConfigTable brcdIp.1.1.3.37.1.1	None	This table enables or disables IP source guard on each physical interface.
fdryIpSrcGuardIfEnable brcdIp.1.1.3.37.1.1.1 Syntax: TruthValue	Read-write	This object indicates whether IP source guard is enabled on this interface. If this object is set to "true", IP source guard is enabled. Traffic coming to this interface will be forwarding the traffic from the list of IP addresses obtained from DHCP Snooping. Otherwise, it is denied. If this object is set to "false", IP source guard is disabled.

## IP source guard per port per VLAN configuration table

The following objects are used to configure IP source guard on per port per VLAN.

Name, OID, and syntax	Access	Description
fdryIpSrcGuardPortVlanConfigTable brcdIp.1.1.3.37.2.1	None	This table enables or disables IP source guard per port per VLAN.
fdryIpSrcGuardPortVlanPortId brcdIp.1.1.3.37.2.1.1 Syntax: InterfaceIndex	None	The ifIndex of the port for IP source guard per port per VLAN.

Name, OID, and syntax	Access	Description
fdryIpSrcGuardPortVlanVlanId brcdIp.1.1.3.37.2.1.1.2 Syntax: VlanIndex	None	The number of VLANs for IP source guard per port per VLAN.
fdryIpSrcGuardPortVlanEnabled brcdIp.1.1.3.37.2.1.1.3 Syntax: TruthValue	Read-write	This object indicates whether IP source guard is enabled at this interface and this VLAN number. If this object is set to "true", IP source guard per port per VLAN is enabled. If this object is set to "false", IP source guard per port per VLAN is disabled.

## IP source guard binding table

The following table is used to configure IP source entries.

Name, OID, and syntax	Access	Description
fdryIpSrcGuardBindTable brcdIp.1.1.3.37.3.1	None	This table provides the IP addresses used for IP source guard on each physical interface with or without specific VLAN memberships.
fdryIpSrcGuardBindIpAddress brcdIp.1.1.3.37.3.1.1.1 Syntax: IpAddress	None	The IP address of the device.
fdryIpSrcGuardBindVlanId brcdIp.1.1.3.37.3.1.1.2 Syntax: VlanIndex	Read-create	This object indicates the specific VLAN memberships on this interface. The VLAN number is optional. If you configure a VLAN number, the binding applies only to that VLAN. If you do not configure a VLAN number, the static applies to all VLANs associated with the port. In this case, the VLAN number will be displayed as "0".
fdryIpSrcGuardBindRowStatus brcdIp.1.1.3.37.3.1.1.3 Syntax: RowStatus	Read-create	This variable is used to create or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except this object.
fdryIpSrcGuardBindMode brcdIp.1.1.3.37.3.1.1.4 Syntax: BindMode	Read-only	The mode of the IP source guard entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• active(2)</li> <li>• inactive(3)</li> </ul>
fdryIpSrcGuardBindType brcdIp.1.1.3.37.3.1.1.5 Syntax: BindType	Read-only	The type of the IP source guard entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• ip(2)</li> </ul>

## DAI MIB Definition

### In this chapter

- [DAI VLAN configuration table](#) ..... 353
- [DAI interface configuration table](#) ..... 353
- [DAI entry table](#) ..... 353

### DAI VLAN configuration table

The following objects are used to configure Dynamic ARP Inspection (DAI) VLAN.

Name, OID, and syntax	Access	Description
fdryDaiVlanConfigTable brcdIp.1.1.3.35.1.1	None	This table provides the mechanism to control DAI per VLAN.
fdryDaiVlanVlanId brcdIp.1.1.3.35.1.1.1 Syntax: VlanIndex	None	This object indicates the VLAN number on which DAI is configured.
fdryDaiVlanDynArpInspEn- able brcdIp.1.1.3.35.1.1.1.2 Syntax: TruthValue	Read-write	This object indicates whether DAI is enabled in this VLAN. If this object is set to “true”, DAI is enabled. If this object is set to “false”, DAI is disabled.

### DAI interface configuration table

The following objects are used to configure DAI on each interface.

Name, OID, and syntax	Access	Description
fdryDaiIfConfigTable brcdIp.1.1.3.35.2.1	None	This table allows you to configure the trust state for DAI purposes on each physical interface.
fdryDaiIfTrustValue brcdIp.1.1.3.35.2.1.1.1 Syntax: TruthValue	Read-write	This object indicates whether the interface is trusted for DAI. If this object is set to “true”, the interface is trusted. ARP packets coming to this interface will be forwarded without being checked. If this object is set to “false”, the interface is not trusted. ARP packets received on this interface will be subjected to ARP inspection.

### DAI entry table

The following table is used to display the DAI entries.

Name, OID, and syntax	Access	Description
fdryDaiArpInspectTable brcd.ip.1.1.3.35.3.1	None	This table controls DAI entries. When an IP address to MAC address mapping entry is created on a device supporting this table, a corresponding entry of this table will be added.
fdryDaiArpInspectIpAddress brcd.ip.1.1.3.35.3.1.1.1 Syntax: IpAddress	None	The IP address of the device.
fdryDaiArpInspectMacAddress brcd.ip.1.1.3.35.3.1.1.2 Syntax: MacAddress	Read-create	The MAC address of the device.
fdryDaiArpInspectRowStatus brcd.ip.1.1.3.35.3.1.1.3 Syntax: RowStatus	Read-create	This variable is used to create or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except this object.
fdryDaiArpInspectType brcd.ip.1.1.3.35.3.1.1.4 Syntax: ArpType	Read-only	The type of the ARP entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• static(2)</li> <li>• dynamic(3)</li> <li>• inspect(4)</li> <li>• dhcp(5)</li> <li>• dynamicDhcp(6)</li> <li>• staticDhcp(7)</li> <li>• host(8)</li> </ul>
fdryDaiArpInspectState brcd.ip.1.1.3.35.3.1.1.5 Syntax: ArpState	Read-only	The state of the ARP entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• pending(3)</li> </ul>
fdryDaiArpInspectAge brcd.ip.1.1.3.35.3.1.1.6 Syntax: Unsigned32	Read-only	The timer of the ARP entry.
fdryDaiArpInspectPort brcd.ip.1.1.3.35.3.1.1.7 Syntax: DisplayString	Read-only	The port of the ARP entry.

# Traffic Manager MIB Definition

## In this chapter

- [TM statistics information group](#) ..... 355
- [TM statistics table](#) ..... 356
- [TM VOQ statistics table](#) ..... 357
- [TM unicast VOQ statistics table](#) ..... 359
- [TM multicast VOQ statistics table](#) ..... 361
- [TM multicast stream VOQ statistics table](#) ..... 363
- [TM CPU VOQ statistics table](#) ..... 365
- [TM CPU VOQ information table](#) ..... 367

## TM statistics information group

### NOTE

This chapter describes the objects for the Traffic Manager (TM) statistics supported on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices.

Use the **clear tm statistics** CLI command to clear both the CLI and SNMP statistics counters for the Traffic Manager. Use the **clear tm-voq-stats** command to clear the VOQ statistics. The **snmp-server preserve-statistics** CLI command does not preserve the TM statistics.

This table contains information about the TM statistics information group on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

The **show tm port-mapping** CLI command displays information about the TM statistics information group.

Name, OID, and syntax	Access	Description
brcdTMPortMappingMaxPorts brcdIp.1.14.2.2.1.1 Syntax: Unsigned32	Read-only	Shows the maximum number of ports that are supported by the Traffic Manager on the system.
brcdTMPortMappingUsedPorts brcdIp.1.14.2.2.1.2 Syntax: Unsigned32	Read-only	Shows the currently used ports for this system
brcdTMPortMappingAvailablePorts brcdIp.1.14.2.2.1.3 Syntax: Unsigned32	Read-only	Shows the available ports on the system.

## TM statistics table

The following table contains the TM-related statistics. Use the **show tm statistics** CLI command to display information about the TM-related statistics.

This table contains information for the TM statistics on all the POS and the Ethernet 10/100/1000M/10G/100G cards.

Name, OID, and syntax	Access	Description
brcdTMStatsTable brcdIp.1.14.2.2.2	None	The Traffic Manager statistics table.
brcdTMStatsSlotId brcdIp.1.14.2.2.2.1.1 Syntax: Unsigned32	None	Shows the slot ID of the LP module that uniquely identifies a line card. The LP module must be physically present and operationally up.
brcdTMStatsTMDeviceId brcdIp.1.14.2.2.2.1.2 Syntax: Unsigned32	None	Shows the TM device ID that uniquely identifies the Network Processor TM within a line card in the system.
brcdTMStatsDescription brcdIp.1.14.2.2.2.1.3 Syntax: DisplayString	Read-only	Shows the range of ports serviced by brcdTMStatsTMDeviceId.
brcdTMStatsTotalIngressPktsCnt brcdIp.1.14.2.2.2.1.4 Syntax: Counter64	Read-only	Shows the count of all packets entering into the TM.
brcdTMStatsIngressEnqueuePkts brcdIp.1.14.2.2.2.1.5 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM.
brcdTMStatsEgressEnqueuePkts brcdIp.1.14.2.2.2.1.6 Syntax: Counter64	Read-only	Shows the count of all packets entering egress queues and forwarded out of the TM.
brcdTMStatsIngressEnqueueBytes brcdIp.1.14.2.2.2.1.7 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM. <b>NOTE:</b> This object is not supported on the NI-MLX-10Gx8-D 8-port 10GbE (D) module, NI-MLX-10Gx8-M 8-port 10GbE (M) module, and BR-MLX-100Gx2 cards. Zero is returned for these cards.
brcdTMStatsEgressEnqueueBytes brcdIp.1.14.2.2.2.1.8 Syntax: Counter64	Read-only	Shows the count of all bytes entering egress queues and forwarded out of the TM. <b>NOTE:</b> This object is not supported on the NI-MLX-10Gx8-D 8-port 10GbE (D) module, NI-MLX-10Gx8-M 8-port 10GbE (M) module, and BR-MLX-100Gx2 cards. Zero is returned for these cards.
brcdTMStatsIngressDequeuePkts brcdIp.1.14.2.2.2.1.9 Syntax: Counter64	Read-only	Shows the count of all packets dequeued from ingress queues and forwarded to the TM.

Name, OID, and syntax	Access	Description
brcdTMStatsIngressDequeueBytes brcdIp.1.14.2.2.2.1.10 Syntax: Counter64	Read-only	Shows the count of all bytes dequeued from ingress queues and forwarded to the TM.  <b>NOTE:</b> This object is not supported on the NI-MLX-10Gx8-D 8-port 10GbE (D) module, NI-MLX-10Gx8-M 8-port 10GbE (M) module, and BR-MLX-100Gx2 cards. Zero is returned for these cards.
brcdTMStatsIngressTotalQDiscardPkts brcdIp.1.14.2.2.2.1.11 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMStatsIngressTotalQDiscardBytes brcdIp.1.14.2.2.2.1.12 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMStatsIngressOldestDiscardPkts brcdIp.1.14.2.2.2.1.13 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMStatsIngressOldestDiscardBytes brcdIp.1.14.2.2.2.1.14 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMStatsEgressDiscardPkts brcdIp.1.14.2.2.2.1.15 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter egress queues on the TM.
brcdTMStatsEgressDiscardBytes brcdIp.1.14.2.2.2.1.16 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter egress queues on the TM.

## TM VOQ statistics table

The brcdTMDestUcastQStatTable contains information of the unicast queue counters aggregated across all the Traffic Managers (TMs) per destination interface. The following MIB objects are supported on the Brocade NetIron XMR and Brocade MLX Series devices and the table is not supported on the Brocade NetIron CES and Brocade NetIron CER series devices.

By default, the SNMP support for brcdTMDestUcastQStatTable is disabled. Use **tm-voq-collection [interval <seconds>]** command to enable Traffic Manager (TM) Virtual Output Queue (VOQ) statistics and **snmp-server enable mib tm-dest-qstat** command to enable the SNMP support.

Use **clear tm-voq-stats dst\_port [ ethernet | all ] <slot/port>** command to clear all the CLI and SNMP statistics counters for the TM VOQ statistics.

**NOTE**

Expect a delay or latency of 25 seconds in the reported statistics values because of internal caching of the statistics.

The Brocade NetIron devices can support the TM statistics aggregation only for traffic coming from the following card types:

- BR-MLX-10Gx8-X 8-port 10GbE Module
- NI-MLX-10Gx8-D 8-port 10GbE Module
- NI-MLX-10Gx8-M 8-port 10GbE (M) Module
- BR-MLX-100Gx2-X 2-port 100GbE Module
- NI-X-OC192x1 1-port OC192 STM64 Module
- NI-X-OC192x2 2-port OC192 STM64 Module
- NI-X-OC48x2 2-port OC48/12 STM16/STM4 Module
- NI-X-OC48x4 4-port OC48/12 STM16/STM4 Module
- NI-X-OC48x8 8-port OC48/12 STM16/STM4 Module
- NI-MLX-1Gx48-T 48-port 10/100/1000Base-T MRJ21 Module
- BR-MLX-1Gx24-X 24-port 10/100/1000Base-T Copper Module
- BR-MLX-1Gfx24-X 24-port 1GbE SFP Module

**NOTE**

The MIB objects in the following table are read-only and support only SNMP GET, GET-NEXT, WALK, and GET-BULK requests.

Name, OID, and syntax	Access	Description
brcdTMDestUcastQStatTable brcdIp.1.14.2.1.2.8	NA	The TM unicast queue counters aggregated across all the TMs per destination interface per priority table.
brcdTMDestUcastQStatDestIfIndex brcdIp.1.14.2.1.2.8.1.1 Syntax: InterfaceIndex	NA	The ifindex of the destination interface. The table includes all the interfaces of the LP modules that are physically present and operationally up and it also includes all the deployed LAG interfaces.
brcdTMDestUcastQStatPriority brcdIp.1.14.2.1.2.8.1.2 Syntax: PriorityTC	NA	The priority of the packets that are stored in the queue. This is a 1-based value. The priority0 maps to 1, priority1 maps to 2, and so on. The priority value equal to nonPriority(128) indicates the aggregated counters for the given destination port. When tm-max-queues is set to 4, the two consecutive priorities are stored in one unicast queue. Valid values: 1, 3, 5, 7, and 128
brcdTMDestUcastQStatEnquePkts brcdIp.1.14.2.1.2.8.1.3 Syntax: Counter64	Read-only	The total aggregated count of the packets entering an ingress queue across the TMs.
brcdTMDestUcastQStatEnqueBytes brcdIp.1.14.2.1.2.8.1.4 Syntax: Counter64	Read-only	The total aggregated count of the bytes entering an ingress queue across the TMs.



Name, OID, and syntax	Access	Description
brcdTMDestUcastQStatDequePkts brcdIp.1.14.2.1.2.8.1.5 Syntax: Counter64	Read-only	The total aggregated count of the packets that are dequeued or transmitted from an ingress queue across the TMs.
brcdTMDestUcastQStatDequeBytes brcdIp.1.14.2.1.2.8.1.6 Syntax: Counter64	Read-only	The total aggregated count of the bytes that are dequeued or transmitted from an ingress queue across the TMs.
brcdTMDestUcastQStatTotalQDiscardedPkts brcdIp.1.14.2.1.2.8.1.7 Syntax: Counter64	Read-only	For a VOQ, the total aggregated count across all the packets of TMs is discarded due to one of the following reasons: <ul style="list-style-type: none"> <li>• Before enqueueing, caused by WRED</li> <li>• When the maximum queue depth is reached</li> <li>• After enqueueing but before dequeuing, caused by aging</li> </ul>
brcdTMDestUcastQStatTotalQDiscardedBytes brcdIp.1.14.2.1.2.8.1.8 Syntax: Counter64	Read-only	For a VOQ, the total aggregated count across all the bytes of TMs is discarded due to one of the following reasons: <ul style="list-style-type: none"> <li>• Before enqueueing, caused by WRED</li> <li>• When the maximum queue depth is reached</li> <li>• After enqueueing but before dequeuing, caused by aging</li> </ul>

## TM unicast VOQ statistics table

The Traffic Manager(TM) unicast Virtual Output Queue (VOQ) statistics table contains information about the TM unicast VOQ-related statistics. Use the **show tm-voq-stat src\_port [ethernet | pos] <slot/port> dst\_port [ethernet | pos] <slot/port> [<priority> | all]** command for information about the TM unicast queue-related statistics.

### NOTE

The following table contains information about the TM unicast queue-related statistics on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

Name, OID, and syntax	Access	Description
brcdTMUcastQStatsTable brcdIp.1.14.2.2.3	None	The TM unicast VOQ statistics table.
brcdTMUcastQStatsSlotId brcdIp.1.14.2.2.3.1.1 Syntax: Unsigned32	None	Shows the slot ID of the LP module that uniquely identifies a line card. The LP module must be physically present and operationally up.
brcdTMUcastQStatsTMDeviceId brcdIp.1.14.2.2.3.1.2 Syntax: Unsigned32	None	Shows the TM device ID that uniquely identifies the Network Processor TM within a line card in the system.
brcdTMUcastQStatsDstIfIndex brcdIp.1.14.2.2.3.1.3 Syntax: InterfaceIndex	None	Shows the destination interface index. This is applicable only for the interface on the LP module that is physically present and operationally up.

Name, OID, and syntax	Access	Description
brcdTMUcastQStatsPriority brcdIp.1.14.2.2.3.1.4 Syntax: PriorityTC	None	Shows the priority of the packets that will be stored in this queue. This is a 1-based index. When the tm-max-queues is set to 4, two consecutive priorities are stored in one unicast queue. In this case, the valid values for this index are 1, 3, 5, and 7.
brcdTMUcastQStatsDescription brcdIp.1.14.2.2.3.1.5 Syntax: DisplayString	Read-only	This object gives the range of ports serviced by brcdTMUcastQStatsTMDeviceld and priorities serviced by this queue.
brcdTMUcastQStatsEnquePkts brcdIp.1.14.2.2.3.1.6 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM.
brcdTMUcastQStatsEnqueBytes brcdIp.1.14.2.2.3.1.7 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM.
brcdTMUcastQStatsDequePkts brcdIp.1.14.2.2.3.1.8 Syntax: Counter64	Read-only	Shows the count of all packets dequeued from ingress queues and forwarded to the TM.
brcdTMUcastQStatsDequeBytes brcdIp.1.14.2.2.3.1.9 Syntax: Counter64	Read-only	Shows the count of all bytes dequeued from ingress queues and forwarded to the TM.
brcdTMUcastQStatsDiscardPkts brcdIp.1.14.2.2.3.1.10 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMUcastQStatsTotalQDiscardBytes brcdIp.1.14.2.2.3.1.11 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMUcastQStatsTotalQOldestDiscardPkts brcdIp.1.14.2.2.3.1.12 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the Traffic Manager, but deleted later due to the buffer being full.
brcdTMUcastQStatsOldestDiscardBytes brcdIp.1.14.2.2.3.1.13 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMUcastQStatsWREDDroppedPkts brcdIp.1.14.2.2.3.1.14 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM but dropped due to WRED.

Name, OID, and syntax	Access	Description
brcdTMUcastQStatsWREDDroppedBytes brcdIp.1.14.2.2.3.1.15 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM but dropped due to WRED.
brcdTMUcastQStatsMaxQDepthSinceLastRead brcdIp.1.14.2.2.3.1.16 Syntax: Counter64	Read-only	Indicates the maximum queue depth since last access to read.
brcdTMUcastQStatsQSize brcdIp.1.14.2.2.3.1.17 Syntax: Unsigned32	Read-only	Shows the current size of the queue.
brcdTMUcastQStatsCreditCount brcdIp.1.14.2.2.3.1.18 Syntax: Unsigned32	Read-only	Shows the current credit count of the queue.

## TM multicast VOQ statistics table

The Traffic Manager multicast VOQ statistics table contains information about the queue-related statistics. Use the **show tm-voq-stat src\_port [ethernet | pos] <slot/port> multicast [<priority> | all]** CLI command for information about the TM multicast queue-related statistics.

### NOTE

The following table contains information about the TM multicast VOQ statistics on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

Name, OID, and syntax	Access	Description
brcdTMMcastQStatsTable brcdIp.1.14.2.2.4	None	The Traffic Manager multicast VOQ statistics table.
brcdTMMcastQStatsSlotId brcdIp.1.14.2.2.4.1.1 Syntax: Unsigned32	None	Shows the slot ID of the LP module that uniquely identifies a line card. The LP module must be physically present and operationally up.
brcdTMMcastQStatsTMDeviceId brcdIp.1.14.2.2.4.1.2 Syntax: Unsigned32	None	Shows the TM device ID that uniquely identifies the Network Processor TM within a line card in the system.
brcdTMMcastQStatsPriority brcdIp.1.14.2.2.4.1.3 Syntax: Integer	None	Shows the priority of the packets that will be stored in the queue. Two consecutive priorities are stored in one multicast queue. There are 4 multicast queues per TM for 8 priorities: <ul style="list-style-type: none"> <li>• Priority1And2 (1)</li> <li>• Priority3And4 (3)</li> <li>• Priority5And6 (5)</li> <li>• Priority7And8 (7)</li> </ul>
brcdTMMcastQStatsDescription brcdIp.1.14.2.2.4.1.4 Syntax: DisplayString	Read-only	This object gives the range of ports serviced by brcdTMMcastQStatsTMDeviceId and priorities serviced by the queue.

Name, OID, and syntax	Access	Description
brcdTMMcastQStatsEnquePkts brcdIp.1.14.2.2.4.1.5 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM.
brcdTMMcastQStatsEnqueBytes brcdIp.1.14.2.2.4.1.6 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM.
brcdTMMcastQStatsDequePkts brcdIp.1.14.2.2.4.1.7 Syntax: Counter64	Read-only	Shows the count of all packets dequeued from ingress queues and forwarded to the TM.
brcdTMMcastQStatsDequeBytes brcdIp.1.14.2.2.4.1.8 Syntax: Counter64	Read-only	Shows the count of all bytes dequeued from ingress queues and forwarded to the TM.
brcdTMMcastQStatsDiscardPkts brcdIp.1.14.2.2.4.1.9 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMMcastQStatsTotalQDiscardBytes brcdIp.1.14.2.2.4.1.10 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMMcastQStatsTotalQOldestDiscardPkts brcdIp.1.14.2.2.4.1.11 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMMcastQStatsOldestDiscardBytes brcdIp.1.14.2.2.4.1.12 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMMcastQStatsWREDDroppedPkts brcdIp.1.14.2.2.4.1.13 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but dropped due to WRED.
brcdTMMcastQStatsWREDDroppedBytes brcdIp.1.14.2.2.4.1.14 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but dropped due to WRED.
brcdTMMcastQStatsMaxQDepthSinceLastRead brcdIp.1.14.2.2.4.1.15 Syntax: Counter64	Read-only	Indicates the maximum queue depth since last access to read.

Name, OID, and syntax	Access	Description
brcdTMMcastQStatsQSize brcdIp.1.14.2.2.4.1.16 Syntax: Unsigned32	Read-only	Shows the current size of the queue.
brcdTMMcastQStatsCreditCount brcdIp.1.14.2.2.4.1.17 Syntax: Unsigned32	Read-only	Shows the current credit count of the queue.

## TM multicast stream VOQ statistics table

The Traffic Manager multicast stream VOQ statistics table contains the multicast stream queue-related statistics.

### NOTE

The following table contains information of the TM multicast stream queue-related statistics on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

Name, OID, and syntax	Access	Description
brcdTMMcastStreamQStatsTable brcdIp.1.14.2.2.5	None	The Traffic Manager multicast stream VOQ statistics table.
brcdTMMcastStreamQStatsAddressType brcdIp.1.14.2.2.5.1.1 Syntax: InetAddressType	None	Shows the value indicating the address family of the address contained in brcdTMMcastStreamQStatsSource and brcdTMMcastStreamQStatsGroup.
brcdTMMcastStreamQStatsSource brcdIp.1.14.2.2.5.1.2 Syntax: InetAddress	None	Shows the source IP address of the multicast stream.
brcdTMMcastStreamQStatsGroup brcdIp.1.14.2.2.5.1.3 Syntax: InetAddress	None	Shows the group IP address of the multicast stream.
brcdTMMcastStreamQStatsGroupPrefixLength brcdIp.1.14.2.2.5.1.4 Syntax: InetAddressPrefixLength	None	Shows the length in bits of the mask which, when combined with the corresponding value of brcdTMMcastStreamQStatsGroup, identifies the groups for which this entry contains queue statistics.
brcdTMMcastStreamQStatsPriority brcdIp.1.14.2.2.5.1.5 Syntax: Integer	Read-only	Shows the priority of the packets that will be stored in the queue. Two consecutive priorities are stored in one multicast stream queue: <ul style="list-style-type: none"> <li>• Priority1And2 (1)</li> <li>• Priority3And4 (3)</li> <li>• Priority5And6 (5)</li> <li>• Priority7And8 (7)</li> </ul>
brcdTMMcastStreamQStatsEnquePkts brcdIp.1.14.2.2.5.1.6 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM.

Name, OID, and syntax	Access	Description
brcdTMMcastStreamQStatsEnqueBytes brcdIp.1.14.2.2.5.1.7 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM.
brcdTMMcastStreamQStatsDequePkts brcdIp.1.14.2.2.5.1.8 Syntax: Counter64	Read-only	Shows the count of all packets dequeued from ingress queues and forwarded to the TM.
brcdTMMcastStreamQStatsDequeBytes brcdIp.1.14.2.2.5.1.9 Syntax: Counter64	Read-only	Shows the count of all bytes dequeued from ingress queues and forwarded to the TM.
brcdTMMcastStreamQStatsDiscardPkts brcdIp.1.14.2.2.5.1.10 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMMcastStreamQStatsTotalQDiscardBytes brcdIp.1.14.2.2.5.1.11 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMMcastStreamQStatsTotalQOldestDiscardPkts brcdIp.1.14.2.2.5.1.12 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMMcastStreamQStatsOldestDiscardBytes brcdIp.1.14.2.2.5.1.13 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMMcastStreamQStatsWREDDroppedPkts brcdIp.1.14.2.2.5.1.14 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but dropped due to WRED.
brcdTMMcastStreamQStatsWREDDroppedBytes brcdIp.1.14.2.2.5.1.15 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but dropped due to WRED.
brcdTMMcastStreamQStatsMaxQueueDepthSinceLastRead brcdIp.1.14.2.2.5.1.16 Syntax: Counter64	Read-only	Shows the maximum queue depth since last access to read.

Name, OID, and syntax	Access	Description
brcdTMMcastStreamQStatsQSize brcdIp.1.14.2.2.5.1.17 Syntax: Counter64	Read-only	Shows the current size of the queue.
brcdTMMcastStreamQStatsCreditCount brcdIp.1.14.2.2.5.1.18 Syntax: Counter64	Read-only	Shows the current credit count of the queue.

## TM CPU VOQ statistics table

The Traffic Manager CPU VOQ statistics table contains the CPU queue-related statistics. Use the **show tm-voq-stat src\_port [ethernet | pos] <slot/port> cpu-queue | cpu-copy-q [<priority> | all]** CLI command for information about the Traffic Manager (TM) CPU queue-related statistics.

### NOTE

The following table contains information about the Traffic Manager (TM) CPU queue-related statistics on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

Name, OID, and syntax	Access	Description
brcdTMCPuQStatsTable brcdIp.1.14.2.2.6	None	The Traffic Manager CPU VOQ statistics table.
brcdTMCPuQStatsSlotId brcdIp.1.14.2.2.6.1.1 Syntax: Unsigned32	None	Shows the slot ID of the LP module that uniquely identifies a line card. The LP module must be physically present and operationally up.
brcdTMCPuQStatsTMDeviceId brcdIp.1.14.2.2.6.1.2 Syntax: Unsigned32	None	Shows the TM device ID that uniquely identifies the Network Processor TM within a line card in the system.
brcdTMCPuQStatsType brcdIp.1.14.2.2.6.1.3 Syntax: Integer	None	Shows the type of the CPU queue: <ul style="list-style-type: none"> <li>CpuQ(1) - This queue contains the packets that do not fall under any of the following categories.</li> <li>CpuCopyQ(2) - This queue contains the packets related to SA learning, sFlow, RPF Log, ACL Log, and so on.</li> <li>CpuManagementQ(3) - This queue contains the CPU management packets.</li> <li>CpuProtocolQ(4) - This queue contains the CPU protocol packets.</li> </ul>
brcdTMCPuQStatsPriority brcdIp.1.14.2.2.6.1.4 Syntax: PriorityTC	None	Shows the priority of the packets that is stored in the queue. This is a 1-based index. The priority0 maps to 1, priority1 maps to 2, and so on.
brcdTMCPuQStatsDescription brcdIp.1.14.2.2.6.1.5 Syntax: DisplayString	Read-only	Shows the range of ports serviced by brcdTMCPuQStatsTMDeviceId.
brcdTMCPuQStatsEnquePkts brcdIp.1.14.2.2.6.1.6 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM.

Name, OID, and syntax	Access	Description
brcdTMCPuQStatsEnqueBytes brcdIp.1.14.2.2.6.1.7 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM.
brcdTMCPuQStatsDequePkts brcdIp.1.14.2.2.6.1.8 Syntax: Counter64	Read-only	Shows the count of all packets dequeued from ingress queues and forwarded to the TM.
brcdTMCPuQStatsDequeBytes brcdIp.1.14.2.2.6.1.9 Syntax: Counter64	Read-only	Shows the count of all bytes dequeued from ingress queues and forwarded to the TM.
brcdTMCPuQStatsDiscardPkts brcdIp.1.14.2.2.6.1.10 Syntax: Counter64	Read-only	Shows the count of all packets failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMCPuQStatsTotalQDiscardBytes brcdIp.1.14.2.2.6.1.11 Syntax: Counter64	Read-only	Shows the count of all bytes failing to enter ingress queues on the TM. This may be due to the following reasons: <ul style="list-style-type: none"> <li>The queue reaches its maximum depth, WRED, or other reasons.</li> <li>The Network Processor drops the packets due to an unknown Layer 3 route, RPF, or segment filtering.</li> </ul>
brcdTMCPuQStatsTotalQOldestDiscardPkts brcdIp.1.14.2.2.6.1.12 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMCPuQStatsOldestDiscardBytes brcdIp.1.14.2.2.6.1.13 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but deleted later due to the buffer being full.
brcdTMCPuQStatsWREDDroppedPkts brcdIp.1.14.2.2.6.1.14 Syntax: Counter64	Read-only	Shows the count of all packets entering ingress queues on the TM, but dropped due to WRED.
brcdTMCPuQStatsWREDDroppedBytes brcdIp.1.14.2.2.6.1.15 Syntax: Counter64	Read-only	Shows the count of all bytes entering ingress queues on the TM, but dropped due to WRED.
brcdTMCPuQStatsMaxQDepthSinceLastRead brcdIp.1.14.2.2.6.1.16 Syntax: Counter64	Read-only	Shows the maximum queue depth since last access to read.
brcdTMCPuQStatsQSize brcdIp.1.14.2.2.6.1.17 Syntax: Counter64	Read-only	Shows the current size of the queue.
brcdTMCPuQStatsCreditCount brcdIp.1.14.2.2.6.1.18 Syntax: Counter64	Read-only	Shows the current credit count of the queue.



## TM CPU VOQ information table

The Traffic Manager CPU VOQ information table is used for profiling the CPU queue size and credit count at regular intervals. It is advised for the SNMP manager to request the complete row in a single GET or GET-NEXT request for profiling.

### NOTE

The following table displays information about the TM CPU queue on the NI-MLX-1Gx48-T, NI-MLX-1Gx24, NI-MLX-10Gx8, BR-MLX-100Gx2, and all the POS modules.

Name, OID, and syntax	Access	Description
brcdTMCPUQInfoTable brcdIp.1.14.2.2.7	None	The Traffic Manager CPU VOQ information table.
brcdTMCPUQInfoSlotId brcdIp.1.14.2.2.7.1.1 Syntax: Unsigned32	None	Shows the slot ID of the LP module that uniquely identifies a line card. The LP module must be physically present and operationally up.
brcdTMCPUQInfoTMDeviceId brcdIp.1.14.2.2.7.1.2 Syntax: Unsigned32	None	Shows the TM device ID that uniquely identifies the Network Processor TM within a line card in the system.
brcdTMCPUQInfoPriority0QSize brcdIp.1.14.2.2.7.1.3 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority 0.
brcdTMCPUQInfoPriority0CreditCount brcdIp.1.14.2.2.7.1.4 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority 0.
brcdTMCPUQInfoPriority1QSize brcdIp.1.14.2.2.7.1.5 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority1.
brcdTMCPUQInfoPriority1CreditCount brcdIp.1.14.2.2.7.1.6 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority1.
brcdTMCPUQInfoPriority2QSize brcdIp.1.14.2.2.7.1.7 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority2.
brcdTMCPUQInfoPriority2CreditCount brcdIp.1.14.2.2.7.1.8 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority2.
brcdTMCPUQInfoPriority3QSize brcdIp.1.14.2.2.7.1.9 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority3.
brcdTMCPUQInfoPriority3CreditCount brcdIp.1.14.2.2.7.1.10 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority3.
brcdTMCPUQInfoPriority4QSize brcdIp.1.14.2.2.7.1.11 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority4.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
brcdTMCPuQInfoPriority4CreditCount brcdIp.1.14.2.2.7.1.12 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority4.
brcdTMCPuQInfoPriority5QSize brcdIp.1.14.2.2.7.1.13 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority5.
brcdTMCPuQInfoPriority5CreditCount brcdIp.1.14.2.2.7.1.14 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority5.
brcdTMCPuQInfoPriority6QSize brcdIp.1.14.2.2.7.1.15 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority6.
brcdTMCPuQInfoPriority6CreditCount brcdIp.1.14.2.2.7.1.16 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority6.
brcdTMCPuQInfoPriority7QSize brcdIp.1.14.2.2.7.1.17 Syntax: Unsigned32	Read-only	Shows the size of the CPU queue for the priority7.
brcdTMCPuQInfoPriority7CreditCount brcdIp.1.14.2.2.7.1.18 Syntax: Unsigned32	Read-only	Shows the credit count of the CPU queue for the priority7.

# IPv4 ACL MIB Definition

## In this chapter

- IPv4 ACL table ..... 369
- ACL bind to port table ..... 376
- ACL port table ..... 377
- ACL accounting table..... 378
- Textual conventions..... 380
- Layer 2 ACL next clause table..... 380
- Layer 2 ACL configuration table ..... 381
- Layer 2 ACL binding configuration table ..... 384

## IPv4 ACL table

The IPv4 ACL table contains the access control lists (ACLs) defined for the device. The `snAgAcIgbIcUrRowIndex` object determines the number of ACLs that can be added to this table.

Use the following table to create IPv6 ACLs on FastIron IPv6 devices. Apply the ACLs to interfaces using `snAgAcIbIndToPortTable`.

### NOTE

The following table is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
<code>snAgAcITable</code> <code>brcdIp.1.2.2.15.2</code>	None	Access control list table.
<code>snAgAcIIndex</code> <code>brcdIp.1.2.2.15.2.1.1</code> Syntax: Integer32	Read-only	Shows the index for an ACL entry that is associated with this ACL. This number must be unique among all the entries, even though the value of other objects for an entry may be the same as those of another entry.
<code>snAgAcINumber</code> <code>brcdIp.1.2.2.15.2.1.2</code> Syntax: AcINumber	Read-write	The access control list number for an entry: <ul style="list-style-type: none"> <li>• 1 to 99 – Standard access list</li> <li>• 100 to 199 – Extended access list</li> </ul>
<code>snAgAcIName</code> <code>brcdIp.1.2.2.15.2.1.3</code> Syntax: DisplayString	Read-write	Shows the ACL name.

Name, OID, and syntax	Access	Description
snAgAclAction brcdIp.1.2.2.15.2.1.4 Syntax: Integer	Read-write	<p>Indicates if IP packets that matched this access control list are permitted or denied:</p> <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul> <p>The default action when no ACLs are configured on a device is to permit all traffic. However, once you configure an ACL and apply it to a port, the default action for that port is to deny all traffic that is not explicitly permitted on the port.</p> <ul style="list-style-type: none"> <li>If you want to tightly control access, configure ACLs consisting of permit entries for the access you want to permit. The ACLs implicitly deny all other access.</li> <li>If you want to secure access in environments with many users, you might want to configure ACLs that consist of explicit deny entries, then add an entry to permit all access to the end of each ACL. The software permits packets that are not denied by the deny entries.</li> </ul>
snAgAclProtocol brcdIp.1.2.2.15.2.1.5 Syntax: IPProtocol	Read-write	<p>Indicates the protocol denied or permitted by the extended ACL.</p> <p>The protocol can be one of the following well-known names or any protocol number from 0 through 255:</p> <ul style="list-style-type: none"> <li>Internet Control Message Protocol (ICMP)</li> <li>Internet Group Management Protocol (IGMP)</li> <li>Internet Gateway Routing Protocol (IGRP)</li> <li>Internet Protocol (IP)</li> <li>Open Shortest Path First (OSPF)</li> <li>Transmission Control Protocol (TCP)</li> <li>User Datagram Protocol (UDP)</li> </ul> <p>Entering "0" indicates any protocol.</p>
snAgAclSourceIp brcdIp.1.2.2.15.2.1.6 Syntax: IpAddress	Read-write	<p>Applies only to extended ACLs.</p> <p>Identifies the source IP address of the packet that will either be permitted or denied.</p>
snAgAclSourceMask brcdIp.1.2.2.15.2.1.7 Syntax: IpAddress	Read-write	<p>Applies only to extended ACLs.</p> <p>Identifies the source IP subnet mask of the packet that will either be permitted or denied.</p>

Name, OID, and syntax	Access	Description
snAgAcIsourceOperator brcdIp.1.2.2.15.2.1.8 Syntax: Operator	Read-write	Applies only to TCP or UDP ports in extended ACLs. Indicates how the policy will be compared to the ports specified in the “snAgAcIsourceOperand1” and “snAgAcIsourceOperand2” objects: <ul style="list-style-type: none"> <li>eq(0) – The policy applies only to packets whose source port number matches the port number specified in the objects.</li> <li>neq(1) – The policy applies only to packets whose source port numbers are not included in the specified range.</li> <li>lt(2) – The policy applies only to packets whose source port numbers are less than those in the specified range.</li> <li>gt(3) – The policy applies only to packets whose source port numbers are greater than those in the specified range.</li> <li>range(4) – The policy applies to packets whose source port numbers fall within the specified range.</li> <li>undefined(7)</li> </ul>
snAgAcIsourceOperand1 brcdIp.1.2.2.15.2.1.9 Syntax: Integer	Read-write	Applies only to TCP or UDP ports in extended ACLs. Shows the source port number to be matched. If used with the “snAgAcIsourceOperand2” object, it defines the start of the range of source port numbers to be matched. Valid values: 0 – 65535. A value of 0 means that this object is not applicable.
snAgAcIsourceOperand2 brcdIp.1.2.2.15.2.1.10 Syntax: Integer	Read-write	Applies only to TCP or UDP ports in extended ACLs. Used with the “snAgAcIsourceOperand1” object, it defines the end of the range of source port numbers to be matched. Valid values: 0 – 65535. A value of 0 means that this object is not applicable.
snAgAcIdestinationIp brcdIp.1.2.2.15.2.1.11 Syntax: IpAddress	Read-write	Applies only to extended ACLs. Identifies the destination IP address of the packet that can either be permitted or denied.
snAgAcIdestinationMask brcdIp.1.2.2.15.2.1.12 Syntax: IpAddress	Read-write	Applies only to extended ACLs. Identifies the destination subnet mask of the packet that can either be permitted or denied.

Name, OID, and syntax	Access	Description
snAgAcIDestinationOperator brcdIp.1.2.2.15.2.1.13 Syntax: Operator	Read-write	<p>Applies only to TCP or UDP ports in extended ACLs. Indicates how the policy will be compared to the ports specified in the “snAgAcIDestinationOperand1” and “snAgAcIDestinationOperand2” objects:</p> <ul style="list-style-type: none"> <li>eq(0) – The policy applies only to packets whose destination port number matches the port number specified in the objects.</li> <li>neq(1) – The policy applies only to packets whose destination port numbers are not included in the specified range.</li> <li>lt(2) – The policy applies only to packets whose destination port numbers are less than those in the specified range.</li> <li>gt(3) – The policy applies only to packets whose destination port numbers are greater than those in the specified range.</li> <li>range(4) – The policy applies to packets whose destination port numbers fall within the specified range.</li> <li>undefined(7)</li> </ul>
snAgAcIDestinationOperand1 brcdIp.1.2.2.15.2.1.14 Syntax: Integer	Read-write	<p>Applies only to TCP or UDP ports in extended ACLs. Shows the destination port number to be matched. If used with the “snAgAcIDestinationOperand2” object, it defines the start of the range of destination port numbers to be matched.</p> <p>Valid values: 0 – 65535. A value of 0 means that this object is not applicable.</p>
snAgAcIDestinationOperand2 brcdIp.1.2.2.15.2.1.15 Syntax: Integer	Read-write	<p>Applies only to TCP or UDP ports in extended ACLs. Used with the “snAgAcIDestinationOperand1” object, it defines the end of the range of destination port numbers to be matched.</p> <p>Valid values: 0 – 65535. A value of 0 means that this object is not applicable.</p>
snAgAcIPrecedence brcdIp.1.2.2.15.2.1.16 Syntax: PrecedenceValue	Read-write	<p>Applies only to extended ACLs. Indicates the IP precedence value that a packet must have to be permitted or denied:</p> <ul style="list-style-type: none"> <li>routine(0)</li> <li>priority(1)</li> <li>immediate(2)</li> <li>flash(3)</li> <li>flash-override(4)</li> <li>critical(5)</li> <li>internet(6)</li> <li>network(7)</li> </ul> <p>The following priorities specify a hardware-forwarding queue: routine(0), priority(1), immediate(2), and flash(3).</p>

Name, OID, and syntax	Access	Description
snAgAcITos brcdIp.1.2.2.15.2.1.17 Syntax: TosValue	Read-write	Applies only to extended ACLs. Indicates the type of service a packet must have to be denied or permitted: <ul style="list-style-type: none"> <li>normal(0) – The ACL matches packets that have the normal TOS. If TOS is not defined, packets are matched to this value.</li> <li>minMonetaryCost(1) – The ACL matches packets that have the minimum monetary cost TOS.</li> <li>maxReliability(2) – The ACL matches packets that have the maximum reliability TOS.</li> <li>maxThroughput(4) – The ACL matches packets that have the maximum throughput TOS.</li> <li>minDelay(8) – The ACL matches packets that have the minimum delay TOS.</li> </ul>
snAgAcIEstablished brcdIp.1.2.2.15.2.1.18 Syntax: Integer	Read-write	Applies only to extended ACLs. Enables or disables the filtering of established TCP packets that have the ACK or RESET flag turned on. This additional filter only applies to TCP transport protocol: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snAgAcILogOption brcdIp.1.2.2.15.2.1.19 Syntax: TruthVal	Read-write	Determines if ACL matches are logged: <ul style="list-style-type: none"> <li>false(0) – Do not log ACL matches.</li> <li>true(1) – Log ACL matches.</li> </ul>
snAgAcIStandardFlag brcdIp.1.2.2.15.2.1.20 Syntax: TruthVal	Read-write	Indicates if this is a standard ACL: <ul style="list-style-type: none"> <li>false(0) – The ACL is an extended ACL.</li> <li>true(1) – The ACL is a standard ACL.</li> </ul>
snAgAcIRowStatus brcdIp.1.2.2.15.2.1.21 Syntax: SnRowStatus	Read-write	Creates or deletes an ACL entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>
snAgAcIFlowCounter brcdIp.1.2.2.15.2.1.22 Syntax: Counter64	Read-only	Shows an approximate count of flows that match the individual ACL entry.
snAgAcIPacketCounter brcdIp.1.2.2.15.2.1.23 Syntax: Counter64	Read-only	Shows the number of packets that matched the ACL entry.
snAgAcIComments brcdIp.1.2.2.15.2.1.24 Syntax: DisplayString	Read-write	Indicates the description of an individual ACL entry.
snAgAcIPriority brcdIp.1.2.2.15.2.1.25 Syntax: Integer	Read-write	Indicates the QoS priority option for this ACL. This priority assigns traffic that matches the ACL to a hardware-forwarding queue. In addition to changing the internal forwarding priority, if the outgoing interface is an 802.1Q interface, this option maps the specified priority to its equivalent 802.1p (CoS) priority and marks the packet with the new 802.1p priority.  <b>NOTE:</b> This option applies only to 10 Gigabit Ethernet modules.

Name, OID, and syntax	Access	Description
snAgAcIPriorityForce brcdIp.1.2.2.15.2.1.26 Syntax: Integer	Read-write	Indicates the priority that is being forced on the outgoing packet. This parameter allows you assign packets of outgoing traffic that match the ACL to a specific hardware-forwarding queue, even though the incoming packet may be assigned to another queue. Valid values: <ul style="list-style-type: none"> <li>• qosp0(0)</li> <li>• qosp1(1)</li> <li>• qosp2(2)</li> <li>• qosp3(3)</li> <li>• Not defined(4)</li> </ul> Default: Not defined(4) <b>NOTE:</b> This option applies only to 10 Gigabit Ethernet modules.
snAgAcIPriorityMapping brcdIp.1.2.2.15.2.1.27 Syntax: Integer <b>NOTE:</b> This is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices. It is also not supported on the FastIron devices.	Read-write	Indicates the priority of the incoming packet to be matched. This option maps the packet's 802.1p value. It does not change the packet's forwarding priority through the device nor does it mark the packet. Valid values: 0 – 8 Default: Not defined(8)
snAgAcIDscpMarking brcdIp.1.2.2.15.2.1.28 Syntax: Integer	Read-write	Indicates the DSCP marking of a packet that will be matched. Valid values: 0 – 64 Default: Not defined(64) <b>NOTE:</b> This option applies only to 10 Gigabit Ethernet modules.
snAgAcIDscpMapping brcdIp.1.2.2.15.2.1.29 Syntax: Integer	Read-write	Indicates the DCSP value of the incoming packet value to be matched. Valid values: 0 – 64 Default: Not defined(64) <b>NOTE:</b> This option applies only to 10 Gigabit Ethernet modules.



Name, OID, and syntax	Access	Description
snAgAclIcmpCode brcdIp.1.2.2.15.2.1.30 Syntax: Integer	Read write	<p>If you entered a value for ICMP message type number in the "snAgAclSourceOperand2" object, enter the code number in this object.</p> <p>Valid value for type code 1, Echo reply</p> <ul style="list-style-type: none"> <li>1 = Echo reply</li> </ul> <p>Valid values for type code 4, Destination unreachable</p> <ul style="list-style-type: none"> <li>• 1 = Network unreachable</li> <li>• 2 = Host unreachable</li> <li>• 3 = Protocol unreachable</li> <li>• 4 = Port unreachable</li> <li>• 5 = Fragmentation needed but do not fragment bit set</li> <li>• 6 = Source route failed</li> <li>• 7 = Destination network unknown</li> <li>• 8 = Destination host unknown</li> <li>• 9 = Source host isolated</li> <li>• 10 = Destination network administratively prohibited</li> <li>• 11 = Destination host administratively prohibited</li> <li>• 12 = Network unreachable for TOS</li> <li>• 13 = Host unreachable for TOS</li> <li>• 14 = Communication administratively prohibited by filter</li> <li>• 15 = Host precedence violation</li> <li>• 16 = Precedence cutoff in effect</li> </ul> <p>Valid values for type code 5, Source quench</p> <ul style="list-style-type: none"> <li>1 = Source quench</li> </ul> <p>Valid values for type code 6, Redirect</p> <ul style="list-style-type: none"> <li>• 1 = Redirect for network</li> <li>• 2 = Redirect for host</li> <li>• 3 = Redirect for TOS and network</li> <li>• 4 = Redirect for TOS and host</li> </ul> <p>Valid value for type code 9, Echo request</p> <ul style="list-style-type: none"> <li>1 = Echo request</li> </ul> <p>Valid value for type code 10, Router advertisement</p> <ul style="list-style-type: none"> <li>1 = Router advertisement</li> </ul> <p>Valid value for type code 11, Router solicitation</p> <ul style="list-style-type: none"> <li>1 = Router solicitation</li> </ul> <p>Valid values for type code 12, Time exceeded</p> <ul style="list-style-type: none"> <li>• 1 = Time to live equals 0 during transmit</li> <li>• 2 = Time to live equals 0 during reassembly</li> </ul> <p>Valid values for type code 13, Parameter problem</p> <ul style="list-style-type: none"> <li>• 1 = IP header bad (catchall error)</li> <li>• 2 = Required option missing</li> </ul> <p>Valid value for type code 14, Timestamp request</p> <ul style="list-style-type: none"> <li>1 = Timestamp request</li> </ul> <p>Valid value for type code 15, Timestamp reply</p> <ul style="list-style-type: none"> <li>1 = Timestamp reply</li> </ul> <p>Valid value for type code 16, Information request</p> <ul style="list-style-type: none"> <li>1 = Information request</li> </ul> <p>Valid value for type code 17, Information reply</p> <ul style="list-style-type: none"> <li>1 = Information reply</li> </ul>

Name, OID, and syntax	Access	Description
snAgAcIcmpCode (continued)		Valid value for type code 18, Address mask request 1 = Address mask request Valid value for type code 19, Address mask reply 1 = Address mask reply

## ACL bind to port table

The ACL bind to port table contains ACL port bindings for a Layer 3 switch. Port numbers and bind direction are used to index entries.

This table has been deprecated.

Name, OID, and syntax	Access	Description
snAgAcIBindToPortTable brcdIp.1.2.2.15.3	None	The ACL bind to port table.
<b>NOTE:</b> This object is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices.		
snAgAcIPortNum brcdIp.1.2.2.15.3.1.1 Syntax: Integer32	Read-only	Shows the format of port number: <ul style="list-style-type: none"> <li>• LS octet – port number (max 255).</li> <li>• Next octet – slot number (max 255).</li> <li>• MS Octet: <ul style="list-style-type: none"> <li>• 0 (phy) – 0000 to 0FFFF</li> <li>• 1 (ve) – 10000 to 1FFFF</li> </ul> </li> </ul>
snAgAcIPortBindDirection brcdIp.1.2.2.15.3.1.2 Syntax: Direction	Read-only	Shows the traffic direction to which the ACL will be applied: <ul style="list-style-type: none"> <li>• inbound(0)</li> <li>• outbound(1)</li> </ul>
snAgAcINum brcdIp.1.2.2.15.3.1.3 Syntax: Integer32	Read-write	Shows the defined ACL number that will be bound to the port.
snAgAcINameString brcdIp.1.2.2.15.3.1.4 Syntax: DisplayString	Read-write	Shows the defined ACL name that will be bound to the port.

Name, OID, and syntax	Access	Description
snAgBindPortListInVirtualInterface brcdIp.1.2.2.15.3.1.5 Syntax: OCTET STRING	Read-write	Contains a list of ports for binding a virtual interface.
snAgAclPortRowStatus brcdIp.1.2.2.15.3.1.6 Syntax: SnRowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## ACL port table

### NOTE

The ACL port MIBs are supported on the Brocade MLXe and Brocade NetIron XMR devices.

Name, OID, and syntax	Access	Description
snAgAclIfBindTable brcdIp.1.2.2.15.4	None	The ACL bind to port table.
snAgAclIfBindIndex brcdIp.1.2.2.15.4.1.1 Syntax: InterfaceIndex	Read-only	The number of the virtual or physical interface to which this ACL is bound.
snAgAclIfBindDirection brcdIp.1.2.2.15.4.1.2 Syntax: Direction	Read-only	Shows the traffic direction to which the ACL will be applied: <ul style="list-style-type: none"> <li>inbound(0)</li> <li>outbound(1)</li> </ul>
snAgAclIfBindNum brcdIp.1.2.2.15.4.1.3 Syntax: Integer	Read-write	Shows the defined ACL number that will be bound to the port.
snAgAclIfBindNameString brcdIp.1.2.2.15.4.1.4 Syntax: DisplayString	Read-write	Shows the defined ACL name that will be bound to the port.

Name, OID, and syntax	Access	Description
snAgAclIfBindVifPortList brcdIp.1.2.2.15.4.1.5 Syntax: Octet string	Read-write	Contains a list of ports for binding a virtual interface. Each port index is an ifIndex. If there are four or more consecutive ifIndexes, then they will be encoded. The Encoding and decoding scheme is range-based. Each range prefix with 0000 (2 octets) where 0000 is not a valid ifIndex. The next 2 octets indicates the lower range ifIndex, followed by 2 octets of higher range ifIndex. The individual (non- range) ones will be displayed as is. For example: Port list: 0001..0005 0015 0032..0047 Port list in PDU: 0000 0001 0005 000f 0000 0020 002f
snAgAclIfRowStatus brcdIp.1.2.2.15.4.1.6 Syntax: SnRowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snAgAclIfBindDenyLogging brcdIp.1.2.2.15.4.1.7 Syntax: Integer	Read-write	Enables or disables deny logging.

## ACL accounting table

The following table contains the ACLs configured on the NetIron devices.

### NOTE

The ACL accounting table is supported on the Brocade NetIron XMR, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
agAclAccntTable brcdIp.1.2.2.15.5	None	Table of ACL accounting statistics for router.
agAclAccntKind brcdIp.1.2.2.15.5.1.1 Syntax: Integer	None	The kind of ACL accounting statistics needed.
agAclAccntIfIndex brcdIp.1.2.2.15.5.1.2 Syntax: InterfaceIndex	None	Physical or virtual interface on which ACL accounting is desired. For Receive-ACL, use the lowest port of the management module as the value for this object.
agAclAccntDirection brcdIp.1.2.2.15.5.1.3 Syntax: Direction	None	ACL port direction, inbound or outbound. For Receive-ACL kind, direction cannot be outbound.

Name, OID, and syntax	Access	Description
agAclAccntAclNumber brcdIp.1.2.2.15.5.1.4 Syntax: AclNumber	None	The access list number for this entry.
agAclAccntFilterId brcdIp.1.2.2.15.5.1.5 Syntax: Unsigned	None	Filter ID within a given ACL. This is a zero-based value.
agAclAccntAclName brcdIp.1.2.2.15.5.1.6 Syntax: AclNameString	Read-only	ACL name for an entry, if applicable. Otherwise, a null string is returned.
agAclAccntOneSecond brcdIp.1.2.2.15.5.1.7 Syntax: Counter64	Read-only	Accounting data for last one second.
agAclAccntOneMinute brcdIp.1.2.2.15.5.1.8 Syntax: Counter64	Read-only	Accounting data for last one minute.
agAclAccntFiveMinute brcdIp.1.2.2.15.5.1.9 Syntax: Counter64	Read-only	Accounting data for last five minute.
agAclAccntCumulative brcdIp.1.2.2.15.5.1.10 Syntax: Counter64	Read-only	Cumulative accounting data since the ACL was installed.
agAclAccntRaclDropCnt brcdIp.1.2.2.15.5.1.11 Syntax: Counter64	Read-only	Receive-ACL drop counter used for rate limiting. Not used for other ACL kind. The value returned is per ACL, instead of per filter within the ACL. This object supports rate limiting statistics for ACL and Layer 2 ACL-enabled interfaces.
agAclAccntRaclFwdCnt brcdIp.1.2.2.15.5.1.12 Syntax: Counter64	Read-only	Receive-ACL forward counter used for rate limiting. Not used for other ACL kind. The value returned is per ACL, instead of per filter within the ACL. This object supports rate limiting statistics for ACL and Layer 2 ACL-enabled interfaces.
agAclAccntRaclRemarkCnt brcdIp.1.2.2.15.5.1.13 Syntax: Counter64	Read-only	Receive-ACL remark counter used for rate limiting. Not used for other ACL kind. The value returned is per ACL, instead of per filter within the ACL. This object supports rate limiting statistics for ACL and Layer 2 ACL-enabled interfaces.
agAclAccntRaclTotalCnt brcdIp.1.2.2.15.5.1.14 Syntax: Counter64	Read-only	Receive-ACL total counter used for rate limiting. Not used for other ACL kind. The value returned is per ACL, instead of per filter within the ACL. This object supports rate limiting statistics for ACL and Layer 2 ACL-enabled interfaces.
agAclAccntRaclTotalSWHitCountCnt brcdIp.1.2.2.15.5.1.15 Syntax: Counter64	Read-only	Receive-ACL cumulative software hit counter. Not used for other ACL kind. The value returned is per ACL, instead of per filter within the ACL.

## Textual conventions

The Layer 2 ACL tables use the following textual conventions.

Name and syntax	Description
fdryVlanIdOrNoneTC Syntax: Integer32	The VLAN ID that uniquely identifies a specific VLAN, or no VLAN. The special value of zero is used to indicate that no VLAN ID is present or used. This can be used in any situation where an object or a table entry must refer either to a specific VLAN, or to no VLAN. Valid values: 0 or 1 - 4094
PortQoSTC Syntax: Integer	The port QoS priority-hardware queue. The value 0 is the lowest priority and 7 is the highest. Valid values: <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> <li>• invalid(127)</li> </ul>
fdryEnetTypeOrZeroTC Syntax: Integer	Ethernet Type field within the Ethernet-II frame: <ul style="list-style-type: none"> <li>• invalid(0)</li> <li>• ipv4(1)</li> <li>• arp(2)</li> <li>• ipv6(3)</li> </ul>
fdryClauseIndexTC Syntax: Unsigned 32	One-based clause index value within a given ACL number.

## Layer 2 ACL next clause table

The Layer 2 ACL next clause table (fdryL2AcINextClauseTable) contains the list of the next lowest available clause index that can be used for creating a Layer 2 ACL in the fdryL2AcITable configuration table. (Refer to [“Layer 2 ACL configuration table”](#) on page 381.)

Every Layer 2 ACL in fdryL2AcITable has a clause index that consists of a list of ACL clause entries. A Layer 2 ACL cannot be created without any clause entries. There must be at least one clause entry in a Layer 2 ACL. Thus, when all the clause entries are deleted from a Layer 2 ACL, the ACL itself will also be deleted.

By default, there will be 64 clause entries for each Layer 2 ACL. This number can be changed by issuing the **system-max l2-acl-table-entries** command on the device CLI. You can specify up to 256 clause entries per Layer 2 ACL.

The initial value of fdryL2AcINextClauseIndex in each table row is 1. When a clause entry is created for a Layer 2 ACL, this value is incremented by one. When the number of clause entries created for an ACL reaches the maximum limit, a Get operation on fdryL2AcIClauseIndex will return a noSuchInstance error. The error indicates that no more clauses can be added to fdryL2AcITable for this ACL.

When a clause entry for an ACL is removed (in the beginning or middle or end), the clause index is available for adding a new clause entry for this ACL. The `fdryL2AcIClauseIndex` always returns the lowest available clause index where a new clause must be added.

The CLI displays the ACL clause in chronological order. However, SNMP is bounded by clause index, and thus it may not display the rows in chronological order. The clause index does not map to the sequence in which the ACL clause is checked at run time. The clause index is an internal value used to identify unique ACL clauses within a given ACL ID.

For example, if only three clause entries can be created for a Layer 2 ACL, the following steps describe how the ACL clause is assigned.

1. Before adding any clause to a Layer 2 ACL, a Get operation on `fdryL2AcINextClauseIndex` returns "1".
2. When you add the first clause entry, a Get operation on `fdryL2AcINextClauseIndex` returns "2".
3. When you add the second clause entry, a Get operation on `fdryL2AcINextClauseIndex` returns "3".
4. When you add the third clause entry, a Get operation on `fdryL2AcINextClauseIndex` returns "4".
5. If you remove the second clause entry (#2), a Get operation on `fdryL2AcINextClauseIndex`, returns "2" because it is the lowest available index.

The `fdryL2AcINextClauseTable` is a read-only table.

Name, OID, and syntax	Access	Description
<code>fdryL2AcINextClauseTable</code> <code>brcdIp.1.2.2.15.6</code>	None	This read-only table contains the list of the next lowest available clause index that can be used for creating a new entry in <code>fdryL2AcITable</code> . The clause index values will not change as a result of switchovers or hitless upgrades, but may change as a result of a device reload. However, the relative order of persistent entries would remain the same.
<code>fdryL2AcINextClauseIndex</code> <code>brcdIp.1.2.2.15.6.1.1</code> Syntax: " <code>fdryClauseIndexTC</code> "	Read-only	The next lowest available clause index for a given Layer 2 ACL number. The maximum value of this object is the configured maximum number of clauses for a Layer 2 ACL. Even though the syntax of <code>fdryL2AcIClauseIndex</code> is " <code>fdryClauseIndexTC</code> ", its value will be from 1 to the configured maximum clause entries for each Layer 2 ACL.

## Layer 2 ACL configuration table

The following objects are available for Layer 2 ACL configuration.

Name, OID, and syntax	Access	Description
<code>fdryL2AcITable</code> <code>brcdIp.1.2.2.15.7</code>	None	The table of Layer 2 ACLs. A Layer 2 ACL number can have 64 (default) to 256 clauses. The clause index values will not change as a result of switchovers or hitless upgrades, but may change as a result of a device reload. However, the relative order of persistent entries remains the same.
<code>fdryL2AcINumber</code> <code>brcdIp.1.2.2.15.7.1.1</code> Syntax: <code>AcINumber</code>	None	The access list number for this entry. For Layer 2 ACLs, valid values are from 400 through 599.

Name, OID, and syntax	Access	Description
fdryL2AclClauseIndex brcdIp.1.2.2.15.7.1.2 Syntax: "fdryClauseIndexTC"	None	The index of the clause within a given ACL number. During row creation, the clause index value should match the next available clause index for a given ACL number. It is advisable to first perform a Get operation on fdryL2AclNextClauseTable for a given ACL number, and use the value of fdryL2AclNextClauseIndex returned by the agent.
fdryL2AclAction brcdIp.1.2.2.15.7.1.3 Syntax: Action	Read-write	Action to take if the Layer 2 packet on the port matches this ACL.
fdryL2AclSourceMac brcdIp.1.2.2.15.7.1.4 Syntax: MAC address	Read-write	Optional source MAC address. By default, it matches with any source MAC address within a packet. Default: '000000000000'H
fdryL2AclSourceMacMask brcdIp.1.2.2.15.7.1.5 Syntax: MAC address	Read-write	Optional source MAC address mask. For a Set operation, this object can only be used in conjunction with fdryL2AclSourceMac. By default, this matches any source MAC address within a packet. If you want to match the first two bytes of the address aabb.ccdd.eeff, use the mask ffff.0000.0000. In this case, the clause matches all source MAC addresses that contain "aabb" as the first two bytes and any values in the remaining bytes of the MAC address. Default: '000000000000'H
fdryL2AclDestinationMac brcdIp.1.2.2.15.7.1.6 Syntax: MAC address	Read-write	Optional destination MAC address. By default, it matches any destination MAC address within a packet. Default: '000000000000'H
fdryL2AclDestinationMacMask brcdIp.1.2.2.15.7.1.7 Syntax: MAC address	Read-write	Optional destination MAC address mask. For a Set operation, this object can only be used in conjunction with fdryL2AclDestinationMac. By default, it matches any destination MAC address within a packet. If you want to match the first two bytes of the address aabb.ccdd.eeff, use the mask ffff.0000.0000. In this case, the clause matches all destination MAC addresses that contain "aabb" as the first two bytes and any values in the remaining bytes of the MAC address. Default: '000000000000'H
fdryL2AclVlanId brcdIp.1.2.2.15.7.1.8 Syntax: "fdryVlanIdOrNoneTC"	Read-write	The optional VLAN ID to match against the incoming packet. By default, the VLAN ID field is ignored during the match and the value 0 is returned. Default: 0
fdryL2AclEthernetType brcdIp.1.2.2.15.7.1.9 Syntax: "fdryEnetTypeOrZeroTC"	Read-write	The optional Ethernet type to match against the etype field of the incoming packet. By default, the etype field is ignored during the match. Default: invalid



Name, OID, and syntax	Access	Description
fdryL2AclDot1pPriority brcdIp.1.2.2.15.7.1.10 Syntax: "PortQoS TC"	Read-write	<p>This object is optional. It assigns the traffic that matches the ACL to a hardware-forwarding queue. In addition to changing the internal forwarding priority, if the outgoing interface is an 802.1q interface, this option maps the specified priority to its equivalent 802.1p (QoS) priority and marks the packet with the new 802.1p priority. This option is applicable only for the inbound Layer 2 ACLs.</p> <p><b>NOTE:</b> The fdryL2AclDot1pPriority object following fdryL2AclDot1pPriorityForce cannot be used together in a Layer 2 ACL entry.</p> <p>Default: level0(0)</p>
fdryL2AclDot1pPriorityForce brcdIp.1.2.2.15.7.1.11 Syntax: "PortQoS TC"	Read-write	<p>This object is optional. It assigns the packets of outgoing traffic that match the Layer 2 ACL to a specific hardware-forwarding queue, even though the incoming packet may be assigned to another queue. This option is applicable only for the inbound ACLs.</p> <p><b>NOTE:</b> The fdryL2AclDot1pPriority object following fdryL2AclDot1pPriorityForce cannot be used together in a Layer 2 ACL entry.</p> <p>Default: level0(0)</p>
fdryL2AclDot1pPriorityMapping brcdIp.1.2.2.15.7.1.12 Syntax: "PortQoS TC"	Read-write	<p>This object is optional. It matches the packet's 802.1p value. This option does not change the packet's forwarding priority through the device or mark the packet. It is applicable for both inbound and outbound Layer 2 ACLs.</p> <p>Default: level0(0)</p>
fdryL2AclMirrorPackets brcdIp.1.2.2.15.7.1.13 Syntax: TruthVal	Read-write	<p>This object is optional. It is applicable only for the ACLs with a permit clause.</p> <p>When you bind a Layer 2 ACL to a port, you can configure the port to mirror the packets to another port using the <b>acl-mirror-port</b> CLI command. Then the packets permitted on this port (as a result of the bound ACL) will be mirrored on the other port.</p> <p>Default: "false"</p>
fdryL2AclLogEnable brcdIp.1.2.2.15.7.1.14 Syntax: TruthVal	Read-write	<p>The optional parameter to enable logging only when a deny clause is specified. Note that the traffic denied by the implicit deny mechanism is not subject to logging. The implicit deny occurs when traffic does not match any of the clauses and there is no <b>permit any any</b> clause specified at the end of the Layer 2 ACL.</p> <p>Default: "false"</p>
fdryL2AclRowStatus brcdIp.1.2.2.15.7.1.15 Syntax: RowSts	Read-write	<p>The row status variable is used according to installation and removal conventions for conceptual rows. Setting this object to active(1) or createAndGo(4) results in the addition of a Layer 2 ACL filter in the router. Duplicate entries will be rejected during row creation.</p> <p>As part of the row creation, entries are appended to this table. Row insertion may not be supported.</p> <p>Setting this object to destroy(6) removes the associated filter from the router. Other values in the enumeration are not used.</p>

## Layer 2 ACL binding configuration table

The Layer 2 ACL binding configuration table lists the Layer 2 ACLs that have been bound to a port.

Name, OID, and syntax	Access	Description
fdryL2AclIfBindTable brcdIp.1.2.2.15.8	None	The table of Layer 2 ACL binding to a port. Layer 2 ACLs and Layer 3 ACLs cannot be bound to the same port. However, you can configure a port to use Layer 2 ACLs, and another port on the same device to use Layer 3 ACLs. In general: <ul style="list-style-type: none"> <li>• Layer 2 ACLs cannot be bound to virtual interfaces, unlike Layer 3 ACLs.</li> <li>• You cannot modify an existing Layer 2 ACL clause. You must first unbind the Layer 2 ACL, delete it, and then create a new clause.</li> </ul>
fdryL2AclIfBindDirection brcdIp.1.2.2.15.8.1.1 Syntax: Direction	None	Indicates if Layer 2 ACLs are bound to incoming or outgoing ports: <ul style="list-style-type: none"> <li>• inbound(0)</li> <li>• outbound(1)</li> </ul>
fdryL2AclIfBindAclNumber brcdIp.1.2.2.15.8.1.2 Syntax: Unsigned32	Read-write	The Layer 2 ACL number that is to be bound to a physical interface. Valid values: 400 - 599
fdryL2AclIfBindRowStatus brcdIp.1.2.2.15.8.1.3 Syntax: RowSts	Read-write	The row status variable is used according to the installation and removal conventions for conceptual rows. Setting this object to active(1) or createAndGo(4) binds the Layer 2 ACL to the specified physical port. Setting this object to destroy(6) unbinds the Layer 2 ACL from the port. Other values in the enumeration are not used.

# IPv6 ACL MIB Definition

## In this chapter

- [IPv6 ACL table \(FastIron X series IPv6 devices\)](#). . . . . 385

## IPv6 ACL table (FastIron X series IPv6 devices)

The following table contains the IPv6 ACLs for FastIron X series IPv6 devices.

### NOTE

The objects in the following table are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
fdryIpv6AclTable brcdIp.1.2.16.1.1.1.1	None	The IPv6 access control list table.
fdryIpv6AclIndex brcdIp.1.2.16.1.1.1.1.1 Syntax: Unsigned32	None	The index number for an ACL entry. This is a unique number even though the name is not unique for a given ACL with the same or different source address, prefix length, destination address, destination prefix length, protocol type, action (permit or deny) type, and operator (neq, eq, gt, and lt).
fdryIpv6AclName brcdIp.1.2.16.1.1.1.1.2 Syntax: DisplayString	Read-create	The ACL name for an entry.
fdryIpv6AclAction brcdIp.1.2.16.1.1.1.1.3 Syntax: Action	Read-create	The action to take if the IP packet matches this ACL.
fdryIpv6AclProtocol brcdIp.1.2.16.1.1.1.1.4 Syntax: IpProtocol	Read-create	The transport protocols. 0 means any protocol.
fdryIpv6AclSourceIp brcdIp.1.2.16.1.1.1.1.5 Syntax: Ipv6Address	Read-create	The source IPv6 address.
fdryIpv6AclSourcePrefixLen brcdIp.1.2.16.1.1.1.1.6 Syntax: Unsigned32	Read-create	The source IPv6 address prefix length.
fdryIpv6AclSourceOperator brcdIp.1.2.16.1.1.1.1.7 Syntax: Operator	Read-create	The type of comparison to perform. This applies only to TCP or UDP.

Name, OID, and syntax	Access	Description
fdryIpv6AcISourceOperand1 brcdIp.1.2.16.1.1.1.1.8 Syntax: Unsigned32	Read-create	This object refers to the source transport protocol port number of the operand 1.
fdryIpv6AcISourceOperand2 brcdIp.1.2.16.1.1.1.1.9 Syntax: Unsigned32	Read-create	This object refers to the source transport protocol port number of the operand 2.
fdryIpv6AcIDestinationIp brcdIp.1.2.16.1.1.1.1.10 Syntax: Ipv6Address	Read-create	The destination IPv6 address.
fdryIpv6AcIDestinationPrefixLen brcdIp.1.2.16.1.1.1.1.11 Syntax: Unsigned32	Read-create	The destination IPv6 address prefix length.
fdryIpv6AcIDestinationOperator brcdIp.1.2.16.1.1.1.1.12 Syntax: Operator	Read-create	The type of comparison to perform. This applies only to TCP or UDP.
fdryIpv6AcIDestinationOperand1 brcdIp.1.2.16.1.1.1.1.13 Syntax: Unsigned32	Read-create	This object refers to the destination transport protocol port number of the operand 1.
fdryIpv6AcIDestinationOperand2 brcdIp.1.2.16.1.1.1.1.14 Syntax: Unsigned32	Read-create	This object refers to the destination transport protocol port number of the operand 2.
fdryIpv6AcIEstablished brcdIp.1.2.16.1.1.1.1.15 Syntax: RtrStatus	Read-create	Enables or disables the filtering of established TCP packets for which the ACK or RESET flag is on. This filter applies only to the TCP transport protocol.
fdryIpv6AcILogOption brcdIp.1.2.16.1.1.1.1.16 Syntax: TruthValue	Read-create	The log flag. This should be set to one, which enables logging.
fdryIpv6AcIComments brcdIp.1.2.16.1.1.1.1.17 Syntax: DisplayString	Read-create	A description of the individual ACL entry.
fdryIpv6AcIRowStatus brcdIp.1.2.16.1.1.1.1.18 Syntax: RowStatus	Read-create	Creates or deletes an ACL entry.

# IP VRRP MIB Definition

## In this chapter

- [VRRP and VRRP-Extended MIBs](#) . . . . . 387
- [VRRP interface table](#) . . . . . 388
- [VRRP and VRRP-E interface table](#) . . . . . 389
- [VRRP virtual router table](#) . . . . . 389
- [VRRP and VRRP-E virtual router configuration table](#) . . . . . 394

## VRRP and VRRP-Extended MIBs

The following table contains the global objects that apply to Virtual Router Redundancy Protocol (VRRP), Virtual Router Redundancy Protocol Extended (VRRP-E), and Virtual Switch Redundancy Protocol (VSRP).

Name, OID, and syntax	Access	Description
snVrrpGroupOperMode brcdIp.1.2.12.1.1 Syntax: Integer <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if VRRP is enabled for this system: <ul style="list-style-type: none"> <li>• disabled(0) – Disable VRRP.</li> <li>• enabled(1) – Activate VRRP.</li> </ul> Default: disabled(0)
snVrrpIfStateChangeTrap brcdIp.1.2.12.1.2 Syntax: Integer <b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if the SNMP agent process has been enabled to generate VRRP interface state change traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1) <b>NOTE:</b> The standard MIB "vrrpNotificationCntl" will work exactly the same as the IronWare Proprietary MIB "snVrrpIfStateChangeTrap".
snVrrpIfMaxNumVridPerIntf brcdIp.1.2.12.1.3 Syntax: Integer	Read-only	Indicates the maximum number of VRID per interface.
snVrrpIfMaxNumVridPerSystem brcdIp.1.2.12.1.4 Syntax: Integer	Read-only	Indicates the maximum number of VRID per system.

Name, OID, and syntax	Access	Description
snVrrpClearVrrpStat brcdIp.1.2.12.1.5 Syntax: Integer	Read-write	Clear VRRP statistics command.
snVrrpGroupOperModeVrrpextended brcdIp.1.2.12.1.6 Syntax: Integer	Read-write	Indicates if VRRP-E is enabled on this device: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
<p><b>NOTE:</b> This object is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.</p>		

## VRRP interface table

The objects in the following table apply to VRRP, VRRP-E, and VSRP, depending on which protocol is enabled in the device. This table has been replaced by the “[snVrrpIf2Table](#)” table, which is presented in “[VRRP and VRRP-E interface table](#)”.

Name, OID, and syntax	Access	Description
snVrrpIfTable brcdIp.1.2.12.2.1	None	The VRRP interface table.
snVrrpIfPort brcdIp.1.2.12.2.1.1.1 Syntax: Integer	Read-only	Shows the IP port of this VRRP interface.
snVrrpIfAuthType brcdIp.1.2.12.2.1.1.2 Syntax: Integer	Read-write	Indicates the authentication type of this interface: <ul style="list-style-type: none"> <li>noAuth(0)</li> <li>simpleTextPasswd(1)</li> <li>ipAuthHeader(2)</li> </ul>
snVrrpIfAuthPassword brcdIp.1.2.12.2.1.1.3 Syntax: OCTET STRING	Read-write	Shows the simple text password for this interface. You can use a simple text password if the “ <a href="#">snVrrpIfAuthType</a> ” object is set to simpleTextPasswd(1).
snVrrpIfRxHeaderErrors brcdIp.1.2.12.2.1.1.4 Syntax: Counter32	Read-only	Shows the number of VRRP or VRRP-E packets received by the interface that had a header error.
snVrrpIfRxAuthTypeErrors brcdIp.1.2.12.2.1.1.5 Syntax: Counter32	Read-only	Shows the number of VRRP or VRRP-E packets received by the interface that had an authentication error.

Name, OID, and syntax	Access	Description
snVrrpIfRxAuthPwdMismatchErrCnts brcdIp.1.2.12.2.1.1.6 Syntax: Counter32	Read-only	Shows the number of VRRP or VRRP-E packets received by the interface that had a password value that does not match the password used by the interface for authentication.
snVrrpIfRxVridErrCnts brcdIp.1.2.12.2.1.1.7 Syntax: Counter32	Read-only	Shows the number of VRRP or VRRP-E packets received by the interface that contained a VRID that is not configured on this interface.

## VRRP and VRRP-E interface table

The following table replaces the “[snVrrpIfTable](#)” (presented in the “[VRRP interface table](#)” section), which uses the slot or port number to index an entry. This table uses the ifindex to present the configuration and statistics of VRRP and VRRP-E interfaces. Each entry in the table describes one VRRP or VRRP-E interface.

Name, OID, and syntax	Access	Description
snVrrpIf2Table brcdIp.1.2.12.4.1	None	The VRRP and VRRP-E table for interfaces, using the ifindex.
snVrrpIf2AuthType brcdIp.1.2.12.4.1.1.1 Syntax: Integer	Read-write	The authentication type of the interface: <ul style="list-style-type: none"> <li>noAuth(0)</li> <li>simpleTextPasswd(1)</li> <li>ipAuthHeader(2)</li> </ul>
snVrrpIf2AuthPassword brcdIp.1.2.12.4.1.1.2 Syntax: OCTET STRING	Read-write	Password for the interface if the snVrrpIf2AuthType type is set to simpleTextPasswd(1).
snVrrpIf2RxHeaderErrCnts brcdIp.1.2.12.4.1.1.3 Syntax: Counter32	Read-only	The number of packets received by the interface that had a header error.
snVrrpIf2RxAuthTypeErrCnts brcdIp.1.2.12.4.1.1.4 Syntax: Counter32	Read-only	The number of packets received by the interface that had an authentication error.
snVrrpIf2RxAuthPwdMismatchErrCnts brcdIp.1.2.12.4.1.1.5 Syntax: Counter32	Read-only	The number of packets received by the interface that had a password value that does not match the password used by the interface for authentication.
snVrrpIf2RxVridErrCnts brcdIp.1.2.12.4.1.1.6 Syntax: Counter32	Read-only	The number of packets received by the interface that contained a VRID that is not configured on this interface.

## VRRP virtual router table

The following table has been replaced by the “[snVrrpVirRtr2Table](#)”. The new table is presented in the section “[VRRP and VRRP-E virtual router configuration table](#)”.

**NOTE**

The following table is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snVrrpVirRtrTable brcdIp.1.2.12.3.1	None	The VRRP virtual router table.
snVrrpVirRtrPort brcdIp.1.2.12.3.1.1.1 Syntax: Integer32	Read-only	Shows the port number of this VRRP interface.
snVrrpVirRtrId brcdIp.1.2.12.3.1.1.2 Syntax: Integer	Read-only	Shows the VRID that has been configured on this interface. If multiple VRIDs are configured, there is an entry for each VRID.
snVrrpVirRtrOwnership brcdIp.1.2.12.3.1.1.3 Syntax: Integer	Read-write	Indicates the owner of the router interface. The owner or master router owns the IP addresses associated with the VRID: <ul style="list-style-type: none"> <li>incomplete(0) – No IP address has been assigned to this VRRP router interface.</li> <li>owner(1) – The owner or the master router is the owner of the VRRP router interface.</li> <li>backup(2) – The backup router is the owner of the interface.</li> </ul>
snVrrpVirRtrCfgPriority brcdIp.1.2.12.3.1.1.4 Syntax: Integer	Read-write	Applies only if the “snVrrpVirRtrOwnership” object is set to backup(2). It indicates the backup router’s preferability to becoming the active router for the interface. The higher the number, the higher the priority. If two or more devices are tied with the highest priority, the backup interface with the highest IP address becomes the active router for the VRID. Valid values: 3 – 254 Default: 100
snVrrpVirRtrTrackPriority brcdIp.1.2.12.3.1.1.5 Syntax: Integer	Read-write	Applies to interfaces that are configured with track ports. It indicates the priority of the track ports. A higher number indicates a higher priority. Track port priority is always lower than the “snVrrpVirRtrCfgPriority” priority. This object is adjusted dynamically with the “snVrrpVirRtrCurrPriority” object when the track port state first changes from up to down. Valid values: 1 – 254
snVrrpVirRtrCurrPriority brcdIp.1.2.12.3.1.1.6 Syntax: Integer	Read-only	The current VRRP priority of this Layer 3 switch for the VRID. The current priority can differ from the configured priority for the following reasons: <ul style="list-style-type: none"> <li>The VRID is still in the initialization stage and has not yet become a master or backup. In this case, the current priority is 0.</li> <li>The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> A higher number indicates a higher priority. This object is adjusted dynamically with the “snVrrpVirRtrTrackPriority” object. Valid values: 1 – 254
snVrrpVirRtrHelloInt brcdIp.1.2.12.3.1.1.7 Syntax: Integer	Read-write	Shows the number of seconds between hello messages that are sent between the master and the backup. Valid values: 1 – 84 seconds Default: 1 second



Name, OID, and syntax	Access	Description
snVrrpVirRtrDeadInt brcdIp.1.2.12.3.1.1.8 Syntax: Integer	Read-write	Applies only to VRRP backups. It shows the configured value for the dead interval. The dead interval is the number of seconds that a backup router waits for a hello message from the VRID master before determining that the master is no longer active. If the master does not send a hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master for the VRID. Valid values: 0 – 84 seconds. A value of 0 means that this object has not been configured. Default: 0 seconds
snVrrpVirRtrPreemptMode brcdIp.1.2.12.3.1.1.9 Syntax: Integer	Read-write	Indicates if the backup preempt mode is enabled. The backup preempt mode prevents a backup router with a higher VRRP priority from taking control of the VRID from another backup router that has a lower priority, but has already assumed control of the VRID: <ul style="list-style-type: none"> <li>disabled(0) – Prohibit preemption.</li> <li>enabled(1) – Allow preemption.</li> </ul> Default: enabled(1)
snVrrpVirRtrState brcdIp.1.2.12.3.1.1.10 Syntax: Integer	Read-only	Specifies the state of the VRRP router's interface: <ul style="list-style-type: none"> <li>init(0) – Initialization state.</li> <li>master(1) – Master state.</li> <li>backup(2) – Backup state.</li> </ul>
snVrrpVirRtrActivate brcdIp.1.2.12.3.1.1.11 Syntax: Integer	Read-write	Indicates if the VRRP router feature is enabled. <ul style="list-style-type: none"> <li>disabled(0) – The VRRP Router is deactivated.</li> <li>enabled(1) – The VRRP Router has been activated.</li> </ul>
snVrrpVirRtrIpAddrMask brcdIp.1.2.12.3.1.1.12 Syntax: OCTET STRING	Read-write	The number of IP addresses of this virtual router of this interface.
snVrrpVirRtrTrackPortMask brcdIp.1.2.12.3.1.1.13 Syntax: OCTET STRING	Read-write	This object was obsoleted and replaced by " <a href="#">snVrrpVirRtrTrackPortList</a> ". It specifies the identity of the physical port whose state is to be monitored. Each bit represents a port on a device. There can be up to 64 octets in this object: <ul style="list-style-type: none"> <li>Chassis devices can have up to 32 octets.</li> <li>Stackable devices can have up to 4 octets.</li> </ul> Default: 0 octets If this object is configured on an interface, then the preference level for the interface will be adjusted dynamically, depending on the state of the track port: <ul style="list-style-type: none"> <li>When the track port states first changes from up to down, the interface's preference level is reduced by the value of the Preference Level parameter.</li> <li>The next time the track port state changes from down to up, the interface's preference level is increased by the amount specified by the preference level.</li> </ul>

Name, OID, and syntax	Access	Description
snVrrpVirRtrTrackVifMask brcdIp.1.2.12.3.1.1.14 Syntax: OCTET STRING	Read-write	<p>This object was obsoleted and replaced by "snVrrpVirRtrTrackVifPortList".</p> <p>It specifies the identity of the virtual interface whose state is to be monitored. Each bit represents a port on a device.</p> <p>Valid values:</p> <ul style="list-style-type: none"> <li>Chassis devices can have up to 32 octets.</li> <li>Stackable devices can have up to 4 octets.</li> </ul> <p>Default: 0 octets</p> <p>If this object is configured on an interface, then the preference level for the interface will be adjusted dynamically, depending on the state of the track port:</p> <ul style="list-style-type: none"> <li>When the track port states first changes from up to down, the interface's preference level is reduced by the value of the preference level parameter.</li> <li>The next time the track port state changes from down to up, the interface's preference level is increased by the amount specified by the preference level.</li> </ul>
snVrrpVirRtrRowStatus brcdIp.1.2.12.3.1.1.15 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snVrrpVirRtrRxArpPktDropCn ts brcdIp.1.2.12.3.1.1.16 Syntax: Counter32	Read-only	Shows the number of ARP packets addressed to the interface that were dropped.
snVrrpVirRtrRxIpPktDropCnt s brcdIp.1.2.12.3.1.1.17 Syntax: Counter32	Read-only	Shows the number of IP packets addressed to the interface that were dropped.
snVrrpVirRtrRxPortMismatch Cnts brcdIp.1.2.12.3.1.1.18 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configuration for the receiving interface.
snVrrpVirRtrRxNumOfIpMis matchCnts brcdIp.1.2.12.3.1.1.19 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configured IP addresses.
snVrrpVirRtrRxIpMismatchC nts brcdIp.1.2.12.3.1.1.20 Syntax: Counter32	Read-only	Shows the number of receive VRRP IP addresses that did not match the configured VRRP addresses.

Name, OID, and syntax	Access	Description
snVrrpVirRtrRxHelloIntMismatchCnts brcdIp.1.2.12.3.1.1.21 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configured hello interval.
snVrrpVirRtrRxPriorityZeroFromMasterCnts brcdIp.1.2.12.3.1.1.22 Syntax: Counter32	Read-only	Shows the counts of the virtual router interface with priority zero from the master.
snVrrpVirRtrRxHigherPriorityCnts brcdIp.1.2.12.3.1.1.23 Syntax: Counter32	Read-only	Shows the number of VRRP packets received by the interface that had a higher backup priority for the VRID than what this interface's backup priority is.
snVrrpVirRtrTransToMasterStateCnts brcdIp.1.2.12.3.1.1.24 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the backup state to the master state for the VRID.
snVrrpVirRtrTransToBackupStateCnts brcdIp.1.2.12.3.1.1.25 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.
snVrrpVirRtrCurrDeadInt brcdIp.1.2.12.3.1.1.26 Syntax: Integer32	Read-only	Shows the number of seconds a backup waits for a hello message from the master before determining that the master is no longer active. If the master does not send a hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master.
snVrrpVirRtrTrackPortList brcdIp.1.2.12.3.1.1.27 Syntax: OCTET STRING	Read-write	<p>This object specifies the identity of the physical port whose state is to be monitored.</p> <p>Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the next 8 bits are the port number. Default value is 0 length octet string.</p> <p>If this object is configured on an interface, then the preference level for the interface will be adjusted dynamically, depending on the state of the track port:</p> <ul style="list-style-type: none"> <li>When the track port state first changes from up to down, the interface's preference level is reduced by the value of the preference level parameter.</li> <li>The next time the track port state changes from down to up, the interface's preference level is increased by the amount specified by the preference level.</li> </ul>
snVrrpVirRtrTrackVifPortList brcdIp.1.2.12.3.1.1.28 Syntax: OCTET STRING	Read-write	<p>This object specifies the identity of the virtual interface whose state is to be monitored.</p> <p>Each port index is a 16-bit integer in big-endian order. The first 8 bits are the slot number; the next 8 bits are the port number. Default value is 0 length octet string.</p> <p>If this object is configured on an interface, then the preference level for the interface will be adjusted dynamically, depending on the state of the track port:</p>

Name, OID, and syntax	Access	Description
snVrrpVirRtrTrackVifPortList (Continued)		<ul style="list-style-type: none"> <li>When the track port states first changes from up to down, the interface's preference level is reduced by the value of the preference level parameter.</li> <li>The next time the track port state changes from down to up, the interface's preference level is increased by the amount specified by the preference level.</li> </ul>

## VRRP and VRRP-E virtual router configuration table

The following table replaces the “snVrrpVirRtrTable”, which uses a slot or port number to index entries. This new table uses the ifindex method to present the configuration and statistics for VRRP and VRRP-E. Each entry in the table describes one VRRP or VRRP-E router.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snVrrpVirRtr2Table brcdIp.1.2.12.5.1	None	The VRRP virtual router 2 table.
snVrrpVirRtr2Id brcdIp.1.2.12.5.1.1.1 Syntax: Integer	Read-only	Shows one of the VRIDs configured on this interface. If multiple VRIDs are configured on the interface, there is an entry for each VRID.
snVrrpVirRtr2Ownership brcdIp.1.2.12.5.1.1.2 Syntax: Integer	Read-write	Indicates the owner of the VRRP router interface. The owner or master router owns the IP addresses associated with the VRID: <ul style="list-style-type: none"> <li>incomplete(0) – No IP address has been assigned to this VRRP or VRRP-E interface.</li> <li>owner(1) – The owner or the master router is the owner of the VRRP router interface. This applies only to VRRP.</li> <li>backup(2) – The backup router (VRRP or VRRP-E) is the owner of the interface. This is the only value that can be assigned to a VRRP-E router interface.</li> </ul>
snVrrpVirRtr2CfgPriority brcdIp.1.2.12.5.1.1.3 Syntax: Integer	Read-write	Indicates the preferability of a router for becoming the active router for the interface. A higher number indicates a higher priority. If two or more devices are tied with the highest priority, the backup interface with the highest IP address becomes the active router for the VRID. Valid values: 0 – 255, where: <ul style="list-style-type: none"> <li>0 – The master no longer participates in the VRRP and a backup router should transition to be the new master.</li> <li>255 – The router is the owner.</li> </ul> Default: 100.
snVrrpVirRtr2TrackPriority brcdIp.1.2.12.5.1.1.4 Syntax: Integer	Read-write	Applies to interfaces that are configured with track ports. It indicates the priority of the track ports. The higher the number, the higher the priority. Track port priority is always lower than the “snVrrpVirRtr2CfgPriority” priority. This object dynamically adjusts the value of the “snVrrpVirRtr2CfgPriority” object when the track port state first changes from up to down. Valid values: 1 – 254

Name, OID, and syntax	Access	Description
snVrrpVirRtr2CurrPriority brcdIp.1.2.12.5.1.1.5 Syntax: Integer	Read-only	<p>The current VRRP or VRRP-E priority of this Layer 3 switch for the VRID. The current priority can differ from the configured priority for the following reasons:</p> <ul style="list-style-type: none"> <li>The VRID is still in the initialization stage and has not become a master or backup yet. In this case, the current priority is 0.</li> <li>The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> <p>A higher number indicates a higher priority. This object is adjusted dynamically when the tracked port first changes from up to down. Valid values: 1 – 254</p>
snVrrpVirRtr2HelloInt brcdIp.1.2.12.5.1.1.6 Syntax: Integer	Read-write	<p>Shows the number of seconds between hello advertisements from the master and the backup. Valid values: 1 – 84 Default: 1 second.</p>
snVrrpVirRtr2DeadInt brcdIp.1.2.12.5.1.1.7 Syntax: Integer	Read-write	<p>Applies only to VRRP or VRRP-E backups. It shows the configured value for the dead interval. The dead interval is the number of seconds that a backup router waits for a hello message from the VRID master before determining that the master is no longer active. If the Master does not send a hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master for the VRID. Valid values: 1 – 84 Default: 0, which means that this object has not been configured.</p>
snVrrpVirRtr2PreemptMode brcdIp.1.2.12.5.1.1.8 Syntax: Integer	Read-write	<p>Indicates if the backup preempt mode is enabled:</p> <ul style="list-style-type: none"> <li>disabled(0) – Prohibit preemption.</li> <li>enabled(1) – Allow preemption.</li> </ul> <p>Default: enabled(1) The backup preempt mode prevents a backup router with a higher VRRP priority from taking control of the VRID from another backup router that has a lower priority, but has already assumed control of the VRID.</p>
snVrrpVirRtr2State brcdIp.1.2.12.5.1.1.9 Syntax: Integer	Read-only	<p>Specifies the VRRP or VRRP-E router's interface state:</p> <ul style="list-style-type: none"> <li>init(0) – Initialization state</li> <li>master(1) – Master state</li> <li>backup(2) – Backup state</li> </ul>
snVrrpVirRtr2IpAddrMask brcdIp.1.2.12.5.1.1.10 Syntax: OCTET STRING	Read-write	<p>The number of IP addresses of this virtual router of this interface.</p>
snVrrpVirRtr2Activate brcdIp.1.2.12.5.1.1.11 Syntax: Integer	Read-write	<p>Indicates if VRRP or VRRP-E router is enabled:</p> <ul style="list-style-type: none"> <li>disabled(0) – The router is deactivated.</li> <li>enabled(1) – The router has been activated.</li> </ul>
snVrrpVirRtr2BackupInt brcdIp.1.2.12.5.1.1.12 Syntax: Integer	Read-write	<p>Time interval between backup routers hello message advertisements in seconds. The default is 60 seconds.</p>

Name, OID, and syntax	Access	Description
snVrrpVirRtr2RowStatus brcdIp.1.2.12.5.1.1.13 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snVrrpVirRtr2RxArpPktDropCnts brcdIp.1.2.12.5.1.1.14 Syntax: Counter32	Read-only	The received VRRP and VRRP-E ARP packet drop counts.
snVrrpVirRtr2RxIpPktDropCnts brcdIp.1.2.12.5.1.1.15 Syntax: Counter32	Read-only	Shows the number of IP packets addressed to the interface that were dropped.
snVrrpVirRtr2RxPortMismatchCnts brcdIp.1.2.12.5.1.1.16 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configuration for the receiving interface.
snVrrpVirRtr2RxNumOfIpMismatchCnts brcdIp.1.2.12.5.1.1.17 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configured IP addresses.
snVrrpVirRtr2RxIpMismatchCnts brcdIp.1.2.12.5.1.1.18 Syntax: Counter32	Read-only	Shows the number of VRRP IP addresses received that did not match the VRRP or VRRP-E addresses.
snVrrpVirRtr2RxHelloIntervalMismatchCnts brcdIp.1.2.12.5.1.1.19 Syntax: Counter32	Read-only	Shows the number of packets received that did not match the configured hello interval.
snVrrpVirRtr2RxPriorityZeroFromMasterCnts brcdIp.1.2.12.5.1.1.20 Syntax: Counter32	Read-only	Shows the count of the virtual router interfaces that received priority zero from the master.
snVrrpVirRtr2RxHigherPriorityCnts brcdIp.1.2.12.5.1.1.21 Syntax: Counter32	Read-only	Shows the number of packets received by the interface that had a higher backup priority for the VRID than this interface's backup priority for the VRID.
snVrrpVirRtr2TransToMasterStateCnts brcdIp.1.2.12.5.1.1.22 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.

Name, OID, and syntax	Access	Description
snVrrpVirRtr2TransToBackupStateCnts brcdIp.1.2.12.5.1.1.23 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the master state to the backup state.
snVrrpVirRtr2CurrDeadInt brcdIp.1.2.12.5.1.1.24 Syntax: Integer32	Read-only	Shows the current dead interval in increments of 100 milliseconds for the virtual router. This is the time period that a backup waits for a hello message from the master before determining that the master is no longer active. If the master does not send a hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master for the VRID.
snVrrpVirRtr2TrackPortList brcdIp.1.2.12.5.1.1.25 Syntax: OCTET STRING	Read-write	<p>Specifies the router's physical track port membership. The membership includes physical ports and virtual ports whose state is to be monitored.</p> <p>Each port index is an ifIndex. If there are four or more consecutive ifIndexes, then the encoding and decoding scheme is range-based, as follows:</p> <ul style="list-style-type: none"> <li>• Each range prefix with 0000 (2 octets) is not a valid ifIndex.</li> <li>• The first two octets in a set of four octets indicate the beginning of the range. The next two octets show the end of the range.</li> <li>• IfIndexes that are not in a range are displayed as they are.</li> </ul> <p>For example, you may see the following lists:</p> <ul style="list-style-type: none"> <li>• Port list: 0001..0005 0015 0032..0047 0001..0005 and 0032..0047 show ranges of ifindexes; whereas, 0015 is one ifindex</li> <li>• Port list in PDU: 0000 0001 0005 000f 0000 0020 002f</li> </ul> <p>The list contains ifindexes not in a range.</p> <p>If this object is configured, then the preference level of this interface will be adjusted dynamically depending on the state of the track port. The interface's preference level is reduced by the value of preference level parameter when the track port states first changes from up to down. When the track port returns to the up state, the interface's preference level is increased by the amount specified by the preference level.</p>
snVrrpVirRtr2AdvertiseBackup brcdIp.1.2.12.5.1.1.26 Syntax: Integer	Read-write	<p>Indicates if the ability for this backup to advertise itself to the current master is enabled:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p>Default: disabled(0)</p>
snVrrpVirRtr2MasterIpAddress brcdIp.1.2.12.5.1.1.27 Syntax: IpAddress	Read-only	Shows the master's real or virtual (primary) IP address. This IP address is listed as the source in VRRP and VRRP-E advertisement that was last received by this virtual router.
snVrrpVirRtr2IpAddrCount brcdIp.1.2.12.5.1.1.28 Syntax: Integer	Read-only	Shows the number of IP addresses that are associated with this virtual router. This number is equal to the number of rows in the vrrpAssolpAddrTable of the standard MIB that corresponds to a given ifindex and VRID pair.
snVrrpVirRtr2VirtualMacAddr brcdIp.1.2.12.5.1.1.29 Syntax: MAC address	Read-only	Shows the virtual MAC address of the virtual router.





# VSRP MIB Definition

## In this chapter

- [Global VSRP objects](#) ..... 399
- [VSRP interface table](#) ..... 400
- [VSRP virtual router table](#) ..... 400

The Virtual Switch Redundancy Protocol (VSRP) is a proprietary protocol that provides redundancy and sub-second failover in Layer 2 and Layer 3 mesh topologies. Based on the Virtual Router Redundancy Protocol Extended (VRRP-E), VSRP provides one or more backups for a Layer 2 Switch or Layer 3 switch. If the active Layer 2 Switch or Layer 3 switch becomes unavailable, one of the backups takes over as the active device and continues forwarding traffic for the network.

The MIB objects of the following sections are available for VSRP to provide SNMP support for VSRP and these MIB objects are supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## Global VSRP objects

The following table contains the global VSRP objects. Use the **router vsrp** and **snmp-server enable traps vsrp** CLI commands for information on global VSRP objects.

### NOTE

Only one of the virtual router protocols can be enabled at any one time.

Name, OID, and syntax	Access	Description
snVsrpGroupOperModeVsrp brcdIp.1.1.3.21.1.1 Syntax: Integer	Read-write	Indicates if VSRP is enabled or disabled on this system: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snVsrpIfStateChangeTrap brcdIp.1.1.3.21.1.2 Syntax: Integer	Read-write	Indicates whether the SNMP agent process is permitted to generate VSRP interface state change traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)
snVsrpIfMaxNumVridPerIntf brcdIp.1.1.3.21.1.3 Syntax: Integer32	Read-only	Indicates the maximum number of VRIDs that an interface can have.

Name, OID, and syntax	Access	Description
snVsrpIfMaxNumVridPerSystem brcdIp.1.1.3.21.1.4 Syntax: Integer32	Read-only	Indicates the maximum number of VRIDs that a system can have.
snVsrpClearVrrpStat brcdIp.1.1.3.21.1.5 Syntax: Integer	Read-write	Clears the VSRP statistics: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• clear(1)</li> </ul>

## VSRP interface table

The following table contains objects used to configure VSRP interfaces. The following objects are equivalent to the **vsrp auth-type** CLI command.

### NOTE

Make sure that “snVsrpGroupOperModeVsrp” is set to enable(1).

Name, OID, and syntax	Access	Description
snVsrpIfTable brcdIp.1.1.3.21.2.1	None	The VSRP interface table.
snVsrpIfVlanId brcdIp.1.1.3.21.2.1.1.1 Syntax: Integer32	Read-only	VLAN ID used to index the entries in this table.
snVsrpIfAuthType brcdIp.1.1.3.21.2.1.1.2 Syntax: Integer	Read-write	Indicates the authorization type used to verify access to the interface: <ul style="list-style-type: none"> <li>• noAuth(0)</li> <li>• simpleTextPasswd(1)</li> <li>• ipAuthHeader(2)</li> </ul>
snVsrpIfAuthPassword brcdIp.1.1.3.21.2.1.1.3 Syntax: OCTET STRING	Read-write	The simple text password is allowed only if the “snVsrpIfAuthType” is simpleTextPasswd(1) and the size should be greater than zero. This object can contain 0 to 8 octets and if the value is noAuth then zero length string is returned.

## VSRP virtual router table

The VSRP virtual router table describes the configuration of the VSRP virtual router. The following objects are equivalent to the **vsrp vrid** and **show vsrp** CLI commands.

Name, OID, and syntax	Access	Description
snVsrpVirRtrTable brcdIp.1.1.3.21.3.1	None	The VSRP virtual router table.
snVsrpVirRtrVlanId brcdIp.1.1.3.21.3.1.1.1 Syntax: Integer32	Read-only	VLAN index of the VSRP router.
snVsrpVirRtrId brcdIp.1.1.3.21.3.1.1.2 Syntax: Integer	Read-only	Shows a virtual router ID for the interface.

Name, OID, and syntax	Access	Description
snVsrpVirRtrOwnership brcdIp.1.1.3.21.3.1.1.3 Syntax: Integer	Read-write	Indicates the owner of the VSRP router interface. The owner or master router owns the IP addresses associated with the VRID: <ul style="list-style-type: none"> <li>incomplete(0) – No IP address has been assigned to this interface.</li> <li>owner(1) – This does not apply to VSRP.</li> <li>backup(2) – The backup router is the owner of the interface. This is the only value that can be assigned to a VSRP router interface.</li> </ul>
snVsrpVirRtrCfgPriority brcdIp.1.1.3.21.3.1.1.4 Syntax: Integer	Read-write	Indicates the preferability of a router for becoming the active router for the interface. A higher number indicates a higher priority. If two or more devices are tied with the highest priority, the backup interface with the highest IP address becomes the active router for the VRID. This object can be set only if “snVsrpVirRtrCfgPriority” is set to backup(2). Valid values: 8 – 255 Default: 100
snVsrpVirRtrTrackPriority brcdIp.1.1.3.21.3.1.1.5 Syntax: Integer <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-write	Indicates the amount by which the default track priority is reduced when a tracked interface goes down. The higher the number, the higher the priority. After this object is configured, the “snVsrpVirRtrCurrPriority” object of this interface will be adjusted dynamically with this track priority the first time the track port states changes from up to down. <b>NOTE:</b> Valid values: 1 – 254
snVsrpVirRtrCurrPriority brcdIp.1.1.3.21.3.1.1.6 Syntax: Integer	Read-only	The current VSRP priority of this Layer 3 switch for the VRID. The current priority can differ from the configured priority for the following reasons: <ul style="list-style-type: none"> <li>The VRID is still in the initialization stage and has not become a master or backup. In this case, the current priority is 0.</li> <li>The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> A higher number indicates a higher priority. This object is adjusted dynamically when the tracked port first changes from up to down. Valid values: 1 – 254
snVsrpVirRtrHelloInt brcdIp.1.1.3.21.3.1.1.7 Syntax: Integer	Read-write	Shows the number of seconds between hello advertisements sent from the master and the backup. Valid values: 1 – 84 Default: 1 second <b>NOTE:</b> This object cannot be combined with either the snVsrpVirRtrDeadInt or snVsrpVirRtrHoldDownInt objects in one SNMP set request.
snVsrpVirRtrDeadInt brcdIp.1.1.3.21.3.1.1.8 Syntax: Integer	Read-write	Shows the number of seconds a Backup waits for a hello message from the master for the VRID before determining that the master is no longer active. If the master does not send a hello messages before the dead interval expires and the backups negotiate (compare priorities) to select a new master . Valid values: 1 – 84 Default: 3 seconds <b>NOTE:</b> This object cannot be combined with the snVsrpVirRtrHelloInt object in one SNMP set request.

Name, OID, and syntax	Access	Description
snVsrpVirRtrPreemptMode brcdIp.1.1.3.21.3.1.1.9 Syntax: Integer	Read-write	Enables or disables preemption. When preemption is enabled, a higher priority backup router preempts a lower priority master. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snVsrpVirRtrState brcdIp.1.1.3.21.3.1.1.10 Syntax: Integer	Read-only	Specifies the virtual router's interface state: <ul style="list-style-type: none"> <li>init(0) – Initialization state</li> <li>master(1) – Master state</li> <li>backup(2) – Backup state</li> </ul>
snVsrpVirRtrIpAddrMask brcdIp.1.1.3.21.3.1.1.11 Syntax: OCTET STRING	Read-write	The numbers of IP addresses for this virtual router of this interface. This object is for Layer 3 VSRP. Valid values: Up to 64 octets
snVsrpVirRtrActivate brcdIp.1.1.3.21.3.1.1.12 Syntax: Integer	Read-write	Indicates if a VRRP or VRRP-E router has been activated. <ul style="list-style-type: none"> <li>disabled(0) – The router has not been activated.</li> <li>enabled(1) – The router has been activated.</li> </ul>
snVsrpVirRtrTrackPortList brcdIp.1.1.3.21.3.1.1.13 Syntax: OCTET STRING	Read-write	Specifies the router's physical track port membership. The membership includes physical ports and virtual ports whose state is to be monitored. Each port index is an ifIndex. If there are four or more consecutive ifIndexes, then the encoding and decoding scheme is range-based, as follows: <ul style="list-style-type: none"> <li>Each range prefix with 0000 (2 octets) is not a valid ifIndex.</li> <li>The first two octets in a set of four octets indicate the beginning of the range. The next two octets show the end of the range.</li> <li>Ifindexes that are not in a range are displayed as individual indexes.</li> </ul> For example, you may see the following lists: <ul style="list-style-type: none"> <li>Port list: 0001..0005 0015 0032..0047 0001..0005 and 0032..0047 show ranges of ifindexes; whereas, 0015 is one ifindex</li> <li>Port list in PDU: 0000 0001 0005 000f 0000 0020 002f</li> </ul> The list contains ifindexes not in a range. If this object is configured, then the preference level of this interface will be adjusted dynamically depending on the state of the track port. The interface's preference level is reduced by the value of preference level parameter when the track port states first changes from up to down. When the track port returns to the up state, the interface's preference level is increased by the amount specified by the preference level.
snVsrpVirRtrAdvertiseBackup brcdIp.1.1.3.21.3.1.1.14 Syntax: Integer	Read-write	Indicates if the ability for this backup to advertise itself to the current master is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)

Name, OID, and syntax	Access	Description
snVsrpVirRtrHoldDownInterval brcdIp.1.1.3.21.3.1.1.15 Syntax: Integer	Read-write	The amount of time a backup that has sent a hello packet announcing its intent to become master waits before beginning to forward traffic for the VRID. The hold-down interval prevents Layer 2 loops from occurring during rapid failover of VSRP. The interval can be from 1 through 84 seconds. Default: 2 seconds <b>NOTE:</b> This object cannot be combined with the snVsrpVirRtrHelloInterval object in one SNMP set request.
snVsrpVirRtrInitTtl brcdIp.1.1.3.21.3.1.1.16 Syntax: Integer	Read-write	Indicates the time-to-live (TTL) value in the hello packets. TTL is the maximum number of hops a VSRP hello packet can traverse before being dropped. TTL in a packet helps regulate the distance that a hello packet can travel. It prevents the flooding of VSRP hello packets in the network. Valid values: 1 – 255 seconds Default: 1 second on most devices; 2 seconds in the NetIron devices
snVsrpVirRtrIncPortList brcdIp.1.1.3.21.3.1.1.17 Syntax: OCTET STRING	Read-write	Groups all free ports of a VLAN into their control ports.
snVsrpVirRtrSave brcdIp.1.1.3.21.3.1.1.18 Syntax: Integer	Read-write	Sets VSRP to save current parameters value: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snVsrpVirRtrBackupInterval brcdIp.1.1.3.21.3.1.1.19 Syntax: Integer	Read-write	Indicates the time interval when backup routers send hello message advertisements. Valid values: 60 – 3600 seconds Default: 60 seconds
snVsrpVirRtrRowStatus brcdIp.1.1.3.21.3.1.1.20 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row.</li> <li>• create(4) – Create a new row.</li> <li>• modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>
snVsrpVirRtrRxArpPacketDropCounts brcdIp.1.1.3.21.3.1.1.21 Syntax: Counter32	Read-only	The received VSRP ARP packet drop counts.
snVsrpVirRtrRxIpPacketDropCounts brcdIp.1.1.3.21.3.1.1.22 Syntax: Counter32	Read-only	The received VSRP IP packet drop counts.
snVsrpVirRtrRxPortMismatchCounts brcdIp.1.1.3.21.3.1.1.23 Syntax: Counter32	Read-only	The received VSRP port mismatching counts.

Name, OID, and syntax	Access	Description
snVsrpVirRtrRxNumOfIpMismatchCnts brcdIp.1.1.3.21.3.1.1.24 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the received number of mismatched IP addresses for VSRP.
snVsrpVirRtrRxIpMismatchCnts brcdIp.1.1.3.21.3.1.1.25 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the number of received VSRP IP addresses that are mismatched.
snVsrpVirRtrRxHelloIntervalMismatchCnts brcdIp.1.1.3.21.3.1.1.26 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the number of the virtual router interfaces with hello intervals that are mismatched.
snVsrpVirRtrRxPriorityZeroFromMasterCnts brcdIp.1.1.3.21.3.1.1.27 Syntax: Counter32 <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the number of advertisements with priority of zero received from the master.
snVsrpVirRtrRxHigherPriorityCnts brcdIp.1.1.3.21.3.1.1.28 Syntax: Counter32	Read-only	The counts of the virtual router interfaces with higher priority.
snVsrpVirRtrTransToMasterStateCnts brcdIp.1.1.3.21.3.1.1.29 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.
snVsrpVirRtrTransToBackupStateCnts brcdIp.1.1.3.21.3.1.1.30 Syntax: Counter32	Read-only	Shows the number of times this interface has changed from the master state to the backup state.
snVsrpVirRtrCurrDeadInterval brcdIp.1.1.3.21.3.1.1.31 Syntax: Integer32	Read-only	Shows the current dead intervals in increments of 100 milliseconds for the virtual router. This is the time period that a backup waits for a hello message from the master before determining that the master is no longer active. If the master does not send a hello message before the dead interval expires and the backups negotiate (compare priorities) to select a new master.

Name, OID, and syntax	Access	Description
snVsrpVirRtrCurHelloInt brcdIp.1.1.3.21.3.1.1.32 Syntax: Integer	Read-only	Shows the current backup router hello interval.
snVsrpVirRtrCurHoldDownInt brcdIp.1.1.3.21.3.1.1.33 Syntax: Integer	Read-only	Shows the current value of the hold-down interval. Valid values: 1 - 84
snVsrpVirRtrCurInitTtl brcdIp.1.1.3.21.3.1.1.34 Syntax: Integer	Read-only	Shows the current TTL value. Valid values: 1 - 255
snVsrpVirRtrHelloMacAddress brcdIp.1.1.3.21.3.1.1.35 Syntax: MAC address <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the hello MAC address.
snVsrpVirRtrMasterIpAddress brcdIp.1.1.3.21.3.1.1.36 Syntax: IpAddress <b>NOTE:</b> This object is supported on the Brocade NetIron devices.	Read-only	Shows the master router's real or virtual (primary) IP address. This is the IP address listed as the source in VSRP advertisement, which is last received by this virtual router.





# ARP MIB Definition

## In this chapter

- [Global ARP statistics](#) ..... 407

## Global ARP statistics

The following MIB objects display statistics for Address Resolution Protocol (ARP).

### NOTE

The objects in the following table are not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snArpStatsTotalReceived brcdIp.1.1.3.22.1.1 Syntax: Counter32	Read-only	The total number of ARP packets received from the interfaces, including those received in error.
snArpStatsRequestReceived brcdIp.1.1.3.22.1.2 Syntax: Counter32	Read-only	The total number of input ARP request packets received from the interfaces.
snArpStatsRequestSent brcdIp.1.1.3.22.1.3 Syntax: Counter32	Read-only	The total number of output ARP request packets sent from the interfaces.
snArpStatsRepliesSent brcdIp.1.1.3.22.1.4 Syntax: Counter32	Read-only	The total number of output ARP reply packets sent from the interfaces.
snArpStatsPendingDrop brcdIp.1.1.3.22.1.5 Syntax: Counter32	Read-only	The total number of ARP pending packets discarded.
snArpStatsInvalidSource brcdIp.1.1.3.22.1.6 Syntax: Counter32	Read-only	The total number of ARP packets received with invalid sender protocol address.
snArpStatsInvalidDestination brcdIp.1.1.3.22.1.7 Syntax: Counter32	Read-only	The total number of ARP packets received with invalid destination protocol address.

## 44 ARP MIB Definition

# IP MIB Definition

---

## In this chapter

- Global router MIB. . . . . 409
- IP general group. . . . . 410
- IP static route table . . . . . 412
- IP filter table. . . . . 413
- RARP table . . . . . 415
- Static ARP table . . . . . 416
- IP interface port address table. . . . . 417
- IP interface port access table. . . . . 418
- Port configuration tables. . . . . 419
- IP interface counter table . . . . . 422

## Global router MIB

The following table contains a global MIB object covering the switching properties of the Layer 3 switch, regardless of routing protocol.

Name, OID, and syntax	Access	Description
snGblRtRouteOnly brcdIp.1.2.8.1.1 Syntax: Integer	Read-write	Determines if the Layer 3 switch will route or switch packets: <ul style="list-style-type: none"> <li>• disabled(0) – Router will first route the packets. If it cannot route them, it will switch the packets.</li> <li>• enabled(1) – Router will only route the packets; it will not switch them.</li> </ul>

## IP general group

The following table contains the general objects for the IP group.

Name, OID, and syntax	Access	Description
snRtClearArpCache brcdIp.1.2.2.1.1 Syntax: ClearStatus <b>NOTE:</b> This object is supported in the ServerIron devices.	Read-write	Clears learned Address Resolution Protocol (ARP) entries but does not remove any static ARP entries: <ul style="list-style-type: none"> <li>• normal(0) – Do not clear learned entries.</li> <li>• clear(1) – Clear learned entries.</li> </ul>
snRtClearIpCache brcdIp.1.2.2.1.2 Syntax: ClearStatus	Read-write	Clears the entries in the IP forwarding cache table: <ul style="list-style-type: none"> <li>• normal(0) – Do not clear entries.</li> <li>• clear(1) – Clear entries.</li> </ul>
snRtClearIpRoute brcdIp.1.2.2.1.3 Syntax: ClearStatus	Read-write	Clears the IP route tables: <ul style="list-style-type: none"> <li>• normal(0) – Do not clear entries.</li> <li>• clear(1) – Clear entries.</li> </ul>
snRtBootpServer brcdIp.1.2.2.1.4 Syntax: IpAddress <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the IP address of the bootp server to which bootp packets must be relayed.
snRtBootpRelayMax brcdIp.1.2.2.1.5 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the maximum number of hops the bootp packet should travel. Valid values: Up to 15 hops
snRtArpAge brcdIp.1.2.2.1.6 Syntax: Integer	Read-write	Specifies the number of minutes that an ARP entry can be valid without having to be relearned. Valid values: Up to 240 minutes. A value of zero (0) means that the entry will not age out.

Name, OID, and syntax	Access	Description
snRtIpIrdpEnable brcdIp.1.2.2.1.7 Syntax: Integer	Read-write	Indicates if router advertisement is enabled on this device: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpLoadShare brcdIp.1.2.2.1.8 Syntax: Integer	Read-write	Indicates if more than one route is enabled to share the loads: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpProxyArp brcdIp.1.2.2.1.9 Syntax: Integer	Read-write	Indicates if the proxy ARP function is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpRarp brcdIp.1.2.2.1.10 Syntax: Integer	Read-write	Indicates if the RARP server is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpTtl brcdIp.1.2.2.1.11 Syntax: Integer	Read-write	Indicates the time-to-live (TTL) value that will be used in the IP header of an IP packet that was generated by this device. Valid values: 1 – 255
snRtIpSetAllPortConfig brcdIp.1.2.2.1.12 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the index number of a row in “ <a href="#">snRtIpPortConfigTable</a> ” on page 419, such as “ <a href="#">snRtIpPortConfigPortIndex</a> ” on page 419. All the writeable data from that row will be copied to all appropriate rows in all IPinterface port configuration table. <b>NOTE:</b> Prior to setting this object, make sure that the row identified in this object contains a value for all its objects; otherwise, the current data of the row will be used to set the entire IP interface configuration table.
snRtIpFwdCacheMaxEntries brcdIp.1.2.2.1.13 Syntax: Integer32	Read-only	Shows the maximum number of entries in the IP forwarding cache table.
snRtIpFwdCacheCurEntries brcdIp.1.2.2.1.14 Syntax: Integer32	Read-only	Shows the current number of entries in the IP forwarding cache table.
snRtIpMaxStaticRouteEntries brcdIp.1.2.2.1.15 Syntax: Integer	Read-only	Shows the maximum number of entries in the IP static route table.
snRtIpDirBcastFwd brcdIp.1.2.2.1.16 Syntax: Integer	Read-write	Indicates if the directed broadcast forwarding feature is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpLoadShareNumOfPaths brcdIp.1.2.2.1.17 Syntax: Integer32	Read-write	Specifies the number of routes to be used to share the load.

Name, OID, and syntax	Access	Description
snRtlpLoadShareMaxP aths brcdIp.1.2.2.1.18 Syntax: Integer32	Read-only	Indicates the maximum number of routes that can be configured to share the load.
snRtlpLoadShareMinPa ths brcdIp.1.2.2.1.19 Syntax: Integer32	Read-only	Indicates the minimum number of routes that can be configured to share the load.
snRtlpProtocolRouterId brcdIp.1.2.2.1.20 Syntax: IpAddress	Read-write	Shows the router ID for all Internet Protocols.
snRtlpSourceRoute brcdIp.1.2.2.1.21 Syntax: Integer	Read-write	Indicates if strict source routing is enabled to drop source routed packets: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## IP static route table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

The IP static route table contains a list of static routes. These routes can be one of the following types:

- Standard – The static route consists of the destination network address and network mask, plus the IP address of the next-hop gateway.
- Interface-based – The static route consists of the destination network address and network mask, plus the Layer 3 switch interface through which you want the Layer 3 switch to send traffic for the route. Typically, this type of static route is directly attached to the destination networks.
- Null – The static route consists of the destination network address and network mask, plus the “null0” parameter. Typically, the null route is configured as a backup route for discarding traffic if the primary route is unavailable.

The IP static route table also serves as the default route table.

Name, OID, and syntax	Access	Description
snRtlpStaticRouteTable brcdIp.1.2.2.2	None	IP static route table.
snRtlpStaticRouteIndex brcdIp.1.2.2.2.1.1 Syntax: Integer32	Read-only	The table index for a static route entry.
snRtlpStaticRouteDest brcdIp.1.2.2.2.1.2 Syntax: IpAddress	Read-write	Shows the destination IP address of the default route. The address 0.0.0.0 is the IP address of the default router.

Name, OID, and syntax	Access	Description
snRtlpStaticRouteMask brcdIp.1.2.2.2.1.3 Syntax: IpAddress	Read-write	Shows the subnet mask of the default router destination IP address. The subnet mask of the default router is 0.0.0.0.
snRtlpStaticRouteNextHop brcdIp.1.2.2.2.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the next-hop router (gateway) for the route.
snRtlpStaticRouteMetric brcdIp.1.2.2.2.1.5 Syntax: Integer32	Read-write	Shows the metrics to next-hop router. Default: 1
snRtlpStaticRouteRowStatus brcdIp.1.2.2.2.1.6 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>other(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snRtlpStaticRouteDistance brcdIp.1.2.2.2.1.7 Syntax: Integer	Read-write	Specifies the administrative distance of the route. When comparing equal routes to a destination, the Layer 3 switch prefers lower administrative distances over higher ones. Valid values: 1 – 255 Default: 1

## IP filter table

An IP filter is an access policy that determines whether the device forwards or drops IP packets. A filter consists of source and destination IP information and the action to take when a packet matches the values in the filter.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

The following objects define IP filters.

Name, OID, and syntax	Access	Description
snRtlpFilterTable brcdIp.1.2.2.3	None	The IP filter table.
snRtlpFilterIndex brcdIp.1.2.2.3.1.1 Syntax: Integer32	Read-only	Shows the index for an entry in the IP filter table.

Name, OID, and syntax	Access	Description
snRtlpFilterAction brcdIp.1.2.2.3.1.2 Syntax: Integer	Read-write	Determines the action to be taken if the IP packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> <li>qosEnabled(2)</li> </ul> When you configure an IP access policy, the device denies all IP packets by default unless you explicitly permit them. Thus, if you want the device to permit all IP packets except the ones that you filter out, you must configure the last IP access policy to permit all IP packets.
snRtlpFilterProtocol brcdIp.1.2.2.3.1.3 Syntax: Integer	Read-write	Specifies the transport protocol that you can filter. Only the traffic for the transport protocol selected will be allowed: <ul style="list-style-type: none"> <li>all(0) – All traffic of the following transport protocols listed is permitted.</li> <li>ICMP(1)</li> <li>IGMP(2)</li> <li>IGRP(88)</li> <li>OSPF(89)</li> <li>TCP(6)</li> <li>UDP(17)</li> </ul> In addition, if you filter TCP or UDP, you can also specify a particular application port (such as “HTTP” or “80”) or a logical expression consisting of an operator and port names or numbers.
snRtlpFilterSourceIp brcdIp.1.2.2.3.1.4 Syntax: IpAddress	Read-write	Shows the source IP address. The policy will be applied to packets that come from this IP address.
snRtlpFilterSourceMask brcdIp.1.2.2.3.1.5 Syntax: IpAddress	Read-write	Shows the source IP subnet mask. The policy will be applied to packets that come from this subnet mask.
snRtlpFilterDestIp brcdIp.1.2.2.3.1.6 Syntax: IpAddress	Read-write	Shows the destination IP address. The IP access policy will be applied to packets that are going to this IP address.
snRtlpFilterDestMask brcdIp.1.2.2.3.1.7 Syntax: IpAddress	Read-write	Shows the destination IP subnet mask. The IP access policy will be applied to packets that are going to this subnet mask.
snRtlpFilterOperator brcdIp.1.2.2.3.1.8 Syntax: Integer	Read-write	Applies only if the value of the “snRtlpFilterProtocol” object is TCP or UDP. It specifies the type of comparison to be performed to TCP and UDP packets: <ul style="list-style-type: none"> <li>greater(1) – The policy applies to TCP or UDP port numbers that are greater than the value of the “snRtlpFilterOperand” object.</li> <li>equal(2) – The policy applies to TCP or UDP port numbers that are equal to the value of the “snRtlpFilterOperand” object.</li> <li>less(3) – The policy applies to TCP or UDP port numbers that are less than the value of the “snRtlpFilterOperand” object.</li> <li>notEqual(4) – The policy applies to all TCP or UDP port numbers except to those that are equal to the value of the “snRtlpFilterOperand” object.</li> </ul>
snRtlpFilterOperand brcdIp.1.2.2.3.1.9 Syntax: Integer	Read-write	Applies only if the value of the “snRtlpFilterProtocol” object is TCP or UDP. Specifies the TCP or UDP port number that will be used in this filter. Valid values: 0 – 65535. 0 means that this object is not applicable.



Name, OID, and syntax	Access	Description
snRtlpFilterRowStatus brcdIp.1.2.2.3.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snRtlpFilterEstablished brcdIp.1.2.2.3.1.11 Syntax: Integer	Read-write	Applies only to TCP packets. Indicates if the filtering of established TCP packets is enabled for packets that have the ACK or RESET flag on: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtlpFilterQosPriority brcdIp.1.2.2.3.1.12 Syntax: Integer	Read-write	The router Layer 4 QoS Priority values are: <ul style="list-style-type: none"> <li>low(0) – lower priority</li> <li>high(1) – higher priority</li> </ul> The Priority values are: <ul style="list-style-type: none"> <li>level0(0) – Lower priority</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3),</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7) – Higher priority</li> </ul>

## RARP table

The Reverse Address Resolution Protocol (RARP) provides a simple mechanism for directly-attached IP hosts to boot over the network. RARP allows an IP host that does not have a means of storing its IP address across power cycles or software reloads to query a directly-attached router for an IP address.

RARP is enabled by default. However, there must be a static RARP entry for each host that will use the Layer 3 switch for booting. The following table contains the objects that define each RARP entry.

### NOTE

The following table is supported on Brocade MLXe router, Brocade MLX, and Brocade NetIron XMR devices.

Name, OID, and syntax	Access	Description
snRtlpRarpTable brcdIp.1.2.2.4	None	IP RARP table.
snRtlpRarpIndex brcdIp.1.2.2.4.1.1 Syntax: Integer	Read-only	An index for an entry in the RARP table. There can be up to 16 entries.
snRtlpRarpMac brcdIp.1.2.2.4.1.2 Syntax: OCTET STRING	Read-write	Shows the MAC address of the RARP client.
snRtlpRarpIp brcdIp.1.2.2.4.1.3 Syntax: IpAddress	Read-write	Shows the IP address for a RARP client.
snRtlpRarpRowStatus brcdIp.1.2.2.4.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Static ARP table

The Address Resolution Protocol (ARP) is a standard IP protocol that enables an IP Layer 3 switch to obtain the MAC address of another device's interface when the Layer 3 switch knows the IP address of the interface. ARP is enabled by default and cannot be disabled.

The static ARP table in a Layer 3 switch contains entries that are useful in cases where you want to preconfigure an entry for a device that is not connected to the Layer 3 switch, or you want to prevent a particular entry from aging out. The software removes a dynamic entry from the ARP cache if the ARP aging interval expires before the entry is refreshed. Static entries do not age out, regardless of whether or not the device receives an ARP request from the device that has the entry's address.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtStaticArpTable brcdIp.1.2.2.5	None	IP static ARP table.
snRtStaticArpIndex brcdIp.1.2.2.5.1.1 Syntax: Integer	Read-only	An index for a static ARP entry. There can be up to 16 entries.

Name, OID, and syntax	Access	Description
snRtStaticArpIp brcdIp.1.2.2.5.1.2 Syntax: IpAddress	Read-write	Shows the IP address of a static ARP entry.
snRtStaticArpMac brcdIp.1.2.2.5.1.3 Syntax: OCTET STRING	Read-write	Specifies the MAC address of a static ARP entry.
snRtStaticArpPort brcdIp.1.2.2.5.1.4 Syntax: PortIndex	Read-write	Specifies the port number attached to the device that has the MAC address of the entry. For FastIron or NetIron products, the value of this object is from 1 through 42.
snRtStaticArpRowStatus brcdIp.1.2.2.5.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IP interface port address table

### NOTE

The following table is supported on the Brocade MLXe, Brocade MLX, and Brocade NetIron XMR devices.

The IP interface port address table shows the port IP address and its port type.

Name, OID, and syntax	Access	Description
snRtIpPortAddrTable brcdIp.1.2.2.6	None	IP port address table.
snRtIpPortAddrPortIndex brcdIp.1.2.2.6.1.1 Syntax: PortIndex	Read-only	The index of the port address entry. For FastIron or NetIron products, the value of this object is from 1 through 42.
snRtIpPortAddress brcdIp.1.2.2.6.1.2 Syntax: IpAddress	Read-only	Specifies the port IP address.
snRtIpPortSubnetMask brcdIp.1.2.2.6.1.3 Syntax: IpAddress	Read-write	Specifies the port IP address subnet mask.

Name, OID, and syntax	Access	Description
snRtlpPortAddrType brcdIp.1.2.2.6.1.4 Syntax: Integer	Read-write	Shows the port type of the entry: <ul style="list-style-type: none"> <li>primary(1)</li> <li>secondary(2)</li> </ul> Default: primary(1)
snRtlpPortRowStatus brcdIp.1.2.2.6.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a set with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IP interface port access table

The following table determines if the port is for incoming or outgoing traffic and the filter used on the interface.

The following table is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpPortAccessTable brcdIp.1.2.2.7	None	IP port access table.
snRtlpPortAccessPortIndex brcdIp.1.2.2.7.1.1 Syntax: PortIndex	Read-only	The index for an entry in the IP port access table. For FastIron or NetIron products, the value of this object is from 1 through 42.
snRtlpPortAccessDirection brcdIp.1.2.2.7.1.2 Syntax: Integer	Read-only	Specifies if the port is for incoming or outgoing traffic: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>

Name, OID, and syntax	Access	Description
snRtlpPortAccessFilters brcdIp.1.2.2.7.1.3 Syntax: OCTET STRING	Read-write	Each octet represents a filter number.
snRtlpPortAccessRowStatus brcdIp.1.2.2.7.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Port configuration tables

The following table define the size, encapsulation format, and cost of the packet that will be transmitted through a port.

### IP interface port configuration table

#### NOTE

The following table is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpPortConfigTable brcdIp.1.2.2.8	None	The IP port configuration table.
snRtlpPortConfigPortIndex brcdIp.1.2.2.8.1.1 Syntax: PortIndex	Read-only	An index for an entry in the IP port configuration table. For FastIron or NetIron products, the value of this object is from 1 through 42.
snRtlpPortMtu brcdIp.1.2.2.8.1.2 Syntax: Integer	Read-write	Indicates the maximum size of IP packets that will be transmitted on the port.
snRtlpPortEncap brcdIp.1.2.2.8.1.3 Syntax: Integer	Read-write	Shows the encapsulation format that will be used on the IP frame transmitted on the port: <ul style="list-style-type: none"> <li>ethernet(1) – Ethernet</li> <li>snap(2) – ATM and Ethernet</li> <li>hdlc(3) – POS</li> <li>ppp(4) – POS</li> </ul>

Name, OID, and syntax	Access	Description
snRtlpPortMetric brcdIp.1.2.2.8.1.4 Syntax: Integer	Read-write	Specifies the metric or cost the router adds to the route. Valid values: 1 – 15 Default: 1
snRtlpPortDirBcastFwd brcdIp.1.2.2.8.1.5 Syntax: Integer	Read-write	Indicates if the directed broadcast forwarding feature is enabled. A directed broadcast is a packet containing all ones (or in some cases, all zeros) in the host portion of the destination IP address. When a router forwards such a broadcast, it sends a copy of the packet out each of its enabled IP interfaces: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)

## IP interface address table

### NOTE

The following table is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpPortIfAddrTable brcdIp.1.2.2.18	None	IP port interface address table.
snRtlpPortIfAddrInterfaceIndex brcdIp.1.2.2.18.1.1 Syntax: InterfaceIndex	Read-only	The interface index for port address entry.
snRtlpPortIfAddress brcdIp.1.2.2.18.1.2 Syntax: IpAddress	Read-only	The port IP address.
snRtlpPortIfSubnetMask brcdIp.1.2.2.18.1.3 Syntax: IpAddress	Read-write	The port IP address subnet mask.
snRtlpPortIfAddrType brcdIp.1.2.2.18.1.4 Syntax: Integer	Read-write	The port IP address type.
snRtlpPortIfRowStatus brcdIp.1.2.2.18.1.5 Syntax: RowSts	Read-write	To create or delete a port address entry.

## IP interface port access table

The following table determines if the port is for incoming or outgoing traffic and the filter used on the interface.

### NOTE

The following table is not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpPortIfAccessTable brcdIp.1.2.2.19	None	IP port if access table.
snRtlpPortIfAccessInterf aceIndex brcdIp.1.2.2.19.1.1 Syntax: InterfaceIndex	Read-only	The interface index for port access entry.
snRtlpPortIfAccessDirec tion brcdIp.1.2.2.19.1.2 Syntax: Integer	Read-only	The incoming or outgoing check.
snRtlpPortIfAccessFilter s brcdIp.1.2.2.19.1.3 Syntax: OCTET STRING	Read-write	The first octet correspond to the first filter number and so on.
snRtlpPortIfAccessRowS tatus brcdIp.1.2.2.19.1.4 Syntax: RowSts	Read-write	To create or delete a port access entry.

## IP interface configuration table

### NOTE

The following table is supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpPortIfConfigTable brcdIp.1.2.2.20	None	IP port if configuration table.
snRtlpPortIfConfigInterf aceIndex brcdIp.1.2.2.20.1.1 Syntax: InterfaceIndex	Read-only	The if index for port configuration entry.
snRtlpPortIfMtu brcdIp.1.2.2.20.1.2 Syntax: Integer32	Read-Write	The maximum transfer unit: <ul style="list-style-type: none"> <li>Ethernet MTU range: 46 to 1500</li> <li>POS MTU range: 60 to 4470</li> <li>ATM MTU range: 1500 to 9180</li> <li>ATM SubIf MTU range: 1500 to 9180</li> </ul> For jumbo support, the MTU range could be higher.
snRtlpPortIfEncap brcdIp.1.2.2.20.1.3 Syntax: Integer	Read-Write	Data link encapsulation to be used on the IP frame transmitted on the port.
snRtlpPortIfMetric brcdIp.1.2.2.20.1.4 Syntax: Integer	Read-Write	The metric for port configuration entry.

Name, OID, and syntax	Access	Description
snRtlpPortIfDirBcastFwd brcdIp.1.2.2.20.1.5 Syntax: RtrStatus	Read-Write	Enables or disables directed broadcast forwarding on the port.
snRtlpPortConfigIfDonor Interface brcdIp.1.2.2.20.1.6 Syntax: InterfaceIndexOrZero	Read-only	Returns the ifIndex of the donor interface, if the interface is configured as an unnumbered interface. Returns its own ifIndex value, if the interface is configured as a donor interface. Otherwise, returns 0.

## IP interface counter table

Name, OID, and Syntax	Access	Description
agIpPortCounterTable brcdIp.1.2.2.21	None	IP port counter table to display IP traffic statistics. At present, the system supports only IP statistics for Ethernet ports.
agIpPortCounterIpVersion brcdIp.1.2.2.21.1.1 Syntax: IpAddress	None	The version of IP for which this counter entry is returned. This table supports ipv4(1) and ipv6(2) enumerations.
agIpPortCounterRxPacket brcdIp.1.2.2.21.1.2 Syntax: Counter64	Read-only	Total IP packets received on a given interface.
agIpPortCounterRxOctet brcdIp.1.2.2.21.1.3 Syntax: Counter64	Read-only	Total IP octets received on a given interface.
agIpPortCounterTxPacket brcdIp.1.2.2.21.1.4 Syntax: Counter64	Read-only	Total IP packets transmitted from a given interface.
agIpPortCounterTxOctet brcdIp.1.2.2.21.1.5 Syntax: Counter64	Read-only	Total IP octets transmitted from a given interface.



# IPV6 IP MIB Definition

---

## In this chapter

- [ECMP MIB objects](#) ..... 423

---

### NOTE

The MIB objects presented in this chapter are supported on the FastIron devices that support IPv6.

---

## ECMP MIB objects

The SNMP Equal-Cost Multi-Path (ECMP) MIB object is used to configure ECMP for IPv6 using SNMP. ECMP enables the router to balance traffic to a specific destination across multiple equal-cost paths.

To use these objects, perform the following steps.

1. Enable ECMP for RIP using the `snRtIpRipEcmpEnable` MIB object.  
IP load sharing is enabled by default. However, ECMP must be enabled for RIP IP load sharing.
2. Enable IPv6 load sharing using the `fdryIpv6LoadShare` MIB object.  
IPv6 load sharing is enabled by default. If it needs to be enabled, set `fdryIpv6LoadShare` to 1.
3. Configure the maximum number of load sharing paths for IPv6 using the `fdryIpv6LoadShareNumOfPaths` MIB object.

Name, OID, and syntax	Access	Description
<code>fdryIpv6LoadShare</code> brcdIp.1.2.17.1.1.1 Syntax: RtrStatus	Read-write	This object directs the IPv6 traffic to distribute the traffic load to IPv6 routes if more than one IPv6 route is available: <ul style="list-style-type: none"> <li>• 0 — Disables IPv6 load sharing.</li> <li>• 1 — Enables IPv6 load sharing.</li> </ul>
<code>fdryIpv6LoadShareNumOfPaths</code> brcdIp.1.2.17.1.1.2 Syntax: Unsigned32	Read-write	Enter the number of IPv6 routes to be used to share a load. Enter a value from 2 through 6.



# IPX MIB Definition

---

## In this chapter

• IPX general objects .....	425
• IPX cache table .....	427
• IPX route table .....	428
• IPX server table .....	429
• IPX forward filter table .....	429
• IPX RIP filter table .....	430
• IPX SAP filter table .....	431
• IPX IF forward access table .....	432
• IPX IF RIP access table .....	432
• IPX IF SAP access table .....	433
• IPX port address table .....	433
• IPX port counters table .....	434

## IPX general objects

---

### NOTE

The Internet Packet Exchange (IPX) MIBs are not supported on all FastIron products, Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

The following table presents the general objects used to define IPX.

Name, OID, and syntax	Access	Description
snIpxRoutingMode brcdIp.1.2.1.1.1 Syntax: Integer	Read-write	Shows the IPX routing mode status: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snIpxNetBiosFilterMode brcdIp.1.2.1.1.2 Syntax: Integer	Read-write	Shows the NetBios filter mode status: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snIpxClearCache brcdIp.1.2.1.1.3 Syntax: ClearStatus	Read-write	Indicates if the cache table will be cleared: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• clear(1)</li> </ul>
snIpxClearRoute brcdIp.1.2.1.1.4 Syntax: ClearStatus	Read-write	Indicates if the IPX table will be cleared: <ul style="list-style-type: none"> <li>• normal(0)</li> <li>• clear(1)</li> </ul>

Name, OID, and syntax	Access	Description
snlpxClearTrafficCnts brcdIp.1.2.1.1.5 Syntax: ClearStatus	Read-write	Indicates if all IPX traffic counters are cleared: <ul style="list-style-type: none"> <li>• normal(0) – Do not clear counters.</li> <li>• clear(1) – Clear counters.</li> </ul> The following IPX traffic counters are affected by this object: <ul style="list-style-type: none"> <li>• <a href="#">snlpxRcvPktsCnt</a></li> <li>• <a href="#">snlpxFwdPktsCnt</a></li> <li>• <a href="#">snlpxRcvDropPktsCnt</a></li> <li>• <a href="#">snlpxTxDropPktsCnt</a></li> <li>• <a href="#">snlpxRcvFiltPktsCnt</a></li> <li>• <a href="#">snlpxTxFiltPktsCnt</a></li> </ul>
snlpxRcvPktsCnt brcdIp.1.2.1.1.6 Syntax: Counter	Read-only	The number of IPX packets received on the Layer 3 switch.
snlpxTxPktsCnt brcdIp.1.2.1.1.7 Syntax: Counter	Read-only	The number of IPX packets that originated on the Layer 3 switch and sent on its port.
snlpxFwdPktsCnt brcdIp.1.2.1.1.8 Syntax: Counter	Read-only	The number of IPX packets received by the Layer 3 switch from another device and then sent out on its port.
snlpxRcvDropPktsCnt brcdIp.1.2.1.1.9 Syntax: Counter	Read-only	The number of packets received by the Layer 3 switch that the switch dropped.
snlpxRcvFiltPktsCnt brcdIp.1.2.1.1.10 Syntax: Counter	Read-only	The number of packets received by a port that matched an inbound IPX filter configured on the port.
snlpxRipGblFiltList brcdIp.1.2.1.1.11 Syntax: OCTET STRING	Read-write	An IPX RIP global filter list. There can be up to 32 octets in this object.
snlpxRipFiltOnAllPort brcdIp.1.2.1.1.12 Syntax: Integer	Read-write	Applies the IPX RIP global filter list in the “ <a href="#">snlpxRipGblFiltList</a> ” object to all interfaces. This object adds all RIP filter lists and deletes all RIP filter lists from all ports. Before sending the command, the “ <a href="#">snlpxRipGblFiltList</a> ” object must be defined. The following values can be written: <ul style="list-style-type: none"> <li>• deleteAllInBound(2) – Deletes all in-bound filter lists from all ports.</li> <li>• deleteAllOutBound(3) – Deletes all out-bound filter lists from all ports.</li> <li>• addAllInBound(4) – Adds all in-bound filter lists to all ports.</li> <li>• addAllOutBound(5) – Adds all out-bound filter lists to all ports.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – Set operation has not been performed.</li> <li>• valid(1) – Set operation is done and is valid.</li> </ul>
snlpxSapGblFiltList brcdIp.1.2.1.1.13 Syntax: OCTET STRING	Read-write	An IPX SAP global filter list. There can be up to 32 octets in this object.

Name, OID, and syntax	Access	Description
snlpxSapFiltOnAllPort brcdIp.1.2.1.1.14 Syntax: Integer	Read-write	Applies the IPX RIP global filter list in the “snlpxSapGblFiltList” object to all interfaces. This object adds all filter lists and deletes all SAP filter lists from all ports. Before sending this command, the “snlpxSapGblFiltList” object must be defined. The following values can be written: <ul style="list-style-type: none"> <li>deleteAllInBound(2) – Deletes all in-bound filter lists from all ports.</li> <li>deleteAllOutBound(3) – Deletes all out-bound filter lists from all ports.</li> <li>addAllInBound(4) – Adds all in-bound filter lists to all ports.</li> <li>addAllOutBound(5) – Adds all out-bound filter lists to all ports.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – Set operation has not be performed.</li> <li>valid(1) – Set operation is done and is valid.</li> </ul>
snlpxTxDropPktsCnt brcdIp.1.2.1.1.15 Syntax: Counter	Read-only	Shows the number of packets that were queued to be sent on a port by the Layer 3 switch, but then dropped.
snlpxTxFiltPktsCnt brcdIp.1.2.1.1.16 Syntax: Counter	Read-only	The number of packets that were queued to be sent on a port that matched an outbound IPX filter that was configured on the port.

## IPX cache table

The IPX cache table contains information about the IPX forwarding cache for the router.

Name, OID, and syntax	Access	Description
snlpxCacheTable brcdIp.1.2.1.2.1	None	The IPX cache table.
snlpxCacheIndex brcdIp.1.2.1.2.1.1.1 Syntax: Integer	Read-only	The table index for an IPX cache table entry.
snlpxCacheNetNum brcdIp.1.2.1.2.1.1.2 Syntax: NetNumber	Read-only	Shows the network number containing the destination node.
snlpxCacheNode brcdIp.1.2.1.2.1.1.3 Syntax: Physical address	Read-only	Shows the number of the destination node.
snlpxCacheOutFilter brcdIp.1.2.1.2.1.1.4 Syntax: Integer	Read-only	Shows if an outbound cache filter has been enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and syntax	Access	Description
snIpxCacheEncap brcdIp.1.2.1.2.1.1.5 Syntax: Integer	Read-only	Shows the IPX frame encapsulation type: <ul style="list-style-type: none"> <li>EthernetII(1)</li> <li>Ethernet8022(2)</li> <li>Ethernet8023(3)</li> <li>EthernetSnap(4)</li> </ul>
snIpxCachePort brcdIp.1.2.1.2.1.1.6 Syntax: PortIndex	Read-only	Shows the number of the port through which the Layer 3 switch sends IPX traffic to the destination network and node.

## IPX route table

The IPX route table contains objects for IPX routes.

Name, OID, and syntax	Access	Description
snIpxRouteTable brcdIp.1.2.1.3.1	None	The IPX route table.
snIpxRouteIndex brcdIp.1.2.1.3.1.1.1 Syntax: Integer	Read-only	The table index for an IPX route entry.
snIpxDestNetNum brcdIp.1.2.1.3.1.1.2 Syntax: OCTET STRING	Read-only	Shows the destination network number. A value of all zeros indicates that any destination network number is accepted.
snIpxFwdRouterNode brcdIp.1.2.1.3.1.1.3 Syntax: Physical address	Read-only	Shows the MAC address of the next hop IPX route.
snIpxDestHopCnts brcdIp.1.2.1.3.1.1.4 Syntax: Integer	Read-only	Shows the number of hops to reach the destination.
snIpxRouteMetric brcdIp.1.2.1.3.1.1.5 Syntax: Integer	Read-only	Shows the metric for the next-hop router.
snIpxDestPort brcdIp.1.2.1.3.1.1.6 Syntax: Integer	Read-only	Shows the destination port.

## IPX server table

The IPX server table presents information about the IPX servers.

Name, OID, and syntax	Access	Description
snIpxServerTable brcdIp.1.2.1.4.1	None	The IPX server table.
snIpxServerIndex brcdIp.1.2.1.4.1.1.1 Syntax: Integer	Read-only	The table index for an IPX server entry.
snIpxServerType brcdIp.1.2.1.4.1.1.2 Syntax: Integer	Read-only	Shows the IPX server type.
snIpxServerNetNum brcdIp.1.2.1.4.1.1.3 Syntax: NetNumber	Read-only	Shows the IPX server network number.
snIpxServerNode brcdIp.1.2.1.4.1.1.4 Syntax: Physical address	Read-only	Shows the IPX server node number.
snIpxServerSocket brcdIp.1.2.1.4.1.1.5 Syntax: Integer	Read-only	Shows the IPX server socket number.
snIpxServerHopCnts brcdIp.1.2.1.4.1.1.6 Syntax: Integer	Read-only	Shows the IPX number of intervening networks to reach the IPX server.
snIpxServerName brcdIp.1.2.1.4.1.1.7 Syntax: OCTET STRING	Read-only	Shows the IPX server name. There can be up to 47 octets in this object.

## IPX forward filter table

The following table defines forward filters, which control the access of remote IPX clients to a server with restricted access.

Name, OID, and syntax	Access	Description
snIpxFwdFilterTable brcdIp.1.2.1.5.1	None	The IPX forward filter table.
snIpxFwdFilterIdx brcdIp.1.2.1.5.1.1.1 Syntax: Integer	Read-only	The filter ID for a filter entry.
snIpxFwdFilterAction brcdIp.1.2.1.5.1.1.2 Syntax: Integer	Read-write	Shows what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxFwdFilterSocket brcdIp.1.2.1.5.1.1.3 Syntax: Integer	Read-write	Indicates the IPX forward filter socket number.

Name, OID, and syntax	Access	Description
snIpxFwdFilterSrcNet brcdIp.1.2.1.5.1.1.4 Syntax: NetNumber	Read-write	Indicates the source network number.
snIpxFwdFilterSrcNode brcdIp.1.2.1.5.1.1.5 Syntax: Physical address	Read-write	Indicates the source node number.
snIpxFwdFilterDestNet brcdIp.1.2.1.5.1.1.6 Syntax: NetNumber	Read-write	Indicates the destination network number.
snIpxFwdFilterDestNode brcdIp.1.2.1.5.1.1.7 Syntax: Physical address	Read-write	Indicates the destination node number.
snIpxFwdFilterRowStatus brcdIp.1.2.1.5.1.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX RIP filter table

The following table allows you to define filters that a router uses to block RIP routes being advertised to other parts of the network.

Name, OID, and syntax	Access	Description
snIpxRipFilterTable brcdIp.1.2.1.6.1	None	The IPX RIP filter table.
snIpxRipFilterId brcdIp.1.2.1.6.1.1.1 Syntax: Integer	Read-only	The ID for an entry.
snIpxRipFilterAction brcdIp.1.2.1.6.1.1.2 Syntax: Integer	Read-write	Shows what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxRipFilterNet brcdIp.1.2.1.6.1.1.3 Syntax: NetNumber	Read-write	Indicates the IPX RIP filter network number.



Name, OID, and syntax	Access	Description
snIpxRipFilterMask brcdIp.1.2.1.6.1.1.4 Syntax: NetNumber	Read-write	Indicates the IPX RIP filter network or subnet mask.
snIpxRipFilterRowStatus brcdIp.1.2.1.6.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX SAP filter table

The following table is used to define filters that a router uses to block SAP routes being advertised to other parts of the network.

Name, OID, and syntax	Access	Description
snIpxSapFilterTable brcdIp.1.2.1.7.1	None	The IPX SAP filter table.
snIpxSapFilterId brcdIp.1.2.1.7.1.1.1 Syntax: Integer	Read-only	The filter ID for a filter entry.
snIpxSapFilterAction brcdIp.1.2.1.7.1.1.2 Syntax: Integer	Read-write	Determines what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxSapFilterType brcdIp.1.2.1.7.1.1.3 Syntax: Integer	Read-write	Identifies the IPX SAP filter type to be matched.
snIpxSapFilterName brcdIp.1.2.1.7.1.1.4 Syntax: OCTET STRING	Read-write	Identifies the IPX SAP filter name. Valid values: Up to 47 octets.
snIpxSapFilterRowStatus brcdIp.1.2.1.7.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX IF forward access table

The following table explains the MIB objects of the IPX interface forward access.

Name, OID, and syntax	Access	Description
snIpxIfFwdAccessTable brcdIp.1.2.1.8.1	None	The IPX Interface (IF) forward access table.
snIpxIfFwdAccessPort brcdIp.1.2.1.8.1.1.1 Syntax: Integer	Read-only	The IPX interface to which the forward filter applies.
snIpxIfFwdAccessDir brcdIp.1.2.1.8.1.1.2 Syntax: Integer	Read-only	Shows the direction of packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snIpxIfFwdAccessFilterList brcdIp.1.2.1.8.1.1.3 Syntax: OCTET STRING	Read-write	An IPX IF forward filter list. There can be up to 32 octets in this object.
snIpxIfFwdAccessRowStatus brcdIp.1.2.1.8.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX IF RIP access table

The following table explains the MIB objects of the IPX IF RIP access.

Name, OID, and syntax	Access	Description
snIpxIfRipAccessTable brcdIp.1.2.1.9.1	None	The IPX IF RIP access table.
snIpxIfRipAccessPort brcdIp.1.2.1.9.1.1.1	Read-only	The IPX interface to which the RIP filter applies.
snIpxIfRipAccessDir brcdIp.1.2.1.9.1.1.2	Read-only	Shows the direction of the packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>

Name, OID, and syntax	Access	Description
snIpxIfRipAccessFilterList brcdIp.1.2.1.9.1.1.3	Read-write	An IPX IF RIP access filter list.
snIpxIfRipAccessRowStatus brcdIp.1.2.1.9.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX IF SAP access table

The following table explains the MIB objects of the IPX IF SAP access.

Name, OID, and syntax	Access	Description
snIpxIfSapAccessTable brcdIp.1.2.1.10.1	None	The IPX IF SAP access table
snIpxIfSapAccessPort brcdIp.1.2.1.10.1.1.1 Syntax: Integer	Read-only	The IPX interface to which the SAP filter applies.
snIpxIfSapAccessDir brcdIp.1.2.1.10.1.1.2 Syntax: Integer	Read-only	Shows the direction of the packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snIpxIfSapAccessFilterList brcdIp.1.2.1.10.1.1.3 Syntax: OCTET STRING	Read-write	An IPX IF SAP access filter list. There can be up to 32 octets in this object.
snIpxIfSapAccessRowStatus brcdIp.1.2.1.10.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IPX port address table

The following table explains the MIB objects of the IPX port address.

Name, OID, and syntax	Access	Description
snIpxPortAddrTable brcdIp.1.2.1.11.1	None	The IPX port address table.
snIpxPortAddrPort brcdIp.1.2.1.11.1.1.1 Syntax: PortIndex	Read-only	The port index for port address entry.
snIpxPortAddrEncap brcdIp.1.2.1.11.1.1.2 Syntax: Integer	Read-only	Shows the IPX frame encapsulation type: <ul style="list-style-type: none"> <li>Ethernet8022(1)</li> <li>Ethernet8023(2)</li> <li>EthernetII(3)</li> <li>EthernetSnap(4)</li> </ul> Each network number must be assigned a unique frame type; otherwise, an SNMP-SET error is returned.
snIpxPortAddrNetNum brcdIp.1.2.1.11.1.1.3 Syntax: NetNumber	Read-write	A unique network number for the IPX interface port.
snIpxPortAddrRowStatus brcdIp.1.2.1.11.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Delete the row.</li> <li>create(4) – Create a new row.</li> <li>modify(5) – Modify an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snIpxPortAddrNetBiosFilterMode brcdIp.1.2.1.11.1.1.5 Syntax: Integer	Read-write	Shows the status of the NetBios filter mode for each port address: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## IPX port counters table

The following table explains the MIB objects of the IPX port counters.

Name, OID, and syntax	Access	Description
snIpxPortCountersTable brcdIp.1.2.1.12.1	None	The IPX port counters table.
snIpxPortCountersPort brcdIp.1.2.1.12.1.1.1 Syntax: PortIndex	Read-only	The port index for an entry in the table.
snIpxPortCountersRcvPktsCnt brcdIp.1.2.1.12.1.1.2 Syntax: Counter	Read-only	The IPX incoming packets counter for the interface.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snIpxPortCountersTxPkts Cnt brcdIp.1.2.1.12.1.1.3 Syntax: Counter	Read-only	The IPX outgoing packets counter for the interface.
snIpxPortCountersFwdPkts Cnt brcdIp.1.2.1.12.1.1.4 Syntax: Counter	Read-only	The IPX forwarding packets counter for the interface.
snIpxPortCountersRcvDrop PktsCnt brcdIp.1.2.1.12.1.1.5 Syntax: Counter	Read-only	The IPX receiving drop packets counter for the interface.
snIpxPortCountersTxDrop PktsCnt brcdIp.1.2.1.12.1.1.6 Syntax: Counter	Read-only	The IPX transmitting drop packets counter for the interface.
snIpxPortCountersRcvFilter PktsCnt brcdIp.1.2.1.12.1.1.7 Syntax: Counter	Read-only	The IPX receiving filter packets counter for the interface.
snIpxPortCountersTxFilter PktsCnt brcdIp.1.2.1.12.1.1.8 Syntax: Counter	Read-only	The IPX transmitting filter packets counter for the interface.



# BGP4 MIB Definition

---

## In this chapter

• BGP4 general variables. . . . .	437
• BGP4 address filter table . . . . .	447
• BGP4 aggregate address table. . . . .	448
• BGP4 AS-Path filter table . . . . .	449
• BGP4 community filter table. . . . .	450
• BGP4 neighbor general configuration table . . . . .	451
• BGP4 neighbor distribute group table . . . . .	454
• BGP4 neighbor filter group table . . . . .	456
• BGP4 neighbor route map table. . . . .	457
• BGP4 network table. . . . .	458
• BGP4 redistribution of routes table . . . . .	459
• BGP4 route map filter table . . . . .	460
• BGP4 route map match table. . . . .	461
• BGP4 neighbor operational status table . . . . .	465
• BGP4 router operational status table . . . . .	467
• BGP4 neighbor summary table . . . . .	469
• BGP4 attribute entries table. . . . .	470
• BGP4 clear neighbor command table . . . . .	471
• BGP4 neighbor prefix group table . . . . .	472

## BGP4 general variables

The BGP4 implementation complies with RFC 4273. The BGP4 implementation also supports the following RFCs:

- RFC 1745 (OSPF Interactions)
- RFC 1965 (BGP4 Confederations)
- RFC 1997 (BGP Communities Attributes)
- RFC 2385 (TCP MD5 Signature Option)
- RFC 2439 (Route Flap Dampening)
- RFC 2796 (Route Reflection)
- RFC 2842 (Capability Advertisement)

The BGP4 objects apply globally to a device's BGP4 process.

Name, OID, and syntax	Access	Description
snBgp4GenAlwaysCompareMed brcdIp.1.2.11.1.1 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, and Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if the comparison of the Multi-Exit Discriminator (MED) for paths from neighbors in different autonomous systems is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenAutoSummary brcdIp.1.2.11.1.2 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if subnet routes are automatically summarized: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenDefaultLocalPreference brcdIp.1.2.11.1.3 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Sets the default local preference attribute. When the router uses the BGP4 algorithm to select a route to send to the IP route table, one of the parameters the algorithm uses is the local preference. Local preference is an attribute that indicates a degree of preference for a route relative to other routes. BGP4 neighbors can send the local preference value as an attribute of a route in an Update message. Local preference applies only to routes within the local autonomous system (AS). BGP4 routers can exchange local preference information with neighbors who are also in the local AS; however, BGP4 routers do not exchange local preference information with neighbors in remote autonomous systems. Valid values: 0 – 4294967295 Default: 100
snBgp4GenDefaultInfoOriginate brcdIp.1.2.11.1.4 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if the default Information Originate is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> By default, the router does not originate and advertise a default route using BGP4. A BGP4 default route is the IP address 0.0.0.0 and the route prefix 0 or network mask 0.0.0.0. For example, 0.0.0.0/0 is a default route. Layer 3 switches check for the existence of an IGP route with 0.0.0.0/0 in the IP route table before creating a local BGP route for 0.0.0.0/0.
snBgp4GenFastExternalFallover brcdIp.1.2.11.1.5 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates whether or not automatic resetting of BGP sessions of any directly adjacent sessions is enabled, if the links used to reach them go down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>



Name, OID, and syntax	Access	Description
snBgp4GenNextBootNeighbors brcdIp.1.2.11.1.6 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	The next boot-configured number of neighbors in a BGP peer group. The minimum value of this object is the value of the "snBgp4GenMinNeighbors" object. Its maximum value is the value of the "snBgp4GenMaxNeighbors" object.
snBgp4GenNextBootRoutes brcdIp.1.2.11.1.7 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	The next boot-configured number of routes. The minimum value of this MIB is "snBgp4GenMinRoutes". The maximum value of this MIB is "snBgp4GenMaxRoutes".
snBgp4GenSynchronization brcdIp.1.2.11.1.8 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Enables or disables the synchronization between BGP and your IGP: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snBgp4GenKeepAliveTime brcdIp.1.2.11.1.9 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates how often the device sends keepalive messages. Valid values: 1 – 65535 seconds Default: 60 seconds
snBgp4GenHoldTime brcdIp.1.2.11.1.10 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Determines how many seconds the device will wait for a keepalive or update message from a BGP4 neighbor before deciding that the neighbor is dead. Valid values: 1 – 65535 seconds Default: 180 seconds

Name, OID, and syntax	Access	Description
snBgp4GenRouterId brcdIp.1.2.11.1.11 Syntax: IpAddress <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates the BGP router IP address.
snBgp4GenTableMap brcdIp.1.2.11.1.12 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Defines the route map name. Each character of the name is represented by one octet. Valid values: Up to 32 octets.
snBgp4GenAdminStat brcdIp.1.2.11.1.13 Syntax: Integer	Read-write	Indicates if BGP4 routing is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snBgp4GenDefaultMetric brcdIp.1.2.11.1.14 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates the default metric values for the BGP4. The Layer 3 switches can redistribute directly connected routes, static IP routes, RIP routes, and OSPF routes into BGP4. The MED (metric) is a global parameter that specifies the cost that will be applied to all routes by default when they are redistributed into BGP4. Valid values: 0 – 4294967295
snBgp4GenMaxNeighbors brcdIp.1.2.11.1.15 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of neighbors that can be configured in a BGP peer group.
snBgp4GenMinNeighbors brcdIp.1.2.11.1.16 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the minimum number of neighbors that can be configured in a BGP peer group.

Name, OID, and syntax	Access	Description
snBgp4GenMaxRoutes brcdIp.1.2.11.1.17 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured routes.
snBgp4GenMinRoutes brcdIp.1.2.11.1.18 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the minimum number of configured routes.
snBgp4GenMaxAddrFilters brcdIp.1.2.11.1.19 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 address filters.
snBgp4GenMaxAggregateAddresses brcdIp.1.2.11.1.20 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 aggregate addresses.
snBgp4GenMaxAsPathFilters brcdIp.1.2.11.1.21 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 AS-Path filters.

Name, OID, and syntax	Access	Description
snBgp4GenMaxCommunityFilters brcdIp.1.2.11.1.22 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 community filters.
snBgp4GenMaxNetworks brcdIp.1.2.11.1.23 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 networks.
snBgp4GenMaxRouteMapFilters brcdIp.1.2.11.1.24 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the maximum number of configured BGP4 route map filters.
snBgp4GenNeighPrefixMinValue brcdIp.1.2.11.1.25 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the minimum configured value of the BGP4 neighbor prefix.
snBgp4GenOperNeighbors brcdIp.1.2.11.1.26 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the current operational maximum number of neighbors configured for a BGP group.

Name, OID, and syntax	Access	Description
snBgp4GenOperRoutes brcdIp.1.2.11.1.27 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the current operational number of routes.
snBgp4GenLocalAs brcdIp.1.2.11.1.28 Syntax: Integer	Read-only	Shows the BGP4 local AS number. Valid values: 1 - 65536
snBgp4GenRoutesInstalled brcdIp.1.2.11.1.29 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the BGP4 installed routes.
snBgp4GenAsPathInstalled brcdIp.1.2.11.1.30 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the BGP4 installed AS-Path.
snBgp4ExternalDistance brcdIp.1.2.11.1.31 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Determines the administrative distance for BGP external routes. Default: 200
snBgp4InternalDistance brcdIp.1.2.11.1.32 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Determines the administrative distance for BGP internal routes. Default: 200

Name, OID, and syntax	Access	Description
snBgp4LocalDistance brcdIp.1.2.11.1.33 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Determines the administrative distance for BGP local routes. Default: 200
snBgp4OperNumOfAttributes brcdIp.1.2.11.1.34 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the operational number of attribute entries.
snBgp4NextBootMaxAttributes brcdIp.1.2.11.1.35 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Defines the next boot maximum attribute entries. Default: 10000 (which means to reset to the default)
snBgp4ClusterId brcdIp.1.2.11.1.36 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Defines a cluster ID which is represented by 4-unsigned-byte integers (0..0xFFFFFFFF). 0 means to reset to the default.
snBgp4ClientToClientReflection brcdIp.1.2.11.1.37 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if the client-to-client reflection in BGP4 is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4GenTotalNeighbors brcdIp.1.2.11.1.38 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the current total number of neighbors running in a BGP group.
snBgp4GenMaxPaths brcdIp.1.2.11.1.39 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates the maximum number of configured paths.
snBgp4GenConfedId brcdIp.1.2.11.1.40 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Determines the BGP4 confederation ID. This ID identifies the confederation to BGP routers outside the confederation. A confederation is a BGP4 AS that has been subdivided into multiple, smaller autonomous systems. Subdividing an AS into smaller autonomous systems simplifies administration and reduces BGP-related traffic, thus reducing the complexity of the Interior Border Gateway Protocol (IBGP) mesh among the BGP routers in the AS. The confederation ID is the AS ID.
snBgp4GenConfedPeers brcdIp.1.2.11.1.41 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the sub-AS numbers that are members of the confederation. There is a maximum of 50 peers. This is a number from 1 to 0xFFFF. It is represented by two octets.
snBgp4GenDampening brcdIp.1.2.11.1.42 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the dampening of BGP4 in the device: <ul style="list-style-type: none"> <li>• none(0) – BGP4 dampening is off.</li> <li>• parameters(1) – Parameters are configurable.</li> <li>• routemap(2) – The route map is configurable.</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4GenDampenHalfLife brcdIp.1.2.11.1.43 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the number of minutes after which the route's penalty becomes half its value.
snBgp4GenDampenReuse brcdIp.1.2.11.1.44 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies how low a route's penalty must be before the route becomes eligible for use again after being suppressed.
snBgp4GenDampenSuppress brcdIp.1.2.11.1.45 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies how high a route's penalty can be before the Layer 3 switch suppresses the route.
snBgp4GenDampenMaxSuppress brcdIp.1.2.11.1.46 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the maximum number of minutes that a route can be suppressed regardless of how unstable it is.
snBgp4GenDampenMap brcdIp.1.2.11.1.47 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the name of the route map that will be used to redirect traffic. The name is an octet string. Each character is represented by one octet. Valid values: Up to 32 octets.
snBgp4GenLocalAs4 brcdIp.1.2.11.1.48 Syntax: InetAutonomousSystemNumber	Read-write	The BGP4 local AS number to support 4-byte AS format.



Name, OID, and syntax	Access	Description
snBgp4GenDefaultMetric1 brcdIp.1.2.11.1.49 Syntax: Unsigned32	Read-write	Specifies to set the default metric values for the BGP4 protocol.
snBgp4GenDefaultLocalPreference1 brcdIp.1.2.11.1.50 Syntax: Unsigned32	Read-write	Specifies to set the default local preference attribute.

## BGP4 address filter table

You can configure the router to explicitly permit or deny specific IP addresses received in updates from BGP4 neighbors by defining IP address filters. The router permits all IP addresses by default. You can define up to 100 IP address filters for BGP4:

- If you want **permit** to remain the default behavior, define individual filters to deny specific IP addresses.
- If you want to change the default behavior to **deny**, define individual filters to permit specific IP addresses.

### NOTE

Once you define a filter, the default action for addresses that do not match a filter is **deny**. To change the default action to **permit**, configure the last filter as **permitanyany**.

Address filters can be referred to by a BGP neighbor's distribute list number as well as by match statements in a route map.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4AddrFilterTable brcdIp.1.2.11.2.1	None	The BGP4 address filter table.
snBgp4AddrFilterIndex brcdIp.1.2.11.2.1.1.1 Syntax: Integer32	Read-only	The table index for a filter entry.
snBgp4AddrFilterAction brcdIp.1.2.11.2.1.1.2 Syntax: Integer	Read-write	Indicates what the device will do if the BGP address matches this filter: <ul style="list-style-type: none"> <li>• deny(0)</li> <li>• permit(1)</li> </ul>
snBgp4AddrFilterSourceIp brcdIp.1.2.11.2.1.1.3 Syntax: IpAddress	Read-write	Specifies the source IP address.
snBgp4AddrFilterSourceMask brcdIp.1.2.11.2.1.1.4 Syntax: IpAddress	Read-write	Specifies the source IP subnet mask.

Name, OID, and syntax	Access	Description
snBgp4AddrFilterDestIp brcdIp.1.2.11.2.1.1.5 Syntax: IpAddress	Read-write	Specifies the destination IP address.
snBgp4AddrFilterDestMask brcdIp.1.2.11.2.1.1.6 Syntax: IpAddress	Read-write	Specifies the destination IP subnet mask.
snBgp4AddrFilterRowStatus brcdIp.1.2.11.2.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 aggregate address table

By default, the Layer 3 switch advertises individual routes for all the networks. The aggregation feature allows you to configure the Layer 3 switch to aggregate routes in a range of networks into a single Classless Inter-Domain Routing (CIDR) number.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4AggregateAddrTable brcdIp.1.2.11.3.1	None	The BGP4 aggregate address table.
snBgp4AggregateAddrIp brcdIp.1.2.11.3.1.1.1 Syntax: IpAddress	Read-only	Shows the aggregate address IP address. Specify 0 for the host portion and for the network portion that differs among the networks in the aggregate. For example, to aggregate 10.0.1.0, 10.0.2.0, and 10.0.3.0, enter the IP address 10.0.0.0 and the network mask 255.255.0.0 in the next object.
snBgp4AggregateAddrMask brcdIp.1.2.11.3.1.1.2 Syntax: IpAddress	Read-only	Shows the aggregate address IP subnet mask.

Name, OID, and syntax	Access	Description
snBgp4AggregateAddrOption brcdIp.1.2.11.3.1.1.3 Syntax: Integer	Read-only	Specifies the type of aggregate address option that is being used: <ul style="list-style-type: none"> <li>address(1) – Adds an address. This is the default option.</li> <li>asSet(2) – Causes the router to aggregate AS-Path information for all the routes in the aggregate address into a single AS-Path.</li> <li>summaryOnly(3) – Prevents the router from advertising more specific routes contained within the aggregate route.</li> <li>suppressMap(4) – Prevents the more specific routes contained in the specified route map from being advertised.</li> <li>advertiseMap(5) – Configures the router to advertise the more specific routes in the specified route map.</li> <li>attributeMap(6) – Configures the router to set attributes for the aggregate routes based on the specified route map.</li> </ul>
snBgp4AggregateAddrMap brcdIp.1.2.11.3.1.1.4 Syntax: OCTET STRING	Read-write	Specifies the name of the route map to be used if the “snBgp4AggregateAddrOption” object is set to suppressMap(4), advertiseMap(5), or attributeMap(6). The value of this object is an octet string. Each character in the address map name is represented by one octet. There can be up to 32 octets in this object.
snBgp4AggregateAddrRowStatus brcdIp.1.2.11.3.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 AS-Path filter table

A list of the other autonomous systems through which a route passes. BGP4 routers can use the AS-Path to detect and eliminate routing loops.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4AsPathFilterTable brcdIp.1.2.11.4.1	None	The BGP4 AS-Path filter table.
snBgp4AsPathFilterIndex brcdIp.1.2.11.4.1.1.1 Syntax: Integer32	Read-only	The table index for a filter entry.
snBgp4AsPathFilterAction brcdIp.1.2.11.4.1.1.2 Syntax: Integer	Read-write	Specifies what the device will do if the BGP address matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snBgp4AsPathFilterRegExpression brcdIp.1.2.11.4.1.1.3 Syntax: OCTET STRING	Read-write	Shows the AS in the filter that is using a regular expression. Each character of the regular expression string is represented by one octet. Valid values: Up to 256 octets
snBgp4AsPathFilterRowStatus brcdIp.1.2.11.4.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 community filter table

You can filter routes received from BGP4 neighbors based on community names.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4CommunityFilterTable brcdIp.1.2.11.5.1	None	The BGP4 community filter table.
snBgp4CommunityFilterIndex brcdIp.1.2.11.5.1.1.1 Syntax: Integer32	Read-only	The table index for a filter entry.
snBgp4CommunityFilterAction brcdIp.1.2.11.5.1.1.2 Syntax: Integer	Read-write	Specifies what the device will do if the BGP address matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4CommunityFilterCommNum brcdIp.1.2.11.5.1.1.3 Syntax: OCTET STRING	Read-write	Identifies the filter's number. This is a number from 1 through 0xFFFFFFFF. There can be up to 20 filters. Each integer is represented by four octets.
snBgp4CommunityFilterInternet brcdIp.1.2.11.5.1.1.4 Syntax: Integer	Read-write	Indicates if Internet Community is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4CommunityFilterNoAdvertise brcdIp.1.2.11.5.1.1.5 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "NO_ADVERTISE". If the route has the keyword, it will not be advertised to EBGp peers: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snBgp4CommunityFilterNoExport brcdIp.1.2.11.5.1.1.6 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "NO_EXPORT". If the route has the keyword, it will not be advertised to EBGp peers outside the local AS: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snBgp4CommunityFilterRowStatus brcdIp.1.2.11.5.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snBgp4CommunityFilterLocalAs brcdIp.1.2.11.5.1.1.8 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "LOCAL_AS". If the route has the keyword, the community applies only to confederations. The device will advertise the route only within the sub-AS: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>

## BGP4 neighbor general configuration table

BGP4 does not contain a peer discovery process. You must indicate the neighbor's IP address for each of the router's BGP4 neighbors (peers), as well as the AS each neighbor is in. Neighbors that are in different autonomous systems communicate using EBGp. Neighbors within the same AS communicate using IBGP.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighGenCfgTable brcdIp.1.2.11.6.1	None	The BGP4 neighborhood general configuration table.
snBgp4NeighGenCfgNeighIp brcdIp.1.2.11.6.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address for a neighbor entry.
snBgp4NeighGenCfgAdvertlevel brcdIp.1.2.11.6.1.1.2 Syntax: Integer	Read-write	Specifies the minimum delay (in seconds) between messages to the specified neighbor. Valid values: 0 – 600 Defaults: <ul style="list-style-type: none"> <li>• 30 for EBGP neighbors (neighbors in other autonomous systems)</li> <li>• 5 for IBGP neighbors (neighbors in the same AS).</li> </ul>
snBgp4NeighGenCfgDefOriginate brcdIp.1.2.11.6.1.1.3 Syntax: Integer	Read-write	Indicates if the default originate for this neighbor is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> If enabled, the device sends the default route 0.0.0.0 to the neighbor.
snBgp4NeighGenCfgEbgpMultihop brcdIp.1.2.11.6.1.1.4 Syntax: Integer	Read-write	Indicates if the EBGP multihop for this neighbor is enabled. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> If enabled, the neighbor is more than one hop away and that the session type with the neighbor is thus EBGP multihop. Default: disabled(0)
snBgp4NeighGenCfgMaxPrefix brcdIp.1.2.11.6.1.1.5 Syntax: Integer32	Read-write	Specifies the maximum number of IP network prefixes (routes) that can be learned from the specified neighbor or peer group. You can specify a value from 0 through 4294967295. Default: 0 (unlimited) The minimum value of the maximum prefix is defined by the “snBgp4GenNeighPrefixMinValue” object. The maximum value of the maximum prefix is defined by the “snBgp4GenOperRoutes” object.
snBgp4NeighGenCfgNextHopSelf brcdIp.1.2.11.6.1.1.6 Syntax: Integer	Read-write	Indicates if the option that allows the router to list itself as the next hop in the updates sent to the specified neighbor is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snBgp4NeighGenCfgRemoteAs brcdIp.1.2.11.6.1.1.7 Syntax: Integer	Read-write	Specifies the AS that the remote neighbor is in. Valid values: 1 – 65535 Default: No default
snBgp4NeighGenCfgSendComm brcdIp.1.2.11.6.1.1.8 Syntax: Integer	Read-write	Indicates if the option to send community attributes in updates to specified neighbors is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)

Name, OID, and syntax	Access	Description
snBgp4NeighGenCfgWeight brcdIp.1.2.11.6.1.1.9 Syntax: Integer	Read-write	Assigns a weight to a neighbor connection. BGP4 prefers larger weights over smaller weights. Valid values: 0 – 65535 Default: 0
snBgp4NeighGenCfgWeightFilterList brcdIp.1.2.11.6.1.1.10 Syntax: OCTET STRING	Read-write	Specifies a weight that the device applies to routes received from the neighbor that match the AS-Path filter or ACL. Valid values: 1 – 0xFFFF. Each integer is represented by two octets.
snBgp4NeighGenCfgRowStatus brcdIp.1.2.11.6.1.1.11 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>
snBgp4NeighGenCfgUpdateSrcLpbrIntf brcdIp.1.2.11.6.1.1.12 Syntax: Integer	Read-write	Specifies the loopback interface number for TCP connections. Valid values: 0 – 8 Generally, loopback interfaces are used for links to IBGP neighbors, which often are multiple hops away, rather than to EBGP neighbors. Zero interface means to restore the interface assignment to the closest interface, which is called the best local address.
snBgp4NeighGenCfgRouteRefClient brcdIp.1.2.11.6.1.1.13 Syntax: Integer	Read-write	Indicates if the option to allow this neighbor to be a router reflector client is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snBgp4NeighGenCfgRemovePrivateAS brcdIp.1.2.11.6.1.1.14 Syntax: Integer	Read-write	Specifies if the option to remove private AS numbers from update messages that routers sent to this neighbor is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> If enabled, the router will remove AS numbers 64512 – 65535 (the well-known BGP4 private AS numbers) from the AS-Path attribute in UPDATE messages the device sends to the neighbor. Default: disabled(0)
snBgp4NeighGenCfgEbgpMultihopTtl brcdIp.1.2.11.6.1.1.15 Syntax: Integer	Read-write	Specifies the time-to-live (TTL) for the neighbor. Valid values: 0 – 255. Default: 0. If you leave the EBGP TTL value set to 0, the software uses the IP TTL value.

Name, OID, and syntax	Access	Description
snBgp4NeighGenCfgShutdown brcdIp.1.2.11.6.1.1.16 Syntax: Integer	Read-write	Indicates if BGP4 neighbor shutdown is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> If enabled, the device shuts down the session with this neighbor. Shutting down the session allows you to completely configure the neighbor and save the configuration without actually establishing a session with the neighbor. Default: disabled(0)
snBgp4NeighGenCfgKeepAliveTime brcdIp.1.2.11.6.1.1.17 Syntax: Integer	Read-write	Indicates how often the device sends keep alive messages. This object overrides the global settings for the Keepalive Time. Valid values: 0 – 65535 seconds
snBgp4NeighGenCfgHoldTime brcdIp.1.2.11.6.1.1.18 Syntax: Integer	Read-write	Determines how many seconds the device will wait for a keepalive or update message from a BGP4 neighbor before deciding that the neighbor is dead. This object overrides the global settings for Hold Time. Valid values: 0 or 3 – 65535 seconds (1 and 2 seconds are not allowed). If you set the Hold Time to 0, the router waits indefinitely for messages from a neighbor.
snBgp4NeighGenCfgDefOrigMap brcdIp.1.2.11.6.1.1.19 Syntax: OCTET STRING	Read-write	Indicates the name of the default route map. This is an octet string. Each character is represented by one octet. Valid values: Up to 32 octets
snBgp4NeighGenCfgDesc brcdIp.1.2.11.6.1.1.20 Syntax: OCTET STRING	Read-write	Specifies the name for the neighbor. Valid values: Up to 80 octets
snBgp4NeighGenCfgPass brcdIp.1.2.11.6.1.1.21 Syntax: OCTET STRING	Read-write	Specifies an MD5 password for securing sessions between the device and its neighbor. Valid values: Up to 80 octets

## BGP4 neighbor distribute group table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighDistGroupTable brcdIp.1.2.11.7.1	None	The BGP4 neighbor distribute group table.
snBgp4NeighDistGroupNeighIp brcdIp.1.2.11.7.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address for this entry.



Name, OID, and syntax	Access	Description
snBgp4NeighDistGroupDir brcdIp.1.2.11.7.1.1.2 Syntax: Integer	Read-only	Indicates if the access list is applied to incoming or outgoing advertisements: <ul style="list-style-type: none"> <li>• out(0)</li> <li>• in(1)</li> </ul>
snBgp4NeighDistGroupAccessList brcdIp.1.2.11.7.1.1.3 Syntax: OCTET STRING	Read-write	Indicates the access list that will be applied to advertisements. This is a number from 1 through 0xFFFF. Each integer is represented by two octets.
snBgp4NeighDistGroupRowStatus brcdIp.1.2.11.7.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>
snBgp4NeighDistGroupInFilterList brcdIp.1.2.11.7.1.1.5 Syntax: OCTET STRING	Read-write	Indicates the group filter list that will be applied to incoming advertisements. This is number from 1 through 0xFFFF. The incoming and outgoing list can have a mximum of 16 entries each. Each integer is represented by two octets.
snBgp4NeighDistGroupOutFilterList brcdIp.1.2.11.7.1.1.6 Syntax: OCTET STRING	Read-write	Indicates the group filter list that will be applied to outgoing advertisements. This is number from 1 through 0xFFFF. The incoming and outgoing list can have a mximum of 16 entries each. Each integer is represented by two octets.
snBgp4NeighDistGroupInIpAccessList brcdIp.1.2.11.7.1.1.7 Syntax: OCTET STRING	Read-write	Indicates the access list that will be applied to incoming advertisements. This is number from 1 through 0xFFFF. The incoming and outgoing list can have a mximum of 16 entries each. Each integer is represented by two octets.
snBgp4NeighDistGroupOutIpAccessList brcdIp.1.2.11.7.1.1.8 Syntax: OCTET STRING	Read-write	Indicates the access list that will be applied to outgoing advertisements. This is number from 1 through 0xFFFF. The incoming and outgoing list can have a mximum of 16 entries each. Each integer is represented by two octets.
snBgp4NeighDistGroupInPrefixList brcdIp.1.2.11.7.1.1.9 Syntax: OCTET STRING	Read-write	Specifies the prefix name list of incoming advertisements. Valid values: Up to 32 octets
snBgp4NeighDistGroupOutPrefixList brcdIp.1.2.11.7.1.1.10 Syntax: OCTET STRING	Read-write	Specifies the prefix name list of outgoing advertisements. Valid values: Up to 32 octets

## BGP4 neighbor filter group table

The BGP4 neighbor filter group table controls the routes that the device learns or advertises.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighFilterGroupTable brcdIp.1.2.11.8.1	None	The BGP4 neighbor filter group table.
snBgp4NeighFilterGroupNeighIp brcdIp.1.2.11.8.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address for a neighbor entry.
snBgp4NeighFilterGroupDir brcdIp.1.2.11.8.1.1.2 Syntax: Integer	Read-only	Shows the direction of advertisements to which the access list is applied: <ul style="list-style-type: none"> <li>out(0) – Outgoing</li> <li>in(1) – Incoming</li> </ul>
snBgp4NeighFilterGroupAccessList brcdIp.1.2.11.8.1.1.3 Syntax: OCTET STRING	Read-write	Identifies the access list that is being used to filter a neighbor group. This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.
snBgp4NeighFilterGroupRowStatus brcdIp.1.2.11.8.1.1.4 Syntax: IpAddress	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snBgp4NeighFilterGroupInFilterList brcdIp.1.2.11.8.1.1.5 Syntax: OCTET STRING	Read-write	Identifies the filter list that is being used to filter incoming routes from a neighbor group. This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.
snBgp4NeighFilterGroupOutFilterList brcdIp.1.2.11.8.1.1.6 Syntax: OCTET STRING	Read-write	Identifies the filter list that is being used to filter outgoing routes from a neighbor group. This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.
snBgp4NeighFilterGroupInAsPathAccessList brcdIp.1.2.11.8.1.1.7 Syntax: OCTET STRING	Read-write	Identifies the AS-Path list that is being used to filter incoming routes from a neighbor group. This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.

Name, OID, and syntax	Access	Description
snBgp4NeighFilterGroupOutAsPathAccessList brcdIp.1.2.11.8.1.1.8 Syntax: OCTET STRING	Read-write	Identifies the AS-Path list that is being used to filter outgoing routes from a neighbor group. This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.
snBgp4NeighFilterGroupWeight brcdIp.1.2.11.8.1.1.9 Syntax: Integer	Read-write	Assigns a weight to a neighbor filter. Valid values: 0 – 65535
snBgp4NeighFilterGroupWeightAccessList brcdIp.1.2.11.8.1.1.10 Syntax: OCTET STRING	Read-write	This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 16 entries each. This integer is represented by two octets.

## BGP4 neighbor route map table

A route map can be one of the parameters to be advertised by the BGP4 network. The Layer 3 switch can use the route map to set or change BGP4 attributes when creating a local BGP4 route.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighRouteMapTable brcdIp.1.2.11.9.1	None	The BGP4 neighbor route map table.
snBgp4NeighRouteMapNeighborIp brcdIp.1.2.11.9.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address for a neighbor entry.
snBgp4NeighRouteMapDir brcdIp.1.2.11.9.1.1.2 Syntax: Integer	Read-only	Indicates the direction of the advertisement to which the access list is applied: <ul style="list-style-type: none"> <li>• out(0)</li> <li>• in(1)</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4NeighRouteMapMapName brcdIp.1.2.11.9.1.1.3 Syntax: OCTET STRING	Read-write	Specifies the name of the route map you want to use. The value of this object is an octet string. Each character of the name is represented by one octet. There can be up to 32 octets in this object.
snBgp4NeighRouteMapRowStatus brcdIp.1.2.11.9.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 network table

The BGP4 network table shows the weight used for the network.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NetworkTable brcdIp.1.2.11.10.1	None	The BGP4 network table.
snBgp4NetworkIp brcdIp.1.2.11.10.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address for a network entry.
snBgp4NetworkSubnetMask brcdIp.1.2.11.10.1.1.2 Syntax: IpAddress	Read-only	Shows the subnet mask for a network entry.
snBgp4NetworkWeight brcdIp.1.2.11.10.1.1.3 Syntax: Integer	Read-write	Shows the weight of the neighbor connection. Valid values: 0 – 65535

Name, OID, and syntax	Access	Description
snBgp4NetworkBackdoor brcdIp.1.2.11.10.1.1.4 Syntax: Integer	Read-write	Indicates if the backdoor option is enabled for this network: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> The backdoor option changes the administrative distance of the route to this network from the EBGp administrative distance (20 by default) to the Local BGP weight (200 by default). The route is tagged as a backdoor route. Use this option when you want the router to prefer IGP routes such as RIP or OSPF routes over the EBGp route for the network.
snBgp4NetworkRowStatus brcdIp.1.2.11.10.1.1.5 Syntax: Integer		Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 redistribution of routes table

The BGP4 redistribution of routes table contains configurations that could be imported into the BGP4 domain. Each entry specifies a particular RIP, OSPF, or static route that will be imported into the BGP4 domain.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4RedisTable brcdIp.1.2.11.11.1	None	The BGP4 redistribution of routes table.
snBgp4RedisProtocol brcdIp.1.2.11.11.1.1.1 Syntax: Integer	Read-only	Shows the type of route that was imported into the BGP4 domain: <ul style="list-style-type: none"> <li>rip(1) – RIP</li> <li>ospf(2) – OSPF</li> <li>static(3) – Static</li> <li>connected(4) – Connected</li> <li>isis(5) – IS-IS</li> </ul>
snBgp4RedisMetric brcdIp.1.2.11.11.1.1.2 Syntax: Integer32	Read-write	Indicates the metric used.
snBgp4RedisRouteMap brcdIp.1.2.11.11.1.1.3 Syntax: OCTET STRING	Read-write	Indicates the name of the route map used. Each character is represented by one octet. Valid values: Up to 32 octets

Name, OID, and syntax	Access	Description
snBgp4RedisWeight brcdIp.1.2.11.11.1.1.4 Syntax: Integer	Read-write	Specifies the weight assigned to this entry.
snBgp4RedisMatchInternal brcdIp.1.2.11.11.1.1.5 Syntax: Integer	Read-write	Applies only to the OSPF protocol: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisMatchExternal1 brcdIp.1.2.11.11.1.1.6 Syntax: Integer	Read-write	Applies only to the OSPF protocol: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisMatchExternal2 brcdIp.1.2.11.11.1.1.7 Syntax: Integer	Read-write	Applies only to the OSPF protocol: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisRowStatus brcdIp.1.2.11.11.1.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 route map filter table

A route map is a named set of match conditions and parameter settings that a Layer 3 switch can use to modify route attributes and to control redistribution of routes.

BGP4 allows you to include the redistribution filters as part of a route map. A route map examines and modifies route information exchanged between BGP4 and RIP or OSPF.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4RouteMapFilterTable brcdIp.1.2.11.12.1	None	The BGP4 route map filter table.
snBgp4RouteMapFilterMapName brcdIp.1.2.11.12.1.1.1 Syntax: OCTET STRING	Read-only	Shows the route map's name. The value of this object contains an octet string. Each character is represented by one octet. There can be up to 32 octets in this object.
snBgp4RouteMapFilterSequenceNum brcdIp.1.2.11.12.1.1.2 Syntax: Integer32	Read-only	Shows the sequence number for this particular route map.

Name, OID, and syntax	Access	Description
snBgp4RouteMapFilterAction brcdIp.1.2.11.12.1.1.3 Syntax: Integer	Read-write	<p>Informs the device what to do if the BGP address matches this entry:</p> <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snBgp4RouteMapFilterRowStatus brcdIp.1.2.11.12.1.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## BGP4 route map match table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4RouteMapMatchTable brcdIp.1.2.11.13.1	None	The BGP4 route map match table.
snBgp4RouteMapMatchMapName brcdIp.1.2.11.13.1.1.1 Syntax: OCTET STRING	Read-only	Shows the name of the route map to be matched. The value of this object is an octet string. Each character of the name is represented by one octet. There can be up to 32 octets in this object.
snBgp4RouteMapMatchSequenceNum brcdIp.1.2.11.13.1.1.2 Syntax: Integer32	Read-only	Shows the sequence number for this particular route map. Routes are matched to the route map in ascending numerical order. Matching stops once a match is found.
snBgp4RouteMapMatchAsPathFilter brcdIp.1.2.11.13.1.1.3 Syntax: OCTET STRING	Read-write	<p>Identifies the AS-Path list number that this route must match.</p> <p>This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 10 entries each. Each number consists of two octets.</p>
snBgp4RouteMapMatchCommunityFilter brcdIp.1.2.11.13.1.1.4 Syntax: OCTET STRING	Read-write	<p>Identifies the community filter number that this route must match.</p> <p>This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 10 entries each. Each number consists of two octets.</p>

Name, OID, and syntax	Access	Description
snBgp4RouteMapMatchAddressFilter brcdIp.1.2.11.13.1.1.5 Syntax: OCTET STRING	Read-write	Identifies the address filter number that this route must match.  This is a number from 1 through 0xFFFF. The incoming and outgoing list can have a maximum of 10 entries each. Each number consists of two octets. There can be a total of 20 octets in this object.
snBgp4RouteMapMatchMetric brcdIp.1.2.11.13.1.1.6 Syntax: Integer32	Read-write	Compares the route's MED (metric) to this value. There can be up to 20 octets in this object.
snBgp4RouteMapMatchNextHopList brcdIp.1.2.11.13.1.1.7 Syntax: OCTET STRING	Read-write	Compares the IP address of the route's next hop to the IP address filters in this route.  This is a number from 1 - 0xFFFF, represented by two octets. The incoming and outgoing list can have a maximum of 16 entries each. There can be a total of 32 octets in this object.
snBgp4RouteMapMatchRouteType brcdIp.1.2.11.13.1.1.8 Syntax: Integer	Read-write	Determines the OSPF route type to match: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• external(1)</li> <li>• externalType1(2)</li> <li>• externalType2(3)</li> <li>• internal(4)</li> <li>• local(5)</li> </ul> Currently only externalType1(2), externalType2(3), and internal(4) are supported for SNMP-SET.
snBgp4RouteMapMatchTagList brcdIp.1.2.11.13.1.1.9 Syntax: OCTET STRING	Read-write	Identifies the community tag access list that this route must match.  This is a number represented by an octet strings. There can be up to 32 octets in this object.
snBgp4RouteMapMatchRowMask brcdIp.1.2.11.13.1.1.10 Syntax: Integer32	Read-write	This object is used together with the MIB objects above in the same VARBIND to set and reset any MIBs in the table. The bit number is referred to the snBgp4RouteMapMatchEntry number of each row in the table: <ul style="list-style-type: none"> <li>• The bit is ON - Means set</li> <li>• The bit is OFF - Means reset</li> </ul>
snBgp4RouteMapMatchAsPathAccessList brcdIp.1.2.11.13.1.1.11 Syntax: OCTET STRING	Read-write	Indicates which BGP AS-Path access list this route must match.  This is an integer from 1 through 0xFFFFFFFF, consisting of five sets of four octets.
snBgp4RouteMapMatchCommunityList brcdIp.1.2.11.13.1.1.12 Syntax: OCTET STRING	Read-write	Indicates which BGP community access list this route must match.  This is an integer from 1 through 0xFFFFFFFF, consisting of five sets of four octets.
snBgp4RouteMapMatchAddressAccessList brcdIp.1.2.11.13.1.1.13 Syntax: OCTET STRING	Read-write	Indicates which BGP address access list this route must match.  This is an integer from 1 through 0xFFFFFFFF, consisting of five sets of two octets.



Name, OID, and syntax	Access	Description
snBgp4RouteMapMatchAddressPrefixList brcdIp.1.2.11.13.1.1.14 Syntax: OCTET STRING	Read-write	Indicates the prefix list that must match a BGP address access list. Valid values: Up to 170 octets.
snBgp4RouteMapMatchNextHopAccessList brcdIp.1.2.11.13.1.1.15 Syntax: OCTET STRING	Read-write	Indicates the ID of the next-hop router that this route must match. This is an integer from 1 through 0xFFFFFFFF, consisting of five integers. Each integer has two octets.
snBgp4RouteMapMatchNextHopPrefixList brcdIp.1.2.11.13.1.1.16 Syntax: OCTET STRING	Read-write	Indicates the prefix list of the next-hop router that this route must match. Valid values: Up to 170 octets.

The BGP4 route map set table describes the route map set MIB objects.

#### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4RouteMapSetTable brcdIp.1.2.11.14.1	None	The BGP4 route map set table.
snBgp4RouteMapSetMapName brcdIp.1.2.11.14.1.1.1 Syntax: OCTET STRING	Read-only	An octet string of the route map name; each character of the name is represented by one octet.
snBgp4RouteMapSetSequenceNumber brcdIp.1.2.11.14.1.1.2 Syntax: Integer32	Read-only	A sequence number for this particular route map.
snBgp4RouteMapSetAsPathType brcdIp.1.2.11.14.1.1.3 Syntax: Integer	Read-write	Modifies an autonomous system path for BGP routes: <ul style="list-style-type: none"> <li>tag(0) - Converts the tag of a route into an autonomous system path.</li> <li>prepend(1) - Appends the string from snBgp4RouteMapSetAsPathString to the AS-Path of the route that is matched by the route map.</li> </ul>
snBgp4RouteMapSetAsPathString brcdIp.1.2.11.14.1.1.4 Syntax: OCTET STRING	Read-write	This AS-Path string is used only if snBgp4RouteMapSetAsPathCmd was sent together with the value set to prepend(1).
snBgp4RouteMapSetAutoTag brcdIp.1.2.11.14.1.1.5 Syntax: Integer	Read-write	Enables or disables the automatic tag for BGP routes.
snBgp4RouteMapSetCommunityType brcdIp.1.2.11.14.1.1.6 Syntax: Integer	Read-write	Sets the BGP communities attribute: <ul style="list-style-type: none"> <li>None - No other community attributes are allowed.</li> <li>Nums - Allows community attributes.</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4RouteMapSetCommunityNum brcdIp.1.2.11.14.1.1.7 Syntax: Integer	Read-write	This number is used only if snBgp4RouteMapSetCommunityCmd was sent together with the value set to number(0).
snBgp4RouteMapSetCommunityAdditive brcdIp.1.2.11.14.1.1.8 Syntax: Integer	Read-write	Adds the community to the existing communities.
snBgp4RouteMapSetLocalPreference brcdIp.1.2.11.14.1.1.9 Syntax: Integer	Read-write	Modifies a local preference for BGP routes.
snBgp4RouteMapSetMetric brcdIp.1.2.11.14.1.1.10 Syntax: Integer32	Read-write	Modifies a metric for BGP routes.
snBgp4RouteMapSetNextHop brcdIp.1.2.11.14.1.1.11 Syntax: IpAddress	Read-write	Modifies the IP address of the next hop for BGP routes.
snBgp4RouteMapSetOrigin brcdIp.1.2.11.14.1.1.12 Syntax: Integer	Read-write	Sets the BGP origin code.
snBgp4RouteMapSetTag brcdIp.1.2.11.14.1.1.13 Syntax: Integer	Read-write	Specifies the tag for BGP routes.
snBgp4RouteMapSetWeight brcdIp.1.2.11.14.1.1.14 Syntax: Integer	Read-write	Specifies the BGP weight for the routing table.
snBgp4RouteMapSetRowMask brcdIp.1.2.11.14.1.1.15 Syntax: Integer	Read-write	This object is used together with the MIBs in the same VARBIND to set and reset any MIBs in the table.
snBgp4RouteMapSetCommunityNums brcdIp.1.2.11.14.1.1.16 Syntax: OCTET STRING	Read-write	The community number is from 1 through 0xFFFFFFFF. The incoming and outgoing list can have a maximum of 6 entries each. This integer number is represented by four octets.
snBgp4RouteMapSetDampenHalfLife brcdIp.1.2.11.14.1.1.17 Syntax: Integer	Read-write	The BGP4 route map dampening half life.
snBgp4RouteMapSetDampenReuse brcdIp.1.2.11.14.1.1.18 Syntax: Integer	Read-write	The BGP4 route map dampening reuse.

Name, OID, and syntax	Access	Description
snBgp4RouteMapSetDampenSuppress brcdIp.1.2.11.14.1.1.19 Syntax: Integer	Read-write	The BGP4 route map dampening suppress.
snBgp4RouteMapSetDampenMaxSuppress brcdIp.1.2.11.14.1.1.20 Syntax: Integer	Read-write	The BGP4 route map dampening maximum suppress time.

## BGP4 neighbor operational status table

The BGP4 neighbor operational status table shows the state of a neighbor and statistics about the messages sent and received.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighOperStatusTable brcdIp.1.2.11.15.1	None	The BGP4 neighbor operational status table.
snBgp4NeighOperStatusIndex brcdIp.1.2.11.15.1.1.1 Syntax: Integer32	Read-only	The index for the entry. Each entry represents a neighbor.
snBgp4NeighOperStatusIp brcdIp.1.2.11.15.1.1.2 Syntax: IpAddress	Read-only	Shows the IP address of the neighbor.
snBgp4NeighOperStatusRemoteAs brcdIp.1.2.11.15.1.1.3 Syntax: Integer32	Read-only	Shows the AS that the neighbor is in.
snBgp4NeighOperStatusBgpType brcdIp.1.2.11.15.1.1.4 Syntax: Integer	Read-only	Shows the type of BGP used by this entry: <ul style="list-style-type: none"> <li>• ebgp(0) – The neighbor is in another AS.</li> <li>• ibgp(1) – The neighbor is in the same AS.</li> </ul>

Name, OID, and syntax	Access	Description
snBgp4NeighOperStatusState brcdIp.1.2.11.15.1.1.5 Syntax: Integer	Read-only	Shows the state of this neighbor: <ul style="list-style-type: none"> <li>noState(0)</li> <li>idle(1) – BGP4 process is waiting to be started. Usually, enabling BGP4 or establishing a neighbor session starts the BGP4 process. A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> <li>connect(2) – BGP4 is waiting for the connection process for the TCP neighbor session to be completed.</li> <li>active(3) – BGP4 is waiting for a TCP connection from the neighbor.</li> <li>openSent(4) – BGP4 is waiting for an OPEN message from the neighbor.</li> <li>openConfirm(5) – BGP4 has received an OPEN message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the router receives a KEEPALIVE message from the neighbor, the state changes to established(6). If the message is a NOTIFICATION, the state changes to idle(1).</li> <li>established(6) – BGP4 is ready to exchange UPDATE messages with the neighbor.</li> </ul> <p><b>NOTE:</b> If there is more BGP data in the TCP receiver queue, a plus sign (+) is also displayed.</p>
snBgp4NeighOperStatusKeepAlive Time brcdIp.1.2.11.15.1.1.6 Syntax: Integer	Read-only	Specifies how often this router sends keepalive messages to the neighbor.
snBgp4NeighOperStatusHoldTime brcdIp.1.2.11.15.1.1.7 Syntax: Integer32	Read-only	Specifies how many seconds the router will wait for a keepalive or update message from a BGP4 neighbor before deciding that the neighbor is dead.
snBgp4NeighOperStatusAdvertleve l brcdIp.1.2.11.15.1.1.8 Syntax: Integer32	Read-only	Shows the minimum interval between the sending of BGP routing updates.
snBgp4NeighOperStatusKeepAlive TxCounts brcdIp.1.2.11.15.1.1.9 Syntax: Integer32	Read-only	Shows the number of keepalive message sent.
snBgp4NeighOperStatusKeepAlive RxCounts brcdIp.1.2.11.15.1.1.10 Syntax: Counter32	Read-only	Shows the number of keepalive message received.
snBgp4NeighOperStatusUpdateTx Counts brcdIp.1.2.11.15.1.1.11 Syntax: Counter32	Read-only	Shows the number of updated messages sent.
snBgp4NeighOperStatusUpdateRx Counts brcdIp.1.2.11.15.1.1.12 Syntax: Counter32	Read-only	Shows the number of updated messages received.

Name, OID, and syntax	Access	Description
snBgp4NeighOperStatusNotifTxCounts brcdIp.1.2.11.15.1.1.13 Syntax: Counter32	Read-only	Shows the number of notification messages sent.
snBgp4NeighOperStatusNotifRxCounts brcdIp.1.2.11.15.1.1.14 Syntax: Counter32	Read-only	Shows the number of notification messages received.
snBgp4NeighOperStatusOpenTxCounts brcdIp.1.2.11.15.1.1.15 Syntax: Counter32	Read-only	Shows the number of open messages sent.
snBgp4NeighOperStatusOpenRxCounts brcdIp.1.2.11.15.1.1.16 Syntax: Counter32	Read-only	Shows the number of open messages received.

## BGP4 router operational status table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4RouteOperStatusTable brcdIp.1.2.11.16.1	None	The BGP4 router operational status table.
snBgp4RouteOperStatusIndex brcdIp.1.2.11.16.1.1.1 Syntax: Integer32	Read-only	The index for a route entry.
snBgp4RouteOperStatusIp brcdIp.1.2.11.16.1.1.2 Syntax: IpAddress	Read-only	Shows the IP address of the route.
snBgp4RouteOperStatusSubnetMask brcdIp.1.2.11.16.1.1.3 Syntax: IpAddress	Read-only	Shows the IP subnet mask of the route.
snBgp4RouteOperStatusNextHop brcdIp.1.2.11.16.1.1.4 Syntax: IpAddress	Read-only	Shows the IP address of the next hop in the route.
snBgp4RouteOperStatusMetric brcdIp.1.2.11.16.1.1.5 Syntax: Integer	Read-only	Shows the value of the route's MED attribute.

Name, OID, and syntax	Access	Description
snBgp4RouteOperStatusLocalPreference brcdIp.1.2.11.16.1.1.6 Syntax: Integer32	Read-only	Shows the degree of preference for this route relative to other routes in the local AS. When the BGP4 algorithm compares routes on the basis of local preferences, the route with the higher local preference is chosen. The preference can have a value from 0 through 4294967295.
snBgp4RouteOperStatusWeight brcdIp.1.2.11.16.1.1.7 Syntax: Integer32	Read-only	The value that this router associates with routes from a specific neighbor. For example, if the router receives routes to the same destination from two BGP4 neighbors, the router prefers the route from the neighbor with the larger weight.
snBgp4RouteOperStatusOrigin brcdIp.1.2.11.16.1.1.8 Syntax: Integer	Read-only	Shows the route's origin: <ul style="list-style-type: none"> <li>• igp(0) – Routes with this set of attributes came to BGP through IGP.</li> <li>• egp(1) – Routes with this set of attributes came to BGP through EGP.</li> <li>• incomplete(2) – Routes came from an origin other than IGP or EGP. For example, they may have been redistributed from OSPF or RIP.</li> </ul>
snBgp4RouteOperStatusStatus brcdIp.1.2.11.16.1.1.9 Syntax: Integer32	Read-only	Shows the route's status. The value of this object is a bit array, a packed bit string. The following shows the meaning of each bit. A bit position may be set to 0 – FALSE or 1 – TRUE: <p style="margin-left: 40px;">Bit position Meaning</p> <p style="margin-left: 40px;">6 – 31reserved</p> <p style="margin-left: 40px;">5 aggregate route for multiple networks</p> <p style="margin-left: 40px;">4 best route to destination</p> <p style="margin-left: 40px;">3 internal, learned through BGP4</p> <p style="margin-left: 40px;">2 local, originated on this device</p> <p style="margin-left: 40px;">1 suppressed, suppressed during aggregation and thus is not advertised to neighbors</p> <p style="margin-left: 40px;">0 valid</p>
snBgp4RouteOperStatusRouteTag brcdIp.1.2.11.16.1.1.10 Syntax: Integer32	Read-only	Sets the route's tag. This can be a value from 0 through 4294967295. This object applies only to routes redistributed into OSPF
snBgp4RouteOperStatusCommunityList brcdIp.1.2.11.16.1.1.11 Syntax: OCTET STRING	Read-only	Shows the communities the route is in. A community is represented by 4 octets. The community list, could have some well-known numbers such as: <ul style="list-style-type: none"> <li>• BGP_COMMUNITY_ATTRIBUTE_NO_EXPORT0xFFFFFFFF01</li> <li>• BGP_COMMUNITY_ATTRIBUTE_NO_ADVERTISE0xFFFFFFFF02</li> </ul> If the community list is a NULL string (empty list), then the community is INTERNET, which is represented by a number from 1 through 0xFFFFFFFF.
snBgp4RouteOperStatusAsPathList brcdIp.1.2.11.16.1.1.12 Syntax: OCTET STRING	Read-only	Shows the AS-Path list of this route. Valid values: 1 – 0xFFFF. This integer is represented by two octets.

## BGP4 neighbor summary table

The BGP4 neighbor summary table shows statistics for the router's BGP4 neighbors.

Name, OID, and syntax	Access	Description
snBgp4NeighborSummaryTable brcdIp.1.2.11.17.1	None	The BGP4 neighbor summary table.
snBgp4NeighborSummaryIndex brcdIp.1.2.11.17.1.1.1 Syntax: Integer32	Read-only	The index for a route entry.
snBgp4NeighborSummaryIp brcdIp.1.2.11.17.1.1.2 Syntax: IpAddress	Read-only	Shows the IP address of the neighbor.
snBgp4NeighborSummaryState brcdIp.1.2.11.17.1.1.3 Syntax: Integer	Read-only	Shows the state of the BGP4 process during the current session with the neighbor: <ul style="list-style-type: none"> <li>noState(0)</li> <li>idle(1) – The BGP4 process is waiting to be started. Usually, enabling BGP4 or establishing a neighbor session starts the BGP4 process. A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> <li>connect(2) – Waiting for the connection process for the TCP neighbor session to be completed.</li> <li>active(3) – BGP4 is waiting for a TCP connection from the neighbor.</li> <li>openSent(4) – BGP4 is waiting for an OPEN message from the neighbor.</li> <li>openConfirm(5) – BGP4 has received an OPEN message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the router receives a KEEPALIVE message from the neighbor, the state changes to established(6). If the message is a NOTIFICATION, the state changes to idle(1).</li> <li>established(6) – BGP4 is ready to exchange UPDATE messages with the neighbor.</li> </ul> <p><b>NOTE:</b> If there is more BGP data in the TCP receiver queue, a plus sign (+) is also displayed.</p>
snBgp4NeighborSummaryStateChgTime brcdIp.1.2.11.17.1.1.4 Syntax: Integer32	Read-only	Shows the number of times the state of this neighbor has changed. If the state frequently changes between CONNECT and ACTIVE, there may be a problem with the TCP connection.
snBgp4NeighborSummaryRoutesReceived brcdIp.1.2.11.17.1.1.5 Syntax: Integer32	Read-only	Shows the number of routes received from the neighbor during the current BGP4 session.
snBgp4NeighborSummaryRoutesAccepted brcdIp.1.2.11.17.1.1.6 Syntax: Integer32	Read-only	Indicates how many of the received routes were accepted and installed in the BGP4 route table.

## BGP4 attribute entries table

The BGP4 attribute entries table contains the sets of BGP4 attributes stored in the router's memory. Each set of attributes is unique and can be associated with one or more routes.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4AttributeTable brcdIp.1.2.11.18.1	None	The BGP4 attribute entries table.
snBgp4AttributeIndex brcdIp.1.2.11.18.1.1.1 Syntax: Integer32	Read-only	Shows the index for a route entry.
snBgp4AttributeNextHop brcdIp.1.2.11.18.1.1.2 Syntax: Integer	Read-only	Shows the IP address of the next-hop router for routes that have this set of attributes.
snBgp4AttributeMetric brcdIp.1.2.11.18.1.1.3 Syntax: Integer32	Read-only	Shows the cost of the route entry.
snBgp4AttributeOrigin brcdIp.1.2.11.18.1.1.4 Syntax: Integer	Read-only	Shows the origin of this route: <ul style="list-style-type: none"> <li>• igp(0) – Routes with this set of attributes came to BGP through IGP.</li> <li>• egp(1) – Routes with this set of attributes came to BGP through EGP.</li> <li>• incomplete(2) – Routes came from an origin other than IGP or EGP. For example, they may have been redistributed from OSPF or RIP.</li> </ul>
snBgp4AttributeAggregatorAs brcdIp.1.2.11.18.1.1.5 Syntax: Integer32	Read-only	Shows the aggregator AS number for an attribute entry. The AS in which the network information in the attribute set was aggregated. This value applies only to aggregated routes and is otherwise 0.
snBgp4AttributeRouterId brcdIp.1.2.11.18.1.1.6 Syntax: Integer	Read-only	Shows the ID of the device that originated this aggregator.
snBgp4AttributeAtomicAggregationPresent brcdIp.1.2.11.18.1.1.7 Syntax: Integer	Read-only	Shows if this aggregation has resulted in information loss: <ul style="list-style-type: none"> <li>• false(0) – No information loss.</li> <li>• true(1) – Information has been lost.</li> </ul>
snBgp4AttributeLocalPreference brcdIp.1.2.11.18.1.1.8 Syntax: Integer32	Read-only	Shows the degree of preference for routes that use this set of attributes, relative to other routes in the local AS.



Name, OID, and syntax	Access	Description
snBgp4AttributeCommunityList brcdIp.1.2.11.18.1.1.9 Syntax: OCTET STRING	Read-only	Shows the community list of this attribute entry. A community is represented by four octets. The community list, could have some well-known numbers such as: <ul style="list-style-type: none"> <li>BGP_COMMUNITY_ATTRIBUTE_NO_EXPORT0xFFFFFFFF01</li> <li>BGP_COMMUNITY_ATTRIBUTE_NO_ADVERTISE0xFFFFFFFF02</li> </ul> If the community list is a NULL string (empty list), then the community is INTERNET, which is represented by a number from 1 through 0xFFFFFFFF.
snBgp4AttributeAsPathList brcdIp.1.2.11.18.1.1.10 Syntax: OCTET STRING	Read-only	Shows the ASs through which routes with this set of attributes have passed. The local AS is shown in parentheses. This is a number from 1 through 0xFFFF. This integer number is represented by two octets.
snBgp4AttributeOriginator brcdIp.1.2.11.18.1.1.11 Syntax: IpAddress	Read-only	Shows the originator of the route in a route reflector environment.
snBgp4AttributeClusterList brcdIp.1.2.11.18.1.1.12 Syntax: OCTET STRING	Read-only	Shows the route reflector clusters through which this set of attributes has passed. The list is a group of cluster IDs. Each ID is an IP address represented by four octets.

## BGP4 clear neighbor command table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4ClearNeighborCmdTable brcdIp.1.2.11.19.1	None	The BGP4 clear neighbor command table.
snBgp4ClearNeighborCmdIp brcdIp.1.2.11.19.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address of a neighbor entry. If the IP address is 255.255.255.255, then the entry applies to all neighbors.
snBgp4ClearNeighborCmdElement brcdIp.1.2.11.19.1.1.2 Syntax: Integer	Read-write	Indicates what will be cleared: <ul style="list-style-type: none"> <li>valid(0) – Received in SNMP-GET.</li> <li>lastPacketWithError(1) – Clears the buffer containing the first 400 bytes of the last BGP4 packet that contained an error.</li> <li>notificationErrors(2) – Clears the buffer containing the last NOTIFICATION message sent or received.</li> <li>softOutbound(3) – Updates all outbound routes by applying the new or changed filters, but sends only the existing routes affected by the new or changed filters to the neighbor.</li> <li>traffic(4) – Clears the BGP4 message counters for all neighbors (the default) or a neighbor.</li> <li>neighbor(5) – Clears the BGP4 message counter for all neighbors within a peer group.</li> </ul>

## BGP4 neighbor prefix group table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snBgp4NeighPrefixGroupTable brcdIp.1.2.11.20.1	None	The BGP4 neighbor prefix group table.
snBgp4NeighPrefixGroupNeighIp brcdIp.1.2.11.20.1.1.1 Syntax: IpAddress	Read-only	Shows the neighbor's IP address.
snBgp4NeighPrefixGroupDir brcdIp.1.2.11.20.1.1.2 Syntax: Integer	Read-only	Shows the direction of the advertisement to which this filter will be applied: <ul style="list-style-type: none"> <li>outgoing(0) – Applied to routes that will be transmitted to the neighbor.</li> <li>incoming(1) – Applied to routes received from the neighbor.</li> </ul>
snBgp4NeighPrefixGroupInAccessList brcdIp.1.2.11.20.1.1.3 Syntax: OCTET STRING	Read-write	If the “snBgp4NeighPrefixGroupDir” object is set to incoming(1), this object shows the name of the prefix list for incoming routes. There can be up to 32 octets in this object.
snBgp4NeighPrefixGroupOutAccessList brcdIp.1.2.11.20.1.1.4 Syntax: OCTET STRING	Read-write	If the “snBgp4NeighPrefixGroupDir” object is set to outgoing(0), this object shows the name of the prefix list for outgoing routes. There can be up to 32 octets in this object.
snBgp4NeighPrefixGroupRowStatus brcdIp.1.2.11.20.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

# OSPF MIB Definition

---

## In this chapter

- OSPF general objects ..... 473
- OSPF area table..... 475
- Area range table ..... 476
- OSPF interface configuration tables ..... 477
- OSPF interface 2 configuration table..... 480
- OSPF virtual interface table ..... 483
- OSPF redistribution of routes table ..... 486
- OSPF neighbor table ..... 487
- OSPF virtual neighbor table ..... 489
- OSPF link-state database ..... 491
- OSPF link-state database (external)..... 492
- OSPF area status table ..... 493
- OSPF interface status table ..... 494
- OSPF virtual interface status table ..... 497
- OSPF routing information table ..... 499
- Trap support objects ..... 500

## OSPF general objects

The objects in the following table are not supported on the Brocade MLX, Brocade MLXe router, and Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

The Open Shortest Path First (OSPF) general objects provide information about the OSPF process, and they apply globally to the routers.

Name, OID, and syntax	Access	Description
snOspfRouterId brodIp.1.2.4.1.1 Syntax: RouterID	Read-write	Shows the IP address of the Autonomous System Boundary Router (ASBR). Conventionally, this ID defaults to the IP address of one of the routers to ensure uniqueness in the network. This object contains a 32-bit integer.
snOspfAdminStat brodIp.1.2.4.1.2 Syntax: Integer	Read-write	Specifies the state of the OSPF in the router: <ul style="list-style-type: none"> <li>• disabled(0) – OSPF is disabled on all interfaces.</li> <li>• enabled(1) – OSPF is active on at least one interface.</li> </ul>

Name, OID, and syntax	Access	Description
snOspfASBdrRtrStatus brcdIp.1.2.4.1.3 Syntax: TruthVal	Read-write	Indicates if this router is an Autonomous System Boundary Router: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snOspfRedisMode brcdIp.1.2.4.1.4 Syntax: Integer	Read-write	Specifies if OSPF redistribution has been enabled on this router: <ul style="list-style-type: none"> <li>disabled(0) – OSPF redistribution is disabled.</li> <li>enabled(1) – OSPF redistribution is active.</li> </ul>
snOspfDefaultOspfMetric Value brcdIp.1.2.4.1.5 Syntax: Integer	Read-write	Shows the cost of using a default OSPF metric value on this route. Valid values: 1 – 65535
snOspfExternLSACount brcdIp.1.2.4.1.6 Syntax: Gauge32	Read-only	The number of external link-state advertisements in the link-state database.
snOspfExternLSACksumSum brcdIp.1.2.4.1.7 Syntax: Integer32	Read-only	Indicates the 32-bit unsigned sum of the link-state (LS) checksums of the external link-state advertisements (LSA) contained in the link-state database. This sum can be used to determine if there has been a change in a router's link-state database and to compare the link-state database of two routers.
snOspfOriginateNewLSAs brcdIp.1.2.4.1.8 Syntax: Counter	Read-only	Shows the number of new link-state advertisements that have been originated by the router. This number increments each time the router originates a new LSA.
snOspfRxNewLSAs brcdIp.1.2.4.1.9 Syntax: Counter32	Read-only	Shows the number of link-state advertisements received by the router. This number does not include newer instantiations of self-originated link-state advertisements.
snOspfOspfRedisMetricType brcdIp.1.2.4.1.10 Syntax: Integer	Read-write	Indicates the type of route: <ul style="list-style-type: none"> <li>type1(1) – External Type 1 (comparable value) intra-area and inter-area routes. It is an OSPF metric plus the external metric.</li> <li>type2(2) – External Type 2 (non-comparable value) routes. It is the external metric.</li> </ul>
snOspfExtLsdbLimit brcdIp.1.2.4.1.11 Syntax: Integer32	Read-write	Provides compliance with RFC 1765 in the handling of OSPF external link-state database (LSDB) overflow. Specifies the maximum number of non-default AS-external-LSAs entries that can be stored in the link-state database. When the number of non-default AS-external-LSAs in a router's link-state database reaches ospfExtLsdbLimit, the router enters overflow state. The router never holds more than ospfExtLsdbLimit non-default AS-external-LSAs in its database. OspfExtLsdbLimit must be set identically in all routers attached to the OSPF backbone and any regular OSPF area. OSPF stub areas and NSSAs are excluded. Valid values: 1 – 2000.
snOspfExitOverflowInterval brcdIp.1.2.4.1.12 Syntax: Integer	Read-write	Specifies the number of seconds that a router will attempt to leave the overflow state. This value allows the router to again originate non-default AS-external-LSAs. If this object is set to 0, the router will not leave the overflow state until it is restarted. Valid values: 0 – 86400 seconds
snOspfRfc1583Compatibility brcdIp.1.2.4.1.13 Syntax: Integer	Read-write	Specifies if the OSPF route is compatible with RFC 1583 or RFC 2178: <ul style="list-style-type: none"> <li>disabled(0) – Compatible with RFC 2178.</li> <li>enabled(1) – Compatible with RFC 1583.</li> </ul>

Name, OID, and syntax	Access	Description
snOspfRouterIdFormat brcdIp.1.2.4.1.14 Syntax: Integer	Read-write	Specifies the format of how the router ID will be entered in the “snOspfRouterId” object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>
snOspfDistance brcdIp.1.2.4.1.15 Syntax: Integer	Read-write	Determines the OSPF administrative distance area. The value is zero is the distance is not set. Valid values: 1 – 255 Default: 110
snOspfDistanceIntra brcdIp.1.2.4.1.16 Syntax: Integer	Read-write	Determines the OSPF administrative distance for intra-area routes. Valid values: 1 – 255 Default: 110
snOspfDistanceInter brcdIp.1.2.4.1.17 Syntax: Integer	Read-write	Determines the OSPF administrative distance for inter-area routes. Valid values: 1 – 255 Default: 110
snOspfDistanceExternal brcdIp.1.2.4.1.18 Syntax: Integer	Read-write	Determines the OSPF administrative distance for external routes. Valid values: 1 – 255 Default: 110

## OSPF area table

The OSPF area data structure contains information that describes the various OSPF areas. The interfaces and virtual links are configured as parts of these areas. Area 0.0.0.0, by definition, is the Backbone Area.

### NOTE

The following objects are not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfAreaTable brcdIp.1.2.4.2.1	None	The OSPF area table.
snOspfAreaId brcdIp.1.2.4.2.1.1.1 Syntax: AreaID	Read-only	Specifies the address of the area. This address identifies the router, independent of its IP address. Area ID 0.0.0.0 is used for the OSPF backbone. The format used for this ID is specified by the “snOspfAreaIdFormat” object.
snOspfImportASExtern brcdIp.1.2.4.2.1.1.2 Syntax: Integer32	Read-write	Indicates the type of OSPF area that this router supports: <ul style="list-style-type: none"> <li>0 – Stub area. OSPF routers within a stub area cannot send or receive external LSAs. In addition, OSPF routers in a stub area must use a default route to the area’s Area Border Router (ABR) or Autonomous System Boundary Router (ASBR) to send traffic out of the area.</li> <li>1 – Normal area. OSPF routers within a normal area can send and receive external link-state advertisements.</li> <li>2 – NSSA area. ASBR of an NSSA can import external route information into the area.</li> </ul>

Name, OID, and syntax	Access	Description
snOspfStubMetric brcdIp.1.2.4.2.1.1.3 Syntax: BigMetric	Read-write	The metric value applied at the default type of service (ospfMetric). By default, this equals the least metric at the type of service among the interfaces to other areas. This object exists only if the value of snOspfAreaSummary is snOspfAreaSummary(2); Otherwise, an SNMP_GET or GET_NEXT attempt of this object will return NO_SUCH_NAME.
snOspfAreaRowStatus brcdIp.1.2.4.2.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snOspfAreaIdFormat brcdIp.1.2.4.2.1.1.5 Syntax: Integer	Read-write	Specifies the format of the area ID entered in the "snOspfAreaId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## Area range table

The area range allows you to assign an aggregate value to a range of IP addresses. This aggregate value becomes the address that is advertised instead of all the individual addresses it represents being advertised. The area range table contains the aggregate value of the ranges of IP addresses that are configured to be propagated from an OSPF area.

### NOTE

The following objects are not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfAreaRangeTable brcdIp.1.2.4.3.1	None	The area range table.
snOspfAreaRangeAreaID brcdIp.1.2.4.3.1.1.1 Syntax: AreaID	Read-only	Specifies the ID of the area where the address range can be found. The "snOspfAreaRangeAreaIdFormat" object determines the format of this object.
snOspfAreaRangeNet brcdIp.1.2.4.3.1.1.2 Syntax: IpAddress	Read-only	Specifies the IP address of the net or subnet indicated by the range.
snOspfAreaRangeMask brcdIp.1.2.4.3.1.1.3 Syntax: IpAddress	Read-write	Specifies the subnet mask that pertains to the net or subnet.

Name, OID, and syntax	Access	Description
snOspfAreaRangeRowStatus brcdIp.1.2.4.3.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snOspfAreaRangeArealdFormat brcdIp.1.2.4.3.1.1.5 Syntax: Integer	Read-only	Specifies the format of how area ID will be entered in the "snOspfAreaRangeAreald" object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP Address</li> </ul>

## OSPF interface configuration tables

The OSPF interface table augments the ifTable with OSPF-specific information. The following table is deprecated by "OSPF interface 2 configuration table" (snOspfIf2Table).

### NOTE

The following objects are not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## OSPF interface configuration table

Name, OID, and syntax	Access	Description
snOspfIfTable brcdIp.1.2.4.4.1	None	The OSPF interface configuration table.
snOspfIfPort brcdIp.1.2.4.4.1.1.1 Syntax: Integer32	Read-only	The physical router port of this OSPF interface.
snOspfIfAreald brcdIp.1.2.4.4.1.1.2 Syntax: Areald	Read-write	Specifies the address of the area in a 32-bit integer. This address uniquely identifies the area to which the interface connects. Area ID 0.0.0.0 is used for the OSPF backbone. Default: '00000000'h, which is equal to 0.0.0.0 .
snOspfIfAdminStat brcdIp.1.2.4.4.1.1.3 Syntax: Integer	Read-write	Indicates if neighbor relationships may be formed on this interface: <ul style="list-style-type: none"> <li>disabled(0) – The interface is external to OSPF.</li> <li>enabled(1) – Neighbor relationships may be formed on the interface, which will be advertised as an internal route to an area.</li> </ul> Default: enabled(1)

Name, OID, and syntax	Access	Description
snOspfIfRtrPriority brcdIp.1.2.4.4.1.1.4 Syntax: DesignatedRouterPriority	Read-write	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks. Valid values: 0 - 255. A value of 0 signifies that the router is not eligible to become the designated router on this particular network. If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.
snOspfIfTransitDelay brcdIp.1.2.4.4.1.1.5 Syntax: UpToMaxAge	Read-write	Shows the time it takes to transmit link-state update packets on this interface. Valid values: 0 - 3600 seconds Default: 1 second
snOspfIfRetransInterval brcdIp.1.2.4.4.1.1.6 Syntax: UpToMaxAge	Read-write	Specifies the number of seconds between link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting database description and link-state request packets. Valid values: 0 - 3600 seconds Default: 5 seconds
snOspfIfHelloInterval brcdIp.1.2.4.4.1.1.7 Syntax: HelloRange	Read-write	Specifies the number of seconds the router waits before it sends the next hello packet on this interface. This value must be the same for all routers attached to a common network Valid values: 1 - 65535 seconds (up to 'FFFF'h) Default: 10 seconds
snOspfIfRtrDeadInterval brcdIp.1.2.4.4.1.1.8 Syntax: PositiveInteger	Read-write	Specifies the number of seconds that neighbor routers wait for a router's hello packets before they declare that the router is down. This should be a multiple of the hello interval. This value must be the same for all routers attached to a common network. Valid values: 1 - 2147483647 seconds Default: 40 seconds
snOspfIfAuthType brcdIp.1.2.4.4.1.1.9 Syntax: Integer	Read-write	Specifies the authentication type for an interface. Valid values: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• md5(2)</li> <li>• reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per interface basis, up to 255. Default: none(0)



Name, OID, and syntax	Access	Description
snOspfIfAuthKey brcdIp.1.2.4.4.1.1.10 Syntax: OCTET STRING	Read-write	<p>Indicates the authentication key:</p> <ul style="list-style-type: none"> <li>If the authentication type selected is a simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets. The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 through 255 and identifies the MD5 key that is being used. The MD5 key can be up to 16 alphanumeric characters long.</li> </ul> <p>Default: '0000000000000000'h, which is equal to 0.0.0.0.0.0.0.0.</p> <p>When read, "snOspfIfAuthKey" always returns a blank.</p>
snOspfIfMetricValue brcdIp.1.2.4.4.1.1.11 Syntax: Integer	Read-write	<p>Specifies the cost of using this type of service (TOS) on this interface. The default value of the TOS 0 Metric is equal to 10<sup>8</sup> divided by the ifSpeed.</p>
snOspfIfRowStatus brcdIp.1.2.4.4.1.1.12 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snOspfIfMd5AuthKeyId brcdIp.1.2.4.4.1.1.13 Syntax: Integer	Read-write	<p>Specifies the ID of the MD5 authentication key. If the "snOspfVirtIfAuthType" object is set to MD5, this object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface (or equivalently, per subnet). The value of this object must be a number from 1 through 255.</p>
snOspfIfMd5AuthKey brcdIp.1.2.4.4.1.1.14 Syntax: OCTET STRING	Read-write	<p>Specifies the MD5 authentication key. If the "snOspfVirtIfAuthType" object is set to MD5, the value of this object is encrypted and included in each OSPF packet transmitted.</p> <p>The agent will left-adjust and zero-fill the key to equal 16 octets.</p> <p>When read, snOspfIfMd5AuthKey always returns a blank.</p>

Name, OID, and syntax	Access	Description
snOspfIfMd5ActivationWaitTime brcdIp.1.2.4.4.1.1.15 Syntax: Integer	Read-write	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 through 14400 seconds. Default: 300 seconds
snOspfIfAreaIdFormat brcdIp.1.2.4.4.1.1.16 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the "snOspfIfAreaId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP Address</li> </ul>
snOspfIfPassiveMode brcdIp.1.2.4.4.1.1.17 Syntax: Integer	Read-write	Indicates if passive mode is enabled on this interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snOspfIfDatabaseFilterAllOut brcdIp.1.2.4.4.1.1.18 Syntax: Integer	Read-write	Determines if the filtering of an outgoing OSPF LSA on this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – Filtering is disabled.</li> <li>enabled(1) – Filtering is enabled.</li> </ul>
snOspfIfMtuIgnore brcdIp.1.2.4.4.1.1.19 Syntax: Integer	Read-write	Determines if the MTU detection mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – MTU detection mode is disabled.</li> <li>enabled(1) – MTU detection mode is enabled.</li> </ul>
snOspfIfNetworkP2mp brcdIp.1.2.4.4.1.1.20 Syntax: Integer	Read-write	Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled.</li> <li>enabled(1) – P2MP mode is enabled.</li> </ul>

## OSPF interface 2 configuration table

The following table replaces snOspfIfTable and snOspfIf2Port is an ifIndex of the table.

Name, OID, and syntax	Access	Description
snOspfIf2Table brcdIp.1.2.4.4.2	None	The OSPF interface table describes the interfaces from the viewpoint of OSPF. Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled.</li> <li>enabled(1) – P2MP mode is enabled.</li> </ul>
snOspfIf2Port brcdIp.1.2.4.4.2.1.1 Syntax: Integer32	Read-only	The physical router port of this OSPF interface.
snOspfIf2AreaId brcdIp.1.2.4.4.2.1.2 Syntax: AreaID	Read-write	Specifies the address of the area in a 32-bit integer. This address uniquely identifies the area to which the interface connects. Area ID 0.0.0.0 is used for the OSPF backbone. Default: '00000000'h, which is equal to 0.0.0.0

Name, OID, and syntax	Access	Description
snOspfIf2AdminStat brcdIp.1.2.4.4.2.1.3 Syntax: Integer	Read-write	Indicates if neighbor relationships may be formed on this interface: <ul style="list-style-type: none"> <li>disabled(0) – The interface is external to OSPF.</li> <li>enabled(1) – Neighbor relationships may be formed on the interface, which will be advertised as an internal route to an area.</li> </ul> Default: enabled(1)
snOspfIf2RtrPriority brcdIp.1.2.4.4.2.1.4 Syntax: DesignatedRouterPriority	Read-write	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks. Valid values: 0 – 255. A value of 0 signifies that the router is not eligible to become the designated router on this particular network. If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.
snOspfIf2TransitDelay brcdIp.1.2.4.4.2.1.5 Syntax: UpToMaxAge	Read-write	Shows the time it takes to transmit link-state update packets on this interface. Valid values: 0 – 3600 seconds Default: 1 second
snOspfIf2RetransInterval brcdIp.1.2.4.4.2.1.6 Syntax: UpToMaxAge	Read-write	Specifies the number of seconds between link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting database description and link-state request packets. Valid values: 0 – 3600 seconds Default: 5 seconds
snOspfIf2HelloInterval brcdIp.1.2.4.4.2.1.7 Syntax: HelloRange	Read-write	Specifies the number of seconds that router waits before it sends the next hello packet on this interface. This value must be the same for all routers attached to a common network. Valid values: 1 – 65535 seconds (up to 'FFFF'h) Default: 10 seconds
snOspfIf2RtrDeadInterval brcdIp.1.2.4.4.2.1.8 Syntax: PositiveInteger	Read-write	Specifies the number of seconds that neighbor routers wait for a router's hello packets before they declare that the router is down. This should be a multiple of the hello interval. This value must be the same for all routers attached to a common network. Valid values: 1 – 2147483647 seconds Default: 40 seconds
snOspfIf2AuthType brcdIp.1.2.4.4.2.1.9 Syntax: Integer	Read-write	Specifies the authentication type for an interface. Valid values: <ul style="list-style-type: none"> <li>none(0)</li> <li>simplePassword(1)</li> <li>md5(2)</li> <li>reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per-interface basis. The value of this object can be up to 255. Default: none(0)

Name, OID, and syntax	Access	Description
snOspfIf2AuthKey brcdIp.1.2.4.4.2.1.10 Syntax: OCTET STRING	Read-write	<p>Indicates the authentication key:</p> <ul style="list-style-type: none"> <li>If the authentication type selected is a simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets. The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 through 255 and identifies the MD5 key that is being used. The MD5 key can be up to 16 alphanumeric characters long.</li> </ul> <p>Valid values: Up to eight octets Default: '0000000000000000'h, which is equal to 0.0.0.0.0.0.0 When read, "snOspfIf2AuthKey" always returns a blank.</p>
snOspfIf2MetricValue brcdIp.1.2.4.4.2.1.11 Syntax: Integer	Read-write	<p>Specifies the cost of using this type of service (TOS) on this interface. The default value of the TOS 0 Metric is equal to 10<sup>8</sup> divided by the ifSpeed. Valid values: 0 – 65535</p>
snOspfIf2RowStatus brcdIp.1.2.4.4.2.1.12 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snOspfIf2Md5AuthKeyId brcdIp.1.2.4.4.2.1.13 Syntax: Integer	Read-write	<p>Specifies the ID of the MD5 authentication key. If the "snOspfVirtIfAuthType" object is set to MD5, this object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface (or equivalently, per subnet). The value of this object must be a number from 1 through 255.</p>
snOspfIf2Md5AuthKey brcdIp.1.2.4.4.2.1.14 Syntax: OCTET STRING	Read-write	<p>Specifies the MD5 authentication key. If the "snOspfVirtIfAuthType" object is set to MD5, the value of this object is encrypted and included in each OSPF packet transmitted.</p> <p>The agent will left-adjust and zero-fill the key to equal 16 octets. When read, "snOspfIf2Md5AuthKey" always returns a blank. Valid values: Up to 16 octets.</p>

Name, OID, and syntax	Access	Description
snOspfIf2Md5ActivationWaitTime brcdIp.1.2.4.4.2.1.15 Syntax: Integer	Read-write	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 through 14400 seconds. Default: 300 seconds
snOspfIf2AreaIdFormat brcdIp.1.2.4.4.2.1.16 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the “snOspfIfAreaId” object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP Address</li> </ul>
snOspfIf2PassiveMode brcdIp.1.2.4.4.2.1.17 Syntax: Integer	Read-write	Indicates if passive mode is enabled on this interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snOspfIf2DatabaseFilterAllOut brcdIp.1.2.4.4.2.1.18 Syntax: Integer	Read-write	Determines if the filtering of an outgoing OSPF LSA on this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – Filtering is disabled.</li> <li>enabled(1) – Filtering is enabled.</li> </ul>
snOspfIf2MtuIgnore brcdIp.1.2.4.4.2.1.19 Syntax: Integer	Read-write	Determines if the MTU detection mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – MTU detection mode is disabled.</li> <li>enabled(1) – MTU detection mode is enabled.</li> </ul>
snOspfIf2NetworkP2mp brcdIp.1.2.4.4.2.1.20 Syntax: Integer	Read-write	Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled.</li> <li>enabled(1) – P2MP mode is enabled.</li> </ul>
snOspfIf2NetworkP2pt brcdIp.1.2.4.4.2.1.21 Syntax: Integer	Read-write	This object enables and disables OSPF point-to-point mode on an interface: <ul style="list-style-type: none"> <li>disabled(0) – Disables the feature.</li> <li>enabled(1) – Enables the feature.</li> </ul>
snOspfIf2NetworkNonBroadcast brcdIp.1.2.4.4.2.1.22 Syntax: Integer	Read-write	This object enables or disables non-broadcast mode of this interface.

## OSPF virtual interface table

The OSPF virtual interface table describes the virtual links that the OSPF process is configured to carry.

References:

- RFC 1583 “OSPF Version 2”, section C.4 Virtual link parameters
- RFC 1583 “OSPF Version 2”, section 9 The Interface Data Structure

### NOTE

The following objects in this section are not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfVirtIfTable brcdIp.1.2.4.5.1	None	The OSPF virtual interface table.
snOspfVirtIfAreaID brcdIp.1.2.4.5.1.1.1 Syntax: AreaID	Read-only	Specifies the ID of the transit area that the virtual link traverses. A value of 0.0.0.0 is not valid.
snOspfVirtIfNeighbor brcdIp.1.2.4.5.1.1.2 Syntax: RouterID	Read-only	Shows the IP address of the ID of the router that is serving as the virtual neighbor.
snOspfVirtIfTransitDelay brcdIp.1.2.4.5.1.1.3 Syntax: UpToMaxAge	Read-write	Shows the time it takes to transmit link-state update packets on this interface. Valid values: 0 – 3600 seconds Default: 1 second
snOspfVirtIfRetransInterval brcdIp.1.2.4.5.1.1.4 Syntax: UpToMaxAge	Read-write	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface. Valid values: 0 – 3600 seconds Default: 5 seconds This value is also used when retransmitting database description and link-state request packets. This value should be greater than the expected roundtrip time.
snOspfVirtIfHelloInterval brcdIp.1.2.4.5.1.1.5 Syntax: HelloRange	Read-write	Specifies the number of seconds that router waits before it sends the next hello packet on this interface. This value must be the same for all routers attached to a common network. Valid values: 1 – 65535 seconds Default: 10 seconds This value must be the same for the virtual neighbor.
snOspfVirtIfRtrDeadInterval brcdIp.1.2.4.5.1.1.6 Syntax: PositiveInteger	Read-write	Specifies the number of seconds that neighbor routers wait for a router's hello packets before they declare that the router is down. This should be a multiple of the hello interval. This value must be the same for the virtual neighbor. Default: 60 seconds
snOspfVirtIfAuthType brcdIp.1.2.4.5.1.1.7 Syntax: Integer	Read-write	Specifies the authentication type for an interface. Valid values: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• md5(2)</li> <li>• reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per-interface basis. Default: none(0)

Name, OID, and syntax	Access	Description
snOspfVirtIfAuthKey brcdIp.1.2.4.5.1.1.8 Syntax: OCTET STRING	Read-write	<p>Specifies the authentication key:</p> <ul style="list-style-type: none"> <li>If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets. The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 through 255 and identifies the MD5 key that is being used. The MD5 key can be up to 16 alphanumeric characters long.</li> </ul> <p>When read, "snOspfVirtIfAuthKey" always returns a blank. Default: 0000000000000000'h, which is 0.0.0.0.0.0.0</p>
snOspfVirtIfRowStatus brcdIp.1.2.4.5.1.1.9 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snOspfVirtIfMd5AuthKeyId brcdIp.1.2.4.5.1.1.10 Syntax: Integer	Read-write	<p>Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface.</p> <p>If the "snOspfVirtIfAuthType" object is set to MD5, the value of this object must be a number from 1 through 255.</p>
snOspfVirtIfMd5AuthKey brcdIp.1.2.4.5.1.1.11 Syntax: OCTET STRING	Read-write	<p>Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted.</p> <p>If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets.</p> <p>When read, snOspfVirtIfMd5AuthKey always returns a blank.</p>
snOspfVirtIfMd5ActivationW aitTime brcdIp.1.2.4.5.1.1.12 Syntax: Integer	Read-write	<p>Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation.</p> <p>Valid values: 0 – 14400 seconds Default: 300 seconds</p>
snOspfVirtIfAreaIdFormat brcdIp.1.2.4.5.1.1.13 Syntax: Integer	Read-only	<p>Specifies the format of how area ID is entered in the "snOspfVirtIfAreaID" object:</p> <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address.</li> </ul>

## OSPF redistribution of routes table

The OSPF redistribution of routes table contains a list of routes that will be used to decide whether a particular RIP or static route is to be imported into an OSPF domain. Routes will be imported if the parameter "Import Route into OSPF" is enabled. They will be imported as external type 2 routes.

### NOTE

The following objects in this section are not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfRedisTable brcdIp.1.2.4.6.1	None	The OSPF redistribution of routes table contains a list of routes that could be imported into the OSPF domain.
snOspfRedisIndex brcdIp.1.2.4.6.1.1.1 Syntax: Integer	Read-only	An ID identifying this destination route. There can be up to 64 entries for this object.
snOspfRedisIpAddress brcdIp.1.2.4.6.1.1.2 Syntax: IpAddress	Read-write	Shows the destination IP address that is associated with this particular route.
snOspfRedisMask brcdIp.1.2.4.6.1.1.3 Syntax: IpAddress	Read-write	Shows the subnet mask of this route.
snOspfRedisAction brcdIp.1.2.4.6.1.1.4 Syntax: Integer	Read-write	Specifies what action to be taken if the route matches this entry: <ul style="list-style-type: none"> <li>• nolmport(0) – Do not import the route into the OSPF domain.</li> <li>• import(1) – Import the route into the OSPF domain as an external type 2 route.</li> </ul>
snOspfRedisProtocol brcdIp.1.2.4.6.1.1.5 Syntax: Integer	Read-write	Specifies how routes are imported into the OSPF domain: <ul style="list-style-type: none"> <li>• rip(1) – The RIP route.</li> <li>• all(2) – All protocol route.</li> <li>• static(3) – The static route.</li> <li>• bgp(4) – The BGP route.</li> <li>• connected(5) – The connected route.</li> <li>• isis(6) – The IS-IS route.</li> </ul>
snOspfRedisSetOspfMetric brcdIp.1.2.4.6.1.1.6 Syntax: Integer	Read-write	The value indicates whether the route metric matches the OSPF metric field: <ul style="list-style-type: none"> <li>• disabled(0) – The route metric does not match the OSPF metric field.</li> <li>• enabled(1) – The route metric matches the OSPF metric field.</li> </ul>
snOspfRedisOspfMetricValue brcdIp.1.2.4.6.1.1.7 Syntax: Integer	Read-write	Specifies the cost of using this Type of Service (TOS) on this interface. Valid values: 0 – 65535.
snOspfRedisMatchRipMetric brcdIp.1.2.4.6.1.1.8 Syntax: Integer	Read-write	The value indicates whether the route metric matches the RIP metric field: <ul style="list-style-type: none"> <li>• disabled(0) – The route metric does not match the RIP metric field.</li> <li>• enabled(1) – The route metric matches the RIP metric field.</li> </ul>



Name, OID, and syntax	Access	Description
snOspfRedisRipMetricValue brcdIp.1.2.4.6.1.1.9 Syntax: Integer	Read-write	Specifies the cost of using RIP on this interface. Valid values: 1 – 15 hops
snOspfRedisRowStatus brcdIp.1.2.4.6.1.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## OSPF neighbor table

The OSPF neighbor table describes non-virtual neighbors in the locality of the router.

References:

- RFC 1583 “OSPF Version 2”, section 10 The Neighbor Data Structure
- RFC 1583 “OSPF Version 2”, section 12.1.2 Options

### NOTE

The following objects in this section are not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfNbrTable brcdIp.1.2.4.7.1	None	A table of non-virtual neighbor information.
snOspfNbrEntryIndex brcdIp.1.2.4.7.1.1.1 Syntax: Integer32	Read-only	The table entry index of this neighbor.
snOspfNbrPort brcdIp.1.2.4.7.1.1.2 Syntax: Integer32	Read-only	Shows the physical port ID of this neighbor.
snOspfNbrIpAddr brcdIp.1.2.4.7.1.1.3 Syntax: IpAddress	Read-only	Shows the IP address of this neighbor.
snOspfNbrIndex brcdIp.1.2.4.7.1.1.4 Syntax: Integer32	Read-only	Contains an index of each neighbor's port and IP address.
snOspfNbrRtrId brcdIp.1.2.4.7.1.1.5 Syntax: RouterID	Read-only	Specifies the IP address of the neighboring router in the autonomous system. The value of this object is a 32-bit integer. Default: '00000000'h, which is equal to 0.0.0.0

Name, OID, and syntax	Access	Description
snOspfNbrOptions brcdIp.1.2.4.7.1.1.6 Syntax: Integer32	Read-only	<p>The bit mask that is set corresponding to the neighbor's options field:</p> <ul style="list-style-type: none"> <li>• Bit 0 – The system will operate on Type of Service metrics other than TOS 0. The neighbor will ignore all metrics except for the TOS 0 metric.</li> <li>• Bit 1 – The associated area accepts and operates on external information; it is a stub area.</li> <li>• Bit 2 – The system is capable of routing IP Multicast datagrams. It implements the multicast extensions to OSPF.</li> <li>• Bit 3 – The associated area is an NSSA. These areas are capable of carrying type 7 external advertisements, which are translated into type 5 external advertisements at NSSA borders.</li> </ul> <p>Default: Bit 0</p>
snOspfNbrPriority brcdIp.1.2.4.7.1.1.7 Syntax: DesignatedRouterPriority32	Read-only	<p>Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks.</p> <p>Valid values: 0 – 255</p> <p>Default: 1. A value of 0 signifies that the router is not eligible to become the designated router on this particular network.</p> <p>If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.</p>
snOspfNbrState brcdIp.1.2.4.7.1.1.8 Syntax: Integer	Read-only	<p>Shows the state of the communication between the Layer 3 switch and the neighbor:</p> <ul style="list-style-type: none"> <li>• down(1) – There has been no recent information received from the neighbor.</li> <li>• attempt(2) – This state is only valid for neighbors attached to non-broadcast networks. It indicates that no recent information has been received from the neighbor.</li> <li>• init(3) – A hello packet has recently been seen from the neighbor. However, bidirectional communication has not yet been established with the neighbor. (The router itself did not appear in the neighbor's hello packet.) All neighbors in this state (or higher) are listed in the hello packets sent from the associated interface.</li> <li>• twoWay(4) – Communication between the two routers is bidirectional. This is the most advanced state before beginning adjacency establishment. The Designated Router and Backup Designated Router are selected from the set of neighbors in the two-way state or greater.</li> <li>• exchangeStart(5) – The first step in creating an adjacency between the two neighboring routers. The goal of this step is to decide which router is the master, and to decide upon the initial Database Description (DD) sequence number. Neighbor communications in this state or greater are called adjacencies.</li> <li>• exchange(6) – The router is describing its entire link-state database by sending DD packets to the neighbor. Each DD packet has a DD sequence number, and is explicitly acknowledged. Only one DD packet can be outstanding at any time. In this state, link-state request packets can also be sent asking for the neighbor's more recent advertisements. All adjacencies that are in the exchange state or greater are used by the flooding procedure. In fact, these adjacencies are fully capable of transmitting and receiving all types of OSPF routing protocol packets.</li> <li>• loading(7) – Link-state request packets are sent to the neighbor asking for the more recent advertisements that have been discovered (but not yet received) in the exchange state.</li> <li>• full(8) – The neighboring routers are fully adjacent. These adjacencies will now appear in router links and network link advertisements.</li> </ul> <p>Default: down(1)</p>

Name, OID, and syntax	Access	Description
snOspfNbrEvents brcdIp.1.2.4.7.1.1.9 Syntax: Counter	Read-only	Shows the number of times this neighbor's state has changed state, or the number of times an error occurred.
snOspfNbrLsRetrans QLen brcdIp.1.2.4.7.1.1.10 Syntax: Gauge32	Read-only	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface. The range is from 0 through 3600 seconds. Default: 5 seconds

## OSPF virtual neighbor table

The OSPF virtual neighbor table describes all virtual neighbors. Because virtual links are configured in the virtual interface table, this table is read-only.

Reference: RFC 1583 "OSPF Version 2", section 15 Virtual Links.

Name, OID, and syntax	Access	Description
snOspfVirtNbrTable brcdIp.1.2.4.8.1	None	The OSPF virtual neighbor table.
snOspfVirtNbrEntryIndex brcdIp.1.2.4.8.1.1.1 Syntax: Integer32	Read-only	The ID of an entry in the OSPF virtual neighbor table.
snOspfVirtNbrArea brcdIp.1.2.4.8.1.1.2 Syntax: AreaID	Read-only	Shows the ID of the transit area. The format is defined in the "snOspfVirtNbrAreaIDFormat" object.
snOspfVirtNbrRtrId brcdIp.1.2.4.8.1.1.3 Syntax: RouterID	Read-only	Identifies the IP address of the neighboring router in the autonomous system (AS). This is a 32-bit integer.
snOspfVirtNbrIpAddr brcdIp.1.2.4.8.1.1.4 Syntax: IpAddress	Read-only	Shows the IP address of this virtual neighbor.
snOspfVirtNbrOptions brcdIp.1.2.4.8.1.1.5 Syntax: Integer32	Read-only	Shows a bit map that corresponds to the neighbor's options field. Thus, Bit 1, if set, indicates that the neighbor supports Type of Service routing; if zero, no metrics other than TOS 0 are in use by the neighbor.

Name, OID, and syntax	Access	Description
snOspfVirtNbrState brcdIp.1.2.4.8.1.1.6 Syntax: Integer	Read-only	Shows the state of the communication between the Layer 3 switch and the virtual neighbor: <ul style="list-style-type: none"> <li>• down(1) – There has been no recent information received from the neighbor.</li> <li>• attempt(2) – This state is only valid for neighbors attached to non-broadcast networks. It indicates that no recent information has been received from the neighbor.</li> <li>• init(3) – A hello packet has recently been seen from the neighbor. However, bidirectional communication has not yet been established with the neighbor. (The router itself did not appear in the neighbor's hello packet.) All neighbors in this state (or higher) are listed in the hello packets sent from the associated interface.</li> <li>• twoWay(4) – Communication between the two routers is bidirectional. This is the most advanced state before beginning adjacency establishment. The Designated Router and Backup Designated Router are selected from the set of neighbors in the two-way state or greater.</li> <li>• exchangeStart(5) – The first step in creating an adjacency between the two neighboring routers. The goal of this step is to decide which router is the master, and to decide upon the initial DD sequence number. Neighbor communications in this state or greater are called adjacencies.</li> <li>• exchange(6) – The router is describing its entire link-state database by sending DD packets to the neighbor. Each DD packet has a DD sequence number, and is explicitly acknowledged. Only one DD packet can be outstanding at any time. In this state, link-state request packets can also be sent asking for the neighbor's more recent advertisements. All adjacencies in the exchange state or greater are used by the flooding procedure. In fact, these adjacencies are fully capable of transmitting and receiving all types of OSPF routing protocol packets.</li> <li>• loading(7) – Link-state request packets are sent to the neighbor asking for the more recent advertisements that have been discovered (but not yet received) in the exchange state.</li> <li>• full(8) – The neighboring routers are fully adjacent. These adjacencies will now appear in router links and network link advertisements.</li> </ul>
snOspfVirtNbrEvents brcdIp.1.2.4.8.1.1.7 Syntax: Counter32	Read-only	Shows the number of times the state of this virtual link has changed or an error has occurred.
snOspfVirtNbrLSRetransQLen brcdIp.1.2.4.8.1.1.8 Syntax: Gauge32	Read-only	Shows the current length of the retransmission queue.
snOspfVirtNbrArealdFormat brcdIp.1.2.4.8.1.1.9 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the "snOspfVirtNbrRtrld" object: <ul style="list-style-type: none"> <li>• integer(0) – Integer</li> <li>• ipAddress(1) – IP address</li> </ul>

## OSPF link-state database

The OSPF link-state database contains the link-state advertisement from all the areas to which the device is attached.

Reference: RFC 1583 “OSPF Version 2”, section 12 Link State Advertisements.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfLsdbTable brcdIp.1.2.4.9.1	None	The OSPF process's link-state database.
snOspfLsdbEntryIndex brcdIp.1.2.4.9.1.1.1 Syntax: Integer32	Read-only	The ID of the entry in the link-state database.
snOspfLsdbAreald brcdIp.1.2.4.9.1.1.2 Syntax: ArealD	Read-only	Shows the area from which the LSA was received. The value is in a 32-bit format.
snOspfLsdbType brcdIp.1.2.4.9.1.1.3 Syntax: Integer	Read-only	Specifies the type of the link-state advertisement. Each link-state type has a separate advertisement format: <ul style="list-style-type: none"> <li>• routerLink(1)</li> <li>• networkLink(2)</li> <li>• summaryLink(3)</li> <li>• asSummaryLink(4)</li> </ul>
snOspfLsdbLsld brcdIp.1.2.4.9.1.1.4 Syntax: IpAddress	Read-only	Specifies the link-state ID. This ID is an LS type-specific field containing either a router ID or an IP address. It identifies the piece of the routing domain that is being described by the advertisement.
snOspfLsdbRouterId brcdIp.1.2.4.9.1.1.5 Syntax: RouterID	Read-only	Identifies the originating router in the autonomous system. This information is in a 32-bit number. The format is determined by the “snOspfLsdbArealdFormat” object. <b>NOTE:</b> OSPF sequence number is a 32-bit signed integer. It starts with the value '80000001'h or '7FFFFFFF'h, and increments until '7FFFFFFF'h. Thus, a typical sequence number will be more negative than a negative number.
snOspfLsdbSequence brcdIp.1.2.4.9.1.1.6 Syntax: Integer32	Read-only	Shows the sequence number of this entry. The OSPF neighbor that sent the LSA stamps the LSA with a sequence number to enable the Layer 3 switch and other OSPF routers to determine which LSA for a given route is the most recent. This object can be used to detect old and duplicate link-state advertisements. The higher the sequence number, the more recent the advertisement.
snOspfLsdbAge brcdIp.1.2.4.9.1.1.7 Syntax: Integer32	Read-only	Shows the age of the link-state advertisement in seconds.
snOspfLsdbChecksum brcdIp.1.2.4.9.1.1.8 Syntax: Integer32	Read-only	Indicates the checksum for the LSA packet. The checksum is based on all the fields in the packet except the age field. The Layer 3 switch uses the checksum to verify that the packet is not corrupted.

Name, OID, and syntax	Access	Description
snOspfLsdbAdvertisement brcdIp.1.2.4.9.1.1.9 Syntax: OCTET STRING	Read-only	Shows the data in the link-state advertisement, including its header in octets. Reference: RFC 1583 "OSPF Version 2", section Section 12 Link State Advertisements
snOspfLsdbAreaIdFormat brcdIp.1.2.4.9.1.1.10 Syntax: Integer	Read-only	Specifies the format of how RouterId will be entered in the "snOspfLsdbRouterId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF link-state database (external)

The following table is identical to the OSPF LSDB table in format, but contains only external link-state advertisements. The purpose is to allow external LSAs to be displayed once for the router rather than once in each non-stub area.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfExtLsdbTable brcdIp.1.2.4.10.1	None	The link-state external database table.
snOspfExtLsdbEntryIndex brcdIp.1.2.4.10.1.1.1 Syntax: Integer32	Read-only	The table entry index of this link-state database.
snOspfExtLsdbType brcdIp.1.2.4.10.1.1.2 Syntax: Integer	Read-only	Shows the type of the link-state advertisement. Each link-state type has a separate advertisement format.
snOspfExtLsdbLsId brcdIp.1.2.4.10.1.1.3 Syntax: Integer	Read-only	Specifies the external link-state ID. This ID is an LS type-specific field containing either a router ID or an IP address. It identifies the piece of the routing domain that is being described by the advertisement.
snOspfExtLsdbRouterId brcdIp.1.2.4.10.1.1.4 Syntax: Integer	Read-only	Identifies the originating router in the autonomous system. This information is in a 32-bit number. <b>NOTE:</b> OSPF Sequence Number is a 32-bit signed integer. It starts with the value '80000001'h, or '-7FFFFFFF'h. It increments until '7FFFFFFF'h. Thus, a typical sequence number will be more negative.
snOspfExtLsdbSequence brcdIp.1.2.4.10.1.1.5 Syntax: Integer32	Read-only	Shows the sequence number of this entry. The OSPF neighbor that sent the LSA stamps it with a sequence number to enable the Layer 3 switch and other OSPF routers to determine which LSA for a given route is the most recent. This object can be used to detect old and duplicate link-state advertisements. The higher the sequence number, the more recent the advertisement.
snOspfExtLsdbAge brcdIp.1.2.4.10.1.1.6 Syntax: Integer32	Read-only	Shows the age of the link-state advertisement in seconds.

Name, OID, and syntax	Access	Description
snOspfExtLsdbChecksum brcdIp.1.2.4.10.1.1.7 Syntax: Integer32	Read-only	Indicates the checksum for the LSA packet. The checksum is based on all the fields in the packet except the age field. The Layer 3 switch uses the checksum to verify that the packet is not corrupted.
snOspfExtLsdbAdvertisem ent brcdIp.1.2.4.10.1.1.8 Syntax: OCTET STRING	Read-only	Shows the data in the link-state advertisement, including its header in octets. There can be up to 36 octets in this object.

## OSPF area status table

The OSPF area status data structure contains information regarding the configured parameters and cumulative statistics of the router's attached areas. The interfaces and virtual links are configured as part of these areas. Area 0.0.0.0 is the Backbone Area.

Reference: RFC 1583 "OSPF Version 2", section 6 The Area Data Structure.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER seriesR devices.

Name, OID, and syntax	Access	Description
snOspfAreaStatusTable brcdIp.1.2.4.11.1	None	The OSPF area status table.
snOspfAreaStatusEntryIndex brcdIp.1.2.4.11.1.1.1 Syntax: Integer32	Read-only	The ID of an entry in the OSPF area status table.
snOspfAreaStatusAreaId brcdIp.1.2.4.11.1.1.2 Syntax: AreaID	Read-only	Specifies the ID of an area. The format of this 32-bit integer is determined by the value of the <a href="#">"snOspfAreaStatusAreaIdFormat"</a> object. Area ID 0.0.0.0 is used for the OSPF backbone.
snOspfAreaStatusImportASExtern brcdIp.1.2.4.11.1.1.3 Syntax: Integer32	Read-only	The area's support for importing AS external link-state advertisements. Default: 1
snOspfAreaStatusStubMetric brcdIp.1.2.4.11.1.1.4 Syntax: BigMetric	Read-only	The metric value applied at the default type of service (ospfMetric). By default, this equals the least metric at the type of service among the interfaces to other areas. This object exists only if the value of snOspfAreaSummary is snOspfAreaSummary(2); otherwise, an SNMP_GET or GET_NEXT attempt of this object will return NO_SUCH_NAME.
snOspfAreaStatusSpfRuns brcdIp.1.2.4.11.1.1.5 Syntax: Counter32	Read-only	Shows the number of times that the intra-area route table has been recalculated using this area's link-state database.
snOspfAreaStatusAreaBdrRtrCou nt brcdIp.1.2.4.11.1.1.6 Syntax: Gauge32	Read-only	Shows the number of area border routers that are reachable within this area. This is initially zero, the default, and is calculated in each shortest path first (SPF) pass.

Name, OID, and syntax	Access	Description
snOspfAreaStatusASBdrRtrCount brcdIp.1.2.4.11.1.1.7 Syntax: Gauge32	Read-only	Shows the total number of Autonomous System border routers that are reachable within this area. This is initially zero, the default, and is calculated in each SPF pass.
snOspfAreaStatusLSACount brcdIp.1.2.4.11.1.1.8 Syntax: Gauge32	Read-only	Shows the total number of link-state advertisements in this area's link-state database, excluding AS external LSAs. Default: 0
snOspfAreaStatusLSACksumSum brcdIp.1.2.4.11.1.1.9 Syntax: Integer32	Read-only	Shows the total link-state advertisements of area's link-state database. This number is a 32-bit unsigned sum of the LS checksums, excluding external (LS type 5) link-state advertisements. The value can be used to determine if there has been a change in a router's link-state database, and to compare the link-state database of two routers. Default: 0
snOspfAreaStatusAreaIdFormat brcdIp.1.2.4.11.1.1.10 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the "snOspfAreaStatusAreaId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address.</li> </ul>

## OSPF interface status table

The OSPF interface status table describes the interfaces from the viewpoint of OSPF. It augments the ifStatusTable with OSPF-specific information.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfIfStatusTable brcdIp.1.2.4.12.1	None	The OSPF interface status table.
snOspfIfStatusEntryIndex brcdIp.1.2.4.12.1.1.1 Syntax: Integer32	Read-only	The ID of an entry in the OSPF interface status table.
snOspfIfStatusPort brcdIp.1.2.4.12.1.1.2 Syntax: Integer32	Read-only	Shows the ID of the physical router port of this OSPF interface.
snOspfIfStatusIpAddress brcdIp.1.2.4.12.1.1.3 Syntax: IpAddress	Read-only	Shows the IP address of this OSPF interface.
snOspfIfStatusAreaId brcdIp.1.2.4.12.1.1.4 Syntax: AreaID	Read-only	Identifies the area to which the interface connects. This ID is a 32-bit integer. Area ID 0.0.0.0 (in the '00000000'h format) is used for the OSPF backbone. The format of this ID is determined by the value of the "snOspfIfStatusAreaIdFormat" object.



Name, OID, and syntax	Access	Description
snOspfIfStatusType brcdIp.1.2.4.12.1.1.5 Syntax: Integer	Read-only	Identifies the OSPF interface type. (By way of a default, this field may be derived from the corresponding value of ifType.) <ul style="list-style-type: none"> <li>• broadcast(1) – For broadcast LANs such as Ethernet and IEEE 802.5.</li> <li>• nbma(2) – For X.25, Frame Relay, and similar technologies.</li> <li>• pointToPoint(3) – For point-to-point interfaces.</li> </ul>
snOspfIfStatusAdminStat brcdIp.1.2.4.12.1.1.6 Syntax: Integer	Read-only	Shows if OSPF has been enabled to form neighbor relationships on the interface: <ul style="list-style-type: none"> <li>• disabled(0) – The interface is external to OSPF.</li> <li>• enabled(1) – OSPF has been enabled to form neighbor relationships and the interface will be advertised as an internal route to some area.</li> </ul>
snOspfIfStatusRtrPriority brcdIp.1.2.4.12.1.1.7 Syntax: DesignatedRouterPriority	Read-only	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks. Valid values: 0 – 255 Default: 1. A value of 0 means that the router is not eligible to become the designated router on this particular network. If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.
snOspfIfStatusTransitDelay brcdIp.1.2.4.12.1.1.8 Syntax: UpToMaxAge	Read-only	Shows the time it takes to transmit link-state update packets on this interface. Valid values: 0 – 3600 seconds Default: 1 second
snOspfIfStatusRetransInterval brcdIp.1.2.4.12.1.1.9 Syntax: UpToMaxAge	Read-only	Shows the number of seconds between retransmissions of link-state advertisements, to adjacencies that belong to this interface. This value is also used when retransmitting database description and link-state request packets. Valid values: 0 – 3600 seconds Default: 5 seconds
snOspfIfStatusHelloInterval brcdIp.1.2.4.12.1.1.10 Syntax: HelloRange	Read-only	Specifies the number of seconds that router waits before it sends the next hello packet on this interface. This value must be the same for all routers attached to a common network. Valid values: 1 – 65535 seconds Default: 10 seconds
snOspfIfStatusRtrDeadInterval brcdIp.1.2.4.12.1.1.11 Syntax: PositiveInteger	Read-only	Specifies the number of seconds that neighbor routers wait for a router's hello packets before they declare that the router is down. This should be a multiple of the hello interval and must be the same for all routers attached to a common network. Default: 40 seconds
snOspfIfStatusState brcdIp.1.2.4.12.1.1.12 Syntax: Integer	Read-only	Shows the OSPF interface state: <ul style="list-style-type: none"> <li>• down(1)</li> <li>• loopback(2)</li> <li>• waiting(3)</li> <li>• pointToPoint(4)</li> <li>• designatedRouter(5)</li> <li>• backupDesignatedRouter(6)</li> <li>• otherDesignatedRouter(7)</li> </ul> Default: down(1)

Name, OID, and syntax	Access	Description
snOspfIfStatusDesignatedRouter brcdIp.1.2.4.12.1.1.13 Syntax: IpAddress	Read-only	Shows the IP address of the designated router. Default: '00000000'h, which is equal to 0.0.0.0
snOspfIfStatusBackupDesignatedRouter brcdIp.1.2.4.12.1.1.14 Syntax: IpAddress	Read-only	Shows the IP address of the backup router. Default: '00000000'h, which is equal to 0.0.0.0
snOspfIfStatusEvents brcdIp.1.2.4.12.1.1.15 Syntax: Counter32	Read-only	Shows the following: <ul style="list-style-type: none"> <li>The number of times that the state of this OSPF interface has changed</li> <li>The number of times an error has occurred</li> </ul>
snOspfIfStatusAuthType brcdIp.1.2.4.12.1.1.16 Syntax: Integer32	Read-only	Specifies the authentication type for an interface. Valid values: <ul style="list-style-type: none"> <li>none(0)</li> <li>simplePassword(1)</li> <li>md5(2)</li> <li>reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per-interface basis. Default: none(0)
snOspfIfStatusAuthKey brcdIp.1.2.4.12.1.1.17 Syntax: OCTET STRING	Read-only	Indicates the area's authentication key: <ul style="list-style-type: none"> <li>If the authentication type selected is a simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets. The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 through 255 and identifies the MD5 key that is being used. The MD5 key can be up to 16 alphanumeric characters long.</li> </ul> When read, "snOspfIfAuthKey" always returns a blank. Default: '0000000000000000'h, which is 0.0.0.0.0.0.0.0
snOspfIfStatusMetricValue brcdIp.1.2.4.12.1.1.18 Syntax: Integer	Read-only	Specifies the cost of using this TOS on this interface. The default value of the TOS 0 Metric is 10^8 or ifSpeed. Valid values: 0 – 65535
snOspfIfStatusMd5AuthKeyId brcdIp.1.2.4.12.1.1.19 Syntax: Integer	Read-only	Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface. If the "snOspfIfAuthType" object is set to MD5, the value of this object must be a number from 1 through 255.
snOspfIfStatusMd5AuthKey brcdIp.1.2.4.12.1.1.20 Syntax: OCTET STRING	Read-only	Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted. If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets. When read, snOspfIfMd5AuthKey always returns a blank.

Name, OID, and syntax	Access	Description
snOspfIfStatusMd5ActivationWaitTime brcdIp.1.2.4.12.1.1.21 Syntax: Integer	Read-only	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 through 14400 seconds.
snOspfIfStatusAreaIdFormat brcdIp.1.2.4.12.1.1.22 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the “snOspfIfStatusAreaId” object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF virtual interface status table

The OSPF virtual interface status table contains information about this router’s virtual interfaces.

Reference: RFC 1583 “OSPF Version 2”, section C.4 Virtual link parameters.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfVirtIfStatusTable brcdIp.1.2.4.13.1	None	The OSPF virtual interface status table.
snOspfVirtIfStatusEntryIndex brcdIp.1.2.4.13.1.1.1 Syntax: Integer32	Read-only	The ID of the entry in this table.
snOspfVirtIfStatusAreaID brcdIp.1.2.4.13.1.1.2 Syntax: AreaID	Read-only	Shows the ID of the transit area that the virtual link traverses. The value of this object cannot be 0.0.0.0. The format of this object is determined by the value of the “snOspfVirtIfStatusAreaIdFormat” object.
snOspfVirtIfStatusNeighbor brcdIp.1.2.4.13.1.1.3 Syntax: RouterID	Read-only	Shows the ID or IP address of the router that is serving as the virtual neighbor.
snOspfVirtIfStatusTransitDelay brcdIp.1.2.4.13.1.1.4 Syntax: UpToMaxAge	Read-only	Shows the time it takes to transmit link-state update packets on this interface. Valid values: 0 – 3600 seconds Default: 1 second
snOspfVirtIfStatusRetransInterval brcdIp.1.2.4.13.1.1.5 Syntax: UpToMaxAge	Read-only	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface. Valid values: 0 – 3600 seconds Default: 5 seconds

Name, OID, and syntax	Access	Description
snOspfVirtIfStatusHelloInterval brcdIp.1.2.4.13.1.1.6 Syntax: HelloRange	Read-only	Specifies the number of seconds that the router waits before it sends the next hello packet on this interface. This value must be the same for all routers attached to a common network. Valid values: 1 – 65535 seconds Default: 10 seconds
snOspfVirtIfStatusRtrDeadInterval brcdIp.1.2.4.13.1.1.7 Syntax: PositiveInteger	Read-only	Specifies the number of seconds that neighbor routers wait for a router's hello packets before they declare that the router is down. This should be a multiple of the hello interval. This value must be the same for all routers attached to a common network. Default: 60 seconds
snOspfVirtIfStatusState brcdIp.1.2.4.13.1.1.8 Syntax: Integer	Read-only	Shows the state of the OSPF virtual interface: <ul style="list-style-type: none"> <li>• down(1)</li> <li>• pointToPoint(4)</li> </ul> Default: down(1)
snOspfVirtIfStatusEvents brcdIp.1.2.4.13.1.1.9 Syntax: Counter32	Read-only	Shows the following: <ul style="list-style-type: none"> <li>• The number of times that the state of this OSPF interface has changed</li> <li>• The number of times an error has occurred</li> </ul>
snOspfVirtIfStatusAuthType brcdIp.1.2.4.13.1.1.10 Syntax: Integer32	Read-only	Specifies the authentication type for an interface. Valid values:: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• reserved for specification by IANA(&gt; 1)</li> </ul> Additional authentication types may be assigned locally on a per-interface basis. Default: none(0)
snOspfVirtIfStatusAuthKey brcdIp.1.2.4.13.1.1.11 Syntax: OCTET STRING	Read-only	Specifies the authentication key: <ul style="list-style-type: none"> <li>• If the authentication type selected is a simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets. The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>• If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 through 255 and identifies the MD5 key that is being used. The MD5 key can be up to 16 alphanumeric characters long.</li> </ul> When read, "snOspfVirtIfAuthKey" always returns a blank. Default: '0000000000000000'h, which is 0.0.0.0.0.0.0
snOspfVirtIfStatusMd5AuthKeyId brcdIp.1.2.4.13.1.1.12 Syntax: Integer	Read-only	Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface. If the "snOspfVirtIfAuthType" object is set to MD5, the value of this object must be a number from 1 through 255.

Name, OID, and syntax	Access	Description
snOspfVirtIfStatusMd5AuthKey brcdIp.1.2.4.13.1.1.13 Syntax: OCTET STRING	Read-only	Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted. If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets. When read, snOspfIfMd5AuthKey always returns a blank.
snOspfVirtIfStatusMd5ActivationWaitTime brcdIp.1.2.4.13.1.1.14 Syntax: Integer	Read-only	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 through 14400 seconds.
snOspfVirtIfStatusAreaIDFormat brcdIp.1.2.4.13.1.1.15 Syntax: Integer	Read-only	Specifies the format of how Area ID will be entered in the "snOspfVirtIfStatusAreaID" object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF routing information table

The OSPF routing information table contains information on the OSPF Area Border Router (ABR) or Autonomous System Boundary Router (ASBR) routing.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snOspfRoutingInfoTable brcdIp.1.2.4.14.1	None	The OSPF routing information table.
snOspfRoutingInfoIndex brcdIp.1.2.4.14.1.1.1 Syntax: Integer32	Read-only	The ID of an entry in this table.
snOspfRoutingInfoRouterID brcdIp.1.2.4.14.1.1.2 Syntax: RouterID	Read-only	Shows the ID or IP address of the destination router.
snOspfRoutingInfoRouterType brcdIp.1.2.4.14.1.1.3 Syntax: Integer	Read-only	Shows what router type the destination router is: <ul style="list-style-type: none"> <li>abr(1) – Area Border Router</li> <li>asbr(2) – Autonomous System Border Router</li> <li>abrANDasbr(3) – Area Border and Autonomous System Border Router</li> </ul>

Name, OID, and syntax	Access	Description
snOspfRoutingInfoNextHopRouterID brcdIp.1.2.4.14.1.1.4 Syntax: RouterID	Read-only	Shows the ID or IP address of the next-hop destination router.
snOspfRoutingInfoOutgoingInterface brcdIp.1.2.4.14.1.1.5 Syntax: Integer32	Read-only	Shows the outgoing interface of the destination router.

## Trap support objects

The following table contains the support objects for the OSPF traps.

Name, OID, and syntax	Access	Description
snOspfSetTrap brcdIp.1.2.4.15.1 Syntax: OCTET STRING	Read-write	Indicates if specific OSPF traps are enabled. The four octets serves as a bit map for the trap events defined by the OSPF traps. A value of 1 in the bit field indicates that the trap is enabled. The right-most bit (least significant) represents Trap 0.
snOspfConfigErrorType brcdIp.1.2.4.15.2 Syntax: Integer	Read-only	Indicates the potential types of configuration conflicts used by the ospfConfigError and ospfConfigVirtError traps: <ul style="list-style-type: none"> <li>• badVersion(1)</li> <li>• areaMismatch(2)</li> <li>• unknownNbmaNbr(3) – Router is eligible.</li> <li>• unknownVirtualNbr(4)</li> <li>• authTypeMismatch(5)</li> <li>• authFailure(6)</li> <li>• netMaskMismatch(7)</li> <li>• helloIntervalMismatch(8)</li> <li>• deadIntervalMismatch(9)</li> <li>• optionMismatch(10)}</li> </ul>
snOspfPacketType brcdIp.1.2.4.15.3 Syntax: Integer	Read-only	Indicates the OSPF packet type in the trap: <ul style="list-style-type: none"> <li>• hello(1)</li> <li>• dbDescript(2)</li> <li>• lsReq(3)</li> <li>• lsUpdate(4)</li> <li>• lsAck(5)}</li> </ul>
snOspfPacketSrc brcdIp.1.2.4.15.4 Syntax: IpAddress	Read-only	Shows the IP address of an inbound packet that cannot be identified by a neighbor instance.
snOspfTrapsGenerationMode brcdIp.1.2.4.15.5 Syntax: RtrStatus	Read-write	Indicates if this router has been enabled to generate OSPF traps: <ul style="list-style-type: none"> <li>• disabled(0) – OSPF traps cannot be generated by this router, even if the “snOspfSetTrap” object is set to generate traps.</li> <li>• enabled(1) – OSPF traps can be generated by the router.</li> </ul> This object provides global control on the generation of traps.

# Broadcast Forwarding Group

## In this chapter

- [General UDP broadcast forwarding group](#) ..... 501
- [UDP broadcast forwarding port table](#) ..... 501
- [UDP helper table](#) ..... 502

## General UDP broadcast forwarding group

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, and Brocade NetIron XMR devices.

Name, OID, and syntax	Access	Description
snRtUdpBcastFwdEnable brcdIp.1.2.2.9 Syntax: RtrStatus	Read-write	Indicates if the UDP broadcast forwarding feature is enabled: <ul style="list-style-type: none"> <li>• disabled(0) – When this object is set to disabled, entries in the UDP broadcast forwarding port table are deleted.</li> <li>• enabled(1) – When UDP broadcast forwarding is enabled, default entries are added to the UDP broadcast forwarding port table.</li> </ul> Default: enabled(1)

## UDP broadcast forwarding port table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, and Brocade NetIron XMR devices.

The following table contains a list of UDP port numbers for which forwarding UDP broadcast is enabled.

Name, OID, and syntax	Access	Description
snRtUdpBcastFwdPortTable brcdIp.1.2.2.9.2.1	None	The UDP broadcast forwarding port table.
snRtUdpBcastFwdPortIndex brcdIp.1.2.2.9.2.1.1.1 Syntax: Integer	Read-only	The index of an entry in the UDP broadcast forwarding port table. There can be up to 20 entries.

Name, OID, and syntax	Access	Description
snRtUdpBcastFwdPortNumber brcdIp.1.2.2.9.2.1.1.2 Syntax: Integer	Read-write	Shows the port number for which the UDP broadcast forwarding feature has been enabled. Possible port numbers are: <ul style="list-style-type: none"> <li>port(68) – bootpc</li> <li>port(67) – bootps</li> <li>port(9) – discard</li> <li>port(53) – dns</li> <li>port(90) – dnsm</li> <li>port(7) – echo</li> <li>port(434) – mobile-ip</li> <li>port(138) – netbios-dgm</li> <li>port(137) – netbios-ns</li> <li>port(123) – ntp</li> <li>port(65) – tacacs</li> <li>port(517) – talk</li> <li>port(37) – time</li> <li>port(69) – tftp</li> </ul> Other application port numbers can also be specified.
snRtUdpBcastFwdPortRowStatus brcdIp.1.2.2.9.2.1.1.3 Syntax: RowSts	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the rows</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## UDP helper table

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, and Brocade NetIron XMR devices.

A UDP helper table contains addresses that are used to forward a client's broadcast request for a UDP application when the client and server are on different networks. There can be up to four helper addresses on each interface. Helper addresses can be configured on an Ethernet port or a virtual interface.

Name, OID, and syntax	Access	Description
snRtUdpHelperTable brcdIp.1.2.2.9.3.1	None	The UDP helper table.
snRtUdpHelperPortIndex brcdIp.1.2.2.9.3.1.1.1 Syntax: PortIndex	Read-only	Indicates the port index for a UDP helper address. For Brocade FastIron or Brocade NetIron products, the value of this object is from 1 through 42.



Name, OID, and syntax	Access	Description
snRtUdpHelperIndex brcdIp.1.2.2.9.3.1.1.2 Syntax: Integer	Read-only	An index in the UDP helper table for this entry. Valid values: 1- 4
snRtUdpHelperAddrType brcdIp.1.2.2.9.3.1.1.3 Syntax: IpAddress	Read-write	Indicates if the address is unicast or subnet broadcast address. Valid values: <ul style="list-style-type: none"> <li>• unicast(1)</li> <li>• broadcast(2)</li> </ul>
snRtUdpHelperAddr brcdIp.1.2.2.9.3.1.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the UDP helper. UDP packets will be forwarded to this address. It can be a helper address or a subnet broadcast address, but it cannot be 255.255.255.255 or 0.0.0.0.
snRtUdpHelperRowStatus brcdIp.1.2.2.9.3.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>



# Router IP RIP MIB

---

## In this chapter

- IP RIP general group ..... 505
- IP RIP port configuration table ..... 507
- IP RIP redistribution table ..... 508
- IP RIP route filter table ..... 510
- IP RIP neighbor filter table ..... 510
- IP RIP port access table ..... 511
- Global RIP statistics ..... 512

## IP RIP general group

The Routing Information Protocol (RIP) is an IP route exchange protocol that uses a distance vector (a number representing distance) to measure the cost of a given route. The cost is a distance vector because the cost often is equivalent to the number of hops between the Layer 3 switch and the destination network.

A Layer 3 switch can receive multiple paths to a destination. A RIP route can have a maximum cost of 15.

---

### NOTE

The IP RIP MIBs are supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

The following objects are general objects for RIP.

Name, OID, and syntax	Access	Description
snRtIpRipEnable brcdIp.1.2.3.1.1 Syntax: Integer	Read-write	Indicates if IP RIP routing is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snRtIpRipUpdateTime brcdIp.1.2.3.1.2 Syntax: Integer	Read-write	Specifies the RIP update interval in seconds. Valid values: 1 – 21845 seconds

Name, OID, and syntax	Access	Description
snRtlpRipRedisEnable brcdIp.1.2.3.1.3 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates if redistribution of static routes from the IP route table into RIP is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snRtlpRipRedisDefMetric brcdIp.1.2.3.1.4 Syntax: Integer	Read-write	Shows the default metric to be used when static routes are redistributed to RIP. Valid values: 1 – 15
snRtlpRipSetAllPortConfig brcdIp.1.2.3.1.5 Syntax: Integer32 <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	The value of this object is a number corresponding to a row in the “snRtlpRipPortConfigPortIndex” object of “snRtlpRipPortConfigTable”. The values of the “snRtlpRipPortVersion” and “snRtlpRipPortPoisonReverse” objects will be written to that row. <b>NOTE:</b> Before setting this object, all the intended data of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire “IP RIP port configuration table”. The previous setting will be overwritten by the new one.
snRtlpRipGblFiltList brcdIp.1.2.3.1.6 Syntax: OCTET STRING <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	An IP RIP global filter list. Each octet contains a filter ID number that forms a group of filters. A valid entry in “snRtlpRipRouteFilterTable” with the corresponding filter ID number in the “snRtlpRipRouteFilterId” object must be created before a filter list is initialized. Valid values: 1 – 64 octets
snRtlpRipFiltOnAllPort brcdIp.1.2.3.1.7 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Applies the IP RIP global filter object “snRtlpRipGblFiltList” to all interfaces. This object is used to add and delete all RIP filter lists to and from all interfaces. Prior to sending this command, “snRtlpRipGblFiltList” must contain the correct filter list. The following values can be written: <ul style="list-style-type: none"> <li>deleteAllInBound(2) – Delete all in-bound filter lists from all ports.</li> <li>deleteAllOutBound(3) – Delete all out-bound filter lists from all ports.</li> <li>addAllInBound(4) – Add all in-bound filter lists to all ports.</li> <li>addAllOutBound(5) – Add all out-bound filter lists to all ports.</li> </ul> If a set operation failed, then a SET with value of (2) or (3) returns the error code "GenError". If the operation succeeded, then entries in this filter list are deleted immediately. The following value is returned on reads: <ul style="list-style-type: none"> <li>valid(1) – Set operation is done and is valid.</li> </ul>

Name, OID, and syntax	Access	Description
snRtlpRipDistance brcdIp.1.2.3.1.8 Syntax: Integer	Read-write	Shows the administrative distance of this filter. Valid values: 1 - 255
snRtlpRipEcmpEnable brcdIp.1.2.3.1.9 Syntax: RtrStatus  <b>NOTE:</b> This MIB object is supported on the Brocade FastIron devices.	Read-write	Enables or disables ECMP for IP RIP: <ul style="list-style-type: none"> <li>0 - Disables ECMP</li> <li>1 - Enables ECMP</li> </ul>

## IP RIP port configuration table

The IP RIP port configuration table contains the configuration of RIP on a particular interface. Before you can use this table, RIP must be enabled in the device and must be configured with permit and deny commands.

### NOTE

The IP RIP MIBs are not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpRipPortConfigTable brcdIp.1.2.3.2	None	The IP RIP port configuration table.
snRtlpRipPortConfigPortIndex brcdIp.1.2.3.2.1.1 Syntax: PortIndex	Read-only	The port index for an entry in the IP RIP port configuration table.
snRtlpRipPortVersion brcdIp.1.2.3.2.1.2 Syntax: Integer	Read-write	Specifies the IP RIP version on this port: <ul style="list-style-type: none"> <li>disabled(0) – RIP is disabled on this port.</li> <li>v1Only(1) – RIP version 1 only.</li> <li>v2Only(2) – RIP version 2 only.</li> <li>v1CompatibleV2(3) – RIP version 2 is compatible with version 1.</li> </ul>
snRtlpRipPortPoisonReverse brcdIp.1.2.3.2.1.3 Syntax: Integer	Read-write	Indicates if poison reverse is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Poison reverse prevents routing loops and slow convergence within the network.
snRtlpRipPortLearnDefault brcdIp.1.2.3.2.1.4 Syntax: Integer	Read-write	Indicates if the ability to learn advertised routes is enabled on the interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## IP RIP redistribution table

The IP RIP redistribution table contains routes where RIP routes are redistributed. RIP can redistribute routes from other routing protocols such as OSPF and BGP4 into RIP. A redistributed route means that a Layer 3 switch learns through another protocol, and then distributes into RIP.

Name, OID, and syntax	Access	Description
snRtlpRipRedisTable brcdIp.1.2.3.3	None	The IP RIP redistribution table.
snRtlpRipRedisIndex brcdIp.1.2.3.3.1.1 Syntax: Integer	Read-only	The table index for a IP RIP redistribution entry. There can be up to 64 entries in this table.
snRtlpRipRedisAction brcdIp.1.2.3.3.1.2 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Indicates what to do if routes match this IP RIP redistribution entry. <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtlpRipRedisProtocol brcdIp.1.2.3.3.1.3 Syntax: Integer	Read-write	Indicates which protocol is to be distributed: <ul style="list-style-type: none"> <li>other(1) – Cannot be used for SNMP-SET.</li> <li>all(2)</li> <li>static(3)</li> <li>ospf(4)</li> <li>bgp(5)</li> <li>isis(6)</li> </ul>
snRtlpRipRedisIp brcdIp.1.2.3.3.1.4 Syntax: IpAddress <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the IP address of the IP route to be distributed. The address 0.0.0.0 means that all routes will be distributed.

Name, OID, and syntax	Access	Description
snRtIpRipRedisMask brcdIp.1.2.3.3.1.5 Syntax: IpAddress <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Shows the IP subnet mask of the IP route to be distributed.
snRtIpRipRedisMatchMetric brcdIp.1.2.3.3.1.6 Syntax: Integer <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-write	Specifies the metric of the route to be matched to determine the redistribution.  Valid values: 0 – 65535. A value of 0 means that any metric value will be matched.
snRtIpRipRedisSetMetric brcdIp.1.2.3.3.1.7 Syntax: Integer	Read-write	Specifies the new metric of the route to be advertised.  Valid values: 0 – 15. A value of 0 indicates that the default metric will be used.
snRtIpRipRedisRowStatus brcdIp.1.2.3.3.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snRtIpRipRedisRouteMapName brcdIp.1.2.3.3.1.9 Syntax: DisplayString	Read-write	Indicates the name of the route map used for this redistribution entry.

## IP RIP route filter table

The IP RIP route filter table defines the IP network numbers the router will learn from RIP. The numbers are stored in the router's IP routing table. Once RIP filters are defined, you can assign them to individual interfaces.

### NOTE

The IP RIP route filter MIBs are not supported on the Brocade MLX, Brocade MLXe router, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtIpRipRouteFilterTable brcdIp.1.2.3.4	None	The IP RIP route filter table.
snRtIpRipRouteFilterId brcdIp.1.2.3.4.1.1 Syntax: Integer	Read-only	Shows the filter ID to identify a filter entry. There can be up to 64 entries in this table.
snRtIpRipRouteFilterAction brcdIp.1.2.3.4.1.2 Syntax: Integer	Read-write	Indicates what action to take if the IP RIP packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtIpRipRouteFilterIpAddr brcdIp.1.2.3.4.1.3 Syntax: IpAddress	Read-write	Indicates the route IP address that needs to be matched by any IP address in a RIP packet. A value of 0.0.0.0 means that any IP address in any RIP packets will be matched.
snRtIpRipRouteFilterSubnetMask brcdIp.1.2.3.4.1.4 Syntax: IpAddress	Read-write	If "snRtIpRipRouteFilterIpAddr" is 0, this value is ignored, and all IP RIP packets will be matched. Otherwise, this mask is applied to the IP RIP packet and then compared to "snRtIpRipRouteFilterIpAddr" to determine a match.
snRtIpRipRouteFilterRowStatus brcdIp.1.2.3.4.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.           The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IP RIP neighbor filter table

The IP RIP neighbor filter table specifies the routers from which a router will receive RIP routes. By default, RIP routes will be learned from all neighbors.



Name, OID, and syntax	Access	Description
snRtlpRipNbrFilterTable brcdIp.1.2.3.5	None	The IP RIP neighbor filter table.
snRtlpRipNbrFilterId brcdIp.1.2.3.5.1.1 Syntax: Integer	Read-only	Indicates the ID of this entry in the table. There can be up to 64 entries in this table.
snRtlpRipNbrFilterAction brcdIp.1.2.3.5.1.2 Syntax: Integer	Read-write	Indicates what action to take if the source IP address in a packet matches the source IP address in this filter. The IP address to be matched is defined by the "snRtlpRipNbrFilterSourceIp" object:: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtlpRipNbrFilterSourceIp brcdIp.1.2.3.5.1.3 Syntax: IpAddress	Read-write	Shows the source IP address that needs to be matched by the RIP packet. An IP address of 0.0.0.0 always matches any source IP addresses in any IP RIP packets.
snRtlpRipNbrFilterRowStatus brcdIp.1.2.3.5.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## IP RIP port access table

The IP RIP port access table allows a group of RIP filters to be applied to an IP interface. The filters can be applied to either incoming or outgoing traffic.

### NOTE

The IP RIP port access MIBs are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpRipPortAccessTable brcdIp.1.2.3.6	None	The IP interface RIP access table.
snRtlpRipPortAccessPort brcdIp.1.2.3.6.1.1 Syntax: PortIndex	Read-only	The port number to which the IP RIP filter applies.
snRtlpRipPortAccessDir brcdIp.1.2.3.6.1.2 Syntax: Integer	Read-only	Specifies if the filter is for incoming or outgoing packets: <ul style="list-style-type: none"> <li>in(1) – Incoming packet</li> <li>out(2) – Outgoing packet</li> </ul>

Name, OID, and syntax	Access	Description
snRtlpRipPortAccessFilterList brcdIp.1.2.3.6.1.3 Syntax: OCTET STRING	Read-write	Contains an IP RIP filter list. Valid values: Up to 64 octets. Each octet contains a filter ID number that consists of a group of filters. Before a filter list can be created, there must be valid entries in the IP RIP route filter table ("snRtlpRipRouteFilterTable" object) with the corresponding filter ID number entered in the "snRtlpRipRouteFilterId" object.
snRtlpRipPortAccessRowStat us brcdIp.1.2.3.6.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Global RIP statistics

The following objects provide global RIP statistics.

### NOTE

The global RIP statistics MIBs are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snRtlpRipStats brcdIp.1.2.3.9	None	The RIP statistics group table.
snRtlpRipStatsOutRequest brcdIp.1.2.3.9.1 Syntax: Integer	Read-only	The number of outgoing RIP requests.
snRtlpRipStatsOutResponse brcdIp.1.2.3.9.2 Syntax: Integer	Read-only	The number of outgoing RIP responses.
snRtlpRipStatsInRequest brcdIp.1.2.3.9.3 Syntax: Integer	Read-only	The number of incoming RIP requests.
snRtlpRipStatsInResponse brcdIp.1.2.3.9.4 Syntax: Integer	Read-only	The number of incoming RIP responses.
snRtlpRipStatsUnrecognized brcdIp.1.2.3.9.5 Syntax: Integer	Read-only	The number of unrecognized RIP packets.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snRtIpRipStatsBadVersion brcdIp.1.2.3.9.6 Syntax: Integer	Read-only	The number of RIP packets with bad version numbers.
snRtIpRipStatsBadAddrFamily brcdIp.1.2.3.9.7 Syntax: Integer	Read-only	The number of RIP packets with bad address family values.
snRtIpRipStatsBadRequestFormat brcdIp.1.2.3.9.8 Syntax: Integer	Read-only	The number of RIP packets with bad request format.
snRtIpRipStatsBadMetrics brcdIp.1.2.3.9.9 Syntax: Integer	Read-only	The number of RIP packets with bad metric values.
snRtIpRipStatsBadResponseFormat brcdIp.1.2.3.9.10 Syntax: Integer	Read-only	The number of RIP packets with bad response format.
snRtIpRipStatsResponseFromNonRipPort brcdIp.1.2.3.9.11 Syntax: Integer	Read-only	The number of RIP packet responses coming from non-RIP-configured ports.
snRtIpRipStatsResponseFromLoopback brcdIp.1.2.3.9.12 Syntax: Integer	Read-only	The number of RIP packet responses coming from loopback ports.
snRtIpRipStatsPacketRejected brcdIp.1.2.3.9.13 Syntax: Integer	Read-only	The number of RIP packets rejected.



# DVMRP MIB Definition

---

## In this chapter

- [Global DVMRP objects](#) . . . . . 515
- [DVMRP virtual interface table](#) . . . . . 517
- [DVMRP neighbor table](#) . . . . . 518
- [DVMRP route table](#) . . . . . 519
- [DVMRP routing next hop table](#) . . . . . 520
- [DVMRP virtual interface statistics table](#) . . . . . 521

## Global DVMRP objects

The following table displays the MIB objects of global Distance Vector Multicast Routing Protocol (DVMRP).

Name, OID, and syntax	Access	Description
snDvmrpVersion brcdIp.1.2.5.1.1 Syntax: DisplayString <b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.	Read-only	Shows the DVMRP version in the Layer 3 switch. There can be up to 255 characters in this object.
snDvmrpEnable brcdIp.1.2.5.1.2 Syntax: Integer	Read-write	Indicates if DVMRP is enabled on this Layer 3 switch: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)

Name, OID, and syntax	Access	Description
snDvmrpGenerationId brcdIp.1.2.5.1.3 Syntax: Integer32	Read-only	Shows the generation identifier for the routing process. This is used by neighboring Layer 3 switches to determine if pruning information should be resent.
<b>NOTE:</b> This object is not supported on the Brocade MLXe router, Brocade NetIron XMR, Brocade MLX, Brocade NetIron CES, and Brocade NetIron CER series devices.		
snDvmrpProbeInterval brcdIp.1.2.5.1.4 Syntax: Integer	Read-write	Defines how often neighbor probe messages are sent to the ALL-DVMRP-ROUTERS IP multicast group address. A Layer 3 switch's probe message lists those neighbor DVMRP routers from which it has received probes. Valid values: 5 – 30 seconds Default: 10 seconds
snDvmrpReportInterval brcdIp.1.2.5.1.5 Syntax: Integer	Read-write	Defines how often Layer 3 switches propagate their complete routing tables to other DVMRP neighbor routers. Valid values: 10 – 2000 seconds Default: 60 seconds
snDvmrpTriggerInterval brcdIp.1.2.5.1.6 Syntax: Integer	Read-write	Defines how often trigger updates, which reflect changes in the network topology, are sent. For example, changes in a network topology, including router up or down, or changes in the metric, would cause trigger updates to be sent. Valid values: 5 – 30 seconds Default: 5 seconds
snDvmrpNeighborRouterTimeOut brcdIp.1.2.5.1.7 Syntax: Integer	Read-write	Specifies how long a router waits before it determines that an attached DVMRP neighbor router is down. Valid values: 40 – 8000 seconds Default: 180 seconds
snDvmrpRouteExpireTime brcdIp.1.2.5.1.8 Syntax: Integer	Read-write	Defines how long a route is considered valid in the absence of the next route update. Valid values: 20 – 4000 seconds Default: 200 seconds
snDvmrpRouteDiscardTime brcdIp.1.2.5.1.9 Syntax: Integer	Read-write	Defines how long a router waits before it deletes a route. Valid values: 40 – 8000 seconds Default: 340 seconds
snDvmrpPruneAge brcdIp.1.2.5.1.10 Syntax: Integer	Read-write	Defines how long a prune state will remain in effect for a source-routed multicast tree. After the prune age period expires, flooding will resume. Valid values: 20 – 3600 seconds Default: 180 seconds

Name, OID, and syntax	Access	Description
snDvmpGraftRetransmitTime brcdIp.1.2.5.1.11 Syntax: Integer	Read-write	Defines how long a router that is sending a graft message will wait for the first graft acknowledgement from an upstream router before retransmitting that message. Subsequent retransmissions are sent at an interval twice that of the preceding interval. For NetIron platforms: <ul style="list-style-type: none"> <li>Valid values: 5 – 3600 seconds</li> <li>Default: 10 seconds</li> </ul> For FastIron platforms: <ul style="list-style-type: none"> <li>Valid values: 2 – 10 seconds</li> <li>Default: 3 seconds</li> </ul>
snDvmpDefaultRoute brcdIp.1.2.5.1.12 Syntax: IpAddress	Read-write	This is the IP address of a router that is connected to one of the directly attached subnets. If a multicast route is not present on the local router, this default route will be used for multicast forwarding. The “snDvmpEnable” object must be set to “enabled” before this object can be written.

## DVMRP virtual interface table

The DVMRP virtual interface table contains the router’s DVMRP virtual interfaces.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snDvmpVInterfaceTable brcdIp.1.2.5.1.13	None	The DVMRP virtual interface table.
snDvmpVInterfaceVifIndex brcdIp.1.2.5.1.13.1.1 Syntax: Integer	Read-only	The ifIndex value of this DVMRP virtual interface.
snDvmpVInterfaceType brcdIp.1.2.5.1.13.1.2 Syntax: Integer	Read-write	Indicates the type of this DVMRP virtual interface: <ul style="list-style-type: none"> <li>tunnel(1) – Tunnel interface, for which the interface is a querier.</li> <li>queries(2) – Tunnel interface, for which the interface is not a querier.</li> <li>subnet(3) – Physical interface, for which the interface is not a querier.</li> </ul>
snDvmpVInterfaceOperState brcdIp.1.2.5.1.13.1.3 Syntax: Integer	Read-only	Shows the current state of this DVMRP virtual interface: <ul style="list-style-type: none"> <li>up(1)</li> <li>down(2)</li> </ul>
snDvmpVInterfaceLocalAddress brcdIp.1.2.5.1.13.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the local end of this DVMRP virtual interface.
snDvmpVInterfaceRemoteAddress brcdIp.1.2.5.1.13.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the remote end of this DVMRP virtual interface. For a tunnel, enter the IP address of the neighboring router. For a subnet, enter the subnet address.

Name, OID, and syntax	Access	Description
snDvmpVInterfaceRemoteSubnet Mask brcdIp.1.2.5.1.13.1.6 Syntax: IpAddress	Read-only	Shows the subnet mask for a directly connected subnet. For a tunnel, this should be 0.0.0.0.
snDvmpVInterfaceMetric brcdIp.1.2.5.1.13.1.7 Syntax: Integer	Read-write	Defines the distance metric for this DVMRP virtual interface. The router uses the metric when establishing reverse paths to some networks on directly attached interfaces. Valid values: 1 – 31 hops Default: 1
snDvmpVInterfaceTtlThreshold brcdIp.1.2.5.1.13.1.8 Syntax: Integer	Read-write	Defines the minimum value required in a packet in order for the packet to be forwarded out of the interface. For example, if the TTL for an interface is set at 10, then only those packets with a TTL value of 10 or more are forwarded. Likewise, if an interface is configured with a TTL threshold value of 1, all packets received on that interface are forwarded. Valid values: 1 – 64 Default: 1
snDvmpVInterfaceAdvertiseLocal brcdIp.1.2.5.1.13.1.9 Syntax: Integer	Read-write	Determines if advertising of this local route is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)
snDvmpVInterfaceEncapsulation brcdIp.1.2.5.1.13.1.10 Syntax: Integer	Read-write	Indicates if the encapsulation of the DVMRP control packets when using IPINIP encapsulation is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snDvmpVInterfaceStatus brcdIp.1.2.5.1.13.1.11 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

## DVMRP neighbor table

The DVMRP neighbor table lists the router DVMRP neighbors, as discovered by the receiving neighbor probe messages.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.



Name, OID, and syntax	Access	Description
snDvmpNeighborTable brcdIp.1.2.5.1.14	None	The DVMRP neighbor table.
snDvmpNeighborEntryIndex brcdIp.1.2.5.1.14.1.1 Syntax: Integer32	Read-only	The table entry index.
snDvmpNeighborVifIndex brcdIp.1.2.5.1.14.1.2 Syntax: Integer32	Read-only	The value of VifIndex for the virtual interface used to reach this DVMRP neighbor.
snDvmpNeighborAddress brcdIp.1.2.5.1.14.1.3 Syntax: IpAddress	Read-only	Shows the IP address of the DVMRP neighbor for which this entry contains information.
snDvmpNeighborUpTime brcdIp.1.2.5.1.14.1.4 Syntax: Time ticks	Read-only	Shows the time since this DVMRP neighbor became a neighbor of the local router.
snDvmpNeighborExpiryTime brcdIp.1.2.5.1.14.1.5 Syntax: Time ticks	Read-only	Shows the number of seconds remaining before this DVMRP neighbor will be aged out.
snDvmpNeighborGenerationId brcdIp.1.2.5.1.14.1.6 Syntax: Integer32	Read-only	Shows the neighboring router generation identifier.
snDvmpNeighborMajorVersion brcdIp.1.2.5.1.14.1.7 Syntax: Integer	Read-only	Shows the neighboring router major DVMRP version number. Valid values: 0 – 255
snDvmpNeighborMinorVersion brcdIp.1.2.5.1.14.1.8 Syntax: Integer	Read-only	Shows the neighboring router minor DVMRP version number. Valid values: 0 – 255
snDvmpNeighborCapabilities brcdIp.1.2.5.1.14.1.9 Syntax: Integer32	Read-only	Describes the neighboring router capabilities. The following list shows the position of each bit: <ul style="list-style-type: none"> <li>• 3 – Trace bit. If on, neighbor can handle mtrace requests.</li> <li>• 2 – GenerationID bit. If on, the neighbor sends its generationID in probe messages.</li> <li>• 1 – Prune bit. If on, the neighbor supports pruning.</li> <li>• 0 – Leaf bit. If on, the neighbor has only one interface with other neighbors.</li> </ul>

## DVMRP route table

DVMRP uses a routing table instead of the unicast routing table. The DVMRP route table contains information on the DVMRP source and destination routes.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snDvmrpRouteTable brcdIp.1.2.5.1.15	None	The DVMRP route table.
snDvmrpRouteEntryIndex brcdIp.1.2.5.1.15.1.1 Syntax: Integer32	Read-only	The table entry index.
snDvmrpRouteSource brcdIp.1.2.5.1.15.1.2 Syntax: IpAddress	Read-only	Shows the network address of the source. This object plus the value of the “snDvmrpRouteSourceMask” object identifies the sources of this entry.
snDvmrpRouteSourceMask brcdIp.1.2.5.1.15.1.3 Syntax: IpAddress	Read-only	Shows the network mask of the source. This object plus the value of the “snDvmrpRouteSource” object identifies the sources of this entry.
snDvmrpRouteUpstreamNeighbor brcdIp.1.2.5.1.15.1.4 Syntax: IpAddress	Read-only	Shows the address of the upstream neighbor (for example, RPF neighbor) from which IP datagrams were received.
snDvmrpRouteVifIndex brcdIp.1.2.5.1.15.1.5 Syntax: Integer32	Read-only	The value of snDvmrpVInterfaceVifIndex for the virtual interface on which IP datagrams sent by these sources are received.
snDvmrpRouteMetric brcdIp.1.2.5.1.15.1.6 Syntax: Integer32	Read-only	Shows the number of hops to the source subnet.
snDvmrpRouteExpiryTime brcdIp.1.2.5.1.15.1.7 Syntax: Time ticks	Read-only	Shows the amount of time remaining before this entry will be aged out.

## DVMRP routing next hop table

The DVMRP routing next hop table contains information on the next hop for routing IP multicast datagrams.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snDvmrpRouteNextHopTable brcdIp.1.2.5.1.16	None	The DVMRP routing next hop table.
snDvmrpRouteNextHopSource brcdIp.1.2.5.1.16.1.1 Syntax: IpAddress	Read-only	Shows the network mask address of the source. This object plus the “snDvmrpRouteNextHopSourceMask” object identify the sources of the next hop.
snDvmrpRouteNextHopSourceMask brcdIp.1.2.5.1.16.1.2 Syntax: IpAddress	Read-only	Shows the network mask of the source. This object plus the “snDvmrpRouteNextHopSource” object identify the sources of the next hop.

Name, OID, and syntax	Access	Description
snDvmrpRouteNextHopVifIndex brcdIp.1.2.5.1.16.1.3 Syntax: Integer32	Read-only	The snDvmrpVInterfaceVifIndex value of the virtual interface for the outgoing interface for this next hop.
snDvmrpRouteNextHopType brcdIp.1.2.5.1.16.1.4 Syntax: Integer	Read-only	Identifies the type of router for the next hop: <ul style="list-style-type: none"> <li>leaf(1) – There are no neighbors at the next hop.</li> <li>branch(2) – Neighbors are attached to the next hop.</li> </ul>

## DVMRP virtual interface statistics table

The DVMRP virtual interface statistics table provides information about the DVMRP routes.

### NOTE

The following table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snDvmrpVifStatTable brcdIp.1.2.5.1.17	None	The DVMRP virtual interface statistics table.
snDvmrpVifStatVifIndex brcdIp.1.2.5.1.17.1.1 Syntax: Integer	Read-only	The ifIndex value of this DVMRP virtual interface.
snDvmrpVifStatInPkts brcdIp.1.2.5.1.17.1.2 Syntax: Counter32	Read-only	Shows the number of packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutPkts brcdIp.1.2.5.1.17.1.3 Syntax: Counter32	Read-only	Shows the number of packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatInOctets brcdIp.1.2.5.1.17.1.4 Syntax: Counter32	Read-only	Shows the number of octets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutOctets brcdIp.1.2.5.1.17.1.5 Syntax: Counter32	Read-only	Shows the number of octets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatInProbePkts brcdIp.1.2.5.1.17.1.6 Syntax: Counter32	Read-only	Shows the number of probe packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutProbePkts brcdIp.1.2.5.1.17.1.7 Syntax: Counter32	Read-only	Shows the number of probe packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatDiscardProbePkts brcdIp.1.2.5.1.17.1.8 Syntax: Counter32	Read-only	Shows the number of probe packets that have been discarded by the DVMRP virtual interface.

Name, OID, and syntax	Access	Description
snDvmpVlFStatInRtUpdatePkts brcdIp.1.2.5.1.17.1.9 Syntax: Counter32	Read-only	Shows the number of route update packets that have arrived on the DVMRP virtual interface.
snDvmpVlFStatOutRtUpdatePkts brcdIp.1.2.5.1.17.1.10 Syntax: Counter32	Read-only	Shows the number of route update packets that have been sent on the DVMRP virtual interface.
snDvmpVlFStatDiscardRtUpdatePkts brcdIp.1.2.5.1.17.1.11 Syntax: Counter32	Read-only	Shows the number of route update packets that have been discarded by the DVMRP virtual interface.
snDvmpVlFStatInGraftPkts brcdIp.1.2.5.1.17.1.12 Syntax: Counter32	Read-only	Shows the number of graft packets that have arrived on the DVMRP virtual interface.
snDvmpVlFStatOutGraftPkts brcdIp.1.2.5.1.17.1.13 Syntax: Counter32	Read-only	Shows the number of graft packets that have been sent on the DVMRP virtual interface.
snDvmpVlFStatDiscardGraftPkts brcdIp.1.2.5.1.17.1.14 Syntax: Counter32	Read-only	Shows the number of graft packets that have been discarded by the DVMRP virtual interface.
snDvmpVlFStatInGraftAckPkts brcdIp.1.2.5.1.17.1.15 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have arrived on the DVMRP virtual interface.
snDvmpVlFStatOutGraftAckPkts brcdIp.1.2.5.1.17.1.16 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have been sent on the DVMRP virtual interface.
snDvmpVlFStatDiscardGraftAckPkts brcdIp.1.2.5.1.17.1.17 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have been discarded by the DVMRP virtual interface.
snDvmpVlFStatInPrunePkts brcdIp.1.2.5.1.17.1.18 Syntax: Counter32	Read-only	Shows the number of prune packets that have arrived on the DVMRP virtual interface.
snDvmpVlFStatOutPrunePkts brcdIp.1.2.5.1.17.1.19 Syntax: Counter32	Read-only	Shows the number of prune packets that have been sent on the DVMRP virtual interface.
snDvmpVlFStatDiscardPrunePkts brcdIp.1.2.5.1.17.1.20 Syntax: Counter32	Read-only	Shows the number of prune packets that have been discarded by the DVMRP virtual interface.

# FSRP MIB Definition

---

## In this chapter

- [FSRP objects](#) ..... 523
- [FSRP global variables](#) ..... 523
- [FSRP interface table](#) ..... 524

## FSRP objects

The Foundry Standby Routing Protocol (FSRP) allows alternate paths to be provided to a host. To provide path redundancy between given hosts, a virtual router is created. To create a virtual router, unique IP addresses are assigned to ports on existing routers in the network routers that could provide a path between the given hosts.

This chapter presents the objects for FSRP. You must determine if your device supports FSRP before using the MIB objects for FSRP traps.

---

### NOTE

The FSRP MIBs are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series, and Brocade FastIron devices.

---

## FSRP global variables

The following MIB objects apply to all FSRP interfaces.

Name, OID, and syntax	Access	Description
snFsrpGroupOperMode brcdIp.1.2.7.1.1 Syntax: Integer	Read-write	Indicates if FSRP is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <b>NOTE:</b> Do not enable both FSRP and VRRP. It is recommended that you use only one of these router redundancy protocols on a Layer 3 switch. Default: disabled(0)
snFsrpIfStateChangeTrap brcdIp.1.2.7.1.2 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate FSRP interface state change traps: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)

## FSRP interface table

The FSRP interface table describes the configuration of FSRP interfaces.

Name, OID, and syntax	Access	Description
snFsrplfTable brcdIp.1.2.7.2.1	None	The FSRP interface table.
snFsrplfPort brcdIp.1.2.7.2.1.1.1 Syntax: Integer	Read-only	Identifies the physical router port number of this FSRP interface.
snFsrplfIpAddress brcdIp.1.2.7.2.1.1.2 Syntax: IpAddress	Read-only	Identifies the IP address of the physical router port of this interface.
snFsrplfVirRtrIpAddr brcdIp.1.2.7.2.1.1.3 Syntax: IpAddress	Read-write	Identifies the IP address of the virtual router for the interface. The virtual router IP address must be configured on the interface before the redundant router function can operate on the interface. This address must be the same on all the routers that are going to participate in the redundant router function on a given subnet.
snFsrplfOtherRtrIpAddr brcdIp.1.2.7.2.1.1.4 Syntax: IpAddress	Read-write	Identifies the IP address of the other router on this IP subnet. The other router is the router that operates FSRP and to which the keepalive message must be sent by this router. This object must be configured in order for FSRP to work correctly.
snFsrplfPreferLevel brcdIp.1.2.7.2.1.1.5 Syntax: Integer	Read-write	Decides which router should become the active router for the interface. The active router is the one with the higher priority. A higher number indicates a higher priority. Valid values: 1 – 255 Default: 100
snFsrplfTrackPortMask brcdIp.1.2.7.2.1.1.6 Syntax: PortMask <b>NOTE:</b> This object is not supported on all the Brocade NetIron and Brocade FastIron devices.	Read-write	Specifies the identity of the physical port whose state is to be monitored. Each bit is a port of the system. If the object is configured then the preference level of the interface is adjusted dynamically depending on the state of the track port. The preference level of the interface is reduced by value of preference level parameter when the track port state first changes from Up to Down. When the track port comes up, the interface's preference level is increased by the amount specified by the preference level. Default value: 0
snFsrplfRowStatus brcdIp.1.2.7.2.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

Name, OID, and syntax	Access	Description
snFsrplfState brcdIp.1.2.7.2.1.1.8 Syntax: Integer	Read-only	Specifies the state of the FSRP router interface: <ul style="list-style-type: none"> <li>• init(0) – Initialization state</li> <li>• negotiating(1) – Negotiating state</li> <li>• standby(2) – Standby state</li> <li>• active(3) – Active state</li> </ul>
snFsrplfKeepAliveTime brcdIp.1.2.7.2.1.1.9 Syntax: Integer	Read-write	Defines the heartbeat of the interface. Valid values: 1 – 120 seconds Default: 3 seconds
snFsrplfRouterDeadTime brcdIp.1.2.7.2.1.1.10 Syntax: Integer	Read-write	Defines the hold time of the FSRP router. Valid values: 3 – 255 seconds Default: 9 seconds
snFsrplfChassisTrackPortMask brcdIp.1.2.7.2.1.1.11 Syntax: OCTET STRING	Read-write	This object is replaced by the “snFsrplfTrackPortList” object. This object shows the chassis router FSRP track port membership. It specifies the identity of the physical port whose state is to be monitored. Each bit is a port of the system. Valid values: Up to 32 octets Default: 0 If this object is configured, then the preference level of this interface will be adjusted dynamically, depending on the state of the track port. The preference level is configured in the “snFsrplfPreferLevel” object. The interface’s preference level is reduced by the value of the preference level parameter when the track port states first changes from up to down. When the track port comes up, the interface’s preference level is increased by the amount specified by the preference level.
snFsrplfTrackPortList brcdIp.1.2.7.2.1.1.12 Syntax: OCTET STRING	Read-write	Shows the router FSRP physical track port membership. It specifies the identity of the physical port whose state is to be monitored. Each port index is a 16-bit integer in big-endian order. The first 8-bit is the slot number, the other eight bits is the port number. Default: 0 length octet string If this object is configured, then the preference level of this interface will be adjusted dynamically, depending on the state of the track port. The preference level is configured in the “snFsrplfPreferLevel” object. The interface’s preference level is reduced by the value of the preference level parameter when the track port states first changes from up to down. When the track port comes up, the interface’s preference level is increased by the amount specified by the preference level.





# PIM MIB Definition

---

## In this chapter

- [Common PIM objects](#) ..... 527
- [PIM virtual interface table](#) ..... 528
- [PIM neighbor table](#) ..... 529
- [PIM virtual interface statistics table](#) ..... 530
- [PIM-SM](#) ..... 532

## Common PIM objects

---

### NOTE

The following section describes the Protocol Independent Multicast (PIM) MIB objects that are supported on the Unified IP MIB. The following objects in this chapter are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

The following table presents objects that are common to all PIM interfaces.

Name, OID, and syntax	Access	Description
snPimEnable brcdIp.1.2.9.1.1 Syntax: RtrStatus	Read-write	Determines if PIM is enabled on this Layer 3 switch: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0) The remaining objects apply only if this object is set to enabled(1).
snPimNeighborRouterTimeout brcdIp.1.2.9.1.2 Syntax: Integer	Read-write	Specifies the number of seconds the PIM Layer 3 switch waits before it considers a neighbor to be absent. Absence of PIM hello messages from a neighboring Layer 3 switch indicates that a neighbor is not present. Valid values: 60 – 8000 seconds Default: 180 seconds

Name, OID, and syntax	Access	Description
snPimPruneTime brcdIp.1.2.9.1.4 Syntax: Integer	Read-write	<p>Specifies the number of seconds that a PIM Layer 3 switch will maintain a prune state for a forwarding entry. The first multicast that the Layer 3 switch receives from an interface is forwarded to all other PIM interfaces on the Layer 3 switch. If there is no presence of groups on that interface, the leaf node sends a prune message upstream and stores a prune state. This prune state travels up the tree and installs a prune state.</p> <p>A prune state is maintained until the prune timer expires or a graft message is received for the forwarding entry.</p> <p>Valid values: 10 – 3600 seconds Default: 60 seconds</p>
snPimGraftRetransmitTime brcdIp.1.2.9.1.5 Syntax: Integer	Read-write	<p>Specifies the number of seconds between the transmission of graft messages.</p> <p>A graft message is sent by a Layer 3 switch to cancel a prune state. When a Layer 3 switch receives a graft message, the Layer 3 switch responds with a Graft ACK (acknowledge) message. If this Graft ACK message is lost, the Layer 3 switch that sent the graft message will resend it.</p> <p>For NetIron platforms:</p> <ul style="list-style-type: none"> <li>Valid values: 2 – 3600 seconds</li> <li>Default: 180 seconds</li> </ul> <p>For FastIron platforms:</p> <ul style="list-style-type: none"> <li>Valid values: 2 – 10 seconds</li> <li>Default: 3 seconds</li> </ul>
snPimInactivityTime brcdIp.1.2.9.1.6 Syntax: Integer	Read-write	<p>Defines how long a forwarding entry can remain unused before the Layer 3 switch deletes it. The Layer 3 switch deletes a forwarding entry if the entry is not used to send multicast packets.</p> <p>This object is used only to keep the forwarding entries for the active sessions.</p> <p>Valid values: 10 – 3600 seconds Default: 180 seconds</p>

## PIM virtual interface table

The PIM virtual interface table lists the PIM virtual interfaces on a Layer 3 switch.

### NOTE

The PIM virtual interface table is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snPimVInterfaceTable brcdIp.1.2.9.1.7	None	The PIM virtual interface table.
snPimVInterfaceVifIndex brcdIp.1.2.9.1.7.1.1 Syntax: Integer	Read-only	<p>The ifIndex value of this PIM virtual interface. There can be up to 48 entries.</p> <p>Valid values: 1 - 48</p>

Name, OID, and syntax	Access	Description
snPimVInterfaceType brcdIp.1.2.9.1.7.1.2 Syntax: Integer	Read-write	Indicates the type of PIM virtual interface the row represents: <ul style="list-style-type: none"> <li>tunnel(1)</li> <li>subnet(2) or a physical interface</li> </ul>
snPimVInterfaceLocalAddress brcdIp.1.2.9.1.7.1.3 Syntax: IpAddress	Read-write	Indicates the IP address of the local end of the interface being configured. IP tunneling must also be enabled and defined on the destination Layer 3 switch interface.
snPimVInterfaceLocalSubnetMask brcdIp.1.2.9.1.7.1.4 Syntax: IpAddress	Read-only	Shows the network mask for the IP address of the PIM virtual interface. For a tunnel, this should be 0.0.0.0.
snPimVInterfaceRemoteAddress brcdIp.1.2.9.1.7.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the remote end of this PIM virtual interface.
snPimVInterfaceDR brcdIp.1.2.9.1.7.1.6 Syntax: IpAddress	Read-only	Defines the designated Layer 3 switch on this PIM virtual interface. For point-to-point interfaces, this object has the value 0.0.0.0.
snPimVInterfaceTtlThreshold brcdIp.1.2.9.1.7.1.7 Syntax: Integer	Read-write	Determines the minimum time-to-live (TTL) value to forward the packets out of this interface. Valid values: 1 – 31 Default: 1
snPimVInterfaceStatus brcdIp.1.2.9.1.7.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a “bad value” error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snPimVInterfaceMode brcdIp.1.2.9.1.7.1.9 Syntax: Integer	Read-write	Shows the configured mode of this PIM interface: <ul style="list-style-type: none"> <li>dense(1) – Traffic is initially flooded to all PIM interface neighbors. Branches that do not want the data are pruned.</li> <li>sparse(2) – PIM interface neighbors must join the multicast group if they want to receive the traffic.</li> </ul> Default: dense(1)

## PIM neighbor table

The PIM neighbor table is a conceptual table that lists the PIM neighbors of the Layer 3 switch.

### NOTE

This PIM neighbor table is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snPimNeighborTable brcdIp.1.2.9.1.8	None	The PIM neighbor table.
snPimNeighborEntryIndex brcdIp.1.2.9.1.8.1.1 Syntax: Integer32	Read-only	The table entry index.
snPimNeighborVifIndex brcdIp.1.2.9.1.8.1.2 Syntax: Integer32	Read-only	Shows the value of VifIndex for the virtual interface used to reach this PIM neighbor.
snPimNeighborAddress brcdIp.1.2.9.1.8.1.3 Syntax: IpAddress	Read-only	Shows the IP address of this PIM neighbor.
snPimNeighborUpTime brcdIp.1.2.9.1.8.1.4 Syntax: Time ticks	Read-only	Indicates the last time this PIM neighbor became a neighbor of the local Layer 3 switch.
snPimNeighborExpiryTime brcdIp.1.2.9.1.8.1.5 Syntax: Time ticks	Read-only	Displays the time remaining before this PIM neighbor will be aged out.

## PIM virtual interface statistics table

The PIM virtual interface statistics table lists the PIM virtual interface statistical counters of the Layer 3 switch.

### NOTE

This PIM virtual interface statistics table is not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snPimVifStatTable brcdIp.1.2.9.1.9	None	The PIM virtual interface statistics table.
snPimVifStatVifIndex brcdIp.1.2.9.1.9.1.1 Syntax: Integer	Read-only	The ifIndex value of this PIM virtual interface. There can be 32 entries. Valid values: 1 - 32
snPimVifStatInJoinPkts brcdIp.1.2.9.1.9.1.2 Syntax: Counter32	Read-only	Shows the number of join and prune messages sent or received on the interface. <b>NOTE:</b> Unlike PIM Dense, PIM Sparse uses the same messages for joins and prunes.
snPimVifStatOutJoinPkts brcdIp.1.2.9.1.9.1.3 Syntax: Counter32	Read-only	Indicates the number of join packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardJoinPkts brcdIp.1.2.9.1.9.1.4 Syntax: Counter32	Read-only	Shows the number of join packets that have been discarded by the PIM virtual interface.

Name, OID, and syntax	Access	Description
snPimVifStatInPrunePkts brcdIp.1.2.9.1.9.1.5 Syntax: Counter32	Read-only	Shows the number of prune packets that have arrived on the PIM virtual interface.
snPimVifStatOutPrunePkts brcdIp.1.2.9.1.9.1.6 Syntax: Counter32	Read-only	Shows the number of prune packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardPrunePkts brcdIp.1.2.9.1.9.1.7 Syntax: Counter32	Read-only	Shows the number of prune packets that have been discarded by the PIM virtual interface.
snPimVifStatInAssertPkts brcdIp.1.2.9.1.9.1.8 Syntax: Counter32	Read-only	Shows the number of assert packets that have arrived on the PIM virtual interface.
snPimVifStatOutAssertPkts brcdIp.1.2.9.1.9.1.9 Syntax: Counter32	Read-only	Shows the number of assert packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardAssertPkts brcdIp.1.2.9.1.9.1.10 Syntax: Counter32	Read-only	Shows the number of assert packets that have been discarded by the PIM virtual interface.
snPimVifStatInHelloPkts brcdIp.1.2.9.1.9.1.11 Syntax: Counter32	Read-only	Shows the number of hello packets that have arrived on the PIM virtual interface.
snPimVifStatOutHelloPkts brcdIp.1.2.9.1.9.1.12 Syntax: Counter32	Read-only	Shows the number of hello packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardHelloPkts brcdIp.1.2.9.1.9.1.13 Syntax: Counter32	Read-only	Shows the number of hello packets that have been discarded by the PIM virtual interface.
snPimVifStatInGraftPkts brcdIp.1.2.9.1.9.1.14 Syntax: Counter32	Read-only	Shows the number of graft packets that have arrived on the PIM virtual interface.
snPimVifStatOutGraftPkts brcdIp.1.2.9.1.9.1.15 Syntax: Counter32	Read-only	Shows the number of graft packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardGraftPkts brcdIp.1.2.9.1.9.1.16 Syntax: Counter32	Read-only	Shows the number of graft packets that have been discarded by the PIM virtual interface.
snPimVifStatInGraftAckPkts brcdIp.1.2.9.1.9.1.17 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have arrived on the PIM virtual interface.
snPimVifStatOutGraftAckPkts brcdIp.1.2.9.1.9.1.18 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardGraftAckPkts brcdIp.1.2.9.1.9.1.19 Syntax: Counter32	Read-only	Shows the number of graft acknowledge packets that have been discarded by the PIM virtual interface.

## PIM-SM

The following tables are available for the PIM Sparse feature.

### NOTE

The following tables in this section are not supported on the Brocade MLXe router, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Description
snPimJoinPruneInterval brcdIp.1.2.9.2.1 Syntax: Integer	Read-write	The default interval in seconds at which periodic PIM Sparse join and prune messages are to be sent. These messages inform other PIM Sparse Layer 3 switches about clients who want to become receivers (join) or stop being receivers (prune) for PIM Sparse groups. Valid values: 10 – 3600 seconds Default: 60 seconds

### PIM Sparse: candidate BSR table

The candidate Bootstrap Router (BSR) table contains information about BSRs that are candidates to become the active BSR for the domain. The BSR distributes Rendezvous Point (RP) information to the other PIM Sparse routers within the domain. Each PIM Sparse domain has one active BSR. For redundancy, you can configure ports on multiple routers as candidate BSRs. The PIM Sparse protocol uses an election process to select one of the candidate BSRs as the active BSR for the domain. The BSR with the highest BSR priority is elected. If the priorities result in a tie, the candidate BSR interface with the highest IP address is elected.

Name, OID, and syntax	Access	Description
snPimCandidateBSRTable brcdIp.1.2.9.2.2	None	The candidate bootstrap router (BSR) table.
snPimCandidateBSRPortID brcdIp.1.2.9.2.2.1.1 Syntax: Integer32	Read-write	Identifies the IP address of the PIM interface: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number</li> <li>Bit 8 to bit 11 – Slot number</li> </ul>
snPimCandidateBSRIPAddress brcdIp.1.2.9.2.2.1.2 Syntax: IpAddress	Read-only	Shows the unicast IP address of the candidate BSR.
snPimCandidateBSRHashMaskLen brcdIp.1.2.9.2.2.1.3 Syntax: Integer	Read-write	Indicates the hash mask value for this Layer 3 switch as a candidate bootstrap router. Valid values: 1 – 32
snPimCandidateBSRPreference brcdIp.1.2.9.2.2.1.4 Syntax: Integer	Read-write	Indicates the preference value for this Layer 3 switch as a candidate bootstrap router. Valid values: 0 – 255 Default: 100

### PIM RP set table

The PIM RP set table contains information about candidate Rendezvous Points (RPs) for IP multicast groups. When the local Layer 3 switch is the BSR, this information is obtained from the advertisements received from the candidate-RP. When the local Layer 3 switch is not the BSR, this information is obtained from the received RP-Set messages.

Name, OID, and syntax	Access	Description
snPimRPSetTable brcdIp.1.2.9.2.3	None	The PIM RP set table.
snPimRPSetGroupAddress brcdIp.1.2.9.2.3.1.1 Syntax: IpAddress	Read-only	Shows the IP multicast group address. This object plus snPimRPSetMask forms the group prefix for the Ccandidate-RP.
snPimRPSetMask brcdIp.1.2.9.2.3.1.2 Syntax: IpAddress	Read-only	Shows the IP multicast group address mask. This object plus snPimRPSetGroupAddress forms the group prefix for the candidate-RP.
snPimRPSetIPAddress brcdIp.1.2.9.2.3.1.3 Syntax: IpAddress	Read-only	Shows the IP address of the candidate-RP.
snPimRPSetHoldTime brcdIp.1.2.9.2.3.1.4 Syntax: Integer	Read-only	Shows the holdtime, in seconds, of a candidate-RP. If the local router is not the BSR, this value is 0. Valid values: 0 - 255

## PIM RP candidate table

The PIM RP candidate table lists the IP multicast groups for which the local router is to advertise itself as a candidate-RP. If this table is empty, the local router will advertise itself as a candidate-RP for all groups. The snPimEnable object must be "enabled" before this table is read or written.

Name, OID, and syntax	Access	Description
snPimCandidateRPTable brcdIp.1.2.9.2.4	None	The PIM RP candidate table.
snPimCandidateRPGroupAddress brcdIp.1.2.9.2.4.1.1 Syntax: IpAddress	Read-only	Shows the IP multicast group address mask. This object combined with snPimCandidateRPMask forms the group prefix for which the local router will advertise itself as a candidate-RP.
snPimCandidateRPMask brcdIp.1.2.9.2.4.1.2 Syntax: IpAddress	Read-only	Shows the multicast group address mask. This object combined with snPimCandidateRPGroupAddress forms the group prefix for which the local router will advertise itself as a candidate-RP.
snPimCandidateRPIPAddress brcdIp.1.2.9.2.4.1.3 Syntax: IpAddress	Read-write	Indicates the unicast IP address of the interface that will be advertised as a candidate-RP.
snPimCandidateRPRowStatus brcdIp.1.2.9.2.4.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>





# IGMP MIB Definition

## In this chapter

- [General IGMP objects](#) ..... 535
- [IGMP interface table](#) ..... 536
- [IGMP static group table](#) ..... 536

## General IGMP objects

### NOTE

This section describes the Internet Group Management Protocol (IGMP) MIB objects that are supported in the Unified IP MIB. The objects in this chapter are not supported on the Brocade MLXe, Brocade MLX, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

The following general IGMP objects are available in all devices.

Name, OID, and syntax	Access	Description
snIcmpQueryInterval brcdIp.1.2.6.1.1 Syntax: Integer	Read-write	<p>Specifies how often the Layer 3 switch sends out IGMP host query packets to query an interface for group membership. Valid values: 0 – 3600 seconds</p> <p><b>NOTE:</b> For FastIron platforms, the configuration ranges from 10 through 3600 seconds.</p> <p>Default: 60 seconds</p> <p>For a Layer 3 switch, the “snDvmrpEnable” object must be set to “enabled(1)” before this object can be written.</p> <p>For a Layer 2 Switch, the “snSwGroupIpMcastMode” object must be set to “enabled(1)” and the “snSwIpMcastQuerierMode” object must be set to “querier(1)” before this object can be written.</p>
snIcmpGroupMembershipTime brcdIp.1.2.6.1.2 Syntax: Integer	Read-write	<p>Specifies how many seconds an IP multicast group can remain on a Layer 3 switch interface in the absence of a group report. Valid values: 0 – 7200 seconds</p> <p><b>NOTE:</b> For FastIron platforms, the configuration ranges from 20 through 7200 seconds.</p> <p>Default: 140 seconds</p> <p>For a Layer 3 switch, the “snDvmrpEnable” object must be set to “enabled(1)” before this object can be written.</p> <p>For a Layer 2 Switch, the “snSwGroupIpMcastMode” object must be set to “enabled(1)” before this object can be written.</p>

## IGMP interface table

The IGMP interface table contains the group membership information of a port.

Name, OID, and syntax	Access	Description
snIgmplfTable brcdIp.1.2.6.1.3	None	The IGMP interface table.
snIgmplfEntryIndex brcdIp.1.2.6.1.3.1.1 Syntax: Integer32	Read-only	The table entry index.
snIgmplfPortNumber brcdIp.1.2.6.1.3.1.2 Syntax: Integer32	Read-only	Shows the port number (interface) on which the group was learned.
snIgmplfGroupAddress brcdIp.1.2.6.1.3.1.3 Syntax: IpAddress	Read-only	Shows the group's IP address learned from the interface.
snIgmplfGroupAge brcdIp.1.2.6.1.3.1.4 Syntax: Integer32	Read-only	Specifies how many seconds the Layer 3 switch will wait for an IGMP response from an interface before concluding that the group member on that interface is down. The switch will then begin to remove the interface from the group. Valid values: 1 – 10 seconds Default: 5 seconds

## IGMP static group table

The IGMP static group table contains a list of IGMP static group entries. This table is available when IP Multicast Traffic Reduction is enabled on a Layer 2 Switch. The snSwGroupIpMcastMode MIB object enables or disables IP multicast using SNMP.

By default, Layer 2 Switches forward all IP multicast traffic out of all ports except the port on which the traffic was received. To reduce multicast traffic through the Layer 2 Switch, you can enable IP Multicast Traffic Reduction. This feature configures the Layer 2 Switch to forward multicast traffic only on the ports attached to multicast group members. The Layer 2 Switch determines the ports that are attached to multicast group members based on entries in the IGMP table. Each entry in the table consists of an IP multicast group address and the Layer 2 Switch ports from which the Layer 2 Switch has received Group Membership reports for that group.

After you enable IP Multicast Traffic Reduction, when the Layer 2 Switch receives traffic for an IP multicast group, the Layer 2 Switch looks in the IGMP table for an entry for that group. If the Layer 2 Switch finds an entry, the Layer 2 Switch forwards the group traffic out of the ports listed in the group entry. If the table does not contain an entry for the group, the Layer 2 Switch broadcasts the traffic.

The IGMP table is populated by receipt of Group Membership messages from IP multicast group members. Each Group Membership message contains the member's IP address and the group address.

Name, OID, and syntax	Access	Description
snIcmpStaticGroupTable brcdIp.1.2.6.1.4	None	The IGMP static group table.
snIcmpStaticGroupIfIndex brcdIp.1.2.6.1.4.1.1 Syntax: Integer32	Read-only	Shows the interface for which the group was configured.
snIcmpStaticGroupAddress brcdIp.1.2.6.1.4.1.2 Syntax: IpAddress	Read-only	Shows the IP address for the group.
snIcmpStaticGroupPortList brcdIp.1.2.6.1.4.1.3 Syntax: OCTET STRING	Read-write	Contains a list of ports that are members of the static group. Each port contains a 16-bit integer ifIndex.
snIcmpStaticGroupRowStatus brcdIp.1.2.6.1.4.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• other(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>



## QoS Profile Group

---

### In this chapter

- QoS profile table ..... 539
- QoS bind table ..... 539
- DOS attack statistics ..... 540
- DOS attack port table ..... 540
- Authorization and accounting ..... 541

### QoS profile table

The following table contains the configuration of QoS profile groups.

Name, OID, and syntax	Access	Description
snQosProfileTable brcdIp.1.1.3.14.1	None	The QoS profile table.
snQosProfileIndex brcdIp.1.1.3.14.1.1.1 Syntax: Integer	Read-only	The table index of the QoS Profile. There can be up to four profiles in this table.
snQosProfileName brcdIp.1.1.3.14.1.1.2 Syntax: DisplayString	Read-write	Shows the name of the QoS profile. Valid values: Up to 32 characters
snQosProfileRequestedBandwidth brcdIp.1.1.3.14.1.1.3 Syntax: Integer	Read-write	Shows the requested bandwidth for the QoS profile.
snQosProfileCalculatedBandwidth brcdIp.1.1.3.14.1.1.4 Syntax: Integer	Read-only	Shows the calculated bandwidth of the QoS profile.

### QoS bind table

The following table binds 802.1p tags to the entries in the QoS profile table.

Name, OID, and syntax	Access	Description
snQosBindTable brcdIp.1.1.3.14.2	None	The QoS bind table.
snQosBindIndex brcdIp.1.1.3.14.2.1.1 Syntax: Integer	Read-only	The table index of the QoS Bind.
snQosBindPriority brcdIp.1.1.3.14.2.1.2 Syntax: Integer32	Read-only	Shows the QoS bind priority.
snQosBindProfileIndex brcdIp.1.1.3.14.2.1.3 Syntax: Integer	Read-write	An index that serves as a pointer to the index of the <a href="#">"snQosProfileTable"</a> .

## DOS attack statistics

The following objects provide denial of service (DOS) attack statistics through SNMP.

Name, OID, and syntax	Access	Description
snDosAttackICMPDropCount brcdIp.1.1.3.14.3.1.1 Syntax: Counter32	Read-only	Provides the contents of the ICMP drop counter.
snDosAttackICMPBlockCount brcdIp.1.1.3.14.3.1.2 Syntax: Counter32	Read-only	Provides the contents of the ICMP block counter.
snDosAttackSYNDropCount brcdIp.1.1.3.14.3.1.3 Syntax: Counter32	Read-only	Provides the contents of the SYN drop counter.
snDosAttackSYNBlockCount brcdIp.1.1.3.14.3.1.4 Syntax: Counter32	Read-only	Provides the contents of the SYN block counter.

## DOS attack port table

The following objects have been created to filter traffic for DOS-attacks through SNMP.

### NOTE

The DOS attack port MIBs are supported on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices.

Name, OID, and syntax	Access	Description
snDosAttackPortTable brcdIp.1.1.3.14.3.2 Syntax: Sequence of snDosAttackPortEntry	None	The denial of service attack port table.
snDosAttackPort brcdIp.1.1.3.14.3.2.1.1 Syntax: Integer32	Read-only	The index value of a port.
snDosAttackPortICMPDropCounter brcdIp.1.1.3.14.3.2.1.2 Syntax: Counter32	Read-only	The value of the ICMP drop counter.
snDosAttackPortICMPBlockCounter brcdIp.1.1.3.14.3.2.1.3 Syntax: Counter32	Read-only	The value of the ICMP block counter.
snDosAttackPortSYNDropCounter brcdIp.1.1.3.14.3.2.1.4 Syntax: Counter32	Read-only	The value of the SYN drop counter.
snDosAttackPortSYNBlockCounter brcdIp.1.1.3.14.3.2.1.5 Syntax: Counter32	Read-only	The value of the SYN block counter.

## Authorization and accounting

The following objects are for authorization and accounting functions.

Name, OID, and syntax	Access	Description
snAuthorizationCommandMethods brcdIp.1.1.3.15.2.1 Syntax: OCTET STRING	Read-write	Specifies the sequence of authorization methods. This object can have zero to three octets. Each octet represents a method to authorize the user command. Each octet has the following value: <ul style="list-style-type: none"> <li>radius(2) – Authorize by the requesting RADIUS server</li> <li>tacplus(5) – Authorize by the requesting TACACS+ server</li> <li>none(6) – Skip authorization</li> </ul> Setting a zero length octet string invalidates all previous authorization methods.
snAuthorizationCommandLevel brcdIp.1.1.3.15.2.2 Syntax: IpAddress	Read-write	Specifies the commands that must be authorized. Any command that is equal to or less than the selected level will be authorized: <ul style="list-style-type: none"> <li>level(0) – Privilege level 0</li> <li>level(4) – Privilege level 4</li> <li>level(5) – Privilege level 5</li> </ul>

Name, OID, and syntax	Access	Description
snAuthorizationExec brcdIp.1.1.3.15.2.3 Syntax: OCTET STRING	Read-write	Shows the sequence of authorization methods for EXEC programs. This object can have zero to three octets. Each octet represents a method for Telnet or SSH login authorization. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>radius(2) – Send EXEC authorization request to the RADIUS server .</li> <li>tacplus(5) – Send EXEC authorization request to the TACACS+ server .</li> <li>none(6) – No EXEC authorization method.</li> </ul> Setting a zero length octet string invalidates all authorization methods.
snAccountingCommandMethods brcdIp.1.1.3.15.3.1 Syntax: OCTET STRING	Read-write	Shows a sequence of accounting methods. This object can have zero to three octets. Each octet represents an accounting method. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>radius(2) – Send accounting information to the RADIUS server.</li> <li>tacplus(5) – Send accounting information to the TACACS+ server.</li> <li>none(6) – No accounting method.</li> </ul> Setting a zero length octet string invalidates all authorization methods.
snAccountingCommandLevel brcdIp.1.1.3.15.3.2 Syntax: Integer	Read-write	Specifies the commands that need to be accounted for. Any command that is equal to or less than the selected level will be accounted for: <ul style="list-style-type: none"> <li>level(0) – Privilege level 0</li> <li>level(4) – Privilege level 4</li> <li>level(5) – Privilege level 5</li> </ul>
snAccountingExec brcdIp.1.1.3.15.3.3 Syntax: OCTET STRING	Read-write	Shows the sequence of accounting methods for EXEC programs. This object can have zero to three octets. Each octet represents a method for Telnet or SSH login accounting. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>radius(2) – Send accounting information to the RADIUS server.</li> <li>tacplus(5) – Send accounting information to the TACACS+ server.</li> <li>none(6) – No accounting method.</li> </ul> Setting a zero length octet string invalidates all authorization methods.
snAccountingSystem brcdIp.1.1.3.15.3.4 Syntax: OCTET STRING	Read-write	A sequence of accounting methods. This object can have zero to three octets. Each octet represents a method to account for the system-related events. Each octet has the following values: <ul style="list-style-type: none"> <li>radius(2) – Send accounting information to the RADIUS server.</li> <li>tacplus(5) – Send accounting information to the TACACS+ server.</li> <li>none(6) – No accounting method.</li> </ul> Setting a zero length octet string invalidates all previous accounting methods.



# CAR MIB Definition

## In this chapter

- [CAR port table](#) ..... 543
- [Rate limit counter table](#) ..... 544
- [VLAN CAR objects](#) ..... 545

---

### NOTE

The objects in this chapter are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

---

## CAR port table

The Common Access Rate (CAR) port table shows the definitions of CAR objects. This table is indexed by the “[snPortCARifIndex](#)”, “[snPortCARDirection](#)”, and “[snPortCARRowIndex](#)” objects.

Name, OID, and syntax	Access	Description
snPortCARTable brcdIp.1.1.3.16.1.1	None	The CAR port table.
snPortCARifIndex brcdIp.1.1.3.16.1.1.1.1 Syntax: Integer	Read-only	Shows the ifIndex value for this rate limit entry.
snPortCARDirection brcdIp.1.1.3.16.1.1.1.2 Syntax: Integer	Read-only	Specifies the transmission direction of the rate-limit object: <ul style="list-style-type: none"> <li>• input(0) – For inbound traffic.</li> <li>• output(1) – For outbound traffic.</li> </ul>
snPortCARRowIndex brcdIp.1.1.3.16.1.1.1.3 Syntax: Integer	Read-only	Shows the table index for rate limit objects. Rows are numbered in sequential order. When a row is added, it is assigned the next sequential number. When a row is deleted, the row is skipped.
snPortCARType brcdIp.1.1.3.16.1.1.1.4 Syntax: RateLimitType	Read-only	Shows the type of traffic to which the rate limit is applied: <ul style="list-style-type: none"> <li>• standardAcc(1) – Traffic matches standard access list.</li> <li>• quickAcc(2) – Traffic matches the rate-limit access list.</li> <li>• all(3) – All traffic.</li> </ul>
snPortCARAccIdx brcdIp.1.1.3.16.1.1.1.5 Syntax: Integer32	Read-only	Indicates the index to the access list if the rate limit type is one of the following: <ul style="list-style-type: none"> <li>• standardAcc(1) – Traffic matches standard access list.</li> <li>• quickAcc(2) – Traffic matches the rate-limit access list.</li> </ul>
snPortCARRate brcdIp.1.1.3.16.1.1.1.6 Syntax: Integer32	Read-only	Shows the committed access rate for the long-term average transmission rate in bits per second. Traffic that falls under this rate always conforms to this rate.

Name, OID, and syntax	Access	Description
snPortCARLimit brcdIp.1.1.3.16.1.1.1.7 Syntax: Integer32	Read-only	Shows the normal burst size in bytes. Normal burst size is the number of bytes that are guaranteed to be transported by the network at the average rate under normal conditions during the committed time interval.
snPortCARExtLimit brcdIp.1.1.3.16.1.1.1.8 Syntax: Integer32	Read-only	Shows the extended burst limit in bytes. The extended burst limit determines how large traffic bursts can be before all the traffic exceeds the rate limit.
snPortCARConformAction brcdIp.1.1.3.16.1.1.1.9 Syntax: Integer	Read-only	Indicates what happens to packets when the traffic is within the rate limit: <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and allow it after evaluated by subsequent rate limits.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snPortCARExceedAction brcdIp.1.1.3.16.1.1.1.10 Syntax: Integer	Read-only	Indicates what happens to packets when the traffic exceeds the rate limit: <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and allow it after evaluated by subsequent rate limits.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snPortCARStatSwitchedPackets brcdIp.1.1.3.16.1.1.1.11 Syntax: Counter64	Read-only	Indicates the number of packets permitted by this rate limit.
snPortCARStatSwitchedBytes brcdIp.1.1.3.16.1.1.1.12 Syntax: Counter64	Read-only	Indicates the number of bytes permitted by this interface.
snPortCARStatFilteredPkts brcdIp.1.1.3.16.1.1.1.13 Syntax: Counter64	Read-only	Indicates the number of packets that exceeded this rate limit.
snPortCARStatFilteredBytes brcdIp.1.1.3.16.1.1.1.14 Syntax: Counter64	Read-only	Indicates the number of bytes that exceeded this rate limit.
snPortCARStatCurBurst brcdIp.1.1.3.16.1.1.1.15 Syntax: Gauge32	Read-only	Shows the current burst size of received packets.

## Rate limit counter table

The following table shows rate limit counter entries.

Name, OID, and syntax	Access	Description
agRateLimitCounterTable brcdIp.1.1.3.16.1.2	None	The rate limit counter table.
agRateLimitCounterFwdedOctets brcdIp.1.1.3.16.1.2.1.1 Syntax: Counter64	Read-only	The forwarded octet count for this rate limit entry.
agRateLimitCounterDroppedOctets brcdIp.1.1.3.16.1.2.1.2 Syntax: Counter64	Read-only	The dropped octet count for this rate limit entry.
agRateLimitCounterReMarkedOctets brcdIp.1.1.3.16.1.2.1.3 Syntax: Counter64	Read-only	The remarked octet count for this rate limit entry.
agRateLimitCounterTotalOctets brcdIp.1.1.3.16.1.2.1.4 Syntax: Counter64	Read-only	The total octet count for this rate limit entry.

## VLAN CAR objects

The objects in the following table contain the rate limit configuration for VLANs. This table is indexed by the “snVlanCARVlanId”, “snVlanCARDirection”, and “snVlanCARRowIndex” objects.

Name, OID, and syntax	Access	Description
snVlanCARTable brcdIp.1.1.3.17.1.1	None	The VLAN rate limit table.
snVlanCARVlanId brcdIp.1.1.3.17.1.1.1.1 Syntax: Integer	Read-only	Shows the VLAN ID. VLAN ID is one of the indices of this table. Each VLAN ID can have a membership of multiple ports. Valid values: 1 – 4095
snVlanCARDirection brcdIp.1.1.3.17.1.1.1.2 Syntax: Integer	Read-only	Specifies the transmission direction of the rate-limit object: <ul style="list-style-type: none"> <li>input(0) – For inbound traffic.</li> <li>output(1) – For outbound traffic.</li> </ul>
snVlanCARRowIndex brcdIp.1.1.3.17.1.1.1.3 Syntax: Integer	Read-only	Shows the table index for rate limit objects for the VLAN. Rows are numbered in sequential order. When a row is added, it is assigned the next sequential number. When a row is deleted, the row is skipped.
snVlanCARType brcdIp.1.1.3.17.1.1.1.4 Syntax: Integer	Read-only	Shows the type of traffic to which the rate limit is applied: <ul style="list-style-type: none"> <li>standardAcc(1) – Traffic matches standard access list.</li> <li>quickAcc(2) – Traffic matches the rate limit access list.</li> <li>all(3) – All traffic.</li> </ul>
snVlanCARAccIdx brcdIp.1.1.3.17.1.1.1.5 Syntax: Integer32	Read-only	Indicates the index to the access list if the rate limit type is one of the following: <ul style="list-style-type: none"> <li>standardAcc(1) – Traffic matches standard access list.</li> <li>quickAcc(2) – Traffic matches the rate limit access list.</li> </ul>
snVlanCARRate brcdIp.1.1.3.17.1.1.1.6 Syntax: Integer32	Read-only	Shows the committed access rate for long-term average transmission for this VLAN in bits per second. Traffic that falls under this rate always conforms to this rate.

Name, OID, and syntax	Access	Description
snVlanCARLimit brcdIp.1.1.3.17.1.1.1.7 Syntax: Integer32	Read-only	Shows the normal burst size in bytes. Normal burst size is the number of bytes that are guaranteed to be transported by the network at the average rate under normal conditions during the committed time interval.
snVlanCARExtLimit brcdIp.1.1.3.17.1.1.1.8 Syntax: Integer32	Read-only	Shows the extended burst limit in bytes. The extended burst limit determines how large traffic bursts can be before all the traffic exceeds the rate limit.
snVlanCARConformAction brcdIp.1.1.3.17.1.1.1.9 Syntax: Integer	Read-only	Indicates what happens to packets when the traffic is within the rate limit: <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and allow it after evaluated by subsequent rate limits.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snVlanCARExceedAction brcdIp.1.1.3.17.1.1.1.10 Syntax: Integer	Read-only	Indicates what happens to packets when the traffic exceeds the rate limit: <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and allow it after evaluated by subsequent rate limits.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snVlanCARStatSwitchedPkts brcdIp.1.1.3.17.1.1.1.11 Syntax: Counter64	Read-only	Indicates the number of packets permitted by this rate limit.
snVlanCARStatSwitchedBytes brcdIp.1.1.3.17.1.1.1.12 Syntax: Counter64	Read-only	Indicates the number of bytes permitted by this interface.
snVlanCARStatFilteredPkts brcdIp.1.1.3.17.1.1.1.13 Syntax: Counter64	Read-only	Indicates the number of packets that exceeded this rate limit.
snVlanCARStatFilteredBytes brcdIp.1.1.3.17.1.1.1.14 Syntax: Counter64	Read-only	Indicates the number of bytes that exceeded this rate limit.
snVlanCARStatCurrent brcdIp.1.1.3.17.1.1.1.15 Syntax: Gauge32	Read-only	Shows the current burst size of received packets.

# LAG MIB Definition

## In this chapter

- LAG group table ..... 547
- LAG group port table ..... 548

## LAG group table

The fdryLinkAggregationGroupTable object replaces the snLinkAggregationGroupTable object.

Name, OID, and syntax	Access	Description
fdryLinkAggregationGroupTable brcdIp.1.1.3.33.1.1	None	The Link Aggregation Group (LAG) table.
fdryLinkAggregationGroupName brcdIp.1.1.3.33.1.1.1.1 Syntax: DisplayString	None	Displays the name of a LAG.
fdryLinkAggregationGroupType brcdIp.1.1.3.33.1.1.1.2 Syntax: Integer	Read-create	Displays the LAG type.
fdryLinkAggregationGroupAdminStatus brcdIp.1.1.3.33.1.1.1.3 Syntax: Integer	Read-create	Displays the desired deployed state of this LAG entry. <b>NOTE:</b> This is not the operational status. Refer to ifTable for the operational status. <ul style="list-style-type: none"> <li>• deploy(1)—Deploy the LAG and set to LACP active if a dynamic LAG.</li> <li>• deployPassive(2)—Deploy the LAG and set to LACP passive if a dynamic LAG.</li> <li>• undeploy(3)—Undeploy the LAG if no more than two ports are enabled.</li> <li>• undeployForced(4)—Undeploy the LAG regardless of the number of ports enabled.</li> </ul> <b>NOTE:</b> undeployForced(4) status is a write-only value. In particular, a row cannot be deployed until the corresponding instances of fdryLinkAggregationGroupIfList have been set.
fdryLinkAggregationGroupIfList brcdIp.1.1.3.33.1.1.1.4 Syntax: OCTET STRING	Read-create	Displays a list of interface indices which are the port memberships of a trunk group. Each interface index is a 32-bit integer in big-endian order. <b>NOTE:</b> This object accepts a 32-bit integer only.
fdryLinkAggregationGroupPrimaryPort brcdIp.1.1.3.33.1.1.1.5 Syntax: InterfaceIndex	Read-create	Displays the primary port for the Link Aggregation Group. This must be set before deploying the Link Aggregation Group unless this is a keepalive Link Aggregation Group.

Name, OID, and syntax	Access	Description
fdryLinkAggregationGroupTrunkType brcdIp.1.1.3.33.1.1.1.6 Syntax: Integer	Read-create	Displays the trunk connection type, which specifies the scheme of load-sharing among the trunk ports.
fdryLinkAggregationGroupTrunkThresh old brcdIp.1.1.3.33.1.1.1.7 Syntax: Unsigned32	Read-create	Displays the number of up ports needed to keep the trunk up. <b>NOTE:</b> This object is not applicable to keepalive LAGs.
fdryLinkAggregationGroupLacpTimeout brcdIp.1.1.3.33.1.1.1.8 Syntax: Integer	Read-create	Displays the LACP timeout value this LACP LAG will use. Applicable for dynamic and keepalive LAGs only.
fdryLinkAggregationGroupIfIndex brcdIp.1.1.3.29.2.1.1.9 Syntax: InterfaceIndex	Read-only	After a LAG is deployed, this object displays information for the LAG entry in the ifTable. Use the variable to access the entry in the ifTable and ifXTable. Zero(0) is returned for LAGs that have not been deployed.
fdryLinkAggregationGroupPortCount brcdIp.1.1.3.33.1.1.1.10 Syntax: Unsigned32	Read-only	Displays the number of member ports that belong to this LAG.
fdryLinkAggregationGroupRowStatus brcdIp.1.1.3.33.1.1.1.11 Syntax: RowSts	Read-create	Displays the status of this conceptual row. createAndWait(5) is not supported. To create a row in this table, a manager must set this object to createAndGo(4) together with the setting of fdryLinkAggregationGroupType. After that, the row status becomes active(1) regardless of whether or not the LAG entry is deployed. To deploy the LAG entry, set the corresponding instance of fdryLinkAggregationGroupAdminStatus to deployActive or deployPassive.
fdryLinkAggregationGroupId brcdIp.1.1.3.33.1.1.1.12 Syntax: Unsigned 32	Read-only	The numeric identifier assigned to this LAG.

## LAG group port table

The following table list the MIB objects of LAG group port table.

Name, OID, and syntax	Access	Description
fdryLinkAggregationGroupPortTable brcdIp.1.1.3.33.2.1	None	This table contains the Link Aggregation Control Configuration information about every aggregation port associated with this device. A row is listed in this table for each physical port.
fdryLinkAggregationGroupPortLacpPriority brcdIp.1.1.3.33.2.1.1.1 Syntax: Integer	Read-write	The LACP priority value assigned to this link aggregation port. valid values: 0 - 65535 Default: 1.

# MPLS MIB Definition

---

## In this chapter

- Pseudo wire MIB ..... 549
- MPLS or BGP Layer 3 VPN MIB. .... 556
- General MPLS objects. .... 562
- MPLS LSP table ..... 562
- MPLS administrative group table ..... 566
- MPLS interface table. .... 567

## Pseudo wire MIB

Pseudo wire describe the SNMP MIB objects for the Multiprotocol Label Switching (MPLS) feature that is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices. .

### pwTable

The following table contains the pseudo wire MIB objects for configuring and monitoring VLL, VLL-local, and VPLS services.

---

**NOTE**

Use the **snmp-server disable mib** *<mib-table-keyword>* command to disable the SNMP support for the table and use the **no** form of the command to re-enable the support. The overall SNMP-WALK performance is increased when the SNMP support is disabled for the table.

---

TABLE 5 Support for the pwTable

Object	Object identifier	Support for VLL	Support for VLL-local	Support for VPLS
pwIndex	brcdlp.3.1.2.1.2.1.1	VPLS-specific coding	VPLS-specific coding	VPLS-specific coding
pwType	brcdlp.3.1.2.1.2.1.2	Tagged: ethernetTagged(4) Untagged: ethernet(5)	ethernet(5) for raw transport as PW acts as a switch	System supports raw mode only, no VLAN tagging. Returns ipLayer2Transport(11) if global command <b>vpls-vc-type-ethernet-vpls</b> is configured, otherwise Ethernet(5) [BID 84147] ethernetTagged(4) for tagged VPLS
pwOwner	brcdlp.3.1.2.1.2.1.3	pwldFecSignaling(2)	other(5)	Always pwldFecSignaling(2)
pwPsnType	brcdlp.3.1.2.1.2.1.4	mpls(1)	other(6)	Always mpls(1)
pwSetUpPriority	brcdlp.3.1.2.1.2.1.5	Always 0	Always 0	Always 0
pwHoldingPriority	brcdlp.3.1.2.1.2.1.6	Always 0	Always 0	Always 0
pwPeerAddrType	brcdlp.3.1.2.1.2.1.8	ipv4(1) only	unknown(0)	Always ipv4(1)
pwPeerAddr	brcdlp.3.1.2.1.2.1.9	Supported	Always 0	Supported For example, Peer IP 3.3.3.3 translates to string 0x03x03x03x03 (without commas)
pwAttachedPwIndex	brcdlp.3.1.2.1.2.1.10	Always 0	Always 0	Always 0
pwIfIndex	brcdlp.3.1.2.1.2.1.11	Always 0	Always 0	Always 0
pwID	brcdlp.3.1.2.1.2.1.12	VC ID	VC ID (internal)	VC ID
pwLocalGroupID	brcdlp.3.1.2.1.2.1.13	Always 0	Always 0	Always 0
pwGroupAttachmentID	brcdlp.3.1.2.1.2.1.14	Always null	Always null	Always null
pwLocalAttachmentID	brcdlp.3.1.2.1.2.1.15	Always null	Always null	Always null
pwPeerAttachmentID	brcdlp.3.1.2.1.2.1.16	Always null	Always null	Always null
pwCwPreference	brcdlp.3.1.2.1.2.1.17	false(2)	false(2)	false(2)
pwLocalIfMtu	brcdlp.3.1.2.1.2.1.18	Supported	Not supported	Supported
pwLocalIfString	brcdlp.3.1.2.1.2.1.19	false(2)	false(2)	false(2)
pwLocalCapableAdv	brcdlp.3.1.2.1.2.1.20	Always null	Always null	Always null
pwRemoteGroupID	brcdlp.3.1.2.1.2.1.21	Always 0	Always 0	Always 0
pwCwStatus	brcdlp.3.1.2.1.2.1.22	cwNotPresent(6)	cwNotPresent(6)	cwNotPresent(6)



TABLE 5 Support for the pwTable

Object	Object identifier	Support for VLL	Support for VLL-local	Support for VPLS
pwRemotelfMtu	brcdlp.3.1.2.1.2.1.23	Supported	Always 0	Supported
pwRemotelfString	brcdlp.3.1.2.1.2.1.24	Always null	Always null	Always null
pwRemoteCapabilities	brcdlp.3.1.2.1.2.1.25	Always null	Always null	Always null
pwFragmentCfgSize	brcdlp.3.1.2.1.2.1.26	Always 0	Always 0	Always 0
pwRmtFragCapability	brcdlp.3.1.2.1.2.1.27	Always null	Always null	Always null
pwFcsRetentionCfg	brcdlp.3.1.2.1.2.1.28	fcsRetentionDisable(1)	fcsRetentionDisable(1)	fcsRetentionDisable(1)
pwFcsRetentionStatus	brcdlp.3.1.2.1.2.1.29	return 0x10 (to set bit fcsRetentionDisabled(3))	return 0x10 (to set bit fcsRetentionDisabled(3))	return 0x10 (to set bit fcsRetentionDisabled(3))
pwOutboundLabel	brcdlp.3.1.2.1.2.1.30	Supported	Always 0	Supported
pwInboundLabel	brcdlp.3.1.2.1.2.1.31	Supported	Always 0	Supported
pwName	brcdlp.3.1.2.1.2.1.32	Supported (VLL name)	Supported (VLL-local name)	Supported (VPLS name)
<b>NOTE:</b> The object is an extension added by the device and it is not part of the draft MIB.				
pwDescr	brcdlp.3.1.2.1.2.1.33	Always null	Always null	Always null
pwCreateTime	brcdlp.3.1.2.1.2.1.34	Always 0	Always 0	Always 0
pwUpTime	brcdlp.3.1.2.1.2.1.35	Always 0	Always 0	Always 0
pwLastChange	brcdlp.3.1.2.1.2.1.36	Always 0	Always 0	Always 0
pwAdminStatus	brcdlp.3.1.2.1.2.1.37	Supported: <ul style="list-style-type: none"> <li>• up(1)</li> <li>• down(2)</li> </ul>	Supported: <ul style="list-style-type: none"> <li>• up(1)</li> <li>• down(2)</li> </ul>	Supported: <ul style="list-style-type: none"> <li>• up(1)</li> <li>• down(2)</li> </ul>
pwOperStatus	brcdlp.3.1.2.1.2.1.38	<ul style="list-style-type: none"> <li>• up(1) - Running</li> <li>• down(2) - Tunnel down</li> <li>• dormant(4) - Waiting For LDP to establish</li> <li>• notPrsent(5) - Incomplete configuration</li> <li>• lowerLayerDown(6) - Tunnel Down</li> </ul>	<ul style="list-style-type: none"> <li>• up(1)</li> <li>• notPrsent(5) - Incomplete configuration</li> </ul>	<ul style="list-style-type: none"> <li>• up(1) - Running</li> <li>• down(2) - Tunnel down</li> <li>• dormant(4) - Waiting for LDP to establish</li> <li>• notPrsent(5) - Incomplete Configuration</li> <li>• lowerLayerDown(6) - Tunnel down</li> </ul>

TABLE 5 Support for the pwTable

Object	Object identifier	Support for VLL	Support for VLL-local	Support for VPLS
pwLocalStatus	brcdlp.3.1.2.1.2.1.39	If tunnel is down, returns 0x80, otherwise returns 0x00	Supported	If tunnel is down, returns 0x80, otherwise returns 0x00
pwRemoteStatusCapable	brcdlp.3.1.2.1.2.1.40	notApplicable(1)	notApplicable(1)	notApplicable(1)
pwRemoteStatus	brcdlp.3.1.2.1.2.1.41	Always null	Always null	Always null
pwTimeElapsed	brcdlp.3.1.2.1.2.1.42	Always 0	Always 0	Always 0
pwValidIntervals	brcdlp.3.1.2.1.2.1.43	Always 0	Always 0	Always 0
pwRowStatus	brcdlp.3.1.2.1.2.1.44	active(1)	active(1)	active(1)
pwStorageType	brcdlp.3.1.2.1.2.1.45	permanent(4)	permanent(4)	permanent(4)
pwOamEnable	brcdlp.3.1.2.1.2.1.46	false(2)	false(2)	false(2)

## Draft-ietf-pwe3-pw-mib-11.txt

The following pseudo Wire (PW) MIB objects, as defined in draft-ietf-pwe3-pw-mib-11.txt, are supported on the Brocade MLXe and Brocade NetIron series devices.

Draft-ietf-pwe3-pw-mib-11.txt obsoletes draft-ietf-pwe3-pw-mib-06.txt; however, some objects in draft-ietf-pwe3-pw-mib-06.txt are still supported on the NetIron series devices. (Refer to [“Supported objects in draft-ietf-pwe3-pw-mib-06.txt”](#) on page 554

Support for draft-ietf-pwe3-pw-mib-11.txt has been extended to VLL, VLL-local, and VPLS on the Brocade MLXe and Brocade NetIron series devices. For additional objects, refer to [“VLL endpoint table”](#) on page 569, and [“VPLS instance table”](#) on page 571.

### NOTE

Support for the following objects in draft-ietf-pwe3-pw-mib-11.txt provides read-only access.

Object	Object identifier	Support for VLL	Support for VLL-local	Support for VPLS
pwindex	brcdlp.3.1.2.1.2.1.1 1	VLL-specific encoding. One row per VLL instance.	VLL-local-specific encoding. Two rows per VLL-local instance, one for each E. Ethernet endpoint for each instance.	VPLS-specific encoding. One row per VPLS instance and peer combination.
pwEnetPwInstance	brcdlp.3.1.4.1.1.1.1 1	Always 1	1 for first endpoint, 2 for second	Always 1
pwEnetPwVlan	brcdlp.3.1.4.1.1.1.1 2	<ul style="list-style-type: none"> <li>VLAN ID 4097 for pseudo wire in raw mode</li> <li>Default VLAN ID for PW untagged frames</li> </ul>	Always 4096 for raw mode	VPLS works in raw mode. Always 4096 in raw mode. There is no VLAN tagging in outgoing packets.

Object	Object identifier	Support for VLL	Support for VLL-local	Support for VPLS
pwEnetVlanMode	brcdIp.3.1.4.1.1.1.3	<ul style="list-style-type: none"> <li>portBased(1) - No VLAN tag</li> <li>noChange(2) - Retain same VLAN ID</li> <li>changeVlan(3) - Change id</li> <li>addVlan(4)</li> <li>removeVlan(5)</li> </ul>	<ul style="list-style-type: none"> <li>portBased(1) - no VLAN tag; both instances use default VLAN ID</li> <li>noChange(2) - retain same VLAN ID</li> <li>changeVlan(3) - change non-default VLAN IDs between two instances</li> <li>addVlan(4) - instance ID 1 has default VLAN, Instance ID 2 has non-default VLAN</li> <li>removeVlan(5) - instance ID 1 has default VLAN, Instance ID 2 has non-default VLAN</li> </ul>	<ul style="list-style-type: none"> <li>portBased(1) - no vlan tag</li> </ul>
pwEnetPortVlan	brcdIp.3.1.4.1.1.1.4	Endpoint VLAN ID, which can be 4096 or an actual VLAN ID.	Endpoint VLAN ID	Always 0. For end-point, use fdryVplsEndPointTable.
pwEnetPortIfIndex	brcdIp.3.1.4.1.1.1.5	Endpoint ifIndex	Endpoint ifIndex	Always 0. For endpoint, use fdryVplsEndPointTable.
pwEnetPwIfIndex	brcdIp.3.1.4.1.1.1.6	Tunnel ifIndex	Because no tunnel, value 0	Tunnel ifIndex
pwEnetRowStatus	brcdIp.3.1.4.1.1.1.7	Always active(1)	Always active(1)	Always active(1)
pwEnetStorageType	brcdIp.3.1.4.1.1.1.8	Always permanent(4)	Always permanent(4)	Always permanent(4)

## Values that affect some VLL services

The following table shows how the value of pwType for VLL services is determined.

Pseudo Wire tag mode is	End Point tag mode is	Value of pwType is
raw (untagged)	untagged	ethernet(5)
raw (untagged)	tagged	ethernet(5)
tagged	untagged	ethernetTagged(4)
tagged	tagged	ethernetTagged(4)

The following table shows how the value of pwEnetPwVlan for VLL services is determined.

Pseudo Wire tag mode is	End Point tag mode is	Value of pwEnetPwVlan is
raw (untagged)	untagged	4097
raw (untagged)	tagged	4097
tagged	untagged	Default VLAN ID
tagged	tagged	VLAN ID of endpoint

The following table shows how the value of pwEnetVlanMode for VLL services is determined.

Pseudo Wire tag mode is	End Point tag mode is	Value of pwEnetVlanMode is
raw (untagged)	untagged	portBased(1) - No VLAN tag
raw (untagged)	tagged	removeVlan(5)
tagged	untagged	addVlan(4)
tagged	tagged	noChange(2)

The following table shows how the value of pwEnetPortVlan for VLL services is determined.

Pseudo Wire tag mode is	End Point tag mode is	Value of pwEnetPortVlan is
raw (untagged)	untagged	4096
raw (untagged)	tagged	VLAN ID of endpoint VLAN
tagged	untagged	4096
tagged	tagged	VLAN ID of endpoint VLAN

## Supported objects in draft-ietf-pwe3-pw-mib-06.txt

The following pseudo Wire (PW) MIB objects are the only objects in draft-ietf-pwe3-pw-mib-06.txt that are supported on the Brocade MLX, Brocade MLXe, and Brocade NetIron XMR devices. They are used to support draft-ietf-pwe3-pw-mib-11.txt. Read-only access is available for draft-ietf-pwe3-pw-mib-06.txt.

**TABLE 6** Comparison of objects within drafts v.6 and v.11

Object	Object Identifier	Differences
pwPsnType	brcdIp.3.1.2.1.2.1.4	The pwPsnType object is now of IANAPwPsnTypeTC type. The changes are highlighted below. pwPsnType: <ul style="list-style-type: none"> <li>• mpls(1)</li> <li>• l2tp(2)</li> <li>• ip(3)</li> <li>• mplsOverIp(4)</li> <li>• gre(5)</li> <li>• other(6)</li> </ul> IANAPwPsnTypeTC: <ul style="list-style-type: none"> <li>• mpls(1)</li> <li>• l2tp(2)</li> <li>• udpOverIp(3)</li> <li>• mplsOverIp(4)</li> <li>• mplsOverGre(5)</li> <li>• other(6)</li> </ul>
pwAttachedPwIndex	brcdIp.3.1.2.1.2.1.1.0	Type changed from PwIndexType to PwIndexOrZeroType.
pwFragmentCfgSize	brcdIp.3.1.2.1.2.1.2.6	Added UNIT "bytes".
pwFcsRetentionCfg	brcdIp.3.1.2.1.2.1.2.8	Name changed to pwFcsRetentionCfg.
pwOutboundVcLabel	brcdIp.3.1.2.1.2.1.3.0	Renamed to pwOutboundLabel.
pwInboundVcLabel	brcdIp.3.1.2.1.2.1.3.1	Renamed to pwInboundLabel.
pwStorageType	brcdIp.3.1.2.1.2.1.4.5	Added DEFVAL nonvolatile
pwOamEnable	brcdIp.3.1.2.1.2.1.4.6	Supported
pwIndexMappingEntry/pwIndexMappingVcType	brcdIp.3.1.2.1.7.1.1	Replaced by pwIndexMappingEntry/pwIndexMappingPwType Type has changed from PwTypeTC to IANAPwTypeTC.
pwIndexMappingEntry/pwIndexMappingVcID	brcdIp.3.1.2.1.7.1.2	Replaced by pwIndexMappingEntry/pwIndexMappingPwID.
pwIndexMappingEntry/pwIndexMappingVcIndex	brcdIp.3.1.2.1.7.1.5	Replaced by pwIndexMappingEntry/pwIndexMappingPwIndex.
pwPeerMappingEntry/pwPeerMappingVcType	brcdIp.3.1.2.1.8.1.3	Replaced by pwPeerMappingEntry/pwPeerMappingPwType Type changed from PwTypeTC to IANAPwTypeTC.
pwPeerMappingEntry/pwPeerMappingVcID	brcdIp.3.1.2.1.8.1.4	Replaced by pwPeerMappingEntry/pwPeerMappingPwID.
pwPeerMappingEntry/pwPeerMappingVcIndex	brcdIp.3.1.2.1.8.1.5	Replaced by pwPeerMappingEntry/pwPeerMappingPwIndex.

## Proprietary extension

The following table lists the proprietary extension MIB objects.

Name	Access	Supported?
fdryPwServiceType brcdIp.3.1.2.1.20 Syntax: Integer	None	A L2VPN service type, used only for notification: <ul style="list-style-type: none"> <li>vll(1)</li> <li>vlllocal(2)</li> <li>vpls(3)</li> </ul>

## MPLS or BGP Layer 3 VPN MIB

The MPLS or BGP Layer 3 VPN MIB (draft-ietf-lwvpn-mpls-vpn-mib-07.txt) is supported on the Brocade NetIron XMR and the Brocade MLX series devices.

**NOTES:** The following objects are implemented as read-only:

- mplsL3VpnIfConfTable
- mplsL3VpnVrfTable
- mplsL3VpnVrfRTTable
- mplsL3VpnVrfRteTable

Object	Object identifier	Supported?
mplsL3VpnConfiguredVrfs	brcdIp.3.2.1.1.1.1	Yes, but read-only.
mplsL3VpnActiveVrfs	brcdIp.3.2.1.1.1.2	Yes, but read-only.
mplsL3VpnConnectedInterfaces	brcdIp.3.2.1.1.1.3	Yes, but read-only.
mplsL3VpnNotificationEnable	brcdIp.3.2.1.1.1.4	Yes, Read-write.
mplsL3VpnVrfConfMaxPossRts	brcdIp.3.2.1.1.1.5	Yes, but read-only.
mplsL3VpnVrfConfRteMxThrshTime	brcdIp.3.2.1.1.1.6	No
mplsL3VpnIILblRcvThrsh	brcdIp.3.2.1.1.1.7	No

## VPN interface configuration table

Object	Object Identifier	Supported?
mplsL3VpnConf	brcdIp.3.2.1.1.2	Yes
mplsL3VpnIfConfTable	brcdIp.3.2.1.1.2.1	Yes, but read-only.
mplsL3VpnIfConfEntry	brcdIp.3.2.1.1.2.1.1	Yes
mplsL3VpnIfConfIndex	brcdIp.3.2.1.1.2.1.1.1	Yes
mplsL3VpnIfVpnClassification	brcdIp.3.2.1.1.2.1.1.2	Yes Only enterprise(2) is supported.

Object	Object Identifier	Supported?
mplsL3VpnIrfVpnRouteDistProtocol	brcdIp.3.2.1.1.2.1.1.3	Yes <ul style="list-style-type: none"> <li>isis(4) - Not supported</li> <li>static(5) - Always true</li> </ul>
mplsL3VpnIrfConfStorageType	brcdIp.3.2.1.1.2.1.1.4	Yes

## VRF configuration table

Object	Object Identifier	Supported?
mplsL3VpnVrfTable	brcdIp.3.2.1.1.2.2	Yes, but read-only.
mplsL3VpnVrfEntry	brcdIp.3.2.1.1.2.2.1	Yes
mplsL3VpnVrfName	brcdIp.3.2.1.1.2.2.1.1	Yes Supported in simple VRF textual name format. Not supported in format specified in RFC 2685.
mplsL3VpnVrfVpnId	brcdIp.3.2.1.1.2.2.1.2	No Returns null string
mplsL3VpnVrfDescription	brcdIp.3.2.1.1.2.2.1.3	No Returns null string
mplsL3VpnVrfRD	brcdIp.3.2.1.1.2.2.1.4	Read-only
mplsL3VpnVrfCreationTime	brcdIp.3.2.1.1.2.2.1.5	No Returns 0
mplsL3VpnVrfOperStatus	brcdIp.3.2.1.1.2.2.1.6	No Always returns up(1)
mplsL3VpnVrfActiveInterfaces	brcdIp.3.2.1.1.2.2.1.7	Yes, but read-only.
mplsL3VpnVrfAssociatedInterfaces	brcdIp.3.2.1.1.2.2.1.8	Yes, but read-only.
mplsL3VpnVrfConfMidRteThresh	brcdIp.3.2.1.1.2.2.1.9	No Returns 0
mplsL3VpnVrfConfHightRteThresh	brcdIp.3.2.1.1.2.2.1.10	No Returns 0
mplsL3VpnVrfConfMaxRoutes	brcdIp.3.2.1.1.2.2.1.11	Read-only
mplsL3VpnVrfConfLastChanged	brcdIp.3.2.1.1.2.2.1.12	No Returns 0
mplsL3VpnVrfConfRowStatus	brcdIp.3.2.1.1.2.2.1.13	Yes
mplsL3VpnVrfConfAdminStatus	brcdIp.3.2.1.1.2.2.1.14	Only Up(1) is supported.
mplsL3VpnVrfConfStorageType	brcdIp.3.2.1.1.2.2.1.15	Yes, but read-only. This object always returns permanent(4).

## VRF route target table

Object	Object identifier	Supported?
mplsL3VpnVrfRTTable	brcdIp.3.2.1.1.2.3	Yes, but read-only.
mplsL3VpnVrfRTEntry	brcdIp.3.2.1.1.2.3.1	Yes
mplsL3VpnVrfRTIndex	brcdIp.3.2.1.1.2.3.1.2	Yes
mplsL3VpnVrfRTType	brcdIp.3.2.1.1.2.3.1.3	Yes, but read-only.
mplsL3VpnVrfRT	brcdIp.3.2.1.1.2.3.1.4	Yes, but read-only.
mplsL3VpnVrfRTDescr	brcdIp.3.2.1.1.2.3.1.5	No Returns null string
mplsL3VpnVrfRTRowStatus	brcdIp.3.2.1.1.2.3.1.6	Yes, but read-only.
mplsL3VpnVrfRTStorageType	brcdIp.3.2.1.1.2.3.1.7	Yes, but read-only. This object always returns permanent(4).

## VRF security table

Object	Object identifier	Supported?
mplsL3VpnVrfSecTable	brcdIp.3.2.1.1.2.6	Yes
mplsL3VpnVrfSecEntry	brcdIp.3.2.1.1.2.6.1	Yes
mplsL3VpnVrfSecIllegalLbIVltns	brcdIp.3.2.1.1.2.6.1.1	No Returns 0
mplsL3VpnVrfSecDiscontinuityTime	brcdIp.3.2.1.1.2.6.1.2	No Returns 0

## VRF performance table

Object	Object identifier	Supported?
mplsL3VpnPerf	brcdIp.3.2.1.1.3	Yes
mplsL3VpnVrfPerfTable	brcdIp.3.2.1.1.3.1	Yes
mplsL3VpnVrfPerfEntry	brcdIp.3.2.1.1.3.1.1	Yes
mplsL3VpnVrfPerfRoutesAdded	brcdIp.3.2.1.1.3.1.1.1	Yes, but read-only.
mplsL3VpnVrfPerfRoutesDeleted	brcdIp.3.2.1.1.3.1.1.2	Yes, but read-only.
mplsL3VpnVrfPerfCurrNumRoutes	brcdIp.3.2.1.1.3.1.1.3	Yes, but read-only.
mplsL3VpnVrfPerfRoutesDropped	brcdIp.3.2.1.1.3.1.1.4	No
mplsL3VpnVrfPerfDiscTime	brcdIp.3.2.1.1.3.1.1.5	No



## VRF routing table

Object	Object identifier	Supported?
mplsL3VpnRoute	brcdIp.3.2.1.1.4	Yes
mplsL3VpnVrfRteTable	brcdIp.3.2.1.1.4.1	Yes, but read-only.
mplsL3VpnVrfRteEntry	brcdIp.3.2.1.1.4.1.1.	Yes
mplsL3VpnVrfRtelNetCidrDestType	brcdIp.3.2.1.1.4.1.1.1	IPv4 value
mplsL3VpnVrfRtelNetCidrDest	brcdIp.3.2.1.1.4.1.1.2	Yes
mplsL3VpnVrfRtelNetCidrPfxLen	brcdIp.3.2.1.1.4.1.1.3	Yes
mplsL3VpnVrfRtelNetCidrPolicy	brcdIp.3.2.1.1.4.1.1.4	Default The value {0 0} is returned.
mplsL3VpnVrfRtelNetCidrNHopType	brcdIp.3.2.1.1.4.1.1.5	IPv4 value
mplsL3VpnVrfRtelNetCidrNextHop	brcdIp.3.2.1.1.4.1.1.6	Yes
mplsL3VpnVrfRtelNetCidrRfIndex	brcdIp.3.2.1.1.4.1.1.7	Yes, but read-only.
mplsL3VpnVrfRtelNetCidrType	brcdIp.3.2.1.1.4.1.1.8	Yes, but read-only.
mplsL3VpnVrfRtelNetCidrProto	brcdIp.3.2.1.1.4.1.1.9	Yes, but read-only.
mplsL3VpnVrfRtelNetCidrAge	brcdIp.3.2.1.1.4.1.1.10	Yes, but read-only.
mplsL3VpnVrfRtelNetCidrNextHopAS	brcdIp.3.2.1.1.4.1.1.11	No Returns 0
mplsL3VpnVrfRtelNetCidrMetric1	brcdIp.3.2.1.1.4.1.1.12	Yes, but read-only.
mplsL3VpnVrfRtelNetCidrMetric2	brcdIp.3.2.1.1.4.1.1.13	No Returns 0
mplsL3VpnVrfRtelNetCidrMetric3	brcdIp.3.2.1.1.4.1.1.14	No Returns 0
mplsL3VpnVrfRtelNetCidrMetric4	brcdIp.3.2.1.1.4.1.1.15	No Returns 0
mplsL3VpnVrfRtelNetCidrMetric5	brcdIp.3.2.1.1.4.1.1.16	No Returns 0
mplsL3VpnVrfRteXCPointer	brcdIp.3.2.1.1.4.1.1.17	No Returns null string
mplsL3VpnVrfRtelNetCidrStatus	brcdIp.3.2.1.1.4.1.1.18	Yes, but read-only.

## Supported objects in VPLS-generic-draft-01-mib

The following tables present the objects supported in the VPLS-generic-draft-01-mib module of draft-ietf-l2vpn-vpls-mib-01.

Tables and scalars in the draft that are not listed in the following tables are not supported.

### Scalars

The following scalars are supported.

Name, OID, and syntax	Access	Description
vplsConfigIndexNext brcdIp.3.4.1.1.1 Syntax: Unsigned 32	Read-only	Unique index for the conceptual row identifying a VPLS service. However, in the current implementation, this index is always 0.
vplsStatusNotifEnable brcdIp.3.4.1.1.5 Syntax: TruthValue	Read-write	If this object is set to true(1), then it enables vplsStatusChanged notification to be generated. Change notification is determined by the use of the <b>snmp-server enable trap mpls vpls</b> and <b>no snmp-server enable trap mpls vpls</b> commands.
vplsNotificationMaxRate brcdIp.3.4.1.1.6 Syntax: SnmpAdminString	Read-write	Always 0.

### *vplsConfigTable*

The following table below presents the objects supported in the vplsConfigTable. Refer to “[VPLS instance table](#)” on page 571 for objects that are not supported in this table.

#### NOTE

The following table is supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Name, OID, and syntax	Access	Supported?
vplsConfigIndex brcdIp.3.4.1.1.2.1.1 Syntax: Unsigned 32	Read-only	Yes
vplsConfigName brcdIp.3.4.1.1.2.1.2 Syntax: SnmpAdminString	Read-only	Yes
vplsConfigDescr brcdIp.3.4.1.1.2.1.3 Syntax: SnmpAdminString	Read-only	Always null string
vplsConfigAdminStatus brcdIp.3.4.1.1.2.1.4 Syntax: Integer	Read-only	Yes Always up(1)
vplsConfigMacLearning brcdIp.3.4.1.1.2.1.6 Syntax: TruthValue	Read-only	Yes Always true(1)
vplsConfigDiscardUnknownDest brcdIp.3.4.1.1.2.1.7 Syntax: TruthValue	Read-only	No Always false(2)
vplsConfigMacAging brcdIp.3.4.1.1.2.1.8 Syntax: TruthValue	Read-only	Yes Always true(1)
vplsConfigFwdFullHighWatermark brcdIp.3.4.1.1.2.1.10 Syntax: Unsigned 32	Read-only	Always 0

Name, OID, and syntax	Access	Supported?
vplsConfigFwdFullLowWatermark brcdIp.3.4.1.1.2.1.11 Syntax: Unsigned 32	Read-only	Always 0
vplsConfigRowStatus brcdIp.3.4.1.1.2.1.12 Syntax: RowStatus	Read-only	Yes Always active (1)
vplsConfigMtu brcdIp.3.4.1.1.2.1.13 Syntax: Unsigned 32	Read-only	Yes
vplsConfigVpnId brcdIp.3.4.1.1.2.1.14 Syntax: Octet string	Read-only	Always null
vplsConfigServiceType brcdIp.3.4.1.1.2.1.15 Syntax: Integer	Read-only	Yes: <ul style="list-style-type: none"> <li>vlan(1)</li> <li>ethernet(2)</li> <li>ethernetTagged(4)</li> </ul> <b>NOTE:</b> vlan(1) if part of VLAN, otherwise ethernet(2) for tagged VPLS
vplsConfigStorageType brcdIp.3.4.1.1.2.1.16 Syntax: StorageType	Read-only	Yes Always permanent(4)

### *vplsStatusTable*

The following table lists the objects that are supported for the vplsStatusTable.

Name	Access	Supported?
vplsStatusOperStatus brcdIp.3.4.1.1.3.1.1 Syntax: Integer	Read-only	Yes
vplsStatusPeerCount brcdIp.3.4.1.1.3.1.2 Syntax: Counter 32	Read-only	Yes

### *vplsPwBindTable*

This vplsPwBindTable binds a given VPLS instance to various pseudo wires. It provides transport service for a VPLS.

Name	Access	Supported?
vplsPwBindIndex brcdIp.3.4.1.1.4.1.1 Syntax: PWIndexType	Read-only	Yes PwIndex of corresponding PWTable. One VPLS may have multiple PWTable entries.
vplsPwBindConfigType brcdIp.3.4.1.1.4.1.2 Syntax: Integer	Read-only	Yes Always manual(1)
vplsPwBindType brcdIp.3.4.1.1.4.1.3 Syntax: Integer	Read-only	Yes Always mesh(1)
vplsPwBindRowStatus brcdIp.3.4.1.1.4.1.4 Syntax: RowStatus	Read-only	Yes. <ul style="list-style-type: none"> <li>• active(1) - If PW state is operational</li> <li>• not-in-service(2) - If PW is not operational</li> </ul>
vplsPwBindStorageType brcdIp.3.4.1.1.4.1.5 Syntax: StorageType	Read-only	Yes Only permanent(4) is supported

## General MPLS objects

The following table contains the general MPLS MIB objects.

Name, OID, and syntax	Access	Description
mplsVersion brcdIp.1.2.15.1.1.1 Syntax: Unsigned32	Read-only	The MPLS version number.
mplsConfiguredLsps brcdIp.1.2.15.1.2.1 Syntax: Unsigned32	Read-only	The number of configured LSPs. This is calculated by adding the number of RSVPs and statically configured label switched paths (LSPs).
mplsActiveLsps brcdIp.1.2.15.1.2.2 Syntax: Unsigned32	Read-only	The number of active LSPs. This is calculated by adding the number of RSVPs, LDPs, and statically configured LSPs.

## MPLS LSP table

The following table contains objects for the MPLS LSPs table.

Name, OID, and syntax	Access	Description
mplsLspTable brcdIp.1.2.15.1.2.3	None	The MPLS LSP table.
mplsLspSignalingProto brcdIp.1.2.15.1.2.3.1.1 Syntax: Integer	None	MPLS signaling protocol used by this LSP: <ul style="list-style-type: none"> <li>• ldp(1)</li> <li>• rsvp(2)</li> </ul>

Name, OID, and syntax	Access	Description
mplsLspIndex brcdIp.1.2.15.1.2.3.1.2 Syntax: Unsigned32	None	The unique index of the LSP in the system for a given signaling protocol.
mplsLspName brcdIp.1.2.15.1.2.3.1.3 Syntax: DisplayString	Read-only	The name of the label switched path (LSP).
mplsLspState brcdIp.1.2.15.1.2.3.1.4 Syntax: Integer	Read-only	The operational state of the LSP: <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• up(2)</li> <li>• down(3)</li> </ul>
mplsLspPackets brcdIp.1.2.15.1.2.3.1.5 Syntax: Counter64	Read-only	The number of egress Layer 3 VPN and IP MPLS packets that has been sent to outbound, meeting the in-label and tunnel criteria. This object is equivalent to show mpls statistics tunnel or show mpls ldp traffic command.
mplsLspAge brcdIp.1.2.15.1.2.3.1.6 Syntax: TimeStamp	Read-only	The age in 10-millisecond periods since the creation of the LSP.
mplsLspTimeUp brcdIp.1.2.15.1.2.3.1.7 Syntax: TimeStamp	Read-only	The total time in 10-millisecond units that this LSP has been operational. Calculate the percentage up-time using the following equation: $\text{mplsLspTimeUp or mplsLspAge} \times 100\%$
mplsLspPrimaryTimeUp brcdIp.1.2.15.1.2.3.1.8 Syntax: TimeStamp	Read-only	The total time in 10-millisecond units that the primary path of the LSP has been operational. The percentage contribution of the primary path to the operational time is calculated using the following equation: $\text{mplsLspPrimaryTimeUp or mplsLspTimeUp} \times 100\%$
mplsLspTransitions brcdIp.1.2.15.1.2.3.1.9 Syntax: Counter32	Read-only	The number of times the state of the LSP transitioned from up to down and down to up.
mplsLspLastTransition brcdIp.1.2.15.1.2.3.1.10 Syntax: TimeStamp	Read-only	The time in 10-millisecond units since the last transition occurred on this LSP.
mplsLspFrom brcdIp.1.2.15.1.2.3.1.11 Syntax: IpAddress	Read-only	Source IP address of this LSP.
mplsLspTo brcdIp.1.2.15.1.2.3.1.12 Syntax: IpAddress	Read-only	Destination IP address of this LSP.
mplsPathName brcdIp.1.2.15.1.2.3.1.13 Syntax: DisplayString	Read-only	The name of the active path for this LSP. If there is no name, this field should be empty and all the fields in this table do not apply.

Name, OID, and syntax	Access	Description
mplsPathType brcdIp.1.2.15.1.2.3.1.14 Syntax: Integer	Read-only	The type of path that is active. This field is meaningless unless mplsPathName contains no value. Paths can be the following types: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• primary(2)</li> <li>• standby(3)</li> <li>• secondary(4)</li> </ul>
mplsLspAdaptive brcdIp.1.2.15.1.2.3.1.15 Syntax: TruthVal	Read-only	Indicates if this LSP supports the Adaptive mechanism.
mplsLspBfdSessionId brcdIp.1.2.15.1.2.3.1.16 Syntax: Unsigned32	Read-only	The BFD session associated to this LSP: <ul style="list-style-type: none"> <li>• Zero indicates that no BFD session exists for this LSP.</li> <li>• Non-zero is an index to an entry in bfdSessTable.</li> </ul>
mplsLspReoptimizeTimer brcdIp.1.2.15.1.2.3.1.17 Syntax: Unsigned32	Read-only	The number of seconds from the beginning of one reoptimization attempt to the beginning of the next attempt.
mplsLspCoS brcdIp.1.2.15.1.2.3.1.18 Syntax: ClassOfService	Read-only	The Class of Service.
mplsLspHopLimit brcdIp.1.2.15.1.2.3.1.19 Syntax: Unsigned32	Read-only	The number of hops this LSP can traverse.
mplsLspCspf brcdIp.1.2.15.1.2.3.1.20 Syntax: Integer	Read-only	Indicates if the CSPF path calculation is enabled on this LSP.
mplsLspCspfTieBreaker brcdIp.1.2.15.1.2.3.1.21 Syntax: Integer	Read-only	The tie-breaker to use for selecting the CSPF equal-cost paths. This field is not applicable if mplsLspCspf is disabled.
mplsLspFrrMode brcdIp.1.2.15.1.2.3.1.22 Syntax: Integer	Read-only	Indicates which protection method is to be used for MPLS Fast Reroute: <ul style="list-style-type: none"> <li>• “detour” for one-to-one backup</li> <li>• “facility” for facility backup</li> </ul>
mplsLspFrrSetupPriority brcdIp.1.2.15.1.2.3.1.23 Syntax: Unsigned32	Read-only	The setup priority for the MPLS Fast Reroute. The value of this variable is not applicable if mplsLspFrrMode is “none”.
mplsLspFrrHoldingPriority brcdIp.1.2.15.1.2.3.1.24 Syntax: Unsigned32	Read-only	The hold priority for the MPLS Fast Reroute. The value of this variable is not applicable if mplsLspFrrMode is “none”.
mplsLspFrrHopLimit brcdIp.1.2.15.1.2.3.1.25 Syntax: Unsigned32	Read-only	The hop limit for the MPLS Fast Reroute. The value of this variable is not applicable if mplsLspFrrMode is “none”.
mplsLspFrrBandwidth brcdIp.1.2.15.1.2.3.1.26 Syntax: Unsigned32	Read-only	The bandwidth constraint for the MPLS Fast Reroute. The value zero indicates that the detour route uses a best-effort value for bandwidth. The value of this variable is not applicable if mplsLspFrrMode is “none”.

Name, OID, and syntax	Access	Description
mplsLspFrrAdmGrpIncludeAny brcdIp.1.2.15.1.2.3.1.27 Syntax: MplsTunnelAffinity	Read-only	The administrative group setting that the device includes any of the interfaces that are members of the group when calculating detour routes for this LSP. The value of this variable is not applicable if mplsLspFrrMode is "none".
mplsLspFrrAdmGrpIncludeAll brcdIp.1.2.15.1.2.3.1.28 Syntax: MplsTunnelAffinity	Read-only	The administrative group setting that an interface must be a member of all of the groups to be considered in a detour route for the LSP. Any interface that is not a member of all the groups is eliminated from consideration. The value of this variable is not applicable if mplsLspFrrMode is "none".
mplsLspFrrAdmGrpExcludeAny brcdIp.1.2.15.1.2.3.1.29 Syntax: MplsTunnelAffinity	Read-only	The administrative group setting that the device excludes any of the interfaces that are members of the group when calculating detour routes for this LSP. The value of this variable is not applicable if mplsLspFrrMode is "none".
mplsLspPathSelectMode brcdIp.1.2.15.1.2.3.1.30 Syntax: Integer	Read-only	Indicates the path selection mode to use: <ul style="list-style-type: none"> <li>• Auto-select is the default mode. In this mode, the primary path is always selected to carry traffic when the primary path has stayed operating in the working state for at least the amount of time specified in mplsLspPathSelectRevertTimer.</li> <li>• For manual-select, the traffic is switched to a user-selected path specified in mplsLspPathSelectPathname after the selected path has stayed operating in the working state for at least the amount of time specified in mplsLspPathSelectRevertTimer.</li> <li>• For unconditional-select, the traffic is switched to and stays on the selected path regardless of the path's condition, even if it is in a failure state.</li> </ul>
mplsLspPathSelectPathname brcdIp.1.2.15.1.2.3.1.31 Syntax: DisplayString	Read-only	The user-selected secondary path for path-select mode "manual" and "unconditional".
mplsLspPathSelectRevertTimer brcdIp.1.2.15.1.2.3.1.32 Syntax: Unsigned32	Read-only	The number of seconds to wait after the primary or selected path comes up before traffic reverts to that path. A value of zero indicates that it will switch immediately after the current working path goes down.
mplsLspShortcutOspfAllowed brcdIp.1.2.15.1.2.3.1.33 Syntax: TruthVal	Read-only	Indicates that this LSP allows a shortcut between nodes in an autonomous system (AS). The OSPF route includes the LSP in its SPF calculation.
mplsLspShortcutIsisAllowed brcdIp.1.2.15.1.2.3.1.34 Syntax: TruthVal	Read-only	Indicates that this LSP allows a shortcut through the network to a destination based on the path's cost (metric). The traffic is forwarded through this LSP to destinations within the IS-IS routing domain. The IS-IS route includes the LSP in its SPF calculation.
mplsLspShortcutIsisLevel brcdIp.1.2.15.1.2.3.1.35 Syntax: Integer	Read-only	Indicates the level of the IS-IS routing enabled on the device. The value of this variable is not applicable if mplsLspShortcutIsisAllowed is "False".

Name, OID, and syntax	Access	Description
mplsLspShortcutIspAnnounce brcdIp.1.2.15.1.2.3.1.36 Syntax: TruthVal	Read-only	Indicates that this IS-IS shortcut will be announced or advertised. The metric to announce is specified by mplsLspShortcutIspAnnounceMetric. The value of this variable is not applicable if mplsLspShortcutIspAllowed is "False".
mplsLspShortcutIspAnnounceMetric brcdIp.1.2.15.1.2.3.1.37 Syntax: Unsigned32	Read-only	Indicates the metric value to announce for this shortcut. The value of this variable is not applicable if mplsLspShortcutIspAnnounce is "False".
mplsLspShortcutIspRelativeMetric brcdIp.1.2.15.1.2.3.1.38 Syntax: Unsigned32	Read-only	Indicates the relative metric used to compute the LSP cost when announce is not enabled. The value of this variable is not applicable if mplsLspShortcutIspAllowed is "False".

## MPLS administrative group table

The administrative groups, also known as resource classes or link colors, allow MPLS-enabled interfaces to be assigned to various classes. A group name can be associated to up to 32 administrative groups on the device.

The following table contains the MPLS AdminGroup MIB objects that lists the Administrative Group ID that has a configured group name. This is indexed by the Group ID, and with only one columnar object, which is the group name in the DisplayString type. Use the **show mpls policy** command to display the configured information of the Admin Group name to IPD mapping.

### NOTE

This MPLS administrative group table is a read-only table and supports the GET, GETBULK, and GETNEXT operations.

Name, OID, and syntax	Access	Description
brcdMplsAdminGroupTable brcdIp.1.2.15.1.1.2	None	The list of administrative groups (by ID) that have a configured group name.
brcdMplsAdminGroupId brcdIp.1.2.15.1.1.2.1.1 Syntax: Unsigned32	None	Identifies the administrative group ID in a 1-based index. The end user of this object must convert this to a 0-based because the index maps to the bit position in the constraint-based link selection.
brcdMplsAdminGroupName brcdIp.1.2.15.1.1.2.1.2 Syntax: DisplayString	Read-write	The group name with which this administrative group is associated.
brcdMplsAdminGroupRowStatus brcdIp.1.2.15.1.1.2.1.3 Syntax: RowSts	Read-only	The row status of an entry. <b>NOTE:</b> A set request to this table is not supported. Always returns "active" for the existing entries.



## MPLS interface table

The MPLS interface table contains all configured MPLS interfaces. It will be indexed by the ifIndex of the MPLS-enabled port or the VE interface. Use the **show mpls interface** command to display the configured information of interfaces and Admin Group settings.

---

### NOTE

The MPLS interface table is a read-only table and supports the GET, GETBULK, and GETNEXT operations.

---

Name, OID, and syntax	Access	Description
brcdMplsInterfaceTable brcdIp.1.2.15.1.1.3	None	The list of MPLS-enabled Interfaces.
brcdMplsInterfaceIndex brcdIp.1.2.15.1.1.3.1.1 Syntax: Unsigned32	None	The ifIndex of the MPLS-enabled port or VE interface.
brcdMplsInterfaceAdminGroup brcdIp.1.2.15.1.1.3.1.2 Syntax: MplsTunnelAffinity	Read-write	Specifies to which administrative groups this MPLS-enabled interface belongs to. It is represented in bitmapped format where each bit from 0 through 31 maps to the (internal) group ID. If a bit is set, it indicates that the corresponding group ID is configured for a particular MPLS interface.
brcdMplsInterfaceRowStatus brcdIp.1.2.15.1.1.3.1.3 Syntax: RowSts	Read-only	The row status of an entry. <b>NOTE:</b> A set request to this table is not supported. Always returns "active" for the existing entries.

---



# MPLS Layer 2 VPN MIB Definition

## In this chapter

- VLL endpoint table. . . . . 569
- VPLS endpoint2 table . . . . . 570
- VPLS instance table. . . . . 571

This chapter describes the MIB objects for the Virtual Local Area Network (VLAN) extended statistics supported on G2 products of Brocade MLX series and Brocade NetIron XMR devices.

Use the **extended-counters priority** command to configure a module to enable per VLAN port, or priority accounting (or extended counters) that applies to both ingress and egress counters. Use the **extended-counters routed-switched** command to configure the system to count switched and routed packets separately. All the counters reset to “0” when the state is changed. For more information, refer to the *Brocade MLXe and NetIron Family Configuration Guide*.

---

### NOTE

The Layer 2 VPN counters apply only to switched packets.

---

## VLL endpoint table

The following table (fdryVIIEndPointTable) contains objects for VLL and VLL-local endpoints that are not available in the pseudo Wire MIB.

---

### NOTE

Use the **snmp-server disable mib <mib-table-keyword>** command to disable the SNMP support for the table and use the **no** form of the command to re-enable the support. The overall SNMP-WALK performance is increased when the SNMP support is disabled for the table.

---

Name, OID, and syntax	Access	Description
pwIndex brcdIp.3.1.2.1.1 Syntax: pwIndexType	None	pwIndex of pwTable and pwEnetTable (foreign index)
pwEnetPwInstance brcdIp.3.1.4.1.1.1.1 Syntax: Unsigned32	None	The second index of pwEnetTable (foreign index) to support VLL-local: <ul style="list-style-type: none"> <li>• VLL - 1</li> <li>• vlllocal - 1 and 2</li> </ul>
fdryVIIEndPointServiceType brcdIp.1.2.15.2.1.1.1.1 Syntax: Integer	None	Indicates the service type for the endpoint: <ul style="list-style-type: none"> <li>• vll(1)</li> <li>• vlllocal(2)</li> </ul>

Name, OID, and syntax	Access	Description
fdryVIIEndPointVlanTagMode brcdIp.1.2.15.2.1.1.1.2 Syntax: Integer32	Read-only	Indicates the VLAN mode of this endpoint. Ports can have only the following modes: <ul style="list-style-type: none"> <li>tagged(1)</li> <li>untagged(2)</li> </ul>
fdryVIIEndPointClassOfService brcdIp.1.2.15.2.1.1.1.3 Syntax: Unsigned32	Read-only	For VLL, this value is used to select the appropriate tunnel whose CoS value is the same as, or almost approaching this value. For VLL-local, this value is applied to the inbound traffic of an endpoint. Valid values: 0 - 7
fdryVIIEndPointInHCPkts brcdIp.1.2.15.2.1.1.1.4 Syntax: Counter64	Read-only	This object indicates the number of packets ingressing into this endpoint. This is available in the output for <b>show mpls statistics vii</b> .
fdryVIIEndPointOutHCPkts brcdIp.1.2.15.2.1.1.1.5 Syntax: Counter64	Read-only	This object indicates the number of ingress packets from this endpoint as shown in the <b>show mpls statistics vii-local</b> output. For VLL-local, this value is the fdryVIIEndPointInHCPkts of the other endpoint.
fdryVIIEndPointAdminStatus brcdIp.1.2.15.2.1.1.1.6 Syntax: Integer32	Read-only	The desired administrative status of the endpoint. <ul style="list-style-type: none"> <li>up(1)</li> <li>down(2)</li> </ul>
fdryVIIEndPointOperStatus brcdIp.1.2.15.2.1.1.1.7 Syntax: PwOperStatusTC	Read-only	Indicates the operational status of the endpoint: <ul style="list-style-type: none"> <li>up(1)</li> <li>down(2)</li> </ul>
fdryVIIEndPointRowStatus brcdIp.1.2.15.2.1.1.1.8 Syntax: RowStatus	Read-only	Status will be active(1) if the endpoint is up; otherwise it will be not in service.
fdryVIIEndPointInnerVlanId brcdIp.1.2.15.2.1.1.1.9 Syntax: PwVlanCfg	Read-only	This value indicates the inner VLAN ID for this endpoint. Default: 0 (not configured or not supported.)
fdryVIIEndPointInHCOctets brcdIp.1.2.15.2.1.1.1.10 Syntax: Counter64	Read-only	This value indicates the number of octets into the endpoint from a Customer Edge device. This object is supported only on the Brocade Netron CES and Brocade Netron CER series devices.
fdryVIIEndPointOutHCOctets brcdIp.1.2.15.2.1.1.1.11 Syntax: Counter64	Read-only	This value indicates the number of octets egressing out from the endpoint towards the Customer Edge device. This object is supported only on the Brocade Netron CES and Brocade Netron CER series devices.

## VPLS endpoint2 table

The following table supports VPLS ISID mapping that is configured in the inner VLAN at the endpoint level. It contains objects for the VPLS endpoints that are not available in the pseudo Wire or draft-ietf-pwe3-pw-mib-11.txt MIB. The VPLS endpoint table replaces fdryVplsEndPointTable.

Name, OID, and syntax	Access	Description
fdryVplsEndPoint2Table brcdIp.1.2.15.2.2.3	None	This table specifies information about the VPLS endpoints that are not available in the PW MIB or the VPLS draft MIB. This table replaces fdryVplsEndPointTable, as inner VLAN or ISID has been added as an index of this table.
fdryVplsEndPoint2VlanId brcdIp.1.2.15.2.2.3.1.1 Syntax: PwVlanCfg	None	This value specifies the VLAN ID value of this endpoint.
fdryVplsEndPoint2InnerTagType brcdIp.1.2.15.2.2.3.1.2 Syntax: Integer	None	This value indicates the inner ID for the endpoint: <ul style="list-style-type: none"> <li>invalid(1)</li> <li>innerVlan(2)</li> <li>isid(3)</li> </ul> If no inner tag is specified, the value invalid(1) is returned.
fdryVplsEndPoint2InnerTag brcdIp.1.2.15.2.2.3.1.3 Syntax: Unsigned32	None	This value indicates the inner ID for this endpoint. If the index fdryVplsEndPoint2InnerTagType has the value isid(3), then this object will have the ISID value for that endpoint. The valid ISID value is between 256 (0x100) and 16777214 (0xFFFFFE). If no inner tag is specified, the value 0 is returned.
fdryVplsEndPoint2IfIndex brcdIp.1.2.15.2.2.3.1.4 Syntax: InterfaceIndex	None	This value specifies the ifIndex value of this endpoint.
fdryVplsEndPoint2VlanTagMode brcdIp.1.2.15.2.2.3.1.5 Syntax: VlanTagMode	Read-create	This value indicates the VLAN mode for this endpoint. The values dual(3) and other(4) are not used in this table.
fdryVplsEndPoint2InHCOctets brcdIp.1.2.15.2.2.3.1.6 Syntax: Counter64	Read-only	This counter indicates the number of octets ingressing into this endpoint from the Customer Edge device. This object is supported only on the Brocade Netron CES and Brocade Netron CER series devices.
fdryVplsEndPoint2Layer2State brcdIp.1.2.15.2.2.3.1.7 Syntax: Layer2StateTC	Read-only	The Layer 2 state of this VPLS endpoint.
fdryVplsEndPoint2OperStatus brcdIp.1.2.15.2.2.3.1.8 Syntax: PwOperStatusTC	Read-only	This object indicates the operational status of this endpoint: <ul style="list-style-type: none"> <li>up(1)</li> <li>down(2)</li> </ul> No other values are used in this table.
fdryVplsEndPoint2RowStatus brcdIp.1.2.15.2.2.3.1.9 Syntax: RowStatus	Read-create	This variable is used to create, modify, and delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except this object and the fdryVplsEndPointAdminStatus object.

## VPLS instance table

The following table can be used to configure additional virtual circuit properties that are not supported in vplsConfigTable.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
vplsConfigIndex brcdIp.3.4.1.1.2.1.1 Syntax: Unsigned32	None	This object is the index for this table.
fdryVplsClassOfService brcdIp.1.2.15.2.2.2.1.1 Syntax: Unsigned 32	Read-write	Indicates the Class of Service for this VPLS instance. This value is used to select the appropriate tunnel that has a CoS value is less than or equal to this value.
fdryVplsMaxMacLearned brcdIp.1.2.15.2.2.2.1.2 Syntax: Unsigned 32	Read-only	This value indicates the maximum number of MAC addresses that can be learned by this VPLS instance. No default value is specified as the system default can change.
fdryVplsClearMac brcdIp.1.2.15.2.2.2.1.3 Syntax: TruthValue	Read-only	The Set value of TRUE tells the system to clear all the MAC addresses learned by this VPLS instance. Setting a value of FALSE(2) returns an error. During read operations, FALSE(2) is returned at all times.
fdryVplsVcId brcdIp.1.2.15.2.2.2.1.4 Syntax: Unsigned 32	Read-only	The VPLS Instance ID of a given VPLS session.

# BFD MIB Definition

## In this chapter

- [BFD session table](#) ..... 573
- [BFD session performance table](#) ..... 575
- [BFD session mapping table](#) ..... 576
- [BFD scalar objects](#) ..... 577

## BFD session table

The following table specifies information about the Bidirectional Forwarding Detection (BFD) session.

Name, OID, and syntax	Access	Description
bfdSessTable brcdIp.3.3.1.1.2	None	Describes the BFD sessions.
bfdSessIndex brcdIp.3.3.1.1.2.1.1 Syntax: BfdSessIndexTC	None	Contains an index used to represent a unique BFD session on this device.
bfdSessApplicationId brcdIp.3.3.1.1.2.1.2 Syntax: Unsigned32	Read-only	Contains an index used to indicate a local application which owns or maintains this BFD session. For instance, the MPLS VPN process may maintain a subset of the total number of BFD sessions. This application ID provides a convenient way to segregate sessions by the applications which maintain them.
bfdSessDiscriminator brcdIp.3.3.1.1.2.1.3 Syntax: Unsigned32	Read-only	Specifies the local discriminator for this BFD session, used to uniquely identify it.
bfdSessRemoteDiscr brcdIp.3.3.1.1.2.1.4 Syntax: Unsigned32	Read-only	Specifies the session discriminator chosen by the remote system for this BFD session.
bfdSessUdpPort brcdIp.3.3.1.1.2.1.5 Syntax: InetPortNumber	Read-only	The UDP port for BFD. Default: The well-known value for this port.
bfdSessState brcdIp.3.3.1.1.2.1.6 Syntax: Integer	Read-only	The perceived state of the BFD session: <ul style="list-style-type: none"> <li>• adminDown(1)</li> <li>• down(2) - BFD session is down.</li> <li>• init(3) - BFD session is initializing.</li> <li>• up(4) - BFD session is up.</li> </ul>

Name, OID, and syntax	Access	Description
bfdSessRemoteHeardFlag brcdIp.3.3.1.1.2.1.7 Syntax: TruthValue	Read-only	Status of BFD packet reception from the remote system: <ul style="list-style-type: none"> <li>true(1) - The local device is actively receiving BFD packets from the remote device.</li> <li>false(0) - Either the local device has not received BFD packets recently (within the detection time) or the local device is attempting to tear down the BFD session.</li> </ul>
bfdSessDiag brcdIp.3.3.1.1.2.1.8 Syntax: Unsigned32	Accessible-f or-notify	A diagnostic code specifying the local system's reason for the last transition of the session from up(1) to some other state. The following values are applicable in the implementation of this MIB object: <ul style="list-style-type: none"> <li>No Diagnostic(1)</li> <li>Control Detection Time Expired(2)</li> <li>Echo Failed(3)</li> <li>Neighbor Signaled Session Down(4)</li> <li>Forwarding Plan Reset(5)</li> <li>Path Down(6)</li> <li>Concatenated Path Down(7)</li> <li>Admin Down(8)</li> <li>Reverse Concatenated Path Down(9)</li> </ul> Each notification uses one of the following varbinds: <ul style="list-style-type: none"> <li>bfdSessUp - High range value</li> <li>bfdSessDown - Low range value</li> </ul>
bfdSessOperMode brcdIp.3.3.1.1.2.1.9 Syntax: Integer	Read-only	Specifies the current operating mode of the BFD session: <ul style="list-style-type: none"> <li>asyncModeWEchoFun(1)</li> <li>asynchModeWOEchoFun(2)</li> <li>demandModeWEchoFunction(3)</li> <li>demandModeWOEchoFunction(4)</li> </ul>
bfdSessDemandModeDesiredFlag brcdIp.3.3.1.1.2.1.10 Syntax: TruthValue	Read-only	Indicates if the device uses the demand mode: <ul style="list-style-type: none"> <li>true(1) - The device will use demand mode.</li> <li>false(0) - The device will use demand mode.</li> </ul>
bfdSessEchoFuncModeDesiredFlag brcdIp.3.3.1.1.2.1.11 Syntax: TruthValue	Read-only	Indicates if the device uses Echo mode: <ul style="list-style-type: none"> <li>true(1) - The device will use Echo mode.</li> <li>false(0) - The device will use Echo mode.</li> </ul>
bfdSessControPlanIndepFlag brcdIp.3.3.1.1.2.1.12 Syntax: TruthValue	Read-only	Indicates if the device can continue to function when there is a disruption of the control plane: <ul style="list-style-type: none"> <li>true(1) - The local system BFD implementation is independent of the control plane.</li> <li>false(0) - The local system BFD implementation is dependent on the control plane.</li> </ul>
bfdSessAddrType brcdIp.3.3.1.1.2.1.13 Syntax: InetAddressType	Read-only	The IP address type of the interface associated with this BFD session: <ul style="list-style-type: none"> <li>unknown(0) - Allowed only when the outgoing interface is of the type point-to-point, or when the BFD session is not associated with a specific interface.</li> <li>ipv4(1) - IP address is IPv4.</li> <li>ipv6(2) - IP address is IPv6.</li> </ul>



Name, OID, and syntax	Access	Description
bfdSessAddr brcdIp.3.3.1.1.2.1.14 Syntax: InetAddress	Read-only	The IP address of the interface associated with this BFD session. Also used to enable BFD on a specific interface. The value is set to zero when the BFD session is not associated with a specific interface.
bfdSessDesiredMinTxInterval brcdIp.3.3.1.1.2.1.15 Syntax: Unsigned32	Read-only	Specifies the minimum interval, in microseconds, that the local system would like to use when transmitting BFD Control packets.
bfdSessReqMinRxInterval brcdIp.3.3.1.1.2.1.16 Syntax: Unsigned32	Read-only	Specifies the minimum interval, in microseconds, between received BFD Control packets the local system is capable of supporting.
bfdSessReqMinEchoRxInterval brcdIp.3.3.1.1.2.1.17 Syntax: BfdInterval	Read-only	Specifies the minimum interval, in microseconds, between received BFD Echo packets that this system is capable of supporting.
bfdSessDetectMult brcdIp.3.3.1.1.2.1.18 Syntax: Unsigned32	Read-only	Specifies the Detect time multiplier.
bfdSessStorType brcdIp.3.3.1.1.2.1.19 Syntax: StorageType	Read-only	Indicates the storage type for this object. Conceptual rows having the value "permanent" need not allow write-access to any columnar objects in the row.
bfdSessRowStatus brcdIp.3.3.1.1.2.1.20 Syntax: RowStatus	Read-only	Creates, modifies, or deletes a row in this table. When a row in this table has a row in the active(1) state, no objects in this row can be modified except bfdSessRowStatus and bfdSessStorageType.
bfdSessAuthPressFlag brcdIp.3.3.1.1.2.1.21 Syntax: TruthValue	Read-only	Indicates if the device wants the BFD sessions to be authenticated: <ul style="list-style-type: none"> <li>true(1) - BFD sessions will be authenticated.</li> <li>false(0) - BFD sessions will not be authenticated.</li> </ul>
bfdSessAuthenticationType brcdIp.3.3.1.1.2.1.22 Syntax: Integer	Read-only	Indicates the authentication type used for this BFD session, if BFD sessions are authenticated: <ul style="list-style-type: none"> <li>simplePassword(1)</li> <li>keyedMD5(2)</li> <li>meticulousKeyedMD5(3)</li> <li>keyedSHA1(4)</li> <li>meticulousKeyedSHA1(5)</li> </ul>

## BFD session performance table

This table specifies the performance counters for BFD sessions.

Name, OID, and syntax	Access	Description
bfdSessPerfTable brcdIp.3.3.1.1.3	None	The BFD session performance table.
bfdSessPerfPktIn brcdIp.3.3.1.1.3.1.1 Syntax: Counter32	Read-only	The total number of BFD messages received for this BFD session.

Name, OID, and syntax	Access	Description
bfdSessPerfPktOut brcdIp.3.3.1.1.3.1.2 Syntax: Counter32	Read-only	The total number of BFD messages sent for this BFD session.
bfdSessPerfUpTime brcdIp.3.3.1.1.3.1.3 Syntax: TimeStamp	Read-only	The value of sysUpTime on the most recent occasion at which the session came up. If no such up event exists, this object contains a zero value.
bfdSessPerfLastSessDownTime brcdIp.3.3.1.1.3.1.4 Syntax: TimeStamp	Read-only	The value of sysUpTime on the most recent occasion at which the last time communication was lost with the neighbor. If no such down event exists, this object contains a zero value.
bfdSessPerfLastCommLostDiag brcdIp.3.3.1.1.3.1.5 Syntax: BfdDiag	Read-only	The BFD diag code for the last time communication was lost with the neighbor. If no such down event exists, this object contains a zero value.
bfdSessPerfSessUpCount brcdIp.3.3.1.1.3.1.6 Syntax: Counter32	Read-only	The number of times this session has gone into the up state since the router last rebooted.
bfdSessPerfDiscTime brcdIp.3.3.1.1.3.1.7 Syntax: TimeStamp	Read-only	The value of sysUpTime on the most recent occasion at which any one or more of the session counters suffered a discontinuity. The relevant counters are the specific instances associated with this BFD session of any Counter32 object contained in BfdSessPerfTable. If no such discontinuities have occurred since the last re-initialization of the local management subsystem, then this object contains a zero value.
bfdSessPerfPktInHC brcdIp.3.3.1.1.3.1.8 Syntax: Counter64	Read-only	This value represents the total number of BFD messages received for this BFD session. It must be equal to the least significant 32 bits of bfdSessPerfPktIn if bfdSessPerfPktInHC is supported according to the rules spelled out in RFC 2863.
bfdSessPerfPktOutHC brcdIp.3.3.1.1.3.1.9 Syntax: Counter64	Read-only	This value represents the total number of BFD messages transmitted for this BFD session. It must be equal to the least significant 32 bits of bfdSessPerfPktIn if bfdSessPerfPktOutHC is supported according to the rules spelled out in RFC 2863.

## BFD session mapping table

The BFD session mapping table maps the complex indexing of the BFD sessions to the flat BfdIndex used in the BfdSessionTable.

Name, OID, and syntax	Access	Description
BfdSessMapTable brcdIp.3.3.1.1.4	None	The BFD session mapping table. <b>NOTE:</b> If the value of the bfdSessAddr (an OID) has more than 111 sub-identifiers, then OIDs of column instances in this table will have more than 128 sub-identifiers and cannot be accessed using SNMPv1, SNMPv2c, or SNMPv3.
bfdSessMapBfdIndex brcdIp.3.3.1.1.4.1.1 Syntax: Unsigned32	Read-only	Specifies the BFD index referred to by the indexes of this row. In essence, a mapping is provided between these indexes and the BFD session table.

## BFD scalar objects

The following table presents the BFD scalar objects that are supported.

Name, OID, and syntax	Access	Description
bfdAdminStatus brcdIp.3.3.1.1.1.1 Syntax: Integer	Read-only	The global administrative status of BFD in this router: <ul style="list-style-type: none"><li>enabled(1) - BFD process is active on at least one interface.</li><li>disabled(2) - BFD is disabled on all interfaces.</li></ul> Default: enabled(1)
bfdSessNotificationsEnable brcdIp.3.3.1.1.1.4 Syntax: TruthValue	Read-write	Indicates if notification messages are sent when BFD sessions are up and when they are down: <ul style="list-style-type: none"><li>true(1) - Notification messages are sent.</li><li>false(2) - Notifications messages are not sent.</li></ul> Default: false(2)

## 61 BFD MIB Definition

# AppleTalk MIB Definition

## In this chapter

- [AppleTalk general group](#) ..... 579
- [AppleTalk socket priority table](#) ..... 581
- [AppleTalk port zone filter table](#) ..... 582
- [AppleTalk port table](#) ..... 583
- [AppleTalk forwarding cache table](#) ..... 584
- [AppleTalk zone table](#) ..... 585
- [AppleTalk additional zone filter table](#) ..... 585

The AppleTalk MIB objects in this chapter are supported only on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

## AppleTalk general group

The following table contains general objects of AppleTalk routing functionalities.

Name, OID, and syntax	Access	Description
snRtATRoutingEnable brcdIp.1.2.10.1.1 Syntax: Integer	Read-write	Indicates if AppleTalk routing functions are enabled on this device: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snRtATClearArpCache brcdIp.1.2.10.1.2 Syntax: ClearStatus	Read-write	Indicates if the cache will be cleared: <ul style="list-style-type: none"> <li>• normal(0) – Data in AppleTalk ARP cache table will not be cleared.</li> <li>• clear(1) – Data in AppleTalk ARP cache table will be cleared.</li> </ul>
snRtATClearFwdCache brcdIp.1.2.10.1.3 Syntax: ClearStatus	Read-write	Indicates if all learned data from non-local networks that is currently in the AppleTalk forward cache table will be cleared: <ul style="list-style-type: none"> <li>• normal(0) – Data will not be cleared.</li> <li>• clear(1) – Data will be cleared.</li> </ul>
snRtATClearRoute brcdIp.1.2.10.1.4 Syntax: ClearStatus	Read-write	Indicates if all learned routes and zones (non-local routes and zones) that currently resident in the AppleTalk route table will be cleared: <ul style="list-style-type: none"> <li>• normal(0) – Data will not be cleared.</li> <li>• clear(1) – Data will be cleared.</li> </ul>
snRtATClearTrafficCounters brcdIp.1.2.10.1.5 Syntax: ClearStatus	Read-write	Indicates if AppleTalk RTMP, ZIP, AEP, DDP, and AARP statistics counters will be cleared: <ul style="list-style-type: none"> <li>• normal(0) – Counters will not be cleared.</li> <li>• clear(1) – Counters will be cleared.</li> </ul>

Name, OID, and syntax	Access	Description
snRtATArpRetransmitCount brcdIp.1.2.10.1.6 Syntax: Integer	Read-write	Indicates the maximum number of times that a packet will be sent out for ARP cache informational updates. The packet is sent out until the information is received or the maximum amount defined has been reached. Valid values: 1 – 10 Default: 2
snRtATArpRetransmitInterval brcdIp.1.2.10.1.7 Syntax: Integer	Read-write	The number of seconds the device waits for an AppleTalk ARP response before sending out the next ARP packet. Valid values: 1 – 120 seconds Default: 1 second
snRtATGleanPacketsEnabled brcdIp.1.2.10.1.8 Syntax: Integer	Read-write	Indicates if the AppleTalk glean packets function is enabled on this device: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> If enabled, the device tries to learn the MAC address from the packet instead of sending out an ARP request. Default: disabled(0)
snRtATRtmpUpdateInterval brcdIp.1.2.10.1.9 Syntax: Integer	Read-write	Indicates how often the device sends RTMP updates on AppleTalk interfaces. Valid values: 1 – 3600 seconds. Default: 10 seconds.
snRtATZipQueryInterval brcdIp.1.2.10.1.10 Syntax: Integer	Read-write	Indicates how often the device transmits a ZIP query. Valid values: 1 – 1000 seconds Default: 10 seconds
snRtATInRtmpPkts brcdIp.1.2.10.1.11 Syntax: Counter	Read-only	Shows the total number of RTMP packets received by this device.
snRtATOutRtmpPkts brcdIp.1.2.10.1.12 Syntax: Counter	Read-only	Shows the total number of RTMP packets that were transmitted by this device.
snRtATFilteredRtmpPkts brcdIp.1.2.10.1.13 Syntax: Counter	Read-only	Shows the total number of RTMP packets that were filtered by this device.
snRtATInZipPkts brcdIp.1.2.10.1.14 Syntax: Counter	Read-only	Shows the total number of ZIP packets that were received by this device.
snRtATOutZipPkts brcdIp.1.2.10.1.15 Syntax: Counter	Read-only	Shows the total number of ZIP packets that were transmitted by this device.
snRtATInZipGZLPkts brcdIp.1.2.10.1.16 Syntax: Counter	Read-only	Shows the total number of ZIP get zone list packets that were received by this device.
snRtATOutZipGZLPkts brcdIp.1.2.10.1.17 Syntax: Counter	Read-only	Shows the total number of ZIP get zone list packets that were transmitted by this device.
snRtATInZipNetInfoPkts brcdIp.1.2.10.1.18 Syntax: Counter	Read-only	Shows the total number of ZIP network information packets that were received by this device.

Name, OID, and syntax	Access	Description
snRtATOutZipNetInfoPkts brcdIp.1.2.10.1.19 Syntax: Counter	Read-only	Shows the total number of ZIP network information packets that were transmitted by this device.
snRtATInDdpPkts brcdIp.1.2.10.1.20 Syntax: Counter	Read-only	Shows the total number of DDP datagrams that were received by this device.
snRtATOutDdpPkts brcdIp.1.2.10.1.21 Syntax: Counter	Read-only	Shows the total number of DDP datagrams that were transmitted by this device.
snRtATForwardedDdpPkts brcdIp.1.2.10.1.22 Syntax: Counter	Read-only	Shows the number of input DDP datagrams whose DDP final destination was not this device. The device attempted to forward the datagrams to that final destination.
snRtATInDeliveredDdpPkts brcdIp.1.2.10.1.23 Syntax: Counter	Read-only	Shows the total number of input DDP datagrams whose final DDP destination is this device.
snRtATDroppedNoRouteDdpPkts brcdIp.1.2.10.1.24 Syntax: Counter	Read-only	Shows the total number of DDP datagrams dropped because this device could not find a route to their final destination.
snRtATDroppedBadHopCountsDdpPkts brcdIp.1.2.10.1.25 Syntax: Counter	Read-only	Shows the total number of input DDP datagrams that were dropped because this device was not their final destination and their hop count exceeded 15.
snRtATDroppedOtherReasonsDdpPkts brcdIp.1.2.10.1.26 Syntax: Counter	Read-only	Shows the total number of DDP datagrams dropped for various reasons. For example, the device ran out of resources so the datagrams were dropped.
snRtATInAarpPkts brcdIp.1.2.10.1.27 Syntax: Counter	Read-only	Shows the total number of AppleTalk ARP packets received by this device.
snRtATOutAarpPkts brcdIp.1.2.10.1.28 Syntax: Counter	Read-only	Shows the total number of AppleTalk ARP packets that were transmitted by this device.

## AppleTalk socket priority table

The following table shows the priority-level assigned to each QoS socket. By default, all AppleTalk sockets are in the best effort queue (chassis devices) or the normal queue (stackable devices).

Name, OID, and syntax	Access	Description
snRtATSocketPriorityTable brcdIp.1.2.10.2	None	AppleTalk socket priority table.
snRtATSocketPrioritySocket brcdIp.1.2.10.2.1.1 Syntax: Integer	Read-only	The socket number for an entry. There can be up to 254 entries.
snRtATSocketPriorityPriority brcdIp.1.2.10.2.1.2 Syntax: Integer	Read-write	Indicates the QoS priority for the socket. The priority level for a socket that applies to stackable devices: <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> </ul> The priority level for a socket that applies to Chassis devices: <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3),</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>

## AppleTalk port zone filter table

The AppleTalk Zone Filter Table shows if access to network zones is permitted or denied.

Name, OID, and syntax	Access	Description
snRtATPortZoneFilterTable brcdIp.1.2.10.3	None	AppleTalk port zone filter table.
snRtATPortZoneFilterPortIndex brcdIp.1.2.10.3.1.1 Syntax: PortIndex	Read-only	Shows the port index for a zone filter entry.
snRtATPortZoneFilterZone brcdIp.1.2.10.3.1.2 Syntax: DisplayString	Read-only	Shows the zone name granted for this filter: <ul style="list-style-type: none"> <li>0 to 32 octets of AppleTalk</li> <li>ASCII if outside of AppleTalk</li> </ul>
snRtATPortZoneFilterAction brcdIp.1.2.10.3.1.3 Syntax: Integer	Read-write	Indicates what the device will do with the AppleTalk packet if it matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>



Name, OID, and syntax	Access	Description
snRtATPortZoneFilterRtmpEnable brcdIp.1.2.10.3.1.4 Syntax: Integer	Read-write	Indicates if Routing Table Maintenance Protocol (RTMP) filtering is enabled on this device. RTMP filtering provides the zone filtering capability that allows devices to filter on a network. When this filter is enabled on an interface, the denied network numbers are removed from the RTMP packet before the packet is transmitted out of the interface. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtATPortZoneFilterRowStatus brcdIp.1.2.10.3.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Create sa new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## AppleTalk port table

The AppleTalk port table defines how long a MAC address learned by a port through ARP remains valid.

The device resets the timer to zero each time the ARP entry is refreshed and removes the entry if the timer reaches the ARP age.

ARP age is managed on an individual port basis. However, when you enter an ARP age value for a port and apply the change to the running-config file or save the change to the startup-config file, the change is saved as the global setting. If you try to set different values for different ports, the interface does not display an error message. Instead, the most recent value you enter before saving the configuration change becomes the global setting.

Name, OID, and syntax	Access	Description
snRtATPortTable brcdIp.1.2.10.4	None	The AppleTalk port table.
snRtATPortIndex brcdIp.1.2.10.4.1.1 Syntax: PortIndex	Read-only	The port index for port table entry.
snRtATPortArpAge brcdIp.1.2.10.4.1.2 Syntax: Integer	Read-write	Shows the number of minutes an ARP entry can be valid without relearning. This can be from 0 through 240 minutes. Default: 10 minutes. If this is set to 0, then the ARP entry will always relearn.
snRtATPortState brcdIp.1.2.10.4.1.3 Syntax: Integer	Read-only	Shows the state of this port: <ul style="list-style-type: none"> <li>other(1)</li> <li>down(2)</li> <li>up(3)</li> </ul>

Name, OID, and syntax	Access	Description
snRtATPortSeedRouter brcdIp.1.2.10.4.1.4 Syntax: Integer	Read-only	Shows if this port is a seed or non-seed router: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• seedRouter(2)</li> <li>• nonSeedRouter(3)</li> </ul>
snRtATPortOperationMode brcdIp.1.2.10.4.1.5 Syntax: Integer	Read-only	Shows the operational state of this port: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• seedRouter(2)</li> <li>• nonSeedRouter(3)</li> <li>• notOperational(4)</li> <li>• routingDisabled(5)</li> </ul>

## AppleTalk forwarding cache table

The AppleTalk forwarding cache table contains data learned from non-local networks that is currently resident in the AppleTalk cache.

Name, OID, and syntax	Access	Description
snRtATFwdCacheTable brcdIp.1.2.10.5	None	AppleTalk forwarding cache table.
snRtATFwdCacheIndex brcdIp.1.2.10.5.1.1 Syntax: Integer	Read-only	Shows the table index for a table entry.
snRtATFwdCacheNetAddr brcdIp.1.2.10.5.1.2 Syntax: OCTET STRING	Read-only	Shows the AppleTalk network address of a station.
snRtATFwdCacheMacAddr brcdIp.1.2.10.5.1.3 Syntax: OCTET STRING	Read-only	Shows the MAC address of an AppleTalk station. This object has six octets.
snRtATFwdCacheNextHop brcdIp.1.2.10.5.1.4 Syntax: Integer	Read-only	Shows the network address of the router in the next hop.
snRtATFwdCacheOutgoingPort brcdIp.1.2.10.5.1.5 Syntax: Integer	Read-only	Shows the outgoing port through which the packets will be forwarded. If set to zero, then no outgoing port has been defined.
snRtATFwdCacheType brcdIp.1.2.10.5.1.6 Syntax: Integer	Read-only	Shows the type of AppleTalk forwarding cache type: <ul style="list-style-type: none"> <li>• dynamic(1)</li> <li>• permanent(2)</li> </ul>

Name, OID, and syntax	Access	Description
snRtATFwdCacheAction brcdIp.1.2.10.5.1.7 Syntax: Integer	Read-only	Determines what the device will do if a match is found: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• forward(2)</li> <li>• forUs(3)</li> <li>• waitForArp(4)</li> <li>• dropPacket(5)</li> </ul>
snRtATFwdCacheVlanId brcdIp.1.2.10.5.1.8 Syntax: Integer	Read-only	Shows the ID of the VLAN associated with this entry. If set to zero, then no VLAN is associated with this entry.

## AppleTalk zone table

The AppleTalk zone table shows the network numbers and zones learned on the network.

Name, OID, and syntax	Access	Description
snRtATZoneTable brcdIp.1.2.10.6	None	AppleTalk zone table.
snRtATZoneIndex brcdIp.1.2.10.6.1.1 Syntax: Integer	Read-only	Shows the table index for an AppleTalk zone table entry.
snRtATZoneNetStart brcdIp.1.2.10.6.1.2 Syntax: ATNetworkNumber	Read-only	Shows the first AppleTalk network address in the range under this zone name. (Refer to the “ <a href="#">snRtATZoneName</a> ” object.)
snRtATZoneNetEnd brcdIp.1.2.10.6.1.3 Syntax: ATNetworkNumber	Read-only	Shows the last AppleTalk network addresses in the range under this zone name.
snRtATZoneName brcdIp.1.2.10.6.1.4 Syntax: DisplayString	Read-only	Shows the zone’s name. There can be up to 32 characters in this object.

## AppleTalk additional zone filter table

The AppleTalk additional zone filter table contains information about zones that do not match any zones defined in the “[AppleTalk zone table](#)” on page 585.

Name, OID, and syntax	Access	Description
snRtATAddZoneFilterTable brcdIp.1.2.10.7	None	The AppleTalk additional zone filter table.
snRtATAddZoneFilterPortIndex brcdIp.1.2.10.7.1.1 Syntax: PortIndex	Read-only	Shows the port index for an additional zone filter table entry.

<b>Name, OID, and syntax</b>	<b>Access</b>	<b>Description</b>
snRtATAddZoneFilterAction brcdIp.1.2.10.7.1.2 Syntax: Integer	Read-write	Indicates what the device will do when a match is found: <ul style="list-style-type: none"><li>• deny(0)</li><li>• permit(1)</li></ul>
snRtATAddZoneFilterRtmpEnable brcdIp.1.2.10.7.1.3 Syntax: Integer	Read-write	Indicates if RTMP filtering on an additional zone is enabled on this device: <ul style="list-style-type: none"><li>• disabled(0)</li><li>• enabled(1)</li></ul>

# Layer 4 Switch Group MIB Definition

---

## In this chapter

• Layer 4 general MIBs. . . . .	588
• Server load balancing table . . . . .	588
• Server load balancing traffic information . . . . .	589
• Session. . . . .	590
• Hot standby . . . . .	590
• Enabling or disabling Layer 4 traps . . . . .	592
• Server cache groups . . . . .	593
• GSLB group global . . . . .	594
• Virtual server configuration table . . . . .	595
• Real server configuration table . . . . .	597
• Virtual server port configuration table . . . . .	598
• Real server port configuration table . . . . .	600
• Layer4 bind table . . . . .	600
• Virtual server statistics table . . . . .	601
• Virtual server port statistics table . . . . .	603
• Layer 4 policy table . . . . .	606
• Layer 4 policy port access table . . . . .	607
• Layer 4 trap variable binding table. . . . .	608
• Web cache table . . . . .	609
• Web cache group table . . . . .	610
• Web cache traffic statistics table . . . . .	611
• Web uncached traffic statistics table. . . . .	613
• Web cache real server port table . . . . .	614
• GSLB remote ServerIron configuration table. . . . .	615
• Real server history control table. . . . .	616
• Real server history group table. . . . .	617
• Real server port history control group table . . . . .	618
• Real server port history group table. . . . .	620
• Virtual server history control group table. . . . .	621
• Virtual server history table . . . . .	622
• Virtual server port history control table . . . . .	624
• Virtual server port history table . . . . .	625

**NOTE**

The objects in this chapter are supported only on the ServerIron devices.

The following tables have been replaced in real server objects:

- The real server table (snL4RealServerTable) has been deprecated and replaced by the real server configuration table (snL4RealServerCfg).
- The real server port table (snL4RealServerPortTable) has been replaced by the real server port configuration table (snL4RealServerPortCfg).
- The real server status table (snL4RealServerStatusTable) has been replaced by the real server statistics table (snL4RealServerStatistic).
- The real server port status table (snL4RealServerPortStatusTable) has been replaced by the real server port statistics table (snL4RealServerPortStatisticTable).

The following tables have been replaced in virtual server objects:

- The virtual server table (snL4VirtualServerTable) has been replaced by the virtual server configuration table (snL4VirtualServerCfg).
- The virtual server port table (snL4VirtualServerPortTable) has been replaced by the virtual server port configuration table (snL4VirtualServerPortCfg).
- The virtual server status table (snL4VirtualServerStatusTable) has been replaced by the virtual server statistics table (snL4VirtualServerStatistic).
- The virtual server port status table (snL4VirtualServerPortStatusTable) has been replaced by the virtual server port statistics table (snL4VirtualServerPortStatisticTable).

## Layer 4 general MIBs

The following objects define TCP and UDP sessions in a ServerIron device.

Name, OID, and syntax	Access	Description
snL4MaxSessionLimit brcdIp.1.1.4.1.1 Syntax: Integer	Read-write	Specifies the maximum number of active sessions the ServerIron device allows. An active session is an entry in the ServerIron session table. A UDP or TCP session that has become idle but has not yet timed out (according to the UDP or TCP age timer) is an active session in the table.  Valid values: 0 - 1,000,000 Default: Depends on the target system configuration
snL4TcpSynLimit brcdIp.1.1.4.1.2 Syntax: Integer	Read-write	Shows the maximum number of TCP SYN requests per second per real server that the ServerIron device is allowed to send. A TCP SYN request is a packet that a client sends to request a TCP connection to the server. Limiting the number of TCP SYN requests that can be sent to the server each second protects the ServerIron device from TCP SYN request attacks.  Valid values: 1 - 65535 Default: 65535

## Server load balancing table

The following objects define TCP and UDP sessions in a ServerIron device.

Name, OID, and syntax	Access	Description
snL4slbGlobalSDAType brcdIp.1.1.4.1.3 Syntax: Integer	Read-write	Shows the method the ServerIron device uses to select a real server for client request: <ul style="list-style-type: none"> <li>leastconnection(1) – The ServerIron device sends the request to the real server that currently has the fewest number of active connections with clients.</li> <li>roundrobin(2) – The ServerIron device sends the request to each server in rotation, regardless of how many connections each server has.</li> <li>weighted(3) – The ServerIron device uses the weights you assign to the real servers to select a real server. The weights are based on the number of entries the ServerIron device has for each server in the sessions table.</li> </ul> Default: leastconnection(1)
snL4slbTotalConnections brcdIp.1.1.4.1.4 Syntax: Counter	Read-only	Shows the total number of client connections on the ServerIron device since its last reboot. A connection consists of two sessions: client-to-server session and server-to-client session.
snL4slbLimitExceeds brcdIp.1.1.4.1.5 Syntax: Integer	Read-only	Shows the number of times the TCP SYN requests from clients exceeded the configured “snL4TcpSynLimit” value.

## Server load balancing traffic information

Server Load Balancing (SLB) is based on associations between real servers and virtual servers. The real servers are your application servers. The virtual servers have one or more virtual IP addresses (VIPs). You associate a real server with a virtual server by binding TCP or UDP ports on the real servers with TCP or UDP ports on the virtual server. When a client sends a TCP or UDP request for a port on the virtual server, the ServerIron device sends the client’s request to the real server.

The following objects provide information on the SLB traffic packets that were transmitted between the server and the clients.

Name, OID, and syntax	Access	Description
snL4slbForwardTraffic brcdIp.1.1.4.1.6 Syntax: Counter	Read-only	Shows the number of packets sent by clients to the server.
snL4slbReverseTraffic brcdIp.1.1.4.1.7 Syntax: Counter	Read-only	Shows the number of packets sent by servers to clients. Generally, this value is 0 unless the client is using FTP or another application that causes the server to initiate connections.
snL4slbDrops brcdIp.1.1.4.1.8 Syntax: Integer	Read-only	Shows the total number of packets dropped by the ServerIron device. This statistic includes the following: <ul style="list-style-type: none"> <li>TCP Resets – Resets sent by the ServerIron device.</li> <li>Forward Resets – Resets from the client.</li> <li>Unsuccessful requests – Requests sent to a TCP or UDP port that is not bound to the request’s destination VIP.</li> </ul>
snL4slbDangling brcdIp.1.1.4.1.9 Syntax: Integer	Read-only	Shows the number of old types of connections. For use by Foundry technical support.

Name, OID, and syntax	Access	Description
snL4slbDisableCount brcdIp.1.1.4.1.10 Syntax: Integer	Read-only	Shows the number of packets the ServerIron device dropped because they were sent by a client to a VIP port that is bound to a disabled real server port.
snL4slbAged brcdIp.1.1.4.1.11 Syntax: Integer	Read-only	Shows the total number of TCP and UDP sessions that have been aged out and closed. A session ages out when the age timer configured on the ServerIron device expires.
snL4slbFinished brcdIp.1.1.4.1.12 Syntax: Integer	Read-only	The total number of TCP connections that are either in the FIN or RST state.

## Session

The following table contains object that define a session in a ServerIron device.

Name, OID, and syntax	Access	Description
snL4FreeSessionCount brcdIp.1.1.4.1.13 Syntax: Integer	Read-only	Shows the number of sessions that are still available for use. This number is the maximum number of sessions configured, minus the number of active sessions.

## Hot standby

Hot standby redundancy is a backup feature that allows a ServerIron device to serve as an automatic backup for another ServerIron device. Each hot-standby pair consists of two ServerIron devices. One ServerIron device serves as the primary or active ServerIron device, and the other serves as the secondary or standby ServerIron device. The standby ServerIron device becomes active only if the primary ServerIron device fails due to loss of power or loss of data path. The active and standby ServerIron devices must have the same SLB or TCS configuration and share the same virtual MAC address. The shared MAC address can be selected from the available pool on either the active ServerIron device or the standby ServerIron device.

The following objects apply to the hot standby redundancy feature.

Name, OID, and syntax	Access	Description
snL4BackupInterface brcdIp.1.1.4.1.14 Syntax: Integer	Read-write	Identifies which port is the hot standby port. This is the port that serves as a private link between the active and the redundant ServerIrons. The ServerIrons use this port to monitor any failover and to communicate those events to the standby. Valid values: 0 – 26
snL4BackupMacAddr brcdIp.1.1.4.1.15 Syntax: Physical address	Read-write	Identifies the associated MAC address for the backup monitoring port. The active and backup ServerIron must have the same MAC address.



Name, OID, and syntax	Access	Description
snL4Active brcdIp.1.1.4.1.16 Syntax: L4flag	Read-only	The “snL4Redundancy” object and this object are the same. Indicates if this ServerIron has been configured as redundant or hot standby: <ul style="list-style-type: none"> <li>• false(0) – This ServerIron is the active one.</li> <li>• true(1) – This ServerIron is the standby.</li> </ul>
snL4Redundancy brcdIp.1.1.4.1.17 Syntax: Integer	Read-only	The “snL4Active” object and this object are the same. Indicates if this ServerIron has been configured as redundant or hot standby: <ul style="list-style-type: none"> <li>• false(0) – This ServerIron is the active one.</li> <li>• true(1) – This ServerIron is the standby.</li> </ul>
snL4Backup brcdIp.1.1.4.1.18 Syntax: L4flag	Read-only	Indicates if the ServerIron is the backup (standby) ServerIron: <ul style="list-style-type: none"> <li>• false(0) – This ServerIron is the active one.</li> <li>• true(1) – This ServerIron is the standby.</li> </ul>
snL4BecomeActive brcdIp.1.1.4.1.19 Syntax: Integer	Read-only	Shows the number of times this ServerIron has changed from standby to active.
snL4BecomeStandBy brcdIp.1.1.4.1.20 Syntax: Integer	Read-only	Shows the number of times this ServerIron has changed from active to standby.
snL4BackupState brcdIp.1.1.4.1.21 Syntax: Integer	Read-only	Shows the state of the backup or redundancy link of the active or standby ServerIron: <ul style="list-style-type: none"> <li>• slbSyncComplete(0) – Synchronization is complete.</li> <li>• slbSyncReqMap(1) – Port map has been synchronized.</li> <li>• slbSyncreqMac(2) – MAC addresses have been synchronized.</li> <li>• slbSyncreqServers(3) – Server information has been synchronized.</li> <li>• slbSyncReqL4(4) – L4 packets have been synchronized.</li> </ul>
snL4NoPDUSent brcdIp.1.1.4.1.22 Syntax: Integer <b>NOTE:</b> This object is not supported.	Read-only	The number of Layer 4 or MAC-layer PDUs sent.
snL4NoPDUCount brcdIp.1.1.4.1.23 Syntax: Integer	Read-only	The number of missed Layer 4 or MAC-layer PDUs.
snL4NoPortMap brcdIp.1.1.4.1.24 Syntax: Integer	Read-only	Shows the number of missed port map PDUs, which are PDUs used by ServerIron to discover information about the maps on the other ServerIron.
snL4unsuccessfulConn brcdIp.1.1.4.1.25 Syntax: Integer	Read-only	Shows the number of packets that were dropped due to one of the following reasons: <ul style="list-style-type: none"> <li>• A deny filter configured on the switch matched the packet, causing the switch to drop the packet.</li> <li>• A client requested a TCP or UDP port that is not bound on the virtual interface.</li> </ul>
snL4PingInterval brcdIp.1.1.4.1.26 Syntax: Integer	Read-write	Shows how often the ServerIron sends a Layer 3 IP ping to test the basic health and reachability of the real servers. This object allows you to change the interval between the ping packets. Valid values: 1 – 10 seconds Default: 2 seconds

Name, OID, and syntax	Access	Description
snL4PingRetry brcdIp.1.1.4.1.27 Syntax: Integer	Read-write	Shows the number of times the ServerIron resends a ping to a real server that is not responding before the server fails the health check. Valid values: 2 – 10 tries Default: 4 tries
snL4TcpAge brcdIp.1.1.4.1.28 Syntax: Integer	Read-write	Specifies how many minutes a TCP server connection can remain inactive before the session times out and the ServerIron disconnects the session. Changing the value of this object affects only the new TCP sessions that are opened after the change is made. Current sessions will use the maximum age that was specified before the change occurred. This object globally sets the age for all TCP ports. To override this value for a port, specify the age locally on the individual port using the device's CLI. Valid values: 2 – 60 minutes Default: 30 minutes
snL4UdpAge brcdIp.1.1.4.1.29 Syntax: Integer	Read-write	Specifies how many minutes a UDP server connection can remain inactive before the session times out and the ServerIron closes the session. Changing the value of this object affects only the new UDP sessions that are opened after the change is made. Current sessions will use the maximum age that was specified before the change occurred. This object globally sets the age for all UDP ports. To override this value for a port, specify the age locally on the individual port using the device's CLI. Valid values: 2 – 60 minutes Default: 5 minutes

## Enabling or disabling Layer 4 traps

The following objects enable or disable traps for Layer 4 functionalities.

Name, OID, and syntax	Access	Description
snL4EnableMaxSessionLimitReachedTrap brcdIp.1.1.4.1.30 Syntax: Integer	Read-write	Indicates whether this device has been enabled to generate traps if the maximum number of connections has been reached: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableTcpSynLimitReachedTrap brcdIp.1.1.4.1.31 Syntax: Integer	Read-write	Indicates whether this device has been enabled to generate traps if the maximum number of TCP SYN request has been reached: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableRealServerUpTrap brcdIp.1.1.4.1.32 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server is up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableRealServerDownTrap brcdIp.1.1.4.1.33 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server is down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and syntax	Access	Description
snL4EnableRealServerPortUpTrap brcdIp.1.1.4.1.34 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server TCP port is up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableRealServerPortDownTrap brcdIp.1.1.4.1.35 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server TCP port is down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableRealServerMaxConnectionsLimitReachedTrap brcdIp.1.1.4.1.36 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server reaches its maximum number of connections: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableBecomeStandbyTrap brcdIp.1.1.4.1.37 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the Server Load Balancing switch changes its state from active to standby: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableBecomeActiveTrap brcdIp.1.1.4.1.38 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the Server Load Balancing switch changes its state from standby to active: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4slbRouterInterfacePortMask brcdIp.1.1.4.1.39 Syntax: Integer	Read-only	Shows the router interface port mask. This object is not used or supported.

## Server cache groups

All cache servers must belong to a cache group. The ServerIron device uses a hashing algorithm to distribute HTTP requests among the servers in the cache group. In addition, cache groups provide automatic recovery from a failed or otherwise out-of-service Web cache server. If a Web cache server failure occurs, the ServerIron device detects the failure and directs subsequent requests to the next available cache server or forwards the request directly to the WAN link. Up to four server cache groups can be assigned to a ServerIron device.

Name, OID, and syntax	Access	Description
snL4MaxNumWebCacheGroup brcdIp.1.1.4.1.40 Syntax: Integer	Read-only	Shows the maximum number of Web cache groups that can be configured on this ServerIron.

Name, OID, and syntax	Access	Description
snL4MaxNumWebCachePerGroup brcdIp.1.1.4.1.41 Syntax: Integer	Read-only	Shows the maximum number of Web cache servers that a Web cache group can have.
snL4WebCacheStateful brcdIp.1.1.4.1.42 Syntax: L4Status <b>NOTE:</b> This object is not supported.	Read-write	Web cache servers cache-stateful.

## GSLB group global

The following table contains the objects of Global Server Load Balancing (GSLB) group table.

Name, OID, and syntax	Access	Description
snL4EnableGslbHealthCheckIpUpTrap brcdIp.1.1.4.1.43 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address passes its Layer 4 TCP or UDP health check, resulting in a status change to up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpDownTrap brcdIp.1.1.4.1.44 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps whenever GSLB determines that the IP address belonging to a domain name for which the ServerIron is providing GSLB is DOWN: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpPortUpTrap brcdIp.1.1.4.1.45 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address passes its Layer 4 TCP or UDP health check, resulting in a status change to up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpPortDownTrap brcdIp.1.1.4.1.46 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address fails its Layer 4 TCP or UDP health check, resulting in a status change to down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteGslbSiDownTrap brcdIp.1.1.4.1.47 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the connection from this site to the remote GSLB ServerIron is down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteGslbSiUpTrap brcdIp.1.1.4.1.48 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the connection from this site to the remote GSLB ServerIron is up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and syntax	Access	Description
snL4EnableGslbRemoteSiDownTrap brcdIp.1.1.4.1.49 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the GSLB connection from this GSLB ServerIron to the remote ServerIron is down: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteSiUpTrap brcdIp.1.1.4.1.50 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the GSLB connection from this GSLB ServerIron to remote the ServerIron is up: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4slbRouterInterfacePortList brcdIp.1.1.4.1.51 Syntax: OCTET STRING	Read-write	Shows the router interface port list. Each port index is a 16-bit integer in big-endian order. The first 8 bits indicate the slot number, the other 8 bits indicate the port number.

## Virtual server configuration table

The virtual server configuration table allows you to configure virtual servers on the ServerIron devices.

Name, OID, and syntax	Access	Description
snL4VirtualServerCfgTable brcdIp.1.1.4.21.1	None	Virtual server configuration table.
snL4VirtualServerCfgVirtualIP brcdIp.1.1.4.21.1.1.1 Syntax: IpAddress	Read-only	Specifies the virtual server IP address.
snL4VirtualServerCfgName brcdIp.1.1.4.21.1.1.2 Syntax: L4ServerName	Read-write	Specifies the name of the virtual server. This name must be unique among the other virtual servers. Valid values: 1 – 32 octets
snL4VirtualServerCfgAdminStatus brcdIp.1.1.4.21.1.1.3 Syntax: L4Status	Read-write	Indicates if the virtual server feature is enabled on the ServerIron: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)

Name, OID, and syntax	Access	Description
snL4VirtualServerCfgSDAType brcdIp.1.1.4.21.1.1.4 Syntax: Integer	Read-write	<p>Specifies the load-balancing or Session Distribution Algorithm (SDA) method that the ServerIron uses to select a real server for a client request. The following methods are supported:</p> <ul style="list-style-type: none"> <li>• default(0) – The ServerIron uses the global SDAType configured (snL4SibGlobalSDAType).</li> <li>• leastconnection(1) – The ServerIron sends the request to the real server that currently has the fewest active connections with clients.</li> <li>• roundrobin(2) – The ServerIron sends the request to each real server in rotation, regardless of how many connections or sessions each real server has.</li> <li>• weighted(3) – The ServerIron uses the weights you assign to the real servers to select a real servers. The weights are based on the number of session table entries the switch has for each server.</li> </ul> <p>Default: default(0)</p>
snL4VirtualServerCfgRowStatus brcdIp.1.1.4.21.1.1.5 Syntax: L4RowStatus	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>
snL4VirtualServerCfgDeleteState brcdIp.1.1.4.21.1.1.6 Syntax: L4DeleteState	Read-only	<p>Shows the state of the port being deleted:</p> <ul style="list-style-type: none"> <li>• done(0) – The port is deleted.</li> <li>• waitunbind(1) – The port is in an unbind state.</li> <li>• waitdelete(2) – The port is in a delete state.</li> </ul>
snL4VirtualServerCfgSymPriority brcdIp.1.1.4.21.1.1.7 Syntax: Integer	Read-write	<p>When a pair of SLB switches are configured to provide redundancy for individual virtual IP addresses (VIPs), a symmetric SLB priority must be specified on each switch for each of the VIPs. The switch with the higher priority for a given VIP is the default active switch for that VIP. The other switch is the default standby for the VIP.</p> <p>It is recommended that you use a priority of 2 (instead of 1) as a low priority or 254 (instead of 255) as a high priority. This method would make it easy to force a failover of the high priority switch to a low priority switch by simply changing the priority on one of the switches.</p> <p>For example, you can force a failover by changing the priority on the high priority switch from 254 to 1. because the priority on the low priority switch is 2, the low priority switch takes over for the VIP. Likewise, you can force the low priority switch to take over by changing its priority to 255, because the priority on the high priority switch is only 254.</p> <p>Valid values: 0 – 255 Default: 0</p>

## Real server configuration table

The real server configuration table shows the configuration of real servers. A real server is an application server that is load-balanced by the SLB switch.

Name, OID, and syntax	Access	Description
snL4RealServerCfgTable brcdIp.1.1.4.19.1	None	Real server configuration table.
snL4RealServerCfgIP brcdIp.1.1.4.19.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address of the real server.
snL4RealServerCfgName brcdIp.1.1.4.19.1.1.2 Syntax: L4ServerName	Read-write	Shows the name of the real server. This name must be unique among the real server names. Valid values: 1- 32 octets
snL4RealServerCfgAdminStatus brcdIp.1.1.4.19.1.1.3 Syntax: L4Status	Read-write	Enables or disables the real server: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4RealServerCfgMaxConnections brcdIp.1.1.4.19.1.1.4 Syntax: Integer	Read-write	Specifies the maximum number of connections the ServerIron can maintain in its session table for a real server. When a real server reaches this threshold, an SNMP trap is sent. When all the real servers in a server pool reach this threshold, additional TCP or UDP packets are dropped, and an ICMP destination unreachable message is sent. Valid values: 0 - 1000000 Default: 1000000
snL4RealServerCfgWeight brcdIp.1.1.4.19.1.1.5 Syntax: Integer	Read-write	Specifies the server's weight relative to other real servers. This weight is based on the number of session table entries the ServerIron has for TCP or UDP sessions with the real server. Set this object to 0 to disable it if a weight based on the server response time is desired. Valid values: 0 - 65000. Setting this object to 0 disables it. Default: 1
snL4RealServerCfgRowStatus brcdIp.1.1.4.19.1.1.6 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) - Deletes the row.</li> <li>create(4) - Creates a new row.</li> <li>modify(5) - Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) - No such row.</li> <li>invalid(1) - Row is inoperative.</li> <li>valid(2) - Row exists and is valid.</li> </ul>

Name, OID, and syntax	Access	Description
snL4RealServerCfgDeleteState brcdIp.1.1.4.19.1.1.7 Syntax: L4DeleteState	Read-only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>
snL4RealServerCfgSrcNat brcdIp.1.1.4.19.1.1.8 Syntax: DisplayString	Read-only	Returns the string "src-nat" if source NAT for the real server is configured; otherwise, the display is empty if source NAT is not configured.

## Virtual server port configuration table

The virtual server port configuration table contains all the ports configured for the virtual server. The virtual server port configuration table allows you to configure attributes for individual ports and override global attributes for those ports.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortCfgTable brcdIp.1.1.4.22.1	None	Virtual Server Port Configuration table.
snL4VirtualServerPortCfgIP brcdIp.1.1.4.22.1.1.1 Syntax: IPAddress	Read-only	Indicates the IP address of the virtual server where the port is located.
snL4VirtualServerPortCfgPort brcdIp.1.1.4.22.1.1.2 Syntax: Integer	Read-only	Specifies the port that the virtual server (SLB switch) uses to listen for connections from clients. Valid values: 0 – 65535
snL4VirtualServerPortCfgServerName brcdIp.1.1.4.22.1.1.3 Syntax: L4ServerName	Read-only	Specifies the name of the virtual server. This name must be different from the names of other virtual servers. Valid values: 1 – 32 octets
snL4VirtualServerPortCfgAdminStatus brcdIp.1.1.4.22.1.1.4 Syntax: L4Status	Read-write	Enables or disables the port on the virtual server for accepting client requests and load balancing those requests among the real servers: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul> Default: enable(1)



Name, OID, and syntax	Access	Description
snL4VirtualServerPortCfgSticky brcdIp.1.1.4.22.1.1.5 Syntax: Integer	Read-write	<p>Enables or disables the “sticky” feature. If enabled, the ServerIron sends all requests from the same client to this application and to the same real server during the current session. By default, the ServerIron sends a client request to the next available real server, based on the load balancing method. This is true regardless of whether the client has already sent a request for the same application. If the switch has to send all of a client’s requests for a given application to the same real server during a client session with the server, set this object to enable(1) for the application port.</p> <p>Set this object and the “snL4VirtualServerPortCfgConcurrent” object to enable(1), on ServerIron FTP ports that use passive FTP:</p> <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> <p>Default: disable(0)</p>
snL4VirtualServerPortCfgConcurrent brcdIp.1.1.4.22.1.1.6 Syntax: Integer	Read-write	<p>Enables or disables the port for concurrent connections. A port that allows concurrent connections can have more than one connection open to the same client at the same time.</p> <p>The concurrent feature allows a client to have sessions on different application ports on the same real server at the same time. When an application port is enabled to be concurrent, the real server can open additional concurrent TCP or UDP sessions with the client using arbitrary TCP or UDP port numbers.</p> <p>Set this object and the “snL4VirtualServerPortCfgSticky” object to enable(1) on ServerIron FTP ports that use passive FTP:</p> <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> <p>Default: disable(0)</p>
snL4VirtualServerPortCfgRowStatus brcdIp.1.1.4.22.1.1.7 Syntax: L4RowStatus	Read-write	<p>Controls the management of the table rows. The following values can be written:</p> <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a “bad value” error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>
snL4VirtualServerPortCfgDeleteState brcdIp.1.1.4.22.1.1.8 Syntax: L4DeleteState	Read-only	<p>Shows the state of the port being deleted:</p> <ul style="list-style-type: none"> <li>• done(0) – The port is deleted.</li> <li>• waitunbind(1) – The port is in an unbind state.</li> <li>• waitdelete(2) – The port is in a delete state.</li> </ul>

## Real server port configuration table

The real server port table contains all the ports that have been configured for the real server. The real server port configuration table also shows information for remote servers.

Most attributes are configured globally for the server's port. The following table allows you to change individual port attributes and override global settings.

Name, OID, and syntax	Access	Description
snL4RealServerPortCfgTable brcdIp.1.1.4.20.1	None	Real server port table.
snL4RealServerPortCfgIP brcdIp.1.1.4.20.1.1.1 Syntax: IpAddress	Read-only	Specifies the IP address for the server.
snL4RealServerPortCfgServerName brcdIp.1.1.4.20.1.1.2 Syntax: L4ServerName	Read-only	Specifies the name of the server. This name must be unique among the other servers. Valid values: 1 – 32 octets
snL4RealServerPortCfgPort brcdIp.1.1.4.20.1.1.3 Syntax: Integer	Read-only	Specifies the port that the server port uses to listen for connections. Valid values: 0 – 65535
snL4RealServerPortCfgAdminStatus brcdIp.1.1.4.20.1.1.4 Syntax: L4Status	Read-write	Enables or disables the application port on the server: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4RealServerPortCfgRowStatus brcdIp.1.1.4.20.1.1.5 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snL4RealServerPortCfgDeleteState brcdIp.1.1.4.20.1.1.6 Syntax: L4DeleteState	Read-only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>
snL4RealServerPortCfgMaxConnections brcdIp.1.1.4.20.1.1.7 Syntax: Integer	Read-write	Defines the maximum number of connections allowed per port. Enter a value up to 1000000.

## Layer4 bind table

### NOTE

This table has been deprecated and use the snL4VirtualServerBindTable instead.

Name, OID, and syntax	Access	Description
snL4BindTable brcdIp.1.1.4.6.1	None	The Bind table.
snL4BindIndex brcdIp.1.1.4.6.1.1.1 Syntax: Integer	Read-only	The index for this entry. This must be unique and care must be taken to assign an unused index when creating an entry.
snL4BindVirtualServerName brcdIp.1.1.4.6.1.1.2 Syntax: L4ServerName	Read-write	Indicates the name of the virtual server. Valid values: 1 – 32 octets
snL4BindVirtualPortNumber brcdIp.1.1.4.6.1.1.3 Syntax: Integer	Read-write	Specifies the TCP or UDP port number on the virtual server that will be bound to the real server. Valid values: 0 – 65535
snL4BindRealServerName brcdIp.1.1.4.6.1.1.4 Syntax: L4ServerName	Read-write	Indicates the name of the real server that has been configured on the ServerIron. Valid values: 1 – 32 octets
snL4BindRealPortNumber brcdIp.1.1.4.6.1.1.5 Syntax: Integer	Read-write	Specifies the TCP or UDP port number of the real server to which the virtual port is bound. Valid values: 0 – 65535
snL4BindRowStatus brcdIp.1.1.4.6.1.1.6 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>• delete(3) – Deletes the row.</li> <li>• create(4) – Creates a new row.</li> <li>• modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row.</li> <li>• invalid(1) – Row is inoperative.</li> <li>• valid(2) – Row exists and is valid.</li> </ul>

## Virtual server statistics table

The virtual server statistics table contains statistics for all the virtual servers configured in the ServerIron.

Name, OID, and syntax	Access	Description
snL4VirtualServerStatisticTable brcdIp.1.1.4.25.1	None	Virtual server statistic table.
snL4VirtualServerStatisticIP brcdIp.1.1.4.25.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address of the virtual server.
snL4VirtualServerStatisticName brcdIp.1.1.4.25.1.1.2 Syntax: L4ServerName	Read-only	Shows the name of the virtual server.

Name, OID, and syntax	Access	Description
snL4VirtualServerStatisticReceivePkts brcdIp.1.1.4.25.1.1.3 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has received from the real server.
snL4VirtualServerStatisticTransmitPkts brcdIp.1.1.4.25.1.1.4 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has sent to the real server.
snL4VirtualServerStatisticTotalConnections brcdIp.1.1.4.25.1.1.5 Syntax: Counter	Read-only	Shows the number of client connections on the virtual server since the last time the ServerIron was booted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerStatisticReceiveBytes brcdIp.1.1.4.25.1.1.6 Syntax: Counter64	Read-only	The number of bytes the switch has received from the real server.
snL4VirtualServerStatisticTransmitBytes brcdIp.1.1.4.25.1.1.7 Syntax: Counter64	Read-only	The number of bytes the switch has sent to the real server.
snL4VirtualServerStatisticSymmetricState brcdIp.1.1.4.25.1.1.8 Syntax: Integer	Read-only	Shows which ServerIron is the active one: <ul style="list-style-type: none"> <li>• other(3) – Not the active ServerIron</li> <li>• active(5) – Active ServerIron</li> </ul>
snL4VirtualServerStatisticSymmetricPriority brcdIp.1.1.4.25.1.1.9 Syntax: Integer	Read-only	Shows the Symmetric SLB priority configured on the ServerIron.
snL4VirtualServerStatisticSymmetricKeep brcdIp.1.1.4.25.1.1.10 Syntax: Integer	Read-only	This object is applicable only to the active ServerIrons. Shows the number of times an symmetric SLB backup has failed to communicate with the active ServerIron. By default, the counter is incremented by 1 every 400 milliseconds, if the backup switch is responding slowly to the active switch's keepalive message. The counter is reset to 0 each time the backup switch replies to a keepalive message. If the counter exceeds the maximum number allowed (20 by default, thus 8 seconds), the standby switch takes over as the new active switch. Normally, this field almost always contains 0.
snL4VirtualServerStatisticSymmetricActivates brcdIp.1.1.4.25.1.1.11 Syntax: Counter	Read-only	The number of times this ServerIron has become the active switch.
snL4VirtualServerStatisticSymmetricInactive brcdIp.1.1.4.25.1.1.12 Syntax: Counter	Read-only	Shows the number of times this ServerIron has changed from being the active switch to the backup switch.
snL4VirtualServerStatisticSymmetricBestStandbyMacAddr brcdIp.1.1.4.25.1.1.13 Syntax: Physical address	Read-only	Shows the MAC address of the backup ServerIron with the second-highest priority. This ServerIron will become the active switch if a failover occurs.

Name, OID, and syntax	Access	Description
snL4VirtualServerStatisticSymmetricActiveMacAddr brcdIp.1.1.4.25.1.1.14 Syntax: Physical address	Read-only	Shows the MAC address of the active ServerIron with the highest priority. This ServerIron will become the backup switch if a failover occurs.
snL4VirtualServerStatisticTrackPortList brcdIp.1.1.4.25.1.1.15 Syntax: DisplayString	Read-only	Virtual port track group port list.
snL4VirtualServerStatisticTrackPortState brcdIp.1.1.4.25.1.1.16 Syntax: Integer	Read-only	Shows the port track-group state. Valid values: <ul style="list-style-type: none"> <li>• none(0) - The track-group port list is empty.</li> <li>• up(1)</li> <li>• suspect(2)</li> </ul>

## Virtual server port statistics table

The virtual server port statistics table contains statistics for all the ports configured for all the virtual servers.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortStatisticTable brcdIp.1.1.4.26.1	None	The Virtual server port statistics table.
snL4VirtualServerPortStatisticIP brcdIp.1.1.4.26.1.1.1 Syntax: IpAddress	Read-only	The IP address of the virtual server to which the port is located.
snL4VirtualServerPortStatisticPort brcdIp.1.1.4.26.1.1.2 Syntax: Integer	Read-only	The port number that the virtual server (SLB switch) uses to listen for connections.
snL4VirtualServerPortStatisticServerName brcdIp.1.1.4.26.1.1.3 Syntax: L4ServerName	Read-only	Shows the name of the virtual server.
snL4VirtualServerPortStatisticCurrentConnection brcdIp.1.1.4.26.1.1.4 Syntax: Integer	Read-only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortStatisticTotalConnection brcdIp.1.1.4.26.1.1.5 Syntax: Counter	Read-only	The number of client connections on the virtual server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortStatisticPeakConnection brcdIp.1.1.4.26.1.1.6 Syntax: Integer	Read-only	The highest number of connections the VIP has had at any time.

## Real server port statistics table

The real server port statistics table contains statistics for all the ports configured for all the real servers.

Name, OID, and syntax	Access	Description
snL4RealServerPortStatisticTable brcdIp.1.1.4.24.1	None	Real server port statistic table.
snL4RealServerPortStatisticIP brcdIp.1.1.4.24.1.1.1 Syntax: IPAddress	Read-only	The IP address of the server where the port is located.
snL4RealServerPortStatisticPort brcdIp.1.1.4.24.1.1.2 Syntax: Integer	Read-only	The port number that the server uses to listen for connections.
snL4RealServerPortStatisticServerName brcdIp.1.1.4.24.1.1.3 Syntax: L4ServerName	Read-only	Shows the name of the server.
snL4RealServerPortStatisticReassignCount brcdIp.1.1.4.24.1.1.4 Syntax: Integer	Read-only	Shows the number of times the ServerIron has reassigned the connection to another server in the rotation because the server that is in use has not responded to two TCP SYN requests from the client.

Name, OID, and syntax	Access	Description
snL4RealServerPortStatisticState brcdIp.1.1.4.24.1.1.5 Syntax: Integer	Read-only	<p>Shows the operational state of the server when the statistics were obtained:</p> <ul style="list-style-type: none"> <li>disabled(0) – This value is not used.</li> <li>enabled(1) – There is no link to the server. The server is configured on the ServerIron, but is not physically connected to the ServerIron.</li> <li>failed(2) – The server has failed to respond to repeated Layer 3 health checks (IP pings). Typically, a server changes to the failed(2) state from the suspect(4) state.</li> <li>testing(3) – The server is still reachable at Layer 3, but at least one of the application ports on the server has failed to respond to its health checks. If the application port is not a TCP or UDP port known to the ServerIron or if the Layer 7 health check for the port is disabled, only the Layer 4 health check is used. If the service is a TCP or UDP port known to the ServerIron and the Layer 7 health check is enabled, then the application must pass both health checks to avoid entering the testing(3) state. The ServerIron continues to try to reach the application indefinitely. If the server continues to be reachable at Layer 3, the state will remain testing(3) as long as the ServerIron cannot reach the application that is failing its health check.</li> <li>suspect(4) – The ServerIron associates a time stamp with each packet sent to and received from the servers. If the time gap between the last packet received from the server and the last packet sent to the server increases to three or four seconds, the ServerIron sends a Layer 3 health check (ping) to the server. If the server does not respond within the ping interval (configured in the “snL4PingInterval” object, the ServerIron changes the state to suspect(4) and resends the ping, up to the number of retries specified by the “snL4PingRetry” object. If the server still does not respond after all the retries, the state changes to failed(2). If the server does respond, the state changes to active(6).</li> <li>shutdown(5) – The forced-shutdown option has been used to gracefully shut down the server.</li> <li>active(6) – The server has responded to the Layer 3 health check (IP ping), and all the services on the server have passed their Layer 4, and if applicable, Layer 7) health checks.</li> <li>unbound(7) – The unbind action is complete.</li> <li>awaitUnbind(8) – The unbind action has been issued and is waiting for completion.</li> <li>awaitDelete(9) – The delete action has been issued and is waiting for completion.</li> </ul> <p>Await actions occur because ServerIron sends a command from MP to all BPs and needs to wait for all BPs to have gracefully synced with other BPs that, for example, are deleting real servers, and so on.</p>
snL4RealServerPortStatisticFailedTime brcdIp.1.1.4.24.1.1.6 Syntax: Integer	Read-only	<p>This object applies only to a port whose operational state is failed(2).</p> <p>Shows the number of seconds that has elapsed since the last time the port tried to re-establish connection with the server.</p>
snL4RealServerPortStatisticCurrentConnection brcdIp.1.1.4.24.1.1.7 Syntax: Integer32	Read-only	<p>Shows the number of client connections currently on this port of the server. A connection consists of two sessions; the client-to-server session and the server-to-client session.</p>

Name, OID, and syntax	Access	Description
snL4RealServerPortStatisticTotalConnection brcdIp.1.1.4.24.1.1.8 Syntax: Counter	Read-only	Shows the number of client connections on the server since the last time the ServerIron rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortStatisticRxPkts brcdIp.1.1.4.24.1.1.9 Syntax: Counter	Read-only	Shows the number of packets that the ServerIron has received from the server.
snL4RealServerPortStatisticTxPkts brcdIp.1.1.4.24.1.1.10 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has sent to the server.
snL4RealServerPortStatisticRxBytes brcdIp.1.1.4.24.1.1.11 Syntax: Counter	Read-only	Shows the number of bytes the ServerIron has received from the server.
snL4RealServerPortStatisticTxBytes brcdIp.1.1.4.24.1.1.12 Syntax: Counter	Read-only	Shows the number of bytes the ServerIron has sent to the server.
snL4RealServerPortStatisticPeakConnection brcdIp.1.1.4.24.1.1.13 Syntax: Integer	Read-only	Shows the highest number of simultaneous client connections on the server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.

## Layer 4 policy table

The Layer 4 policy table allows you to configure Layer 4 policies and specify the ports to which they will be applied.

Name, OID, and syntax	Access	Description
snL4PolicyTable brcdIp.1.1.4.11.1	None	Layer 4 policy table.
snL4PolicyId brcdIp.1.1.4.11.1.1.1 Syntax: Integer	Read-only	Specifies the ID of the policy. Valid values: 1 – 64



Name, OID, and syntax	Access	Description
snL4PolicyPriority brcdIp.1.1.4.11.1.1.2 Syntax: Integer	Read-write	Shows the priority of the policy in the ServerIron. Standalone stackable ServerIrons have the following priorities: <ul style="list-style-type: none"> <li>normal(0) – Normal priority</li> <li>high(1) – High priority</li> <li>cache(2) – Priority for cache</li> <li>transparent(3) – Priority for transparent</li> </ul> Non-stackable ServerIron Layer 4 priority values: <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>
snL4PolicyScope brcdIp.1.1.4.11.1.1.3 Syntax: Integer	Read-write	Indicates if the policy applies to one or all ports: <ul style="list-style-type: none"> <li>global(0) – Applies to all ports.</li> <li>local(1) – Applies to one port.</li> </ul>
snL4PolicyProtocol brcdIp.1.1.4.11.1.1.4 Syntax: Integer	Read-write	Indicates if the policy is for UDP or TCP: <ul style="list-style-type: none"> <li>udp(0)</li> <li>tcp(1)</li> </ul>
snL4PolicyPort brcdIp.1.1.4.11.1.1.5 Syntax: Integer	Read-write	Indicates the TCP or UDP port number to which this policy will be applied. Valid values: 0 – 65535
snL4PolicyRowStatus brcdIp.1.1.4.11.1.1.6 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Layer 4 policy port access table

The Layer 4 policy port access table lists all access policy entries. These access policies are applied to IP interfaces (ports) that have Layer 4 IP policies configured on them.

Name, OID, and syntax	Access	Description
snL4PolicyPortAccessTable brcdIp.1.1.4.12.1	None	The IP Layer 4 policy interface (port) access table.

Name, OID, and syntax	Access	Description
snL4PolicyPortAccessPort brcdIp.1.1.4.12.1.1.1 Syntax: Integer	Read-only	The IP interface (port) to which the Layer 4 policy applies.
snL4PolicyPortAccessList brcdIp.1.1.4.12.1.1.2 Syntax: OCTET STRING	Read-write	This list consists of the policies configured in "snL4PolicyTable". Each octet in the list contains a valid ID number ("snL4PolicyId") that identifies a policy in snL4PolicyTable. That policy must have been created prior to the using this object. Valid values: 1 – 64 octets
snL4PolicyPortAccessRowStatus brcdIp.1.1.4.12.1.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Layer 4 trap variable binding table

The following table contains the configuration of the Layer 4 trap variable binding.

Name, OID, and syntax	Access	Description
snL4TrapRealServerIP brcdIp.1.1.4.13.1 Syntax: IpAddress	Read-only	Real server IP address.
snL4TrapRealServerName brcdIp.1.1.4.13.2 Syntax: L4ServerName	Read-only	Real server name.
snL4TrapRealServerPort brcdIp.1.1.4.13.3 Syntax: Integer32	Read-only	Transport protocol port number of the real server.
snL4TrapRealServerCurConnections brcdIp.1.1.4.13.4 Syntax: Integer32	Read-only	Real server current connections.
snL4TrapLinkName brcdIp.1.1.4.13.5 Syntax: L4ServerName	Read-only	Name of the link.
snL4LinkVirtualInterface brcdIp.1.1.4.13.6 Syntax: Integer32	Read-only	Link virtual interface.

## Web cache table

A Web cache server is an application server that is load-balanced by the Server Load Balancing (SLB) switch. The following table contains the configuration of the Web cache servers in the network.

Name, OID, and syntax	Access	Description
snL4WebCacheTable brcdIp.1.1.4.14.1	None	Web cache table.
snL4WebCacheIP brcdIp.1.1.4.14.1.1.1 Syntax: IpAddress	Read-only	Indicates the IP address of the real server that is serving as the Web cache server.
snL4WebCacheName brcdIp.1.1.4.14.1.1.2 Syntax: L4ServerName	Read-write	Name of the real server that is serving as the Web cache server. This name must be unique among other Web cache server names. Valid values: 1 – 32 octets
snL4WebCacheAdminStatus brcdIp.1.1.4.14.1.1.3 Syntax: L4Status	Read-write	Indicates if the TCS feature is enabled in the real server that is serving as the Web cache server: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1) – When TCS is enabled, the feature detects HTTP traffic addressed for output to the Internet and redirects the traffic to the CPU. The CPU processes the traffic and forwards it to the Web cache servers instead.</li> </ul> <b>NOTE:</b> You cannot enable TCS on both a global (switch) and local (interface) basis.
snL4WebCacheMaxConnections brcdIp.1.1.4.14.1.1.4 Syntax: Integer	Read-write	The maximum number of connections the ServerIron can maintain in its session table for a Web cache server. When a Web cache server reaches this threshold, an SNMP trap is sent. When all the real servers in a server pool reach this threshold, additional TCP or UDP packets are dropped, and an ICMP destination unreachable message is sent. Valid values: 0 – 1000000 Default: 1000000
snL4WebCacheWeight brcdIp.1.1.4.14.1.1.5 Syntax: Integer	Read-write	Shows the Web cache server's least-connections weight. This parameter specifies the server's weight relative to other Web cache servers in terms of the number of connections on the server. This weight is based on the number of session table entries the ServerIron has for TCP or UDP sessions with the real server. However, if a weight based on the server response time is desired, this parameter must be disabled (set to 0). Valid values: 1 – 65535 Default: 1

Name, OID, and syntax	Access	Description
snL4WebCacheRowStatus brcdIp.1.1.4.14.1.1.6 Syntax: L4Status	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snL4WebCacheDeleteState brcdIp.1.1.4.14.1.1.7 Syntax: L4DeleteState	Read-only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state.</li> <li>waitdelete(2) – The port is in a delete state.</li> </ul>

## Web cache group table

The Web cache group table lists the configured group of Web cache servers on the ServerIron. The ServerIron uses a hashing algorithm to distribute the incoming HTTP requests among the servers in the cache group. In addition, cache groups provide automatic recovery from a failed or out-of-service Web cache server. If a Web cache server failure occurs, the ServerIron detects the failure and directs subsequent requests to the next available Web cache server or forwards the request directly to the WAN link. The “[snL4MaxNumWebCachePerGroup](#)” object defines the maximum number of Web cache servers that can be configured in a group. The “[snL4MaxNumWebCacheGroup](#)” object defines the maximum number of cache groups that can be configured on a Web cache server.

Name, OID, and syntax	Access	Description
snL4WebCacheGroupTable brcdIp.1.1.4.15.1	None	Web Cache Group table.
snL4WebCacheGroupId brcdIp.1.1.4.15.1.1.1 Syntax: Integer	Read-only	Shows the ID of an entry in the Web cache group entry. Valid values: 1 value of the “ <a href="#">snL4MaxNumWebCacheGroup</a> ” object.
snL4WebCacheGroupName brcdIp.1.1.4.15.1.1.2 Syntax: L4ServerName	Read-write	Shows the name of the Web cache group. This name must be unique among the Web cache group names. Valid values: 1 – 32 octets.
snL4WebCacheGroupWebCacheIpList brcdIp.1.1.4.15.1.1.3 Syntax: OCTET STRING	Read-write	Contains a list of IP addresses of the Web cache servers in the group. Valid values: The maximum number of IP addresses that a group can contain is equal to the value of the “ <a href="#">snL4MaxNumWebCachePerGroup</a> ” object. Each IP address contains up to four octets.

Name, OID, and syntax	Access	Description
snL4WebCacheGroupDestMask brcdIp.1.1.4.15.1.1.4 Syntax: IpAddress	Read-write	Shows the destination hash-mask for the Web cache group. The ServerIron uses the destination hash-mask (this object) and the source hash-mask ("snL4WebCacheGroupSrcMask") to forward the requests to the Web cache servers. This method ensures that a particular website is always cached on the same Web cache server to minimize duplication of content on the Web cache servers. Default: 255.255.255.0
snL4WebCacheGroupSrcMask brcdIp.1.1.4.15.1.1.5 Syntax: IpAddress	Read-write	Specifies the source hash-mask for the Web cache group. The ServerIron uses the destination hash-mask (this object) and the source hash-mask ("snL4WebCacheGroupSrcMask") to forward the requests to the Web cache servers. This method ensures that a particular website is always cached on the same Web cache server to minimize duplication of content on the Web cache servers. Default: 0.0.0.0
snL4WebCacheGroupAdminStatus brcdIp.1.1.4.15.1.1.6 Syntax: Integer	Read-write	Indicates if the Web cache group feature is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4WebCacheGroupRowStatus brcdIp.1.1.4.15.1.1.7 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>

## Web cache traffic statistics table

The Web cache traffic statistics table contains traffic statistics for the client requests that go to the Web cache server.

Name, OID, and syntax	Access	Description
snL4WebCacheTrafficStats Table brcdIp.1.1.4.16.1	None	Web cache traffic statistics table.
snL4WebCacheTrafficIp brcdIp.1.1.4.16.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address of the Web cache server.
snL4WebCacheTrafficPort brcdIp.1.1.4.16.1.1.2 Syntax: Integer	Read-only	Shows the port that the Web cache server uses to listen for connections. Valid values: 0 – 65535

Name, OID, and syntax	Access	Description
snL4WebCacheCurrConnections brcdIp.1.1.4.16.1.1.3 Syntax: Integer	Read-only	Shows the number of the active connections between the clients and the Web cache server.
snL4WebCacheTotalConnections brcdIp.1.1.4.16.1.1.4 Syntax: Integer	Read-only	Shows the total number of connections between clients and the Web cache server.
snL4WebCacheTxPkts brcdIp.1.1.4.16.1.1.5 Syntax: Counter	Read-only	Shows the number of packets sent from the client or the Web server to the Web cache server.
snL4WebCacheRxPkts brcdIp.1.1.4.16.1.1.6 Syntax: Counter	Read-only	Shows the number of packets sent from the Web cache server to the client or Web server.
snL4WebCacheTxOctets brcdIp.1.1.4.16.1.1.7 Syntax: Counter	Read-only	Shows the number of octets sent from the client or Web server to the Web cache server.
snL4WebCacheRxOctets brcdIp.1.1.4.16.1.1.8 Syntax: Counter	Read-only	Shows the number of octets sent from the Web cache server to the client or Web server.
snL4WebCachePortState brcdIp.1.1.4.16.1.1.9 Syntax: WebCacheState	Read-only	Shows the operational state of the server port: <ul style="list-style-type: none"> <li>disabled(0) – This state has been deprecated.</li> <li>enabled(1) – The server is ready. There is no physical link to the Web cache server. The Web cache server is configured on the ServerIron, but is not physically connected to the ServerIron.</li> <li>failed(2) – The server failed. The Web cache server has failed to respond to repeated Layer 3 health checks (IP pings). Typically, a real server changes from the suspect(4) state to the failed(2) state.</li> <li>testing(3) – The Web cache server is in testing mode. It is still reachable at Layer 3, but at least one of its application ports has failed to respond to its health checks. If the application port is not a TCP or UDP port known to the ServerIron, or if the Layer 7 health check for the port is disabled, only the Layer 4 health check is used. If the service is a TCP or UDP port known to the ServerIron and the Layer 7 health check is enabled, then the application must pass both health checks to avoid entering the testing(3) state.</li> </ul> <p>The ServerIron continues to try to reach the application indefinitely. Thus, if the server continues to be reachable at Layer 3, the state will remain in the testing(3) state as long as the ServerIron cannot reach the application that is failing its health check..</p>

Name, OID, and syntax	Access	Description
snL4WebCachePortState (continued)		<ul style="list-style-type: none"> <li>suspect(4) – The Web cache server is responding slowly. The ServerIron associates a time stamp with each packet sent to and received from the Web cache servers. If the time gap between the last packet received from the server and the last packet sent to the server increases to three or four seconds, the ServerIron sends a ping (Layer 3 health check) to the server. If the server does not respond within the ping interval (configured in the “snL4PingInterval” object), the ServerIron changes the state to suspect(4) and resends the ping. The ping will be sent up to the number of retries specified by the ping retries parameter (configured in the “snL4PingRetry” object). If the server still does not respond after all the retries, the state changes to failed(2). If the server does respond, the state changes to active(6).</li> <li>shutdown(5) – The Web cache server has been forced to shut down. This option is used to gracefully shut down the Web cache server.</li> <li>active(6) – The Web cache server responded to the Layer 3 health check (IP ping), and all the services on the real server have passed their Layer 4, and if applicable, Layer 7 health checks.</li> </ul>

## Web uncached traffic statistics table

The Web uncached traffic statistics table contains traffic statistics for the client requests that go directly to the Web server. Client requests are directed to the Web server when the Web cache server is not available.

Name, OID, and syntax	Access	Description
snL4WebUncachedTrafficStatsTable brcdIp.1.1.4.17.1	None	Web uncached traffic statistics table.
snL4WebServerPort brcdIp.1.1.4.17.1.1.1 Syntax: Integer	Read-only	Identifies the ServerIron port that is attached to the Web servers. This port is typically the port attached to the Border Access Point (BAP) router that goes to the rest of the network or to the Internet.
snL4WebClientPort brcdIp.1.1.4.17.1.1.2 Syntax: Integer	Read-only	Identifies the SLB switch port or Web client port, which connects the client to the ServerIron.
snL4WebUncachedTxPkts brcdIp.1.1.4.17.1.1.3 Syntax: Counter	Read-only	Shows the number of uncached packets sent from the client port to the Web server.
snL4WebUncachedRxPkts brcdIp.1.1.4.17.1.1.4 Syntax: Counter	Read-only	Shows the number of uncached packets tsent from the Web server to the client port.
snL4WebUncachedTxOctets brcdIp.1.1.4.17.1.1.5 Syntax: Counter	Read-only	Shows the number of uncached octets sent from the client port to the Web server.

Name, OID, and syntax	Access	Description
snL4WebUncachedRxOctets brcdIp.1.1.4.17.1.1.6 Syntax: Counter	Read-only	Shows the number of uncached octets sent from the Web server to the client port.
snL4WebServerPortName brcdIp.1.1.4.17.1.1.7 Syntax: DisplayString	Read-only	Shows the name of the Web server port. Valid values: Up to 16 characters
snL4WebClientPortName brcdIp.1.1.4.17.1.1.8 Syntax: DisplayString	Read-only	Shows the name of the Web client port. Valid values: Up to 16 characters

## Web cache real server port table

The Web cache real server port table consists of all the ports configured for the real server. Most attributes are configured globally for the port. Some additional and overriding local attributes can be configured in this table.

Name, OID, and syntax	Access	Description
snL4WebCachePortTable brcdIp.1.1.4.18.1	None	Web cache server port table.
snL4WebCachePortServerIp brcdIp.1.1.4.18.1.1.1 Syntax: IpAddress	Read-only	Shows the IP address of the Web cache server.
snL4WebCachePortPort brcdIp.1.1.4.18.1.1.2 Syntax: Integer	Read-only	Shows the port that the Web cache server uses to listen for connections. Valid values: 0 – 65535
snL4WebCachePortAdminStatus brcdIp.1.1.4.18.1.1.3 Syntax: L4Status	Read-write	Indicates if the Web cache server port is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4WebCachePortRowStatus brcdIp.1.1.4.18.1.1.4 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The following values can be written: <ul style="list-style-type: none"> <li>delete(3) – Deletes the row.</li> <li>create(4) – Creates a new row.</li> <li>modify(5) – Modifies an existing row.</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row.</li> <li>invalid(1) – Row is inoperative.</li> <li>valid(2) – Row exists and is valid.</li> </ul>
snL4WebCachePortDeleteState brcdIp.1.1.4.18.1.1.5 Syntax: L4DeleteState	Read-only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state.</li> <li>waitdelete(2) – The port is in a delete state.</li> </ul>



## GSLB remote ServerIron configuration table

The Global Server Load Balancing (GSLB) enables a ServerIron to add intelligence to authoritative Domain Name System (DNS) servers by serving as a proxy to the servers. As a DNS proxy, the GSLB ServerIron evaluates the server IP addresses in the replies from the DNS server for which the ServerIron is a proxy. Based on the results of the evaluation, the GSLB ServerIron can change the order of the addresses in the reply so that the “best” host address for the client is first on the list.

The GSLB remote ServerIron configuration table contains the configuration of ServerIrons that act as DNS proxies to the clients. They also intercept the IP addresses replied by the DNS authoritative servers to select the best address for the requesting client.

Name, OID, and syntax	Access	Description
snL4GslbSiteRemoteServerIronTable brcdIp.1.1.4.27.1	None	GSLB remote ServerIron configuration table.
snL4GslbSiteRemoteServerIronIP brcdIp.1.1.4.27.1.1.1 Syntax: IpAddress	Read-only	Specifies the management IP address of the remote ServerIron in a site. This address must not be any of the configured VIPs.
snL4GslbSiteRemoteServerIronPreference brcdIp.1.1.4.27.1.1.2 Syntax: Integer	Read-write	<p>Specifies the preference of a remote ServerIron. This metric is a numeric preference value, that is assigned to each site ServerIron. It is used to select that ServerIron if the previous metrics do not select a best site. The GSLB policy prefers the site ServerIron with the highest administrative preference. The preference ServerIron to do the following.</p> <ul style="list-style-type: none"> <li>Temporarily change the preference of a ServerIron site to accommodate changing network conditions. For example, if sites are offering proxy content service, the link between a site proxy server farm and the content origin may be highly congested, making that site less desirable. This factor is not visible to the ServerIrons and thus cannot be reflected in the other GSLB metrics.</li> <li>Temporarily disqualify a site ServerIron from being selected, without otherwise changing the site configuration or the GSLB ServerIron configuration. For example, maintenance can be performed on the site ServerIron without making network changes. In this case, set the preference to 0.</li> <li>A GSLB ServerIron can be biased; that is, it can be configured as a site ServerIron (for locally configured VIPs) to always favor itself as the best site. In this case, assign a preference of 255 to the site for the GSLB ServerIron itself, and assign a lower preference to the other site ServerIrons, or use the default (128) for those sites.</li> </ul> <p>The administrative preference is disabled by default, which means it is not included as one of the GSLB metrics. When this metric is enabled, the default administrative preference for sites is applied. It can be changed on an individual site basis.</p> <p>Valid values: 0 – 255 Default: 128</p>

## Real server history control table

The real server history control table contains objects that control the collection of data samples for real servers.

Name, OID, and syntax	Access	Description
snL4RealServerHistoryControlTable brcdIp.1.1.4.28.1	None	Real server history control table
snL4RealServerHistoryControlIndex brcdIp.1.1.4.28.1.1.1 Syntax: Integer	Read-only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a real server on the ServerIron. Valid values: Up to 65535 entries.
snL4RealServerHistoryControlData Source brcdIp.1.1.4.28.1.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any real server on this ServerIron. It may not be modified if the value of the <a href="#">"snL4RealServerHistoryControlStatus"</a> object for this entry source is equal to valid(1).
snL4RealServerHistoryControlBucketsRequested brcdIp.1.1.4.28.1.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of samples saved in the <a href="#">"snL4RealServerHistoryControlBucketsGranted"</a> object should be close to the value of this object. If the value of this object is modified, then the value of the <a href="#">"snL4RealServerHistoryControlBucketsGranted"</a> object will be adjusted according to the new value of this object. Valid values: 1 – 65535 Default: 50
snL4RealServerHistoryControlBucketsGranted brcdIp.1.1.4.28.1.1.4 Syntax: Integer	Read-only	The number of data samples actually saved for this entry. If the value of the <a href="#">"snL4RealServerHistoryControlBucketsRequested"</a> object is modified, then the actual number of samples saved by this object will be adjusted accordingly. If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted. If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object. If the value of this object changes to a value greater than the current value, the number of buckets will increase but not exceed the new value of this object.

Name, OID, and syntax	Access	Description
snL4RealServerHistoryControlInterval brcdIp.1.1.4.28.1.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket.  <b>NOTE:</b> A counter for a bucket may overflow without any indication; thus, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4RealServerHistoryControlInterval) to a value less than the overflow interval. This is especially important for the "octets" counter in any data-source table.  You cannot modify the value of this object if the value of this entry's "snL4RealServerHistoryControlStatus" object is equal to valid(1).  Valid values: 1 – 3600 seconds Default: 1800 seconds
snL4RealServerHistoryControlOwner brcdIp.1.1.4.28.1.1.6 Syntax: DisplayString	Read-write	The administrator who owns or configured this entry.
snL4RealServerHistoryControlStatus brcdIp.1.1.4.28.1.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) – When the entry is set to this state, it will be deleted from the table.</li> </ul>

## Real server history group table

The real server history group table contains historical data samples that were collected for real servers.

Each counter in this table counts the same event as the counters used by [snL4RealServerStatisticEntry](#); however, the value of the counters in this table represents a cumulative sum of a sampling period.

Name, OID, and syntax	Access	Description
snL4RealServerHistoryTable brcdIp.1.1.4.28.2	None	Real server history group table.
snL4RealServerHistoryIndex brcdIp.1.1.4.28.2.1.1 Syntax: Integer	Read-only	Shows the index entry as identified by " <a href="#">snL4RealServerHistoryControlIndex</a> ".
snL4RealServerHistorySampleIndex brcdIp.1.1.4.28.2.1.2 Syntax: Integer	Read-only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 2,147,483,647 samples.

Name, OID, and syntax	Access	Description
snL4RealServerHistoryIntervalStart brcdIp.1.1.4.28.2.1.3 Syntax: Time ticks	Read-only	The value of sysUpTime at the start of the interval used to measure data samples. If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour. <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, because each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4RealServerHistoryReceivePkts brcdIp.1.1.4.28.2.1.4 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has received from the real server.
snL4RealServerHistoryTransmitPkts brcdIp.1.1.4.28.2.1.5 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has sent to the real server.
snL4RealServerHistoryTotalConnections brcdIp.1.1.4.28.2.1.6 Syntax: Counter	Read-only	Shows the total number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerHistoryCurConnections brcdIp.1.1.4.28.2.1.7 Syntax: Integer	Read-only	Shows the number of client connections currently on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerHistoryPeakConnections brcdIp.1.1.4.28.2.1.8 Syntax: Integer	Read-only	Shows the highest number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerHistoryReassignments brcdIp.1.1.4.28.2.1.9 Syntax: Integer	Read-only	Shows the number of times the ServerIron has reassigned the connection to another real server in the rotation because the real server that is in use has not responded to two TCP SYN requests from the client.

## Real server port history control group table

The real server port history control group table lists all the controls for collecting data samples for a real server port.

Name, OID, and syntax	Access	Description
snL4RealServerPortHistoryControlTable brcdIp.1.1.4.28.3	None	Real server port history control table.
snL4RealServerPortHistoryControlIndex brcdIp.1.1.4.28.3.1.1 Syntax: Integer	Read-only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a real server port on the ServerIron. Valid values: Up to 65535 entries.

Name, OID, and syntax	Access	Description
snL4RealServerPortHistoryControlDataSource brcdIp.1.1.4.28.3.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any real server port on this ServerIron.  It may not be modified if the value of the <a href="#">“snL4VirtualServerPortHistoryControlStatus”</a> object for this entry source is equal to valid(1).
snL4RealServerPortHistoryControlBucketsRequested brcdIp.1.1.4.28.3.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of actual samples saved in the <a href="#">“snL4RealServerPortHistoryControlBucketsGranted”</a> object should be close to the value of this object. If the value of this object is modified, then the value of the <a href="#">“snL4RealServerPortHistoryControlBucketsGranted”</a> object will be adjusted according to the new value of this object. Valid values: 1 – 65535 Default: 50
snL4RealServerPortHistoryControlBucketsGranted brcdIp.1.1.4.28.3.1.4 Syntax: Integer	Read-only	The number of data samples actually saved for this entry. If the value of the <a href="#">“snL4RealServerPortHistoryControlBucketsRequested”</a> object is modified, then the actual number of samples saved by this object will be adjusted accordingly. If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted. If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object. If the value of this object changes to a value greater than the current value, the number of buckets will increase but will not exceed the new value of this object.
snL4RealServerPortHistoryControlInterval brcdIp.1.1.4.28.3.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket.  <b>NOTE:</b> A counter for a bucket may overflow without any indication; thus, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4RealServerPortHistoryControlInterval) to a value less than the overflow interval. This is especially important for the “octets” counter in any data-source table.  You cannot modify the value of this object if the value of this entry’s <a href="#">“snL4RealServerPortHistoryControlStatus”</a> object is equal to valid(1). Valid values: 1 – 3600 seconds Default: 1800 seconds

Name, OID, and syntax	Access	Description
snL4RealServerPortHistoryControlOwner brcdIp.1.1.4.28.3.1.6 Syntax: DisplayString	Read-write	The administrator who owns or configured this entry.
snL4RealServerPortHistoryControlStatus brcdIp.1.1.4.28.3.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) – This entry will be deleted from the table if it is set to this state.</li> </ul>

## Real server port history group table

The real server port history group table contains history data samples for each port on the real server.

Name, OID, and syntax	Access	Description
snL4RealServerPortHistoryTable brcdIp.1.1.4.28.4	None	Real server port history group table.
snL4RealServerPortHistoryIndex brcdIp.1.1.4.28.4.1.1 Syntax: Integer	Read-only	Shows the index entry as identified by <a href="#">“snL4RealServerPortHistoryControlIndex”</a> .
snL4RealServerPortHistorySampleIndex brcdIp.1.1.4.28.4.1.2 Syntax: Integer	Read-only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 2,147,483,647 samples.
snL4RealServerPortHistoryIntervalStart brcdIp.1.1.4.28.4.1.3 Syntax: Time ticks	Read-only	The value of sysUpTime at the start of the interval used to measure data samples. If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour. <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, because each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4RealServerPortHistoryReceivePkts brcdIp.1.1.4.28.4.1.4 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has received from the real server.
snL4RealServerPortHistoryTransmitPkts brcdIp.1.1.4.28.4.1.5 Syntax: Counter	Read-only	Shows the number of packets the ServerIron sent to the real server.
snL4RealServerPortHistoryTotalConnections brcdIp.1.1.4.28.4.1.6 Syntax: Counter	Read-only	Shows the total number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

Name, OID, and syntax	Access	Description
snL4RealServerPortHistoryCurrentConnections brcdIp.1.1.4.28.4.1.7 Syntax: Integer	Read-only	Shows the number of client connections currently on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortHistoryPeakConnections brcdIp.1.1.4.28.4.1.8 Syntax: Integer	Read-only	Shows the highest number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortHistoryResponseTime brcdIp.1.1.4.28.4.1.9 Syntax: Integer	Read-only	Shows the round trip time for a response from a real server on this port.

## Virtual server history control group table

The virtual server history control group table contains objects that control the collection of data samples for virtual servers.

Name, OID, and syntax	Access	Description
snL4VirtualServerHistoryControlTable brcdIp.1.1.4.28.5	None	Virtual server history control group table.
snL4VirtualServerHistoryControlIndex brcdIp.1.1.4.28.5.1.1 Syntax: Integer	Read-only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a virtual server on the ServerIron. This object can have up to 65535 entries.
snL4VirtualServerHistoryControlDataSource brcdIp.1.1.4.28.5.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any virtual server on this ServerIron. It identifies a particular instance defined in the <a href="#">“snL4VirtualServerStatisticTable”</a> . It may not be modified if the value of the <a href="#">“snL4VirtualServerHistoryControlStatus”</a> object for this entry source is equal to valid(1).
snL4VirtualServerHistoryControlBucketsRequested brcdIp.1.1.4.28.5.1.3 Syntax: Integer	Read-write	Indicates the requested number of data samples that will be saved for this entry. The number of samples saved in the <a href="#">“snL4VirtualServerHistoryControlBucketsGranted”</a> object should be close to the value of this object. If the value of this object is modified, then the value of the <a href="#">“snL4VirtualServerHistoryControlBucketsGranted”</a> object will be adjusted according to the new value of this object. Valid values: 1 – 65535 Default: 50

Name, OID, and syntax	Access	Description
snL4VirtualServerHistoryControlBucketsGranted brcdIp.1.1.4.28.5.1.4 Syntax: Integer	Read-only	The number of data samples actually saved for this entry. If the value of the <a href="#">“snL4VirtualServerHistoryControlBucketsRequested”</a> object is modified, then the actual number of samples saved by this object will be adjusted accordingly. If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted. If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object. If the value of this object changes to a value greater than the current value, the number of buckets will increase but not exceed the new value of this object.
snL4VirtualServerHistoryControlInterval brcdIp.1.1.4.28.5.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket. <b>NOTE:</b> A counter for a bucket may overflow without any indication; thus, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4VirtualServerHistoryControlInterval) to a value less than the overflow interval. This is especially important for the “octets” counter in any data-source table. You cannot modify the value of this object if the value of this entry’s <a href="#">“snL4VirtualServerHistoryControlStatus”</a> object is equal to valid(1). Valid values: 1 – 3600 seconds Default: 1800 seconds
snL4VirtualServerHistoryControlOwner brcdIp.1.1.4.28.5.1.6 Syntax: DisplayString	Read-write	The administrator who owns or configured this entry.
snL4VirtualServerHistoryControlStatus brcdIp.1.1.4.28.5.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) – This entry will be deleted from the table if it is changed to this state.</li> </ul>

## Virtual server history table

The virtual server history g table contains historical data samples that were collected for virtual servers.

Each counter in this table identifies the same event as the counters used by [“snL4VirtualServerStatisticTable”](#); however, the value of the counters in this table represents a cumulative sum of a sampling period.



Name, OID, and syntax	Access	Description
snL4VirtualServerHistoryTable brcdIp.1.1.4.28.6	None	Virtual server history table.
snL4VirtualServerHistoryIndex brcdIp.1.1.4.28.6.1.1 Syntax: Integer	Read-only	Shows the index entry as identified by “snL4VirtualServerHistoryControllIndex”.
snL4VirtualServerHistorySampleIndex brcdIp.1.1.4.28.6.1.2 Syntax: Integer	Read-only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 2,147,483,647 samples.
snL4VirtualServerHistoryIntervalStart brcdIp.1.1.4.28.6.1.3 Syntax: Time ticks	Read-only	The value of sysUpTime at the start of the interval used to measure data samples. If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour. <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, because each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4VirtualServerHistoryReceivePkts brcdIp.1.1.4.28.6.1.4 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has received from the virtual server.
snL4VirtualServerHistoryTransmitPkts brcdIp.1.1.4.28.6.1.5 Syntax: Counter	Read-only	Shows the number of packets the ServerIron sent to the virtual server.
snL4VirtualServerHistoryTotalConnections brcdIp.1.1.4.28.6.1.6 Syntax: Counter	Read-only	Shows the total number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerHistoryCurrentConnections brcdIp.1.1.4.28.6.1.7 Syntax: Integer	Read-only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerHistoryPeakConnections brcdIp.1.1.4.28.6.1.8 Syntax: Integer	Read-only	Shows the highest number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

## Virtual server port history control table

The virtual server port history control table lists all the controls for collecting data samples for a virtual server port.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortHistoryControlTable brcdIp.1.1.4.28.7	None	Virtual server port history control table.
snL4VirtualServerPortHistoryControlIndex brcdIp.1.1.4.28.7.1.1 Syntax: Integer	Read-only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a virtual server port on the ServerIron. This object can have up to 65535 entries.
snL4VirtualServerPortHistoryControlDataSource brcdIp.1.1.4.28.7.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any virtual server port on this ServerIron.  It identifies a particular instance defined in <a href="#">“snL4VirtualServerStatisticTable”</a> .  It may not be modified if the value of the <a href="#">“snL4VirtualServerPortHistoryControlStatus”</a> object for this entry source is equal to valid(1).
snL4VirtualServerPortHistoryControlBucketsRequested brcdIp.1.1.4.28.7.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of actual samples saved in the <a href="#">“snL4VirtualServerPortHistoryControlBucketsGranted”</a> object should be close to the value of this object. If the value of this object is modified, then the value of the <a href="#">“snL4VirtualServerPortHistoryControlBucketsGranted”</a> object will be adjusted according to the new value of this object. Valid values: 1 – 65535 Default: 50
snL4VirtualServerPortHistoryControlBucketsGranted brcdIp.1.1.4.28.7.1.4 Syntax: Integer	Read-only	The number of data samples actually saved for this entry. If the value of the <a href="#">“snL4VirtualServerPortHistoryControlBucketsRequested”</a> object is modified, then the actual number of samples saved by this object will be adjusted accordingly. If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted. If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object. If the value of this object changes to a value greater than the current value, the number of buckets will increase but will not exceed the new value of this object.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortHistoryControlInterval brcdIp.1.1.4.28.7.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket.  <b>NOTE:</b> A counter for a bucket may overflow without any indication; thus, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4VirtualServerPortHistoryControlInterval) to a value less than the overflow interval. This is especially important for the "octets" counter in any data-source table.  You cannot modify the value of this object if the value of this entry's "snL4VirtualServerPortHistoryControlStatus" object is equal to valid(1). Valid values: 1 - 3600 seconds Default: 1800 seconds
snL4VirtualServerPortHistoryControlOwner brcdIp.1.1.4.28.7.1.6 Syntax: DisplayString	Read-write	The administrator who owns or configured this entry.
snL4VirtualServerPortHistoryControlStatus brcdIp.1.1.4.28.7.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) - This entry will be deleted from the table if its state changes to this state.</li> </ul>

## Virtual server port history table

The virtual server port history table contains history data samples for each port on the virtual server.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortHistoryTable brcdIp.1.1.4.28.8	None	Virtual server port history table.
snL4VirtualServerPortHistoryIndex brcdIp.1.1.4.28.8.1.1 Syntax: Integer	Read-only	Shows the index entry as identified by "snL4VirtualServerPortHistoryControlIndex".
snL4VirtualServerPortHistorySampleIndex brcdIp.1.1.4.28.8.1.2 Syntax: Integer	Read-only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 2,147,483,647 samples.

Name, OID, and syntax	Access	Description
snL4VirtualServerPortHistoryIntervalStart brcdIp.1.1.4.28.8.1.3 Syntax: Time ticks	Read-only	The value of sysUpTime at the start of the interval used to measure data samples. If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour. <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, because each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4VirtualServerPortHistoryReceivedPkts brcdIp.1.1.4.28.8.1.4 Syntax: Counter	Read-only	Shows the number of packets the ServerIron has received from the virtual server port.
snL4VirtualServerPortHistoryTransmittedPkts brcdIp.1.1.4.28.8.1.5 Syntax: Counter	Read-only	Shows the number of packets the ServerIron sent to the virtual server.
snL4VirtualServerPortHistoryTotalConnections brcdIp.1.1.4.28.8.1.6 Syntax: Counter	Read-only	Shows the total number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortHistoryCurrentConnections brcdIp.1.1.4.28.8.1.7 Syntax: Integer	Read-only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortHistoryPeakConnections brcdIp.1.1.4.28.8.1.8 Syntax: Integer	Read-only	Shows the highest number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

# Wireless MIB Definition

---

## In this chapter

- General MIB objects ..... 627
- WiFi interface table ..... 628
- Roaming peer table ..... 629
- Access Point ADC table ..... 629
- VPN passthrough server table ..... 630
- VPN passthrough filter table ..... 630
- VPN passthrough policy table ..... 631

## General MIB objects

The wgGroup object contains MIB objects for wireless LAN features.

---

### NOTE

Wireless MIB objects are not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series, and on the FastIron devices.

---

The following table lists the general MIB objects for the wireless feature support.

Name, OID, and syntax	Access	Description
wgMobilityId brcdIp.1.1.3.23.1.1 Syntax: Integer	Read-write	Specifies the wireless mobility domain to which this WLAN controller belongs. Valid value: 1 - 65535. Enter 0 to remove from a wireless mobility domain.
wgVpnPTDeletePolicy brcdIp.1.1.3.23.1.2 Syntax: Integer	Read-write	Deletes a VPN passthrough policy from the WLAN controller. Enter a valid VPN passthrough policy ID to remove the policy.

---

## WiFi interface table

The WiFi interface table controls the wireless feature support on a WLAN controller.

Name, OID, and syntax	Access	Description
wgIfTable brcdIp.1.1.3.23.2	None	WiFi interface table
wgIfIndex brcdIp.1.1.3.23.2.1.1 Syntax: Integer	Read-only	The ifIndex value of the switch interface.
wgIfWirelessEnable brcdIp.1.1.3.23.2.1.2 Syntax: Integer	Read-write	Enables or disables the wireless feature support on an interface: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• enable(2)</li> <li>• disable(3)</li> </ul> The default is disable(3).
wgIfPnPLearnNewAP brcdIp.1.1.3.23.2.1.3 Syntax: Integer	Read-write	This object is used by the Automatic Discovery and Configuration (ADC) feature. Enables or disables the ability of an interface to learn new access points:: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• enable(2)</li> <li>• disable(3)</li> </ul>
wgIfAutoPortDisable brcdIp.1.1.3.23.2.1.4 Syntax: Integer	Read-write	This object is for the Automatic Port Deactivation feature. If set to enable, the interface is automatically disabled if the link status of the interface changes: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• enable(2)</li> <li>• disable(3)</li> </ul>
wgIfVpnPTPolicyId brcdIp.1.1.3.23.2.1.5 Syntax: Integer	Read-write	This object binds a VPN Pass through policy to the interface. To bind an interface to a VPN passthrough policy, enter its policy ID. It must be a valid policy number that is larger than zero. To unbind an interface to a VPN passthrough policy, enter zero for the policy ID.
wgIfFullCompRoamingEnable brcdIp.1.1.3.23.2.1.5 Syntax: Integer	Read-write	Indicates if full compatibility tunneling mode is enabled on the interface: <ul style="list-style-type: none"> <li>• other(1) – Other.</li> <li>• enable(2) – Full compatibility tunneling is enabled.</li> <li>• disable(3) – Full compatibility tunneling is disabled. High performance tunneling is used.</li> </ul>

## Roaming peer table

The roaming peer table shows information about the WLAN controller peers in a wireless mobility configuration.

Name, OID, and syntax	Access	Description
wgRoamingPeerTable brcdIp.1.1.3.23.3	None	Roaming peer table.
wgRoamingPeerIpAddress brcdIp.1.1.3.23.3.1.1 Syntax: IpAddress	Read-only	The IP address of a peer.
wgRoamingPeerConnection Status brcdIp.1.1.3.23.3.1.2 Syntax: Integer	Read-only	Shows the state of the connection: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• configured(2)</li> <li>• established(3)</li> </ul>
wgRoamingPeerRowStatus brcdIp.1.1.3.23.3.1.3 Syntax: Integer	Read-write	Shows the state of the row in the peer row table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## Access Point ADC table

The Access Point (AP) Automatic Discovery and Configuration (ADC) table defines the IP address, subnet mask, and default gateway of the access point that will be assigned to an access point with the specified MAC address. This information can be pre-configured on an interface of a WLAN controller. When the access point that has the matching MAC address is attached to the interface, the pre-configured IP address, subnet mask, and default gateway are assigned to that access point.

Name, OID, and syntax	Access	Description
wgPnPTable brcdIp.1.1.3.23.4	None	AP ADC table.
wgPnPIfIndex brcdIp.1.1.3.23.4.1.1 Syntax: Integer	Read-only	The ifIndex value of the switch interface.
wgPnPMacAddress brcdIp.1.1.3.23.4.1.2 Syntax: MacAddress	Read-only	MAC address of the attached AP.
wgPnPIpAddress brcdIp.1.1.3.23.4.1.3 Syntax: IpAddress	Read-write	IP address of the attached AP.
wgPnPIpMask brcdIp.1.1.3.23.4.1.4 Syntax: IpAddress	Read-write	Subnet mask of the attached AP.

Name, OID, and syntax	Access	Description
wgPnPipDefaultGw brcdIp.1.1.3.23.4.1.5 Syntax: IpAddress	Read-write	Default gateway of the attached AP.
wgPnPStatus brcdIp.1.1.3.23.4.1.6 Syntax: Integer	Read-only	The state of the access point that is defined for the interface: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• discovered(2) – The WLAN controller discovered a new access point that has not been configured.</li> <li>• configured(3) – The access point's IP address, subnet mask, and default gateway have been defined on the interface, but the access point with the matching MAC address is not attached to the interface.</li> <li>• operational(4) – The access point's IP address, subnet mask, and default gateway have been defined on the interface and the access point with the matching MAC address is attached to the interface and is operational.</li> </ul>
wgPnPRowStatus brcdIp.1.1.3.23.4.1.7 Syntax: Integer	Read-write	Creates, deletes or modifies a row in the AP ADC table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> <li>• modify(5)</li> </ul>

## VPN passthrough server table

The VPN passthrough server table contains the VPN policies that have been configured on the WLAN controller.

Name, OID, and syntax	Access	Description
wgVpnPTServerTable brcdIp.1.1.3.23.5	None	VPN passthrough server table.
wgVpnPTServerPolicyId brcdIp.1.1.3.23.5.1.1 Syntax: Integer	Read-only	The ID of a VPN passthrough policy. The value of this object must be greater than zero.
wgVpnPTServerIpAddress brcdIp.1.1.3.23.5.1.2 Syntax: IpAddress	Read-only	The IP address of the VPN server that will be used to terminate VPN traffic that goes through this switch.
wgVpnPTServerRowStatus brcdIp.1.1.3.23.5.1.3 Syntax: Integer	Read-write	Creates or deletes a row in the VPN passthrough server table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## VPN passthrough filter table

The VPN passthrough filter table shows the VPN passthrough policies and the action the policy takes when it encounters VPN traffic that matches the policy.



Name, OID, and syntax	Access	Description
wgVpnPTFilterTable brcdIp.1.1.3.23.6	None	The VPN passthrough filter table.
wgVpnPTFilterPolicyId brcdIp.1.1.3.23.6.1.1 Syntax: Integer	Read-only	The ID of the VPN passthrough policy. This is a number greater than zero.
wgVpnPTFilterProtocol brcdIp.1.1.3.23.6.1.2 Syntax: Integer	Read-only	Specifies which protocol will be allowed to pass through: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• udp(2)</li> <li>• tcp(3)</li> </ul>
wgVpnPTFilterPort brcdIp.1.1.3.23.6.1.4 Syntax: Integer	Read-only	Specifies which protocol interface (number) will be allowed to pass through.
wgVpnPTFilterRowStatus brcdIp.1.1.3.23.6.1.4 Syntax: Integer	Read-write	Creates or deletes a row of the VPN passthrough filter table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## VPN passthrough policy table

The VPN passthrough policy table shows to which interfaces a VPN policy is bound.

Name, OID, and syntax	Access	Description
wgVpnPTPolicyTable brcdIp.1.1.3.23.7	None	VPN passthrough policy table.
wgVpnPTPolicyId brcdIp.1.1.3.23.7.1.1 Syntax: Integer	Read-only	The ID of the VPN policy. The value of this object must be greater than zero.
wgVpnPTPolicyPortList brcdIp.1.1.3.23.7.1.2 Syntax: IfIndexList	Read-only	Shows a list of ports to which this VPN policy is bound.



# Trap MIB Definition

---

## In this chapter

- [Objects to enable or disable standard traps](#) . . . . . 633
- [Standard traps](#) . . . . . 634
- [Proprietary traps](#) . . . . . 639
- [Examples](#) . . . . . 673
- [General traps for the Brocade NetIron devices](#) . . . . . 673

This section describes the standard and proprietary traps that are supported in the Unified IP MIB.

## Objects to enable or disable standard traps

---

### NOTE

By default, all the traps are enabled.

---

The following objects from RFC 1213 are the standard objects that are supported in the Unified IP MIB. They are used to set SNMP traps.

Name, OID, and syntax	Access	Description
snmpInTraps 1.3.6.1.2.1.11.19	Read-only	Shows the total number of SNMP trap PDUs that have been accepted and processed by SNMP.
snmpOutTraps 1.3.6.1.2.1.11.29	Read-only	Shows the total number of SNMP trap PDUs that have been generated by SNMP.
snmpEnableAuthenTrap s 1.3.6.1.2.1.11.30	Read-write	Indicates if the SNMP agent process is permitted to generate authentication failure traps. The value of this object overrides any configuration information. This objects provides a way to disable all authentication failure traps.  <b>NOTE:</b> It is strongly recommended that this object to be stored in the nonvolatile memory so that it remains constant between re-initializations of the network management system.

Name, OID, and syntax	Access	Description
IldpRemTablesChange 1.0.8802.1.1.2.1.4.1	None	An IldpRemTablesChange notification is sent when the value of IldpStatsRemTableLastChangeTime changes. It can be used by an NMS to trigger LLDP remote systems table maintenance polls.  <b>NOTE:</b> Transmission of IldpRemTablesChange notifications is throttled by the agent, as specified by the IldpNotificationInterval object.
IldpXMedTopologyChangeDetected 1.0.8802.1.1.2.1.5.479 5.0.1	None	Allows a device to transfer information related to topology changes to management applications in an asynchronous manner. Specifically, this enables notification of the fact that a new remote device was connected to the local port of an LLDP-MED network connectivity device, or that a remote device was removed from the local port. The purpose of this notification is efficient, near-real-time transmission of information regarding moves and changes to the management applications. Information carried by the list of objects (varbind) contained in the notification allows the receiving management application to uniquely identify the local port where the topology change occurred, as well as the device capability of the remote endpoint device that was attached to or removed from the port.

## Standard traps

This section describes the supported standard traps.

### System status traps

Foundry supports the following traps from RFC 1215.

Trap name and number	Varbind	Description
coldStart 1.3.6.1.6.3.1.1.5.1	None	Indicates that the sending protocol entity is reinitializing itself; the agent's configuration or the protocol entity implementation may be altered.
warmStart 1.3.6.1.6.3.1.1.5.2	None	Indicates that the sending protocol entity is reinitializing itself; however, the agent configuration or the protocol entity implementation is not altered.
linkDown 1.3.6.1.6.3.1.1.5.3	ifIndex(1) ifDescr(2)	A failure in one of the communication links.
linkUp 1.3.6.1.6.3.1.1.5.4	ifIndex(1) ifDescr(2)	The communication link is up.

Trap name and number	Varbind	Description
<p><b>NOTE:</b> Regarding linkUp and linkDown traps:</p> <ul style="list-style-type: none"> <li>• Brocade FastIron release 07.1.x. supports a maximum of 32 ports per module; thus, the ifIndex for this release ranges from 1 through 32 for Slot 1, from 33 through 64 for Slot 2, and so on.</li> <li>• Brocade FastIron release 07.2.x supports a maximum of 64 ports per module; thus, the ifIndex for the release ranges from 1 through 64 for Slot 1, from 65 through 128 for Slot2, and so on.</li> </ul> <p>Thus for Slot 2/Port 1, the value of the ifIndex of the port in Brocade FastIron release 07.1.x is 33; whereas, in Brocade FastIron release 07.2.x, it is 65.</p>		
authenticationFailure 1.3.6.1.6.3.1.1.5.5	None	Indicates that the sending protocol entity is the addressee of a protocol message that is not properly authenticated. While implementations of SNMP must be capable of generating this trap, they must also be capable of suppressing the emission of such traps through an implementation-specific mechanism.

## Traps for STP

Foundry supports the following traps for Spanning Tree Protocol (STP) from RFC 1493.

Trap name and number	Description
newRoot 1.3.6.1.2.1.17.0.1	Indicates that the sending agent has become the new root of the Spanning Tree. The trap is sent by a bridge soon after its election as the new root, for example, upon expiration of the Topology Change Timer immediately subsequent to its election.
topologyChange 1.3.6.1.2.1.17.0.2	Sent by a bridge when any of its configured ports transitions from the Learning state to the Forwarding state, or from the Forwarding state to the Blocking state. The trap is not sent if a newRoot trap is sent for the same transition.

## Traps for alarms

Brocade supports the following traps for alarms from RFC 1757.

### NOTE

On Brocade NetIron XMR and Brocade MLX devices, the RFC 1757 has been obsoleted by RFC 2819.

Trap name and number	Description
alarmRisingThreshold 1.3.6.1.2.1.16.3.1.1.7	A threshold for the sampled statistic. This object generates an event when the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold. This object also generates an event if the first sample after this entry becomes valid is greater than or equal to this threshold and the associated alarmStartupAlarm is equal to risingAlarm(1) or risingOrFallingAlarm(3). After a rising event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches the alarmFallingThreshold.

Trap name and number	Description
alarmFallingThreshold 1.3.6.1.2.1.16.3.1.1.8	A threshold for the sampled statistic. This object generates an event when the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold. This object also generates an event if the first sample after this entry becomes valid is less than or equal to this threshold and the associated alarmStartupAlarm is equal to fallingAlarm(2) or risingOrFallingAlarm(3). After a falling event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches the alarmRisingThreshold.

## Pseudo wire traps

The following are the PW traps.

### NOTE

The following traps are supported on the Brocade NetIron XMR, Brocade MLX, and Brocade MLXe devices.

Additional MPLS-related traps are listed in “[MPLS notifications](#)” on page 660, and “[MPLS LSP notification](#)” on page 661.

Trap name and number	Supported?	Varbind	Description
pwDown brcdIp.3.1.2.0.1	Yes	pwOperStatus (for start of range) pwOperStatus (for end of range) fdryPWServiceType	This notification is generated when the pwOperStatus object for one or more contiguous entries in pwTable are about to enter the down(2) state from some other state. The included values of pwOperStatus must all be set equal to this down(2) state. On the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, this object is available for VPLS, VLL, and VLL local services.
pwUp brcdIp.3.1.2.0.2	Yes	pwOperStatus (for start of range) pwOperStatus (for end of range) fdryPWServiceType	This notification is generated when the pwOperStatus object for one or more contiguous entries in pwTable are about to enter the up(1) state from some other state. On the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, this object is available for VPLS, VLL, and VLL local services.
pwDeleted brcdIp.3.1.2.0.3	Yes	pwID pwPeerAddrType pwPeerAddr fdryPWServiceType pwName	This notification is generated when the PW has been deleted. <b>NOTE:</b> The pwname varbind is an extension added by Foundry; it is not a part of the Draft PW MIB Version 11. On the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices, this object is available for VPLS, VLL, and VLL local services.

## MPLS Layer 3 VPN traps

The following table lists the MPLS Layer 3 VPN traps.

Trap name	Supported?	Varbind	Description
mplsL3VpnVrfUp 1.3.6.1.2.1.10.166.11.0.1	Yes	mplsL3VpnIfConfRowStatus, mplsL3VpnVrfOperStatus	Generated when ifOperStatus of any interface within the VRF changes to the up state.
mplsL3VpnVrfDown 1.3.6.1.2.1.10.166.11.0.2	Yes	mplsL3VpnIfConfRowStatus, mplsL3VpnVrfOperStatus	Generated when ifOperStatus of any interface within the VRF changes to the down state.
mplsL3VpnVrfRouteMidThresholdExceeded 1.3.6.1.2.1.10.166.11.0.3	No	mplsL3VpnVrfPerfCurrNumRoutes, mplsL3VpnVrfConfMidRouteThresh	This notification is generated when the number of routes contained by the specified VRF exceeds the value indicated by mplsL3VpnVrfMidRouteThreshold. A single notification must be generated when this threshold is exceeded, and no other notifications of this type should be issued until the value of mplsL3VpnVrfPerfCurrNumRoutes has fallen below that of mplsL3VpnVrfConfMidRteThresh.
mplsL3VpnVrfNumVrfRouteMaxThresholdExceeded 1.3.6.1.2.1.10.166.11.0.4	No	mplsL3VpnVrfPerfCurrNumRoutes, mplsL3VpnVrfConfHighRteThresh	This notification is generated when the number of routes contained by the specified VRF exceeds or attempts to exceed the maximum allowed value as indicated by mplsL3VpnVrfMaxRouteThreshold. In cases where mplsL3VpnVrfConfHighRteThresh is set to the same value as mplsL3VpnVrfConfMaxRoutes, mplsL3VpnVrfConfHighRteThresh need not be exceeded; rather, just reached for this notification to be issued.  Note that the mplsL3VpnVrfConfRteMxThrsTime object denotes the interval at which this notification will be reissued after the maximum value has been exceeded (or reached if mplsL3VpnVrfConfMaxRoutes and mplsL3VpnVrfConfHighRteThresh are equal) and the initial notification has been issued. This value is intended to prevent continuous generation of notifications by an agent in the event that routes are continually added to a VRF after it has reached its maximum value. The default value is 0 minutes. If this value is set to 0, the agent

Trap name	Supported?	Varbind	Description
mplsL3VpnVrfNumVrfRouteMaxThreshExceeded (continued)			should only issue a single notification at the time that the maximum threshold has been reached, and should not issue any more notifications until the value of routes has fallen below the configured threshold value.
mplsL3VpnNumVrfSecIllegalLblThreshExcd 1.3.6.1.2.1.10.166.11.0.5	No	mplsL3VpnVrfSecIllegalLblVltns	This notification is generated when the number of illegal label violations on a VRF as indicated by mplsL3VpnVrfSecIllegalLblVltns has exceeded mplsL3VpnVrfSecIllegalLblVltnsThresh. The threshold is not included in the varbind here because the value of mplsL3VpnVrfSecIllegalLblVltns should be one greater than the threshold at the time this notification is issued.
mplsL3VpnNumVrfRouteMaxThreshCleared 1.3.6.1.2.1.10.166.11.0.6	No	mplsL3VpnVrfPerfCurrentRoutes, mplsL3VpnVrfConfHighRteThresh	This notification is generated only after the number of routes contained by the specified VRF exceeds or attempts to exceed the maximum allowed value as indicated by mplsVrfMaxRouteThreshold, and then falls below this value. The notification informs the operator that the error condition has been cleared without the operator having to query the device. Note that the mplsL3VpnVrfConfRteMxThreshTime object denotes the interval at which the mplsNumVrfRouteMaxThreshExceeded notification will be reissued after the maximum value has been exceeded (or reached if mplsL3VpnVrfConfMaxRoutes and mplsL3VpnVrfConfHighRteThresh are equal) and the initial notification has been issued. Thus, the generation of this notification should also be emitted with this same frequency (assuming that the error condition is cleared). Specifically, if the error condition is reached and cleared several times during the period of time specified in mplsL3VpnVrfConfRteMxThreshTime, only a single notification is issued to indicate the first instance of the error condition as well as the first time the error condition is cleared. This behavior is intended to prevent



Trap name	Supported?	Varbind	Description
mplsL3VpnNumVrfRouteMaxThreshCleared 1.3.6.1.2.1.10.166.11.0.6			continuous generation of notifications by an agent in the event that routes. This notification is generated only after the number of routes contained by the specified VRF exceeds or attempts to exceed the maximum allowed value as indicated by mplsVrfMaxRouteThreshold, and then falls below this value. The default value is 0. If this value is set to 0, the agent should issue a notification whenever the maximum threshold has been cleared.

## Proprietary traps

This section presents the proprietary traps supported on devices running proprietary software.

### NOTE

The traps in the proprietary MIBs include the following lines in their description:

```
--#TYPE "Brocade Trap: Power Supply Failure"
--#SUMMARY "Power supply fails, error status %d."
--#ARGUMENTS { 0 }
--#SEVERITY MINOR
--#STATE OPERATIONAL
```

## General traps

The table below lists the general traps generated by devices. Refer to the previous sections in this chapter to determine if traps for a feature must be enabled (for example, OSPF traps must be enabled).

Trap name and number	Varbinds	Severity	Description and trap message
snTrapChasPwrSupply brcdIp.0.1	snChasPwrSupply Status	Minor	The power supply failed or is not operating normally. The value is a packed bit string; the power supply statuses are encoded into four bits (a nibble). The following shows the meaning of each bit: (Bit 0 is the least significant bit.) Bit position and meaning 4 to 31- Reserved 3 - Power Supply 2 DC (0=bad, 1=good). 2 - Power Supply 1 DC (0=bad, 1=good). 1 - Power Supply 2 present status (0-present, 1-not present). 0 - Power Supply 1 present status (0-present, 1-not present). Sample trap message: Power supply fails, error status <snChasPwrSupplyStatus>
<b>NOTE:</b> This object has been replaced by "snTrapChasPwrSupply Failed" on page 640 and "snTrapChasFanFailed" on page 640			
<b>NOTE:</b> This object is not supported on Brocade NetIron XMR and Brocade MLX devices. It has been replaced by the "Power supply table" on page 117. Also, this object is not supported on the Brocade MLXe.			
snTrapLockedAddressViolation brcdIp.0.2	snSwViolatorPortNumber snSwViolatorMacAddress	Minor	The number of source MAC addresses received from a port is greater than the maximum number of addresses configured for that port. Sample trap message: Lock address violation on Port <snSwViolatorPortNumber> with MAC Address <snSwViolatorMacAddress>
<b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			
snTrapModuleInserted brcdIp.0.28	snAgentBrdIndex	Informational	A module was inserted into the chassis while the system is running. Sample trap message: Module <snAgentBrdIndex> was inserted to the chassis during system running
snTrapModuleRemoved brcdIp.0.29	snAgentBrdIndex	Informational	A module was removed from the chassis while the system is running. Sample trap message: Module <snAgentBrdIndex> was removed from the chassis during system running
snTrapChasPwrSupplyFailed brcdIp.0.30	snChasPwrSupplyIndex snChasPwrSupplyDescription	Minor	A power supply in the device failed. Sample trap message: Power supply <snChasPwrSupplyIndex> {<snChasPwrSupplyDescription>} failed
snTrapChasFanFailed brcdIp.0.31	snChasFanIndex snChasFanDescription	Minor	A fan in the device failed. Sample trap message: Fan <snChasFanIndex> (<snChasFanDescription>) failed

Trap name and number	Varbinds	Severity	Description and trap message
snTrapLockedAddressViolation 2 brcdIp.0.32 <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	snAgGblTrapMessage	Minor	The number of source MAC addresses received from a port is greater than the maximum number of addresses configured for that port. Sample trap message: Locked address violation at interface Ethernet <port>, address <mac>
snTrapMgmtModuleRedundancyChange brcdIp.0.35	snAgGblTrapMessage	Warning	The management module changed its redundancy state. Sample trap message: Management module at slot <slot-num> state changed from <old-state> to <new-state>
snTrapTemperatureWarning brcdIp.0.36	snAgGblTrapMessage	Critical	The actual temperature reading is above the warning temperature threshold. Sample trap message: Temperature <actual-temp> C degrees, warning level <warning-temp> C degrees, shutdown level <shutdown-temp> C degrees
snTrapAccessListDeny brcdIp.0.37	snAgGblTrapMessage	Warning	A packet was denied by an access list. Sample trap message: (for RIP): rip filter list <id> in rip denied <IP>, <n> event(s)
snTrapMacFilterDeny brcdIp.0.38	snAgGblTrapMessage	Warning	A packet was denied by a MAC address filter. Sample trap message: mac filter group denied packets on port <n> src macaddr <mac>, <n> packets
snTrapChasFanNormal brcdIp.0.49 <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	snChasFanIndex snChasFanDescription	Minor	The status of a fan has changed from fail to normal. Sample trap message: Fan <snChasFanIndex> (<snChasFanDescription>) ok
snTrapDuplicateIp brcdIp.0.56		Major	A duplicate IP address was detected. Sample trap message: Duplicate IP address detected.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapRunningConfigChanged brcdIp.0.73	snAgGblTrapMess age	Informational	The running configuration has been changed. Sample trap message: Running-config was changed from telnet.
snTrapStartupConfigChanged brcdIp.0.74	snAgGblTrapMess age	Informational	The startup configuration has been changed. Sample trap message: Startup-config was changed from console.
snTrapUserLogin brcdIp.0.75	snAgGblTrapMess age	Informational	A user logged in to a device. Sample trap message: <user1> login to USER EXEC mode.
snTrapUserLogout brcdIp.0.76	snAgGblTrapMess age	Informational	A user logged out of a device. Sample trap message: <user1> logout from USER EXEC mode.
snTrapChasPwrSupplyOK brcdIp.0.81	snChasPwrSupplyI ndex, snChasPwrSupply Description	Notification	The SNMP trap that is generated when a power supply operational status changes from failure to normal Sample trap message: Power supply <device> OK
snTrapClientLoginReject brcdIp.0.110	snAgGblTrapMess age	Informational	A login by a Telnet or SSH client failed. Sample trap message: telnet SSH access [by <username>] from src IP <ip>, src MAC <mac> rejected, <n> attempt(s)
snTrapLocalUserConfigChange brcdIp.0.111	snAgGblTrapMess age	Informational	The configuration of a local user account has been changed. Sample trap message: user <name> added deleted modified from console telnet ssh web snmp
snTrapVlanConfigChange brcdIp.0.112	snAgGblTrapMess age	Informational	A VLAN configuration has been changed. FSample trap message: vlan <vlan-id> added deleted modified from console telnet ssh web snmp session
snTrapAclConfigChange brcdIp.0.113	snAgGblTrapMess age	Informational	An ACL configuration has been changed. Sample trap message: ACL <acl-id> added deleted modified from console telnet ssh web snmp session

Trap name and number	Varbinds	Severity	Description and trap message
snTrapMacFilterConfigChange brcdIp.0.114	snAgGblTrapMess age	Informational	A MAC filter configuration has been changed. Sample trap message: MAC Filter <added deleted> from console telnet ssh web snmp session (filter id=<id>, src mac=<mac> any, dst mac=<mac> any)
snTrapSNMPConfigChange brcdIp.0.115	snAgGblTrapMess age	Informational	SNMP configuration has been changed. Sample trap message: [read-only community read-write community contact location user  group view engineId trap host] "<value>" deleted added modified from console telnet ssh web snmp session <b>NOTE:</b> A contact, location, user, group, view, trap host name may be displayed for <value>.
snTrapSyslogConfigChange brcdIp.0.116	snAgGblTrapMess age	Informational	Syslog configuration has been changed. Sample trap message: Syslog server <ip-address> deleted added modified from console telnet ssh web snmp or Syslog operation enabled disabled from console telnet ssh web snmp
snTrapPasswordConfigChange brcdIp.0.117	snAgGblTrapMess age	Informational	The enable or line password has been changed. Sample trap message: Enable <super port-config read-only> password deleted added modified from console telnet ssh web snmp or Line password deleted added modified from console telnet ssh web snmp

Trap name and number	Varbinds	Severity	Description and trap message
snTrapServerStatusChange brcdIp.0.118	snAgGblTrapMess age	Informational	SNMP trap server has been enabled or disabled. Sample trap message: SSH Telnet server enabled disabled from console telnet ssh web snmp session [by <user> <username>]
snTrapPortPriorityChange brcdIp.0.122  <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	snAgGblTrapMess age	Informational	This trap is generated when a port's priority is changed. Sample trap message: Port <port-number> priority changed to <new-priority>

## Traps for optics

The following table presents the general optics traps on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOpticalMonitoringWarning brcdIp.0.1003  <b>NOTE:</b> This trap is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	snAgGblTrapMessage	Warning	A warning occurred during optical monitoring. Sample trap message: Latched high Temperature alarm, port <slot>/<port>
snTrapOpticalMonitoringAlarm brcdIp.0.1004  <b>NOTE:</b> This trap is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	snAgGblTrapMessage	Alerts	An alarm occurred during optical monitoring due to a low temperature in the device. Sample trap message: Latched low Temperature alarm, port <slot>/<port>

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOpticalMonitoringError brcdIp.0.1005	snAgGblTrapMessage	Informational	An error occurred during optical monitoring. Samples trap message: OPTICAL MONITORING: sys_create_timer failed, slot <n>, port mask <portmask> OPTICAL MONITORING: sys_set_timer failed, slot <n>, port mask <portmask> OPTICAL MONITORING: THRESHOLDS READ FAILED, port <slot>/<port> OPTICAL MONITORING: AUX AD TYPE READ FAILED, port <slot>/<port>" OPTICAL MONITORING: INT UNMASK ALL WRITE FAILED, port <slot>/<port> OPTICAL MONITORING: INT MASK WRITE FAILED, port <slot>/<port> OPTICAL MONITORING:: XFP INT MASK WRITE FAILED, port <slot>/<port> OPTICAL MONITORING: port <slot>/<port>: sys_create_timer failed OPTICAL MONITORING: port <slot>/<port>: sys_create_timer2 failed OPTICAL MONITORING: port <slot>/<port>: sys_set_timer failed
snTrapOpticalMonitoringError (continued)			OPTICAL MONITORING: port <slot>/<port>, failed to get latched flags(<n>) OPTICAL MONITORING: port <slot>/<port>: sys_set_timer1 failed
snTrapXfpSfpIncompatibleOptics brcdIp.0.1009	snAgGblTrapMessage	Alerts	The optics are incompatible with the port configuration.
<b>NOTE:</b> This trap is supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			

## Traps for TM

The following table contains Traffic Manager (TM) traps that are supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapTMLoggingStart brcdIp.0.1015	snAgGblTrapMessage	Informational	TM logging started, triggered by an event.
snTrapTMLoggingStop brcdIp.0.1016	snAgGblTrapMessage	Informational	TM logging stopped because the storage is full.
snTrapTMLoggingRestart brcdIp.0.1017	snAgGblTrapMessage	Informational	TM logging restarted after the log was cleared.
snTrapTMEgressDataError brcdIp.0.1020	snAgGblTrapMessage	Major	This trap is generated when the system detects egress data errors on the Traffic Manager. Sample trap message: Health Monitoring : TM Egress data errors detected on LP <num>/TM <num>
snTrapSFMLinkDown brcdIp.0.1100	snAgGblTrapMessage	Warning	A link from the LP Traffic Manager to an SFM Fabric Element is down. Sample trap message: Fabric Monitoring Link Down : SFM <num>/FE <num>/Link <num>, LP <num>/TM <num>
snTrapSFMLinkUp brcdIp.0.1101	snAgGblTrapMessage	Informational	A link from the LP Traffic Manager to an SFM Fabric Element is up. Sample trap message: Fabric Monitoring Link Up : SFM <num>/FE <num>/Link <num>, LP <num>/TM <num>
snTrapSFMAccessError brcdIp.0.1102	snAgGblTrapMessage	Major	This trap is generated when the system fails to access an SFM Fabric Element. Sample trap message: Health Monitoring: FE accessfailure on SFM <num>/FE <num>
snTrapSFMStatusChange brcdIp.0.1103	snAgentBrdIndex, snAgentBrdModuleStatus, snAgGblTrapMessage	Notification	The SNMP notification that is generated when there is a change in the operational state of the Switch Fabric Module (SFM). <b>NOTE:</b> For 100G modules, the string SNM5/FE1/Link16 -> LP15/TM1/Link4 is changed to SNM5/FE1/Link16 -> LP15/FE1/Link4 in syslog or TM log or in trap. Sample trap message: System: Health Monitoring: SFM <num> powered off due to failure detection



## Packet over SONET traps

The following contains packet over SONET traps that are supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description
snTrapPosMonitoringWarning brcdIp.0.1006	snAgGblTrapMes sage	Informational	A warning occurred during POS alarm monitoring.
snTrapPosMonitoringAlarm brcdIp.0.1007	snAgGblTrapMes sage	Alert	An alarm up or alarm down incident occurred during POS alarm monitoring.
snTrapPosMonitoringError brcdIp.0.1008	snAgGblTrapMes sage	Informational	An error occurred during POS alarm monitoring.

## MAC-based VLAN traps

The following table contains MAC-based VLAN traps that are supported only on the FastIron devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapMacBasedVlanEnabled brcdIp.0.147	snAgGblTrapMessage	Minor	MAC-based VLAN is enabled. Sample trap message: SNTrapMacBasedVlanEnabled: Mac Based Vlan Enabled on port <port id>.
snTrapMacBasedVlanDisabled brcdIp.0.148	snAgGblTrapMessage	Minor	MAC-based VLAN is disabled. Sample trap message: SNTrapMacBasedVlanDisabled: Mac Based Vlan Disabled on port <port id>.
snTrapMacMoveThresholdRate brcdIp.0.197	snAgGblTrapMessage	Notifications	The SNMP notification is generated when MAC movement is exceeding the certain threshold for a sampling interval is detected. Sample trap message: Mac-Move threshold-rate: MAC address <mac> moved from interface <port-id> to interface <port-id> for vlan <vlan-id>, <move-count> times exceeding the threshold rate <threshold-rate> for a sampling interval <interval> seconds
snTrapMacMoveIntervalHistory	snAgGblTrapMessage	Notifications	The SNMP notification is generated for every user configured interval, summarizing the moves in the interval. Sample trap message: Mac-Move Interval-History: <#macs> macs moved in last <interval> seconds. Total number of mac moves in the interval is <#moves>

## VRRP traps

The following table contains VRRP trap that can be used only by the devices that support VRRP.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapVrrplfStateChange brcdIp.0.34	snAgGblTrapMessage	Warning	A VRRP routing device changed state from master to backup or vice versa. Sample trap message: VRRP intf state changed, intf <port>, vrid <id>, state <new-state>.

## FSRP traps

The following traps can be used by the devices that support FSRP.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapFsrplfStateChange brcdIp.0.33	snAgGblTrapMessage	Informational	An FSRP routing device changed state from active to standby or vice versa. Sample trap message: SRP_FSRP intf state changed, intf <port>, addr <ip>, state <new-state>.

## VSRP traps

The following traps can be used by the devices that support VSRP.

Trap name and number	Varbinds	Severity	Description
snTrapVsrpStateChange brcdIp.0.83	snAgGblTrapMessage	Informational	A VSRP routing device changed its state.
snTrapVsrpCamError brcdIp.0.84	snAgGblTrapMessage	Informational	A VSRP CAM error has occurred.

## OSPF traps

The Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices support RFC 1850 and the objects in the following table are not supported.

### NOTE

You must configure the **log adjacency** command under the "router ospf" mode to see traps for the following objects:

- ospflfStateChange trap
- ospfNbrStateChange trap
- ospfVirtlfStateChange trap
- ospfVirtNbrStateChange trap

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOspfIfStateChange 1.3.6.1.2.1.14.16.2.3	snOspfRouterId (The originator of the trap) snOspfIfStatusIpAddress snOspfIfStatusState (The new state)	Informational	<p>There has been a change in the state of a non-virtual OSPF interface. This trap should be generated when the interface state regresses (for example, goes from Dr to Down) or progresses to a terminal state (for example, Point-to-Point, DR Other, Dr, or Backup).</p> <p><b>NOTE:</b> You must configure the <b>log adjacency</b> command under the "router ospf" mode to see traps.</p> <p>Sample trap message:            OSPF router id            &lt;snOspfRouterId&gt;, interface            &lt;snOspfIfStatusIpAddress&gt;            state changed to            &lt;snOspfIfStatusState&gt;.</p>
snTrapOspfVirtIfStateChange 1.3.6.1.2.1.14.16.2.4	snOspfRouterId (The originator of the trap) snOspfVirtIfStatusAreaID snOspfVirtIfStatusNeighbor snOspfVirtIfStatusState (The new state)	Informational	<p>There has been a change in the state of an OSPF virtual interface. This trap should be generated when the interface state regresses (for example, goes from Point-to-Point to Down) or progresses to a terminal state (for example, Point-to-Point).</p> <p><b>NOTE:</b> You must configure the <b>log adjacency</b> command under the "router ospf" mode to see traps.</p> <p>Sample trap message:            OSPF router id            &lt;snOspfRouterId&gt;, virtual            interface area id            &lt;snOspfVirtIfStatusAreaID&gt;            neighbor            &lt;snOspfVirtIfStatusNeighbor&gt;            state changed to            &lt;snOspfVirtIfStatusState&gt;.</p>

Trap name and number	Varbinds	Severity	Description and trap message
snOspfNbrStateChange 1.3.6.1.2.1.14.16.2.5	snOspfRouterId (The originator of the trap) snOspfNbrIpAddr snOspfNbrRtrId snOspfNbrState (The new state)	Informational	<p>There has been a change in the state of a non-virtual OSPF neighbor. This trap should be generated when a neighbor state regresses (for example, goes from Attempt or Full to 1-Way or Down) or progresses to a terminal state (for example, 2-Way or Full). When an neighbor transitions from or to Full on non-broadcast multi-access and broadcast networks, the trap should be generated by the designated router. A designated router transitioning to Down will be noted by ospfIfStateChange.</p> <p><b>NOTE:</b> You must configure the <b>log adjacency</b> command under the "router ospf" mode to see traps.</p> <p>Sample trap message:          OSPF router id          &lt;snOspfRouterId&gt; neighbor area          &lt;snOspfNbrIpAddr&gt;, neighbor          router id &lt;snOspfNbrRtrId&gt;          state changed to          &lt;snOspfNbrState&gt;.</p>
snOspfVirtNbrStateChange 1.3.6.1.2.1.14.16.2.6	snOspfRouterId (The originator of the trap) snOspfVirtNbrArea snOspfVirtNbrRtrId snOspfVirtNbrState (The new state)	Informational	<p>There has been a change in the state of an OSPF virtual neighbor. This trap should be generated when the neighbor state regresses (for example, goes from Attempt or Full to 1-Way or Down) or progresses to a terminal state (for example, Full).</p> <p><b>NOTE:</b> You must configure the <b>log adjacency</b> command under the "router ospf" mode to see traps.</p> <p>Sample trap message:          OSPF router id          &lt;snOspfRouterId&gt; virtual          neighbor area          &lt;snOspfVirtNbrArea&gt;, virtual          neighbor router id          &lt;snOspfVirtNbrRtrId&gt; state          changed to          &lt;snOspfVirtNbrState&gt;.</p>

Trap name and number	Varbinds	Severity	Description and trap message
snOspfIfConfigError 1.3.6.1.2.1.14.16.2.7	snOspfRouterId (The originator of the trap) snOspfIfStatusIpAddresses snOspfPacketSrc (The source IP address) snOspfConfigErrorType (Type of error) snOspfPacketType	Major	A packet has been received on a non-virtual interface from a router whose configuration parameters conflict with this router's configuration parameters.  <b>NOTE:</b> The optionMismatch event should cause a trap only if it prevents an adjacency from forming.  Sample trap message: Configuration error type <snOspfConfigErrorType> with packet type <snOspfPacketType> has been received on interface <snOspfIfStatusIpAddress>, router id <snOspfRouterId> from <snOspfPacketSrc>.
snOspfVirtIfConfigError 1.3.6.1.2.1.14.16.2.8	snOspfRouterId (The originator of the trap) snOspfVirtIfStatusAreaID snOspfVirtIfStatusNeighbor snOspfConfigErrorType (Type of error) snOspfPacketType	Major	A packet has been received on a virtual interface from a router whose configuration parameters conflict with this router's configuration parameters.  <b>NOTE:</b> The optionMismatch event should cause a trap only if it prevents an adjacency from forming.  Sample trap message: Configuration error type <snOspfConfigErrorType> with packet type <snOspfPacketType> has been received on virtual interface area id <snOspfVirtIfStatusAreaID>, router id <snOspfRouterId> from neighbor <snOspfVirtIfStatusNeighbor>.
snOspfIfAuthFailure 1.3.6.1.2.1.14.16.2.9	snOspfRouterId (The originator of the trap) snOspfIfStatusIpAddresses snOspfPacketSrc (The source IP address) snOspfConfigErrorType (authTypeMismatch or authFailure) snOspfPacketType	Minor	A packet has been received on a non-virtual interface from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type.  Sample trap message: OSPF authentication failed. Router ID <snOspfRouterId>, Interface <snOspfIfStatusIpAddress>, packet src <snOspfPacketSrc>, error type <snOspfConfigErrorType> and packet type <snOspfPacketType>.

Trap name and number	Varbinds	Severity	Description and trap message
snOspfVirtIfAuthFailure 1.3.6.1.2.1.14.16.2.10	snOspfRouterId (The originator of the trap) snOspfVirtIfStatusAreaID snOspfVirtIfStatusNeighbor snOspfConfigErrorType (authTypeMismatch or authFailure) snOspfPacketType	Minor	A packet has been received on a virtual interface from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type. Sample trap message: OSPF authentication failed. Router ID <snOspfRouterId>, virtual interface <snOspfVirtIfStatusAreaID>, Neighbor <snOspfVirtIfStatusNeighbor>, Error type <snOspfConfigErrorType> and packet type <snOspfPacketType>.
snOspfIfRxBadPacket 1.3.6.1.2.1.14.16.2.11	snOspfRouterId (The originator of the trap) snOspfIfStatusIpAddresses snOspfPacketSrc (The source IP address) snOspfPacketType	Warning	An OSPF packet has been received on a non-virtual interface that cannot be parsed. Sample trap message: OSPF Router Id <snOspfRouterId>, interface <snOspfIfStatusIpAddress> receive bad packet (type <snOspfPacketType>) from <snOspfPacketSrc>.
snOspfVirtIfRxBadPacket 1.3.6.1.2.1.14.16.2.12	snOspfRouterId (The originator of the trap) snOspfVirtIfStatusAreaID snOspfVirtIfStatusNeighbor snOspfPacketType	Warning	An OSPF packet has been received on a virtual interface that cannot be parsed. Sample trap message: OSPF router id <snOspfRouterId>, virtual interface <snOspfVirtIfStatusAreaID> received bad packet (type <snOspfPacketType>) from neighbor <snOspfVirtIfStatusNeighbor>.
snOspfTxRetransmit 1.3.6.1.2.1.14.16.2.13	snOspfRouterId (The originator of the trap) snOspfIfStatusIpAddresses snOspfNbrRtrId (Destination) snOspfPacketType snOspfLsdbType snOspfLsdbLsId snOspfLsdbRouterId	Warning	An OSPF packet has been retransmitted on a non-virtual interface. All packets that may be retransmitted are associated with an LSDB entry. The LS type, LS ID, and Router ID are used to identify the LSDB entry. Sample trap message: OSPF router id <snOspfRouterId> interface <snOspfIfStatusIpAddress> retransmitted packet type <snOspfPacketType>, LSDB type <snOspfLsdbType>, LSDB LS ID <snOspfLsdbLsId> and LSDB router id <snOspfLsdbRouterId> to Neighbor router id <snOspfNbrRtrId>.

Trap name and number	Varbinds	Severity	Description and trap message
ospfVirtIfTxRetransmit 1.3.6.1.2.1.14.16.2.14	snOspfRouterId (The originator of the trap) snOspfVirtIfStatusAreaID snOspfVirtIfStatusNeighbor snOspfPacketType snOspfLsdbType snOspfLsdbLsId snOspfLsdbRouterId	Warning	An OSPF packet has been retransmitted on a virtual interface. All packets that may be retransmitted are associated with an LSDB entry. The LS type, LS ID, and Router ID are used to identify the LSDB entry. Sample trap message: OSPF router id <snOspfRouterId>, virtual interface area id <snOspfVirtIfStatusAreaID> retransmitted packet type <snOspfPacketType>, LSDB type <snOspfLsdbType>, LSDB LS ID <snOspfLsdbLsId> and LSDB router id <snOspfLsdbRouterId> to Neighbor <snOspfVirtIfStatusNeighbor>.
snOspfOriginateLsa 1.3.6.1.2.1.14.16.2.15	snOspfRouterId (The originator of the trap) snOspfLsdbAreaId (0.0.0.0 for AS Externals) snOspfLsdbType snOspfLsdbLsId snOspfLsdbRouterId	Informational	This router originated a new LSA. This trap should not be invoked for simple refreshes of LSAs (which happens every 30 minutes), but instead will only be invoked when an LSA is re-originated due to a topology change. Additionally, this trap does not include LSAs that are being flushed because they have reached MaxAge Sample trap message: New LSA (area id <snOspfLsdbAreaId>, type <snOspfLsdbType>, LS Id <snOspfLsdbLsId> and router id <snOspfLsdbRouterId>) has been originated by router id <snOspfRouterId>.
snOspfMaxAgeLsa 1.3.6.1.2.1.14.16.2.16	snOspfRouterId (The originator of the trap) snOspfLsdbAreaId (0.0.0.0 for AS Externals) snOspfLsdbType snOspfLsdbLsId snOspfLsdbRouterId	Warning	One of the LSAs in the router's link-state database has aged to MaxAge. Sample trap message: The LSA (area id <snOspfLsdbAreaId>, type <snOspfLsdbType>, LS Id <snOspfLsdbLsId> and router id <snOspfLsdbRouterId>) in router id <snOspfRouterId> link-state database has aged to maximum age.

Trap name and number	Varbinds	Severity	Description and trap message
snOspfLsdbOverflow 1.3.6.1.2.1.14.16.2.17	snOspfRouterId (The originator of the trap) snOspfExtLsdbLimit	Warning	The number of LSAs in the router's link-state database has exceeded the ospfExtLsdbLimit. Sample trap message: The number of LSAs in the OSPF router id <snOspfRouterId> link-state database has exceeded <snOspfExtLsdbLimit>.
snOspfLsdbApproachingOverflow 1.3.6.1.2.1.14.16.2.18	snOspfRouterId (The originator of the trap) snOspfExtLsdbLimit	Informational	The number of LSAs in the router's link-state database has exceeded 90 percent of the ospfExtLsdbLimit. Sample trap message: The number of LSAs in the OSPF router id <snOspfRouterId> link-state database has exceeded ninety percent of <snOspfExtLsdbLimit>.

## Layer 4 traps

The following table presents the traps that can be generated for Layer 4 functionalities.

### NOTE

The following table contain traps that are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapL4MaxSessionLimitReached brcdIp.0.19	snL4MaxSessionLimit	Warning	The maximum number of connections has been reached. Sample trap message: SLB maximum number of connections <snL4MaxSessionLimit> has been reached.
snTrapL4TcpSynLimitReached brcdIp.0.20	snL4TcpSynLimit	Warning	The TCP SYN limits have been reached. Sample trap message: SLB TCP Syn limits <snL4TcpSynLimit> have been reached.
snTrapL4RealServerUp brcdIp.0.21	snL4TrapRealServerIP snL4TrapRealServerName	Informational	The load balancing real server is up. Sample trap message: SLB real server <snL4TrapRealServerIP> <snL4TrapRealServerName> is up.



Trap name and number	Varbinds	Severity	Description and trap message
snTrapL4RealServerDown brcdIp.0.22	snL4TrapRealServerIP snL4TrapRealServerName	Informational	The load balancing real server is down. Sample trap message: SLB real server <snL4TrapRealServerIP> <snL4TrapRealServerName> is down.
snTrapL4RealServerPortUp brcdIp.0.23	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerPort	Informational	The load balancing real server TCP port is up. Sample trap message: SLB real server port <snL4TrapRealServerIP> <snL4TrapRealServerName> <snL4TrapRealServerPort> is up
snTrapL4RealServerPortDown brcdIp.0.24	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerPort	Informational	The load balancing real server TCP port is down. Sample trap message: SLB real server port <snL4TrapRealServerIP> <snL4TrapRealServerName> <snL4TrapRealServerPort> is.
snTrapL4RealServerMaxConnectionLimitReached brcdIp.0.25	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerCurConnections	Warning	The real server reached its maximum number of connections. Sample trap message: SLB real server <snL4TrapRealServerIP> <snL4TrapRealServerName> maximum connection <snL4TrapRealServerCurConnections> has been reached.
snTrapL4BecomeStandby brcdIp.0.26		Warning	The Server Load Balancing switch changed its state from active to standby. Sample trap message: SLB changes state from active to standby.
snTrapL4BecomeActive brcdIp.0.27		Warning	The Server Load Balancing switch changed its state from standby to active. Sample trap message: SLB changes state from standby to active.
snTrapL4GslbRemoteUp brcdIp.0.39	snAgGblTrapMessage	Warning	The connection to the remote ServerIron is up. Sample trap message: L4 gslb connection to site <name> SI <agent IP> <SI name> is up
snTrapL4GslbRemoteDown brcdIp.0.40	snAgGblTrapMessage	Warning	The connection to the remote ServerIron is down. Sample trap message: L4 gslb connection to site <name> SI <agent IP> <SI name> is down

Trap name and number	Varbinds	Severity	Description and trap message
snTrapL4GslbRemoteControlerUp brcdIp.0.41	snAgGblTrapMessage	Warning	The connection to the GSLB ServerIron is up. Sample trap message: L4 gslb connection to gslb SI <IP> is up
snTrapL4GslbRemoteControlerDown brcdIp.0.42	snAgGblTrapMessage	Warning	The connection to the GSLB ServerIron is down. Sample trap message: L4 gslb connection to gslb SI <IP> is down
snTrapL4GslbHealthCheckIpUp brcdIp.0.43	snAgGblTrapMessage	Warning	The GSLB health check for an address changed from the down to the active state. Sample trap message: L4 gslb health-check <IP> of <subname>.<zonenumber> status changed to up
snTrapL4GslbHealthCheckIpDown brcdIp.0.44	snAgGblTrapMessage	Warning	The GSLB health check for an address changed from the active to the down state. Sample trap message: L4 gslb health-check <IP> of <subname>.<zonenumber> status changed to down
snTrajijpL4GslbHealthCheckIpPortUp brcdIp.0.45	snAgGblTrapMessage	Warning	A port for a health check address is up. Sample trap message: L4 gslb health-check <IP> of <subname>.<zonenumber> port <server-port> is up
snTrapL4GslbHealthCheckIpPortDown brcdIp.0.46	snAgGblTrapMessage	Warning	A port for a health check address is down. Sample trap message: L4 gslb health-check <IP> of <subname>.<zonenumber> port <server-port> is down
snTrapL4FirewallBecomeStandby brcdIp.0.47		Major	The Server Load Balancing switch firewall changed its state from active to standby. Sample trap message: firewall group #<group> become standby
snTrapL4FirewallBecomeActive brcdIp.0.48		Major	The Server Load Balancing switch firewall changed its state from standby to active. Sample trap message: firewall group #<group> become active

Trap name and number	Varbinds	Severity	Description and trap message
snTrapL4FirewallPathUp brcdIp.0.49		Minor	The Server Load Balancing switch firewall path is up. Sample trap message: firewall path up target <IP> nexthop <IP> path <num> port <num>
snTrapL4FirewallPathDown brcdIp.0.50		Minor	The Server Load Balancing switch firewall path is down. Sample trap message: Firewall path down target <IP> nexthop <IP> path <num> port <num>
snTrapL4ContentVerification brcdIp.0.55		Informational	The HTTP match list pattern has been found. Sample trap message: HTTP match-list pattern is found.
snTrapL4RealServerResponseTimeLowerLimit brcdIp.0.67	snAgGblTrapMessage	Warning	The real server average response time exceeded the lower threshold. Sample trap message: Port <port-num> on server <server-name>: <IP>: Avg response time <num> has exceeded lower threshold
snTrapL4RealServerResponseTimeUpperLimit brcdIp.0.68	snAgGblTrapMessage	Warning	The real server average response time exceeded the upper threshold. Sample trap message: Port <port-num> on server <server-name>: <IP>: Avg response time <num> has exceeded upper threshold; Bringing down the port...
snTrapL4TcpAttackRateExceededMax brcdIp.0.69	snAgGblTrapMessage	Critical	The TCP attack rate exceeds the configured maximum TCP attack rate. Sample trap message: L4 TCP Attack Rate Exceed Max
snTrapL4TcpAttackRateExceededThreshold brcdIp.0.70	snAgGblTrapMessage	Warning	The TCP attack rate exceeds 80 percent of the configured maximum. Sample trap message: L4 TCP Attack Rate Exceed Threshold
snTrapL4ConnectionRateExceededMax brcdIp.0.71	snAgGblTrapMessage	Critical	The Layer 4 connection rate exceeds the configured maximum. Sample trap message: L4 Connection Rate Exceed Max
snTrapL4ConnectionRateExceededThreshold brcdIp.0.72	snAgGblTrapMessage	Warning	The Layer 4 connection rate exceeds 80 percent of the configured maximum. Sample trap message: L4 Connection Rate Exceed Threshold

## ICMP traps

The following traps are generated for ICMP functionalities.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapIcmpLocalExceedBurst brcdIp.0.51	snAgGblTrapMessage	Warning	Incoming ICMP exceeded the maximum local burst packets. Sample trap message: Local ICMP exceeds <num> burst packets, stopping for <num> seconds!!
snTrapIcmpTransitExceedBurst brcdIp.0.52	snAgGblTrapMessage	Warning	Transit ICMP exceeded the maximum transit burst packets. Sample trap message: Transit ICMP in interface <port-num> exceeds <num> burst packets, stopping for <num> seconds!!

## TCP traps

The following traps are generated for TCP functionalities.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapTcpLocalExceedBurst brcdIp.0.53	snAgGblTrapMessage	Warning	Incoming TCP exceeded the maximum local burst packets. Sample trap message: Local TCP exceeds <num> burst packets, stopping for <num> seconds!!
snTrapTcpTransitExceedBurst brcdIp.0.54	snAgGblTrapMessage	Warning	Transit TCP exceeded the maximum transit burst packets. Sample trap message: Transit TCP in interface <port-num> exceeds <num> burst packets, stopping for <num> seconds!! Sample trap message: Locked address violation at <port-name> <port-num>, address <mac>

## BGP traps

The following table contains BGP traps that are obsolete and has been replaced with the BGP4v2 notifications.

### NOTE

The following table contains BGP traps that are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapBgpPeerUp brcdIp.0.65	snAgGblTrapMessage	Informational	The Border Gateway Protocol (BGP) peer is up. Sample trap message: BGP Peer <IP> UP (ESTABLISHED)
snTrapBgpPeerDown brcdIp.0.66	snAgGblTrapMessage	Informational	The BGP peer is down. Sample trap message: BGP Peer <IP> DOWN (<reason-string>)\n

## BGP4v2 notifications

The following table contains BGP4v2 traps that are supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description
bgp4V2EstablishedNotification brcdIp.3.5.1.0.1	bgp4V2PeerState, bgp4V2PeerLocalPort, bgp4V2PeerRemotePort	Notification	The Border Gateway Protocol (BGP) established event is generated when the BGP finite state machine (FSM) enters the established state.
bgp4V2BackwardTransitionNotification brcdIp.3.5.1.0.2	bgp4V2PeerState, bgp4V2PeerLocalPort, bgp4V2PeerRemotePort, bgp4V2PeerLastErrorCodeReceived, bgp4V2PeerLastErrorSubCodeReceived, bgp4V2PeerLastErrorReceivedText	Notification	The BGP backward transition event is generated when the BGP FSM moves from a higher-numbered state to a lower-numbered state. The current implementation generates this notification only when the state machine moves out of the established state.

## Port security traps

The port security feature enables a device to learn a limited number of “secure” MAC addresses on an interface. The interface forwards only those packets with source MAC addresses that match the secure addresses. The following traps are generated, if the interface receives MAC addresses that are included in its secure MAC list.

### NOTE

The following traps apply to ports that have the port security feature enabled.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapPortSecurityViolation brcdIp.0.77	snAgGblTrapMessage	Minor	Packets from an unknown MAC address are dropped. Sample trap message: Brocade Trap: Port Security Violation
snTrapPortSecurityShutdown brcdIp.0.78	snAgGblTrapMessage	Minor	The port is disabled for the amount of time configured using the <b>violation shutdown &lt;minutes&gt;</b> port security CLI command. Sample trap message: Brocade Trap: Port Security Violation Cause Shutdown

## MRP traps

The following traps are generated for MRP functionalities.

Trap name and number	Varbinds	Severity	Description
snTrapMrpStateChange brcdIp.0.79	snAgGblTrapMessage	Informational	An MRP state occurred.
snTrapMrpCamError brcdIp.0.80	snAgGblTrapMessage	Warning	An MRP CAM error occurred.

## MPLS notifications

### NOTE

The following MPLS traps are included in the Unified IP MIB but they are not supported:

- snTrapMplsProblem (brcdIp.0.57)
- snTrapMplsException (brcdIp.0.58)
- snTrapMplsAudit (brcdIp.0.59)
- snTrapMplsDeveloper (brcdIp.0.60)

The following traps are supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description
fdryVplsCreated brcdIp.1.2.15.2.0.1	vplsConfigName fdryVplsVcId	Informational	Generated when an entry is created in the fdryVplsTable. It is not generated during system bootup time.

Trap name and number	Varbinds	Severity	Description
fdryVplsDeleted brcdIp.1.2.15.2.0.2	vplsConfigName fdryVplsVcld	Informational	An entry in the fdryVplsTable has been marked for deletion. It indicates the deletion of an existing VPLS instance.
fdryPwCreated brcdIp.1.2.15.2.0.3	fdryPwServiceType (vll(1), vlllocal(2), vpls(3)) pwName (The instance name) pwID (VD ID)	Informational	Generated when an instance of VLL or VLL-Local pseudo-wire entry is created in the pwTable. The fdryPwServiceType varbind shows the service type that originated this notification. This notification is not used for VPLS service. This notification is not generated during device bootup.

## MPLS LSP notification

The following traps are generated for the MPLS LSP feature supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

### NOTE

Do not use the following traps if you are using the snTrapTMLogging traps.

Trap name and number	Varbinds	Severity	Description
snMplsLspUp brcdIp.0.1010	mplsLspName, mplsPathName	Informational	Specifies the LSP is up. The current active path for the LSP is the value of mplsPathName.
snMplsLspDown brcdIp.0.1011	mplsLspName, mplsPathName	Informational	Specifies the LSP is down, because the current active path specified by the mplsPathName went down.
snMplsLspChange brcdIp.0.1012	mplsLspName, mplsPathName	Informational	Specifies the particular LSP that has switched traffic to the new active path "toLspPath". The LSP maintains an up state before and after the switchover.

## MPLS LSR notification

The following traps are generated for the MPLS LSR feature supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Enable the `mplsXCNotificationsEnable` (OID 1.3.6.1.2.1.10.166.2.1.15 ) object to `true(1)` to generate `mplsXCUp` and `mplsXCDown` notifications. Use the `isp-xc-traps enable` command to enable or disable the MPLS cross-connect traps and syslog messages. The `show mpls config` command displays the status of the LSP XC notifications.

Trap name and number	Varbinds	Severity	Description and trap message
<code>mplsXCUp</code> 1.3.6.1.2.1.1 0.166.2.0.1	<code>mplsXCOperStatus</code>	Notification	<p>Generates when the <code>mplsXCOperStatus</code> object for one entry in <code>mplsXCTable</code> are about to enter the <code>up(1)</code> state from <code>down(2)</code> state.</p> <p>The included values of the <code>mplsXCOperStatus</code> object must be set equal to the new <code>up(1)</code> state. The two instances of the <code>mplsXCOperStatus</code> object in the notification indicate the range of indexes that are affected.</p> <p>Sample syslog message: MPLS: The LSP XC with id &lt;n1&gt;, in segment id &lt;n2&gt; and out segment id &lt;n3&gt; has come up</p>
<code>mplsXCDown</code> 1.3.6.1.2.1.1 0.166.2.0.2	<code>mplsXCOperStatus</code>	Notification	<p>Generates when the <code>mplsXCOperStatus</code> object for one entry in <code>mplsXCTable</code> are about to enter the <code>down(2)</code> state from <code>up(1)</code> state.</p> <p>The included values of the <code>mplsXCOperStatus</code> object must be set equal to the <code>down(2)</code> state. The two instances of the <code>mplsXCOperStatus</code> object in the notification indicate the range of indexes that are affected.</p> <p>Sample syslog message: MPLS: The LSP XC with id &lt;n1&gt;, in segment id &lt;n2&gt; and out segment id &lt;n3&gt; has went down</p>

## Traps for BFD

The following Bidirectional Forwarding Detection (BFD) traps are supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.



Trap name and number	Varbinds	Severity	Description
bfdSessUp brcdIp.3.3.1.0.1	bfdSessDiag - Low range value bfdSessDiag - High range value	Notification	<p>This notification is generated when the bfdSessState object for one or more contiguous entries in bfdSessTable are about to enter the up(2) state from some other state. The included values of bfdSessDiag must both be set equal to this new state (for example, up(1)). The two instances of bfdSessDiag in this notification indicate the range of indexes that are affected.</p> <p><b>NOTE:</b> All the indexes of the two ends of the range can be derived from the instance identifiers of these two objects. For the cases where a contiguous range of sessions has transitioned into the up(1) state at roughly the same time, the device must issue a single notification for each range of contiguous indexes in an effort to minimize the emission of a large number of notifications. If a notification has to be issued for just a single bfdSessEntry, then the instance identifier (and values) of the two bfdSessDiag objects must be the identical.</p>
bfdSessDown brcdIp.3.3.1.0.2	bfdSessDiag - Low range value bfdSessDiag - High range value	Notification	<p>This notification is generated when the bfdSessState object for one or more contiguous entries in bfdSessTable are about to enter the down(4) or adminDown(5) states from some other state. The included values of bfdSessDiag must both be set equal to this new state (for example, down(4) or adminDown(5)). The two instances of bfdSessDiag in this notification indicate the range of indexes that are affected.</p> <p><b>NOTE:</b> All the indexes of the two ends of the range can be derived from the instance identifiers of these two objects. For cases where a contiguous range of sessions has transitioned into the down(4) or adminDown(5) states at roughly the same time, the device should issue a single notification for each range of contiguous indexes in an effort to minimize the emission of a large number of notifications. If a notification has to be issued for just a single bfdSessEntry, then the instance identifier (and values) of the two bfdSessDiag objects must be the identical.</p>

## Traps for CAM overflow

The following CAM overflow trap is supported only on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapCAMOverflow brcdIp.0.1002	snAgGbiTrapMessage	Alerts	<p>Displays the SNMP trap that is generated when any CAM partition becomes full.</p> <p>Sample trap message: CAM partition full</p>

## Traps for wireless features

### NOTE

The traps in the following sections are available on devices that support the wireless features, such as automatic discovery and configuration (ADC), wireless mobility, and others.

### *Wireless feature traps*

The WLAN controller generates the following general traps for wireless feature support. Refer to the specific wireless feature sections to determine what traps are generated for each feature.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapWirelessStationStateChange brcdIp.0.127	snAgGblTrapMessage	Notification	The state of the wireless station (client) that is associated with this WLAN controller through the access point has changed. Sample trap message: <date-time>:N: New Station <mac-address> discovered   removed
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			
snTrapWirelessSappStateChange brcdIp.0.129	snAgGblTrapMessage	Notification	The state of the communication between an access point and this WLAN controller has changed. Sample trap message: <date-time>:N:AP <AP-IP-address> has changed state from <old-state> to<new-state>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			

### *Wireless mobility traps*

The following traps are generated by the WLAN controller for wireless mobility.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapWirelessIsrcPeerState Change brcdIp.0.126	snAgGblTrapMessage	Notification	The state of WLAN controller peer has changed. Sample trap message: <date-time>:N:Mobility Peer <IronPoint-FES-IP-address> has changed state from <old-state> to <new-state>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, , Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			
snTrapWirelessStationRoamingEventTriggered brcdIp.0.128	snAgGblTrapMessage	Notification	A wireless station (client) roamed from or to the access point that is attached to this WLAN controller. Sample trap message: <date-time>:N:Station <0009.5b66.eac6> has roamed to switch <IronPoint-FES-IP-address>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, , Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			

### *ADC trap*

The following SNMP trap is generated for the ADC feature.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapPnPStatusChange brcdIp.0.125	snAgGblTrapMessage	Notification	The access point's ADC status changed. Sample trap message: <date-time>:N:PnP status of AP MAC address <mac-address> at port <port-number> has changed from <old state> to <new-state>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			

### *Automatic port deactivation traps*

The following traps are generated for the automatic port deactivation feature.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapAutoPortDisableTrigger brcdIp.0.123	snAgGblTrapMessage	Notification	The specified interface has been deactivated and disabled. Sample trap message: Automatic port disable was triggered at port <port-number>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			
snTrapAutoPortDisableRelease brcdIp.0.124	snAgGblTrapMessage	Notification	The disabled interface has been released and re-enabled. Sample trap message: Automatic port disable was released at port <port-number>
<b>NOTE:</b> This object is not supported on Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.			

## SNMP traps for RSVP-signaled LSP state

SNMP traps that identify when an RSVP-signaled LSP goes up and down and also when an LSP switches traffic to a new active path are available on the Brocade MLXe and Brocade NetIron XMR devices.

Trap name and number	Varbinds	Severity	Description
snMplsLspUp brcdIp.0.139	mplsLspName mplsLspPathName	Informational	Notifies that the specified RSVP-signaled LSP using the specified active path is up.
snMplsLspDown brcdIp.0.140	mplsLspName mplsLspPathName	Informational	Notifies that the specified RSVP-signaled LSP is down because the current active path went down.
snMplsLspChange brcdIp.0.141	mplsLspName mplsLspPathName	Informational	Notifies that the specified RSVP-signaled LSP has switched traffic to the specified new active path. The LSP maintains an up state before and after the switchover.

## UDLD traps

The following UDLD traps are not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, Brocade NetIron CER series devices, and on the FastIron devices.

Trap name and number	Varbinds	Severity	Description
snTrapUDLDLinkDown brcdIp.0.145	ifIndex snAgGblTrapMes sage	Notification	The SNMP trap that is generated when UDLD port link status has changed to down.
snTrapUDLDLinkUp brcdIp.0.146	ifIndex snAgGblTrapMes sage	Notification	The SNMP trap that is generated when UDLD port link status has changed to up.
snTrapUDLDCrcFailureDetecte d brcdIp.0.191	ifIndex, snAgGblTrapMes sage	Warning	The SNMP trap that is generated when UDLD detects CRC failures on PDUs received on a port.

## BPDU guard and root guard traps

The following are the traps for BPDU guard and root guard.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapStpRootGuardDetect brcdIp.0.150	ifIndex, snVlanByPortCfg VlanId, snAgGblTrapMes sage	Notification	The SNMP trap that is generated when a Root-Guarded port receives a superior BPDU. Sample trap message: Brocade Trap: Stp root guard detect
snTrapStpRootGuardExpire brcdIp.0.151	ifIndex, snVlanByPortCfg VlanId, snAgGblTrapMes sage	Notification	The SNMP trap that is generated when a port's Root-Guard expires. Sample trap message: Brocade Trap: Stp root guard expire
snTrapStpBPDUGuardDetect brcdIp.0.152	ifIndex, snVlanByPortCfg VlanId, snAgGblTrapMes sage	Notification	The SNMP trap that is generated when a BPDU-guarded is disabled because it received a BPDU. Sample trap message: Brocade Trap: STP BPDU guard
snTrapMstpBPDUGuardDetect brcdIp.0.153	ifIndex, snAgGblTrapMes sage	Notification	The SNMP trap that is generated when a BPDU-guarded port receives a BPDU. Sample trap message: Brocade Trap: MSTP BPDU guard.

**NOTE:** This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices. Use ["snTrapStpRootGuardExpire"](#) on page 668 instead.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapErrorDisableAction brcdIp.0.154 <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	ifIndex, snAgGblTrapMessage	Notification	The SNMP trap that is generated when an interface error-disable is hit or recovery times out. Sample trap message: Brocade Trap: Error-disable hit or recovery times out.
snTrapStpRootGuardExpire brcdIp.0.160 <b>NOTE:</b> This object is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.	ifIndex, snVlanByPortCfg VlanId, snAgGblTrapMessage	Notification	The SNMP trap that is generated when a port is re-enabled after it has been disabled because it received a BPDU packet and BPDU Guard is enabled. Sample trap message: Brocade Trap: STP BPDU Guard Expire.
snTrapPortLoopDetection brcdIp.0.161	ifIndex, snVlanByPortCfg VlanId, snAgGblTrapMessage	Notification	The SNMP notification is generated when a port loop is detected. Sample trap message: Brocade Trap: LOOP DETECTION: VLAN <id>, port <slot>/<port> detect, putting into err-disable state

## Traps for optics

The following table contains traps that are supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOpticalMonitoringWarning brcdIp.0.1003 <b>NOTE:</b> This trap is also supported on the FastIron devices.	snAgGblTrapMessage	Warning	A warning occurred during optical monitoring. Sample trap message: Latched high Temperature alarm, port <slot>/<port>
snTrapOpticalMonitoringAlarm brcdIp.0.1004 <b>NOTE:</b> This trap is also supported on the FastIron devices.	snAgGblTrapMessage	Alerts	An alarm occurred during optical monitoring due to a low temperature in the device. Sample trap message: Latched low Temperature alarm, port <slot>/<port>

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOpticalMonitoringError brcdIp.0.1005	snAgGblTrapMessage	Informational	An error occurred during optical monitoring. Samples trap message: OPTICAL MONITORING: sys_create_timer failed, slot <n>, port mask <portmask> OPTICAL MONITORING: sys_set_timer failed, slot <n>, port mask <portmask> OPTICAL MONITORING: THRESHOLDS READ FAILED, port <slot>/<port> OPTICAL MONITORING: AUX AD TYPE READ FAILED, port <slot>/<port>" OPTICAL MONITORING: INT UNMASK ALL WRITE FAILED, port <slot>/<port> OPTICAL MONITORING: INT MASK WRITE FAILED, port <slot>/<port> OPTICAL MONITORING:: OPTICAL INT MASK WRITE FAILED, port <slot>/<port> OPTICAL MONITORING: port <slot>/<port>: sys_create_timer failed OPTICAL MONITORING: port <slot>/<port>: sys_create_timer2 failed OPTICAL MONITORING: port <slot>/<port>: sys_set_timer failed OPTICAL MONITORING: port <slot>/<port>, failed to get latched flags(<n>) OPTICAL MONITORING: port <slot>/<port>: sys_set_timer1 failed
snTrapXfpSfpIncompatibleOptics brcdIp.0.1009	snAgGblTrapMessage	Alerts	The optics are incompatible with the port configuration.
snTrapTMLoggingStart brcdIp.0.1015	snAgGblTrapMessage	Informational	TM logging started, triggered by an event.
snTrapTMLoggingStop brcdIp.0.1016	snAgGblTrapMessage	Informational	TM logging stopped because the storage is full.
snTrapTMLoggingRestart brcdIp.0.1017	snAgGblTrapMessage	Informational	TM logging restarted after the log was cleared.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapSFMLinkDown brcdIp.0.1100	snAgGblTrapMessage	Warning	A link from the LP Traffic Manager to an SFM Fabric Element is down. Sample trap message: Fabric Monitoring Link Down : SFM <num>/FE <num>/Link <num> , LP <num>/TM <num> "
snTrapSFMLinkUp brcdIp.0.1101	snAgGblTrapMessage	Informational	A link from the LP Traffic Manager to an SFM Fabric Element is up. Sample trap message: Fabric Monitoring Link Up : SFM <num>/FE <num>/Link <num> , LP <num>/TM <num> "
snTrapXfpSfpNotFoundryOptics brcdIp.0.1018 <b>NOTE:</b> This trap is also supported on the FastIron devices.	snAgGblTrapMessage	Alerts	The SNMP trap that is generated if the optics vendor is not from Foundry.
snTrapOpticalMonitoringFoundryOpticsNotCapable brcdIp.0.157	snAgGblTrapMessage	Alerts	The SNMP trap that is generated if optical monitoring is enabled but the optic device is not capable. Sample trap message: Brocade Trap: Optical Monitoring Optics Not Capable

## Traps for stacking

The following table has traps for stacking that are supported only on the FastIron devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapStackingMasterElected brcdIp.0.163	snChasUnitIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a unit is elected as the Master unit for the stacking system. Sample trap message: Stack unit <unitNumber> has been elected as ACTIVE unit of the stack system
snTrapStackingUnitAdded brcdIp.0.164	snChasUnitIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a unit has been added to the stacking system. Sample trap message: Stack: Stack unit <unitNumber> has been added to the stack system
snTrapStackingUnitDeleted brcdIp.0.165	snChasUnitIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a unit has been deleted from the stacking system. <b>Sample trap message:</b> Stack: Stack unit <unitNumber> has been deleted to the stack system



Trap name and number	Varbinds	Severity	Description and trap message
snTrapStackingChasPwrSupplyOK brcdIp.0.166	snChasUnitIndex, snChasPwrSupplyIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a power supply operational status changed from failure to normal for a stacking system. <b>Sample trap message:</b> System: Stack unit <unitNumber> Power supply <snChasPwrSupplyIndex> is up
snTrapStackingChasPwrSupplyFailed brcdIp.0.167	snChasUnitIndex, snChasPwrSupplyIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a power supply operational status changed from normal to failure for a stacking system. <b>Sample trap message:</b> System: Stack unit <unitNumber> Power supply <snChasPwrSupplyIndex> is down
snTrapStackingChasFanNormal brcdIp.0.168	snChasUnitIndex, snChasFanIndex, snChasFanDescription	Minor	The SNMP trap that is generated when a fan operational status changed from failure to normal for a stacking system. <b>Sample trap message:</b> System: Stack unit <unitNumber> Fan <snChasFanIndex> (<snChasFanDescription>), ok
snTrapStackingChasFanFailed brcdIp.0.169	snChasUnitIndex, snChasFanIndex, snChasFanDescription	Minor	The SNMP trap that is generated when a fan fails to operate normally for a stacking system. <b>Sample trap message:</b> System: Stack unit <unitNumber> Fan <snChasFanIndex> (<snChasFanDescription>), failed
snTrapStackingManagementMACChanged brcdIp.0.170	snAgGblTrapMessage	Minor	The SNMP trap that is generated when the management MAC address of a stacking system has been changed. <b>Sample trap message:</b> System: Management MAC address changed to <mac_address>
snTrapStackingTemperatureWarning brcdIp.0.171	snChasUnitIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when the actual temperature reading is above the warning temperature threshold for a stack system. <b>Sample trap message:</b> System: Stack unit <unitNumber> Temperature <actual-temp> C degrees, warning level <warning-temp> C degrees, shutdown level <shutdown-temp> C degrees
snTrapStackingStandbyElected	snChasUnitIndex, snAgGblTrapMessage	Minor	The SNMP trap that is generated when a unit is elected as Standby unit for the stacking system."

## Trap specific to FWS

The following trap is supported only on the FastIron WS devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapNoFreeTcamEntry brcdIp.0.162	snAgGblTrapMessage	Alerts	The SNMP trap that is generated when the system is running out of TCAM spaces allocated for routing entries. Sample trap message: System: No free TCAM entry. System will be unstable

## Software licensing traps

The following traps apply to devices that support software licensing.

Trap name and number	Varbinds	Severity	Description
snTrapLicenseAdded brcdIp.0.187	snAgGblTrapMessage	Notification	The SNMP trap is generated when a new license is added to the system.
snTrapLicenseRemoved brcdIp.0.188	snAgGblTrapMessage	Notification	The SNMP trap is generated when a license is removed from the system.
snTrapLicenseExpires brcdIp.0.189	snAgGblTrapMessage	Notification	The SNMP trap that is generated when a trial license is about to expire. This trap is generated daily for the last 3 days of the license, and every 2 hours on the day when the license expires.
snTrapLicenseExpired brcdIp.0.190	snAgGblTrapMessage	Notification	The SNMP trap that is generated when a trial license has expired.

## Trap receiver table (FastIron X series IPv6 devices)

The following table allows you to configure trap receivers on FastIron X series IPv6 devices.

### NOTE

The following table is not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Access	Description
fdryTrapReceiverTable brcdIp.1.1.10.1.1.1	None	The trap receiver table.
fdryTrapReceiverIndex brcdIp.1.1.10.1.1.1.1 Syntax: Unsigned32	None	The index to the trap receiver table.
fdryTrapReceiverAddrType brcdIp.1.1.10.1.1.1.1.2 Syntax: InetAddressType	Read-create	The IP address type: <ul style="list-style-type: none"> <li>• ipv4(1)</li> <li>• ipv6(2)</li> </ul> Default: ipv4(1)
fdryTrapReceiverAddr brcdIp.1.1.10.1.1.1.1.3 Syntax: InetAddress	Read-create	The IP address of the SNMP manager that will receive the trap.

Trap name and number	Access	Description
fdryTrapReceiverCommunityOrSecurityName brcdIp.1.1.10.1.1.1.1.4 Syntax: OCTET STRING	Read-create	The community string to use to access the trap receiver. This object can have up to 32 octets. In the case of the USM (SNMPv3) security model, this object is used to provide the security name.
fdryTrapReceiverUDPPort brcdIp.1.1.10.1.1.1.1.5 Syntax: Integer32	Read-create	The UPD port number of the trap receiver. Valid value: 0 – 65535 Default: 162
fdryTrapReceiverSecurityModel brcdIp.1.1.10.1.1.1.1.6 Syntax: SecurityModel	Read-create	The version of trap format to be used. Default: v1
fdryTrapReceiverSecurityLevel brcdIp.1.1.10.1.1.1.1.7 Syntax: SecurityLevel	Read-create	Used for the USM (SNMPv3) security model to specify the level of security. The security name is provided by fdryTrapReceiverCommunityOrSecurityName. Default: noAuth
fdryTrapReceiverRowStatus brcdIp.1.1.10.1.1.1.1.8 Syntax: RowStatus	Read-create	This variable is used to create, modify, or delete a row in this table. When a row in this table is in active(1) state, no objects in that row can be modified except this object.

## Examples

The following is an example of how to generate an SNMP trap for a RMON event.

### RMON event traps

Perform the following steps if you want to configure a device to send an SNMP trap when CPU utilization exceeds 50 percent.

1. Configure a RMON alarm with an ID of 1 that checks for snAgGblCpuUtil1MinAvg every 300 seconds. In every sample, check if the CPU utilization fall exceeds 50 percent. If it does, send an event(id 1) with Tom. The event trigger is re-armed, when the falling-threshold value falls below 45 percent.

```
Brocade(config)# rmon alarm 1 snAgGblCpuUtil1MinAvg.0 300 absolute
rising-threshold 50 1 falling-threshold 45 65535 owner Tom
```

2. Configure a RMON event with an ID of 1, which sends a SNMP trap that contains the community string "public", some description, and owner Tom whenever CPU utilization exceeds 50 percent.

```
Brocade(config)# rmon event 1 description "CPU Utilization exceeds 50%" trap
public owner Tom
```

## General traps for the Brocade NetIron devices

The following table presents the general traps for the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapIfIndexAssignmentChanged brcdIp.0.172	snAgGblTrapMessage	Informational	The SNMP trap is generated when the interface index (ifIndex) assignment for a physical interface is changed. Sample trap message: System: IfIndex assignment was changed
snTrapModuleStatusChange brcdIp.0.176	snChasUnitIndex, snAgentBrdIndex, snAgentBrdModuleStatus, snAgGblTrapMessage	Notification	The operational state of a module is changed. The management entity receiving the notification can identify the module and the event by referencing snChasUnitIndex, snAgentBrdIndex, and snAgentBrdModuleStatus. If the module is down, the snAgGblTrapMessage varbind contains a text string that describes the cause. If the module is up, nothing is displayed for snAgGblTrapMessage. Sample trap message: For module up: System: Module up in slot <slot-number> For module down: System: Module down in slot <slot-number>, reason <reason>. Error Code <error-code> For standby MP up: System: Standby Management Module was ready For standby MP down: System: Standby Management Module was down, reason <reason>. Error Code <error-code>
snTrapI2CAccessLog brcdIp.0.184	snAgGblTrapMessage	Notification	This trap is generated to provide information about the state of the I2C access of the management module. Sample trap message: last good i2c access, Mux index 0, Mux tap 0, ID 0x9, Addr 0x1, (SNM2TEMP) bad i2c access (GIEI = set), Severity Minor, Mux index 0, Mux tap2, ID 0x9, Addr 0x1, (SNM3TEMP)
snTrapDot1agCfmRemoteMEPAgeOut brcdIp.0.192	dot1agCfmMdName, dot1agCfmMaNetName, dot1agCfmMepDbRMepState, snAgGblTrapMessage	Warning	This trap is generated when the 802.1ag Remote MEP ages out. Sample trap message: System: Remote MEP 2 in Domain maint_domain, MA maint_asso aged out
snTrapDot1agCfmRemoteMEPUp brcdIp.0.193	dot1agCfmMdName, dot1agCfmMaNetName, dot1agCfmMepDbRMepState, snAgGblTrapMessage	Informational	This trap is generated when the 802.1ag Remote MEP is up. Sample trap message: System: Remote MEP 2 in Domain maint_domain, MA maint_asso become UP state

Trap name and number	Varbinds	Severity	Description and trap message
snTrapDot1agCfmDomainCrossConnection brcdIp.0.194.	dot1agCfmMdName, dot1agCfmMaNetName, snAgGblTrapMessage	Warning	This trap is generated when the 802.1ag domain gets cross-connected. Sample trap message: System: Cross Connection in Domain MLX4maintDomain, MA MLX4maintAsso
snTrapDot1agCfmDuplicateMEPId brcdIp.0.195	dot1agCfmMdName, dot1agCfmMaNetName, dot1agCfmMepDbRMepState, snAgGblTrapMessage	Warning	This trap is generated when the 802.1ag Remote MEP reports a duplicate MEP ID that conflicts with a local MEP ID. Sample trap message: System: Remote MEP ID 1 in Domain MLX4maintDomain, MA MLX4maintAsso is same as ours
snTrapChasFanOK brcdIp.0.1000	snChasFanIndex, snChasFanDescription	Minor	One of the following occurred on the device: <ul style="list-style-type: none"> <li>The status of the fan operation changed from failure to normal.</li> <li>Fan speed changed due to a decrease in the operating temperature.</li> </ul> Sample trap message: Right fan tray (fan1) OK
snTrapTemperatureOK brcdIp.0.1001	snAgGblTrapMessage	Critical	The actual temperature reading on the device is below the warning temperature threshold. Samples trap message: Switch Fabric 2 temperature 30.2 C degrees is normal Switch Fabric 2 temperature 30.2 C degrees is normal Linecard Module %d PCB temperature 30.2 C degrees is normal Linecard Module %d XPP temperature 30.2 C degrees is normal Active mgmt CPU temperature 30.2 C degrees is normal Standby mgmt CPU temperature 30.2 C degrees is normal
snTrapCAMOverflow brcdIp.0.1002	snAgGblTrapMessage	Alerts	One of the IP CAM levels is full. Sample trap message: NO MORE FREE CAM SPACE for IP level <level>.

Trap name and number	Varbinds	Severity	Description and trap message
snMplsLspUp brcdIp.0.1010	mplsLspName, mplsLspPathName	Informational	<p>The specified LSP is up. The current active path for the LSP is the value of mplsLspPathName.</p> <p><b>NOTE:</b> Do not use this trap if you are using the snTrapTMLogging traps.</p> <p>Sample trap message: Name of the notification received: snMplsLspUp Foundry-MPLS-MIB:mplsLspName.2.1 : (mlx8tobottomcer)</p> <p>Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1) Foundry-MPLS-MIB:mplsLspPathName.2.1 : () Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1)</p>
snMplsLspDown brcdIp.0.1011	mplsLspName, mplsLspPathName	Informational	<p>The specified LSP is down, because the current active path specified by the mplsLSPPathName went down.</p> <p><b>NOTE:</b> Do not use this trap if you are using the snTrapTMLogging traps.</p> <p>Sample trap message: Name of the notification received: snMplsLspDown Foundry-MPLS-MIB:mplsLspName.2.1 : (mlx8tobottomcer)</p> <p>Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1) Foundry-MPLS-MIB:mplsLspPathName.2.1 : () Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1)</p>
snMplsLspChange brcdIp.0.1012	mplsLspName, mplsLspPathName	Informational	<p>The specified LSP has switched traffic to the new active path "toLspPath". The LSP maintains an up state before and after the switchover.</p> <p><b>NOTE:</b> Do not use this trap if you are using the snTrapTMLogging traps.</p> <p>Sample trap message: Name of the notification received: snMplsLspChange Foundry-MPLS-MIB:mplsLspName.2.1 : (mlx8tobottomcer)</p> <p>Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1) Foundry-MPLS-MIB:mplsLspPathName.2.1 : (testpath1) Syntax: SNMPv2-TC:DisplayString, Instance IDs: (2 1)</p>

Trap name and number	Varbinds	Severity	Description and trap message
snTrapChassisFanSpeedLow brcdIp.0.1200	snAgGblTrapMessage	Informational	The speed of all chassis fans changed to low. Sample trap message: System: Set fan speed to LOW (50%%)
snTrapChassisFanSpeedMedium brcdIp.0.1201	snAgGblTrapMessage	Informational	The speed of all chassis fans changed to medium. Sample trap message: System: Set fan speed to MED (75%%)
snTrapChassisFanSpeedMediumHigh brcdIp.0.1202	snAgGblTrapMessage	Informational	The speed of all chassis fans changed to medium high. Sample trap message: System: Set fan speed to MED-HI (90%%)
snTrapChassisFanSpeedHigh brcdIp.0.1203	snAgGblTrapMessage	Informational	The speed of all the chassis fans changed to high. Sample trap message: System: Set fan speed to HI (100%%)
snTrapFIPSMODEEnable brcdIp.0.1207	snAgGblTrapMessage	Informational	The SNMP trap is generated when Federal Information Processing Standard (FIPS) mode is enabled.
snTrapFIPSMODEDisable brcdIp.0.1208	snAgGblTrapMessage	Informational	The SNMP trap is generated when FIPS mode is disabled.
snTrapFIPSHostZeroized brcdIp.0.1209	snAgGblTrapMessage	Informational	The SNMP trap is generated when host keys are set to zero(0) in FIPS mode.
snTrapFIPSSharedSecretZeroized brcdIp.0.1210	snAgGblTrapMessage	Informational	The SNMP trap is generated when shared secrets are set to zero(0) in FIPS mode.
snTrapFIPSPOSTStatus brcdIp.0.1211	snAgGblTrapMessage	Informational	The SNMP trap is generated after POST.
snTrapFIPSCryptoModuleFailure brcdIp.0.1212	snAgGblTrapMessage	Critical	The SNMP trap is generated when the cryptographic module fails.
snTrapLicense2PortNotSupported brcdIp.0.1213	snAgGblTrapMessage	Notifications	The SNMP trap is generated when at two-port licenses cannot be applied due to hardware limitation.

Trap name and number	Varbinds	Severity	Description and trap message
snTrapOpticalMonitoringOK brcdIp.0.1214	snAgGblTrapMessage, ifIndex	Informational	<p>The SNMP trap is generated when an interface transitions from an error state to the normal state because the alarms or warnings are below the threshold value. The snTrapOpticalMonitoringError is generated when the interface transitioned to the error state.</p> <p>The first varbind snAgGblTrapMessage, will have a detailed message on the cause of event. The second varbind ifIndex, points to the affected interface that originates the event. If an event does not have associated port or has multiple associated ports, then ifIndex has the maximum value 0x7ffffff.</p>
snTrapSFMAccessOK brcdIp.0.1215	snAgGblTrapMessage	Informational	<p>The SNMP trap is generated when system can successfully access an SFM Fabric Element (FE).</p> <p>The snTrapSFMAccessError is generated when the system failed to access the FE.</p>
snTrapUpgradeSingleCmdStart brcdIp.0.1216	snAgGblTrapMessage	Informational	<p>The SNMP trap is generated when a single-command package upgrade is started. This happens after a successful download and validation of the manifest file and before the first image download takes place.</p>
snTrapUpgradeSingleCmdDone brcdIp.0.1217	snAgGblTrapMessage	Informational	<p>The SNMP trap is generated when a single-command package upgrade is completed or partially completed. Refer to brcdSwPackageLoadResultTable for the results of the upgrade.</p>
snTrapAutoUpgradeStart brcdIp.0.1218	snAgentBrdIndex	Informational	<p>The SNMP trap is generated when an auto-upgrade on a line card is started.</p>
snTrapAutoUpgradeDone brcdIp.0.1219	snAgentBrdIndex, snAgGblTrapMessage	Informational	<p>The SNMP trap is generated when an auto-upgrade of the interface module is completed.</p>



# Unsupported MIB Objects

---

## In this appendix

- [Proprietary MIBs](#) ..... 679
- [Traps](#) ..... 689

## Proprietary MIBs

The following table lists the proprietary MIB objects that are not supported on the Brocade NetIron XMR, Brocade MLX, Brocade MLXe, Brocade NetIron CES, and Brocade NetIron CER series devices.

Object	Object identifier
ifTestTable	1.3.6.1.2.1.31.1.3.1
ifRcvAddressTable	1.3.6.1.2.1.31.1.4.1
ipForwardNumber	1.3.6.1.2.1.4.24.1
ipForwardTable	1.3.6.1.2.1.4.24.2.1
rip2PeerTable	1.3.6.1.2.1.23.4.1
bgpPathAttrTable	1.3.6.1.2.1.15.5.1
ospfAreaRangeTable	1.3.6.1.2.1.14.5.1
snRtIpFwdCacheTable	brcdIp.1.2.2.11.1
snQosProfileTable	brcdIp.1.1.3.14.1.1
snQosBindTable	brcdIp.1.1.3.14.2.1
sonetVTCurrentTable	1.3.6.1.2.1.10.39.3.1.1.1
sonetVTIntervalTable	1.3.6.1.2.1.10.39.3.1.2.1
sonetFarEndVTCurrentTable	1.3.6.1.2.1.10.39.3.2.1.1
sonetFarEndVTIntervalTable	1.3.6.1.2.1.10.39.3.2.2.1
mplsInSegmentLdpLspTable	1.3.6.1.2.1.10.166.4.1.3.6.1
mplsOutSegmentLdpLspTable	1.3.6.1.2.1.10.166.4.1.3.7.1
mplsLdpLspFecTable	1.3.6.1.2.1.10.166.4.1.3.10.1
snMSTrunkIfTable	brcdIp.1.1.3.6.3
pwPerfCurrentTable	brcdIp.3.1.2.1.3
pwPerfIntervalTable	brcdIp.3.1.2.1.4
pwEnetStatsTable	brcdIp.3.1.4.1.2
isisRATableGroup	1.3.6.1.2.1.138.2.2.7

## A Unsupported MIB Objects

Object	Object Identifier
isisReachAddr	1.3.6.1.2.1.138.1.7
dot1agCfmStackTable	1.3.111.2.802.1.1.8.1.1.1
dot1agCfmVlanTable	1.3.111.2.802.1.1.8.1.3.1
dot1agCfmDefaultMdTable	1.3.111.2.802.1.1.8.1.2.4
dot1agCfmConfigErrorListTable	1.3.111.2.802.1.1.8.1.4.1
dot1agCfmMaCompTable	1.3.111.2.802.1.1.8.1.6.2
ieee8021CfmStackTable	1.3.111.2.802.1.1.8.1.1.2
ieee8021CfmDefaultMdTable	1.3.111.2.802.1.1.8.1.2.5
ieee8021CfmConfigErrorListTable	1.3.111.2.802.1.1.8.1.4.2
ipMRouteBoundaryTable	1.3.6.1.2.1.83.1.1.5
ipMRouteScopeNameTable	1.3.6.1.2.1.83.1.1.6
ipMRouteDifferentInIfPackets	1.3.6.1.2.1.83.1.1.2.1.9
ipMRouteOctets	1.3.6.1.2.1.83.1.1.2.1.10
ipMRouteRtType	1.3.6.1.2.1.83.1.1.2.1.15
ipMRouteHCOctets	1.3.6.1.2.1.83.1.1.2.1.16
ipMRouteNextHopPkts	1.3.6.1.2.1.83.1.1.3.1.11
ipMRouteInterfaceInMcastOctets	1.3.6.1.2.1.83.1.1.4.1.5
ipMRouteInterfaceOutMcastOctets	1.3.6.1.2.1.83.1.1.4.1.6
ipMRouteInterfaceHCInMcastOctets	1.3.6.1.2.1.83.1.1.4.1.7
ipMRouteInterfaceHCOctets	1.3.6.1.2.1.83.1.1.4.1.8
igmpInterfaceVersion1QuerierTimer	1.3.6.1.2.1.85.1.1.1.9
igmpInterfaceWrongVersionQueries	1.3.6.1.2.1.85.1.1.1.10
pimIpMRouteAssertRPTBit	1.3.6.1.3.61.1.1.4.1.4
pimIpMRouteFlags	1.3.6.1.3.61.1.1.4.1.5
mplsInterfacePerfTable	1.3.6.1.2.1.10.166.2.1.2
mplsOutSegmentPerfTable	1.3.6.1.2.1.10.166.2.1.8
mplsLabelStackTable	1.3.6.1.2.1.10.166.2.1.13
mplsInSegmentMapTable	1.3.6.1.2.1.10.166.2.1.14
mplsInterfaceLabelMinIn	1.3.6.1.2.1.10.166.2.1.1.1.2
mplsInterfaceLabelMaxIn	1.3.6.1.2.1.10.166.2.1.1.1.3
mplsInterfaceLabelMinOut	1.3.6.1.2.1.10.166.2.1.1.1.4
mplsInterfaceLabelMaxOut	1.3.6.1.2.1.10.166.2.1.1.1.5
mplsInSegmentIndexNext	1.3.6.1.2.1.10.166.2.1.3
mplsInSegmentInterface	1.3.6.1.2.1.10.166.2.1.4.1.2
mplsInSegmentPerfHCOctets	1.3.6.1.2.1.10.166.2.1.5.1.5
mplsInSegmentPerfOctets	1.3.6.1.2.1.10.166.2.1.5.1.1
mplsInSegmentPerfErrors	1.3.6.1.2.1.10.166.2.1.5.1.3

<b>Object</b>	<b>Object Identifier</b>
mplsInSegmentPerfDiscards	1.3.6.1.2.1.10.166.2.1.5.1.4
mplsInSegmentPerfDiscontinuityTime	1.3.6.1.2.1.10.166.2.1.5.1.6
mplsOutSegmentIndexNext	1.3.6.1.2.1.10.166.2.1.6
mplsOutSegmentInterface	1.3.6.1.2.1.10.166.2.1.7.1.2
mplsXCIndexNext	1.3.6.1.2.1.10.166.2.1.9
mplsLabelStackIndexNext	1.3.6.1.2.1.10.166.2.1.12
spdCompoundFilterTable	1.3.6.1.2.1.153.1.5
spdSubfiltersTable	1.3.6.1.2.1.153.1.6
spdIpOffsetFilterTable	1.3.6.1.2.1.153.1.8
spdTimeFilterTable	1.3.6.1.2.1.153.1.9
spdIpsoHeaderFilterTable	1.3.6.1.2.1.153.1.10
spdCompoundActionTable	1.3.6.1.2.1.153.1.11
spdSubactionsTable	1.3.6.1.2.1.153.1.12
diffServDataPath	1.3.6.1.2.1.97.1.1
diffServClfrNextFree	1.3.6.1.2.1.97.1.2.1
diffServClfrTable	1.3.6.1.2.1.97.1.2.2
diffServClfrElementNextFree	1.3.6.1.2.1.97.1.2.3
diffServClfrElementTable	1.3.6.1.2.1.97.1.2.4
diffServMultiFieldClfrNextFree	1.3.6.1.2.1.97.1.2.5
diffServMeter	1.3.6.1.2.1.97.1.3
diffServTBParam	1.3.6.1.2.1.97.1.4
diffServAction	1.3.6.1.2.1.97.1.5
diffServAlgDrop	1.3.6.1.2.1.97.1.6
diffServQueue	1.3.6.1.2.1.97.1.7
diffServScheduler	1.3.6.1.2.1.97.1.8
fdrySntpServerTable	brcdIp.1.1.7.1.1.1
snNTPPollInterval	brcdIp.1.1.3.11.1.1
snNTPSync	brcdIp.1.1.3.11.1.5
snChasType	brcdIp.1.1.1.1.1
snChasMainBrdDescription	brcdIp.1.1.1.1.5
snChasMainPortTotal	brcdIp.1.1.1.1.6
snChasExpBrdDescription	brcdIp.1.1.1.1.7
snChasExpPortTotal	brcdIp.1.1.1.1.8
snChasStatusLeds	brcdIp.1.1.1.1.9
snChasTrafficLeds	brcdIp.1.1.1.1.10
snChasMediaLeds	brcdIp.1.1.1.1.11
snChasMainBrdId	brcdIp.1.1.1.1.13

## A Unsupported MIB Objects

Object	Object Identifier
snChasExpBrdId	brcdIp.1.1.1.1.14
snChasSpeedLeds	brcdIp.1.1.1.1.15
snChasPwrSupply2Table	brcdIp.1.1.1.2.2
snChasFan2Table	brcdIp.1.1.1.3.2
snAgConfigFromNVRAM	brcdIp.1.1.2.1.4
snAgWebMgmtServerTcpPort	brcdIp.1.1.2.1.64
snAgentBrdExpBrdId	brcdIp.1.1.2.2.1.1.6
snAgentBrdExpPortTotal	brcdIp.1.1.2.2.1.1.7
snAgentBrdExpBrdDescription	brcdIp.1.1.2.2.1.1.5
snAgentBrdTxTrafficLeds	brcdIp.1.1.2.2.1.1.15
snAgentBrdRxTrafficLeds	brcdIp.1.1.2.2.1.1.16
snAgentBrdStatusLeds	brcdIp.1.1.2.2.1.1.8
snAgentBrdMediaLeds	brcdIp.1.1.2.2.1.1.10
snAgentBrdSpeedLeds	brcdIp.1.1.2.2.1.1.11
snAgentBrdAlarmLeds	brcdIp.1.1.2.2.1.1.14
snAgentBrdTrafficLeds	brcdIp.1.1.2.2.1.1.9
snAgentBrd2Table	brcdIp.1.1.2.2.2
snAgCfgEos	brcdIp.1.1.2.5
snStackPriSwitchMode	brcdIp.1.1.5.1.1
snStackMaxSecSwitch	brcdIp.1.1.5.1.2
snStackTotalSecSwitch	brcdIp.1.1.5.1.3
snStackSyncAllSecSwitch	brcdIp.1.1.5.1.4
snStackSmSlotIndex	brcdIp.1.1.5.1.5
snStackFmpSetProcess	brcdIp.1.1.5.1.6
snStackSecSwitchTable	brcdIp.1.1.5.2.1
snAgSysLogGblServer	brcdIp.1.1.2.6.1.9
snAgSysLogGblPersistenceEnable	brcdIp.1.1.2.6.1.11
snAgentConfigModule2Table	brcdIp.1.1.2.8.2
snAgSystemDRAMForBGP	brcdIp.1.1.2.12.4.4
snAgentHwICBMCounterTable	brcdIp.1.1.2.12.1
snAgSystemDRAMForOSPF	brcdIp.1.1.2.12.4.5
snAgSystemDebugTotalIn	brcdIp.1.1.2.12.5.1
snAgSystemDebugTotalOut	brcdIp.1.1.2.12.5.2
snAgSystemDebugCpuQueueRead	brcdIp.1.1.2.12.5.3
snAgSystemDebugDRAMBuffer	brcdIp.1.1.2.12.5.4
snAgSystemDebugBMBuffer	brcdIp.1.1.2.12.5.5
snAgSystemDebugBMFreeBuffer	brcdIp.1.1.2.12.5.6

<b>Object</b>	<b>Object Identifier</b>
snAgSystemDebugBMFreeBufferMgmt	brcdIp.1.1.2.12.5.7
snAgSystemDebugIpcGigLock	brcdIp.1.1.2.12.5.8
snAgSystemDebugDRAMGetError	brcdIp.1.1.2.12.5.9
snAgSystemDebugDRAMToBMCopyFail	brcdIp.1.1.2.12.5.10
snAgentTemp2Table	brcdIp.1.1.2.13.3
snCAMStatTable	brcdIp.1.1.2.12.3
snCAMIpStatTable	brcdIp.1.1.2.12.2
snCpuProcessTable	brcdIp.1.1.2.11.2
snChasUnitActualTemperature	brcdIp.1.1.1.4.1.1.4
snChasUnitWarningTemperature	brcdIp.1.1.1.4.1.1.5
snChasUnitShutdownTemperature	brcdIp.1.1.1.4.1.1.6
snSwGroupOperMode	brcdIp.1.1.3.1.1
snSwGroupDefaultCfgMode	brcdIp.1.1.3.1.4
snVLanGroupSetAllVLan	brcdIp.1.1.3.1.7
snSwPortSetAll	brcdIp.1.1.3.1.8
snPortStpSetAll	brcdIp.1.1.3.1.11
snSwProbePortNum	brcdIp.1.1.3.1.12
snSw8021qTagMode	brcdIp.1.1.3.1.13
snSwGlobalStpMode	brcdIp.1.1.3.1.14
snSwViolatorPortNumbe	brcdIp.1.1.3.1.17
snSwEosBufferSize	brcdIp.1.1.3.1.20
snVLanByPortEntrySize	brcdIp.1.1.3.1.21
snSwPortEntrySize	brcdIp.1.1.3.1.22
snFdbStationEntrySize	brcdIp.1.1.3.1.23
snPortStpEntrySize	brcdIp.1.1.3.1.24
snVLanByIpSubnetMaxSubnets	brcdIp.1.1.3.1.29
snVLanByIpxNetMaxNetworks	brcdIp.1.1.3.1.30
snSwMaxMacFilterPerSystem	brcdIp.1.1.3.1.36
snSwMaxMacFilterPerPort	brcdIp.1.1.3.1.37
snVLanByPortTable	brcdIp.1.1.3.2.1
snVLanByProtocolTable	brcdIp.1.1.3.2.2
snVLanByIpSubnetTable	brcdIp.1.1.3.2.3
snVLanByIpxNetTable	brcdIp.1.1.3.2.4
snVLanByATCableTable	brcdIp.1.1.3.2.5
snSwPortInfoTable	brcdIp.1.1.3.3.1
snVirtualMgmtInterface	brcdIp.1.1.3.3.2.12
snSwIfMacLearningDisable	brcdIp.1.1.3.3.5.1.59

## A Unsupported MIB Objects

Object	Object Identifier
snInterfaceLookup2Table	brcdIp.1.1.3.3.7
snIfIndexLookup2Table	brcdIp.1.1.3.3.8
snFdbStationPort	brcdIp.1.1.3.4.1.1.3
snFdbStationType	brcdIp.1.1.3.4.1.1.6
snPortStpTable	brcdIp.1.1.3.5.1
snTrunkTable	brcdIp.1.1.3.6.1
snMSTrunkTable	brcdIp.1.1.3.6.2
snSwSummaryMode	brcdIp.1.1.3.7.1
snMacFilterPortAccessTable	brcdIp.1.1.3.10.2
snMacSecurity	brcdIp.1.1.3.24.1
snPortMonitorTable	brcdIp.1.1.3.25.1
snRtBootpServer	brcdIp.1.2.2.1.4
snRtBootpRelayMax	brcdIp.1.2.2.1.5
snRtIpSetAllPortConfig	brcdIp.1.2.2.1.12
snRtIpStaticRouteTable	brcdIp.1.2.2.2
snRtIpFilterTable	brcdIp.1.2.2.3
snRtStaticArpTable	brcdIp.1.2.2.5
snRtIpPortAddrTable	brcdIp.1.2.2.6
snRtIpPortAccessTable	brcdIp.1.2.2.7
snRtIpPortConfigTable	brcdIp.1.2.2.8
snRtUdpBcastFwdPortTable	brcdIp.1.2.2.9.2.1
snRtUdpHelperTable	brcdIp.1.2.2.9.3.1
snIpAsPathAccessListTable	brcdIp.1.2.2.12
snIpCommunityListTable	brcdIp.1.2.2.13
snIpPrefixListMask	brcdIp.1.2.2.14.1.6
snRtIpPortIfAccessTable	brcdIp.1.2.2.19
snDvmpVersion	brcdIp.1.2.5.1.1
snDvmpGenerationId	brcdIp.1.2.5.1.3
snDvmpVInterfaceTable	brcdIp.1.2.5.1.13
snDvmpNeighborTable	brcdIp.1.2.5.1.14
snDvmpRouteTable	brcdIp.1.2.5.1.15
snDvmpRouteNextHopTable	brcdIp.1.2.5.1.16
snDvmpVifStatTable	brcdIp.1.2.5.1.17
snFsrp	brcdIp.1.2.7
snPOSInfoTable	brcdIp.1.2.14.1.1
snAgAcIbBindToPortTable	brcdIp.1.2.2.15.3
fdrySntp	brcdIp.1.1.7

<b>Object</b>	<b>Object Identifier</b>
fdryRadius	brcdIp.1.1.8
fdryTacacs	brcdIp.1.1.9
fdryTrap	brcdIp.1.1.10
snlpx	brcdIp.1.2.1
snlgmp	brcdIp.1.2.6
snAppleTalk	brcdIp.1.2.10
snL4	brcdIp.1.1.4
fdryAcl	brcdIp.1.2.16
snStack	brcdIp.1.1.5
snMacAuth	brcdIp.1.1.3.28
snArpInfo	brcdIp.1.1.3.22
fdryDns2MIB	brcdIp.1.1.3.34
fdryMacVlanMIB	brcdIp.1.1.3.32
fdryDaiMIB	brcdIp.1.1.3.35
fdryDhcpSnoopMIB	brcdIp.1.1.3.36
fdryIpSrcGuardMIB	brcdIp.1.1.3.37
fdryIpv6MIB	brcdIp.1.2.17.1
snWireless	brcdIp.1.1.3.23
snStacking	brcdIp.1.1.3.31
snAgentPoe	brcdIp.1.1.2.14
brcdDot1xAuth	brcdIp.1.1.3.38
snVsrpVirRtrSave	brcdIp.1.1.3.21.3.1.1.18
snVsrpVirRtrRxArpPktDropCnts	brcdIp.1.1.3.21.3.1.1.21
snVsrpVirRtrRxIpPktDropCnts	brcdIp.1.1.3.21.3.1.1.22
snVsrpVirRtrRxHelloIntMismatchCnts	brcdIp.1.1.3.21.3.1.1.23
snVsrpVirRtrRxHigherPriorityCnts	brcdIp.1.1.3.21.3.1.1.28
snRtIpRipRedisEnable	brcdIp.1.2.3.1.3
snRtIpRipSetAllPortConfig	brcdIp.1.2.3.1.5
snRtIpRipGblFiltList	brcdIp.1.2.3.1.6
snRtIpRipFiltOnAllPort	brcdIp.1.2.3.1.7
snRtIpRipEcmpEnable	brcdIp.1.2.3.1.9
snRtIpRipRedisAction	brcdIp.1.2.3.3.1.2
snRtIpRipRedisIp	brcdIp.1.2.3.3.1.4
snRtIpRipRedisMask	brcdIp.1.2.3.3.1.5
snRtIpRipRedisMatchMetric	brcdIp.1.2.3.3.1.6
snRtIpRipStats	brcdIp.1.2.3.9
snAgSystemDebug	brcdIp.1.1.2.12.5

## A Unsupported MIB Objects

Object	Object Identifier
snRtlpRipPortConfigTable	brcdIp.1.2.3.2
snRtlpRipRouteFilterTable	brcdIp.1.2.3.4
snRtlpRipPortAccessTable	brcdIp.1.2.3.6
snRtlpRipPortIfConfigTable	brcdIp.1.2.3.7
snRtlpRipPortIfAccessTable	brcdIp.1.2.3.8
snOspfAreaTable	brcdIp.1.2.4.2
snOspfAddrRange	brcdIp.1.2.4.3
snOspfIntf	brcdIp.1.2.4.4
snOspfVirtIfTable	brcdIp.1.2.4.5
snOspfRedisTable	brcdIp.1.2.4.6
snOspfNbrTable	brcdIp.1.2.4.7
snOspfVirtNbrTable	brcdIp.1.2.4.8
snOspfLsdbTable	brcdIp.1.2.4.9
snOspfExtLsdbTable	brcdIp.1.2.4.10
snOspfAreaStatusTable	brcdIp.1.2.4.11
snOspfIfStatusTable	brcdIp.1.2.4.12
snOspfVirtIfStatusTable	brcdIp.1.2.4.13
snOspfRoutingInfoTable	brcdIp.1.2.4.14
snOspfSetTrap	brcdIp.1.2.4.15
snOspfRouterId	brcdIp.1.2.4.1.1
snOspfASBdrRtrStatus	brcdIp.1.2.4.1.3
snOspfRedisMode	brcdIp.1.2.4.1.4
snOspfDefaultOspfMetricValue	brcdIp.1.2.4.1.5
snOspfExternLSACount	brcdIp.1.2.4.1.6
snOspfExternLSACKsumSum	brcdIp.1.2.4.1.7
snOspfOriginateNewLSAs	brcdIp.1.2.4.1.8
snOspfRxNewLSAs	brcdIp.1.2.4.1.9
snOspfOspfRedisMetricType	brcdIp.1.2.4.1.10
snOspfExtLsdbLimit	brcdIp.1.2.4.1.11
snOspfExitOverflowInterval	brcdIp.1.2.4.1.12
snOspfRfc1583Compatibility	brcdIp.1.2.4.1.13
snOspfRouterIdFormat	brcdIp.1.2.4.1.14
snOspfDistance	brcdIp.1.2.4.1.15
snOspfDistanceIntra	brcdIp.1.2.4.1.16
snOspfDistanceInter	brcdIp.1.2.4.1.17
snOspfDistanceExternal	brcdIp.1.2.4.1.18
snBgp4GenAlwaysCompareMed	brcdIp.1.2.11.1.1



<b>Object</b>	<b>Object Identifier</b>
snBgp4GenAutoSummary	brcdIp.1.2.11.1.2
snBgp4GenDefaultLocalPreference	brcdIp.1.2.11.1.3
snBgp4GenDefaultInfoOriginate	brcdIp.1.2.11.1.4
snBgp4GenFastExternalFallover	brcdIp.1.2.11.1.5
snBgp4GenNextBootNeighbors	brcdIp.1.2.11.1.6
snBgp4GenNextBootRoutes	brcdIp.1.2.11.1.7
snBgp4GenSynchronization	brcdIp.1.2.11.1.8
snBgp4GenKeepAliveTime	brcdIp.1.2.11.1.9
snBgp4GenHoldTime	brcdIp.1.2.11.1.10
snBgp4GenRouterId	brcdIp.1.2.11.1.11
snBgp4GenTableMap	brcdIp.1.2.11.1.12
snBgp4GenDefaultMetric	brcdIp.1.2.11.1.14
snBgp4GenMaxNeighbors	brcdIp.1.2.11.1.15
snBgp4GenMinNeighbors	brcdIp.1.2.11.1.16
snBgp4GenMaxRoutes	brcdIp.1.2.11.1.17
snBgp4GenMinRoutes	brcdIp.1.2.11.1.18
snBgp4GenMaxAddrFilters	brcdIp.1.2.11.1.19
snBgp4GenMaxAggregateAddresses	brcdIp.1.2.11.1.20
snBgp4GenMaxAsPathFilters	brcdIp.1.2.11.1.21
snBgp4GenMaxCommunityFilters	brcdIp.1.2.11.1.22
snBgp4GenMaxNetworks	brcdIp.1.2.11.1.23
snBgp4GenMaxRouteMapFilters	brcdIp.1.2.11.1.24
snBgp4GenNeighPrefixMinValue	brcdIp.1.2.11.1.25
snBgp4GenOperNeighbors	brcdIp.1.2.11.1.26
snBgp4GenOperRoutes	brcdIp.1.2.11.1.27
snBgp4GenRoutesInstalled	brcdIp.1.2.11.1.29
snBgp4GenAsPathInstalled	brcdIp.1.2.11.1.30
snBgp4ExternalDistance	brcdIp.1.2.11.1.31
snBgp4InternalDistance	brcdIp.1.2.11.1.32
snBgp4LocalDistance	brcdIp.1.2.11.1.33
snBgp4OperNumOfAttributes	brcdIp.1.2.11.1.34
snBgp4NextBootMaxAttributes	brcdIp.1.2.11.1.35
snBgp4ClusterId	brcdIp.1.2.11.1.36
snBgp4ClientToClientReflection	brcdIp.1.2.11.1.37
snBgp4GenTotalNeighbors	brcdIp.1.2.11.1.38
snBgp4GenMaxPaths	brcdIp.1.2.11.1.39
snBgp4GenConfedId	brcdIp.1.2.11.1.40

## A Unsupported MIB Objects

Object	Object Identifier
snBgp4GenConfedPeers	brcdIp.1.2.11.1.41
snBgp4GenDampening	brcdIp.1.2.11.1.42
snBgp4GenDampenHalfLife	brcdIp.1.2.11.1.43
snBgp4GenDampenReuse	brcdIp.1.2.11.1.44
snBgp4GenDampenSuppress	brcdIp.1.2.11.1.45
snBgp4GenDampenMaxSuppress	brcdIp.1.2.11.1.46
snBgp4GenDampenMap	brcdIp.1.2.11.1.47
snBgp4AddrFilterTable	brcdIp.1.2.11.2.1
snBgp4AggregateAddrTable	brcdIp.1.2.11.3.1
snBgp4AsPathFilterTable	brcdIp.1.2.11.4.1
snBgp4CommunityFilterTable	brcdIp.1.2.11.5.1
snBgp4NeighGenCfgTable	brcdIp.1.2.11.6.1
snBgp4NeighDistGroupTable	brcdIp.1.2.11.7.1
snBgp4NeighFilterGroupTable	brcdIp.1.2.11.8.1
snBgp4NeighRouteMapTable	brcdIp.1.2.11.9.1
snBgp4NetworkTable	brcdIp.1.2.11.10.1
snBgp4RedisTable	brcdIp.1.2.11.11.1
snBgp4RouteMapFilterTable	brcdIp.1.2.11.12.1
snBgp4RouteMapMatchTable	brcdIp.1.2.11.13.1
snBgp4RouteMapSetTable	brcdIp.1.2.11.14.1
snBgp4NeighOperStatusTable	brcdIp.1.2.11.15.1
snBgp4RouteOperStatusTable	brcdIp.1.2.11.16.1
snBgp4AttributeTable	brcdIp.1.2.11.18.1
snBgp4ClearNeighborCmdTable	brcdIp.1.2.11.19.1
snBgp4NeighPrefixGroup	brcdIp.1.2.11.20
snPimHelloTime	brcdIp.1.2.9.1.3
snPimVInterfaceTable	brcdIp.1.2.9.1.7
snPimNeighborTable	brcdIp.1.2.9.1.8
snPimVifStatTable	brcdIp.1.2.9.1.9
snPimSMMIBObjects	brcdIp.1.2.9.2
snVrrpIntf	brcdIp.1.2.12.2
snVrrpVirRtr	brcdIp.1.2.12.3
snVrrpIntf2	brcdIp.1.2.12.4
snVrrpVirRtr2	brcdIp.1.2.12.5
snVrrpIfStateChangeTrap	brcdIp.1.2.12.1.2
snVrrpIfMaxNumVridPerIntf	brcdIp.1.2.12.1.3
snVrrpIfMaxNumVridPerSystem	brcdIp.1.2.12.1.4

Object	Object identifier
snVrrpClearVrrpStat	brcdIp.1.2.12.1.5
snVrrpGroupOperModeVrrpextended	brcdIp.1.2.12.1.6
snAgent	brcdIp.4
snSci	brcdIp.1.1.6
brcdTMMcastStreamQStatsTable	brcdIp.1.14.2.1.2.6
snAgentBrdMemoryUtil100thPercent	brcdIp.1.1.2.2.1.1.28

## Traps

The following table lists the traps that are added in the Unified IP MIB file but not supported on the Brocade MLX, Brocade MLXe, Brocade NetIron XMR, Brocade NetIron CES, and Brocade NetIron CER series devices.

Trap name	Trap number
snTrapChasPwrSupply	brcdIp.0.1
snTrapLockedAddressViolation	brcdIp.0.2
snTrapOspfIfStateChange	brcdIp.0.3
snTrapOspfVirtIfStateChange	brcdIp.0.4
snOspfNbrStateChange	brcdIp.0.5
snOspfVirtNbrStateChange	brcdIp.0.6
snOspfIfConfigError	brcdIp.0.7
snOspfVirtIfConfigError	brcdIp.0.8
snOspfIfAuthFailure	brcdIp.0.9
snOspfVirtIfAuthFailure	brcdIp.0.10
snOspfIfRxBadPacket	brcdIp.0.11
snOspfVirtIfRxBadPacket	brcdIp.0.12
snOspfTxRetransmit	brcdIp.0.13
ospfVirtIfTxRetransmit	brcdIp.0.14
snOspfOriginateLsa	brcdIp.0.15
snOspfMaxAgeLsa	brcdIp.0.16
snOspfLsdbOverflow	brcdIp.0.17
snOspfLsdbApproachingOverflow	brcdIp.0.18
snTrapL4MaxSessionLimitReached	brcdIp.0.19
snTrapL4TcpSynLimitReached	brcdIp.0.20
snTrapL4RealServerUp	brcdIp.0.21
snTrapL4RealServerDown	brcdIp.0.22
snTrapL4RealServerPortUp	brcdIp.0.23

## A Unsupported MIB Objects

Trap name	Trap number
snTrapL4RealServerPortDown	brcdIp.0.24
snTrapL4RealServerMaxConnectionLimitReached	brcdIp.0.25
snTrapL4BecomeStandby	brcdIp.0.26
snTrapL4BecomeActive	brcdIp.0.27
snTrapLockedAddressViolation2	brcdIp.0.32
snTrapFsrpIfStateChange	brcdIp.0.33
snTrapL4GslbRemoteUp	brcdIp.0.39
snTrapL4GslbRemoteDown	brcdIp.0.40
snTrapL4GslbRemoteControllerUp	brcdIp.0.41
snTrapL4GslbRemoteControllerDown	brcdIp.0.42
snTrapL4GslbHealthCheckIpUp	brcdIp.0.43
snTrapL4GslbHealthCheckIpDown	brcdIp.0.44
snTrapL4GslbHealthCheckIpPortUp	brcdIp.0.45
snTrapL4GslbHealthCheckIpPortDown	brcdIp.0.46
snTrapL4FirewallBecomeStandby	brcdIp.0.47
snTrapL4FirewallBecomeActive	brcdIp.0.48
snTrapL4FirewallPathUp	brcdIp.0.49
snTrapL4FirewallPathDown	brcdIp.0.50
snTrapL4ContentVerification	brcdIp.0.55
snTrapBgpPeerUp	brcdIp.0.65
snTrapBgpPeerDown	brcdIp.0.66
snTrapL4RealServerResponseTimeLowerLimit	brcdIp.0.67
snTrapL4RealServerResponseTimeUpperLimit	brcdIp.0.68
snTrapL4TcpAttackRateExceedMax	brcdIp.0.69
snTrapL4TcpAttackRateExceedThreshold	brcdIp.0.70
snTrapL4ConnectionRateExceedMax	brcdIp.0.71
snTrapL4ConnectionRateExceedThreshold	brcdIp.0.72
snTrapMacAuthEnable	brcdIp.0.85
snTrapMacAuthDisable	brcdIp.0.86
snTrapMacAuthMACAccepted	brcdIp.0.87
snTrapMacAuthMACRejected	brcdIp.0.88
snTrapMacAuthPortDisabled	brcdIp.0.89
snTrapL4RealServerPortMaxConnectionLimitReached	brcdIp.0.119
snTrapL4LinkDown	brcdIp.0.120
snTrapL4LinkUp	brcdIp.0.121
snTrapPortPriorityChange	brcdIp.0.122
snTrapAutoPortDisableTrigger	brcdIp.0.123

Trap name	Trap number
snTrapAutoPortDisableRelease	brcdIp.0.124
snTrapPnPStatusChange	brcdIp.0.125
snTrapWirelessIcmpPeerStateChange	brcdIp.0.126
snTrapWirelessStationStateChange	brcdIp.0.127
snTrapWirelessStationRoamingEventTriggered	brcdIp.0.128
snTrapWirelessSappStateChange	brcdIp.0.129
snTrapExternalPowerConnectionStatus	brcdIp.0.130
snTrapWebAuthEnabled	brcdIp.0.139
snTrapWebAuthDisabled	brcdIp.0.140
snTrapIpConfigChange	brcdIp.0.141
snTrapIcmpv6ConfigChange	brcdIp.0.142
snTrapMacAuthRadiusTimeout	brcdIp.0.143
snTrapDot1xRadiusTimeout	brcdIp.0.144
snTrapMacBasedVlanEnabled	brcdIp.0.147
snTrapMacBasedVlanDisabled	brcdIp.0.148
snTrapChasFanNormal	brcdIp.0.149
snTrapMstpBPDUGuardDetect	brcdIp.0.153
snTrapErrorDisableAction	brcdIp.0.154
snTrapStaticMulticastMacConfigAdd	brcdIp.0.158
snTrapStaticMulticastMacConfigRemove	brcdIp.0.159
snTrapPortLoopDetection	brcdIp.0.161
snTrapNoFreeTcamEntry	brcdIp.0.162
snTrapStackingMasterElected	brcdIp.0.163
snTrapStackingUnitAdded	brcdIp.0.164
snTrapStackingUnitDeleted	brcdIp.0.165
snTrapStackingChasPwrSupplyOK	brcdIp.0.166
snTrapStackingChasPwrSupplyFailed	brcdIp.0.167
snTrapStackingChasFanNormal	brcdIp.0.168
snTrapStackingChasFanFailed	brcdIp.0.169
snTrapStackingManagementMACChanged	brcdIp.0.170
snTrapStackingTemperatureWarning	brcdIp.0.171
snTrapChasPwrSupplyRPSAdd	brcdIp.0.174
snTrapChasPwrSupplyRPSRemove	brcdIp.0.175

# A Unsupported MIB Objects