

# PR7062 " Digital Mobile Internet Device

## User' s Manual

Version-01-201301123

<b>1. Appearance</b> .....	2
2 Power Switch .....	2
3 Touch Screen .....	2
4 SD Using SD Card .....	3
5 Getting Started .....	3
6. Desktop .....	4
<b>7. Lock Screen</b> .....	4
8 Reinstalled applications .....	5
9 .Desktop menu function .....	8
10.Managing Applications .....	8
11 Clock .....	9
12 Installing Software Online .....	10
13 Browser .....	11
14 Calendar .....	11
15 Camera .....	12
16 .Calculator .....	13
17. Sound Recorder .....	13
18 Email and Gmail .....	14
20.Music .....	17
21 Video player .....	18
22 Settings .....	19
FAQ .....	21
Battery management .....	22
Important safety instruction .....	22
<b>FCC Statement</b> .....	23

## 1. Appearance



## 2 Power Switch

Switch on: press and hold the power switch for 3 seconds and wait for startup.

Switch off: press and hold the power switch for 3 seconds → click Power off → click OK.

Lock/unlock screen: briefly press the power switch to lock/unlock the screen.

Forced shut down: if the device has no response, press and hold the power switch for 7 seconds to switch off the device by force.

**Warning: forced shut down may cause unexpected errors of the system!**

Reset: press this key to reset the device. Reset will restart the device. **The result is same as startup after forced shutdown. Please be careful with it.**

## 3 Touch Screen

The touch screen is easy and convenient to use.

You can use the touch screen in the following methods:

Single click: briefly touch the screen with the finger and then move away.

Click and hold: click the screen with the finger and hold for about 2 seconds.

Drag: click a certain icon in the screen and hold, then move the finger, the icon will move accordingly.

☆ To avoid damage the screen, never put anything on the it.

## 4 SD Using SD Card

☆ The device supports up to 32GB storage card.

Insert the card into the card slot, and push it in with your finger until a “click” is heard. Now the card is ready for use.

### Removing SD card

Close all programs or files on the card first. Click Settings → Storage → Remove SD card → OK.

Then press the card with your finger, and simply remove it when it is ejected.

☆ Do not insert and remove the card repeatedly in a short time, this may cause damage to the card.

☆ We suggest you use the card of famous brand to ensure compatibility.

## 5 Getting Started

### Charging the device

☆ Charge the device with USB cable is not recommended.

☆ You may operate the device while charging it, but this may prolong the charging time.

Connect one end of the AC adaptor to the mains supply and the other end to the power jack on the device to charge it (it may take about 5 hours to fully charge the device).


### Starting the device


Press and hold the power switch for 3 seconds and wait for system startup.

### Wi-Fi setting

We suggest you configure your Wi-Fi network before using, as many functions require for it to work normally.

1. Click **Settings** → **Wireless and Network**
2. Switch the **Wi-Fi** on.

The device will search and list all available **Wi-Fi** network. If an icon  is displayed, you need to enter a password to connect to such Wi-Fi network.

3. Click the desired **Wi-Fi** network → Enter the password (if any) → Click **Connect**.
4. Click  or press “**BACK**” key to return to desktop.

☆ The *Wi-Fi* set as hidden will not be searched automatically. In this case you need to click **Add Wi-Fi Network** and enter necessary information to add your *Wi-Fi*.

## 6. Desktop



- ① Search
- ② Battery status
- ③ Current time -
- ④ Volume -
- ⑤ Return
- ⑥ Return to desktop directly
- ⑦ Task
- ⑧ Volume +


☆ Click any icon to run it.

☆ Press and hold to drag the procedure or shortcut icon to other places on the screen.



☆ Press and hold to drag the procedure or shortcut icon to  for deleting it from desktop.









## 7. Lock Screen











You can set auto lock screen or lock screen manually by pressing the power switch. The lock screen interface is as follow. Slide at the right to unlock the screen.




## 8 Reinstalled applications



	<b>Play Store</b>	Download applications conveniently.
	<b>Email</b>	Send and receive e-mail with existing e-mail address.
	<b>HD Player</b>	Play and manage videos.
	<b>Calculator</b>	Make four arithmetic operation.
	<b>Browser</b>	Connect to Internet.
	<b>Sound recorder</b>	Record and play recorded sound.
	<b>Calendar</b>	A calendar where you can set agendas.
	<b>Settings</b>	Make personalized settings.


	Clock	Make personalized settings.
	Search	Google search tools
	Resource manager	View and manage files and applications. Install Android applications and backup files in SD card.
	Downloaded files	Records of downloaded files.
	Camera	Take photos.
	Music	Play and manage music files.
	Gmail	Send and receive e-mail with existing e-mail address.
	Voice search	Internet searching through voice identification
	Gallery	View the photos
	Navigation	Google search tools

☆ Click and drag the icon to move it to another place on the screen.

☆ Long press the icon on desktop to “X” at top of the screen to delete it from desktop. In the application list, click and drag the icon to  to uninstall the application from the device.

## 9 .Desktop menu function

On the desktop, click and hold at the center of the screen for 2 seconds to display wallpaper menu.




## 10.Managing Applications

### Installing

☆ You can find many interesting and free Android applications through the internet. Simply open the browser and search for “Android Applications” .

The purchased or downloaded Android applications  can be quickly and simply installed through the File Manager


Click  the Resource Manager icon to find file folder with .apk file stored.

3. Now the application is installed and the icon of such application will display in the interface that displays all applications.

4. Click **Open** to run the application, or click **Complete** to return to **File Browser** interface.

### Downloading applications from internet

You can directly download Android applications from the internet and install it into the device conveniently.

1. Click  Browser icon to connect to internet.
2. Enter the URL and click the link of the application you want to install.
3. After the application is downloaded, press and hold the downloaded file (in Downloaded Files interface) → Click to open → Install.

### Uninstalling the application

You can conveniently uninstall the Android applications.

Click  → **Settings** → **Applications** → **Manage Applications**.

1. Click the application you want to uninstall → Uninstall.
2. Click OK to uninstall the application.



## 11 Clock

Click Clock icon  to view the current date and time.

Click Count down icon  to enter count down function.

Click Stopwatch icon  to enter stopwatch function.


Click Alarm clock icon  to set the alarm clock.

Click World time icon  to add world time.

Click Setting icon  to set the clock.

### Alarm clock

The device supports more than one clock at the same time.

☆ When the icon  bears in the status bar on the top of the screen, it means at least one alarm clock is activated.


### Add alarm clock


1. Click Clock icon 
2. Click Alarm clock icon  → “+” at the top right corner
3. Set your desired alarm clock.
4. Click Enable alarm clock and exit.

### Stop the alarm clock

When the set time is reached, a window will pop up showing the name of the alarm clock. If you want to use the snap function, simply click and hold the alarm clock and drag it to the




You can click and hold the alarm clock icon and drag it to the icon  to stop the alarm.

Click  to return to desktop.

## 12 Installing Software Online

There are many applications available in the Installing Software Online interface. You can easily and quickly download them into your device.

### Download the application

1. Click the Installing Software Online icon 

☆ If this is the first time you use this function, the system will ask to register and login. If you don't have a registered account, you need to click Register to establish a Google account. If you already have a Google account, simply click Login and enter your account information, click Login again to login.

2. You can select application from the recommendation list, or otherwise the list of classification or ranking. You can also search for the application you want by entering a specific name.
3. Click one application → Download → Confirm to download
4. At completion, click "Open" to directly run the application, or click "Remove" to delete the installed application..

### Record

When downloading completes, click Record to manage the installed application. You can submit your comments to the application or view other users' comments.

### Menu function

Click to display the menu function of the Installing Software Online.

### Personal folder

Click to view personal information. You can change your password, change email address and save your password here. Click the Login out at the top right corner of the personal folder to logout your account.

### About

Display the version and support information of Installing Software Online.




## 13 Browser

The user can connect to the internet through the browser.

Click the Browser icon  on the desktop to open the browser.




## 14 Calendar

Click the Calendar icon .

If this is the first time you use this function, you need to open an Exchange account first. Enter your email address and password, click Next, and complete the configuration of the account following the instructions. Now you can use the Calendar.

## New activity



1. In calendar interface, click the date you want to add an activity.
  2. Select time of the activity → enter the details of the activity in the field.
  3. Click Complete.
  4. Click icon  select your desired calendar interface.
- ☆ The date with agenda is displayed in grey.



## 15 Camera


Click  Camera icon.

### Menu function

1. Click  to switch between front and rear camera
2. Click  to switch camera mode.




### Take a photo


In camera interface, click  to take a photo.

1. The photo will be saved automatically.
2. Slide to left to browse the photos.
3. Click Return to return to camera.
4. Click  to exit camera and return to the desktop.




### Record a video

1. Click  to switch to video, and you can record videos.
2. Click  to start recording, click  to stop.

3. Click Return to return to camera.
4. Click  to exit camera and return to the desktop.







## 16 .Calculator

1. Click  the Calculator icon
2. Click the numbers and operators to make operations.
3. Click Clear to clear the entry one by one, or click and hold Clear to clear all entries.



## 17. Sound Recorder

1. Click the Sound Recorder icon 
2. Click the  icon to start recording. When recording completes, click the  icon to stop recording.
3. Click  to check recorded voice. Click the recorded voice, and click Play in the menu popped up to listen to the recorded voice.





## 18 Email and Gmail


- ☆Support POP3 and SMTP accounts.
- ☆ Gmail supports Google account.

### New email account

You enter one or more email accounts that you want to use on the device.

1. Click the Email icon 
  2. In the Your account interface.
  3. Click Email address option → Enter your email address.
  4. In the Password option → Enter the password of your email.
  5. Click **Next**.
  6. Manual setting (optional): Set the server to automatically fill in supplier based on your e-mail account (e.g. In  , gmail.com will be automatically selected during log-in.) However, if you need to change the server setting, you can click Manual setting and make necessary changes.
  7. Click **Next**.
  8. Optional: enter account name.
  9. Enter the signature → Click **Complete**.
- ☆ When setting completes, if you cannot connect to a free email account, please confirm with your email provider whether there sever supports (POP) and (SMTP) protocols or not.

### Inbox

1. Click the Email icon 
2. If only one email account is set, such account will be opened directly. If more than one is set, all email accounts will be listed.
3. Click the email account that you want to open → Click Inbox.


### Open an email

1. In Inbox interface, click an email to open it.
2. If there is attachment, click Open to activate the corresponding application to open it, or click Save to save it to SD card.
3. If you want to reply, click Reply or Reply all.
  - a. Enter the message you want to reply.
  - b. Click Send to send the email. If you save it as draft, the message will be saved but not sent; if you don't save it or sent it, it will be discarded.




4. Click Cancel to cancel an email immediately.

### Compose an email

In Inbox interface, click  → Compose your email.




1. If you want the e-mail CC or BCC to receiver, click “+CC/BCC” following address of the receiver, and then enter e-mail address of the receiver..
2. In the title bar of the email, enter the subject of your email.
3. Click **Write E-mail** option to enter your personal information.  
If needed, click  to add attachment.
4. When composition completes, click →**Send.**

### Edit email account

1. Click the Email icon 
2. In inbox interface, click  →**Setting**
3. Make your email account setting according to your needs.
4. Click  to return to Inbox interface



### Delete an email account

☆ *If you have more than one account, and you have deleted the default account, then the next account in the list will become default.*

1. Click the Email icon 
2. In inbox interface, click  →**Setting**
3. Click the account to be deleted, drag it to  the bottom, click account deletion option to delete it.


### Set default email account








You should always have one default email account. If you have more than one account, you can select any one as default.

1. Click the Email icon 
2. In Inbox interface, click  →**Setting.**
3. Click to select default account, mark to select it as the default account of e-mail.

If the default account is deleted, the next account in the list will become default.

## 19. Resource manager


Click  File Browser icon to view the files in all storage mediums (*internal storage of the device, SD card, USB disk*), and you can quickly and easily install Android applications into the device. Functions of the icons in the screen are as follow:

-  Previous folder
-  Click to view files in local disk
-  Click to view files in TF card.
-  Click to view files in USB.
-  Click to view all pictures.
-  Click to view all videos.
-  Click to edit the file.

### Copy files between PC and device

You can use the File Browser to copy files between PC and the external/internal storage mediums. To copy files into the device, you can firstly copy them to SD card or USB disk.

- ☆ The folder name of the internal storage medium is “Local”, the name of the storage card is “sdcard”, and the name of the USB disk is “udisk”.
- ☆ The following example is that you copy file into the device from SD card or USB disk. You can use the same way to copy the file from the device to the SD card or USB disk. Then connect your storage medium to your PC and copy the files into the desired folder.

1. Open file folder in which the file to be copied is stored.
2. Select the file or file folder to be copied → Click **Duplication**.
3. Click icon  to return to internal storage medium → click the folder you want to copy to → click **Paste**.

### Delete a file

Select the file or file folder to be deleted, select → Click Deletion → Click **OK** for deletion.







## 20. Music

☆ Support MP1, MP2, MP3, WMA, OGG, APE, FLAC, WAV, AC3, AAC, AMR, DTS, RA, M4A formats.

### Play music

1. Click My music icon 
2. Select the track you want to play from All/Album/Artist/Album/Track/Play list/Now playing.
3. Click the track to play
4. To return to previous interface while playing a track, click  to return to desktop.

Click the track in the list to enter Music Player. The interface is as follow:



In this interface, you can use the operations such as Search, Play/Pause, Next track/Previous track, Repeat all and Random play.

### Operate the track and play list

#### New play list

1. Click setting, and click Add to play list
2. Enter the name of the play list.
3. Click **OK**.

### Rename or delete the play list

Click and hold the play lists → click **Rename** or **Delete**.

#### New track

1. Click and hold the track you want to add to play list, → click “Add to play list”.

#### Delete track

Click and hold the track you want to delete → click Delete.





## 21 Video player

☆ Support RM, RMVB, MKV (H.264 编码), MPEG (AVI), MOV, FLV, MPG, VOB, MPE, DAT formats. Support 2160P, 3840×2160.

☆ Supported picture format: JPG, JPEG, BMP and PNG.




1. Click video player icon 
2. Select the desired video for playback.
3. Click on the screen to adjust the video (including volume, pause/play, brightness, etc.).
4. Click  to return to list.



## 22 Settings

<b>Wireless and network</b>	<b>Wi-Fi</b>	Enable Wi-Fi
	<b>More</b>	Set flight mode, mobile network and VPN.
<b>Sound</b>	<b>Volume</b>	Adjust media volume, alarm clock volume and notification volume. Click and move the slider to adjust volume, and then click OK.
	<b>Notification ringtone</b>	Select desired notification ringtone.
	<b>Touch screen tone</b>	Tone played when selecting on screen.
	<b>Screen lock promote tone</b>	Tone played when locking/unlocking screen.
<b>Display</b>	<b>Brightness</b>	Click and move slider to adjust brightness of the screen and click OK to confirm.
	<b>Wallpaper</b>	Set desktop background picture
	<b>Screen timeout</b>	Adjust the time of delay before screen automatic lock.
	<b>Interactive screensaver</b>	Enter screensaver when the device enters sleep mode or is being charged
	<b>Font size</b>	Support adjustment of font size
<b>Storage</b>	<b>Wireless display</b>	Support display of paired equipment through wireless connection
	<b>Total capacity, free space</b>	Display total capacity and free space. Display when a TF card or USB disk is inserted.
	<b>Remove SD card/USB disk</b>	When a TF card or USB disk is inserted, click Remove SD card/USB disk to remove them.
	<b>Format SD card/USB disk</b>	Format (clear) TF card/USB disk.
<b>Battery</b>	<b>Battery level</b>	Battery consumption information
<b>Applications</b>	<b>Manage application</b>	Manage and delete installed applications.
	<b>Service in process</b>	View and control the services in process.
	<b>Storage status</b>	View the space occupation of the application.
<b>Location and information access privilege</b>	<b>Location and information sources</b>	Use wireless network to view location in applications (such as Google map)
	<b>Set screen lock</b>	Use picture, PIN or password to lock screen.

<b>security</b>	<b>Display password</b>	The entered password is visible.
	<b>Select device manager</b>	Add or delete device manager.
	<b>Unknown source</b>	Allow installing applications supplied by electronic market.
	<b>Use security credential</b>	Allow application to access to security credentials and other credentials.
	<b>Install from TF card</b>	Install encrypted certificate from SD card.
<b>Language and input method</b>	Personal dictionary	Add words to the user dictionary.
	<b>Android keypad</b>	Screen keypad setting.
	Listening example	Play short voice examples.
	Always use my setting	Use the following defaulted setting to substitute setting of application
	Preferred engine	Set the voice combination engine for switching between text and voice.
	Install voice data	Install voice data needed for voice combination
	Voice speed	Play speed after the texts are converted into voice.
	Language	Set language needed for text conversion.
	<b>Pico TTS</b>	Pico TTS setting
	Auto	Use value of the internet, sync time with the internet
<b>Backup and recovery</b>	Auto recovery	When an application is reinstalled, the system will recover the back up setting or other data.
	Restore factory setting	Click to clear all data on the device. Click Reset the device will be reset, or click  to cancel and return to previous screen. <b>Warning:</b> the following data will be deleted from the device: ~ Google account. ~ Data and settings of the system and applications. ~ All downloaded applications.  The following data will not be deleted: ~ System software and preinstalled applications. ~ Files in SD card, such as music and photos.
	Recovery mode	Restart the system and enter Recovery mode, where you can clear the partition data or upgrade the system
	Back up my data	Back up the application data, wifi password and other settings to Google server
<b>Account</b>	New account	Add and access to account Google, company and e-mail, and the account needed for other applications.
	Set date	Set date.
	Set time	Set time.

<b>Date and time</b>	Select time zone	Select time zone.
	Use 24-hour time system	Select 24-hour time system or 12-hour time system.
	Select date format	Select date format.
<b>About the device</b>		View status, battery status, legal information, model, Android version, kernel version and version number.

## FAQ

### Android

**Q: What is the Android version?**

A: 4.2.2

### Basic function of the device

**Q: Do I need to charge the device before use?**

A: Minimum 4 hours needed to charge the battery. However, you may use it while charging. Use the power adaptor to charge the battery, but not the USB data cable.

### Email

**Q: May I use my own email address to send and receive emails?**

A: The device support POP3 and SMTP accounts. The device may not support some free email accounts. Please consult the email provider for details.

### Storage card

**Q: What storage card does the device support?**

A: mini SD card.

### Music

**Q: What audio formats does the device support?**

A: MP2, MP3, WAV, AAC, WMA

**Q: How can I add music into the device?**

A: You can copy the audio files from PC to SD card or USB disk, then copy them into the device through File Browser.

### Picture

**Q: What picture formats does the device support?**

A: JPG, JPEG, BMP and PNG.

**Q: How can I add pictures into the device?**

A: You can copy the picture files from PC to SD card or USB disk, then copy them into the device through File Browser.

## Video

**Q: What video formats does the device support?**

A: MPEG1/2/4, MJPG, H263, H264. H264 supports 720×480, other formats support 1280×720.

**Q: Are videos in YouTube playable by the device?**

A: Yes. You can click YouTube icon to play videos.

**Q: How can I add videos into the device?**

A: You can copy the video files from PC to SD card or USB disk, then copy them into the device through File Browser. Or connect to the computer, directly copy the file to the device.

## Wi-Fi

**Q: Do I need an external Wi-Fi device to connect to internet?**

A: No. The device has built in Wi-Fi function.

The actual product you receive may differ.

## Battery management



The battery is not fully charged when leaving the factory, so we suggest you charge the battery for at least 4 hours before using.

The useful life of the battery is usually counted by charging times. However, you can try the following dos to prolong its useful life:

- Use the device at least once every week.
- Regularly fully charge the battery.
- Never keep the battery empty for a long time.
- Keep the device and the battery away from heat.

### Charging the battery

Connect one end of the AC adaptor to the mains supply and the other end to the power jack on the device (it takes about 5 hours to fully charge).

☆ You are not recommended to charge the device with USB cable.

When the battery is full, the battery icon will display

It takes about 5 hours to fully charge an empty battery. You can operate the device while charging.

## Important safety instruction

Please follow the following safety instructions while using the device to avoid risk of fire, electric shock or injury:



- Keep the product away from rain and humidity.
- Keep the product away from direct sunlight and heat.
- Protect the power core. When connecting the power core, do not trample on it or place anything on it. Use care to protect the connectors of the power core.
- Please only use the approved AC adaptor for charging. Using other adaptors may cause damage.
- Never disassemble or try to repair the device.

#### **Clean the device**

Clean the screen tenderly. To clean the fingerprints or dust on the screen, we suggest you use the soft cloth used on camera lens, but don't use any rough cloth.

### **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment..

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.