

RemotePoint[®] Presenter

Start Guide




Box Contents

RemotePoint Presenter	2 AAA Batteries
USB Receiver	CD-ROM
Carrying Case	Start Guide




Installing Batteries in the RemotePoint Presenter Remote

- Remove the battery cover on the underside of the RemotePoint Presenter Remote.
- Insert the two AAA batteries in the compartment. Ensure that the batteries are in the correct orientation as indicated by the positive (+) and negative (-) markings.
- Replace the battery cover.



Connecting the USB Receiver




- Remove the protective cap from the USB Receiver.
- Flip up the antenna.
- Insert the receiver into an available USB port on your computer.
- The slowly flashing green light indicates that the receiver is working.

Because RemotePoint Presenter uses radio waves, the receiver can be placed anywhere. You do *not* need to place it where you have a line-of-sight connection with the RemotePoint Presenter Remote.

Note: Shortly after you connect the receiver, Windows might display the Add New Hardware wizard. If required, click Next a few times to get through the wizard. Some Windows 98 computers require that you insert your Windows 98 installation disk. If you do not have this available, an alternative solution is provided on your RemotePoint Presenter CD in a file titled Win98.pdf.

Using RemotePoint Presenter



The RemotePoint Presenter Remote has four programmable buttons in addition to the laser pointer button and the ClickTrigger on the back.

Using RemotePoint Presenter for a PowerPoint Presentation

With no software loaded, RemotePoint Presenter is ready to help you present a PowerPoint slideshow.

To use the RemotePoint Presenter as a mouse:

- Using your thumb, apply side pressure to the mouse pointer in the direction you want the mouse cursor to move.
- Using your index finger, click the mouse by pressing the ClickTrigger on the back of the RemotePoint Presenter Remote.

The other RemotePoint Presenter Remote buttons work as follows:



Illuminates the red laser pointer on the front of the RemotePoint Presenter Remote. It is typically used as a pointer during presentations. The laser beam emits for the duration that you press the button, up to a maximum of 60 seconds. The range of the beam is in excess of 100 ft.



Moves to the previous slide in a PowerPoint slide show, or moves to the previous page in other applications.



Moves to the next slide in a PowerPoint slide show, or moves to the next page in other applications.



Alternately blanks the screen or restores the current slide in a PowerPoint slide show. Use this when you want to direct the audience's attention away from the screen or to begin or end a slide show.



Starts PowerPoint slide show when PowerPoint is active.

ClickTrigger Serves as a left mouse click.

Installing the RemotePoint Presenter Software

The RemotePoint Presenter software allows you to customize the buttons on RemotePoint Presenter. Built-in profiles for several common applications are provided, and you can create your own profiles if the built-in profiles don't fit your needs.

To install the RemotePoint Presenter software:

- Insert the RemotePoint Presenter CD into the CD-ROM drive.
- Follow the on-screen instructions.

Note: If the setup wizard does not appear, double-click My Computer, double-click the icon for your CD-ROM drive, and then double-click Setup.exe. For complete instructions on using the software, please see the User's Guide on the CD provided.

Using RemotePoint Presenter as a Presentation Remote Control

With the RemotePoint Presenter software running, the RemotePoint Presenter becomes a full-featured presentation remote control. With a single click, you can change to a different *profile*, which is a collection of button assignments.

To use RemotePoint Presenter as a presentation remote control:

- Double-click the RemotePoint Presenter icon in the notification area (also known as the system tray) at the lower right corner of the screen.
- The RemotePoint Presenter software displays the current button assignments.
- You can choose a different profile by clicking it in the list of profiles. The button assignments for the selected profile are loaded into the RemotePoint Presenter Remote.
- Press any of the buttons on the top of the RemotePoint Presenter Remote. As soon as you press one of these buttons, the RemotePoint Presenter software minimizes to an icon in the notification area. The RemotePoint Presenter Remote is ready to use.

Using the 32MB USB Drive

The RemotePoint Presenter receiver has a built-in 32-megabyte flash memory mass storage device that acts just like a removable hard drive. When you insert the RemotePoint Presenter receiver into a USB port, an additional drive appears in Windows. Store your presentation as a back up, or to take on the road.

Warranty

1. What product is covered by this warranty?

The following product ("the Product") is covered by this warranty:
RemotePoint Presenter

2. What does this warranty cover?

Interlink Electronics, Inc. ("Interlink") warrants to the original end-user purchaser of the Product ("you") that the Product will be free from defects in materials or workmanship under normal use and service during the warranty period described in paragraphs 3 and 4.

3. When does your warranty begin?

The warranty will begin on the day you purchase the Product. Dated proof of purchase is necessary to accompany the Product returned for warranty service consideration. Valid proof of purchase must identify the point of purchase, date of purchase, and product model or trade name. Ordinarily, your sales receipt or invoice will suffice.

4. How long does the coverage last?

The warranty for the Product, excluding batteries as follows:
ONE YEAR PARTS AND LABOR.

5. What will Interlink do if the product becomes defective in materials or workmanship during the warranty period?

If the Product covered under this warranty becomes defective in materials or workmanship during the applicable warranty period, INTERLINK will, at its option, either repair the defective Product without charge for parts and labor, or provide a replacement in exchange for the defective Product. INTERLINK reserves the right to provide, at no additional cost, a more current or upgraded model for replacement, if available.

6. What is not covered by this warranty?

- (a) This warranty does not extend to: (i) Products which have been subjected to misuse, accident, physical damage, improper installation, abnormal operation or handling, neglect, inundation or fire, or; (ii) Products which have been damaged due to repair, alteration or modification by anyone other than an authorized representative of INTERLINK, or; (iii) Defects caused by components, parts, or accessories not compatible with the warranted Product, or; (iv) Products whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible, or; (v) Accessory items.
- (b) ANY OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
- (c) INTERLINK'S TOTAL LIABILITY FOR DAMAGES FOR ANY CAUSE RELATED TO, OR ARISING OUT OF, THE USE OR INABILITY TO USE THE PRODUCT, WHETHER IN CONTRACT, NEGLIGENCE, STRICT TORT OR BASED ON ANY OTHER LEGAL THEORY, SHALL NOT EXCEED THE ORIGINAL PRICE PAID FOR THE PRODUCT.
- (d) IN NO CASE SHALL INTERLINK BE LIABLE FOR ANY INDIRECT SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF SAVINGS OR REVENUES, INABILITY TO USE THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT, FACILITIES OR SERVICES, CLAIMS BY THIRD PARTIES OTHER THAN YOU, AND INJURY TO PROPERTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

7. How do you get warranty service?

If your Product requires warranty service, you must first contact Product Support to receive an RMA Number. The telephone numbers for Product Support are (800) 340-1331 and (805) 484-8989. Once you obtain an RMA Number, you must return the Product to INTERLINK, postage prepaid, along with a description of the Product malfunction or difficulty and your RMA Number. You must also substantiate warranty status with a dated proof of purchase (as explained in paragraph 3), inclusive of Product's serial number. The address where you should send the Product to receive warranty service is:

Product Support
INTERLINK ELECTRONICS, INC.
546 Flynn Road, Camarillo, CA 93012
RMA Number _____

INTERLINK assumes no risk for damage or loss in shipment. If, in INTERLINK'S sole opinion, the Product failure is not covered under this warranty you will be notified and an authorization will be requested for any further repair activity. Products repaired under warranty will be returned to you, transportation prepaid. You must pay return shipping costs for the Products repaired, which are not covered by warranty or the Products for which you do not wish to authorize repairs.

8. How does state law apply to this warranty?

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

9. Attorney fees:

If any legal actions arises relating to this warranty, the prevailing party shall be entitled to recover, in addition to other damages, all court costs, expenses and reasonable attorney fees.

10. This warranty is the entire agreement.

Unless modified in writing, signed by both you and INTERLINK, this warranty is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the subject matter of this warranty. No agent or employee of INTERLINK may make modifications to this warranty and any such representations should not be relied upon.

For more information, please contact
PRODUCT SUPPORT at (800) 340-1331 or (805) 484-8989

Technical Support

If you have any difficulties installing or using your RemotePoint Navigator, please re-check the section of this User's Guide that relates to your problem. If you are still unable to solve the problem, please call our Product Support team for assistance.

Product Support
(800) 340-1331
Hours: 8 am to 5 pm, PST
Tel: (805) 484-1331
Fax: (805) 484-8989
Email: support@interlinkelec.com

Please be ready to provide the following information:

- Date and place of purchase
- Brand and model of computer
- Software you use with this product

FCC Certification

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a CLASS B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, can radiate radio frequency energy and if not installed and used in accordance with the instruction guide, may cause harmful interference to radio communications. However, there is no guarantee that this radio interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna using the supplied cable.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced Radio-TV technician for help.

Notice: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This product is equipped with a shielded cable. Extension cables are not recommended, if used, they must be shielded in order to comply with the emission limits.

IC Certification

The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met.



I N T E R L I N K
E L E C T R O N I C S

www.interlinkelectronics.com
546 Flynn Road
Camarillo, CA 93010
805.484.8855 phone
805.484.8989 fax

© 2003 Interlink Electronics, Inc. All rights reserved.

RemotePoint, the six dot logo and Interlink Electronics are registered trademarks of Interlink Electronics, Inc. All other trademarks are the property of their respective owners.

RemotePoint Presenter Start Guide
P/N 90-45876 Rev. A