

Important notice

TPMS is a wireless RF product. Therefore, it may not receive signals due to the poor environment, RF interference, low sensor battery or a damaged sensor.

1. Unit should be installed by a professional auto technician.
2. Route wiring harness away from heat sources and electrical components.
3. It is strongly recommended to check the position of the sensors before the actual drilling of the holes.
4. Perform test after finishing the installation.

note

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Technical specification

TPMS Sensor:

Working frequency:	433.92 MHz
Working voltage:	2.2 ~ 3.6V
Working temperature:	-40°C ~ +125°C
Humidity:	0% ~ 100%
Temperature reading:	±1°C
Pressure reading:	±0.1Bar
Sensor battery life	6 years

About the TPMS sensor



TPMS function

Program the sensors with TPMS sensor partner

TPMS sensors partner is a device which can program TPMS sensors without deflating tires.

1. Switch on the TPMS sensor partner.
2. Place the TPMS sensor partner close to the tire valve (ie, the left front tire) and press the corresponding button (ie, LF) once, the LED light turn on for 4 seconds to confirm the tire location is recognized.
3. Repeat step 2 for other sensors.
4. When all sensors are recognized, the corresponding LED lights will illuminate, take the TPMS sensor partner close to the display.
5. Turn on the display and enter the programming mode (Press the "SET" button for 5 times)
6. Press the TPMS button on in the TPMS sensor partner once, the display will beep once to confirm the programming is successful.

