

**STEELMATE**

TB1

## Smart Tire Pressure Monitoring System for Motorcycle




Please scan the QR code for more details

### Quick start guide



### Includes



### APP download

APP can be downloaded in the following three ways:

- Scan the QR code
- Search the "STEELMATE Connect" in Google Play
- Search the "STEELMATE Connect" in APP Store




### Log in

Follow the steps to install the TPMS APP:

- Open the APP in your smartphone and click "User registration"
- Enter your email address and password, then click "Registration"
- Receive an activation email and click on the activation link
- After activated, go back the APP and log in by entering your email address and password
- Enter APP's home screen

Notes:


- Please ensure the internet is working in the process.
- Facebook email account and Google email account can be directly used for signing in.




### Setup between sensor and app

Follow the steps to pair the sensors to the TPMS APP:


- Turn on GPS
- Open the APP in your smartphone
- Click the "+" icon on APP's home screen
- Choose the product model "TB1", then select your vehicle type
- Enter the name for identification
- Click Front or Rear to pair the corresponding sensor
- Three options can be applied to pair the sensors
  - Option 1: Enter SN number which is on the sensor
  - Option 2: Turn on Bluetooth connection, then deflate the tire, please make sure your smartphone and the corresponding sensor is near the deflating tire for reception of the signal, after the SN number appears on the screen, then click on the SN number to save the current data. (\*Do not install the sensors before pairing completed.)
  - Option 3: Scan the bar code which is on the sensor.
- After the pairing is completed, all information will be shown on the screen
- Click "Save" and start to use the device



### Sensor installation



### Sensor battery replacement



### Disclaimer

- Tire Pressure Monitoring System(TPMS) is designed for monitoring tire abnormality, and providing user as a convenient secondary safety equipment.
- If the tire has been damaged or traffic accident occurs resulting from improper driving behavior, the company will not assume civil or criminal liability.

Notes:

1. This system is for motorcycle with tire pressure within 6Bar / 87PSI.
2. The sensor battery life depends on the driving mileage.
3. Do not expose the battery to high temperature or direct flame.
4. Do not get battery wet or store in high humidity, otherwise short circuit will happen.
5. Do not disassemble or tamper with battery.
6. Tighten the nut slowly with 4.0Nm(±0.5) torque in one rotation to avoid damaging the sensor.

### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.