

Important notice

- This unit is only for vehicles with 12V DC and its tire pressure is within 3.5 Bar/50 Psi
- This unit should be installed by a professional technician according to the installation manual
- TPMS (tire pressure monitoring system) is designed to help the driver to monitor the tire irregularities. It is the driver's responsibility to react promptly to alerts. Abnormal tire pressure should be corrected ASAP.
- This is a wireless RF product, therefore, the signal may be affected by the poor environment, RF interference, low sensor battery or a damaged sensor.
- We do not guarantee or assume liability for the loss of the TPMS sensors.

note

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Technical specification


Sensor:

Operating frequency: 433.92MHz
Battery voltage: 3V
Operating temperature: -20°C~+60°C/
-4°F~140°F
Pressure range: 0~3.5 Bar/0~50Psi


Air pressure unit

1 Bar = 14.5 Psi = 100K Pa = 1.02 Kg/cm²


Sensor battery replacement




Unscrew the nut




Unscrew the sensor




Take out the washer



Unscrew the sensor cover by using the sensor tool




Replace the battery




Follow the "Sensor Installation" steps above


Sensor installation




Unscrew the valve cap




Insert the dustproof cover into the valve stem




Screw in the nut



Screw on the sensor



Tighten up the nut to the sensor by using the spanner



Check air leakage by spraying soapy water

STEELMATE CO., LTD.

No. 39 Heping Street, Dongfu Road, Dongfeng Town, Zhongshan City, Guangdong P.R. 528425 China.

www.steel-mate.com

©Steelmate Co., Ltd. All rights reserved.
The trademark, patent and copyright are owned by Steelmate Co., Ltd.
The right to change the design and specifications reserved