

\* Some of the contents in this manual may differ from your phone,  
depending on the software installed or your service provider.



# **PORTABLE CELLULAR TELEPHONE SCH-X799**



## Table of contents

<b>Important safety precautions .....</b>	<b>8</b>
<b>Unpacking .....</b>	<b>10</b>
<b>Your phone .....</b>	<b>11</b>
Phone layout .....	11
Display .....	14
Backlight .....	16
Service light .....	17
<b>Getting started .....</b>	<b>18</b>
Using a battery .....	18
Switching on or off the phone .....	21
Using the soft keys .....	23
Your phone's modes .....	24
<b>Call functions .....</b>	<b>26</b>
Making a call .....	26
Ending a call .....	27
Emergency dialing .....	27
Using the recent call logs .....	28
Making a call from Phonebook .....	28
Prepend dialing .....	29
Speed dialing .....	30
Pause dialing .....	31
Adjusting the volume during a call .....	33
Answering a call .....	34
Silencing an incoming call .....	34
Rejecting a call .....	35
Viewing missed calls .....	35
Options during a call .....	36
Call forwarding .....	37
Call Waiting .....	37
Three-way calling .....	38
<b>Entering text .....</b>	<b>39</b>
Changing the text input mode .....	40
Using Chinese Pinyin mode .....	41
Using Chinese Stroke mode .....	45

## Table of contents

Using 123 mode .....	48
Using Symbol mode .....	48
Using ABC mode .....	48
Using T9 Word mode .....	51
<b>Using the menus .....</b>	<b>53</b>
Accessing a menu function by scrolling .....	53
Using shortcuts .....	54
List of menu functions .....	55
<b>Calls .....</b>	<b>60</b>
Outgoing (Menu 1-1) .....	60
Incoming (Menu 1-2) .....	60
Missed (Menu 1-3) .....	61
Erase History (Menu 1-5) .....	62
Air Time (Menu 1-5) .....	63
<b>Phone Book .....</b>	<b>64</b>
Find (Menu 2-1) .....	64
Add New Entry (Menu 2-2) .....	68
Group Settings (Menu 2-3) .....	73
My Phone # (Menu 2-4) .....	74
Memory Info (Menu 2-5) .....	74
<b>Messages .....</b>	<b>75</b>
New MSG (Menu 3-1) .....	75
Voice (Menu 3-2) .....	76
Inbox (Menu 3-3) .....	78
Sent (Menu 3-4) .....	80
Draft (Menu 3-5) .....	81
Saved (Menu 3-6) .....	81
Web Alerts (Menu 3-7) .....	82
Erase MSG (Menu 3-8) .....	82
MSG Setting (Menu 3-9) .....	82
<b>Planner .....</b>	<b>85</b>
Today (Menu 4-1) .....	85
Scheduler (Menu 4-2) .....	85
Task List (Menu 4-3) .....	88
Memo Pad (Menu 4-4) .....	89
Alarm (Menu 4-5) .....	90
Calculator (Menu 4-6) .....	90
World Time (Menu 4-7) .....	91

## Table of contents

Countdown (Menu 4-8) .....	92
Set Time (Menu 4-9) .....	93
<b>Voice Tools .....</b>	<b>94</b>
Voice Memo (Menu 5-1) .....	94
Voice Answer (Menu 5-2) .....	96
<b>Sounds .....</b>	<b>99</b>
Ringer Volume (Menu 6-1) .....	99
Ringer Type (Menu 6-2) .....	100
Key tone (Menu 6-3) .....	100
Alerts (Menu 6-4) .....	101
Roam Ringer (Menu 6-5) .....	101
Tone Length (Menu 6-6) .....	102
Power On/Off (Menu 6-7) .....	102
<b>Display .....</b>	<b>103</b>
Menu Style (Menu 7-1) .....	103
Wall Paper (Menu 7-2) .....	103
Language/ (Menu 7-3) .....	104
Backlight (Menu 7-4) .....	104
Banner (Menu 7-5) .....	104
Dual Clock (Menu 7-6) .....	105
Service LED (Menu 7-7) .....	105
Contrast (Menu 7-8) .....	106
<b>Games .....</b>	<b>107</b>
Chicken Run (Menu 8-1) .....	108
Mobile Cop (Menu 8-2) .....	108
<b>Set up .....</b>	<b>110</b>
Call Answer (Menu 9-1) .....	110
Auto Key Lock (Menu 9-2) .....	110
Auto Retry (Menu 9-3) .....	111
Select NAM (Menu 9-4) .....	111
Set System (Menu 9-5) .....	112
Data/Fax (Menu 9-6) .....	112
Version (Menu 9-7) .....	114
Security (Menu 9-8) .....	114
<b>VAS .....</b>	<b>118</b>
Internet Portal (Menu -1) .....	118
Games & App. (Menu -2) .....	122
Ringtone (Menu -3) .....	124
Animation (Menu -4) .....	124

## Table of contents

Voice Portal (Menu -5) .....	125
SMS INFO (Menu -6).....	125
GPS (Menu -7).....	126
What's new? (Menu -8) .....	127
<b>Health and safety information .....</b>	<b>128</b>
Exposure to radio frequency (RF) signals .....	128
For body operation.....	129
Precautions when using batteries .....	131
Road safety .....	132
Operating environment.....	133
Electronic devices .....	133
Potentially Explosive Environments .....	135
Emergency calls .....	136
Other important safety information .....	137
Care and maintenance.....	138
<b>Glossary .....</b>	<b>140</b>
<b>Index.....</b>	<b>143</b>
<b>Quick reference card.....</b>	<b>145</b>

## Table of contents

## Important safety precautions

Read these guidelines before using your wireless phone. Failure to comply with them may be dangerous or illegal.

### Road safety at all times

Do not use a hand-held phone while driving; park the vehicle first.

### Switching off when refuelling

Do not use the phone at a refuelling point (service station) or near fuels or chemicals.

### Switching off in aircraft

Wireless phones can cause interference. Using them in aircraft is both illegal and dangerous.

### Switching off near all medical equipment

Switch off your phone near the medical equipment. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy. Follow any regulations or rules in force.

### Interference

All wireless phones may be subject to interference, which could affect their performance.

### Special regulations

Meet any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger (in a hospital for example).

### Water resistance


Your phone is not water-resistant. Keep it dry.

## Important safety precautions

### Sensible use

Use only in the normal position (held to the ear). Avoid unnecessary contact with the antenna when the phone is switched on, especially when the phone is in service.

### Emergency call

Key in the emergency number for your present location, then press the  key. Give all the necessary information as accurately as possible. Do not cut off the call until given permission to do so.

### Keeping small children away from your phone

Keep the phone and all its parts including accessories out of the reach of small children.

### Accessories and batteries

Use only Samsung-approved accessories. Use of any unauthorised accessories could damage your phone and may be dangerous.

Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers.

### Qualified service

Only qualified service personnel may install or repair your phone.

For more detailed safety information, see "Health and safety information" on page 128.

### CAUTION


RISK OF EXPLOSION IF A BATTERY IS REPLACED BY AN INCORRECT TYPE.  
DISPOSE USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

## Unpacking

Your package contains the following items. The illustrations below may look different from your phone and accessories:



Handset



Travel Adapter



Battery



Hand strap



User's Manual

## Your phone


### Phone layout





The following illustrations show the main elements of your phone:







#### With the phone open



## With the phone closed




Key(s)	Description
 (soft keys)	Performs the functions indicated by the screen text above them, on the bottom line of the display.
	In Menu mode, scrolls through menu options. In Standby mode; quickly enters the following menu respectively: <ul style="list-style-type: none"> <li>• Up: <b>Games</b></li> <li>• Down: <b>U-Magic</b></li> <li>• Left: <b>Message</b></li> <li>• Right: <b>Calendar</b></li> </ul>
	Enters the <b>U-Max</b> menu.
	Makes or answers a call. In Standby mode, retrieves the most recent numbers dialed, received, or missed. Redials the last number when pressed and held.

Key(s)	Description (continued)
	Ends a call. Also switches the phone on and off when pressed and held. In Menu mode, cancels your input and returns to Standby mode.
	Deletes characters from the display. In Menu mode, returns you to the previous menu level.
	Enters numbers, letters, and some special characters.
	In Standby mode, allows you to change the call ringer when pressed and held. In the text entry mode, changes the case of letters.
	In Standby mode, quickly enters or exits Silent mode when pressed and held. In the text entry mode, inserts a space.
	(on the left side of the phone) During a call, adjust the voice volume. In Standby mode, adjusts the key tone volume.

## Display



The display has three areas: the top line of icons, the text and graphic area, and the bottom line of soft key indicators.



### Icons

Icon	Description
	<b>Signal strength:</b> Shows the received signal strength. The greater the number of bars, the better the signal.
	<b>Service:</b> Appears when a call is in progress.
	<b>No service:</b> Appears when you are outside a service area. When it displays, you cannot make or receive calls. Wait a little while for a better signal or move into an open area to regain service.
	<b>Roaming:</b> Appears when you are out of your home area and have logged onto a different network; for example, when traveling in other countries.

Icon	Description (continued)
	<b>Alarm mode:</b> Appears when you set an alarm to ring at a specified time.
	<b>New message:</b> Indicates that there is a new message waiting to be checked.
	<b>Silent mode:</b> Appears when your phone is in the silent mode.
	<b>Restriction on:</b> Appears when any option of the Restriction feature is activated.
	<b>Lock mode:</b> Appears when your phone is locked.
	<b>Ringer mode:</b> Appears when you set the ringer type for calls to <b>Ringer only</b> and <b>1 Beep</b> .
	<b>Silent:</b> Appears when you set the ringer type for calls to <b>Silent</b> .
	<b>Ringer vibration:</b> Appears when the ringer type for calls is set to <b>Vibration</b> .
	<b>Vibration &amp; Ringer :</b> Appears when you set the ringer type for calls to <b>Vib. &amp; ringer</b> .
	<b>Vibration then Ringer :</b> Appears when you set the ringer type for calls to <b>Vib. then ringer</b> .
	<b>Ringer then Vibration :</b> Appears when you set the ringer type for calls to <b>Ringer then vib.</b>

Icon	Description (continued)
	<b>Web alert message:</b> Indicates that there is a new web alert message waiting to be checked.
	<b>Battery status:</b> Shows the level of your battery. The more bars you see, the more power you have remaining.

## External display

Your phone has an external display on the phone. When you close the phone, it turns on and indicates when you have an incoming call or a message. It also alerts you at the specified time when you have set an alarm by turning its backlight and showing the corresponding icon on it.

## Backlight

The backlight illuminates the display and keypad. When you press any key or open the phone, the backlight illuminates. It turns off if no key is pressed within a given period of time, depending on the **Backlight** menu (**Menu 6-2-3**) set in the **Display** menu.

To specify the length of time the phone waits before the backlight turns off, set the **Backlight** menu. See page 104 for further details.

## Service light

The service light on the folder flashes to indicate an incoming call, message, or alarm and flashes for a few seconds when you turn on or off the phone. It lights up while the battery is charging with the travel adapter; the color of the light turns green when the battery is fully charged.

# Getting started

Getting started


## Using a battery

Your phone is powered by a rechargeable Li-ion battery. Use only approved batteries and chargers. Ask your local Samsung dealer for further details.

**Note:** You must fully charge the battery before using your phone for the first time. A discharged battery recharges fully in approximately 180 minutes for a standard battery.


## Installing the battery

1. Place the battery so that the tabs on the end align with the slots at the bottom of the phone.





2. Press the battery until it clicks into place.

Make sure that the battery is properly installed before switching on the phone.



## Removing the battery

1. If necessary, switch off the phone by pressing and holding the  key down until the power-off image displays.
2. To remove the battery. To do so:
  - ① Slide the battery lock towards the top of the phone.
  - ② Lift away the battery, as shown.



## Charging the battery

A travel adapter and a battery charger are provided for charging your batteries.

### Using the travel adapter


The travel adapter allows you to use the phone while the battery is charging, but this will cause the battery to charge more slowly.

1. With the battery in position on the phone, plug the connector of the travel adapter into the jack at the bottom of the phone.


Make sure that the arrow on the connector is facing toward the front of the phone.

2. Plug the adapter into a standard AC wall outlet.

The battery strength icon on the display shows that the battery is charging.





3. When charging is finished, unplug the adapter from both the power outlet and the phone by pressing the buttons on both sides of the connector and pulling the connector out.




**Note:** Do not remove the battery from the phone without unplugging the adapter while it is charging. Otherwise, the phone may be damaged.

## Switching on or off the phone

1. Open the phone.
2. Press and hold the  key for more than one second to switch on the phone.
3. The service light flashes and then the idle screen appears on the display when the system locates services.

If the phone is out of the service area, the No Service icon () appears on the display. In this case, you cannot place and receive calls. You can try again later when service is available.



4. When you wish to switch off the phone, press and hold the  key for more than one seconds until the power-off image displays.

**WARNING!**

Do not switch on the phone when mobile phone use is prohibited or when it may cause interference or danger.


**Note:** Do not touch the antenna on the phone unnecessarily when the phone is switched on. Contact with the antenna affects the call quality and may cause the phone to operate at a higher power level than otherwise needed.

**Using the soft keys**

Your phone offers a set of functions that allows you to customize it. These functions are arranged in menus and submenus, accessed using the two soft keys,  and . Each menu and submenu allows you to view and alter the settings of a particular function.

The roles of the soft keys vary, depending on the current function you are using; the labels on the bottom line of the display just above each key indicate their current role.



Example:





## Your phone's modes

---

### Standby mode

Standby mode is the most basic state of your phone. The phone goes into Standby mode soon after you turn it on, or whenever you briefly press the  key. When your phone is in Standby mode, you will typically see the current time and date. If you enter a phone number, you can press the  key to dial it, or press the **Save** soft key to save it in the internal Phonebook.

Press the  key at any time to return to Standby mode. Be careful; if you are on a call when you press the  key, your phone disconnects the call and returns to Standby mode. Press the **C** key several times or hold it to return to Standby mode without ending the call.

### Talk mode

You can place and answer calls only when your phone is turned on. During a call, the phone is in Talk mode. While you are in Talk mode, pressing the **Menu** soft key gives you a list of options. See page 36 for details on the options.

### Power Save mode


Your phone comes with a power save feature that will automatically be activated if your phone is unable to find a signal after 15 minutes of searching. While this feature is active, the phone's battery charge is conserved. To return to Standby mode, press any key.

### Lock mode

When you lock your phone using the **Phone Lock** menu (**Menu 6-6-1**), you can receive messages and calls, but you cannot place a call until you unlock the phone.

### Silent mode

Silent mode disables all sounds on the phone. This feature is best used in situations where the phone might disturb others, such as in a meeting, a library, and a theater.

To enter Silent mode, press and hold the **#** key until "Entering Silent Mode" and the Silent mode icon () appears.

To exit and reactive the previous sound settings, press and hold the **#** key until "Exit Silent Mode" appears. The Silent mode icon no longer displays.

**Note:** If you turn off the phone in silent mode, the silent mode is still activated when you turn on the phone.

## Making a call

To make a call:

1. In Standby mode, enter the area code, and phone number.

While entering a phone number, press the **Pause** soft key to insert a hard pause. For more information on pause dialing, see page 31.

2. Press the **Call** key. The phone places the call to the entered phone number.

**Note:** If you have set the time interval for automatic redialing in the **Auto Retry** menu (**Menu 6-3**), the phone will automatically retry to make the call when no one answers or the line is busy.

## Correcting the number

To clear	Press the
the last digit displayed	<b>C</b> key.
the whole display	<b>C</b> key for more than one second.

## Ending a call

When you want to finish your call, press the **End Call** key.

The call time, the length of the call, displays along with the phone number of the called person. If the number is stored in your Phonebook, the name displays. If there is no match, you can press the **Save** soft key and store the number in Phonebook. For further details about storing the number in Phonebook, see page 68.

Alternatively, simply close the phone to end a call.







## Emergency dialing

You can place emergency call from your emergency number list even if your phone is locked. For further information on emergency numbers, refer to page xx.

## Using the recent call logs

The phone stores up to 90 of the calls dialed, received, or missed chronologically. The last call is saved in the first position.

To recall any of these numbers:

1. If there are any characters on the display, return to Standby mode by pressing the  key.
2. Press the  key. The list of recent calls displays.
  - : Outgoing calls
  - : Incoming calls
  - : Missed calls
3. Press the Up and Down keys, or the Volume keys on the left side of the phone to scan through the list until the number you want highlights.
4. Press  to dial the highlighted number.


## Making a call from Phonebook

You can store the phone numbers regularly in the card and the phone's memories, which is called "Phonebook." You then simply recall the number to dial. For further details on Phonebook, see page 64.

## Prepend dialing

The Prepend option lets you add digits, such as area codes and network feature activation codes, to a phone number that is in your call logs before dialing it.

To prepend the phone numbers stored in the call logs:

1. Access a call log in the Recent Calls list referring to page 28 or in the **Calls** menu (**Menu 1**).
2. When the phone number you want to dial highlights, press the **Select** soft key.  
The display shows the details of the number.
3. Press the **Menu** soft key to access the Menu pop-up list.
4. Press the **3** key to select the **Prepend** option.
5. Enter the area code or feature code.
6. Press the  key to dial the number.

## Speed dialing

Once you have stored phone numbers in Phonebook, you can dial them easily with the few presses of the keys.

Enter the memory location of a number and press and hold the final digit to dial.

**One-touch dial:** Memory locations 001 through 009 are special one-touch locations. You can dial the phone numbers stored in the Phonebook memory from 001 through 009 simply by pressing one key.

Press and hold the third digit of the memory location containing the number to be dialed.

For example: Location no. 009  
Press the **9** key and hold.

The number (and name) stored displays, then dials.

**Two-touch dial:** For memory locations of two digits.

Press the second digit briefly, then hold down the third digit of the memory cell.

For example: Location no. 023  
Press the **2** key briefly and hold down the **3** key.

The number (and name) stored displays, then dials.

**Three-touch dial:** For memory locations of three digits.

Press the first two digits briefly, then hold down the third digit of the memory cell.

For example: Location no. 123

Press the **1** and **2** key briefly and hold down the **3** key.

The number (and name) stored displays, then dials.

## Pause dialing

When you call an automated system, like a banking service, you are often required to enter a password or an account number. Instead of manually entering the numbers each time, you can store the numbers in your Phonebook, separated by pauses.

### Storing pauses in a Phonebook entry

To store a number in your Phonebook that contains pauses:


1. Enter the phone number you want to store, such as a bank's teleservice phone number.
2. Press the **Pause** soft key to insert a pause. A "P" displays, meaning that a hard pause will occur at that point in the dialing sequence.

The "P" stops the dialing and waits for the teleservice to prompt you for a number. The number following the "P" is your account number, PIN, etc.

3. Enter the digits that need to follow the pause, such as your account number.
4. Repeat steps 2 and 3 to add more pauses and numbers, if necessary.

5. Store the number in your Phonebook as you normally would by pressing the **Save** soft key and following from step 4 on page 68.



#### Pause dialing from a stored Phonebook entry

1. Call the number from Phonebook.
2. Wait for the appropriate prompt from the number you are calling.
3. When prompted, press the  key to send the DTMF (Dual Tone Multi Frequency) number that follows your pause.

"SEND DTMF" flashes on the display and the transmitted tone sounds.



#### Manual pause dialing

You can enter pauses manually during the dialing process.

1. Enter the phone number of the service you want to call, such as a bank's teleservice phone number.
2. Press the **Pause** soft key to insert a pause.  
The screen displays a "P" indicating a pause.
3. Enter the number to be sent after the pause by pressing the digit keys, and then press the  key.
4. After connecting, wait for the prompt from teleservice. Press the  key again after the prompt to send the additional number.

#### Adjusting the volume during a call

During a call, if you want to adjust the voice volume, use the Volume keys on the left side of the phone.

Press the  key to increase the volume level and the  key to decrease the level. The image on the display shows all five levels; the more bars you see, the higher the level is.






In Standby mode, you can also adjust the key tone volume using these keys.


## Answering a call

When somebody calls you, the phone alerts you by ringing and blinking the service light.

If the caller can be identified, the caller's phone number or name, if stored in your Phonebook, displays.

There are many ways to answer a call, depending on your setting in the **Answer Mode** menu (**Menu 6-4**);

Setting option	To answer the call,
By send key	press the  key.
By folder open	open the phone. If it is already open, press the  key.
By any key	open the phone or press any key except the soft keys, the  key or the Volume key.


To end the call, close the phone or press the  key.

**Note:** You can answer a call while using Phonebook or menu features. The current operation stops.

## Silencing an incoming call

You can silence the ringer when a call comes. Press one of the Volume keys. If it is open, press the left soft key.



## Rejecting a call

To reject an incoming call, press the right soft key or the  key.

Press and hold one of the Volume keys on the left side of the phone.

## Viewing missed calls

If you fail to answer a call for any reason, the phone indicates a missed call by displaying a text notification on the screen. Additionally, if caller information is available, a Missed entry is created, and the screen displays the phone number of the last missed call.

When the display informs you of the missed call, press the  key to call the displayed number, or the  key to clear the message and return to Standby mode.

To view the list of the missed calls, refer to "Missed" on page 60.

## Options during a call

---

Your phone provides a number of functions that you can use during a call. As many of these options are network services, you may not be able to use all of them at all times.

Press the **Menu** soft key during a call to access the following options:

**Mute/Quit:** allows you to switch your phone's microphone off, so that the other person cannot hear you.

**Example:** You wish to say something to another person in the room, but do not want the other person to hear you.

**Calls:** allows you to access the **Calls** menu. See page 60.

**Phonebook:** allows you to access the **Phonebook** menu. See page 64.

**Silent/Quit:** does not transmit the key tones. It allows you to press keys without hearing annoying key tones during a call.

**Send my #:** sends your phone number to the calling person or automated services.

**DTMF Length:** manipulates the audible DTMF (Dual-Tone Multi-Frequency) tones. You can choose either **long** or **normal**.

## Call forwarding

---

When the **Call forward** menu (**Menu 1-5**) is enabled, your phone forwards incoming calls to another phone number, even while your phone turns off.

Activating Call forwarding does not affect outgoing calls made from this phone. For further details for activating Call forwarding.




## Call Waiting

---

When the **Call Waiting** menu (**Menu 1-6**) is enabled, you can answer an incoming call while you have a call in progress;

When a waiting call is detected, the incoming call alert sounds, depending on your network, and a text notification displays.



To answer a waiting call:

1. To answer the call, press the  key. The phone connects the calling person, and places the current call on hold.
2. Press the  key again to switch between the two calls.
3. To end the call, press the  key or close the phone. All of the calls are disconnected.

## Three-way calling

This feature enables you to conduct conference calls with two separate people at the same time. The phone records both calls in the Outgoing call log. You are billed airtime for each of the outgoing calls separately. Contact your service provider to activate Three-Way Calling.

To make a three-way call:

1. During a conversation, enter the phone number for the third person and press the  key.
2. When the third person answers, press the  key again to begin your three-way call.

During a three-way call, if one of the callers hangs up, you and the remaining caller will stay connected. If you initiated the call and you hang up first, all calls are disconnected.

## Entering text

At many times when using your phone, you will need to enter text; for example, when storing a name in Phonebook, writing a text message, or scheduling events in your calendar. You can enter alphanumeric characters into your phone by using your phone's keypad.

Your phone has the following text input modes:

- **Pinyin:** allows you to enter a Chinese character using its Pinyin spelling, which is a phonetic system.
- **Stroke:** allows you to a Chinese character using the individual strokes labeled on the keys.
- **123:** allows you to enter numbers.
- **Symbol:** allows you to enter many different symbols and special characters.
- **ABC:** allows you to enter English characters by pressing the key labeled with the character you want until it displays.
- **T9 Word:** allows you to enter English characters with only one keypress per character.

**Note:** Pinyin, Stroke, and T9 Word modes use the T9 input method. T9 mode automatically compares your key presses to an internal linguistic database to determine the correct word.

## Changing the text input mode

### **Example:** Writing a text message

In the text entry screen, press the **Mode** soft key.


1. Scroll to the mode you want by pressing the Navigation keys.

**Note:** If you want to exit the Mode list without changing to a new mode, press the **C** key.

You can change between **ABC** and **T9 Word** mode to enter English words and choose **Pinyin** or **Stroke** to enter Chinese characters. To include a symbol or number(s) between characters, **123** and **Symbol** modes are also available.

2. To select the highlighted mode, press the **Select** soft key.

You will find the selected text input mode indicator on the display.



## Using Chinese Pinyin mode


Pinyin is a system to write the pronunciation of a Chinese word using the Latin alphabet. With the Pinyin input method, you can enter Chinese characters by keying in the Pinyin string using the phone's keypad. The phone automatically presents the matching words.

This mode allows you to enter Pinyin characters with only one key per letter.

### Typing characters in Pinyin mode

1. Press the keys corresponding to the phonetic spelling, referring to the letters printed on the keys. Notice that the choices in the Character Selection Field change.

**Example:** Typing “你” in Pinyin mode



2. If the yellow box is not placed to the phonetic word that you want to find, press Left key of Right key to scroll through the choices. Also, If you cannot find the desired character from the display, press Up key or Down key to scroll through the choices in the Character Selection Field.

When the character you are typing appears in the Character Selection Field, you may select it, without completing the Pinyin spelling.

3. To select a character, press **1** to activate the Character Selection Field. A number from **1** to **6** are added to the beginning of a corresponding character. When the Character Selection Field is activated, a normal press on the **1** key to **6** keys selects the corresponding character.



Press the **1** key to select "你."

**Note:** You can deactivate the Character Selection Field by pressing the **C** key.


## Using the alternative pinyins and tones

You can enter another character using alternative Pinyin for the keys you have pressed or assigning a tone for the selected Pinyin. Entering a tone for a character is optional, but it is especially useful if the Pinyin spelling is similar for several characters.

1. Press the keys corresponding to the letter you need. Press the **✕** key to display another Pinyin spellings and the Tones menu.

For example, to get "mi", press the **6** and the **4** keys. But the screen shows "ni," another Pinyin for your keypress.

Remember there are several Pinyins from the same key pressing. To get alternative Pinyins, press the Left key or Right key.



Press the **6** and **4** keys.

2. If you cannot find the desired character from the display, press Down key to scroll through choices in the Character Selection Field.
3. If you find the character you want to enter, press a key (**1** to **6**) to corresponding the character.


**Note:** You may delete a previously entered tone by pressing **C**.



## Typing strokes and characters in Stroke mode

1. To type a character, press the keys corresponding to its component strokes. Press keys in the order that you would write the strokes, using one press per stroke.

Example: Typing “力” in Stroke mode



2. The phone displays your strokes in the Key Stroke input field and offers character choices in the Character Selection Field. As you enter strokes, notice that the choices in the Character Selection Field change.

To scroll through the choices, press the Up or Down key.

**Note:** If you are uncertain of the order of one or more strokes, press the 6 key in place of each questionable stroke. Continue entering strokes until the character displays in the Character Selection Field or until you finish the character.

3. When the character you are typing appears in the Character Selection Field, you may select it without finishing the stroke sequence for the character. Characters displayed in the Character Selection Field correspond to keys, 7 to # on the keypad. To select a character and add it to your message, press the corresponding key, from the 7 to # key.

## Rapid character entry

Rapid character entry is easy in any mode, using the Character Selection Field. As you enter characters, your phone predicts the next character you might want and presents choices in the Character Selection Field.

For example, try typing the characters “zhong guo (中国)” using the following keystrokes; the 2, 8, and 7 keys. Even though “guo (国)” is the twelve stroke character pair, your phone allows you to enter it in only three key presses.

## Scrolling

To move the cursor to the left or right through your text, press the Left or Right key.

## Clearing strokes and characters

Press the C key once or repeatedly to remove strokes one by one to the left. Once the Key Stroke input field is empty, pressing the C key removes a letter from the Text Area.

To clear all of the strokes and characters on the display, press and hold the C key.

## Using 123 mode

123 mode enables you to enter numbers into your text. Press the keys corresponding to the digits you want, and manually switch back to the text entry mode of your choice. See page 40 for changing the text input mode.

## Using Symbol mode

Symbol mode enables you to enter symbols into your text.

Press the Left or Right key to display more symbol sets.

Press the keys corresponding to the mark you want, and manually switch back to the text entry mode of your choice. See page 40 for changing the text input mode.

## Using ABC mode

When typing in ABC mode, you should press the key labeled with the letter you want:











- once for the first letter
- twice for the second letter
- and so on.

This method is called Multi-tap typing.

For example, you need to press the **2** key three times quickly to display the letter "C" and the **5** key two times quickly to display the letter "K."

Refer to the table below for the list of characters assigned to each key.


### List of characters available:

key	Characters in the Order Displayed
	. @ , : ? - ; ' / ( ) ! # % & * < > _ + = " \ { } \$ [ ] 1
	A B C 2
	D E F 3
	G H I 4
	J K L 5
	M N O 6
	P Q R S 7
	T U V 8
	W X Y Z 9
	O

(Capital Lock)

The cursor moves to the right when you press a different key. When entering the same letter twice or a different letter on the same key, just wait for about four seconds, and enter the next letter.

### Changing the letter-case

To shift case of the next letter(s) that you type, press the  key. There are three cases:

- Initial Capital (**Abc**)
- Lower Case (**abc**)
- Capitals Lock (**ABC**)

### Inserting a space

Press the **#** key to insert a space between words.

### Including a number

You can quickly include a number between letters. Press and hold the corresponding number key.

### Scrolling

To move the cursor to the left or right through your text message, press the Left or Right key.

### Clearing letters and words

Press the **C** key once or repeatedly to clear letters one by one to the left. Press and hold the **C** key to erase all of the letters on the display.

## Using T9 Word mode

To type a word, press the keys corresponding to the letters you need. Remember the following as you are typing:

1. Press keys on the phone just once per letter. For example, to enter "Hello," press the **4**, **3**, **5**, **5**, and **6** keys.
2. The word you are typing appears on the display. It may change with each key press.
3. Type to the end of the word before editing or deleting any keystrokes.

If the word does not display correctly, press the **0** key once or repeatedly to display alternative word choices for the keys you have typed.


For example, both "of" and "me" have the sequence of the **6** and **3** keys. The phone displays the most commonly used choice first.

4. Insert a space between words by pressing the **#** key.

To type words not found in T9 Word mode, you need to change the text input mode to ABC mode.

### Smart punctuation

You can insert periods, hyphens, and apostrophes by pressing the **1** key. T9 Word applies rules of grammar to insert the correct punctuation. Notice that **1** key is used twice in this example to display two punctuation marks:



## Entering text

### Changing the letter-case

To shift case of the next letter(s) that you type, press the **✕** key. There are three cases:

- Initial Capital (**T9Word**)
- Lower Case (**T9word**)
- Capitals Lock (**T9WORD**)

### Including a number

You can include a number between letters without exiting T9 Word mode. Press and hold the corresponding number key.

### Scrolling

To move the cursor to the left or right through your text, press the Left or Right key.

### Clearing letters and words

Press the **C** key once or repeatedly to clear letters one by one to the left. Press and hold the **C** key to erase all of the letters on the display.

## Using the menus

The phone offers a range of functions that allows you to tailor it to your needs. These functions are arranged in menus and submenus.

The menus and submenus can be accessed by scrolling or using the shortcuts.

### Accessing a menu function by scrolling


---

1. In Standby mode, press the **Menu** soft key to access the main menu mode.
2. Scroll using the Navigation keys to reach a main menu, for example, **Settings**. Press the **Select** soft key to enter the menu.
3. Find the menu option you want, for example, **Display**, by scrolling using the Up or Down key. Press the **Select** soft key to enter the menu option.

If the menu you have selected contains submenus, such as 语言/**Language**, repeat this step.

4. Scroll using the Navigation keys to select the setting of your choice.
5. Press the **Save** soft key to confirm the chosen setting.

#### Notes:

- To return to the previous menu level, press the **C** key.
- You can exit the menu without changing the menu settings by pressing the  key.

## Using shortcuts

The menu items, such as menus, submenus, and setting options, are numbered and can be accessed quickly by using their shortcut numbers.

**Note:** The numbers assigned to each menu function are indicated on the list on page 55.

1. In Standby mode, press the **Menu** soft key to access the menu mode.

2. Enter the first digit of the shortcut number. Repeat this for each digit of the shortcut number.

Example: Changing the display language

Press the **6**, **2**, and **7** keys.

**6** enters **Settings**, **2** selects **Display**, and **7** selects **语言/Language**.

3. Scroll using the Navigation keys to select the setting of your choice.
4. Press the **Save** soft key to confirm the chosen setting.

## List of menu functions

The following list shows the menu structure and indicates the number assigned to each option.

### 1. Calls (see page 60)

- 1.1 Outgoing
- 1.2 Incoming
- 1.3 Missed
- 1.4 Erase History
  - 1.4.1 Outgoing
  - 1.4.2 Incoming
  - 1.4.3 Missed
  - 1.4.4 All Calls
- 1.5 Air Time
  - 1.5.1 Last Call
  - 1.5.2 Total
  - 1.5.3 Lifetime
  - 1.5.4 Erase Total

### 2. Phonebook (see page 64)

- 2.1 Find
- 2.2 Add New Entry
- 2.3 Group Settings
- 2.4 My Phone #
- 2.5 Memory Info

### 3. Messages (see page 75)

- 3.1 New MSG
- 3.2 Voice
- 3.3 Inbox
- 3.4 Sent
- 3.5 Draft
- 3.6 Saved
- 3.7 Web Alerts

**3. Message** (continued)

- 3.8 Erase MSG
  - 3.8.1 Voice
  - 3.8.2 Old Inbox
  - 3.8.3 New Inbox
  - 3.8.4 Sent
  - 3.8.5 Draft
  - 3.8.6 Saved
  - 3.8.7 All Messages
- 3.9 MSG Setting
  - 3.9.1 Scroll Timer
  - 3.9.2 MSG Reminder
  - 3.9.3 New MSG
    - 3.9.3.1 Save Message
    - 3.9.3.2 Entry Method
  - 3.9.4 Canned MSG

**4. Planner** (see page 85)

- 4.1 Today
- 4.2 Scheduler
- 4.3 Task List
- 4.4 Memo Pad
- 4.5 Alarm
- 4.6 Calculator
- 4.7 World Time
- 4.8 Countdown
- 4.9 Set Time

**5. Voice Tools** (see page 107)

- 5.1 Voice Memo
  - 5.1.1 Record
  - 5.1.2 Review
  - 5.1.3 Erase All
- 5.2 Voice Answer
  - 5.2.1 On/Off
  - 5.2.2 Inbox
  - 5.2.3 Setting

**6. Sounds** (see page 110)

- 6.1 Ringer Volume
  - 6.1.1 Calls
  - 6.1.2 Messages
  - 6.1.3 Alarm
- 6.2 Ringer Type
  - 6.2.1 Voice Calls
  - 6.2.2 Messages
  - 6.2.3 Data/Fax In
  - 6.2.4 Schedule
- 6.3 Key Tone
  - 6.3.1 Type
  - 6.3.2 Volume
- 6.4 Alerts
- 6.5 Roam Ringer
- 6.6 Tone Length
- 6.7 Power On/Off

**7. Display**

- 7.1 Menu Style
- 7.2 Wall Paper
- 7.3 Language/שפה
- 7.4 Backlight
- 7.5 Banner
- 7.6 Dual Clock
- 7.7 Service LED
- 7.8 Contrast

**8. Games**

- 8.1 Chicken Run
- 8.2 Mobile Cop

## 9. Set up

- 9.1 Call Answer
- 9.2 Auto Key Lock
- 9.3 Auto Retry
- 9.4 Select NAM
- 9.5 Set System
- 9.6 Data/Fax
- 9.7 Version
- 9.8 Security
  - 9.8.1 Lock Phone
  - 9.8.2 Lock Code
  - 9.8.3 Restriction
  - 9.8.4 Emergency #
  - 9.8.5 Erase Pbook
  - 9.8.6 Reset Phone

### VAS (see page 118)

- Internet Portal
- Games & App.
- Ringtone
- Animation
- Voice Portal
- SMS INFO
- Multimedia
- What's new?

## In-Call menu (see page 36)

- 1: Mute/Quit
- 2: Calls
  - 2.1: Missed
  - 2.2: Incoming
  - 2.3: Outgoing
  - 2.4: Air Time
- 3: Phonebook
  - 3.1: Find
  - 3.2: Add
  - 3.3: Group Settings
  - 3.4: My Phone #
- 4: Silent/Quit
- 5: Send my #
- 6: DTMF Length

You can use the **Calls** menu to:

- view and dial the last missed, outgoing, or incoming numbers.
- view the duration of calls.
- set the phone to receive the second call or to forward incoming calls to the preset number.

## Outgoing *(Menu 1-1)*

This menu lets you view up to 20 of the most recent calls you have dialed. When you access this menu, a list of the outgoing calls displays.

## Incoming *(Menu 1-2)*

This menu lets you view up to 30 of the most recent calls you have received if you are subscribed to the Caller Line Identification service. Contact your service provider for more information about this service. When you access this menu, the list of the incoming calls displays.

For further details about scrolling through the list and accessing the call log, see “Missed” on page 60.

## Missed *(Menu 1-3)*



If Caller Line Identification is available, your phone keeps a list of the 30 most recent incoming calls that you failed to answer. Contact your service provider for the availability.

When you press the **Menu** soft key on the call log list, the following options are available:

**Erase:** erases the selected number.

**Erase all:** erases all of numbers.

1. Press the Up and Down keys to find a number or name, if saved in Phonebook.
2. Press the **Select** soft key to select the highlighted number. The dialed number, or name if stored in Phonebook, displays.

3. <b>To</b>	<b>Press the</b>
place a call	 key.
use the menu options	<b>Menu</b> soft key. For details about the options, see below.
view other calls	Navigation keys and volume keys.
return to Standby mode	 key.

When you access the menu options, the following options are available:

**Talk:** dials the selected number.

**Save:** allows you to save the number in Phonebook.

**Prepend:** allows you to add an area code or feature code to the number before calling the number.

**Erase:** allows you to erase the selected number.

### **Erase History** *(Menu 1-5)*

---

You can erase the entries stored in each of the three call logs or all three logs at once.

The following options are available:

**Outgoing:** The calls you made are erased.

**Incoming:** The calls you received are erased.

**Missed:** The calls you missed are erased.

**All Calls:** All calls you made, received and missed are erased.

### **Air Time** *(Menu 1-5)*

---

Your phone records the amount of Air Time, or talk time, used. Using this option, you can view the number of the calls to or from your phone and the air time for all calls. You can easily erase the air time record at any time.

**Note:** This feature is not intended to be used for billing purposes.

The following options are available:

**Last Call:** shows the air time of the last call.

**Total:** shows the number of all calls you have made to or from your phone and the total duration of the calls since the air time counter was last set to zero by using the **Erase Total** option.

**LifeTime:** shows the number and total duration of all calls you have made to or from your phone since the phone was shipped from the factory.

**Erase Total:** erases the "Total" air time measurement and resets the air time counter.



# Phone Book

You can store phone numbers and their corresponding names in the memories of your UIM card and the phone. The UIM card and phone memories, although physically separate, are used as if they were a single entity, called Phonebook.

## Find *(Menu 2-1)*

This menu allows you to find an entry using a person's name, entry number, group name, or memory location.

**Note:** You can quickly access this menu by pressing the **Find** soft key in Standby mode.

To change the finding method, press Left or Right key until the option you want to use displays; **By Name**, **By Entry**, **By Group**, or **By Storage**.

### Finding an entry by name

When you select this method, the whole list of all of Phonebook entries appears in alphabetical order.

1. If necessary, press the Left or Right key to scroll to **By Name**.
2. If necessary, press the Down key to highlight the name input box.


3. Enter the first few letters of the name you want to find.

If you want to find a Chinese name, press the **Menu** soft key when the name input box is highlighted. You can enter a name using other text input modes. For more information on how to enter characters, see page 39.

Your phone highlights the first matching name.

4. If necessary, press the Up or Down key to scroll through the entries.

5. When an entry highlights:

- Press the  key to place a call to the entry's speed-dial number.

- Press the **Menu** soft key to access the following options:

- **Edit**: edits the entry's phone number, name, location number, and other information.

- **Erase**: erases the entry.

- **Add New**: adds a number to Phonebook. You can create a new entry or add it to an existing entry. For more information on how to add a number, see page 68.

- Press the **OK** soft key to select the entry. Information about the entry displays. Move to each item by pressing the Up or Down key.


Press the **Menu** soft key to use one of the following options:

- **Talk**: dials the number labeled as speed-dial number.

- **Edit**: allows you to change the selected item.

- **Copy:** allows you to copy the number in the other memory. For an entry stored in the phone's memory, this option is shown only when you select a number, such as **Home**, **Office**, **Mobile**, **Pager**, or **Fax**.

- **Erase:** erases the entry. If you select one of numbers for the entry, only the number is erased.

- Press the **C** key to return to the previous screen.
- Press the  key to exit the menu.

### Finding an entry by entry number

When you select this method, the whole list of all of the Phonebook entries appears in numeric order.

1. Press the Left or Right key to scroll to **By Entry**.
2. Press the Down key to highlight the number input box.
3. Enter the location number of the entry you want to find.
4. Follow the procedure from step 4 on page 65.

### Finding an entry by group

When you select this method, a list of the Phonebook entries in a group appears.

1. Press the Left or Right key to scroll to **By Group**.
2. Press the Down key to move the group selection field.
3. Press the Left or Right key to select the group you want.

Each time you select a group, a list of the associated entries displays.

4. Follow the procedure from step 4 on page 65.

### Finding an entry by storage

When you select this method, a list of the Phonebook entries in the UIM card's memory appears.

1. Press the Left or Right key to scroll to **By Storage**.
2. Press the Down key to move to the memory selection field.
3. Press the Left or Right key to select a memory, **Card** or **Phone**.

Each time you select a memory, a list of the associated entries displays.

4. Follow the procedure from step 4 on page 65.

## Add New Entry *(Menu 2-2)*

This menu allows you to add a new entry to your Phonebook by saving a phone number, an e-mail address, or a memo.

### Adding a new entry using a number

In the Phone memory, a name can contain up to 5 numbers in different categories; Home, Office, Mobile, Pager, and Fax. You can save only one number with a name in the Card memory.

1. After accessing the **Add** menu (**Menu 2-2**), select **Number** from the pop-up list and press the **Select** soft key.
2. Enter a number you want to save and press the **Save** soft key.
3. When **New Entry** highlights, press the **Save** soft key.
4. Enter a name and press the **OK** soft key.  
For more information about how to enter characters, see page 39.


5. Your phone shows the entry information. Press the Up or Down key to scroll through the items.
  - **Name:** Press the **Edit** soft key to change the name you entered in step 4, if necessary. You can enter a name in this step if one has not already been entered.
  - **Storage:** shows the memory where the number is stored. The card memory is automatically selected for storing the number.

- **Location number:** The first available location displays. If you need to enter the location number using the number keys or press the Left or Right key until the location number you want to use appears.
  - **Number:** shows the number you entered in step 2. You can change the number or insert a pause using the **Pause** soft key.
6. To save the number in the card, skip to step 10.  
To save it in the phone's memory, highlight the storage or location number field and press the **Phone** soft key. Continue the next steps.
  7. Choose a type icon, **Home**, **Office**, **Mobile**, **Pager**, or **Fax**, using the Navigation keys and press the **Select** soft key.
  8. Press the Up or Down key and change the setting or enter more information, if necessary.
    - **Name:** Press the **Edit** soft key to change the name.
    - **Storage:** shows the memory where the number is stored.
    - **Location number:** shows the location number.
    - **Home/Office/Mobile/Pager/Fax:** You can add numbers for each category or change the current number.
    - **E-Mail1/E-Mail2:** Press the **Edit** soft key to enter an e-mail address. For more information about how to enter characters, see page 39.
    - **URL:** Press the **Edit** soft key to enter an URL address. For more information about how to enter characters, see page 39.

- **ETC:** Press the **Edit** soft key to store additional information about the person.
  - **Speed Dial:** allows you to select one of the stored numbers for speed dialling.
  - **Group:** Select one of the default relation groups, where the entry is included. Grouping the entries enables you to search for a number in the group. See page 67.
  - **Ringer:** Press the **Edit** soft key to select a unique ringer melody for the entry. By selecting a different tone for each entry, incoming voice calls having a caller ID can be distinguished from those that do not.
9. Repeat step 8 until you complete the contact information of the entry.
  10. Press the **Save** soft key to save the entry.

After storing, the phone displays the memory status of Phonebook for a few seconds and goes to the Phonebook list.

### Saving a phone number from Standby mode

1. In Standby mode, enter a number you want to save.  
  
Or, press the  key to end the call. The call time and the phone number display.
2. Press the **Save** soft key.
3. Enter a name and press the **OK** soft key.

For more information about how to enter characters, see page 39.

4. Follow the procedure from step 5 on page 68.

### Adding a number into an existing entry

You can store up to 5 numbers for a name saved in the phone's memory by assigning them to the different types.

1. After accessing the **Add** menu (**Menu 2-2**), select **Number** from the pop-up list and press the **Select** soft key.
2. Enter a number you want saved and press the **Save** soft key.
3. Select **Find** and press the **Save** soft key.
4. Find the name you want using the Up and Down keys and press the **OK** soft key.
5. Select a type icon by pressing the Navigation keys and press the **Select** soft key.
6. Follow the procedure from step 8 on page 69.

When the confirmation message to overwrite the entry appears, select **Yes** and press the **Select** soft key.

### Adding a new entry using an e-mail address

You can store an e-mail address as a Phonebook entry.

1. After accessing the **Add** menu (**Menu 2-2**), select **E-mail** from the pop-up list and press the **Select** soft key.

2. Enter the e-mail address and press the **OK** soft key.

For more information about how to enter characters, see page 39.

3. When **New Entry** highlights, press the **Save** soft key.

**Note:** To add the address to an existing entry, select **Find**. Find the name from the Phonebook list and press the **OK** soft key.

4. Enter a name and press the **OK** soft key.
5. Follow the procedure from step 8 on page 69.

### Adding a new entry using a memo

You can make a memo about a person as a Phonebook entry.

1. After accessing the **Add** menu (**Menu 2-2**), select **ETC** from the pop-up list and press the **Select** soft key.

2. Enter a memo and press the **OK** soft key.

For more information about how to enter characters, see page 39.

3. When **New Entry** highlights, press the **Save** soft key.

**Note:** To add the memo to an existing entry, select **Find**. Find the name from the Phonebook list and press the **OK** soft key.

4. Enter a name and press the **OK** soft key.
5. Follow the procedure from step 8 on the page 69

## Group Settings *(Menu 2-3)*

This menu allows you to add a new relation group or change the name of a group. You can also delete a group.

### Adding a new group

1. Press the **Add** soft key, and skip to step 3.

When a group is selected, press the **Menu** soft key.

2. Select the **Add New** option and press the **Select** soft key.

3. Enter the group name you want and press the **OK** soft key.

For further details about entering characters, see page 39.

### Changing a group name

1. On the Group Settings list, select the group name you want to change using the Up or Down key and press the **Menu** soft key.

2. Select **Edit** and press the **Select** soft key.

3. Press and hold the **C** key to clear the old group name.

4. Enter a group name and press the **OK** soft key.

### Erasing a group

1. On the Group Settings list, select the group you want to erase by pressing the Up or Down key and press the **Menu** soft key.
2. Select the **Erase** option and press the **Select** soft key.
3. When a confirmation message displays, select **Yes** and press the **Select** soft key.

### My Phone # *(Menu 2-4)*

---

This menu shows your phone number.

To change the phone number:

1. Press the **Edit** soft key when the number displays.
2. Enter a new phone number and press the **Save** soft key to save it.

### Memory Info *(Menu 2-5)*

---

this option shows the memory status for Phone Book.

## Messages

Your phone can receive voice mail messages, text messages, and web messages from your web server. Your phone can also send text messages if your system supplier provides this service.

Incoming messages are received even when your phone is in Lock mode. The screen displays information about the message. To access the message, you need to unlock the phone.

If you receive an incoming message during a call conversation, your phone sounds an alert tone.

**Note:** You can quickly enter this menu by pressing the Left soft key in Stanby mode.

### New MSG *(Menu 3-1)*

---

You can create short text messages and send them to multiple mobile phones.

1. Enter the message contents and press the **OK** soft key.

For more information on how to enter characters, see page 39.

You can use up to 20 canned messages by pressing the **Mode** soft key and selecting **CannedMsg**. For details, see page 83.


You can use up to 12 domains by pressing the **Mode** soft key and selecting **Domains**. Select a domain from a list.

2. Select one of the following options, and press the **OK** soft key.

- **Save & Send:** allows you to save a copy of the message and then send the message to the required destination. You can read the message in your Outbox.
  - **Send only:** allows you to send the message. The message will be deleted after sending.
  - **Save only:** allows you to save the message so that it can be sent later. You can read the message in your Outbox.
3. Enter a phone number.  
If you press the **Find** soft key, you can search your Phonebook for a number.
  4. To send the message to multiple destinations, press the Down key and enter another number.  
Repeat this step to add more destinations. You can send the message to up to 10 destinations at one time.
  5. When you have finished entering the numbers, press the **OK** soft key to send or save the message.  
Your phone informs you of whether or not the message was successfully sent, and returns to the Message menu screen.

## Voice *(Menu 3-2)*

---

When you receive a voice message the corresponding text notification displays. Press the  key and the phone dials the voice mail center.

If multiple new voice messages are received but not checked, information of the last one will be displayed. The information display includes the time/date stamp and the number of new voice messages.

Press the **Menu** soft key to access the following options:

**Listen:** allows you to listen to the voice message. The phone automatically dials the number of your voicemail center.

**Erase:** clears the New Message icon and resets the counter for a new voice message, if necessary. The system resets the counter automatically after you listen to all of the new messages.

## Inbox *(Menu 3-3)*

Your phone can store SMS messages and their corresponding Caller ID in your UIM card and phone's memories. When your memory is full, the screen displays a text notification and rejects additional incoming messages until you erase the obsolete ones.

### Text messages

When the phone receives a text message, the New Text Message icon (✉) and a text notification with the call back number appear. Press the **Select** soft key to view the message immediately.

When you access the **Phone** menu (**Menu 3-2-1**) or **Card** menu (**Menu 3-2-2**), a list of the received message displays. An icon displayed in the list means the message's status:

- ✉ : displays when you have read the message.
- ✉ : means that the message is urgent.
- ✉ : indicates that a duplicated message.

While viewing the message list, press the Up or Down key to scroll to a message and:

- Press the **View** soft key to view the message you want. The phone displays the contents. If necessary, press the Up or Down key to scan through the message.

While viewing a message, press the **Menu** soft key to use the following options:

**Forward:** allows you to send the message to other people.

**Call/Save:** shows the sender's number of the message. Press the ☎ key to make a call to the

sender's phone number. Press the **Save** soft key to save it.

**Erase:** erases the message from your Inbox.

**To Card:** allows you to move the message from the phone's memory to the UIM card. This option is only available when you select a message stored in the phone's memory.

**To Phone:** allows you to move the message from the UIM card to the phone's memory. This option is only available when you select a message stored in the UIM card.

- While viewing a message, press the **Reply** soft key to send a reply message to the sender.
- Press the **Menu** soft key to access the following options:

**Erase:** allows you to erase the selected message.

**Erase Multi:** allows you to erase the messages you selected by pressing the **Check** soft key.

**Erase all:** allows you to erase all of the messages.

### Voice messages

When you receive a voice mail message, the text notification displays. Press the ☎ key, and the phone dials the voice mail center. Then follow the voice prompts from the system to listen to the message.

You can also check your voice messages by accessing the **Voice mail (Menu 3-2-3)**. For further details about the voice mail service and its availability, contact your service provider.

## Web alert messages



In this menu, you can view a web message from your web server. For details about reading a web message, refer to "Text Messages" on page 78.

## Sent *(Menu 3-4)*

---

Your phone can store your outgoing SMS messages in your UIM card and phone's memories.


When you access the **Phone** menu (**Menu 3-3-1**) or **Card** menu (**Menu 3-3-2**), you can see the message list. An icon displayed in the list means the message's status:

- : indicates that the message was successfully delivered.
- : indicates that the message was not sent.

While viewing the message list, press the Up or Down key to scroll to a message and:

- Press the **View** soft key to view the message you want. The phone displays the contents. If necessary, press the Up or Down key to scan through the message.

While viewing a message, press the **Menu** soft key to use the following options:

**Call/Save:** shows the destination number of the message. Press the  key to make a call to the recipient's phone number. Press the **Save** soft key to save it.

**Erase:** erases the message from your Outbox.

**To Card:** allows you to move the message from the phone's memory to the UIM card. This

option is only available when you select a message stored in the phone's memory.

**To Phone:** allows you to move the message from the UIM card to the phone's memory. This option is only available when you select a message stored in the UIM card.

- While viewing a message, press the **Resend** soft key to send the message to other people.
- Press the **Menu** soft key to use the following options:

**Erase:** erases the selected message.

**Erase Multi:** erases the messages you selected by pressing the **Check** soft key.

**Erase all:** erases all of the messages.

## Draft *(Menu 3-5)*

---

In this menu, you can review the messages your phone couldn't send.

For further details about viewing a message and using the options, see "Sent" on page xx.

## Saved *(Menu 3-6)*

---

Your phone can store draft messages that are yet to be sent in the Saved box. If you save the message contents before sending it, you can access them using this menu.

To review a stored message, press Up key or Down key to scroll to it and press **OK** soft key.

While reviewing a message, press **Menu** soft key to use the following options:

**Resend:** allows you to resend the message.

**Delete:** deletes the message from the Saved box.

## Web Alerts *(Menu 3-7)*

---

## Erase MSG *(Menu 3-8)*

---

Using this menu, you can erase all of the messages in each message box; Voice, Old Inbox, New Inbox, Outbox, Filed. You can also erase all of the messages at one time by selecting **All Messages**.

When a confirming message appears, select **Yes** and press **OK** soft key.

## MSG Setting *(Menu 3-9)*

---

Using this menu, you can set up various options for receiving or sending messages.

### Scroll Timer *(Menu 3-9-1)*

You can set the screen to scroll automatically or not.

1/3/5 seconds: If an incoming message is too long for the display, the phone displays it by scrolling the screen automatically. You can set the time when the phone scrolls to the next screen.

**Off:** It does not scroll automatically. You should scroll to next screen manually using up or down navigation key.

### MSG Reminder *(Menu 3-9-2)*

When a message is received, the phone alerts you by sounding the selected ringer. You can set how often you want to be alerted. Selecting **Off** means that the message alert sounds once when the message is received. Selecting **Once** means is received and sounds again after 2 minutes. Selecting **Every 2 min** means that the message alert sounds every 2 minutes.

### New MSG *(Menu 3-9-3)*

You can set up the following options as default setting when creating a new message.

**Save Message:** allows you to set whether you want the transmitted message to be saved in Outbox or not.

- **Do not save:** not to save automatically.
- **Prompt Save:** asks you to save it or not.
- **Auto Save:** save the message automatically.

**Entry Method:** You can select the text input mode between **T9 Word** and **Alphabet**.

### Canned MSG *(Menu 3-9-4)*

Your phone has 11 preset messages to enable you to use them when writing a new message. You can change them, if necessary.

You can also add up to 9 messages.

## Messages

1. Press the Navigation keys to highlight the message you want to change.

To add a new message, select an empty location.

2. Press the **Select** soft key.
3. Clear the existing message using the **C** key, if necessary, enter a new message.  
  
For further information on how to enter text, see page 39
4. Press the **OK** soft key to save the message.

## Planner

The Scheduler feature enables you to:

- keep track of important dates and events.
- set the phone to ring at a specified time.
- use the phone as a calculator.
- create a list of things to do or memos.
- check the current time in another part of the world.
- set and count down to a particular day or event.
- make a memo

**Note:** When you are out of your service area, you cannot use some of the features in the **Scheduler** menu.

### Today *(Menu 4-1)*

---

This menu allows you to schedule new events for the current day, indicating each event's start and end time. Events scheduled for future dates automatically appear on your Today display for that particular day.

For further details about scheduling and viewing events, refer to "Calendar" on page 85.

### Scheduler *(Menu 4-2)*

---

This menu allows you to view the current month, as well as the past or future month in the calendar format. You can be alerted by the Calendar function before an event commences. When you access this

menu, today's date is automatically selected the date in lunar calendar displays on the bottom.

**Note:** You can quickly access this menu by pressing the Right key in Standby mode.

### Selecting a day on the calendar

- You can move to the next or the previous day by pressing the Left or Right key.
- You can move up or down the Calendar one week by pressing the Up or Down key.
- To display the next or previous month, use the Volume keys on the left side of the phone.

On the Calendar screen, press the **Menu** soft key to use the following options:

**View:** allows you to view the scheduled events of the day.

**Add new:** allows you to add a new event on the selected day.

**Jump to date:** allows you to specify the date you want to access.

### Scheduling an event

You can schedule up to 9 events for one day and 20 events total.

1. Select a day from the calendar, referring to "Selecting a day on the calendar" on page 86, and press the **OK** soft key.
2. Enter your event contents and press the **OK** soft key.

For more information about how to enter characters, see page 39.

3. Enter the start time and date using the numeric keys and press the Down key.

#### Notes:

- You need to enter the time in 24-hour format.
- You can move through the input fields using the Left or Right key.

4. Enter the end time and date using the numeric keys and press the Down key.
5. Specify when an alarm will inform you of your event by pressing the Left or Right key. If you select **No alarm**, the phone does not ring the alarm.
6. Press the **Save** soft key to save your event.

### Viewing your schedule

Days with scheduled events are seen in a rectangle on the calendar when you access the **Calendar** menu (**Menu 4-1**). Select one of them and press the **OK** soft key. The first of the events for date appears.

Highlight to the event you want to view by pressing the Left or Right key. If necessary, press the Down key to display the end time of the event.

While viewing an event, press the **Menu** soft key to use the following options:

**Add new:** adds a new event.

**Edit:** edits the selected event.

**Erase:** erases the selected event.

**Erase All:** erases all of the events.

## Task List *(Menu 4-3)*

This feature allows you to enter up a list of tasks you need to do and assign both a priority and a deadline to them. You can store up to 20 tasks.

### Creating a to-do item

1. Enter the task contents and press the **OK** soft key.

For more information about how to enter characters, see page 39.

2. Select High or Low priority using the Left or Right key and press the Down key.
3. Enter the time and the date when your task needs to be done using the numeric keys.

#### Notes:

- You need to enter the time in 24-hour format.
- You can move through the input fields using the Left or Right key.

4. Press the **Save** soft key to save the task.

### Viewing a task

When you access the **To Do List** menu (**Menu 4-5**), the list of tasks displays along with deadline and the associated priority highlighted: ★ for high priority or ★<sub>2</sub> for low priority.

Scroll to the task you want to view by pressing the Left or Right key.

While viewing a task, press the **Menu** soft key to use the following options:

**Add new:** adds a new task.

**Edit:** edits the selected task.

**Erase:** erases the selected task.

**Erase All:** erases all of the tasks.

## Memo Pad *(Menu 4-4)*

This feature allows you to make memos of important things you need to remember.

### Writing a new memo

1. Enter what you need to remember.

For further details on how to enter characters, see page 39

2. Press the **OK** soft key to save the memo.

### Viewing a memo

The list of your memos displays when you access the **Memo Pad** menu (**Menu 4-8**).

To view details, press the Navigation keys to scroll to the memo you want to view from the list and press the **Select** soft key.

On the Memo pad list, press the **Menu** soft key to use the following options:

**Add new:** adds a new memo.

**Edit:** edits the selected memo.

**Erase:** erases the selected memo.

**Erase All:** erases all of memos.

## Alarm *(Menu 4-5)*

This menu allows you to set the alarm to ring at a specific time.

To set the alarm:

1. Select the alarm frequency option by pressing the Navigation keys.
  - **Once**: The alarm rings only once and is then deactivated.
  - **Daily**: The alarm rings everyday at the same time.
2. Press the **Save** soft key.
3. Enter the time for the alarm to ring by using the numeric keys.

### Notes:

- You need to enter the time in 24-hour format.
- You can move through the input fields using the Left or Right key.

4. Press the **Save** soft key.

To stop the alarm when it rings, simply open and close the phone or press any key.

To deactivate the alarm, access the **Alarm** menu, and select **Off** and press the **Save** soft key.

## Calculator *(Menu 4-6)*

Using this feature, you can use the phone as a calculator. The calculator provides the basic arithmetic functions; addition, subtraction, multiplication, and division.

To perform a calculation:

1. Enter the first number using the numeric keys.
 

**Note:** Use the **✕** key to enter a decimal point and the **#** key to change the sign of a number to a negative (-).
2. Select the operation for your calculation by pressing the Navigation keys according to the illustration on the display; + (add), - (subtract), **x** (multiply), ÷ (divide).
3. Enter the second number.
4. To get the result, press the **OK** soft key.
5. Repeat steps 1 to 4 as many times as required.

## World Time *(Menu 4-7)*

You can use this menu to find out what time it is in another part of the world and apply the DST (Daylight Saving time).

Press the Navigation keys to scroll to the time zone you want to check.

To apply the daylight saving time:

1. After selecting the time zone you want to apply the DST, press the **DST** soft key.
2. When a confirmation message appears, select **Yes** and press the **Select** soft key. The DST icon appears on the right side of time.

## Countdown *(Menu 4-8)*

---

This menu helps you know how much time it takes for you to do something or how many months, days, hours, and/or minutes until a specific event occurs. You can create up to 20 Countdown timers using this feature.

### Creating a countdown timer

1. Enter a name for your Countdown timer and press the **OK** soft key.

For more information about how to enter characters, see page 39.

2. Enter the time and date from which you want to count down.

**Notes:**

- You need to enter the time in 24-hour format.
- You can move through the input fields using the Left or Right key.
- You can enter between 1981 and 2099 for the year.

3. Press the **Save** soft key to save the timer.

### Viewing a countdown timer

The list of Countdown timers displays when you access the **Countdown** menu (**Menu 4-7**).

Scroll to the timer you want to view by pressing the Left or Right key.

While viewing a timer, press the **Menu** soft key to use the following options:

**Add new:** creates a new timer.

**Edit:** edits the selected timer.

**Erase:** erases the selected timer.

**Erase All:** erases all of timers.

## Set Time *(Menu 4-9)*

---

To display the correct date and time on the idle screen or to use the Planner features, such as Today, Scheduler, Task List, Alarm, World Time and Countdown, you need to set the current time and date using this menu.

Enter the time and date using the numeric keys.

The minute, hour, month and day each must be entered using 2 digits and the year requires all 4 digits. You need to enter the hour in 24-hour format.



## Voice Tools

In this menu, you can use the phone's voice features, allowing you to:

- record a voice memo.
- set the phone to answer a call and record the caller's message.

### Voice Memo *(Menu 5-1)*

---

#### Record *(Menu 5-1-1)*

You can record up to voice memos of 4 minutes total. This feature shares the memory with the Voice Answer feature and the amount of time for memos are dependent on the available memory less any callers' messages; for example, if your phone has the callers' messages of 4 minutes total, you cannot record any voice memo.

1. Record a memo by speaking to the microphone.

When you are recording, a timer displays to show you the elapsed time.

You can pause recording by pressing the **Pause** soft key and then resume by pressing the **Resume** soft key.

2. Press the **End** soft key to end recording. The screen provides you with the following choices. Scroll to an option and press the **OK** soft key.
  - **Listen**: allows you to review the voice memo. The screen displays the length of the memo along with the date and time.

- **Rerecord**: allows you to discard the current memo and record another one.
- **Save**: allows you to save the voice memo.
- **Quit**: allows you to quit recording the memo and exit the **Record** menu.

3. When you are satisfied, select the **Save** option and press the **OK** soft key.
4. Enter a title for the memo and press the **OK** soft key.

#### Listen *(Menu 5-1-2)*

When a list of your voice memos displays, scroll to the memo you want to review and press the **OK** soft key. The phone plays back the memo.

On the memo list, press the **Menu** soft key to use the following options:

**Play**: plays back the memo.

**Erase**: erases the selected memo.

**Info**: shows detailed information about the memo, such as title, length, memory size and date and time when the memo was recorded.

#### Erase All *(Menu 5-1-3)*

This menu allows you to erase all of the voice memos and voice answers. When a confirming message displays, select **Yes** and press the **OK** soft key.

## Voice Answer *(Menu 5-2)*

If you are not able to answer an incoming call, you can set your phone to answer a call with the default greeting message and record the caller's message. As this feature shares the memory with voice memos, the total length of messages is dependent on the available memory less any voice memos.

### On/Off *(Menu 5-2-1)*

This option allows you to enable or disable the answering machine mode.

### Inbox *(Menu 5-2-2)*

You can listen to the callers' messages recorded in your phone. When you access this option, a list of the recorded messages appears.

**Note:** If the phone has the callers' messages waiting to be checked, it displays the total number of the messages when the last message was recorded.

On the message list, press the **Menu** soft key to the following options:

**Play:** plays the selected message.

**Erase:** erases the selected message.

**Info:** shows detailed information about the message, such as caller's number if identified, elapsed time, memory size and date and time when the message was recorded.

**Dial:** places a call to the caller's number, if identified.

**Erase All:** erases all of the voice memos and voice answers.

### Setting *(Menu 5-2-3)*

You can change the settings for the voice answer mode.

The following options are available:

**Greeting:** Your phone provides you with the default greeting message to be played when a call comes in. You can also record your own greeting message.

To record a greeting message:

1. Select Record and press the **OK** key.
2. Wait until a beeping prompt sounds and record a greeting message by speaking into the microphone.

You can pause recording by pressing the **Pause** soft key and then resume by pressing the **Resume** soft key.

3. When recording is complete, press the **OK** soft key. The phone automatically saves and activates the message.

If you want to play back the currently selected message, highlight **Play** and press the **OK** soft key.

To enable or disable your own greeting message:

1. Highlight **Select** and press .
2. Select **My Message** to use your message or **Default** to use the default message.

3. Press the Save soft key to save your selection.

**Note:** Once you have recorded your own message and then have changed the greeting to the default message, your message is deleted.

**Screening:** allows you to enable or disable the screening speaker which allows you to listen to the caller's message while the caller is leaving it.

**Wait Time:** allows you to set how long the phone waits before answering a call with the greeting message. Selecting **Immediate** means that the phone plays back the message as soon as a call comes in.

## Sounds

You can use the Sounds menu to customize various sound settings, such as the:

- ringer volume, type, and tone.
- key tone and alert sounds.
- sound which plays when the phone is switched on or off.

### Ringer Volume *(Menu 6-1)*

---

This menu allows you to adjust the ringer volume.

**Calls:** allows you to adjust the ringer volume for incoming voice calls.

**Messages:** allows you to adjust the ringer volume for incoming messages.

**Alarms:** allows you to adjust the ringer volume for alarm settings.

Press the Navigation keys to adjust the volume level or select a ringer type. The following options are available:

- Silent: the phone does not sound a ring.
- Vibrate: the phone switches to the vibration mode. An incoming call vibrates the phone.
- 1-Beep: the phone sounds a beep.
- Level 1 ~ 8: adjust the volume level. The more bars, the louder the volume.
- High+Vib: the phone rings in the highest volume level and then vibrates.

**Note:** The options available may be different depending on the selected ringer item.

## Ringer Type *(Menu 6-2)*

---

This menu allows you to set the unique ringer melodies for the following items:

**Voice Calls:** allows you to set a unique ringer for incoming voice calls.

**Messages:** allows you to have a distinctive ringer for incoming voice mail, text messages independently.

**Data/Fax:** allows you to be alerted with a distinctive ringer when you receive data or fax calls through the phone. This feature may not be available depending on your network.

**Schedule:** allows you to have a distinctive ring for schedule settings.

## Key tone *(Menu 6-3)*

---

Using this menu, you can set up the keypad tone that the phone sounds when you press a key.

The following options are available:

**Type:** allows you to select a tone that the phone sounds when you press a key. Choose one of **Man(Heb)**, **Lady(ENG)**, **Rain Drop** and **Beep**.

**Volume:** allows you to adjust the volume of the keypad tone using the Navigation keys or the Volume keys on the left side of the phone.

## Alerts *(Menu 6-4)*

---

Your phone gives audible alerts (beeps) at a specified time to inform you that certain things have happened. The alerts only occur in your earpiece so that the other person does not hear them.

The available alerts are:

**Minute Beep:** When this option is set to **On**, the phone sounds an alert 50 seconds before each elapsed minute to remind you of the length of the current call.

**Service Alert:** When this option is set to **On**, the phone sounds an alert when you exit service area or when you return to a service area.

**Connect:** When this option is set to **On**, the phone sounds the connect tone when your call is connected to the system.

**Disconnect:** When this option is set to **On**, the phone sounds the disconnect tone when a call is disconnected.

**Fade:** When this option is set to **On**, the phone sounds an alert when a dropped call occurs during conversation in response to a signal fade.

## Roam Ringer *(Menu 6-5)*

---

data required!

### Tone Length *(Menu 6-6)*

---

You can select **long** or **normal** DTMF (Dual-tone Multi-frequency) tones. DTMF tones are sent by your phone to access teleservices, such as a bank account. The system used by the bank or other service determines if you need short or long DTMF tones. If the service is digital, as most are, short DTMF tones will almost always work.

### Power On/Off *(Menu 6-7)*

---

You can turn on or off the tone that the phone sounds when it is switched on or off.

Choose **On** to use the power on/off sound or **Off** not to use it.

## Display

The Display feature enables you to:

- change the display style of the menus.
- select a wallpaper image for the idle screen, or an image to be displayed when you turn on or off your phone.
- change the display language.
- set the length of time for the backlight.
- set a banner message.
- select the time zones for the dual clock.
- turn the service LED on or off.
- adjust the screen contrast of LCD screens.

### Menu Style *(Menu 7-1)*

---

This menu allows you to select the menu display style.

You can choose either **Camera** or **Nature**.

### Wall Paper *(Menu 7-2)*

---

This menu allows you to set an image as a wallpaper for the idle screen. You can also set an image to be displayed when you turn on or off the phone.

When you select **Dual Clock**, the phone displays the analog clocks for the two time zones selected in the **Dual Clock** menu (**Menu 7-5**). See page xx.

## Language/שפה (Menu 7-3)

Sets the language of menus and key-input.

Select the desired language by pressing navigation keys.

The available languages are English and שפה.

## Backlight (Menu 7-4)

You have several options for setting how the LCD backlight operates. Remember that backlight use drains your battery faster.

The following options are available:

**8/30 seconds:** The backlight switches on when you press a key and switches off 8/30 seconds after that. Then the display turns off after 52/30 seconds.

## Banner (Menu 7-5)

This menu allows you to set a banner message to be displayed at the bottom of the display in Standby mode.

1. If necessary, press the **C** key to delete each letter of the old greeting. Press and hold to clear the display.
2. Enter your banner message. For further details about how to enter characters, see page xx.
3. When you finish entering the message, press to save the new banner.

## Dual Clock (Menu 7-6)

You can choose two time zones to be displayed when you select **Dual Clock** for the Idle mode image; for details, see page xx.

To select time zones for the dual clock:

1. When **Location** highlights, press the Down key.
2. Select the time zone for the first clock by pressing the Left or Right key, and press the Down key.
3. Select the time zone for the second clock by pressing the Left or Right key.
4. Press the **OK** soft key to confirm the selection.

To apply the daylight saving time:

1. When **Location** highlights, press the Left or Right key to display **DST**. Press the Down key.
2. Select **Yes** to use the daylight saving time for the first clock. Otherwise, select **No**.
3. Press the Down key and repeat step 2 for the second clock.
4. Press the **OK** soft key to confirm the selection.

## Service LED (Menu 7-7)

This menu allows you to select whether or not the service light is used.

## Contrast (Menu 7-8)

The menu allows you to adjust the brightness of the main LCD screens.

Press right or up navigation key to make the screen brighter, and left or down navigation key to make the screen darker.

Each time you press the key, you will see the selected status of the LCD.


Press the **Save** soft key to save your setting.

## Games

Using the **Games**, you can enjoy games using your phone.

**Note:** You can quickly enter this menu by pressing Up key in Standby mode.


To start a game:

1. Press the Navigation keys to scroll to one of the games and press the **Select** soft key.
2. Press any key except for the  key and Volume keys.

The phone displays the following options:

- **NEW GAME:** allows you to start a new game.
- **HIGH SCORE:** shows you the high score table.
- **HELP:** gives you the information about how to play the game.
- **KEY INFO:** gives you the key helper screen to play the game.
- **CONTINUE:** allows you to continue the last game you played. This option is activated only when you have played a game.

3. While playing a game:

To	Press the
pause/resume the game	<b>C</b> key.
exit the game	 key.

### Chicken Run *(Menu 8-1)*

The goal of this game is to move eggs or chicks to the destination carefully.

When you select **NEW GAME** menu, the first screen displays two menus.

Select **START** menu to start a new game.

Select **OPTION** menu to change following options.

**DIFFICULTY:** allows you to change the game's level of difficulty.

**SOUND:** allows you to turn the game sound on or off.

**VIBRATION:** allows you to turn the vibration on or off.

← : allows you to exit the current screen.

Once the game starts, you need to control blue and red control items to move eggs or chicks carefully. To control the blue items, press **1** or Left key, and press **3** or Right key for the red ones. When you complete the given aims, the level goes up and the speed goes up.

### Mobile Cop *(Menu 8-2)*

The goal of this game is to shoot the enemies.

When you select **NEW GAME** menu, the first screen displays three menus.

Select **START** menu to start a new game.

Select **OPTION** menu to change following options.


**SOUND:** allows you to turn the game sound on or off.

**VIBRATION:** allows you to turn the vibration on or off.

← : allows you to exit the current screen.

Select **HELP** menu to see the simple guide.

Once the game starts, enemies in red appear at target position. Check the position and press appropriate number key to shoot the enemy.



Sometimes enemies hold hostages, If you shoot the hostage, you will lose the bonus points.

After running out of the bullets, press **7**, **8** or **9** to reload them.

Whenever you kill all the enemies for one stage, you can go to the next stage.

# Set up

## Set up


Many different features of your phone can be customized to suit your preferences.


### Call Answer *(Menu 9-1)*

---

This menu allows you to select how to answer an incoming call.

The following options are available:

**Any Key:** The phone answers when you press any key except for the  key and the volume keys.

**SEND Key:** The phone answers only when you press the  key.

### Auto Key Lock *(Menu 9-2)*

---


This function prevents that user pushes keys without intention.


The following options are available:

**15/30 Seconds, 1 Minute:** When the phone is in standby mode, the Key Lock mode switches on 15/30 seconds or 1 minute after the last key is pressed.

If you don't want to use this feature, select **Off**.

When the alarm occurs or the call is received, the Key Lock mode is disabled.

Once Key Lock mode is activated, you can temporarily unlock your keypad by pressing the **Menu** soft key and the  key.

**Note:** You can lock the keypad manually by pressing and holding the  key in Standby mode.

### Auto Retry *(Menu 9-3)*

---

When this menu is activated, your phone automatically redials the call up when a connection fails.

To activate this feature, select how often the phone will automatically retry the call; **60 Seconds**, **30 Seconds**, and **10 Seconds** are available.

To deactivate the feature, select **Off**.

### Select NAM *(Menu 9-4)*

---

NAM stands for Numerical Assignment Module, essentially your phone number. Your phone can have two NAMs. this means that you can have two phone numbers for using your phone and can quickly and easily switch your service back and forth between the two numbers.

**Note:** This Option may not be available on your network.

## Set System *(Menu 9-5)*

Roaming is a feature which is only relevant in areas where there are at least two cellular service providers having valid roaming agreements. Roaming allows you to register your phone on one of the networks, but use the facilities of the other if your own network is not available. This system priority feature allows you to program your phone for optimum operation within or outside your home service area.

You should always check your phone's display because it will let you know when you're outside the service provider network and whether your phone is operating in another network; the roaming icon (📶) appears.

You have the following options which allows you to control the phone's roaming ability:

**Home only:** With this setting, you cannot roam. If your home system is not available, your call will not be connected and the No Service indicator (📶) displays.

**Standard:** Your phone automatically search for a first available one of all types of service according to the Preferred Roaming List supplied by the service provider.

## Data/Fax *(Menu 9-6)*

Your phone is capable of sending and receiving digital data and fax call when connected to a computing device (laptop, desktop, handheld, palmtop, etc) running Windows95, Windows 98,

Windows NT or later versions. The phone functions just like a typical modem on your PC, enabling you to use wireless data involving a wide variety of Windows software applications.

To use digital data or fax services with your phone, you will need to obtain a digital data/fax kit from your service provider. This kit contains the necessary cables, software, and user's guide required for your to connect and use your phone with your computing device.

**Note:** The phone must be on a digital network to receive or send faxes and data.

The following options are available:

**Voice Call Only:** Your phone receives voice calls only.

**Fax in Only:** Your phone receives fax calls only.

**Data in Only:** Your phone receives data calls only.

### Receiving a Fax or Data File

To receive a fax or data, ensure that your phone is connected to your PC and is powered on. Select one of the Data/Fax options. When you receive a fax call, set up the **Answer** mode in the fax program on your PC and click on **Receive** and select one of the following:

- Automatic Receive (recommended)
- Manual Receive

### Sending a Fax or Data File

When connected to a computing device, your phone allows wireless fax and data transmissions. Your computing device software initiates the call to the

destination phone number. The phone functions as a wireless modem to send the fax or data file to the number designated by your PC software.

## Version *(Menu 9-7)*

This menu allows you to view the software and hardware versions of your phone. This feature is helpful if you need to call customer care.

## Security *(Menu 9-8)*

Your phone provides you with many security options, including a user-programmable lock code.

To access the **Security** menu, you need to enter a lock code. The lock code is preset to "0000" at the factory.

### Lock Phone *(Menu 9-8-1)*


When the phone is locked, you cannot operate the phone until you enter the lock code.


The following options are available:

**Unlock:** The phone remains unlocked.

**On Power-Up:** The phone locks automatically the next time you turn it on.

**Lock Now:** The phone locks immediately.

To place an emergency call, enter the number and then press the  key. The phone recognizes 4 stored and 3 empty emergency numbers in the **Emergency #** menu (**MENU 9-8-3**). See page xx.

To unlock the phone, press one of the soft keys, volume keys, navigation keys, VAS key, or  key and enter the lock code. The phone returns to Standby mode.

### Lock Code *(Menu 9-8-2)*

This feature allows you to change your current lock code to a new one. The lock code is preset to "0000" at the factory.

Enter a new, four-digit lock code.

### Restriction *(Menu 9-8-3)*

This feature allows you to restrict the use of your phone.

### Emergency # *(Menu 9-8-4)*

Your phone provides you with the option for storing three emergency numbers. The default numbers are 100, 101, 102, and \*166. All of these numbers can be manually dialed at any time.

### IMPORTANT NOTICE!

Emergency calling may not be available on all wireless networks at all times. A connection cannot always be guaranteed, due to various transmission

methods, network parameters and user settings used to complete a call from your wireless phone.

DO NOT depend on this phone as a primary method of dialing 100 or for any other essential or emergency communications.


Remember to always turn your phone on and check for the adequate signal strength before placing a call.

To store an emergency number:

1. Press the Up key or Down key to select a location and press the **OK** soft key.
2. If necessary, press and hold the **C** key to clear the old number.
3. Enter the number you want.

Each emergency number can be up to 32 digits long.

4. Press the **Save** soft key to store the number.

To make an emergency call in the lock mode, simply enter a programmed number, and then press the  key.

**Note:** Emergency number which assigned 1 to 4 would not be edited.

### Erase Pbook *(Menu 9-8-5)*

This feature allows you to clear all of the numbers in your Phone Book.

When a confirming message displays, select **Yes** and press the **OK** soft key.

### Reset Phone *(Menu 9-8-6)*

Resetting the phone cancels all of your selection in the user-selectable setting options and returns them to the factory default settings.

When a confirming message displays, select **Yes** and press the **OK** soft key. The phone turns itself off and back on, then returns to Standby mode.

This menu allows you to use a variety of services supplied by your service provider, such as the:

- WAP browser
- Voice portal service
- SMS information service

**Note:** You can quickly access this menu by pressing the **i** key in Standby mode.

## Internet Portal (Menu **i** -1)

Your phone is equipped with a WAP (Wireless Application Protocol) browser which allows you to access and navigate the wireless web.

Selecting the **Internet Portal** menu launches the WAP browser. Once you are connected to the network, the homepage of your service provider.

## Navigating the browser

To	Press
Scroll through browser items	Up and Down keys.
Scroll through browser items by one page	Volume keys.
Choose an item	✓ soft key, or press the <b>Menu</b> soft key and select <b>Done</b> .

To	Press
Return to the previous page	<b>Dismiss</b> or <b>Cancel</b> soft key.
Access browser menus	<b>Menu</b> soft key and select <b>Browser menu</b> . For details about each option, see "Using the browser menus".
Exit the browser	☎ <sup>⓪</sup> key.

## Entering text in the browser

When you are in a text input field, you can use the following input mode; to change the input mode, press the **abc** soft key and select a mode:

**Hebrew:** allows you to enter Hebrew letters as you would in ABC mode.

**Sym:** allows you to enter symbols or punctuation marks.

**Number:** allows you to enter numbers.

**English:** allows you enter English characters by pressing the key one or more times until the letter you want appears.

## Using the browser menus

When you access the browser menu list, the following options are available:

**Back:** goes back to the previous page.

**Home:** accesses the homepage.

**Exit:** exits the browser.

**Bookmarks:** allows you to make a bookmark for the current page, or use the bookmark list to quickly access a page.

**Go To URL:** allows you to enter a URL address of the web page you want to access.

**Show URL:** shows the URL address of the current page.

**Reload:** refreshes the current page using the updated information.

**Settings:** provides you with further options.

Homepage: allows you to change the startup homepage manually.

Downloads: allows you to download image or sound items on the current web page.

Restart Browser: restarts the browser without exiting it.

Delete Cookies: deletes all of the cookies and files. A cookie is a piece of user's information that is entered when you use a web site.

View Title Region: allows you to set whether or not the browser shows the title of a web page.

Scroll Mode: lets you set the scroll mode to either **Block** or **Smooth**, or set the speed for scrolling to the next screen, to either **Fast**, **Medium**, or **Slow**.

Send Referrer: allows you to set the browser to send HTTP referrer information to the web server each time the browser is launched.

Key Press Timeout: allows you to set how long the phone waits after you have pressed a key in the text entry mode before moving the cursor to the right. You can select **Fast**, **Medium**, or **Slow**. If you don't want to set the timeout, select **Off**.

Connection Timeout: allows you to set how long the phone keeps connection to the current web page when you don't use the web page. You can select **30seconds** or **60seconds**.

Security: displays all security-related information, such as Secure Prompt, Authentication, and Current Certificate.

**About:** shows the WAP browser version and copyright, encryption, and certificate information.


## Games & App. (Menu -2)

In this menu, you can use Brew applications. On the main screen of the menu, there are three default applications available:

- **MobileShop:** allows you to buy and download Brew applications from the WAP browser.
- **Settings:** allows you to change the application settings and to check the memory status.
- **Help:** gives you help for using applications.

**Note:** You can quickly access this menu by pressing the Down key in standby mode.

### Downloading multimedia files

1. Press  when the **MobileShop** icon is selected.

The following options are available:

- **Catalog:** allows you to browse and purchase application.
- **Search:** allows you to search for an application by entering a keyword.
- **About Download:** provides you with the help information about using the **MobileShop** menu.

2. Press  when the **Catalog** option is selected.

You are accessed to the associated web site preset by your service provider and you can browse available applications.

3. Select the application you want to download and follow the instructions on the screen.


Downloaded applications will display on the main screen of the **Brew** menu.

## Changing the application settings

1. Select the **Settings** icon using the Left or Right key and press the **OK** soft key.
2. Select a setting option using the Up or Down key and press the **OK** soft key.

The following options are available:

- **Order Apps:** allows you to change the order of the downloaded applications.
- **Move Apps:** allows you to move an application to another folder.
- **Manage Apps:** shows the amount of the memory used for downloaded applications.
- **Main Menu View:** allows you to change the view mode of the main menu screen.
- **Screen Savers:** allows you to use one of screen savers downloaded.
- **View Log:** shows the records of your browsing and downloading.

3. When you have finished, press the **C** or  key.

## Viewing help information

1. Select the **Help** icon using the Left or Right key and press the **OK** soft key.
2. Select a help item using the Up or Down key and press the **OK** soft key.
3. Press the Up or Down key to scroll through the information.
4. To go back to the main help screen, press the **OK** soft key or **C** key.

## Ringtone *(Menu **i** -3)*

---

In this menu, you can download ring tones and melodies from the WAP browser and play the downloaded contents.

### Download New Ringtone *(Menu 8-3-1)*

Selecting this menu loads the WAP page preset by your service provider so that you can download a variety of ring tones and melodies.

### Saved Ringtones *(Menu 8-3-2)*

In this menu, you can review ring tones or melodies you have downloaded.

Scroll to the item you want and press the **Save** soft key to play it.

To remove the item, press the **Erase** soft key.

**Note:** You can also access the **Ringer** menu (**Menu 7-1-1**) to use or erase the downloaded ring tones.

## Animation *(Menu **i** -4)*

---

In this menu, you can download animation images from the WAP browser and play the downloaded contents.

### Download New Animation *(Menu **i** -4-1)*

Selecting this menu loads the WAP page preset by your service provider so that you can download a variety of animation images.

## Saved Animation *(Menu **i** -4-2)*

In this menu, you can review animated images you have downloaded.

Scroll to the item you want and press the **Select** soft key to play it.

To remove the item, press the **Erase** soft key.

**Note:** You can also access the **Image box** menu (**Menu 7-2-1**) to use or erase the downloaded animation items.

## Voice Portal *(Menu **i** -5)*

---

This menu allows you to access your service provider's voice-activated service. You can get headline news, get information on movies, the weather, finance, traffic, or restaurants in many cities, plus other features; it's similar to the kind of content that's available on a web portal.

**Note:** Voice Portal is a network feature. Please contact your service provider for further details.

## SMS INFO *(Menu **i** -6)*

---

You can send an SMS query to receive information you want from the web server. A variety of topics are available, such as news, sports, entertainment, fun, finance, and astrology.

Once you select a topic, your phone sends a query with the code associated with the selected topic, and the server will send you the requested information in an SMS message.

## GPS *(Menu **i** -7)*

---

From the **GPS** menu, you can access the GPS feature, which is a handset-based positioning technology, provided by your service provider.

To determine a location, the phone sends and receives signals to and from a location server on the network. After taking readings from GPS satellites and nearby cellular base stations, the server will perform calculations and tell the phone the appropriate position information.

## Voice Navigation *(Menu **i** -7-1)*

You can use the Voice Navigation service, which guides you by voice to your destination, from your current position.

When you select this menu, the preset number of the service dials. Follow the voice prompts from the network.

## Speed Traps Detector *(Menu **i** -7-2)*

You can use the Speed trap detection service, which alerts you to fixed speed camera traps or laser traps, according to your current position.

Selecting this menu dials the preset number of the service and activates the detection service for you. The alert will come in as an incoming call. When you answer the call, the system alerts you to the presence of the speed trap.

## Where Is My Kid *(Menu **i** -7-3)*

Using this menu, you can use the GPS child locator, which enables you to track your child via the Wireless Web.

Selecting this menu loads the preset website and then you can register the number of the phone you want to track. For further details, contact your service provider.

## Emergency Button *(Menu **i** -7-4)*

When in trouble, you can place an SOS call to the emergency center by selecting this menu.

Even if you cannot provide any information on your location, the emergency center pinpoints your position and sends the emergency service to you.

**Note:** This service is available 24 hours a day.

## What's new? *(Menu **i** -8)*

---

Selecting this menu loads the WAP page preset by your service provider so that you can get information about your service provider's latest offerings, such as downloads, pricing plans, entertainment, technical help, and customer services.

## Health and safety information

### Health and safety information

### Exposure to radio frequency (RF) signals

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on the safety standards that were developed by independent scientific organizations through periodic and through evaluation of scientific studies.

The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless phones employs a unit of measurement known as Specific Absorption Rate (SAR). The SAR limit set by the FCC is 1.6W/kg.\*

\*\* .In the U.S. and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

The highest SAR values for this model phone as reported to the FCC are Head: 1.12W/Kg, Body-worn: 1.23W/Kg in CDMA 800MHz. Body-worn operations are restricted to Samsungsupplied, approved or none Samsung designated accessories that have no metal and must provide at least 1.5cm separation between the device, including its antenna whether extended or retracted, and the user's body. None compliance to the above restrictions may violate FCC RF exposure guidelines.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID A3LSCHX799.

## For body operation

To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 1.5 cm. separation distance between the user's body and the back of the phone, including the antenna. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

For more Information concerning exposure to radio frequency signals, see the following websites:

Federal Communications Commission (FCC) <http://www.fcc.gov/oet/rfsafety>

Cellular Telecommunications Industry Association (CTIA): <http://www.wow-com.com>

U.S.Food and Drug Administration (FDA) <http://www.fda.gov/cdrh/consumer>

World Health Organization (WHO) <http://www.who.int/peh-emf/en>

## Precautions when using batteries

- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.

- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).
- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and – terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.
- Dispose of used batteries in accordance with local regulations. Always recycle. Do not dispose of batteries in a fire.

## Road safety

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, make sure that you are following the special regulations in a given area or country.

## Operating environment

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger.

When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

## Electronic devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

## Pacemakers

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on
- Should not carry the phone in a breast pocket
- Should use the ear opposite the pacemaker to minimize potential interference

If you have any reason to suspect that interference is taking place, switch your phone immediately off.

### Hearing aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may wish to consult your hearing aid manufacturer to discuss alternatives.

### Other medical devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

### Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment that has been added to your vehicle.

### Posted facilities

Switch your phone off in any facility where posted notices require you to do so.

### Potentially Explosive Environments

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch off the phone while at a refuelling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.


Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

## Emergency calls

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.
2. Key in the emergency number for your present location (for example, 100 or any other official emergency number). Emergency numbers vary by location.
3. Press .

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

## Other important safety information

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your phone off before boarding an aircraft. The use of wireless phones in aircraft may be dangerous to the operation of the aircraft, and is illegal.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

## Care and maintenance

---

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children's.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.

- Do not put the phone in or on heating devices, such as a microwave oven, a stove or a radiator. The phone may explode when overheated.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

**Air time**

Actual time spent talking on the wireless phone. Most carriers bill customers based on how many minutes of airtime they use each month.

**Antenna**

A device for transmitting or receiving signals. The size and shape of antennas is determined, in part, by the frequency of the signal they receive. Wireless phones and the base station must have antennas.

**Call diverting**

Ability to reroute calls to another number.

**Call waiting**

Informs you that you have an incoming call when you are engaged on another call.

**Caller line identification services** (Caller ID)

Services allowing subscribers to view or block the telephone numbers of callers.

**CDMA** (Code Division Multiple Access)

A spread-spectrum approach to digital transmission. With CDMA, each conversation is digitized and then tagged with a code. The mobile phone deciphers only a particular code to pick the right conversation off the air. The transmitted signal is just above noise level across the available bandwidth.

**Deactivation**

The process of rendering a wireless phone inactive.

**DTMF**

You send DTMF signals when you enter numbers by pressing the digit keys.

**Frequency**

A measure based on time, as one or more waves per second, in an electrical or light wave information signal. A signal's frequency is stated in cycles-per-second or Hertz (Hz).

**LCD** (Liquid Crystal Display)

Commonly used to refer to the screen display on the wireless phone.

**Prepend**

The addition of a prefix, such as an area code, to a phone number.

**Roaming**

The ability to use a wireless phone to make and receive calls in places outside of the home service area.

**Service charge**

The amount paid each month to receive wireless service.

**Standby time**

The amount of time a fully charged wireless portable or transportable phone can be on and idle without being in use. (See Talk Time)

## Glossary

### **Talk time**

The length of time a person can talk on a portable or transportable wireless phone without recharging the battery.

### **Wireless**

Radio-based Systems that allow transmission of telephone or data signals through the air without a physical connection, such as a metal wire (copper) or fiber optic cable.



# Index

## B

Battery  
charging • 18

## C

Care • 130  
Charging battery • 18

## D

Display  
icons • 12

## F

Flashlight • 16

## I

Icons, description • 12

## K

Keys  
description • 10  
location • 9

## M

Maintenance • 130

## P

Phone  
display • 12  
icons • 12  
keys • 10  
layout • 9  
unpacking • 8

## S

Safety

precautions • 6  
Service light • 15

## I

Icons, description • 12

## K

Keys  
description • 10  
location • 9

## M

Maintenance • 130

## P

Phone  
display • 12  
icons • 12  
keys • 10  
layout • 9  
unpacking • 8










## S

Safety  
precautions • 6  
Service light • 15



## SCH-X799 Quick reference card

SAMSUNG

Basic Operation		Internal Phonebook
Make a call	Phone number + 	Store a new number into memory
End a call		
Receive a call	 or open the phone	
Adjust the key volume	(in Standby mode)   on the left side	
Adjust the voice volume	(during a call)   on the left side	
Redial the last call	 twice or Hold 	Speed dial
Switch to Silent mode	(in Standby mode) Hold #	Location number + hold the last digit
		Find + Up/Down/Left/Right + OK

Main Menu (To access, press the Menu soft key)			
1: Calls	1: Outgoing 2: Incoming 3: Incoming 4: Erase History 5: Air Time	5: Voice Tools	1: Voice Memo 2: Voice Answer
2: Phone Book	1: Find 2: Add New Entry 3: Group Setting 4: My Phone # 5: Memory Info 6: Call Forward	6: Sounds	1: Ringer Volume 2: Ringer Type 3: Alerts 4: Key tone 5: Roam Ringer 6: Power On/Off 7: Escalating
3: Messages	1: New MSG 2: Voice 3: Inbox 4: Outbox 5: Filed MSG 6: WAP Alerts 7: Erase MSG 8: MSG Setting	7: Display	1: Menu Style 2: Wall Paper 3: Backlight 4: Banner 5: Dual Clock 6: Service LED 7: Contrast 8: Auto Hyphen 9: Power Saving
4: Planner	1: Today 2: Scheduler 3: Task List 4: Memo Pad 5: Alarm 6: Calculator 7: World Time 8: Countdown 9: Set Time	8: Games	1: Chicken Run 2: Mobile Cop
		9: Set up	1: Answering Method 2: Auto Key Lock 3: Auto Retry 4: Select NAM 5: Set System 6: Data/Fax 7: Version 8: Security

Licensed by QUALCOMM incorporated under one or more of the following Patents.  
 U.S Patent No. 4,901,307 5,056,109 5,099,204  
 5,101,501 5,103,459 5,107,225  
 5,109,390