

## Configuring Bluetooth Device Settings

Some connected Bluetooth devices are capable of more than just functioning as a headphone, but also have built in microphones for picking up voice. Although both functions are detected by the device and activated, there might be times when you need to change or update these settings for Phone and Media Audio:

- I can hear the other person but they can't hear me...
  - I want to use my Bluetooth device only as a headphone
1. Verify Bluetooth is active.
  2. From the Bluetooth settings page, tap  (**Settings**).
  3. Toggle the **Call audio** field to activate/de-activate the Bluetooth device's on-board microphone.
  4. Toggle the **Media audio** field to activate/de-activate the Bluetooth device's headset functions.

---

**Note:** If callers can not hear you during a call while using a paired Bluetooth headset (with built-in microphone), verify the **Call audio** option is enabled within the entry's Bluetooth Settings page.

---

## Disconnecting a Paired Bluetooth Device

Disconnecting a paired device breaks the connection between the device and your phone, but retains the knowledge of the pairing. At a later point when you wish to reconnect the device, there is no need to setup the connection information again.

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, tap the previously paired device (from the bottom of the page).
3. Tap **OK** to confirm disconnection.

---

**Note:** Disconnections are manually done but often occur automatically if the paired device goes out of range of your phone or it is powered off.

---

## Deleting a Paired Bluetooth Device

Deleting a device from your list removes its "connection record" and upon reconnection would require that you re-enter all the previous pairing information.

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap  (**Settings**) → **Unpair** to delete the paired device.

## Sending Contacts via Bluetooth

Depending on your paired devices' settings and capabilities, you may be able to send pictures, Contact information, or other items using a Bluetooth connection.

---

**Note:** Prior to using this feature, Bluetooth must first be enabled on both your phone and the external device, and the recipient's device must be visible.

---

1. Verify your Bluetooth is active and your phone is visible.
2. From the Home screen, tap  (**Contacts**).
3. Touch and hold the entry from the list to display the on-screen context menu.
4. Tap **Share namecard via → Bluetooth** and select a paired external Bluetooth device.

---

**Note:** The external Bluetooth device must be visible and communicating for the pairing to be successful.

---

5. A Bluetooth share notification displays in your notifications list.

## Enable Downloading for Web Applications

---

**Important!** Before you can download a web application you must insert an SD into the phone and enable the **Unknown sources** feature (enables downloading). For more information, refer to *"Installing the microSD Memory Card"* on page 11. Also, see *"Mounting the SD Card"* on page 68

---

1. From the Home screen, press  and then tap **Settings** →  (**More tab**) → **Security** → **Unknown sources** check box.
2. Tap **OK** to allow install of non-Play Store applications. Tap again to remove the check mark and disable the installation of non-Play Store applications.

---

**Warning!** Not all web applications are safe to download. In order to protect your phone and data, use the Play Store to install web applications. For more information, refer to *"Downloading a New Google Application"* on page 232.

---

## PC Connections

You can connect your device to a PC using an optional PC data cable using various USB connection modes.

**Media device (MTP):** allows you to transfer media files in Windows, or using an Android file transfer on a Mac.

**Camera (PTP):** allows you to transfer photos using the camera software, and transfer any files onto a PC that does not support MTP.

**Kies:** allows you to manage music, movies and photos. You can also backup precious contacts and calendars, download apps and podcasts and automatically upgrade device firmware. Kies conveniently syncs your life across all your devices.

---

**Note:** To sync your device to your computer it is highly recommended that you install Samsung Kies which is available at <http://www.samsung.com/kies> (for Windows/Mac).

---

---

**Note:** If you are a Windows XP user, ensure that you have Windows XP Service Pack 3 or higher installed on your computer. Also, ensure that you have Samsung Kies 2.0 or Windows Media Player 10 or higher installed on your computer.

---

### Connecting as a Storage Device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can also access the files directory from the memory card by using the device as a memory card reader.

---

**Note:** The file directory of the memory card displays as a removable disk, separate from the internal memory.

---

1. Connect the USB cable to the device and connect the cable to the computer. After a few seconds, a pop-up window displays on the PC when connected.
2. Open the folder to view files.
3. Copy files from the PC to the memory card.

DRAFT  
Internal Use Only

## Wi-Fi

### About Wi-Fi

Wi-Fi (short for "wireless fidelity") is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to an existing and accessible Wireless Access Point (WAP). These WAPs can either be Open (unsecured) as within most Hot Spots, or Secured (requiring knowledge of the Router name and password).

---

**Note:** After you complete a connection to an active Wi-Fi network, the Wi-Fi Calling feature will automatically be enabled.

---

---

**Note:** For additional information on WPS Connections, refer to "WPS Push Button" on page 280 and "WPS PIN Entry" on page 280.

---

### Activating Wi-Fi

By default, your device's Wi-Fi feature is turned off (deactivated). Activating Wi-Fi allows your device to discover and connect to compatible in-range WAPs (Wireless Access Points).

1. From the Home screen, press  and then tap **Settings** →  (Connections tab).
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on . The device scans for available in-range wireless networks and displays them under Wi-Fi networks on the same screen.

### Connecting to a Wi-Fi Network

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Wi-Fi**.  
The network names and security settings (Open network or Secured with WEP) of detected Wi-Fi networks display in the Wi-Fi networks section.
2. Tap the network you wish to connect to.

---

**Note:** When you select an open network you are automatically connected.

---

3. Enter a wireless password (if necessary).
4. Tap **Connect**.

## Wi-Fi Status Indicators

The following icons indicate the Wi-Fi connection status:



Displays when Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP).



Displays when Wi-Fi is active and there is an available open wireless network.



Displays when Wi-Fi Direct is active and configured for a direct connection to another compatible device in the same direct communication mode.



Displays when Wi-Fi Direct is active and communicating



Displays when Wi-Fi is being used as a Mobile HotSpot feature is active and communicating.

## Manually Add a New Network Connection

1. From the Wi-Fi network screen, tap **Add Wi-Fi network**.
2. Enter the Network SSID (the name of your Wireless Access Point).
3. Tap the **Security** field and select a security option. This must match the current security setting on your target WAP.
4. Enter your WAP's password if the WAP is secure.
5. Tap **Save** to store the new information and connect to the target WAP.

---

**Note:** No prompt to enter the WAP key displays if this is the second time to connect to a previously accessed or secured wireless network. The WAP key is required when the device is reset using factory default settings.

---

DRAFT  
Internal Use Only

## Deactivating Wi-Fi

1. From the Home screen, press  and then tap **Settings → Connections** tab.
2. In a single motion touch and slide the **Wi-Fi** slider to the left to turn it off .

– or –

Activate and Deactivate Wi-Fi from the Notification bar.

---

**Note:** Use of wireless data connections such as Wi-Fi and Bluetooth can reduce battery life and use times.

---

## Manually Scan for a Wi-Fi Network

1. From the Home screen, press  and then tap **Settings → Connections** tab → **Wi-Fi**.
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on.
3. Tap **Scan**.

## Wi-Fi Advanced Settings

The Wi-Fi settings - Advanced menu allows you to set up many of the device's Wi-Fi services, including:

- Setting the Wi-Fi sleep policy
- Viewing the device's MAC Address
- Configuring use of either a DHCP or Static IP

**To access the Wi-Fi Advanced Settings menu:**

1. From the Home screen, press  and then tap **Settings → Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.

DRAFT

Internal Use Only

## USB Tethering

This option allows you to share your device's mobile data connection via a direct USB connection between your device and a single computer. The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

---

**Note:** You can not mount your device's microSD card to your computer while using the USB tethering feature. If additional software or USB drivers are required, navigate to: <http://www.samsung.com/us/support/downloads>.

---

### To connect using USB Tethering:

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).  
— or —

From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings** → **Tethering and Mobile HotSpot**.

2. Plug in the USB cable between your computer and your device.
3. Tap **USB tethering** from the Tethering menu. This places a green check mark next to the entry and activates the feature. A Tethering or HotSpot active notification briefly appears on the screen.  
Look for the Tethering active icon  in the Status bar area of the screen.
4. Read the on-screen notification regarding data use and tap **OK**.

DRAFT  
Internal Use Only

### To disconnect tethering:

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).
2. Tap **USB tethering** from the Tethering menu to remove the check mark and deactivate the feature.
3. Remove the USB cable from the device.

## Mobile HotSpot

This feature allows you to turn your device into a Wi-Fi hotspot. The feature works best when used in conjunction with 4G/LTE data services (although 3G service can also be used).

The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

---

**Important!** The Mobile HotSpot service cannot be active when device is connected to Wi-Fi. Please disconnect your Wi-Fi connection prior to active this service.

---

---

**Note:** You must have a tethering plan on your account in order to use the Mobile HotSpot. You cannot use data on the device while using Mobile HotSpot.

---

### To activate the Mobile HotSpot service:

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).  
— OR —

From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings** → **Tethering and Mobile HotSpot**.

2. In a single motion touch and slide the **Mobile HotSpot** slider to the right to turn it on.
3. Read the on-screen notification regarding data use and tap **OK**.
4. Edit the **Network SSID** name and then write it down.
5. Enable the **Broadcast network name (SSID)** field if you would like to broadcast your SSID name to nearby devices.
6. Verify the **Security** field is set to **WPA2 PSK**.
7. Enter a new password then write it down.
8. Tap **Save** to store the new settings.
9. Confirm the Mobile HotSpot active icon  appears at the top of the screen.

---

**Note:** By default, the connection is not secured.

---

---

**Note:** Using your Mobile HotSpot drains your device's battery much faster. The best way to keep using the device as a HotSpot is by connecting to a Charger.

---

### To connect to the HotSpot:

1. Enable Wi-Fi (wireless) functionality on your target device (laptop, media device, etc.).
2. Scan for Wi-Fi networks from the external device and select your device's Mobile HotSpot name from the network list.
  - The SSID name for your device's hotspot is determined by what you entered into the **Network SSID** field.
  - You can change the name by tapping **Configure** → **Network SSID** and changing the entry.
3. Select this HotSpot and follow your on-screen instructions to complete the connection.
4. Launch your Web browser to confirm you have an Internet connection.

### To change the Portable HotSpot password:

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot** → **Configure**.
3. Tap the **Security** field and select **WPA2 PSK**.
4. With security enabled, delete the previous password and enter a new one into the **Password** field.

---

**Important!** The more complex the password, the harder it will be for intruders to break your security. It is recommended that you not use names, birthdays, or other personal information.

---

5. Tap **Save** to store the new settings.

DRAFT  
Internal Use Only

### To manage connected devices:

This feature allows you to provide MAC filtering on your device. This is similar to a “VIP list” where only device on the list are allowed access.

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot → Allowed devices**.
3. Tap  (Add new device) to add devices to the allowed for connection list.
4. Enter the Device name and Mac address.
5. Tap **OK** to save the new device.

DRAFT  
Internal Use Only

## Section 11: Changing Your Settings

---

This section explains the device settings for your device. It includes such settings as: display, security, memory, and any extra settings associated with your device.

### Accessing the Settings Tabs

- From the Home screen, tap  (Apps) →



(Settings).

— or —

Press  →  and then tap **Settings**. The Settings screen displays.

### Settings Tabs - Overview

The Settings are divided into 4 main groups. When the Settings screen displays, the following 4 tabs are located at the top of the screen:



#### Connections:

This tab allows you to see all of settings related to the connection of your device to external sources. Features include: Wi-Fi, Bluetooth, Airplane mode, Data usage, More settings (Mobile networks, Tethering and Mobile HotSpot, VPN, and Wi-Fi Calling), NFC, S Beam, Nearby devices, Screen Mirroring, and Kies via Wi-Fi.



#### My device:

This tab provides access to device configuration and customization features. Features include: Lock screen, Display, LED indicator, Sound, Home screen mode, Call, Blocking mode, Accessory, Accessibility, Language and input, Motions and gestures, Smart screen, Air view, and Voice control.

DRAFT

Internal Use Only



### Accounts:

This tab provides both the ability to create and modify your accounts (ex: Samsung account, Email, etc.), configure Cloud functionality, and access Backup and reset features.



### More:

This tab provides access to the remaining set of device settings not listed under the other three tabs. These include Location services, Security, Application manager, Battery, Power saving mode, Storage, Date and time, and About device.

---

**Note:** The settings for your device are described below using the order in which they appear in the Settings menu. Functions found under the Connections tab are listed first, followed by My device, Accounts, and More settings tabs.

---

## Wi-Fi Settings

This section describes the Wi-Fi settings. For more information, refer to “Wi-Fi” on page 268.

### Activating Wi-Fi

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab).
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on . The device scans for available in-range wireless networks and displays them under Wi-Fi networks on the same screen.

### Wi-Fi settings

Once set up for Wi-Fi connectivity, your device automatically uses Wi-Fi, when available, for all your mobile services.

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab) → **Wi-Fi**.
2. Press  and then tap **Advanced**. Configure the settings as desired.

The available Wi-Fi connection are displayed with a security type displayed next to them.

DRAFT

Internal Use Only

## Network Notification

By default, when Wi-Fi is on, you receive notifications in the Status bar anytime your phone detects an available Wi-Fi network. You can deactivate this feature if you do not want to receive notifications.

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap **Network notification**. A check mark displayed next to the feature indicates Network notification is active.
4. Tap **Network notification** again to remove the check mark and deactivate this feature.

## Passpoint

Wi-Fi CERTIFIED Passpoint™ allows users connect to Wi-Fi hotspot networks by simplifying the process of connecting to the correct network. In addition, this connection type provides WPA2™ security protection for safe data communication. Mobile devices, such as handsets and tablets, that are certified for Passpoint can still be used in existing hotspots. Users on passpoint-enabled hotspots, will also enjoy Wi-Fi roaming.

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. In a single motion touch and slide the **Passpoint** slider to the right to turn it on .
4. Tap the **Passpoint** field and begin the on-screen process of connecting to a compatible AP.

DRAFT  
Internal Use Only

## Wi-Fi During Sleep

By default, when your device enters a sleep mode, your Wi-Fi connection stays on all the time. If the feature is Never enabled during sleep that current data usage is taken over by your SIM and its network connection.

1. From the Home screen, press  and then tap **Settings → Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced → Keep Wi-Fi on during sleep**.
3. Select an available option:
  - **Always:** maintains your current active Wi-Fi connection even during sleep.
  - **Only when plugged in:** maintains the active Wi-Fi connection only when the device detects it is connected to a power supply. This reduced the drain on your device's battery.
  - **Never (increase data usage):** shuts off the current Wi-Fi connection during sleep and diverts any current data usage to the cellular network connection.

## Check for Internet Service

Allows you to check for Wi-Fi Internet access once connected to a WAP (Wireless Access Point).

1. From the Home screen, press  and then tap **Settings → Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap the **Check for Internet service** field to activate the feature. A green check mark indicates the feature is active.

DRAFT  
Internal Use Only

## Finding your Wi-Fi Address Information

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Locate the MAC Address and IP Address information at the bottom of the screen.
  - **MAC address:** view your device's MAC address, required when connecting to some secured networks (not configurable).
  - **IP address:** view your device's IP address.

## Manually Adding a Wi-Fi Network

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Wi-Fi** → **Add Wi-Fi network**.
2. Enter the Network SSID (the name of your Wireless Access Point).
3. Tap the **Security** field and select a security option. This must match the current security setting on your target WAP (Wireless Access Point).
4. Enter your WAP's password if the WAP is secure.
5. Tap **Save** to store the new information and connect to the target WAP.

---

**Note:** An SSID is a unique key which identifies a wireless LAN. Its purpose is to stop other wireless equipment from accessing your LAN — whether accidentally or intentionally. To communicate, wireless devices must be configured with the same SSID.

---

DRAFT

Internal Use Only

## WPS Push Button

The WPS (Wi-Fi Protected Setup) feature (sometimes associated with a physical or on-screen button on most WAPs) allows you to pair your device and WAP without the need for entering a passcode. This process is similar to Wi-Fi Direct pairing.

In this case, once the WPS feature is active on your WAP, your device can then detect it and then immediately pair to it.

---

**Note:** WPS-capable routers appear in the Wi-Fi list of available devices with the term **(WPS available)** below their name.

---

### To pair your device using WPS:

1. Follow the WPS activation instructions specific to your Wireless Access Point.
2. From the Home screen, press  and then tap **Settings → Connections tab → Wi-Fi**.
3. Press  then tap **WPS push button**.
4. Once the connection is complete, confirm the external router now appears in the Wi-Fi list as connected.

## WPS PIN Entry

If a WPS Push Button does not work, there is an alternative WPS connection method where you would use a device generated PIN number to establish the connection. This number is then entered into your WAP's WPS client PIN field to complete the connection.

### To pair your device using WPS PIN:

1. From the Home screen, press  and then tap **Settings → Connections tab → Wi-Fi**.
2. Press  then tap **WPS PIN entry**.
3. Write down the generate PIN number and enter it into your Wi-Fi Router's client PIN field.
4. Once the connection is complete, confirm the external router now appears in the Wi-Fi list as connected.

DRAFT  
Internal Use Only

## Wi-Fi Direct Setup and Settings

You can configure your device to connect directly with other Wi-Fi capable devices. This is an easy way to transfer data between devices. These devices must be enabled for Wi-Fi direct communication. This connection is direct and not via a HotSpot or WAP.



Displays when Wi-Fi Direct is active and configured for a direct connection to another compatible device in the same direct communication mode.



Displays when Wi-Fi Direct is active and communicating.

---

**Note:** Activating this feature will disconnect your current Wi-Fi network connection.

---

### To activate your connection:

1. From the Home screen, press  and then tap **Settings** → **Connections** tab.
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on. The slider color indicates the activation status.
3. Tap **Wi-Fi Direct**.
4. Tap **Scan** and select the single device name to begin the connection process to another Wi-Fi Direct compatible device.

– or –

Tap **Multi-connect** → **Scan** and select all the device names to begin the connection process to these Wi-Fi Direct compatible devices.

---

**Note:** The target device must also have Wi-Fi Direct service active and running before it can be detected by your device.

---

DRAFT

Internal Use Only

5. Tap **Done**. The direct connection is then established. Confirm  appears in the Status bar.
6. When prompted to complete the connection, the recipient should tap **OK**. Your status field now reads “Connected” and your connected device is listed within the Wi-Fi Direct devices listing.

#### To give your Wi-Fi Direct connection a unique name:

It can be difficult to pair to external devices if all you have is a generic name (ex: Android 12345). It is recommended you provide your connection with a unique name.

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Wi-Fi** → **Wi-Fi Direct**.
2. Press  and then tap **Rename device**.
3. Edit the current name and tap **OK** to save the new identification.

## Bluetooth settings

In this menu you can activate Bluetooth, view or assign a device name, activate your phone so other Bluetooth devices can discover it, or scan for other, available Bluetooth devices with which to pair. For more information, refer to “Bluetooth” on page 262.

### Turning Bluetooth On and Off

#### To turn Bluetooth on:

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab).
2. In a single motion touch and slide the **Bluetooth** slider to the right to turn it on  .  
The slider color indicates the activation status. When active,  displays in the Status area.

#### To turn Bluetooth off:

1. From the Home screen, press  and then tap **Settings**.
2. In a single motion touch and slide the **Bluetooth** slider to the left to turn it off  .

---

**Note:** Bluetooth must be enabled prior to use.

---

## Changing the Device Name

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **About device**.
2. Tap the **Device name** field and use the on-screen keyboard to edit the current device name.
3. Tap  to erase the current device name and enter a new name for this device using the keyboard.
4. Tap **OK** to confirm your setting.

## Activating Visibility

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Bluetooth**.
2. Verify your Bluetooth is active.
3. From the top of the Bluetooth settings page, toggle the state of the visibility check mark. Activating this feature enabled your device visible allows other devices to pair and communicate.

## Scanning for Devices

This option allows you to scan for active Bluetooth devices so you can pair with them.

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Bluetooth**.
2. From the bottom of the Bluetooth settings page, tap **Scan** to search for visible external Bluetooth-compatible devices such as headsets, devices, printers, and computers.

---

**Important!** Some Bluetooth devices are secured and require a PIN number to confirm and pair with them.

---

3. Enter a PIN to pair with the device, if one is required, and tap **OK**.

DRAFT

Internal Use Only

## Airplane Mode

This mode allows you to use many of your device's features, such as Camera, Games, and more, when you are in an airplane or in any other area where making or receiving calls or data is prohibited.

---

**Important!** When your device is in Airplane mode, it cannot send or receive any calls or access online information or applications.

---

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab).
2. In a single motion touch and slide the **Airplane mode** slider to the right to turn it on .
3. Tap **OK**. The Airplane mode icon  is displayed at the top of your screen.

## Data Usage

Monitor and manage your device's data usage capabilities. Features include activation/deactivation or network data usage, set mobile data usage for a set period of time, and view application data usage.

- From the Home screen, press  and then tap **Settings** →  (**Connections** tab) → **Data usage**.

### To activate/deactivate Mobile data usage:

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Data usage**.
2. Tap the **Mobile data** field to activate the feature. A green check mark indicates the feature is active.
3. Tap the **Mobile data** field again to deactivate the feature.

### To set a mobile data limit:

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Data usage**.
2. Place a check mark in the **Set mobile data limit** field.
3. Read the on-screen disclaimer info and tap **OK**.

DRAFT  
Internal Use Only

4. Touch and drag the far right ends of the Red or Orange horizontal lines to manually adjust both the Warning and Maximum data limits.
5. Touch and drag the bottom grey vertical lines to adjust the time frames.
6. Tap the **Data usage cycle** button and select either the current cycle or define your own by selecting **Change cycle**.
7. Press  and then select from the available on-screen options:
  - **Data roaming** allows you to connect to your service provider's partner networks and access data services when you are out of your service providers area of coverage. For more information, refer to "*Data Roaming*" on page 286.
  - **Restrict background data** prevents background data usage. This can help prevent over usage of your data minutes.
  - **Auto sync data** allows the device to automatically sync information and updates with your various services.
  - **Show Wi-Fi usage** activates an additional Wi-Fi tab that shows you your Wi-Fi data usage.

- **Mobile hotspots** allows you to select available Wi-Fi networks that can service as mobile hotspots. Place a check mark on those entries you wish to use.

## More Settings

This tab displays additional wireless and network information.

- From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings**.

## Mobile networks

Before you use applications such as Google Maps and find your location or search for places of interest, you must enable the Mobile networks options.

- From the Home screen, press  and then tap **Settings** → **Connections** tab → **More settings** → **Mobile networks**.

The following options display:

### Use mobile data

Allows you to activate mobile data usage on your device.

- From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Mobile data**.

### Data Roaming

Data roaming allows you to connect to your service provider's partner networks and access data services when you are out of your service providers area of coverage.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks**.
2. Tap **Data roaming** to connect to data services while roaming outside your network.  
– or –

Tap **Data roaming** again to remove the green check mark and deactivate the feature.

### Access Point Names

To access a wireless access point:

- From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Access Point Names**. A list of the Access point names display. The active access point displays a bright green, filled circle to the right of the name.

### Network mode

You can configure your device to either automatically select the LTE option (LTE/GSM/WCDMA (auto connect) [by default]), GSM/WCDMA (auto connect), GSM only, or WCDMA only.

- From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network mode**.
  - **LTE/GSM/WCDMA (auto connect)** is the default network mode option. This selection allows the device to choose the fastest connection from among the available connection speeds, including LTE.
  - **GSM/WCDMA (auto connect)** allows you to exclude the LTE network and choose from only 4G, 3G, and 2G networks.
  - **GSM only** restricts your connection to only the 2G network.

- **WCDMA only** restricts your connection to only the 3G network.

## Using the LTE Network Option

To confirm you are always using the fastest possible connection, the device has an automatic detection method where it finds both the fastest and most stable connection/communication method from among this selected set (LTE/4G/3G/2G).

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network mode**.
2. Tap **LTE/GSM/WCDMA (auto connect)**. A selection indicator displays next to this option to show that it is active. This is the default mode for this device.

## Using the GSM/WCDMA Option

If you wish to not use LTE but still require a fast connection using the standard 3G/2G network speed, follow these instructions to connect to these network types.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network mode**.

2. Tap **GSM/WCDMA**. A selection indicator displays next to this option to show that it is active. This is the default mode for this device.

## Using the 2G - GSM Only Network

If you are not using applications that require a faster network speed (any application that accesses the network or uses a browser), using the 2G only (WCDMA) network saves battery life.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network mode**.
2. Tap **GSM only**. A check mark displays next to this option to indicate that it is active. Connecting to 2G networks slows the data transfer speed and time.

## Using the WCDMA - 3G Only Network

This option uses a 3G connection only.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network mode**.
2. Tap **WCDMA only**. A check mark displays next to this option to indicate that it is active. Connecting to 3G networks slows the data transfer speed and time.

## Network Operators

Using this feature you can view the current network connection. You can also scan and select a network operator manually, or set the network selection to Automatic.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks**.
2. Tap **Network operators**. The current network connection displays at the bottom of the list.

---

**Important!** You must deactivate data service prior to searching for an available network.

---

3. Tap **Search now** to manually search for a network.
4. Tap **Select automatically** to automatically select a network connection.

---

**Note:** Connecting to 2G networks slows the data transfer speed and time.

---

## Default Setup Options

Your phone default is set to Automatic (to automatically search for an available network. You can set this option to Manual to select a network each time you connect.

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Mobile networks → Network operators**.
2. Tap **Default setup**.
3. Tap **Automatic** to allow the device to automatically select a network.  
– or –

Tap **Manual** to locate and connect to a network manually.

DRAFT  
Internal Use Only

## Tethering and Mobile HotSpot

This option allows you to share your phone's mobile data connection via a direct USB connection between your phone and computer. A wireless version of this same functionality would be the Mobile AP feature.

---

**Note:** You can not mount your device's microSD card to your computer while using the USB tethering feature. If additional software or USB drivers are required, navigate to: <http://www.samsung.com/us/support/downloads>.

---

- From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings** → **Tethering and Mobile HotSpot**.

For more information, refer to “USB Tethering” on page 271.

For more information, refer to “Mobile HotSpot” on page 272.

## VPN settings

The VPN settings menu allows you to set up and manage Virtual Private Networks (VPNs).

---

**Note:** Before using VPN, you must first set up a screen unlock PIN or password. For more information, refer to “Security” on page 335.

---

### Adding a VPN

Before you add a VPN you must determine which VPN protocol to use: PPTP, L2TP/IPSec PSK, L2TP/IPSec RSA, IPSec Xauth PSK, IPSec Xauth RSA, IPSec Hybrid RSA.

---

**Important!** Before you can use a VPN you must establish and configure one.

---

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings** → **VPN**.
2. If prompted, read the screen lock information and follow the on-screen steps to setup an unlock PIN or password.
3. Tap **Add VPN network**.

4. In the form that appears, fill in the information provided by your network administrator.
5. Tap **Save**.

---

**Note:** Similar setup process can be used for all available VPN types.

---

### Connecting to a VPN

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More settings** → **VPN**.
2. Tap the VPN entry you want to connect to.
3. Enter any requested credentials into the pop-up that opens.
4. Tap **Connect**.

### Edit a VPN

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **More settings** → **VPN**.
2. Touch and hold the VPN that you want to edit.
3. In the pop-up that opens, select **Edit network**.
4. Make the desired VPN setting changes.

5. Tap **Save**.

### Delete a VPN

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **More settings** → **VPN**.
2. Touch and hold the VPN that you want to delete.
3. Tap **Delete network** within the pop-up that opens up.

### Wi-Fi Calling

You can configure your device to make and receive calls over an active Wi-Fi connection. Wi-Fi Calling is an excellent solution for coverage issues in and around the home or wherever cellular coverage is limited. Minutes used while connected to the Wi-Fi network count against available rate plan minutes.

For more information, refer to “Wi-Fi Calling” on page 81.

1. Ensure that the **Wi-Fi connected** icon  displays on the status bar.
2. From the Home screen, press  and then tap **Settings** → **Connections** tab → **More settings**.
3. In a single motion touch and slide the **Wi-Fi Calling** slider to the right to turn it on .

## Wi-Fi Calling Settings

---

**Important!** A new ISIM card must be installed within the device prior to using this feature. Wi-Fi must first be active and communicating prior to launching Wi-Fi Calling.

---

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings → Wi-Fi Calling**.
2. Tap **Connection Preferences** and select a preference for use of the Wi-Fi Calling feature:
  - **Wi-Fi Preferred:** Wi-Fi network is preferred over cellular network when making calls. Calling requires you to stay in the Wi-Fi range.
  - **Cellular Network Preferred:** The cellular network is preferred over a Wi-Fi network when making calls.
  - **Never use Cellular Network:** Use only Wi-Fi for calls. Do not use Cellular Network, even if available.
3. Tap **Help** from the main Wi-Fi Calling Settings page to navigate through either an on-screen tutorial or review the top 10 Wi-Fi Calling questions.

## Near Field Communication

This feature is used to read and exchange tags. When used in conjunction with Android Beam, your device can be used to beam application content when NFC-capable devices are touched. For more information, refer to “*TecTiles XXX*” on page 245.

1. From the Home screen, press  and then tap **Settings → Connections tab**.
2. Tap the **NFC** field and verify the feature is active (indicated by .

## Android Beam

When Android Beam is activated, you can beam app content to another NFC-capable device by holding the devices close together. You can beam browser pages, YouTube videos, contacts, and more.

1. From the Home screen, press  and then tap **Settings → Connections tab → NFC → Android Beam**.
2. Tap the **OFF / ON** icon to turn Android Beam ON .
3. Touch the back of your device with another NFC-capable device and the content is transferred.

## S Beam

This feature (when activated via NFC) allows you to beam large files directly to another compatible device that is in direct contact. These files can be larger, such as Videos, HD pictures, and other large files. You can beam images and videos from your gallery, music files from your music player, and more.

1. From the Home screen, press  and then tap **Settings → Connections** tab.
2. Verify the NFC feature is active.
3. Tap **S Beam** and make sure the feature is turned on.
4. If not already active, in a single motion touch and slide the **S Beam** slider to the right to turn it on .
5. Complete the transfer process between the two NFC-enabled devices by placing them back to back.

This feature can come in very handy to quickly share pictures between users with compatible S Beam devices. For more information, refer to “Using S Beam to Share Pictures XXXXX” on page 174.

## Nearby devices

This option allows you to share your media files with nearby devices using DLNA and connected to the same Wi-Fi.

1. Connect to a Wi-Fi network. For more information, refer to “Connecting to a Wi-Fi Network” on page 268.
2. From the Home screen, press  and then tap **Settings → Connections** tab → **Nearby devices**.
3. Tap the **File sharing** field to turn File sharing on. A green check mark indicates the feature is active. Once active,  (**Nearby devices**) appears at the top of the screen.
4. At the Nearby devices prompt, tap **OK**.
5. Tap **Shared contents**, then check the media you would like to share. Tap **OK**.
6. Tap **Allowed devices list**, then select the connected devices you would like to allow.
7. Tap **Not-allowed devices list**, then select the connected devices you would like to not allow.
8. Tap **Download to**, then select the destination of any downloaded (shared) content. Choose from USB storage (Device) or SD card.

DRAFT

Internal Use Only

9. Tap **Upload from other devices**, then select the actions you'll take when you upload content from other devices. Choose from either Always accept, Always ask, or Always reject.

## Screen Mirroring

With feature enabled, you can wirelessly mirror what is currently displayed on your device's screen with an external TV via devices such as the AllShare Cast Hub®.

---

**Note:** Screen mirroring can only be done with a compatible wireless TV or one enabled with the AllShare Cast Hub.

---

For more information, refer to “AllShare Cast Hub” on page 200.

1. From the Home screen, press  and then tap **Settings → Connections tab → Screen Mirroring**.
2. In a single motion touch and slide the **Screen Mirroring** slider to the right to turn it on  **ON**. The slider color indicates the activation status.

---

**Note:** This feature allows a connection between your device and the optional AllShare Cast Hub, via a shared Wi-Fi Direct connection. The AllShare Cast Hub then allows the communicating TV to mirror what is being shown on the device's display.

---

For more information, refer to “AllShare Cast Hub” on page 200.

## Kies via Wi-Fi

1. From the Home screen, press  and then tap **Settings → Connections tab → More settings**.
2. Tap **Kies via Wi-Fi → OK**.
3. Select a network connection and follow the on-screen connection process.

DRAFT

Internal Use Only

## Lock Screen

This menu contains features that allows you to configure the device's security parameters.

### Screen Unlock Pattern Overview

To secure data and limit phone access, set the phone to require a screen unlock pattern each time you turn on the device, or every time the phone wakes up from sleep mode (when the screen automatically turns off).

The Screen lock menu allows to choose from a variety of locking features such as:

- **Swipe:** Swipe the screen to unlock it.
- **Face unlock:** Look at your phone to unlock it.
- **Face and voice:** Look at your phone and speak to unlock.
- **Pattern:** A screen unlock pattern is a touch gesture you create and use to unlock your device. Follow the prompts to create or change your screen unlock pattern.
- **PIN:** Select a PIN to use for unlocking the screen.
- **Password:** Create a password for unlocking the screen.
- **None:** No pattern, PIN, or password is required. The screen will never lock.

### Swipe options

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Lock screen**.
2. Tap **Screen lock**. Configure one of the following options.
  - **Auto unlock zone** disables the screen lock when this feature is enabled. Touch and slide the slider to the right to turn it on .
  - **Lock screen widgets** allows you to lock the widgets that are displayed on your home screens.
  - **Shortcuts** sets shortcuts to appear at the bottom of the Lock screen. Touch and slide the slider to the right to turn it on .
  - **Unlock effect** sets the effect you receive when unlocking the phone. You can select None, Ripple effect, or Light effect.
  - **Help text** shows help information on the Lock screen.
  - **Wake up in lock screen** requires that you say a command to wake-up your phone.
  - **Set wake-up command** designates your wake-up commands. Tap **Set wake-up command** and follow the on-screen prompts to create a new verbal command.

## Using Swipe

This feature is the least secure locking method and only requires that a user swipe the screen to unlock the device.

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Lock screen**.
2. Tap **Screen lock** → **Swipe**.

## Using Face Unlock

This feature used facial recognition to unlock your phone. This feature is less secure than PIN, Pattern, and Password locks and can be bypassed by someone else who looks similar to you.

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Lock screen**.
2. Tap **Screen lock** → **Face unlock**.
3. Read the on-screen notification and tap **Next**.
4. From the About Face Unlock screen, tap **Set it up**.
5. Follow the on-screen instructions.
6. If your face is not recognized, choose an unlocking method: Pattern or PIN.

## Face unlock options

Once Face unlock is enabled, additional options are available:

- **Auto unlock zone** disables the screen lock when this feature is enabled. Touch and slide the slider to the right to turn it on .
- **Lock screen widgets** allows you to lock the widgets that are displayed on your home screens.
- **Improve facial recognition** allows you to improve your device's face matching capability by capturing your face in different lighting, with or without glasses, and bearded or clean-shaven. Follow the on-screen instructions.
- **Presence check** requires that you blink when using the Face unlock feature. This will increase the security of the feature.
- **Secured lock time** allows you to set a time-out for lock screen.

DRAFT  
Internal Use Only

## Using Face and Voice Unlock

This feature used facial recognition to unlock your phone. This feature is less secure than PIN, Pattern, and Password locks and can be bypassed by someone else who looks similar to you.

1. From the Home screen, press  and then tap **Settings → Lock screen**.
2. Tap **Screen lock → Face and voice**.
3. Read the on-screen notification and tap **Next**.
4. From the About Face Unlock screen, tap **Set it up**.
5. Follow the on-screen instructions.
6. Once prompted to speak and unlock command, tap  and repeat the phrase four times.
7. Once complete, tap **Done**.

## Setting an Unlock Pattern

Creating a screen unlock pattern increases security on the phone. When you enable the User visible pattern field, you will draw an unlock pattern on the screen whenever you want to unlock the phone's buttons or touch screen. When you activate the User tactile feedback field, you feel vibration as feedback while drawing the pattern.

The feature is now paired with a backup PIN code that acts as a backup to the pattern lock. If you forget your pattern, you can regain access to the device by entering a PIN code.

---

**Note:** Make sure the Require Pattern field is activated.

---

1. From the Home screen, press  and then tap **Settings → My device tab → Lock screen**.
2. Tap **Screen lock → Pattern**.
3. Read the instructions then tap **Next**.
4. Draw your pattern by touching your first on-screen point. Then, **without removing your finger from the screen, drag your finger over adjacent points until the gray trace line overlaps each point** and they are highlighted with a green circle.

DRAFT  
Internal Use Only

5. When you have connected at least four dots in a vertical, horizontal or diagonal direction, lift your finger from the screen and tap **Continue**.
6. Confirm the new pattern by redrawing it and then tapping **Confirm**. The Unlock pattern is set.
7. Enter the backup PIN code and tap **Continue**.
8. Reenter the PIN to reconfirm the previous entry and tap **OK**.

## Changing the Screen Lock Pattern

This feature allows you to change the previously stored unlock pattern and update it if necessary. This process is similar to changing your password from time to time.

1. From the Home screen, press  and then tap **Settings → My device tab → Lock screen**.
2. Tap **Screen lock**.
3. Retrace your current pattern on the screen.
4. Tap **Pattern** and repeat steps 3 - 7 from the previous section.

## Deleting the Screen Lock Pattern

1. From the Home screen, press  and then tap **Settings → My device tab → Lock screen**.
2. Tap **Screen lock**.
3. Retrace your current pattern on the screen.
4. Tap **None**.

## Pattern options

Once an unlock pattern is enabled, additional options are available:

- **Multiple lock screen** allows you to display multiple lock screen widgets on your lock screen.
- **Auto unlock zone** disables the screen lock when this feature is enabled. Touch and slide the slider to the right to turn it on .
- **Lock screen widgets** allows you to lock the widgets that are displayed on your home screens.
- **Make pattern visible** allows you to see the pattern as you draw it.
- **Lock automatically** allows you to set a time-out for lock screen.

DRAFT  
Internal Use Only

- **Lock instantly with power key** allows you to lock the screen by pressing .

## What If I Forget my Pattern?

If you forget your device's lock pattern, you can unlock your device or reset it using your Google™ Account credentials. When you enter the wrong unlock pattern too many times, you should see an option at the bottom of the screen that says **Forgot pattern?** Follow these steps to use either your PIN or email address.

---

**Important!** You can only enter an incorrect lock pattern 5 times before the device is locked.

---

---

**Important!** If you are unsuccessful in retrieving your lock pattern or unlocking your device, please contact T-Mobile for assistance.

---

### To unlock your device with a PIN code:

1. Tap **Forgot pattern?** (located at the bottom of the screen).

2. Scroll down and tap the **Type PIN code** field and use the on-screen keypad to enter the backup PIN code you setup when you created your lock pattern.
3. Tap **OK**.
4. If you have forgotten your current pattern, tap **Pattern** from the Screen unlock settings menu and follow the procedures outlined in *"Setting an Unlock Pattern"* on page 296 to create a new pattern.

### To unlock your device using your Google account:

1. Tap **Forgot pattern?** (located at the bottom of the screen).
2. Tap the **Username (email)** and **Password** fields, use the on-screen keyboard to enter your Google Account credentials, and tap **Sign in** to complete the login process.
3. If you have forgotten your Google Account credentials, visit the Google website to recover them. If you still cannot get your Google Account credentials, contact your wireless carrier for additional options.

DRAFT  
Internal Use Only

## PIN Lock and Unlock

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Lock screen**.
2. Tap **Screen lock** → **PIN**.
3. Enter a PIN number using the numeric keypad and touch **Continue** to confirm the password.
4. Confirm the PIN by re-entering it and tap **OK** to confirm. Your phone now requires you to enter this PIN number in order to unlock the phone.

## Password Lock and Unlock

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Lock screen**.
2. Tap **Screen lock**.
3. Tap **Password**.
4. Enter a password using the keypad and tap **Continue** to confirm the password.
5. Confirm the password by re-entering it and tap **OK** to confirm.

## Display Settings

In this menu, you can change various settings for the display such as the font, orientation, pop-up notifications, puzzle lock feature, animation, brightness, screen timeout, and power saving mode.

### Adjusting the Screen Display

1. From the Home screen, press  and then tap **Settings** →  (**My device** tab) → **Display**.
2. Configure the following screen display settings:
  - **Wallpaper**: allows you to set the Wallpaper for your Home screen, Lock screen, or both.
  - **Notification Panel**: allows you to set the brightness of your notification panel and also select the quick setting buttons that you want to display at the top of the notification panel (page 37).
  - **Multi window**: tap this option to enable/disable the automatic Multi window feature.
  - **Screen mode**: allows you to select from several different color modes.

DRAFT  
Internal Use Only

- **Brightness:** adjusts the on-screen brightness level. For more information, refer to “*Adjusting Screen Brightness*” on page 301.
- **Auto-rotate screen:** when enabled, the phone automatically switches from portrait to landscape orientation and vice versa. When this setting is disabled, the phone displays in portrait mode only.
- **Screen timeout:** adjusts the delay time before the screen automatically turns off. Selections are: 15 seconds, 30 seconds, 1 minute, 2 minutes, 5 minutes, and 10 minutes.
- **Daydream:** allows you to control what your screen does when your device is docked or sleeping. Tap the adjacent OFF / ON icon to turn it on . Follow the on-screen instructions.
- **Font style:** sets the fonts used on the LCD display. Selections are: **Default font**, **Choco cooky**, **Cool jazz**, **Rosemary**, or **Get fonts online**. Tap **Get fonts online** to download additional fonts.
- **Font size:** allows you to select which size of font is displayed.
- **Touch key light duration:** allows you to adjust the delay before the Touch key light automatically turns off.
- **Display battery percentage:** to activate/deactivate the display of battery charge percentage atop the battery icon at the top of the screen.
- **Edit after screen capture:** allows you to go edit a screen immediately after taking a screen capture.
- **Auto adjust screen tone:** adjusts the phone's LCD brightness level to automatically adjust and conserve battery power.
- **Auto adjust touch sensitivity:** allows you to adjust the touch sensitivity of your phone automatically depending on the type of material on the display.

## Adjusting Screen Brightness

This feature configures the LCD Brightness levels.

1. From the Home screen, press  and then tap **Settings → My device tab → Display → Brightness**.
2. Tap **Automatic brightness** to allow the phone to self-adjust and tap **OK**.

— or —

Touch and slide the on-screen slider to adjust the level and tap **OK**.

## Assigning a Wallpaper

The Wallpaper settings option allows you to set the Wallpaper for your Home screen, Lock screen, or both.

1. From the Home screen, press  and then tap **Settings → My device tab → Display → Wallpaper**.
2. Select an available option to change its current wallpaper.

For more information, refer to “*Managing Wallpapers*” on page 65.

## LED Indicator

This option allows you to turn on your LED lights for charging, missed events, and incoming notifications. The light will turn on by default unless you turn them off.

1. From the Home screen, press  and then tap **Settings → My device tab → Display → LED indicator**.
2. Tap the following LED indicator options to turn them on or off:

- **Charging:** LED lights up when the device is connected to the charger.
- **Low battery:** LED lights up when the battery level is low.
- **Notifications:** LED lights up when you have missed calls, messages, or application events.
- **Voice recording:** LED lights up when you are recording voice. The LED only lights up when the screen is off.

DRAFT  
Internal Use Only

## Sound Settings

From this menu you can control the sounds on the phone as well as configure the display settings.

- From the Home screen, press  and then tap **Settings** →  (**My device** tab) → **Sound**.

The following options display:

### *Silent mode via Device Options Screen*

Silent mode is convenient when you wish to stop the phone from making noise, in a theater for example. In Silent Mode the speaker is muted and the phone only vibrates to notify you of incoming calls, or other functions that normally have a defined tone or sound as an alert.

1. From the Home screen, press and hold  (**Power/End**) until the **Device options** screen displays.
2. Tap either **Mute**, **Vibrate**, or **Sound** from the Device options screen to activate or deactivate these features (the current mode displays).

## Adjusting the Volume Settings

The Volume menu now provides access to various volume settings within one on-screen popup menu.

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Sound** → **Volume**.
2. Touch and drag the on-screen slider to assign the volume settings for any of the following volume levels.
  - **Music, video, games, and other media**, **Ringtone**, **Notifications** or **System**.
3. Tap **OK** to assign the volume levels.

### *Vibration intensity*

Vibration intensity allows you to select how intense the vibration is for different options.

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Sound** → **Vibration intensity**.
2. Touch and drag the slider to adjust the Vibration intensity for **Incoming call**, **Notification**, and **Haptic feedback**.
3. Tap **OK** to assign the vibration levels.

DRAFT  
Internal Use Only

## Setup the Ringtones

This option allows you to set the ringtone.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound**.
2. Tap **Ringtones**.
3. Tap a ringtone from the available list. The ringtone briefly plays when selected.
4. Tap **Add** to locate a compatible media file that can be used as a ringtone.
5. Tap **OK** to assign a ringer.

## Setup the Vibration

This option allows you to set your device to vibrate and ring.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound**.
2. Tap **Vibrations**.
3. Select a vibration pattern and tap **OK**.

– or –

Tap **Create** to then use an on-screen touch circle to create your own custom vibration pattern. Tap **Save** to store the new vibration pattern.

## Notifications

This option allows you to set the ringtone that will sound for notifications and alarms.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound**.
2. Tap **Notifications**.
3. Select a ringtone and tap **OK**.

## Setting up Vibration When Ringing

This option allows you to enable your phone to vibrate when a call is incoming.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound**.
2. Tap the **Vibrate when ringing** field to activate the feature.

## Audible System Tone Settings

These options are used when you use the dialing pad, make a screen selection, lock your screen, or tap the screen. Each time you press a key or make a selection the selected tone sounds.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound**.
2. Tap **Dialing keypad tone** to activate a tone when you use on-screen keys. A check mark displayed next to these features indicates active status.
3. Tap **Touch sounds** to activate a tone when you touch the screen. A check mark displayed next to this feature indicates active status.
4. Tap **Screen lock sound** to activate a tone when you use the Lock screen. A check mark displayed next to this feature indicates active status.
5. Tap **Haptic feedback** to activate the a vibration when you press soft keys on certain screens. A check mark displayed next to the feature indicates this feature is active.

## Adapt sound

The Adapt sound feature allows you to customize your call sounds.

1. From the Home screen, press  and then tap **Settings → My device tab → Sound → Adapt Sound**.
2. Read the instructions and tap **Start**.
3. Follow the on-screen instructions to set up your personal call sound.

DRAFT  
Internal Use Only

## Home Screen Mode

This application allows you to set your display to the conventional layout of **Basic mode** or provide an easier user experience for the first-time smartphone users using **Easy mode**.

1. From the Home screen, press  and then tap **Settings** →  (My device tab) →  (Home screen mode).
2. Tap the pull-down Dropbox and select one of the following options:
  - **Basic mode**: provides conventional layout for the apps and widgets on your home screens.
  - **Easy mode**: provides easier user experience for first-time smartphone users on the home screens.
3. Tap **Apply** and give your device a few seconds to update the device with the new look and feel.

## Call Settings

To configure the Ripple effect:

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Ripple effect**. The feature is active when a checkmark appears.

To access the Call settings menu:

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings**.

### Configuring General Call Settings

Configure the general call settings using this option.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings**.

— or —

From the Home screen, press  and then tap **Settings** →  (My device tab) → **Call**.

3. Tap one of the following options:
  - **Call rejection**: allows you to manage your rejection mode and rejection list.
    - **Auto reject mode**: sets the phone to automatically reject incoming calls or messages.

- **Auto reject list:** provides access to current rejection entries and numbers.
- **Set up call reject messages:** allows you to manage both existing rejection messages and create new ones.
- **Answering/ending calls:** allows you to manage the settings for answering and ending calls.
  - **The home key answers calls** allows you to press  to answer the phone.
  - **Voice control** allows you to answer incoming voice calls using voice.
  - **The power key ends calls** allows you to press the power key to end the current call.
- **Turn off screen during calls:** allows you to force the screen to turn off during an active call.
- **Call alerts:** allows you to assign call alert tones and activate call alerts and vibration.
  - **Call vibrations:** vibrates the phone when the called party answers.
  - **Call status tones:** assigns sounds settings during the call. Choose from: Call connect tone, Minute minder, and Call end tone.

- **Alerts during calls:** selects whether alarm and message notification is turned off during a call.
- **Call accessories:** allows you to assign headset settings during incoming calls.
  - **Automatic answering** configures the device to automatically answer and incoming call when a headset is detected.
  - **Automatic answering timer** configures the time delay before the device automatically accepts the incoming call.
  - **Outgoing call conditions** configures the connected Bluetooth device to make outbound calls within one of two settings: Even when device locked or Only when device unlocked.
- **Wi-Fi Calling:** Allows you to both activate/deactivate the Wi-Fi Calling feature and configure its settings. For more information, refer to “*Wi-Fi Calling*” on page 81.

---

**Note:** If the Wi-Fi Calling feature is active and connected, the Call forwarding feature is greyed-out and inaccessible.

---

- **Additional settings:** allows you to configure additional call settings. For more information, refer to “*Configuring Additional Voice Call Settings*” on page 310.

- **Ringtones and keypad tones:** allows you to manage your Device ringtone, Device vibration, Incoming call vibration, as well as Keytones used when the keypad is pressed.
- **Personalize call sound:** allows you to enable the personalize call sound function within an active call. You can adjust the audio by enabling selecting an audio preset. For more information, refer to “*Adjusting the Call Volume*” on page 84.
- **Noise reduction:** allows you to enable suppression of background audio.
- **Increase volume in pocket:** enables the ringtone volume to be increased when the device is in a pocket or bag.
- **Voicemail service:** allows you to assign the service.
- **Voicemail settings:** displays the settings for the voicemail.
- **Ringtone:** assigns your device's ringtone.
- **Vibrate:** configures the vibrate settings. Choose from Always, Only in Silent mode, or Never.
- **TTY mode:** allows you to configure the TTY settings. For more information, refer to “*TTY Mode*” on page 310.

## Call rejection

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Call rejection**.
3. Activate the feature by moving the **Auto reject mode** slider to the right.
4. Tap **Auto reject mode** and tap one of the following options:
  - **All numbers:** to reject all calls.
  - **Auto reject numbers:** to reject all calls in your Reject list.
5. Tap **Auto reject list**.
6. Tap  to manually add numbers to the Reject list.
7. Tap **Unknown** to create a check mark and automatically reject all calls that are not in your Contacts list.

DRAFT  
Internal Use Only

## Set reject messages

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Set up call reject messages**.
3. Tap  to manually add a reject message.  
– or –

Tap one of the pre-written messages to be displayed when you want the call to be rejected. You can edit the message if desired.

4. Tap **Save** to save the reject message.

## Answering/ending calls

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Call settings** → **Answering/ending calls**.
3. Select any of the following options:
  - **The home key answers calls** allows you to press  to answer the phone.
  - **Voice control** allows you to answer incoming voice calls using voice.

- **The power key ends calls** allows you to press the power key to end the current call.

## Turn off screen during calls

This option turns on the proximity sensor during calls so that your phone will know to turn the screen off to save power.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Turn off screen during calls** to create a check mark and enable the feature.

## Call alerts

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Call alerts**.
3. Tap **Call vibrations** to enable your phone to vibrate when the called party answers the phone.
4. Tap **Call status tones** to set the sound settings during a call then tap **OK**.
5. Tap **Alerts during calls** to turn off alarm and message notifications during a call.

DRAFT  
Internal Use Only

## Accessory settings for call

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Call accessories**.
3. The following options are available:
  - **Automatic answering:** configures the device to automatically answer and incoming call when a headset is detected.
  - **Automatic answering timer:** configures the time delay before the device automatically accepts the incoming call.
  - **Outgoing call conditions:** allows you to make calls even when the device is locked.

## Personalize call sound

This option allows you to personalize the sounds you hear during a call with and without earphones.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Call settings**.
3. Tap **Personalize call sound** and activate the feature by selecting an available option.

For more information, refer to “*Personalizing the Call Sound Setting*” on page 85.

## Ringtones and keypad tones

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Ringtones and keypad tones**.
3. Tap **Ringtones**, select a ringtone, and tap **OK**.
  - Tap **Add** to locate an audio file to create as a ringtone.
4. Tap **Vibrations**, select a vibration type, and tap **OK**.
  - Tap **Create** to begin creating your own custom vibration.
5. Tap **Vibrate when ringing** to create a check mark if you want your phone to vibrate when a call is incoming.
6. Tap **Keypad tones** to create a check mark if you want tones to play when the keypad is pressed.

## Noise reduction

This option allows you to suppress background noise during a call.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Noise reduction** to create a check mark and enable the feature.

## Increase volume in pocket

This option increases the ringtone volume when the device is in a pocket or a bag. It uses the proximity sensor to detect its location.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Increase volume in pocket** to create a check mark and enable the feature.

## TTY Mode

A TTY (also known as a TDD or Text Telephone) is a telecommunications device that allows people who are deaf, hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your device is compatible with select TTY devices. Please check with the manufacturer of your TTY device to ensure that it is compatible with digital cell phones.

Your phone and TTY device will connect via a special cable that plugs into your phone's headset jack. If this cable was not provided with your TTY device, contact your TTY device manufacturer to purchase the connector cable.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **TTY mode**.
3. Tap **TTY Full**, **TTY HCO**, or **TTY VCO** to activate the feature, or **TTY Off** to deactivate the feature. Off is the default setting.

## Configuring Additional Voice Call Settings

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings**.
3. Tap one of the following options:
  - **Caller ID**: chooses whether your number is displayed when someone answers your outgoing call. Choose from: Network default, Hide number, or Show number.
  - **Call forwarding**: configures the forwarding settings. For more information, refer to “*Configuring Call Forwarding*” on page 311.
  - **Auto area code**: allows you to automatically prepend a specific area code to all outbound calls.
  - **Call barring**: blocks specific types of calls (All outgoing calls, International calls, etc.).

- **Call waiting:** notifies you of an incoming call while you are on another call.
- **Auto redial:** automatically redial the dialed number if it is unable to connect or the call is cut off.
- **Fixed Dialing Numbers:** manages fixed dialing numbers. See description below.

## Configuring Call Forwarding

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings** → **Call forwarding**.

---

**Important!** Call Forwarding is disabled when the Wi-Fi Calling feature is enabled.

---

3. Tap an available option:
  - **Always forward:** incoming calls are re-routed to a secondary number that you specify.
  - **Forward when busy:** forwards all your calls to voicemail when your phone is busy.

- **Forward when unanswered:** automatically forwards to your voicemail number when the phone is not answered, and otherwise allows you to enter a voicemail number.
- **Forward when unreachable:** automatically forwards to your voicemail number when the phone is not in service, or is turned off.

## Using Auto Area Code

This feature prepends an area code to all outbound calls. When enabled, the designated prefix is always added before your dialed numbers.

Ex: If you were using 999 as your area code, 555-5555 would be dialed as 999 - 555-5555.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings**.
3. Tap **Auto area code**, enter a new prefix, and then tap **OK**.
4. In a single motion, drag the slider to the right to turn it on .

DRAFT  
Internal Use Only

## Call barring

Configures the device to barr (prevent) selected outbound calls.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings**.
3. Tap **Call barring** and select from the available settings. Choose from: All outgoing calls, International calls, Intl' calls except home, All incoming calls, or Incoming while roaming.

## Call waiting

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings**.
3. Tap **Call waiting** to enable/disable the on-screen notification of new incoming call during an active call.

## Fixed Dialing Numbers

Fixed Dial Number (FDN), allows you to restrict outgoing calls to a limited set of phone numbers.

### Enabling FDN

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings** → **Additional settings** → **Fixed dialing numbers**.
3. Tap **Enable FDN**.
4. At the prompt, enter your PIN2 code and tap **OK**.

---

**Important!** Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering an incorrect PIN2 code could cause the phone to lock. Contact customer service for assistance.

---

DRAFT  
Internal Use Only

## Changing the PIN2 Code

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings → Additional settings → Fixed dialing numbers**.
3. Tap **Change PIN2**.
4. At the prompt, enter your old PIN2 code.
5. At the prompt, enter a new PIN2 code.
6. Confirm your PIN2 code.

---

**Important!** Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering the PIN2 incorrectly three times will cause the device to lock. Contact customer service for assistance.

---

## Managing the FDN List

When this feature is enabled, you can make calls only to phone numbers stored in the FDN list on the SIM card.

1. From the Home screen, tap  (Phone).
2. Press  and then tap **Call settings → Additional settings → Fixed dialing numbers**.
3. Tap **Enable FDN**.
4. At the prompt, enter your PIN2 code and tap **OK**.  
FDN is enabled.
5. Tap **FDN list** then press  and then tap **Add contact** or edit the contacts that were stored.

---

**Important!** Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering the PIN2 incorrectly three times will cause the device to lock. Contact customer service for assistance.

---

DRAFT

Internal Use Only

## Voicemail

You can view your voicemail number from this menu.

1. From the Home screen, tap  (**Phone**).
2. Press  and then tap **Call settings** → **Voicemail service**.
3. Tap **Voice Mail**.
4. If an additional voicemail service is in use (other than carrier), tap **Voice settings** to now view your selected voicemail number and information.

## Blocking Mode

When Blocking mode is enabled, notifications for selected features will be disabled. You will only receive notifications of incoming calls from people on your allowed list.

1. From the Home screen, press  and then tap **Settings** →  (**My device** tab).
2. In a single motion touch and slide the **Blocking mode** slider to the right to turn it on.  
Confirm the Blocking mode active icon  appears in the Status bar.
3. Place a green check mark adjacent to those features you would like to enable. Choose from: Disable incoming calls, Disable notifications, Disable alarm and timer, Disable LED indicator.
4. Configure a timeframe for these features to be active. Remove the check mark from the **Always** field to configure the **From** and **To** time fields.

DRAFT

Internal Use Only

5. Tap **Allowed contacts** to assign those contacts that are exempted from these rules. Choose from None, All contacts, Favorites, or Custom. Allowed contacts will then appear in the **Allowed contact list**.

## Accessory

This menu allows you to select the Audio output mode when using a car or desk dock.

1. From the Home screen, press  and then tap **Settings** →  (**My device tab**) → **Accessory**.
2. Tap **Dock sound** to play sounds when inserting or removing the phone from the dock.
3. Tap **Audio output mode** to use the external dock speakers when the phone is docked.
4. Tap **Automatic unlock** if you are using a phone cover and you want your phone to unlock when you open the cover.
5. Tap **Audio output** to set your Audio output to Stereo or Surround.

## Accessibility Settings

This service lets you enable and disable downloaded accessibility applications that aid in navigating your Android device, such as TalkBack (uses synthesized speech to describe the results of actions), KickBack (provides haptic feedback for actions), and SoundBack (plays sounds for various actions). Also lets you enable use of the power key to end calls.

1. From the Home screen, press  and then tap **Settings** →  (**My device tab**) → **Accessibility**.

---

**Note:** Initially, it might be necessary to download accessibility applications from the Play Store.

---

2. Select the **Auto-rotate screen** field to activate this feature which automatically rotates an available screen.
3. Tap **Screen timeout** to timeout the accessibility feature after a defined amount of time.
4. Tap **Lock automatically** to lock the screen automatically after a selected amount of time.

DRAFT  
Internal Use Only

---

**Note:** The Lock automatically function is only available if your device is already using the screen lock feature.

---

5. Select the **Speak passwords** field to activate this feature which reads out password information.
6. Select **Answering/ending calls** field to select the methods you can use to answer and end a call.
7. Tap **Show shortcut** allows you to press and hold  (**Power/End**) to use the accessibility shortcut under the Device options screen.
8. Tap **Manage accessibility** to save and update your accessibility settings or share them with another device. You can export your settings, import a previously saved file, or share your file with another device.
9. Tap **TalkBack** to activate the feature.

---

**Note:** TalkBack, when installed and enabled, speaks feedback to help blind and low-vision users.

---

---

**Important!** TalkBack can collect all of the text you enter, except passwords, including personal data and credit card numbers. It may also log your user interface interactions with the device.

---

10. Tap the **Font size** field to change the size of the fonts used on the device within menus, options, etc..  
Choose from: Tiny, Small, Normal, Large, or Huge.
11. Enable **Magnification gestures** to use exaggerated gestures such as triple-tapping, double pinching, and dragging two fingers across the screen.
12. Tap the **Negative colors** field to reverse the display of on-screen colors from White text on a Black background to Black text on a White background.
13. Select **Color adjustment** to allow you to adjust the display colors if you are color blind and have difficulty reading the display because of the colors. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.

DRAFT  
Internal Use Only

14. Tap **Accessibility shortcut** to allow you to quickly enable accessibility features in 2 quick steps. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.
15. Tap the **Text-to-speech output** field to configure the text to speech configuration parameters.
16. Tap the **Enhance web accessibility** field to allow apps to install scripts from Google that make their Web content more accessible.
17. Use the **Sound balance** field to allow you to use the slider to set the Left and Right balance when using a stereo device.
18. Tap the **Mono audio** field to enable stereo audio to be compressed into a single mono audio stream for use with a single earbud/earphone.
19. Tap the **Turn off all sounds** field to mute every sound made by the device during taps, selections, notifications, etc..
20. Tap **Flash notification** to allows you to set your camera light to blink whenever you receive a notification.
21. Enable the **Assistant menu** to allow you to improve the device accessibility for users with reduced dexterity. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.
22. Tap the **Tap and hold delay** field to select a time interval for this action. Choose from: Short, Medium, or Long.
23. Enable **Interaction control** to allows you to enable or disable motions and screen timeout. You can also block areas of the screen from touch interaction. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.

DRAFT  
Internal Use Only

## Language and Input Settings

This setting allows you to configure the language in which to display the menus. You can also set on-screen keyboard options.

- From the Home screen, press  and then tap **Settings** →  (My device tab) → **Language and input**.

### Language Settings

To set the language that the menus display on the phone:

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Language and input** → **Language**.
2. Select a language and region from the list.

### Choose Input Method

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Language and input** → **Default**.
2. Select an input method.  
– or –  
Tap **Set up input methods** to alter/modify the available input methods.

## Configure Google Voice Typing

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Language and input**.  
– or –

From a screen where you can enter text, in a single motion, touch and drag the Status bar down to the bottom of the screen, then select  (**Choose input method**) → **Set up input methods**.

2. Tap  (adjacent to the **Google voice typing** field).
3. Select a language by tapping **Choose input languages** area.
4. Remove the check mark from the **Automatic** field. This allows you to select additional languages.
5. Select the desired languages.
6. Activate **Block offensive words** to block recognition of known offensive words or language. (A green check mark indicates the feature is active).
7. Tap **Download offline speech recognition** to enable speech recognition via locally stored files so that even if you are not connected to a network you can still use the service.

## Samsung Keyboard Settings

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Language and input** →  (adjacent to the **Samsung keyboard** field).  
– or –

From within an active text entry screen, touch and hold  (**Input Methods**), drag across the icons, and select  (**Settings**) to reveal the **Samsung keyboard settings** screen.

2. Set any of the following options:
  - **Portrait keyboard types** allows you to choose a keyboard configuration (Qwerty keyboard [default] or 3x4 keyboard).
  - **Input language** sets the input language. Tap a language from the available list. The keyboard is updated to the selected language.
  - **Predictive text** enables predictive text entry mode. This must be enabled to gain access to the advanced settings. Touch and hold to access the advanced settings.

- **Continuous input** like using Swipe, allows you to enter text by sliding your fingers across the on-screen keyboard. This feature is optimized for use with the on-screen QWERTY keyboard.
- **Cursor control** when enabled, allows you to control your on-screen cursor by moving your finger across the keyboard.
- **Handwriting** allows you to configure the handwriting settings such as: Input languages, Recognition type, Recognition time, Pen thickness, Pen color, and About.
- **Advanced** provides access to additional settings such as:
  - **Auto capitalization** automatically capitalizes the first letter of the first word in each sentence (standard English style).
  - **Auto spacing** automatically inserts space between words.
  - **Auto-punctuate** automatically inserts a full stop in a sentence by tapping the space bar twice when using the on-screen QWERTY keyboard.
  - **Character preview** provides an automatic preview of the current character selection within the text string. This is helpful when multiple characters are available within one key.
  - **Key-tap vibration** enables vibration feedback when you tap an on-screen key.

DRAFT  
Internal Use Only

- **Key-tap sound** enables auditory feedback when you tap an on-screen key.
- **Help** launches a brief on-screen help tutorial covering the main concepts related to the Samsung keyboard.
- **Reset settings** resets the keyboard settings back to their original configuration.

## Predictive Text - Advanced Settings

The predictive text system provides next-letter prediction and regional error correction, which compensates for users pressing the wrong keys on QWERTY keyboards.

---

**Note:** Only available when ABC mode is selected. Predictive text advanced settings are available only if the Predictive function is enabled.

---

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Language and input** →  (adjacent to the **Samsung keyboard** field).  
– or –

From within an active text entry screen, touch and hold  (**Input Methods**) →  to reveal the **Samsung keyboard settings** screen.

2. In a single motion touch and slide the **Predictive text** slider to the right to turn it on .
3. Tap the **Predictive text** field and configure any of the following advanced options:
  - **Personalized data** activate this feature to use the personal language data that you have entered and selected to make your text entry prediction results better. By enabling this feature you can choose from the following personalization features:
  - **Learn from Facebook** allows you to log into your current Facebook account and add used text to your personal dictionary.
  - **Learn from Gmail:** allows you to sign in to your existing Gmail account from where your style and existing contact information is added to your personal dictionary. Helps recognize familiar names.
  - **Learn from Twitter** allows you to sign into your existing Twitter account and add used text to your personal dictionary.
  - **Learn from Messaging** allows your device to learn your messaging style by using your Messaging information.
  - **Learn from Contacts** updates predictive style by learning your Contacts style.

- **Clear remote data** allows you to delete your anonymous data stored on the personalization server.
  - **Clear personalized data** removes all personalized data entered by the user.
4. Press  to return to the previous screen.

## Swype Settings

### To configure Swype settings:

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Language and input** →  (adjacent to the **Swype** field).
2. Tap **How to Swype** to view an on-screen manual for Swype.
3. Tap **Gestures** to view an on-screen reference page related to Gesture usage.
4. Tap **Preferences** to alter these settings:
  - **Vibrate on keypress**: activates a vibration sensation as you enter text using the keypad.
  - **Sound on keypress**: turns on sounds generated by the Swype application.
  - **Show helpful tips**: turns on a flashing indicator for quick help.

- **Auto-spacing**: automatically inserts a space between words. When you finish a word, just lift your finger or stylus and start the next word.
- **Auto-capitalization**: automatically capitalizes the first letter of a sentence.
- **Show complete trace**: once enabled, sets whether or not to display the complete Swype path.
- **Pop-up on keypress**: once enabled, displays a character above an on-screen key while typing.
- **Next word prediction**: once enabled, predicts the next word in your text string based on your current text entries.

---

**Note:** If incorrect words are being entered as you type, disabled this feature.

---

- **Reset Swype's dictionary**: once enabled, deletes any words you have added to Swype's dictionary.
  - **Version**: displays the software version information.
5. Tap **Language Options** to activate and select the current text input language. Default language is US English.
- **Living language**: allows you to automatically update Swype with popular new words. Tap **Accept** to continue the process.

6. Tap **Swype Connect** to activate social media personalization and configure data settings.
- **Register now:** allows you register for the Swype Connect service which allows you to backup your Swype dictionary and sync your Swype dictionary across multiple devices.
    - Follow the on-screen instructions to backup and sync your dictionary based on an email address.
    - Enter the activation code received after your email has been confirmed.
  - **Backup & Sync:** when active, allows you to backup your Swype dictionary and sync your Swype dictionary across multiple devices.
  - **Contribute usage data:** when enabled, allows the Nuance® application to collect usage data for better word predictions.
  - **Cellular data:** when enabled, activates cellular data usage by the Swype application so it can receive program updates, language downloads, and other related features via your existing data connection.

7. Tap **Personalization** to access and manage your personal dictionary. Log into the available accounts to add help personalize your personal dictionary with commonly used words or names from your available accounts.
- **Edit Dictionary:** allows you to edit your current personal Swype dictionary.
  - **Facebook:** allows you to log into your current Facebook account from where contact names are added to your Swype's personal dictionary for later use when you enter names into text fields. Helps recognize familiar names.
  - **Twitter:** allows you to sign into your existing Twitter account from where names and words are added to your personal dictionary. Helps recognize familiar names and words.
  - **Gmail:** allows you to sign in to your existing Gmail account from where existing contact information is added to your personal dictionary. Helps recognize familiar names.
8. Tap **Updates** to update the application if new software is available.

DRAFT

Internal Use Only

## Configuring Voice Input Recognition

This feature allows the device to correctly recognize verbal input.

1. From the Home screen, press  and then tap **Settings → My device tab → Language and input**.
2. Tap **Voice search** to configure the following:
  - **Language:** Choose a language for your voice input.
  - **Speech output:** Sets whether you will use speech output always or only when using hands-free.
  - **Block offensive words:** Enable or disable blocking of recognized offensive words from the results of your voice-input Google searches.
  - **Hotword detection:** Enable to being able to launch voice search by saying the word “Google”.
  - **Download offline speech recognition:** Enables voice input while offline.
3. Press  to return to the previous screen.

## Configuring Text-to-speech

This feature allows the device to provide a verbal readout of on-screen data such as messages and incoming caller information. This action is called TTS (Text To Speech).

1. From the Home screen, press  and then tap **Settings → My device tab → Language and input → Text-to-speech output**.
2. Select a current Preferred TTS engine from the list of available options. Select **Google Text-to-speech Engine** or **Samsung TTS**. The default is Google Text-to-speech.
3. Tap  next to the preferred TTS engine configure the following settings:
  - **Language:** allows you to set the language for spoken text.
  - **Settings for Google Text-to-speech Engine:** allows you to view Open Source Licenses.
  - **Settings for Samsung text-to-speech:** allows you to configure the General settings for the Samsung TTS.
  - **Install voice data:** allows you to install voice data for speech synthesis.

DRAFT  
Internal Use Only

4. Configure the General options to alter the settings associated with this feature:
  - **Speech rate:** adjusts the rate at which on-screen text is spoken by the device. Choose from: **Very slow**, **Slow**, **Normal**, **Fast**, and **Very fast**.
  - **Listen to an example:** plays a short example of what the text-to-speech feature sounds like on your device when activated.

### Configuring the Mouse-TrackPad

This feature allows you to configure the pointer speed for the mouse/trackpad.

1. From the Home screen, press  and then tap **Settings → My device tab → Language and input → Pointer speed**.
2. Adjust the slider and tap **OK**.

## Motions and Gestures Settings

This feature allows you to assign specific functions to certain phone actions that are detected by both the accelerometer and gyroscope.

---

**Caution!** Excessive shaking or impact to the device may cause unintended results. To learn how to properly control motions, tap  (**Apps**) → **Settings** → **My device tab** → **Motions and gestures**. When tapped, each entry comes with an on-screen tutorial.

---

- **Air gesture:** Allows you to control your device by performing motions above the sensor (without touching the device).
- **Motion:** Allows you to control your device using natural movements (on the screen).
- **Palm motion:** Allows you to control your device by touching the screen with your entire hand.
- **Gyroscope calibration:** Allows you to properly calibrate your device's touch screen.

DRAFT

Internal Use Only

### To activate Air gesture:

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Motions and gestures**.
2. In a single motion touch and slide the **Air gesture** slider to the right to turn it on.
3. Read the on-screen notification and tap **OK**.

---

**Note:** At least one feature must be activated before Air gesture can be activated.

---

4. Tap **Learn about the sensor and icon** field to review on-screen information about the Airgestures sensor and related icon.
5. In a single motion, slide a feature's activation slider to the on position (   ).

The following is a description some of the most commonly used gestures:

- **Quick glance:** Once enabled, you can move your hand over the air gesture sensor (located above the on-screen clock at the upper-right) to temporarily activate preview window that can be used to display selected user-enabled information such as: Time & Date, Notification icons, Missed calls, etc..
- **Air jump:** Once enabled, you can move your hand over the air gesture sensor (up or down) and easily jump to either the top or bottom of a lengthy display page (ex: Internet or Email).
- **Air browse:** Once enabled, you can move your hand over the air gesture sensor (left or right) and easily move to either the previous or next item in a series (ex: music tracks, pictures, or pages).
- **Air move:** Once enabled, you can move use one finger to hold down on an app shortcut or event entry and then swipe across the air gestures sensor to then move it to a new a different page.
- **Air call-accept:** Once enabled, you can simply wave your hand over the air gesture sensor to accept any incoming call.

DRAFT  
Internal Use Only

### To activate Motion:

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Motions and gestures**.
2. In a single motion touch and slide the **Motion** slider to the right to turn it on.
3. Read the on-screen notification and tap **OK**.

---

**Note:** At least one feature must be activated before Motion can be activated.

---

4. In a single motion, slide a feature's activation slider to the on position (  ).

The following is a description some of the most commonly used gestures:

- **Direct call:** Once enabled, the device will dial the currently displayed on-screen Contact entry as soon as you place the device to your ear.
- **Smart alert:** Once enabled, pickup the device to be alerted and notified of you have missed any calls or messages.

- **Zoom:** Once enabled, you must be on a screen where content can be zoomed. In a single motion, touch and hold two points on the display then tilt the device back and forth to zoom in or out.
- **Browse an image:** Once enabled, touch and hold a desired on-screen image to pan around it. Move the device left or right to pan vertically or up and down to pan horizontally around the large on-screen image.
- **Update/refresh:** Once enabled, shake your device to rescan for Bluetooth devices, rescan for Wi-Fi devices, Refresh a Web page, etc..
- **Mute/pause:** Once enabled, mute incoming calls and any playing sounds by turning the device display down on a surface. This is the opposite of the Pickup to be Notified Gesture.

DRAFT  
Internal Use Only

### To activate Palm Motion:

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Motions and gestures**.
2. In a single motion touch and slide the **Palm motion** slider to the right to turn it on.
3. Read the on-screen notification and tap **OK**.

---

**Note:** At least one feature must be activated before Palm motion can be activated.


---

4. In a single motion, slide a feature's activation slider to the on position (   ).

The following is a description some of the most commonly used gestures:

- **Capture screen:** Once enabled, you can capture any on-screen information swiping across the screen. In a single motion, press the side of your hand on the screen and swipe from left to right. The image is then copied to the clipboard.

Palm Swipe to Screen Capture



- **Mute/pause:** Once enabled, you can pause any on-screen video or mute any current sound by simply covering the screen with your hand. Once you remove your hand from the screen, the device goes back to normal by either continuing to play the current video or unmuting the current sound.

DRAFT  
Internal Use Only

## Gyroscope Calibration

Calibrate your device by using the built-in gyroscope.

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Motions and gestures** → **Gyroscope calibration**.
2. Place the device on a level surface and tap **Calibrate**. The phone adjusts the level of the accelerometer. During the calibration process a green circle appears on-screen and the center circle adjusts to the center position.

## Smart screen

The Smart screen options allow you to customize your screen settings to make the screen more responsive and easier to use.

1. From the Home screen, press  and then tap **Settings** →  (My device tab) → **Smart screen**.
2. Tap any of the following options to create a checkmark and activate the features:
  - **Smart stay**: disables the screen timeout if your phone detects that your face is watching the screen.

- **Smart rotation**: disables the auto screen rotation by checking the orientation of your face and the device.
- **Smart pause**: pauses videos when your device detects that your head has moved away from the screen.
- **Smart control**: once your eyes have been detected, the screen will scroll according to your device's tilt angle. Tap the adjacent field to the right of the Smart scroll field to activate the feature. With Smart scroll, the screen will scroll depending on the phone's tilt angle once your eyes have been detected.

## Air view

With the Air view feature, you can hover your finger over the screen and Air view features will be displayed. For example, you can hover your finger over a scheduled item in your calendar to see more details.

1. From the Home screen, press  and then tap **Settings** → **My device** tab → **Air view**.
2. Tap the ON/OFF icon  at the top of your screen to activate Air view.

3. The following options are available. Tap an option to create a checkmark and activate the feature.
- **Information preview:** allows you to see information previews, extended text, and enlarged images when you hover your finger over the screen.
  - **Progress preview:** allows you to preview a scene or show elapsed time when you hover your finger over the progress bar while watching a video.
  - **Speed dial contacts:** allows you to see the contacts and their speed dial numbers when you hover your finger over them in your contacts list.
  - **Webpage magnifier:** allows you to see magnified links on webpages when you hover your finger over them.
  - **Sound and haptic feedback:** allows you to play sound and feel vibration when you hover your finger over Air view items.

## Voice control

The Voice control settings allow you to set up voice commands to control your device.

1. From the Home screen, press  and then tap **Settings → My device tab → Voice control**.
2. Verify the feature is active by tapping  at the top of your screen to activate Voice control.
3. The following options are available. Tap an option to create a checkmark and activate the feature.
  - **Incoming calls:** allows you to answer or reject calls using the commands **Answer** and **Reject**.
  - **ChatON:** allows you to answer or reject calls using the commands **Answer** and **Reject**.
  - **Alarm:** allows you to stop or snooze an alarm by using the commands **Stop** and **Snooze**.
  - **Camera:** allows you to take pictures using the voice commands **Smile**, **Cheese**, **Capture**, or **Shoot**.
  - **Music:** allows you to control your Music player using the voice commands **Next**, **Previous**, **Pause**, **Play**, **Volume Up**, and **Volume Down**.

DRAFT  
Internal Use Only

---

**Note:** If you set the alert type for calls or alarms to vibration, voice control will not be available.

---

## Add Account

This menu allows you to set up, manage, and synchronize accounts, including your Google and email accounts.

### Adding an Account

1. From the Home screen, press  and then tap **Settings** →  (**Accounts** tab) and then navigate to the **My accounts** area.
2. Tap **Add account** and select one of the account types.
3. Use the keyboard and follow the prompts to enter your credentials and set up the account.
4. A green circle will appear next to the account type once you have created an account. Your email account will also be displayed in the **Accounts** section of the main Settings menu.

## Removing an Account

---

**Important!** Removing an account also deletes all of its messages, contacts, and other data from the device.

---

1. From the Home screen, press  and then tap **Settings** →  (**Accounts** tab) and then navigate to the **My accounts** area.
2. Tap the account name.
3. From the Accounts area of the screen, tap the account entry.
4. Tap **Remove account**, then tap **Remove account** at the prompt to remove the account and delete all its messages, contacts, and other data.

### Synchronizing a Accounts

By default, all managed accounts are synchronized. You can also manually sync all current accounts.

1. From the Home screen, press  and then tap **Settings** →  (**Accounts** tab) and then navigate to the **My accounts** area.
2. Tap the account name.

3. Tap the account name entry.
4. Tap **Sync now** to synchronize your account or tap **Sync all** to synchronize all your accounts. Tap **Cancel sync** to stop the synchronization.
5. Tap **Settings** to access your account settings.

## Cloud

This feature allows you to use your external cloud storage solution to both synchronize your device to your Samsung account and then backup that local content to the cloud. Your device comes with a built-in Cloud storage solution known as Dropbox.

---

**Important!** This feature requires an active Wi-Fi connection prior to use.

---

1. Log into your Samsung account and verify it is active. For more information, refer to “*Creating a Samsung Account*” on page 21.
2. Log into your external cloud storage solution. In our case we are using a Dropbox account. For more information, refer to “*Dropbox*” on page 215.
3. From the Home screen, press  and then tap **Settings** →  (Accounts tab) → **Cloud**.
4. Confirm your Samsung account appears at the top of the screen.

DRAFT

Internal Use Only

5. Tap **Sync settings**, select which device parameters will be synched, and tap **Sync now**. Choose from: Sync Calendar, Sync Contacts, Sync Internet bookmarks, Sync Internet opened pages, and Sync Memo.
6. Tap **Backup or Restore** to launch the feature.
- **Back**: manually loads up the currently selected categories and backs up the data to your cloud storage location. Tap **Backup** to begin the manual backup process.
  - **Restore**: allows you to retrieve your previously backed up data from your Samsung account and then download it to your device.

## Backup and Reset

Location settings, backup configurations, or reset the phone to erase all personal data.

- From the Home screen, press  and then tap **Settings** →  (Accounts tab) → **Backup and reset**.

### Mobile Backup and Restore

The device can be configured to back up your current settings, application data and settings.

1. From the Home screen, press  and then tap **Settings** → **Accounts tab** → **Backup and reset**.
2. Tap **Back up my data** to create a backup of your current phone settings and applications.
3. Tap **Backup account** to assign the account being backed up.
4. Tap **Automatic restore** to assist in the re-installation of a previously installed application (including preferences and data).

DRAFT  
Internal Use Only

5. Tap **Factory data reset** to reset your device and sound settings to the factory default settings. For more information, refer to “*Factory Data Reset*” on page 333.
6. Tap **Collect diagnostics** to collect diagnostic data for troubleshooting use. For more information, refer to “*Collect Diagnostics*” on page 333.

### Prior to doing a Factory Reset

Before initiating a factory reset, it is recommended that you backup your personal data prior to use.

#### To export a Contact list to your microSD card:

1. From the Home screen, tap  (**Contacts**).
2. Press  and then tap **Import/Export**.
3. Tap **Export to SD card** → **OK**. For more information, refer to “*Export/Import*” on page 127.

#### Verify your images and videos are on your microSD card:

1. From the Home screen, tap  (**Applications**) →  (**Gallery**).
2. Verify the Gallery contains all of your pictures and videos.

3. Remove both the back cover and remove the internal microSD card prior to initiating the process.

### Factory Data Reset

From this menu you can reset your device and sound settings to the factory default settings.

1. From the Home screen, press  and then tap **Settings** → **Accounts** tab → **Backup and reset** → **Factory data reset**.
2. Read the on-screen reset information.
3. Tap **Reset device**.
4. If necessary, enter your password and tap **Delete all**. The device resets to the factory default settings automatically and when finished displays the Home screen.

### Collect Diagnostics

This feature only collects diagnostic data for troubleshooting use.

1. From the Home screen, press  and then tap **Settings** → **Accounts** tab → **Backup and reset** → **Collect diagnostics**.

2. Read the on-screen System Manager Application information.

---

**Note:** This software collects only diagnostic data from your device so that T-Mobile technicians can better troubleshoot issues with your device.

---

3. Choose to enable or disable the feature by placing a check mark in the **Allow Diagnostics** field.
4. Select either **More Info..** (to read additional information) or **Close** to close the message screen.

---

**Important!** Selecting **Close** only closes the current description screen and does not disable data collection. To disable data collection, go to **Settings → Back up and reset → Collect diagnostics** and turn off the **Allow Diagnostics** feature.

---

## Location Services

The Location services allows you to configure the device's location services.

---

**Important!** The more location determining functions are enabled, the more accurate the determination will be of your position.

---

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **Location services**.
2. Tap any of the following options to create a checkmark and activate the service:
  - **Access to my location:** allows apps that have asked your permission to use your location information. Tap the ON/OFF slider to turn it on.
  - **Use GPS satellites:** allows applications to use GPS to pinpoint your location.
  - **Use wireless networks:** allows applications to use data from mobile networks and Wi-Fi to help determine your location.
  - **My places:** allows you to add location information for your Home, Office, and Car.

DRAFT  
Internal Use Only

## Enabling the GPS Satellites

1. From the Home screen, press  and then tap **Settings → More tab → Location services**.
2. Tap **Use GPS satellites** to enable the GPS satellite.

## Using Wireless Networks

Before you use applications such as Google Maps and find your location or search for places of interest, you must enable the Use wireless networks option.

1. From the Home screen, press  and then tap **Settings → More tab → Location services**.
2. Tap **Use wireless networks** to allow apps to use data from sources such as Wi-Fi and mobile networks to provide a better approximation of your current location.

## Enabling My Places

1. From the Home screen, press  and then tap **Settings → More tab → Location services**.
2. Tap **My places** to enable the storage of your favorite locations.

## Security

The Security settings allow you to determine the security level for your device.

### Encrypt Device

When enabled, this feature requires a numeric PIN or password to decrypt your phone each time you power it on or encrypt the data on your SD card each time it is connected:

1. From the Home screen, press  and then tap **Settings →  (More tab) → Security**.
2. Tap **Encrypt device**. For more information, read the displayed help screen.
3. Tap **Encrypt external SD card** to enable the encryption on SD card data that requires a password be entered each time the microSD card is connected.

---

**Tip:** Make sure your battery is charged more than 80 percent. Encryption may take an hour or more.

---

DRAFT  
Internal Use Only

## Set up/change password

Use this option to set up your password when one is first required or change your current password.

1. From the Home screen, press  and then tap **Settings → More tab → Security → Set up/change password**.
2. Enter a new password and tap **Confirm**.
3. Enter the new password again and tap **Confirm**.

## Setting up SIM Card Lock

Prevent another user from using your SIM card to make unauthorized calls or from accessing information stored on your SIM card by protecting the information using a PIN code.

When enabled, your phone will ask for a PIN number each time you use the phone. Using this option you can also change your SIM PIN number.

1. From the Home screen, press  and then tap **Settings → More tab → Security**.
2. Tap **Set up SIM card lock**.
3. Tap **Lock SIM card**, enter your SIM PIN code, then tap **OK**.

---

**Note:** You must activate Lock SIM card before you can change your SIM PIN code.

---

### To change an existing SIM Card PIN:

1. Tap **Change SIM PIN**.
2. Enter the old SIM PIN code and tap **OK**.
3. Enter the new SIM PIN code and tap **OK**.
4. Re-type the new SIM PIN code and tap **OK**.

## Password Settings

When you create a phone password you can also configure the phone to display the password as you type it instead of using an asterisk (\*).

1. From the Home screen, press  and then tap **Settings → More tab → Security**.
2. Tap **Make passwords visible** to activate this feature.

DRAFT  
Internal Use Only

## Device Administration

Activating this feature allows Google to administrate your phone in a way similar to IT security settings on a corporate PC. This would be beneficial in the case that your phone was lost or stolen. The phone could be “deactivated” or “restricted” (through administration) from a remote location.

1. From the Home screen, press  and then tap **Settings → More tab → Security**.
2. Tap **Device administrators** to begin configuring this setting.
3. Select an administrator device and follow the prompts.

## Unknown Sources

Before you can download a web application you must enable the Unknown sources feature (enables downloading). Developers can use this option to install non-Play Store applications.

1. From the Home screen, press  and then tap **Settings → More tab → Security**.
2. Tap **Unknown sources** to active this feature.

---

**Note:** If you are notified that you can not download a Play Store application because it comes from an “Unknown source”, enabling this option corrects this issue.

---

## Credential Storage

This option allows certain applications to access secure certificates and other credentials. Certificates and credentials can be installed to the SD card and password protected.

1. From the Home screen, press  and then tap **Settings → More tab → Security**.
2. Tap **Trusted credentials** to display only trusted CA certificates. A check mark displayed next to the feature indicates secure credentials.
3. Tap **Install from device storage** to install encrypted certificates from the USB Storage location.
4. Tap **Clear credentials** to clear the device (SD card or phone memory) of all certificate contents and reset the credentials password.

DRAFT  
Internal Use Only

## Application Manager

This device can be used for Android development. You can write applications in the SDK and install them on this device, then run the applications using the hardware, system, and network. This feature allows you to configure the device for development.

---

**Warning!** Because the device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

---

This menu allows you to manage installed applications. You can view and control currently running services, or use the device for application development.

You can also view the amount of memory or resources used as well as the remaining memory and resources for each of the applications on your phone and clear the data, cache, or defaults.

- From the Home screen, press  and then tap **Settings** →  (More tab) → **Application manager** → **ALL**.

## Clearing Application Cache and Data

---

**Important!** You must have downloaded applications installed to use this feature.

---

1. From the Home screen, press  and then tap **Settings** → **More** tab → **Application manager**.
2. Tap an application in which to clear the cache or data.
3. Tap **Force stop**, **Uninstall**, **Clear data**, **Clear cache**, or **Clear defaults**.

## Uninstalling Third-party Applications

---

**Important!** You must have downloaded applications installed to use this feature.

---

1. From the Home screen, press  and then tap **Settings** → **More** tab → **Application manager**.
2. Tap the **DOWNLOADED** tab and select your desired application.
3. Tap **Uninstall** (from within the top area of the Application info page).
4. At the prompt, tap **OK** to uninstall the application.

5. Select a reason for uninstalling the application, then tap **OK**.

## Memory Usage

See how memory is being used by Downloaded or Running applications.

1. From the Home screen, press  and then tap **Settings → More tab → Applications manager**.
2. Tap **DOWNLOADED**, **RUNNING**, or **ALL** to display memory usage for that category of applications.

The graph at the bottom of the Downloaded tab shows used and free device memory. The graph at the bottom of the Running tab shows used and free RAM.

## Downloaded

Displays apps you have downloaded onto your device.

1. From the Home screen, press  and then tap **Settings → More tab → Applications manager**.
2. Tap the **DOWNLOADED** tab to view a list of all the downloaded applications on your device.
3. To switch the order of the lists displayed in the Downloaded tabs, press  and select **Sort by size** or **Sort by name**.

4. Tap an application to view and update information about the application, including memory usage, default settings, and permissions.

## Running Services

The Running services option allows you to view and control currently running services such as Backup, Google Talk, SNS (messaging), Swype, and more.

1. From the Home screen, press  and then tap **Settings → More tab → Application manager**.
2. Tap the **RUNNING** tab to view all currently active and running applications. This tab also shows the total RAM being used by these currently active applications.
3. Tap a process and select **Stop** to end the process and stop it from running. When you stop the process the service or application will no longer run until you start the process or application again.
4. Tap **Show cached processes** to view additional cached applications.

---

**Important!** Stopping a process might have undesirable consequences on the application.

---

## Storage Used

This option allows you to view a list (on the current tab) of current applications as sorted by size.

1. From the Home screen, press  and then tap **Settings → More tab → Application manager**.
2. Tap the **ALL** tab to display all available applications.
3. Press  and then tap **Sort by size** to change the current list to show items based on the amount of storage they occupy.

## Reset App Preferences

This feature provides you with the ability to reset all preferences for the following features: Disabled apps, Disabled app notifications, Default applications for actions, and Background data restrictions.

1. From the Home screen, press  and then tap **Settings → More tab → Applications manager**.
2. Tap the **ALL** tab to display all available applications.
3. Press  and then tap **Reset app preferences → Reset apps**.

---

**Important!** As an example, if you assigned your browser to always launch YouTube links and want that changed, you must reset the default actions.

---

DRAFT  
Internal Use Only

## Battery Usage

This option allows you to view a list of those components using battery power. The amount of time the battery was used also displays. Battery usage displays in percentages per application.

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **Battery**. The battery level displays in percentage.
2. From the upper-right tap  (**Refresh**) to update the list.  
— or —

Tap an entry to view more detailed information.

---

**Note:** Other applications may be running that affect battery use.

---

## Power Saving Mode

This feature allows you both automatically set the phone to use a power saving mode and configure additional power saving options manually, all in an effort to conserve battery power.

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **Power saving mode**.
2. In a single motion touch and slide the slider to the right to turn it on.
3. Tap the following options to create a check mark and conserve power:
  - **CPU power saving:** allows you to limit the maximum performance of the CPU.
  - **Screen power saving:** allows you to lower the screen power level.
  - **Turn off haptic feedback:** allows you to turn off vibration when you tap or touch the screen.
4. Tap **Learn about Power saving** to learn about various ways to conserve battery power.

When the power gets low, confirm  appears at the top of the screen. This indicates the power saving mode is active.

## SD Card & Device Storage

From this menu you can view the memory allocation for the memory card as well as mount or unmount the SD card.

For more information about mounting or unmounting the SD card, see “Using the SD Card” on page 67.

**To view the memory allocation for your external SD card:**

- From the Home screen, press  and then tap **Settings** →  (More tab) → **Storage**.  
The available memory displays under the Total space and SD card headings.

## Date and Time

This menu allows you to change the current time and date displayed.

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **Date and time**.
2. Tap **Automatic date and time** to allow the network set the date and time.

---

**Important!** Deactivate **Automatic date and time** to manually set the rest of the options.

---

3. Tap **Set date** and use the plus or minus icons to set the **Month**, **Day**, and **Year** then tap **Set**.
4. Tap **Set time** and use the plus or minus icons, set **Hour**, and **Minute**. Tap **PM** or **AM**, then tap **Set**.
5. Tap **Automatic time zone** to allow the network set the time zone information automatically.
6. Tap **Select time zone**, then tap a time zone.
7. Tap **Use 24-hour format**. If this is not selected the device automatically uses a 12-hour format.
8. Tap **Select date format** and select the date format type.

## About Device

This menu contains legal information, system tutorial information, and other phone information such as the model number, firmware version, baseband version, kernel version, and software build number.

### To access phone information:

- From the Home screen, press  and then tap **Settings** →  (More tab) → **About device**. The following information displays:
  - **Software update:** allows you to connect to the network and upload any new phone software directly to your device. The device automatically updates with the latest available software when you access this option.
  - **Status:** displays the battery status, the level of the battery (percentage), the Network connection, Signal strength, Mobile network type, Service state, Roaming status, Mobile network state, My phone number, IMEI number, IP address, Wi-Fi MAC address, Bluetooth address, Serial number, Up time, and Device status.

- **Legal information:** This option displays information about Open source licenses, Google legal information, as well as License settings. This information clearly provides copyright and distribution legal information and facts as well as Google Terms of Service, Terms of Service for Android-powered Phones, and much more pertinent information as a reference. Read the information and terms, then press  to return to the Settings menu.

---

**Tip:** To find your device's DivX® registration code and information about registering your device to play DivX protected video, tap **License settings** → **DivX® VOD**.

---

- **Device name:** allows you to both display and edit the device's name.
- **Model number:** displays the device's model number.
- **Android version:** displays the firmware version loaded on this device.
- **Baseband version:** displays the baseband version loaded on this device.
- **Kernel version:** displays the kernel version loaded on this device.

- **Build number:** displays the software, build number.

---

**Note:** Firmware, baseband, kernel and build numbers are usually used for updates to the handset or support. For additional information please contact your T-Mobile service representative.

---

- **SELinux status:** displays the status of SELinux. SELinux is a set of security policies/modules which is applied to the device to improve the overall security.

## Software Update

The Software Update feature enables you to use your device to connect to the network and upload any new software directly to your device. The device automatically updates with the latest available software when you access this option.

The following icons show your Bluetooth connection status at a glance:



Displays when the Software updated feature is active.



Displays when the Software update feature is in progress.

### To update your device:

1. From the Home screen, press  and then tap **Settings** →  (More tab) → **About device** → **Software update**.
2. Read the Software update information screen.
3. Select an available option:

---

**Note:** You configure the device's software update parameters.

---

- **Cancel:** Tap this option to cancel the operation.
- **Wi-Fi settings:** Enable this option to only download available updates via an active Wi-Fi connection. If disabled, the device will begin available downloads via its' T-Mobile connection.
- **OK:** Tap this option to connect to the remote server, detect if there is an available update, the begin the download over your existing data connection.
  - Software updates can include bug fixes, enhancements to services, to the device or currently installed software.

## Section 12: Health and Safety Information

---

This device is capable of operating in Wi-Fi mode in the 2.4 and 5 GHz bands. The FCC requires that devices operating within 5.15-5.25 GHz may only be used indoors, not outside, in order to avoid interference with Mobile Satellite Services (MSS). Therefore, do not use this device outside as a Wi-Fi hotspot or in Wi-Fi Direct mode outside when using the 5.15-5.25 GHz band.

This section outlines the safety precautions associated with using your phone. The terms “mobile device” or “cell phone” are used in this section to refer to your phone. **Read this information before using your mobile device.**

### Exposure to Radio Frequency (RF) Signals

The U.S. Food and Drug Administration (FDA) has published information for consumers relating to Radio Frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

#### *Do cell phones pose a health hazard?*

Many people are concerned that cell phone radiation will cause cancer or other serious health hazards. The weight of scientific evidence has not linked cell phones with any health problems.

Cell phones emit low levels of Radio Frequency (RF) energy. Over the past 15 years, scientists have conducted hundreds of studies looking at the biological effects of the radio frequency energy emitted by cell phones. While some researchers have reported biological changes associated with RF energy, these studies have failed to be replicated. The majority of studies published have failed to show an association between exposure to radio frequency from a cell phone and health problems.

The low levels of RF cell phones emit while in use are in the microwave frequency range. They also emit RF at substantially reduced time intervals when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects.

The biological effects of radio frequency energy should not be confused with the effects from other types of electromagnetic energy.

Very high levels of electromagnetic energy, such as is found in X-rays and gamma rays, can ionize biological tissues. Ionization is a process where electrons are stripped away from their normal locations in atoms and molecules. It can permanently damage biological tissues including DNA, the genetic material.

The energy levels associated with radio frequency energy, including both radio waves and microwaves, are not great enough to cause ionization of atoms and molecules. Therefore, RF energy is a type of non-ionizing radiation. Other types of non-ionizing radiation include visible light, infrared radiation (heat), and other forms of electromagnetic radiation with relatively low frequencies.

While RF energy does not ionize particles, large amounts can increase body temperatures and cause tissue damage. Two areas of the body, the eyes and the testes, are particularly vulnerable to RF heating because there is relatively little blood flow in them to carry away excess heat.

## **Research Results to Date: Is there a connection between RF and certain health problems?**

The results of most studies conducted to date say no. In addition, attempts to replicate and confirm the few studies that have shown a connection have failed.

The scientific community at large therefore believes that the weight of scientific evidence does not show an association between exposure to Radio Frequency (RF) from cell phones and adverse health outcomes. Still the scientific community has supported additional research to address gaps in knowledge. Some of these studies are described below.

### **Interphone Study**

Interphone is a large international study designed to determine whether cell phones increase the risk of head and neck cancer. A report published in the International Journal of Epidemiology (June, 2010) compared cell phone usage for more than 5,000 people with brain tumors (glioma and meningioma) and a similar number of healthy controls.

Results of this study did NOT show that cell phones caused brain cancer. In this study, most people had no increased risk of brain cancer from using cell phones. For people with the heaviest use of cell phones (an average of more than ½ hour per day, every day, for over 10 years) the study suggested a

slight increase in brain cancer. However, the authors determined that biases and errors prevented any conclusions being drawn from this data. Additional information about Interphone can be found at

[http://www.iarc.fr/en/media-centre/pr/2010/pdfs/pr200\\_E.pdf](http://www.iarc.fr/en/media-centre/pr/2010/pdfs/pr200_E.pdf).

Interphone is the largest cell phone study to date, but it did not answer all questions about cell phone safety. Additional research is being conducted around the world, and the FDA continues to monitor developments in this field.

### **International Cohort Study on Mobile Phone Users (COSMOS)**

The COSMOS study aims to conduct long-term health monitoring of a large group of people to determine if there are any health issues linked to long-term exposure to radio frequency energy from cell phone use. The COSMOS study will follow approximately 300,000 adult cell phone users in Europe for 20 to 30 years. Additional information about the COSMOS study can be found at

<http://www.ukcosmos.org/index.html>.

### **Risk of Brain Cancer from Exposure to Radio Frequency Fields in Childhood and Adolescence (MOBI-KIDS)**

MOBI-KIDS is an international study investigating the relationship between exposure to radio frequency energy from communication technologies including cell phones and brain cancer in young people. This is an international multi-center study involving 14 European and non-European countries. Additional information about MOBI-KIDS can be found at

[http://www.creal.cat/programes-recerca/en\\_projectes-creal/view.php?ID=39](http://www.creal.cat/programes-recerca/en_projectes-creal/view.php?ID=39).

### **Surveillance, Epidemiology, and End Results (SEER) Program of the National Cancer Institute**

The National Cancer Institute (NCI) actively follows cancer statistics in the United States to detect any change in rates of new cases for brain cancer. If cell phones play a role in risk for brain cancer, rates should go up, because heavy cell phone use has been common for quite some time in the U.S. Between 1987 and 2005, the overall age-adjusted incidence of brain cancer did not increase. Additional information about SEER can be found at

<http://seer.cancer.gov/>.

## Cell Phone Industry Actions

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the cell phone industry to take a number of steps, including the following:

- Support-needed research on possible biological effects of RF for the type of signal emitted by cell phones;
- Design cell phones in a way that minimizes any RF exposure to the user; and
- Cooperate in providing users of cell phones with the current information on cell phone use and human health concerns.

The FDA also is working with voluntary standard-setting bodies such as the Institute of Electrical and Electronics Engineers (IEEE), the International Commission on Non-Ionizing Radiation Protection (ICNIRP), and others to assure that safety standards continue to adequately protect the public.

## Reducing Exposure: Hands-Free Kits and Other Accessories

### Steps to Reduce Exposure to Radio Frequency Energy

If there is a risk from being exposed to radio frequency energy (RF) from cell phones - and at this point we do not know that there is - it is probably very small. But, if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your RF exposure.

- Reduce the amount of time spent using your cell phone;
- Use speaker mode or a headset to place more distance between your head and the cell phone.

### Hands-Free Kits

Hands-free kits may include audio or Bluetooth® headsets and various types of body-worn accessories such as belt-clips and holsters. Combinations of these can be used to reduce RF energy absorption from cell phones.

Headsets can substantially reduce exposure because the phone is held away from the head in the user's hand or in approved body-worn accessories. Cell phones marketed in the U.S. are required to meet RF exposure compliance requirements when used against the head and against the body.

DRAFT  
Internal Use Only

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used for convenience and comfort. They are also required by law in many states if you want to use your phone while driving.

### **Cell Phone Accessories that Claim to Shield the Head from RF Radiation**

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that accessories which claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone.

Studies have shown that these products generally do not work as advertised. Unlike “hands-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption.

### **Children and Cell Phones**

The scientific evidence does not show a danger to any users of cell phones from RF exposure, including children and teenagers. The steps adults can take to reduce RF exposure apply to children and teenagers as well.

- Reduce the amount of time spent on the cell phone;
- Use speaker mode or a headset to place more distance between the head and the cell phone.

Some groups sponsored by other national governments have advised that children be discouraged from using cell phones at all. For example, The Stewart Report from the United Kingdom made such a recommendation in December 2000. In this report, a group of independent experts noted that no evidence exists that using a cell phone causes brain tumors or other ill effects. Their recommendation to limit cell phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations (updated 10/1/2010):

- FCC RF Safety Program:  
<http://www.fcc.gov/oet/rfsafety/>

- Environmental Protection Agency (EPA):  
<http://www.epa.gov/radtown/wireless-tech.html>.
- Occupational Safety and Health Administration (OSHA):  
<http://www.osha.gov/SLTC/radiofrequencyradiation/>.  
(Note: This web address is case sensitive.)
- National Institute for Occupational Safety and Health (NIOSH):  
<http://www.cdc.gov/niosh/>.
- World Health Organization (WHO):  
<http://www.who.int/peh-emf/en/>.
- International Commission on Non-Ionizing Radiation Protection:  
<http://www.icnirp.de>.
- Health Protection Agency:  
<http://www.hpa.org.uk/Topics/Radiation/>.
- US Food and Drug Administration:  
<http://www.fda.gov/Radiation-EmittingProducts/RadiationEmittingProductsandProcedures/HomeBusinessandEntertainment/CellPhones/default.htm>.

## Specific Absorption Rate (SAR) Certification Information

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for Radio Frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government.

These FCC RF exposure limits are derived from the recommendations of two expert organizations: the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The RF exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

DRAFT  
Internal Use Only

The FCC SAR limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum reported value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the SAR limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body-worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device a minimum of 1.0cm from the body.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The FCC has granted an Equipment Authorization for this mobile device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. This mobile phone has a FCC ID number: A3LSGHM919 [Model Number: SGH-M919] and the specific SAR levels for this mobile phone can be found at the following FCC website: <http://www.fcc.gov/oet/ea/>.

The SAR information for this device can also be found on Samsung's website: <http://www.samsung.com/sar>.

SAR information on this and other model phones can be accessed online on the FCC's website through <http://transition.fcc.gov/oet/rfsafety/sar.html>. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional SAR information can also be obtained at <http://www.fcc.gov/encyclopedia/specific-absorption-rate-sar-cellular-telephones>.

## FCC Part 15 Information to User

Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Commercial Mobile Alerting System (CMAS)

This device is designed to receive wireless emergency alerts from the Commercial Mobile Alerting System ("CMAS"; which may also be known as the Personal Localized Alerting Network ("PLAN")). If your wireless provider has chosen to participate in CMAS/PLAN, alerts are available while in the provider's coverage area. If you travel outside your provider's coverage area, wireless emergency alerts may not be available. For more information, please contact your wireless provider.

## Smart Practices While Driving On the Road - Off the Phone

The primary responsibility of every driver is the safe operation of his or her vehicle.

Responsible drivers understand that no secondary task should be performed while driving whether it be eating, drinking, talking to passengers, or talking on a mobile phone - unless the driver has assessed the driving conditions and is confident that the secondary task will not interfere with their primary responsibility. **Do not engage in any activity while driving a moving vehicle which may cause you to take your eyes off the road or become so absorbed in the activity that your ability to concentrate on the act of driving becomes impaired.** Samsung is committed to promoting responsible driving and giving drivers the tools they need to understand and address distractions.

**Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. For example, only hands-free use may be permitted in certain areas.**

Before answering calls, consider your circumstances. Let the call go to voicemail when driving conditions require. Remember, driving comes first, not the call!

If you consider a call necessary and appropriate, follow these tips:

- Use a hands-free device;
- Secure your phone within easy reach;
- Place calls when you are not moving;
- Plan calls when your car will be stationary;
- Do not engage in stressful or emotional conversations;
- Let the person with whom you are speaking know that you are driving and will suspend the call if necessary;
- Do not take notes or look up phone numbers while driving;

Notice regarding legal restrictions on mounting this device in an automobile:

Laws in some states may prohibit mounting this device on or near the windshield of an automobile. In other states, the law may permit mounting this device only in specific locations in the automobile. Be sure to consult the state and local laws or ordinances where you drive before mounting this device in an automobile. Failure to comply with these restrictions could result in fines, penalties, or other damages.

Never mount this device in a manner that will obstruct the driver's clear view of the street and traffic.

**Never use wireless data services such as text messaging, Web browsing, or e-mail while operating a vehicle.**

**Never watch videos, such as a movie or clip, or play video games while operating a vehicle.**

For more information, go to <http://www.ctia.org>.

## Battery Use and Safety

---

**Important! Handle and store batteries properly to avoid injury or damage.** Most battery issues arise from improper handling of batteries and, particularly, from the continued use of damaged batteries.

---

- **Do not disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.** Do not put a high degree of pressure on the battery. This can cause leakage or an internal short-circuit, resulting in overheating.

- **Do not let the phone or battery come in contact with liquids.** Liquids can get into the phone's circuits, leading to corrosion. Even when the phone appears to be dry and appears to operate normally, the circuitry could slowly corrode and pose a safety hazard. If the phone and/or battery get wet, have them checked by your service provider or contact Samsung, even if they appear to be working properly.
- **Do not place your battery in or near a heat source.** Excessive heating can damage the phone or the battery and could cause the phone or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron, or radiator. Avoid leaving your phone in your car in high temperatures.
- **Do not dispose of the phone or the battery in a fire.** The phone or the battery may explode when overheated.
- **Do not handle a damaged or leaking battery.** Do not let leaking battery fluid come in contact with your eyes, skin or clothing. For safe disposal options, contact your nearest Samsung-authorized service center.

DRAFT

Internal Use Only

- **Avoid dropping the cell phone.** Dropping the phone or the battery, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- **Never use any charger or battery that is damaged in any way.**
- **Do not allow the battery to touch metal objects.** Accidental short-circuiting can occur when a metallic object (coin, key, jewelry, clip, or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.

---

**Important!** Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers which are specifically designed for your phone.

---

**WARNING!**

**Use of a non-Samsung-approved battery or charger may present a risk of fire, explosion, leakage, or other hazard.** Samsung's warranty does not cover damage to the phone caused by non-Samsung-approved batteries and/or chargers.

- **Do not use incompatible cell phone batteries and chargers.** Some websites and second-hand dealers not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier-recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- **Misuse or use of incompatible phones, batteries, and charging devices could result in damage to the equipment and a possible risk of fire, explosion, or leakage, leading to serious injuries, damages to your phone, or other serious hazard.**

## **Samsung Mobile Products and Recycling**

Samsung cares for the environment and encourages its customers to recycle Samsung mobile devices and genuine Samsung accessories.

Proper disposal of your mobile device and its battery is not only important for safety, it benefits the environment. Batteries must be recycled or disposed of properly.

Recycling programs for your mobile device, batteries, and accessories may not be available in your area.

We've made it easy for you to recycle your old Samsung mobile device by working with respected take-back companies in every state in the country.

### **Drop It Off**

You can drop off your Samsung-branded mobile device and batteries for recycling at one of our numerous Samsung Recycling Direct (SM) locations. A list of these locations may be found at:

[http://pages.samsung.com/us/recyclingdirect/usactivities\\_environment\\_samsungrecyclingdirect\\_locations.jsp](http://pages.samsung.com/us/recyclingdirect/usactivities_environment_samsungrecyclingdirect_locations.jsp)

Samsung-branded devices and batteries will be accepted at these locations for no fee.

Consumers may also recycle their used mobile device or batteries at many retail or carrier-provided locations where mobile devices and batteries are sold. Additional information regarding specific locations may be found at: <http://www.epa.gov/epawaste/partnerships/plugin/cellphone/index.htm> or at <http://www.call2recycle.org/>.

### **Mail It In**

The Samsung Mobile Take-Back Program will provide Samsung customers with a free recycling mailing label. Just go to

[http://www.samsung.com/us/aboutsamsung/citizenship/usactivities\\_environment\\_samsungrecyclingdirect.html?INT=STA\\_recycle\\_your\\_phone\\_page](http://www.samsung.com/us/aboutsamsung/citizenship/usactivities_environment_samsungrecyclingdirect.html?INT=STA_recycle_your_phone_page) and follow the instructions to print out a free pre-paid postage label and then send your old mobile device or battery to the address listed, via U.S. Mail, for recycling.

Dispose of unwanted electronics through an approved recycler.

To find the nearest recycling location, go to our website:

[www.samsung.com/recyclingdirect](http://www.samsung.com/recyclingdirect)

Or call, (877) 278-0799.

### **Follow local regulations regarding disposal of mobile devices and batteries**

Dispose of your mobile device and batteries in accordance with local regulations. In some areas, the disposal of these items in household or business trash may be prohibited. Help us protect the environment - recycle!

Internal Use Only

---

**Warning!** Never dispose of batteries in a fire because they may explode.

---

## UL Certified Travel Charger

The Travel Charger for this phone has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines:

**FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.**

**IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.**

**DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.**

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

## Display / Touch-Screen

Please note the following information when using your mobile device:

### WARNING REGARDING DISPLAY

The display on your mobile device is made of glass or acrylic and could break if your mobile device is dropped or if it receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.

DRAFT  
Internal Use Only

## **WARRANTY DISCLAIMER: PROPER USE OF A TOUCH-SCREEN MOBILE DEVICE**

If your mobile device has a touch-screen display, please note that a touch-screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch-screen may damage the tempered glass surface and void the warranty. For more information, please refer to the “Standard Limited Warranty”.

## **GPS & AGPS**

Certain Samsung mobile devices can use a Global Positioning System (GPS) signal for location-based applications. A GPS uses satellites controlled by the U.S. Government that are subject to changes implemented in accordance with the Department of Defense policy and the 2008 Federal Radio navigation Plan (FRP). Changes may affect the performance of location-based technology on your mobile device.

Certain Samsung mobile devices can also use an Assisted Global Positioning System (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore

airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

### **Your Location**

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. The location-based information may be shared with third-parties, including your wireless service provider, applications providers, Samsung, and other third-parties providing services.

### **Use of AGPS in Emergency Calls**

When you make an emergency call, the cellular network may activate AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**.

Therefore:

- Always tell the emergency responder your location to the best of your ability; and

- Remain on the mobile device for as long as the emergency responder instructs you.

## Navigation

Maps, directions, and other navigation-data, including data relating to your current location, may contain inaccurate or incomplete data, and circumstances can and do change over time. In some areas, complete information may not be available. **Therefore, you should always visually confirm that the navigational instructions are consistent with what you see before following them. All users should pay attention to road conditions, closures, traffic, and all other factors that may impact safe driving or walking. Always obey posted road signs.**

## Emergency Calls

This mobile device, like any wireless mobile device, operates using radio signals, wireless and landline networks, as well as user-programmed functions, which cannot guarantee connection in all conditions, areas, or circumstances.

Therefore, you should never rely solely on any wireless mobile device for essential communications (medical emergencies, for example). Before traveling in remote or underdeveloped areas, plan an alternate method of contacting emergency services personnel. Remember, to

make or receive any calls, the mobile device must be switched on and in a service area with adequate signal strength.

Emergency calls may not be possible on all wireless mobile device networks or when certain network services and/or mobile device features are in use. Check with local service providers.

### To make an emergency call:

1. If the mobile device is not on, switch it on.
2. From the Home screen, tap .
3. Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
4. Tap .

If certain features are in use (call blocking, for example), you may first need to deactivate those features before you can make an emergency call. Consult your User Manual and your local cellular service provider. When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your mobile device

may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

## Care and Maintenance

Your mobile device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years:

### Keep your Samsung Mobile Device away from:

#### Liquids of any kind

Keep the mobile device dry. Precipitation, humidity, and liquids contain minerals that will corrode electronic circuits. If the mobile device does get wet, do not accelerate drying with the use of an oven, microwave, or dryer, because this may damage the mobile device and could cause a fire or explosion.

Do not use the mobile device with a wet hand. Doing so may cause an electric shock to you or damage to the mobile device.

#### Extreme heat or cold

Avoid temperatures below 0°C / 32°F or above 45°C / 113°F.

#### Microwaves

Do not try to dry your mobile device in a microwave oven. Doing so may cause a fire or explosion.

#### Dust and dirt

Do not expose your mobile device to dust, dirt, or sand.

#### Cleaning solutions

Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the mobile device. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.

#### Shock or vibration

Do not drop, knock, or shake the mobile device. Rough handling can break internal circuit boards.

#### Paint

Do not paint the mobile device. Paint can clog the device's moving parts or ventilation openings and prevent proper operation.

DRAFT  
Internal Use Only

## Responsible Listening

---

### Caution! Avoid potential hearing loss.

---

Damage to hearing occurs when a person is exposed to loud sounds over time. The risk of hearing loss increases as sound is played louder and for longer durations. Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss. Some scientific research suggests that using portable audio devices, such as portable music players and cell phones, at high volume settings for long durations may lead to permanent noise-induced hearing loss.

This includes the use of headphones (including headsets, earbuds, and Bluetooth® or other wireless devices). Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound, and distorted hearing. Individual susceptibility to noise-induced hearing loss and potential hearing problem varies. Additionally, the amount of sound produced by a portable audio device varies depending on the nature of the sound, the device settings, and the headphones

that are used. As a result, there is no single volume setting that is appropriate for everyone or for every combination of sound, settings, and equipment.

You should follow some common sense recommendations when using any portable audio device:

- Always turn the volume down before plugging the earphones into an audio source.
- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.
- Be aware that you can adapt to higher volume settings over time, not realizing that the higher volume may be harmful to your hearing.
- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.
- Do not turn the volume up to block out noisy surroundings. If you choose to listen to your portable device in a noisy environment, use noise-cancelling headphones to block out background environmental noise. By blocking background environment noise, noise cancelling headphones should allow you to hear the music at lower volumes than when using earbuds.

- Limit the amount of time you listen. As the volume increases, less time is required before your hearing could be affected.
- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss. Temporary hearing loss might cause unsafe volumes to sound normal.
- Do not listen at any volume that causes you discomfort. If you experience ringing in your ears, hear muffled speech, or experience any temporary hearing difficulty after listening to your portable audio device, discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:

#### **American Academy of Audiology**

11730 Plaza American Drive, Suite 300  
Reston, VA 20190

Voice: (800) 222-2336

Email: [info@audiology.org](mailto:info@audiology.org)

Internet:

<http://www.audiology.org/Pages/default.aspx>

#### **National Institute on Deafness and Other Communication Disorders**

National Institutes of Health  
31 Center Drive, MSC 2320  
Bethesda, MD 20892-2320

Email: [nidcdinfo@nih.gov](mailto:nidcdinfo@nih.gov)

Internet:

<http://www.nidcd.nih.gov/>

#### **National Institute for Occupational Safety and Health (NIOSH)**

395 E Street, S.W., Suite 9200  
Patriots Plaza Building  
Washington, DC 20201

Voice: 1-800-35-NIOSH

(1-800-356-4674)

1-800-CDC-INFO (1-800-232-4636)

Outside the U.S. 513-533-8328

DRAFT  
Internal Use Only

Email: [cdcinfo@cdc.gov](mailto:cdcinfo@cdc.gov)

Internet:

<http://www.cdc.gov/niosh/topics/noise/default.html>

1-888-232-6348 TTY

## Operating Environment

Remember to follow any special regulations in force in any area, and always switch your mobile device off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the mobile device or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

### Using Your Mobile Device Near Other Electronic Devices

Most modern electronic equipment is shielded from Radio Frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless mobile device. Consult the manufacturer to discuss alternatives.

## Implantable Medical Devices

A minimum separation of six (6) inches should be maintained between a handheld wireless mobile device and an implantable medical device, such as a pacemaker or implantable cardioverter defibrillator, to avoid potential interference with the device.

Persons who have such devices:

- Should ALWAYS keep the mobile device more than six (6) inches from their implantable medical device when the mobile device is turned ON;
- Should not carry the mobile device in a breast pocket;
- Should use the ear opposite the implantable medical device to minimize the potential for interference;
- Should turn the mobile device OFF immediately if there is any reason to suspect that interference is taking place;
- Should read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless mobile device with an implantable medical device, consult your health care provider.

For more information see: <http://www.fcc.gov/oet/rfsafety/rf-faqs.html#>.

## **Other Medical Devices**

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your mobile device off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

## **Vehicles**

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle before using your mobile device in a motor vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

## **Posted Facilities**

Switch your mobile device off in any facility where posted notices require you to do so.

## **Potentially Explosive Environments**

Switch your mobile device off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion

or fire resulting in bodily injury or even death. Users are advised to switch the mobile device off while at a refueling point (service station).

Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

## **When your Device is Wet**

Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service center.

## FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices

The U.S. Federal Communications Commission (FCC) has established requirements for digital wireless mobile devices to be compatible with hearing aids and other assistive hearing devices.

When individuals employing some assistive hearing devices (hearing aids and cochlear implants) use wireless mobile devices, they may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and mobile devices also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless mobile devices to assist hearing device users find mobile devices that may be compatible with their hearing devices. Not all mobile devices have been rated. Mobile devices that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not

be able to use a rated mobile device successfully. Trying out the mobile device with your hearing device is the best way to evaluate it for your personal needs.

**M-Ratings:** Wireless mobile devices rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. M4 is the better/higher of the two ratings. M-ratings refer to enabling acoustic coupling with hearing aids that do not operate in telecoil mode.

**T-Ratings:** Mobile devices rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. T4 is the better/higher of the two ratings. T-ratings refer to enabling inductive coupling with hearing aids operating in telecoil mode.


Hearing devices may also be rated. Your hearing aid manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise.

Under the current industry standard, American National Standards Institute (ANSI) C63.19, the hearing aid and wireless mobile device rating values are added together to indicate how usable they are together. For example, if a

hearing aid meets the M2 level rating and the wireless mobile device meets the M3 level rating, the sum of the two values equals M5.

Under the standard, this should provide the hearing aid user with normal use while using the hearing aid with the particular wireless mobile device. A sum of 6 or more would indicate excellent performance.

However, these are not guarantees that all users will be satisfied. T ratings work similarly.



The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

### **HAC for Newer Technologies**

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids.

It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

### **Restricting Children's Access to Your Mobile Device**

Your mobile device is not a toy. Do not allow children to play with it because they could hurt themselves and others, damage the mobile device, or make calls that increase your mobile device bill.

Keep the mobile device and all its parts and accessories out of the reach of small children.

## **FCC Notice and Cautions**

### **FCC Notice**

The mobile device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the mobile device if such interference cannot be eliminated. Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association.

### **Cautions**

Any changes or modifications to your mobile device not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas, and chargers. The use of any unauthorized accessories may be dangerous and void the mobile device warranty if said accessories cause damage or a defect to the mobile device.

Although your mobile device is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.

## **Other Important Safety Information**

- Only qualified personnel should service the mobile device or install the mobile device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Ensure that any mobile devices or related equipment installed in your vehicle are securely mounted.
- Check regularly that all wireless mobile device equipment in your vehicle is mounted and operating properly.
- When using a headset in dry environments, static electricity can build up in the headset and cause a small quick static electrical shock. To minimize the risk of electrostatic discharge from the headset avoid using the headset in extremely dry environments or touch a grounded unpainted metal object to discharge static electricity before inserting the headset.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the mobile device, its parts, or accessories.

- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including installed or portable wireless equipment near or in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your mobile device off before boarding an aircraft. The use of wireless mobile devices in aircraft is illegal and may be dangerous to the aircraft's operation. Check with appropriate authorities before using any function of a mobile device while on an aircraft.
- Failure to observe these instructions may lead to the suspension or denial of cell phone services to the offender, or legal action, or both.
- While using your device, leave some lights on in the room and do not hold the screen too close to your eyes.
- Seizures or blackouts can occur when you are exposed to flashing lights while watching videos or playing games for extended periods. If you feel any discomfort, stop using the device immediately.
- Reduce risk of repetitive motion injuries. When you repetitively perform actions, such as pressing keys, drawing characters on a touch screen with your fingers, or playing games, you may experience occasional discomfort in your hands, neck, shoulders, or other parts of your body. When using your device for extended periods, hold the device with a relaxed grip, press the keys lightly, and take frequent breaks. If you continue to have discomfort during or after such use, stop use and see a physician.
- If your device has a camera flash or light, do not use the flash or light close to the eyes of people or pets. [122011]

INTERNAL USE ONLY

## Section 13: Warranty Information

---

### Standard Limited Warranty

#### What is covered and for how long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC (“SAMSUNG”) warrants that SAMSUNG’s handsets and accessories (“Products”) are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase by the first consumer purchaser and continuing for the following specified period of time after that date:

|                         |         |
|-------------------------|---------|
| Phone                   | 1 Year  |
| Batteries               | 1 Year  |
| Case/Pouch/Holster      | 90 Days |
| Other Phone Accessories | 1 Year  |

#### What is not covered?

This Limited Warranty is conditioned upon proper use of the Product.

This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, dampness, sand or dirt, neglect, or unusual physical, electrical or electromechanical stress; (b) scratches, dents and cosmetic damage, unless caused by SAMSUNG; (c) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (d) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (e) ordinary wear and tear; (f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning, earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source; (i) defects or damage resulting from cellular signal reception

or transmission, or viruses or other software problems introduced into the Product; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery; (ii) any of the seals on the battery are broken or show evidence of tampering; or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

#### **What are SAMSUNG's obligations?**

During the applicable warranty period, provided the Product is returned in accordance with the terms of this Limited Warranty, SAMSUNG will repair or replace the Product, at SAMSUNG's sole option, without charge. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product, or may replace the Product with a rebuilt, reconditioned or new Product.

Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Products will be warranted for a period equal to the

remainder of the original Limited Warranty on the original Product or for ninety (90) days, whichever is longer. All replaced Products, parts, components, boards and equipment shall become the property of SAMSUNG. Except to any extent expressly allowed by applicable law, transfer or assignment of this Limited Warranty is prohibited.

#### **What must you do to obtain warranty service?**

To obtain service under this Limited Warranty, you must return the Product to an authorized phone service facility in an adequate container for shipping, accompanied by the sales receipt or comparable proof of sale showing the original date of purchase, the serial number of the Product and the seller's name and address.

To obtain assistance on where to deliver the Product, please call SAMSUNG Customer Care at 1-888-987-4357. If SAMSUNG determines that any Product is not covered by this Limited Warranty, you must pay all parts, shipping, and labor charges for the repair or return of such Product.

You should keep a separate backup copy of any contents of the Product before delivering the Product to SAMSUNG for warranty service, as some or all of the contents may be deleted or reformatted during the course of warranty service.

### **What are the limits on SAMSUNG's liability?**

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF SAMSUNG'S RESPONSIBILITIES, AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCTS.

ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SAMSUNG BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES; OR DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE

OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Products. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of SAMSUNG regarding the Products or this Limited Warranty.

This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

### **What is the procedure for resolving disputes?**

ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCTS SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY.

Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's Product or claim, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty.

For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant SAMSUNG its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and SAMSUNG shall pay the remainder of such fees.

Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction.

This arbitration provision also applies to claims against SAMSUNG's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

You may opt out of this dispute resolution procedure by providing notice to SAMSUNG no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product. To opt out, you must send notice by e-mail to [optout@sta.samsung.com](mailto:optout@sta.samsung.com), with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the Product was purchased; (c) the Product model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the Product box; (ii) on the Product information screen, which can be found under "Settings;" (iii) on a label on the back of the Product beneath the battery, if the battery is removable; and (iv) on the outside of the Product if the battery is not removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and you will continue to enjoy the benefits of the Limited Warranty.

### **Severability**

If any portion of this Limited Warranty is held to be illegal or unenforceable, such partial illegality or unenforceability shall not affect the enforceability of the remainder of the Limited Warranty.

### ***Precautions for Transfer and Disposal***

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the **Samsung Customer Care Center** for details.

---

**Important!** Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

---

Samsung Telecommunications America, LLC  
1301 E. Lookout Drive  
Richardson, Texas 75082

Phone: 1-800-SAMSUNG  
Phone: 1-888-987-HELP (4357)

©2012 Samsung Telecommunications America, LLC. All rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice. [111611]

## End User License Agreement for Software

IMPORTANT. READ CAREFULLY: This End User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Samsung Electronics Co., Ltd. ("Samsung Electronics Co.") for software, owned by Samsung Electronics Co. and its affiliated companies and its third party suppliers and licensors, that accompanies this EULA, which includes computer software and may include associated media, printed materials, "online" or electronic documentation

("Software"). **Samsung Electronics Co. is a separate company from the company that provides the limited warranty for this mobile device, Samsung Telecommunications America, LLC.**

This device requires the use of preloaded software in its normal operation. BY USING THE DEVICE OR ITS PRELOADED SOFTWARE, YOU ACCEPT THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THESE TERMS, **DO NOT USE** THE DEVICE OR THE SOFTWARE. INSTEAD, RETURN THE DEVICE TO THE RETAILER FOR A REFUND OR CREDIT.

1. GRANT OF LICENSE. Samsung Electronics Co. grants you the following rights provided that you comply with all terms and conditions of this EULA: You may install, use, access, display and run one copy of the Software on the local hard disk(s) or other permanent storage media of one computer and use the Software on a single computer or a mobile device at a time, and you may not make the Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the Software in machine readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.

DRAFT  
Internal Use Only

2. RESERVATION OF RIGHTS AND OWNERSHIP. Samsung Electronics Co. reserves all rights not expressly granted to you in this EULA. The Software is protected by copyright and other intellectual property laws and treaties. Samsung Electronics Co. or its suppliers own the title, copyright and other intellectual property rights in the Software. The Software is licensed, not sold.

3. LIMITATIONS ON END USER RIGHTS. You may not reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code or algorithms of, the Software (except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation), or modify, or disable any features of, the Software, or create derivative works based on the Software. You may not rent, lease, lend, sublicense or provide commercial hosting services with the Software.

4. CONSENT TO USE OF DATA. You agree that Samsung Electronics Co. and its affiliates may collect and use technical information gathered as part of the product support services related to the Software provided to you, if any. Samsung Electronics Co. and its affiliates may use this information solely to improve their products or to provide

customized services or technologies to you and will not disclose this information in a form that personally identifies you.

5. UPGRADES. This EULA applies to updates, supplements and add-on components (if any) of the Software that Samsung Electronics Co. may provide to you or make available to you after the date you obtain your initial copy of the Software, unless we provide other terms along with such upgrade. To use Software identified as an upgrade, you must first be licensed for the Software identified by Samsung Electronics Co. as eligible for the upgrade. After upgrading, you may no longer use the Software that formed the basis for your upgrade eligibility.

6. SOFTWARE TRANSFER. You may not transfer this EULA or the rights to the Software granted herein to any third party unless it is in connection with the sale of the mobile device which the Software accompanied. In such event, the transfer must include all of the Software (including all component parts, the media and printed materials, any upgrades, this EULA) and you may not retain any copies of the Software. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the Software must agree to all the EULA terms.

7. EXPORT RESTRICTIONS. You acknowledge that the Software is subject to export restrictions of various countries. You agree to comply with all applicable international and national laws that apply to the Software, including the U.S. Export Administration Regulations, as well as end user, end use, and destination restrictions issued by U.S. and other governments.

8. TERMINATION. This EULA is effective until terminated. Your rights under this License will terminate automatically without notice from Samsung Electronics Co. if you fail to comply with any of the terms and conditions of this EULA. Upon termination of this EULA, you must cease all use of the Software and destroy all copies, full or partial, of the Software.

9. Disclaimer of Warranty. ALL SOFTWARE PROVIDED BY SAMSUNG ELECTRONICS CO. WITH THIS MOBILE DEVICE IS PROVIDED "AS IS" AND ON AN "AS AVAILABLE" BASIS, WITHOUT WARRANTIES OF ANY KIND FROM SAMSUNG ELECTRONICS CO., EITHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT POSSIBLE PURSUANT TO APPLICABLE LAW, SAMSUNG ELECTRONICS CO. DISCLAIMS ALL WARRANTIES EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY OR

WORKMANLIKE EFFORT, FITNESS FOR A PARTICULAR PURPOSE, RELIABILITY OR AVAILABILITY, ACCURACY, LACK OF VIRUSES, QUIET ENJOYMENT, NON INFRINGEMENT OF THIRD PARTY RIGHTS OR OTHER VIOLATION OF RIGHTS. SOME JURISDICTIONS DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM SAMSUNG ELECTRONICS CO. OR ITS AFFILIATES SHALL BE DEEMED TO ALTER THIS DISCLAIMER BY SAMSUNG ELECTRONICS CO. OF WARRANTY REGARDING THE SOFTWARE, OR TO CREATE ANY WARRANTY OF ANY SORT FROM SAMSUNG ELECTRONICS CO.

10. THIRD-PARTY APPLICATIONS. Certain third party applications may be included with, or downloaded to this mobile device. Samsung Electronics Co. makes no representations whatsoever about any of these applications. Since Samsung Electronics Co. has no control over such applications, you acknowledge and agree that Samsung Electronics Co. is not responsible for the availability of such applications and is not responsible or liable for any content, advertising, products, services, or other materials on or available from such applications. You expressly acknowledge and agree that use of third party applications is at your sole

risk and that the entire risk of unsatisfactory quality, performance, accuracy and effort is with you. It is up to you to take precautions to ensure that whatever you select to use is free of such items as viruses, worms, Trojan horses, and other items of a destructive nature. References on this mobile device to any names, marks, products, or services of any third-parties are provided solely as a convenience to you, and do not constitute or imply an endorsement, sponsorship, or recommendation of, or affiliation with the third party or its products and services. You agree that Samsung Electronics Co. shall not be responsible or liable, directly or indirectly, for any damage or loss caused or alleged to be caused by, or in connection with, use of or reliance on any such third party content, products, or services available on or through any such application. You acknowledge and agree that the use of any third-party application is governed by such third party application provider's Terms of Use, License Agreement, Privacy Policy, or other such agreement and that any information or personal data you provide, whether knowingly or unknowingly, to such third-party application provider, will be subject to such third party application provider's privacy policy, if such a policy exists. SAMSUNG ELECTRONICS CO.

DISCLAIMS ANY RESPONSIBILITY FOR ANY DISCLOSURE OF INFORMATION OR ANY OTHER PRACTICES OF ANY THIRD PARTY APPLICATION PROVIDER.

11. Disclaimer of Warranty Regarding Third Party Applications. SAMSUNG ELECTRONICS CO. DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE AVAILABILITY, USE, TIMELINESS, SECURITY, VALIDITY, ACCURACY, OR RELIABILITY OF, OR THE RESULTS OF THE USE OF, OR OTHERWISE RESPECTING, THE CONTENT OF ANY THIRD PARTY APPLICATION WHETHER SUCH THIRD PARTY APPLICATION IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG ELECTRONICS CO., IS DOWNLOADED, OR OTHERWISE OBTAINED. USE OF ANY THIRD PARTY APPLICATION IS DONE AT YOUR OWN DISCRETION AND RISK AND YOU ARE SOLELY RESPONSIBLE FOR ANY DAMAGE TO THE MOBILE DEVICE OR LOSS OF DATA THAT RESULTS FROM THE DOWNLOADING OR USE OF SUCH THIRD PARTY APPLICATIONS. SAMSUNG ELECTRONICS CO. EXPRESSLY DISCLAIMS ANY WARRANTY REGARDING WHETHER YOUR PERSONAL INFORMATION IS CAPTURED BY ANY THIRD PARTY APPLICATION PROVIDER OR THE USE TO WHICH SUCH PERSONAL INFORMATION MAY BE PUT BY SUCH THIRD PARTY APPLICATION PROVIDER. ANY THIRD PARTY APPLICATIONS PROVIDED WITH THIS MOBILE DEVICE

ARE PROVIDED "AS IS" AND ON AN "AS AVAILABLE" BASIS, WITHOUT WARRANTIES OF ANY KIND FROM SAMSUNG ELECTRONICS CO., EITHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT POSSIBLE PURSUANT TO APPLICABLE LAW, SAMSUNG ELECTRONICS CO. DISCLAIMS ALL WARRANTIES EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY OR WORKMANLIKE EFFORT, FITNESS FOR A PARTICULAR PURPOSE, RELIABILITY OR AVAILABILITY, ACCURACY, LACK OF VIRUSES, QUIET ENJOYMENT, NON INFRINGEMENT OF THIRD PARTY RIGHTS OR OTHER VIOLATION OF RIGHTS. SAMSUNG ELECTRONICS CO. DOES NOT WARRANT AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE THIRD PARTY APPLICATION, THAT THE FUNCTIONS CONTAINED IN THE THIRD PARTY APPLICATION WILL MEET YOUR REQUIREMENTS, THAT THE OPERATION OF THE THIRD PARTY APPLICATION WILL BE UNINTERRUPTED OR ERROR FREE, OR THAT DEFECTS IN THE THIRD PARTY APPLICATION WILL BE CORRECTED. YOU ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR, OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NO

ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM SAMSUNG ELECTRONICS CO. OR ANY OTHER PERSON OR ENTITY SHALL BE DEEMED TO ALTER THIS DISCLAIMER OF WARRANTY REGARDING THIRD PARTY APPLICATIONS, OR TO CREATE ANY WARRANTY BY SAMSUNG ELECTRONICS CO.

12. Limitation of Liability. SAMSUNG ELECTRONICS CO. WILL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND ARISING OUT OF OR RELATING TO THE USE OR THE INABILITY TO USE THE SOFTWARE OR ANY THIRD PARTY APPLICATION, ITS CONTENT OR FUNCTIONALITY, INCLUDING BUT NOT LIMITED TO DAMAGES CAUSED BY OR RELATED TO ERRORS, OMISSIONS, INTERRUPTIONS, DEFECTS, DELAY IN OPERATION OR TRANSMISSION, COMPUTER VIRUS, FAILURE TO CONNECT, NETWORK CHARGES, IN-APP PURCHASES, AND ALL OTHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES EVEN IF SAMSUNG ELECTRONICS CO. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NOTWITHSTANDING THE FOREGOING, SAMSUNG ELECTRONIC CO.'S TOTAL LIABILITY TO YOU FOR ALL

LOSSES, DAMAGES, CAUSES OF ACTION, INCLUDING BUT NOT LIMITED TO THOSE BASED ON CONTRACT, TORT, OR OTHERWISE, ARISING OUT OF YOUR USE OF THE SOFTWARE OR THIRD PARTY APPLICATIONS ON THIS MOBILE DEVICE, OR ANY OTHER PROVISION OF THIS EULA, SHALL NOT EXCEED THE AMOUNT PURCHASER PAID SPECIFICALLY FOR THIS MOBILE DEVICE OR ANY SUCH THIRD PARTY APPLICATION THAT WAS INCLUDED WITH THIS MOBILE DEVICE. THE FOREGOING LIMITATIONS, EXCLUSIONS, AND DISCLAIMERS (INCLUDING SECTIONS 9, 10, 11 AND 12) SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EVEN IF ANY REMEDY FAILS ITS ESSENTIAL PURPOSE.

13. U.S. Government End Users Restricted Rights. The Software is licensed only with "restricted rights" and as "commercial items" consisting of "commercial software" and "commercial software documentation" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Products are provided only with "restricted rights" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Software and Products are provided subject to Federal Acquisition Regulation (FAR) 52.227.19.

14. APPLICABLE LAW. This EULA is governed by the laws of TEXAS, without regard to conflicts of laws principles. This EULA shall not be governed by the UN Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded.

15. DISPUTE RESOLUTION.

(a) Non-United States residents. If a dispute, controversy or difference is not amicably settled, it shall be finally resolved by arbitration in Seoul, Korea in accordance with the Arbitration Rules of the Korean Commercial Arbitration Board. The award of arbitration shall be final and binding upon the parties.

(b) United States residents. ALL DISPUTES WITH SAMSUNG ELECTRONICS CO. ARISING IN ANY WAY FROM THIS EULA OR YOUR USE OF THE SOFTWARE SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with any other person's or entity's claim or dispute, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The

arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the EULA and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the EULA. For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant Samsung Electronics Co. its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and Samsung Electronics Co. shall pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim

case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction. This arbitration provision also applies to claims against Samsung Electronics Co.'s employees, representatives and affiliates if any such claim arises from the licensing or use of the Software. You may opt out of this dispute resolution procedure by providing notice to Samsung Electronics Co. no later than 30 calendar days from the date of the first consumer purchaser's purchase of this device. To opt out, you must send notice by e-mail to [optout@sta.samsung.com](mailto:optout@sta.samsung.com), with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the device was purchased; (c) the device model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the device box; (ii) on the device information screen, which can be found under "Settings;" (iii) on a label on the back of the device beneath the battery, if the battery is removable; and (iv) on the outside of the device if the battery is not removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the

date of the first consumer purchaser's purchase of the device and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect your use of the device or its preloaded Software, and you will continue to enjoy the benefits of this license.

16. ENTIRE AGREEMENT; SEVERABILITY. This EULA is the entire agreement between you and Samsung Electronics Co. relating to the Software and supersedes all prior or contemporaneous oral or written communications, proposals and representations with respect to the Software or any other subject matter covered by this EULA. If any provision of this EULA is held to be void, invalid, unenforceable or illegal, the other provisions shall continue in full force and effect.

[101212]

DRAFT  
Internal Use Only

# Index

---

## Numerics

### 2G Network

Using Only 287

### 2-Sec Pause

Adding 75

## A

### ABC 99

### Accessing

Recently-used applications 60

Voice mail 22

### Accessory 315

Audio Output 315

Dock Sound 315

### Accounts and Sync

Adding Contacts 125

### Add 2 Sec Pause 78, 115

### Add to Favorites 130

### Adjusting

Call volume 84

### Adobe PDF 235

### Air Gesture

Activate 56, 325

382

Air Browse 325

Air Call-Accept 325

Air Jump 325

Air Move 325

On 56, 325

Quick Glance 57, 325

### Airplane Mode

On 284

### Alarm

Deleting an Existing Alarm 213

Setting 211

Turning Off 213

### Alerts

Presidential 141

### Alerts on Call 306

### Allow Diagnostics 17, 334

### AllShare

Definitions 241

### AllShare Cast Hub 35

1st Time Pairing 201

Activation on Device 201

Connecting 200

Disconnecting Your Device 202

Dongle 201

Pairing 201

Pairing Your Devices 201

Re-pairing a Device 202

Set Up Hardware 200

Streaming Videos 204

Troubleshooting 203

### AllShare Play

see Samsung Link 241

### AllShare Play

see Samsung Link 197

### AllShareCast Hub 241

### AMBER Alerts 141

Disable 142

### Android Beam 291

### Answering

Home Key 306, 308

### Answering a call 75

### Application cache and data

Clearing 234

## **Application Menus**

Navigating through 58

## **Applications 42**

Calculator 43, 207

Calendar 43

Camera 44, 210

ChatON 44

Chrome 44

Clock 44

Contacts 45

Downloads 45

Dropbox 45

Email 45, 217

Flipboard 45

Gallery 45

Google 46

Google Mail 46, 218

Google Maps 47, 222

Group Play 46

Help 46

Hide 43

Internet 46, 221

Local 46

Lookout Security 46

Messaging 47

messaging 225

Mobile Hotspot 47

Music Player 47

My files 47

Navigation 48

Phone 48

Photo Reader 48

Play Books 48

Play Magazines 48

Play Movies & TV 48

Play Musc 49

Play Store 49

Polaris Office 4.0 49

S Memo 49

S Translator 50

S Voice 50

Samsung Apps 50

Samsung Hub 50

Samsung Link 50

Samsung Video 50, 242

Samsung WatchON 51

Settings 51

Sharing with Others 61

Show Hidden 43

Shutting Down 24

Storage Used 340

Story Album 51

T-Mobile My Account 51

T-Mobile Name ID 51

T-Mobile TV 51

TripAdvisor 52

Using the Camcorder 169

Using the Camera 162

Visual Voicemail 52

Voice Recorder 52, 249

Voice Search 52

VPN Client 52

YouTube 52, 251

## **Applications and Development 207**

### **Apps**

Adding 42

Close 248

Reset Preferences 340

### **Apps Screen**

Customizing 42

### **Area Code**

Auto Assign 310

## **Audio**

Output Mode 315

**Auto Redial** 311

## **Auto Reject**

Configuration 76

**Auto Reject List** 306

**Auto Reject Mode** 305

**Automatic Answering** 306

**Automatic Restore** 332

## **B**

## **Back up**

My Account 332

My Data 332

**Backup and Restore** 332

**Basic Mode** 305

## **Battery**

Charging 13

Display Percentage 15, 300

Extending Life 15

Installing 12

Low Battery Indicator 15

Removal 12

Wall Charger 13

## **Battery Cover**

Removal 8

Replace 9

## **Battery Life**

Extending 15

**Battery Usage** 341

**Battery Use & Safety** 354

## **Bigger Font**

Setting 316

## **Blacklist**

Adding 117

**Blocking Mode** 314

On 314

## **Bluetooth** 282

About 262

Change Name 263

Changing Name 283

Configure Device Settings 265

Deleting a Paired Device 265

Disconnecting a Paired Device  
265

Media Audio 265

Microhone Function 265

Off 262, 282

On 262, 282

Outgoing Headset Condition 306,  
309

Paring Devices 264

Review Downloaded Files 263

Scan for Devices 263

Scanning for other Devices 283

Sending Contact Information 266

Sending Contacts Via 266

Sending Namecard 122

Set Visibility 263

Settings 262

Status indicators 262

Switching to Headset during call  
86

Turning on and off 262, 282

Visibility 283

Visible Time-Out 263

## **Browser**

Adding bookmarks 258

Deleting bookmarks 259

Emptying cookies 259

Entering a URL 255

Navigation 254

- Options 254
- Resetting Default Actions 340
- Settings 260

## **Bubble**

- Options 138

## **C**

## **Calculator**

- Scientific Functions 207

## **Calendar**

- Creating an event 209
- Settings 209
- Sync 208

## **Calibrate Screen** 58, 328

## **Call**

- Accessories 306
- Settings 75, 76

## **Call Alert**

- Call Vibrations 306

## **Call Alerts** 306

## **Call Answering/Ending** 306

## **Call Barring** 310, 312

## **Call Duration** 94

- Resetting Times 94

## **Call Forwarding** 306

- Configuring 311

## **Call Functions** 71

- Answering 75
- Background Calling 72
- Ending 72
- Ending a Call 72
- Ending via Status Bar 73
- Making a Multi-Party Call 87
- Pause Dialing 78
- Redialing the last number 79
- Wait Dialing 78

## **Call Functions**

- Vibrate 307

## **Call Rejection** 76, 305

## **Call Settings** 305

- Additional Settings 310
- General 305
- Ripple Effect 305

## **Call Sound**

- Adding More Volume 84
- Personalize 84, 85

## **Call Status Tones** 306

## **Call Vibrations** 306

## **Call Volume**

- Adjusting 84

## **Call Waiting** 89, 311, 312

## **Caller ID** 310

## **Calling**

- Using Wi-Fi 81

## **Calls**

- Auto Reject 305
- Making a 71
- Multi-party 87
- Muting 86

## **Camcorder** 169

- Accessing the Video Folder 170
- Settings 166
- Shooting Video 169

## **Camera** 161

- Camera Options 163
- Enabling Share Shot 172
- Quick Settings 165
- Settings 166
- Taking Pictures 162

DRAFT  
Internal Use Only

**Care and Maintenance** 360

**Charging battery** 13

**ChatON** 158

Adding a Buddy 159

Adding New Buddy 159

Buddy photo share 168

Chatting On 159

Deleting Bubble 160

Register Service 158

**Children and Cell Phones** 349

**Chrome**

Google 211

**Clearing**

Application cache and data 234

**Closing Apps** 248

**Cloud** 331

**CMAS** 141, 142

**Collect Diagnostics** 17

**Commercial Mobile Alerting System**

**(CMAS)** 352

**Configuration**

Initial 16

**Connections**

Accessing the Internet 254

**Contact**

Copying to microSD Card 123

Copying to SIM Card 122

Creating a New 109

Joining 118

New From Keypad 111

Photo 177

**Contact Entry**

Options 118

**Contact List**

Options 116

**Contact Menus**

Options 117

**Contacts**

Adding a Number to Existing 114

Adding a Pause or Wait 115

Adding Your Facebook Friends

125

Additional Options 126

Deleting 115

Display Options 124, 127

Displaying Contacts by Name 127

Export List to microSD 333

First Name 127

Groups 128

Last Name First 127

Merge with Samsung Account  
116

Reject List 117

Sending All 121

Setting Default Location 116

Settings 127

Share Namecard Via 117

Sharing Settings 127

Sharing/Sending 121

**Contacts List** 71

**Context Menus** 114, 117

Navigation 59

Using 59

**Continuous Input** 106, 319

**Cookies**

Emptying 259

**Copying Contact** 122

**Create Folder**

Group Apps 42

**Creating a Playlist** 194

**Creating and sending**

Messages 132

## **Customizing**

Home screens 60

## **D**

## **Data**

Auto Sync Data 285

Restrict Background Data 285

## **Data Limit**

Setting 284

## **Data Roaming**

Activate/Deactivate 285, 286

## **Data Usage**

Cycle 285

Limiting 284

## **Date**

Selecting Format 342

## **Date and Time**

## **Default Storage**

Assigning 161

Camcorder 20, 161

Camera 20, 161

## **Deleting**

Multiple Messages 138

Single Bubble 139

Single Message 138

## **Deleting a contact**

115

## **Desk Clock**

211

Configuring 214

## **Device**

Calibration 58, 328

Reset 333

## **Device Name**

Edit 343

## **Device Options**

Screen 302

## **Display**

Icons 32

Settings 32

Status Bar 32

Using Negative Colors 316

## **Display / Touch-Screen**

357

## **Displaying your phone number**

## **DivX**

Locating VOD Number 181

Overview 180

Registering Your DivX Device 181

Registration Code 343

## **Do cell phones pose a health hazard?**

345

## **Dock**

Sound 315

## **Dongle**

AllShare Cast Hub 201

## **Downloading**

New application 232

## **Downloads**

215

Internet Downloads 215

Other Downloads 215

## **Draft Messages**

133

## **Dropbox**

198

Uploading Picture 217

## **E**

## **Easy Mode**

305

## **EDGE Network**

287

## **Edit Page**

61

## **Email**

145

Changing Signature 149, 153

Composing 148

Configuring Settings 148

Creating an Internet Account 146

Internet Email 146

Opening 147

Refreshing Messages 147  
Sending 126  
Wi-Fi Download of Attachments  
149, 154

## **Emergency**

Alert Preview 141  
Alerts 141

## **Emergency Alert**

Configuration 142

## **Emergency Alerts 141**

AMBER 141  
Imminent Extreme 141  
Message Settings 141  
Severe 141

## **Emergency Calls 359**

Making 73  
With SIM 74  
Without SIM 73

## **Emoticons 134**

## **Ending**

A call 72

## **Entering Text 95**

Using SWYPE 96

## **Erasing Files**

Memory Card 69

## **Exchange Email 150**

Account Setup 150  
Composing 152  
Configuring Settings 153  
Deleting Message 153  
Opening 152  
Refreshing Messages 152

## **Exposure to Radio Frequency (RF)**

## **Signals 345**

## **Extra Volume 84**

## **Extreme Alert**

Disable 142

## **F**

## **Face Unlock 295, 296**

## **Facebook**

Personalize 107, 320  
Predictive Text 107, 320  
Swipe Connect 98, 322  
Sync Calendar 126  
Sync Gallery 126

## **Facial Recognition 295**

## **Factory Data Reset 333**

Prior To 333

## **Factory data reset 70**

## **Favorites Tab 130**

## **FCC Hearing Aid Compatibility (HAC)**

## **Regulations for Wireless Devices 365**

## **FCC Notice and Cautions 367**

## **Fixed Dialing Numbers 312**

## **Flipboard 217**

## **Folder**

Create 42

## **Font**

Size 300  
Style 300

## **Font Size**

Caption 251  
Changing 316

## **Forgot Pattern? 298**

## **G**

## **Gallery**

Folder Options 176  
Opening 178  
Picture-In-Picture 180

## **Games**

Volume 302

## **Gesture**

Settings 324

## **Gestures**

Overview 56

Update/Refresh 326

## **Getting Started 7**

Battery 12

Battery Cover 8

Locking/Unlocking the Device 18

microSD card 11

SIM Card 9

Switching Device On/Off 18

Voice Mail 22

## **Gmail 155, 218**

Composing a Message 156

Creating an Additional Account  
157

Opening 155

Other Options 156

Personalize 107, 320

Personalize Swype 98, 322

Refreshing 156

Signing In 155

Viewing 156

## **Google**

Create New Account 19

Retrieving Password 20

Signing into Your Account 19

Voice Typing 95

## **Google Books 230**

## **Google Mail**

see also Gmail 156

## **Google Maps**

Enabling a location source 223

Opening a map 223

## **Google Music 186, 232**

## **Google Now 25, 251**

Adjust Settings 25

## **Google Places**

See also Local 221

## **Google Talk 51, 248**

## **Google Voice Typing**

Configuring 108, 318

Using 108

## **GPS & AGPS 358**

## **Group**

Joining 220

## **Group Play 219**

Creating a Group 219

Dropbox 216

Joining a Group 220

S Memo 238

Share Pictures 168

Sharing Pictures 219

## **Groups**

Adding a Member to an Existing  
Group 128

Creating a new caller group 128

Deleting 129

Deleting a Caller Group 129

Editing a Caller Group 129

Removing an Entry 128

Settings 129

## **Gyroscope**

Calibration 58, 328

## **H**

## **Handwriting 103**

Settings 106, 319

## **Haptic Feedback**

Turn On/Off 341

Vibrate 304

Vibration Setting 302

## **HDR** 164

## **Health and Safety Information** 345

## **Help**

In-Device 220

## **Hidden Applications**

Show 43

## **Hold**

Placing a Call on Hold 85

## **Home** 40

## **Home Key** 39

## **Home Screen**

Assigning a New 61

Changing Wallpaper 65

Menu Settings 42

Overview 40

## **Home screens**

Customizing 60

## **Homepage**

Setting New 258

## **Icons**

Description 32

Indicator 32

Status 32

## **Images**

Assigning as a Contact icon 177

Assigning as wallpaper 178

Transferring 333

Verifying 333

## **Importing and Exporting**

To micro SIM card 127

## **In Call**

Options 84

## **In call**

Options 86

## **Incognito** 257

Create Window 257

Exit Window 257

## **Incoming Call**

Vibration Setting 302

## **Indicator icons** 32

## **International Call** 77

## **International Calls**

Making 77

## **Internet** 254

Brightness Setting 255

Search 256

Set Home Page 260

Set New Homepage 258

## **Internet Downloads** 215

## **Internet Email** 145

## **IP Address** 343

## **IR**

Smart Remote 26

## **Joining**

Contact information 118

## **Language**

Select 318

## **Latitude** 224

## **LDAP** 116

## **Live Wallpaper**

Selecting 65

**Local** 221

**Location**

Settings 224

**Lock Pattern**

If I Forgot My Pattern 298

**Lock Screen** 294

Changing Wallpaper 66

Say Wake-Up Command 294

Shortcuts 294

Viewing Missed Calls 94

**Logs** 91

Accessing 91

Accessing from Notifications 92

Altering Numbers 93

Erasing 93

**Lookout Security** 222

**Low battery indicator** 15

**LTE**

Network Mode 286

Selecting 287

**LTE Network** 287

**M**

**Making**

Emergency Calls 73

International Calls 77

New call 71

**Managing Applications**

Clearing Application Cache 338

Uninstalling Third-party

Applications 338

**Market**

see Play Store 232

**Marking contact**

As a default 120

**Memory Card**

Erasing Files 69

**Merge Calls** 87

**Merge with Google** 116

**Message**

Options 133

Read 136

Register a Number as Spam 137

Reply 137, 159

Thread Options 137

Threads 137

**Message Search** 139

**Message threads** 137

**Messaging**

Adding a Signature 141

Adding Attachments 135

Additional Text 136

Block Unknown Senders 142,  
144

Composing Options 134

Creating and sending 132

Creating and Sending Text  
Messages 132

Deleting a message 138

Draft 133

Google Mail 155

Icons on the Status Bar 131

Insert Smiley 134

Locked 133

Menu Options 133

Options 133

Scheduled Messages 133

Settings 139

Signature 141

Signing into Google Mail 155

RAFT  
Internal Use Only

- Spam 133
- Text Templates 144
- Translate Text 135
- Types of Messages 131
- Viewing new 136
- micro SIM Card** 10
  - Changing Existing PIN 336
  - Importing and Exporting 127
  - Insertion 10
  - Lock 336
  - Removal 10
  - Setting Up Lock 336
- microSD Card**
  - Insertion 11
  - Removal 11
- Microsoft Exchange** 110, 145
- Missed Call**
  - Viewing from Lock Screen 94
- Mobile Data**
  - Activate/Deactivate 284
  - Set Data Limit 284
  - Usage 286
- Mobile HotSpot** 272, 289
  - Activating 272

- Allowed Devices 274
- Changing Password 273
- Connecting 273
- MAC Filtering 274
- Mobile HotSpots**
  - Detect and Connect 285
- Mobile Networks** 285
  - Data Roaming 286
  - Mobile Data 286
- Mobile Web** 254
  - Entering Text in the Mobile Web
    - Browser 255
  - Navigating with the Mobile Web 254
  - Using Bookmarks 257
- Mono**
  - Audio Setup 317
- Motion**
  - Activate 57, 326
  - Browse Image 326
  - Direct Call 326
  - Mute/Pause 326
  - On 57, 326
  - Overview 56

- Settings 324
- Smart Alert 326
- Zoom 326
- Mounting the SD card** 68
- Multi Window**
  - Activate/Deactivate 299
- Multi-Party Call** 87
  - Dropping One Participant 89
  - Private conversation 88
- Multi-party call**
  - Setting up 87
- Multi-party calls** 87
- Multi-Tasking**
  - Background Calling 72
  - Watching Videos 180
- Music** 225
  - Volume 302
- Music App**
  - Adding Songs to Playlists 191
  - Changing Library View 187
  - Changing Settings 187
  - Creating a Playlist 190
  - Deleting a Playlist 191
  - Listening 188

- Music Application 186
- Now Playing Screen 189
- Options While Playing 189
- Playing 188
- Playing a Playlist 191
- Searching for Music 187
- Tab Options 189

## **Music File Extensions**

- 3GP 191
- AAC 191
- AAC+ 191
- eAAC+ 191
- M4A 191
- MP3 191
- MP4 191
- WMA 191

## **Music Files**

- Removing 195
- Transferring 195

## **Music Player**

- Adding Music 194
- Creating a Playlist 194
- Editing a Playlist 195
- Making a Song a Ringtone 192

- Options 192
- Playing Music 191
- Removing Music 195
- Using Playlists 194

## **MusicPlayer** 191

**My Places** 223, 228, 335

## **N**

### **Namecard**

- Sending 121
- Sending All 121
- Share Via 121

### **Navigating**

- Application Menus 58
- Sub-Menus 59
- Through Screens 53

### **Navigation**

- Enable Location 228
- Go Home 229
- Options 228

**Negative Colors** 316

### **Network connection**

- Adding a new 269

### **Network Mode**

- 2G Network 287

- GSM/WCDMA 287

- LTE 287

## **New applications**

- Downloading 232

## **NFC**

- Turning On 245

**NFC (Near Field Communication)** 291

**Noise Reduction** 85

**Non-Market Applications** 234

## **Notification**

- Vibration Setting 302

**Notification Bar** 37

- Using 37

## **Notifications**

- Volume 302

## **O**

**On/Off Switch** 18

**Operating Environment** 363

## **Organizer**

- Calculator 207
- World Clock 213

**Other Downloads** 215

**Other Important Safety Information**

367

## **Out of Office**

Message 154

Settings 154

## **Outlook** 145

## **Overview**

Home Screen 40

## **P**

## **Palm Motion**

Activate 57, 327

Capture Screen 327

Mute/Pause 327

On 57, 177, 327

## **Passpoint**

On 277

## **Passwords**

Make Visible 336

## **Pause**

Adding to a Contact 115

## **Pause Dialing** 78

## **Personal Localized Alerting Network (PLAN)** 352

## **Personalize**

Call Sound 84

394

## **Phone**

Icons 32

Switching on/off 18

## **Phone number**

Finding 71

## **Phone Ringtone** 303

## **Phone Vibration** 303

## **Photo Reader**

Detect Text 169

## **Photos**

Options 168, 170

Sharing 168, 170

## **Picture**

Set As 177

Streaming from Gallery 176

## **Picture-In-Picture** 180

## **Pictures**

Instant Sharing 172

Sharing 171, 174

## **Play Books** 230

## **Play Music** 232

## **Play Store** 232

Quick Access 42

## **Pointer Speed**

Configuration 324

## **Power**

Auto Adjust Screen Tone 300

## **Power Saving**

CPU Power 341

Haptic Feedback 341

LCD Adjustment 300

Learning About 341

Screen Power 341

## **Power Saving Mode** 341

## **Predictive Text**

Activation 107, 320

Using 106

## **Prepend**

Area Code 311

## **Primary Shortcuts** 41

Adding and Deleting 63

Customizing 63

Replacing 63

DRAFT  
Internal Use Only

## Q

**Quick Dialing** 72

**Quick Messaging** 133

## R

**Recently-used Applications**

Accessing 60

**Redialing the last number** 79

**Reducing Exposure**

Hands-Free Kits and Other

Accessories 348

**Reject Call**

Rejection Messages 306

**Reject Calls**

Managing 76

**Reject List**

Add To 77

Add to 92, 93

Adding 117

Auto Reject 77

Removing 117

**Rejection List**

Assigning Multiple Numbers 77

Assigning Single Numbers 77

**Rejection Messages**

Set Up 306

**Reset** 333

**Reset App Preferences** 340

**Reset Device** 333

**Responsible Listening** 361

**Restarting**

Device 18

**Restore** 332

**Restrict**

Background Data 285

**Restricting Children's Access to Your**

**Mobile device** 366

**Ringtone**

Device 303

Volume 302

**Ripple Effect** 75

## S

**S Beam** 292

On 174, 292

Sharing Multiple Pictures 175

Sharing Pictures 174

**S Memo**

Creating a New Memo 236

**S Voice** 239

Set Wake-Up Command 294

Using 90

**Samsung Account**

Creating 21

Merge Contacts 116

Set up 183

**Samsung Hub**

Creating a New Account 183

Using 183

**Samsung Keyboard** 102

ABC Mode 104

Changing the Input Type 103

Enabling 102

Entering Symbols 105

Handwriting Settings 106, 319

Predictive Text Settings 320

Reset Settings 106, 320

Settings 105, 319

Symbol/Numeric Mode 105

**Samsung Link**

Configuring Settings 197

Sharing Files 198

Sharing Media 199

- Uploading Images to Web 198
- Uploading Video to Web 199
- Web Storage Setup 198
- Samsung Mobile Products and Recycling** 355
- Samsung Video**
  - Sharing Videos 179
- Samsung Videos**
  - Picture-In-Picture 180
- Save a Number**
  - From Keypad 111
- Scan for Nearby Devices** 193
- Screen**
  - Home 40
  - Navigation 53
- Screen Capture** 327
  - Taking a Screen Shot 177
- Screen Lock**
  - Set Up 296
  - Sounds 304
- Screen Lock Pattern**
  - Changing 297
  - Creating 296
  - Deleting 297
- Forgot My Pattern 298
- Screen Mirroring**
  - Activate on Device 201
  - Activation 293
  - On 201, 204
  - Using AllShare Cast Hub 200
- Screen Mirroringt**
  - On 293
- Screen Rotation**
  - Auto-Rotate 300
- Screen Timeout** 300
- Screen Unlock**
  - Face and Voice Unlock 296
  - Face Unlock 295
  - Swipe 295
- Screens**
  - Adding and Deleting 60
  - Customizing 60
  - Rearranging 61
- SD card**
  - Communicating With 68
  - Mounting the 68
  - Unmounting 69
- Sending a Namecard** 121
- Setting an alarm** 211
- Setting up**
  - Voicemail 22
- Settings** 166, 275
  - Accessing 275
  - Browser 260
  - Call 75
  - Contact list 127
  - Display 32
  - Enabling the GPS Satellites 335
  - Enabling Wireless Locations 335
  - Messaging 139
  - Tab Overview 275
  - Wallpaper 65, 66
- Setup**
  - Initial 16
- Severe Alert**
  - Disable 142
- Share Applications** 61
- Share Shot** 172
  - Configuring 173
  - Enabling 173
  - Stop Sharing 173

Taking Images 173  
**Shortcuts**  
Adding from Application Screen 62  
Adding from Home Screen 62  
Deleting from a Screen 63  
Managing 62  
Primary 41

**SIM**  
Micro 7, 10  
see also micro SIM 10

**SkyDrive** 198

**Smart Alarm** 212

**Smart Practices While Driving** 352

**Snooze** 213  
Repeat 212

**SNS** 125

**Social Network**  
Adding Facebook Contacts 125  
Resync 126

**Social Networking**  
Adding Contacts From 125

**Software Update** 343  
Wi-Fi 344

**Song**  
Set As 193  
**Sound**  
Adapt Sound 304

**Sounds**  
Turn Off All 317

**Spam** 144  
Accessing Your Spam Folder 144  
Add a Phrase 141, 144  
Add Number 134, 135, 137  
Assigning Manually 143  
Assigning Phone Numbers 143  
Block Unknown Numbers 144  
Block Unknown Senders 142, 144  
Manually Add a Number 141, 143  
Match Criteria 143  
Registering a Phrase as Spam 143  
Settings 141, 143

**Spam Messages** 133  
Assigning 133

**Speakerphone**  
Turning on and off 86

**Specific Absorption Rate (SAR)**

**Certification Information** 350  
**Speed Dial**

Changing an entry 80  
Making a call 80  
Removing an entry 80  
Setting up entries 79

**Standard Limited Warranty** 369

**Status Bar** 32

**Sub-Menus**  
Navigation 59

**SugarSync** 198

**Switching to a Bluetooth**  
During a call 86

**Swepe Connect**  
Backup and Sync 97, 322

**Swepe** 95  
123ABC Mode 100  
ABC Mode 99  
Cellular Data 97, 322  
Connect 97, 322  
Connect Registration 97, 322  
Contribute Usage Data 97, 322  
Entering Numbers 101  
Entering Symbols 101

- Entering Text 96
- Keyboard Mode 99
- Personal Dictionary 98, 322
- Preferences 96, 321
- Reset Dictionary 97, 321
- Select Text Input Mode 99
- Settings 96, 321
- SYM mode 99
- Updates 98, 322

## **System Manager** 334

## **System Tone**

- Settings 304

## **Systeme**

- Volume 302

## **T**

## **Task Manger**

- Overview 24

## **TecTile**

- Joining a Wi-Fi 247
- Programming 246, 247
- Programming a Text Message 247

## **TecTiles** 245

- Installation 245

398

## **Tethering** 289

- Active Icon 271
- Disconnecting 272
- see USB Tethering 271

## **Text Input**

- Methods 95

## **Text Input Method**

- Selecting 95

## **Text Templates** 144

- Create Your Own 145

## **Text To Speech** 323

## **Text-to-speech**

- Configuration 323

## **Third-Party Applications** 338

- Uninstalling 234

## **Time Zone**

- Selecting 342

## **Timer**

- Automatic Answering 306, 309

## **Tington**

- Assigning 307

## **Tools**

- Camera 162

## **TrackPad**

- Configure 324

## **Transferring Large Files** 174, 292

## **Transferring Music Files** 195

## **Translate** 108, 135

## **TranslateMessage Bubble** 138

## **TTS** 323

## **TTY Mode** 310

## **Twitter**

- Personalize Swype 98, 322
- Predictive Text 107, 320

## **U**

## **UL Certified Travel Charger** 357

## **Understanding Your Device** 26

- Back View 29
- Display 31
- Features 26
- Front View 27
- Home 40
- Side Views 30

## **Uninstalling**

- Third-party applications 234

## **Unknown Numbers**

- Blocking Messages 144

**Unknown Sources** 234

**Unlock**

Using Face 295

Using Voice 296

**Unmounting**

SD card 69

**Usage**

Battery 341

**USB Connections**

As Storage Device 267

**USB Settings**

As Storage Device 267

**USB Tethering** 271

Activating 271, 289

**Use GPS Satellites** 223, 228, 335

**Use Wireless Networks** 223, 228, 335

**Using Favorites**

Adding Favorites 258

**V**

**Vibrate** 307

**Vibration**

Create 309

Device 303

Intensity Setup 302

**Video**

Volume 302

**Videos**

Options 169

**Voice Input**

Recognition 323

**Voice mail**

Accessing 22

Accessing from another phone 22

Setting up 22

**Voice Search** 251, 323

**Voice Typing** 95

Configuring 108, 318

Using 108

**Voice mail** 314

**Volume Settings**

Adjusting 302

**VPN**

Adding 289

Settings 289

**VPN Client** 251

**W**

**Wait** 78, 115

Adding to a Contact 115

**Wait dialing** 78

**Wallpaper**

Assign Home 42

Home and Lock Screens 65

**Wallpapers**

Assigning from Gallery 168

Changing Home Screen 65

Changing Lock Screen 66

Changing via Settings Menu 65

Managing 65

**Warranty Information** 369

**Web** 254

History 259

**Web applications**

enable downloading 266

**Widget**

Adding Widgets 42

**Widgets**

Adding and Removing 64

Google Talk 51

DRAFT  
Internal Use Only

Moving to a Different Screen 64  
Settings 243  
Stopwatch 213

## **Wi-Fi**

About 268  
Activating 81, 268, 276  
Advanced settings 270  
Calling 81  
Connecting to 268  
Deactivating 270  
Direct Connection 281  
During Sleep 278  
MAC Address 279  
Manually Adding Network 279  
Manually scan for network 270  
Off 270  
On 268, 270, 276  
Settings 276  
Show Usage 285  
Status icons 269

## **Wi-Fi Calling** 9

Activating 82, 290  
Connection Preferences 82, 291  
Icons 83

Launching 83  
On 290  
Settings 82, 291

## **Wi-Fi Direct** 281

Activate and Connect 281  
Assigning a Name 282  
On 172, 281

## **World Clock**

DST Settings 213

## **WPA2 PSK** 272, 273

## **WPS PIN**

Pairing 280

## **WPS Push Button**

Connect 280  
Pairing 280

## **Y**

## **YouTube**

High Quality 253  
High Quality 206  
Settings 251