

The Samsung logo, consisting of the word "SAMSUNG" in white capital letters inside a blue oval, is positioned in the upper right section of the page.

SAMSUNG

DIGITAL CELLULAR
TELEPHONE
SPH-A840
User's Manual

The Samsung logo, consisting of the word "SAMSUNG" in white capital letters inside a blue oval, is positioned in the middle left section of the page.

SAMSUNG

ELECTRONICS

World Wide Web
<http://www.samsungmobile.com>

Printed in Korea
Code No. : GH68-00000A
English, 4/05, Rev.1.0



Important Safety Precautions

Read these guidelines before using your wireless phone. Failure to comply with them may be dangerous or illegal.

Road Safety at All Times

Do not use a hand-held phone while driving; park the vehicle first.

Switching Off When Refueling

Do not use the phone at a refueling point (service station) or near fuels or chemicals.

Switching Off in Aircraft

Wireless phones can cause interference. Using them in aircraft is both illegal and dangerous.

Switching Off in Hospitals

Switch off your phone near medical equipment. Follow any regulations or rules in force.

Interference

All wireless phones may be subject to interference, which could affect their performance.

Special Regulations

Meet any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger (in a hospital for example).

Please read this manual before operating your phone, and keep it for future reference .

Sensible Use

Use only in the normal position (held to the ear). Avoid unnecessary contact with the antenna when the phone is switched on.

Emergency Call

Ensure the phone is switched on and in service.
Key in the emergency number for your present location, then press **TALK**. If certain feature are in use, deactivate those features before you can make an emergency call. Give all the necessary information as accurately as possible. Do not cut off the call until given permission to do so.

Water Resistance

Your phone is not water-resistance. Keep it dry.

Accessories and Batteries

Use only Samsung-approved accessories and batteries.

Qualified Service

Only qualified service personnel may install or repair your phone.

For more detailed safety information, see “Health and Safety Information” on page 65.

Table of Contents

YOUR PHONE	
Unpacking	4
Key Descriptions	5
Display	6
Built-in Antenna	6
GETTING STARTED	
Charging a Battery	9
Switching the Phone On/Off	11
CALL FUNCTIONS	
Making a Call	12
Answering a Call	17
In-Call Options	18
Using Caller ID	19
Viewing Missed Calls	20
Three-Way Calling	21
Call Waiting	22
Call Forwarding	22
Adjusting the Volume	23
ENTERING TEXT	
Changing Text Input Mode	24
T9 Mode	25
Alpha Mode	26
Symbol Mode	28
Number Mode	28

USING THE MENUS

Accessing a Menu Functions by Scrolling	29
Accessing a Menu Functions by Using its Shortcut.....	30
Your Phone's Main Menu	31

CALL HISTORY

Missed Calls (MENU 1-1)	33
Outgoing Calls (MENU 1-2)	34
Incoming Calls (MENU 1-3)	35
Erase History (MENU 1-4)	36

CONTACTS

Find (MENU 2-1)	37
Add New Entry (MENU 2-2)	39
My Phone # (MENU 2-3)	41
Speed Dial # (MENU 2-4)	41
Group Setting (MENU 2-5)	41
Services (MENU 2-6)	42

MESSAGING

Send Message (MENU 3-1)	43
Text (MENU 3-2)	43
Picture Mail (MENU 3-3)	44
Voice SMS (MENU 3-4)	44
Email (MENU 3-5)	44
Instant Message (MENU 3-6)	44
Voicemail (MENU 3-7)	44
Settings (MENU 3-8)	44

PICTURES

Camera (MENU 4-1)	45
My Pictures (MENU 4-2)	45
Online Albums (MENU 4-3)	45
Order Print (MENU 4-4)	45
Account Info (MENU 4-5)	45
Cam. Key Guard (MENU 4-6)	45

DOWNLOADS

Games (MENU 5-1)	46
Ringers (MENU 5-2)	46
Screen Savers (MENU 5-3)	46
Applications (MENU 5-4)	48

WEB

Launch (MENU 6-1)	47
-------------------------	----

VOICE MEMO

Record (MENU 7-1)	48
Review (MENU 7-2)	48
Erase All (MENU 7-3)	48

TOOLS

Today (MENU 8-1)	49
Scheduler (MENU 8-2)	49
World Time (MENU 8-3)	50
Alarm Clock (MENU 8-4)	50
Task List (MENU 8-5)	50
Memo Pad (MENU 8-6)	51
Claculator (MENU 8-7)	51
Countdown (MENU 8-8)	52

SETTING

Display (MENU 9-1)	54
Sounds (MENU 9-2)	56
PCS Vision (MENU 9-3)	59
Voice Service (MENU 9-4)	59
Security (MENU 9-5)	60
Airplane Mode (MENU 9-6)	63
Launch Pad (MENU 9-7)	63
Others (MENU 9-8)	63
Phone Info (MENU 9-9)	64

HEALTH AND SAFETY INFORMATION	65
-------------------------------------	----

APPENDIX	81
----------------	----

Your Phone

Unpacking

- Handset
- Battery
- DTC
- User Manual
- CD

Key Descriptions

Key Functions

MENU : Enters the menu facility.

OK : *In the menu facility*, selects a menu function or stores information that you have entered (such as a name) in the phone memory. *In Standby mode*, enters the Mail Kit Menu.

Up/Down Navigation : Adjusts the volume level or type of incoming calls.

TALK : Makes or answers a call.
In Standby mode, redials the last outgoing number when pressed twice.

BACK: Deletes characters from the display.
In the menu facility, returns to the previous menu level.

END: Ends a call. Also switches the phone on and off when pressed and held.
In the menu facility, returns to Standby mode and cancels your input.

Volume : *During a call*, adjusts the voice volume. *In Standby mode with the phone open*, adjusts the ringer volume.

Key Descriptions (continued...)

Key Functions


***** : Use this key for the special star calling feature.

: Use this key when you make a call to an automate systemm, especially when using teleservices.

Display

Layout

The display comprises two areas; an upper line of fixed icons, and the lower text and graphic area. The following icons display at power-on:



Icons



Signal strength : Shows the received signal strength. The greater the number of bars, the better the signal strength.



Service: Appears when a call is in progress.



No service indicator: Appears when you are outside a service area. When it appears, you cannot make or receive calls.



New voice message: Appears when you have a new voice message.



New text message: Appears when you have a new text message.



Alarm on: Appears when you set an alarm.



GPS on: Appears when GPS mode is on.



Roaming: Appears when you are out of your home area and have registered with a different network (when travelling in other countries, for example).



Vibration mode: Appears when a vibration mode on.



Battery strength: Shows the level of your battery. The more bars you see, the more power you have left.

Backlight

The display is illuminated by a backlight. When you press any key, the backlight illuminates. It turns off if no key is pressed within a given period of time.

Built-in Antenna

Your phone has a built-in antenna. As with other mobile radio transmitting equipment, do not touch the antenna unnecessarily when the phone is switched on. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Getting Started

Charging a Battery

Your phone is powered by a rechargeable Li-ion battery. A travel adapter is provided with your phone. Use only approved batteries and chargers. Ask your local SAMSUNG dealer for further details.

The phone can be used while the battery is charging.

Note: You must fully charge the battery before using your phone for the first time.

1. Connect the lead from the travel adapter to the bottom of the phone. Check that the arrow on the lead connector is facing towards the front of the phone.
2. Connect the adapter to a standard AC wall outlet.

The LEDs on the front of the charger indicate the following:

- Red indicates that the battery is charging.
- Green indicates that the battery is fully charged.
- Yellow indicates that the battery is operating at a temperature that is too high or too low, or that something is not plugged in correctly. Check the charger and battery for proper connections.

3. When charging is finished, disconnect the adapter from the power outlet.

Disconnect the adapter from the phone by pressing the grey tabs on either side of the connector and pulling the connector out.

Low Battery Indicator

You can easily tell if your battery needs to be recharged by checking the battery strength indicator  in the upper-right corner of your phone's display. The presence of all three bars indicates a full charge, two bars indicates a smaller charge, and one bar indicates an even smaller charge. No bars (the battery icon is empty) means your battery must be charged.

When the battery charge level gets low, the battery sensor blinks an empty battery icon () , sounds a tone. If the battery level gets too low, the phone will turn off automatically. Unfortunately, if this happens you'll lose whatever you are doing, including dropping your call. Watch the battery strength icon and make sure your battery is adequately charged.

Switching the Phone On/Off

1. Press the Flip Up button to flip up.
2. Hold down **END** for more than one second to switch the phone on.

When the system locates services, the greeting message displays along with the date and time.

If the phone is out of service, the  icon appears in the display. In this case, you cannot place and receive calls. You can try again later when service is available.

3. When you wish to switch the phone off, hold down **END** for more than two seconds.

Call Functions

Making a Call

In Standby mode, key in the area code and phone number and press **TALK**.

Correcting the Number

To clear ...

The last digit displayed

The whole display

Then

Press **BACK**.

Hold down **BACK** for more than one second.

Ending a Call

When you have finished your call, briefly press **END** or close the phone.

If you press **END**, the call time (length of the call) displays briefly and the phone returns to Standby mode.

Using Call Log

Press **TALK** to access call log in Standby mode. To recall any number of these log, proceed as follows.

1. Use the navigation key to scroll through the list until you select the required name or number.
2. Press **TALK** to dial the number displayed.

Speed Dialing

Once you have stored phone numbers in the phone book memory, you can dial them easily whenever you want.

You can dial the stored phone number automatically without pressing **TALK**. See below.

One-Touch Dial

Memory locations 01 through 09 are special one-touch locations. You can dial the phone numbers stored in the Phone Book memory from 01 through 09 simply by pressing one button.

Press and hold the third digit of the memory location containing the number to be dialed.

For example: Location no. 009
Press and hold **9**.

The number (and name) stored is displayed, then dialed.

Two-Touch Dial

Memory locations 10 through 99 are special two-touch locations.

Press the second digit briefly, then hold down the third digit of the memory cell.

For example: Location no. 023

Press 2 briefly and hold down 3.

The number (and name) stored is displayed, then dialed.

Three-Touch Dial

Memory locations 100 through 300 are special three-touch locations.

Press the first and the second digit briefly, then hold down the third digit of the memory cell.

For example: Location no. 123

Press 1 and 2 briefly, then hold down 3.

The number (and name) stored is displayed, then dialed.

Pause Dialing

When you call automated system, like banking services, you are often required to enter a password or account number. Instead of manually entering the numbers each time, you can store the numbers in your Phone Book, separated by special characters called pauses.

Your phone has two pause dialing methods:

- Pause dialing from the Phone Book
- Manual pause dialing

Storing Pauses in a Phone Book Entry

To store a number in your Phone Book that contains pauses:

1. Enter the phone number you want to store (such as the bank's tele-service phone number).
2. Press **MENU** . The pause menu options display.
 - 'P' pause : The letter 'P' displays within the number, meaning that a hard pause will occur at that point in the calling sequence. Enter digits that need to follow the pause.
 - 'T' pause: The letter 'T' displays in the number, meaning that a "Timed (2 second) pause will occur at that point in the calling sequence.
 - Hyphen: Places a hyphen between characters.

3. Press **OK** to select an option. Continue entering the number and press **OK** to store the number in your Phone Book.
4. Store the number in your Phone Book as you normally would by pressing **OK** and following the screen prompts..

Pause Dialing from a Stored Phone Book Entry

1. Dial the number from the Phone Book.
2. Wait for the appropriate prompt for the number (credit card number, bank account number, etc.).
3. When prompted, press **TALK** to send the DTMF number that follows your hard pause.

“SENDING DTMF” flashed on the display and the transmitted tone sounds.

Manual Pause Dialing

You can enter pauses manually during the dialing process.

1. Enter the phone number of the service you want to connect to (such as a bank's tele-service phone number).
2. Press **MENU**. The pause menu options display.
3. Press **OK** to select an option.
4. After connecting, press **TALK** again to transmit the additional number at the prompt from the tele-service.

Answering a Call

When somebody calls you, the phone rings and the phone icon is displayed in the middle of the external display.

If the caller can be identified, the caller's phone number (or name if pre-stored in your Phone Book) is displayed. If the caller cannot be identified, only the phone icon appears.

1. To answer a call, open the phone. If the phone is already open, press **TALK**.
2. End the call by closing the phone or pressing **END**.

Note: You can answer a call while using the phone book or menu features. The current operation will be interrupted.

In-Call Options

Your phone provides a number of functions that you can use during a call. You may not utilize all of these functions at all times. Many of the in-call options are network services.

Press **MENU** during a call to access the following in-call options:

Phone Book: allows you to access the **Phone Book** menu.

Mute/Quit: allows you to switch your phone's microphone off, so that the other party cannot hear you.

Example: You wish to say something to another person in the room but do not want the other party to hear you.

Silent/Quit: does not transmit the key tones. It allows you to press keys without hearing annoying key tones during a call.

Send Tel #: Sends the telephone number to the other caller.

My Phone #: shows your phone number.

SEND: Sends the DTMF..

Using Caller ID

This feature tells you who is calling you by displaying the caller's number when the phone rings. If a caller's name and number are stored in your Phone Book, the corresponding name is also displayed. If you call someone who has this feature, your phone number will be displayed on the their phone.

Note: Contact your service provider to setup the Caller ID service.

Viewing Missed Calls

Your phone keeps a list of calls that you do not answer when the phone is on and service is available. The phone indicates a missed call by displaying a text notification on the screen. Additionally, if caller information is available, the screen displays the phone number of the most recent missed call.

Press **TALK** to call the displayed number, or **OK** to save the number in Phone Book.

Dropped Calls

A dropped call can occur during a conversation in response to a signal fade or leaving a service area. In this case, the call ends and “Call Dropped” displays.

Failed Calls

A failed call can occur if your phone is out of calling range or the network is temporarily busy. Your phone responds to a failed call by displaying an appropriate message: “Call Failed Out of Range” or “Call Failed Network Busy.”

Three-Way Calling

This feature enables you to conduct conference calls with two separate parties at the same time. The phone records each party into the Outgoing Calls Log. Also, You are billed airtime for each outgoing call separately.

Note: Contact your service provider to activate Three-Way Calling.

To place a Three-Way call:

1. During a conversation, press **TALK**. The phone places the other party on hold.
2. Enter the phone number for the third party, and then press **TALK**. The phone dials the third party.
3. When you are connected to the third party, press **TALK** again to begin your three-way call.

If one of the callers (not you) hangs up, you and remaining caller stay connected. If you initiated the call and you hang up first, all three parties are disconnected.

Call Waiting

Call Waiting lets you receive a second call during conversation. Your phone notifies you of a call waiting by beeping and displaying “Call Waiting.”

Your phone provides the option of turning the Call Waiting feature on and off (if you have subscribed to the service). Call Waiting is on by default in the phone. If you choose to have an undisturbed conversation, simply turn off the feature for the current call.

Note: Contact your service provider to activate the Call Waiting service.

To answer a waiting call:

1. To answer the call, press **TALK**. The phone connects the calling party, and places the current party on hold.
2. Press **TALK** again to switch between two parties.

Note: If you do not respond to a Call Waiting notification, the phone will forward the call to voicemail or another number that you have set up. Contact your service provider for more information.

Call Forwarding

This feature provides the option of forwarding incoming calls to another phone number, even while your phone is off. Activating Call Forwarding does not affect outgoing calls made from this phone. Contact your service provider to activate Call Forwarding.

Adjusting the Volume

During a call, if you want to adjust the voice volume, use the volume keys on the left side of the phone.

In Standby mode, you can adjust the ring volume using the same keys.

Entering Text

Changing Text Input Mode

When using your phone, you will need to enter text at many times. For example, when storing a name in the Phone Book, creating your personal greeting or scheduling events in your calendar. You can enter alphanumeric characters into your phone by using your phone's keypad.

When you are prompted to enter text, the current text entry method will appear in the bottom of the display as T9, Alpha, Symbol or Number.

To change the input mode, press **MENU** and then press the navigation key to scroll to the mode you want and press **OK**.

T9 Mode

The T9 predictive text input mode allows you to enter words easily with a minimum of key presses. As you press each key, the phone selects a letter that makes up the word that it thinks you are typing, based on a built-in dictionary. As a new letter is added, the word changes based on the key that you have pressed.

1. When you are in the T9 predictive text input mode, start entering a word by pressing keys **2** to **9**. Press each key only once for one letter.

The word that you are typing appears in the display. It may change with each key that you press.

2. Enter the whole word before editing or deleting any keystrokes.
3. If the word is correct, start entering the next word.

Otherwise, press **0** repeatedly to display alternate word choices for the keys that you have pressed.

4. Complete each word with a space by pressing the **#** key.

To type words not found in the T9 mode, change the text input mode to the ABC mode.

To delete letters, press **BACK**. Press and hold down **BACK** to erase entire words.

Alpha Mode

When typing in **Alpha** mode, you should press key labeled with the required letter:

- Once for the first letter
- Twice for the second letter
- And so on.

For example, you press 2 three times quickly to display the letter “C”, 5 two times quickly to display the letter “K”. So, this method is called Multi-tap typing.

Refer to the table on next page for the list of characters assigned on each key.

List of characters available:

Key	Characters in the Order Displayed				
1	. , - ? ! ' @ : / 1				
2	A	B	C	2	
3	D	E	F	3	
4	G	H	I	4	
5	J	K	L	5	
6	M	N	O	6	
7	P	Q	R	S	7
8	T	U	V	8	
9	W	X	Y	Z	9
0	0				

(Caps Lock mode)

To shift the case of the next letter(s) that you type, press * one or more times. There are three shift states: Lower Case is indicated by abc in the right corner of the display, Initial Capital is Abc, and Capitals Lock is ABC.

The cursor moves to the right when you press a different key. When entering the same letter twice (or a different letter on the same key), just wait for a few seconds for the cursor to move right automatically, and then select the next letter.

If you enter a specific word in this mode the first time, the word is automatically added to your phone's database, and offers the new word as an option for its keystroke sequence when you are in the T9(English) mode.

- Press # to insert a space.
- To move the cursor left or right through your text message, press the navigation key.
- Press **BACK** one or more times to clear letters to the left.

Symbol Mode

Symbol mode enables you enter symbols into a text message.

Press the navigation key to display more symbols up to Set 6.

Press keys corresponding to the desired mark, then the phone automatically switches back to the text entry mode used just prior to selecting the Symbol mode.

Number Mode

Number mode enables you to enter numbers into a text message. Press keys corresponding to the desired digits, and manually switch back to text entry mode of choice.

Using the Menus

The phone offers a range of functions that allows you to tailor the phone to your needs. These functions are arranged in menus and submenus.

The menus and submenus can be accessed by scrolling or by using the shortcuts.

Accessing a Menu Functions by Scrolling

1. In Standby mode, press **MENU** to access the menu facility. Scroll with the navigation key to reach the desired main menu. Press **OK**.
2. If the menu contains any submenu, find the one you want by scrolling with the navigation key. Press the **OK** key to enter the submenu.

If the menu you have selected contains submenus, repeat this step.
3. Scroll with the navigation key to find the setting of your choice. Press the **OK** key to confirm the chosen setting.

Notes:

- You can return the previous menu level by pressing **BACK**.
- You can exit the menu without changing the menu settings by pressing **END**.

Accessing a Menu Functions by Using its Shortcut

The menu items (menu, submenus and setting options) are numbered and can be accessed quickly by using their shortcut number.

1. In Standby mode, press **MENU** to access the main menu.
2. Within three seconds, key in the first digit of the shortcut number. Repeat this for each digit of the shortcut number.
3. Find the setting of your choice pressing the navigation key and then press **OK**

Note: The numbers assigned to each menu function are indicated on the list on the next page.

Your Phone's Main Menu

Main menu	Main menu 1	Main menu 2
1. Call History	1. Missed Calls 2. Outgoing Calls 3. Incoming Calls 4. Erase History	1. Missed Calls 2. Outgoing Calls 3. Incoming Calls 4. All Calls
2. Contacts	1. Find 2. Add New Entry 3. My Phone # 4. Speed Dial # 5. Group setting 6. My Phone # 7. Services	1. Account Info 2. Sprint Customer Care 3. Dir Assist
3. Messaging	1. Send Message 2. Text 3. Picture Mail 4. VoiceSMS 5. Email 6. Instant Message 7. Voicemail 8. Settings	
4. Pictures	1. Camera 2. My Pictures 3. Online Albums 4. Order Print 5. Account Info 6. Cam. Key Guard	
5. Downloads	1. Games 2. Ringers 3. Screen Savers 4. Applications	
6. Web	1. Launch	
7. Voice memo	1. Record 2. Review 3. Erase All	
8. Tools	1. Today 2. Scheduler 3. World Time 4. Alarm Clock 5. Task List 6. Memo Pad 7. Calculator 8. Countdown	

Main menu	Main menu 1	Main menu 2
9. Settings	1. Display	1. Screen Saver 2. Slide Show 3. Menu style 4. Incoming Call 5. Greeting 6. Backlight 7. LCD Contrast 8. Service light
	2. Sounds	1. Ringer Volume 2. Ringer Type 3. Alerts 4. Key Tone 5. Tone Length 6. App. Volume
	3. PCS Vision	1. Enable PCS Vision 2. Net Guard 3. Update PCS Vision Profile
	4. Voice Service	1. Launch VSuit 2. Settings
	5. Security	1. Lock Phone 2. Lock Pictures 3. Change Lock 4. Special # 5. Lock Services 6. Erase 7. Reset Phone 8. Reset Picture Account
	6. Airplane Mode	
	7. Launch Pad	1. Up Key 2. Down Key 3. Left Key 4. Right Key
	8. Others	1. Apprev.Dial 2. Contacts Match 3. Restriction 4. Call Answer 5. Auto Answer 6. Language 7. Roaming 8. Location
	9. Phone Info	1. Phone Number 2. Icon Glossary 3. Version 4. Advanced

Call History

You can use the **Call History** menu to:

- View and dial the missed, outgoing or incoming numbers.
- Erase the numbers in the Call Log memory.

Missed Calls

Menu 1-1

This option lets you view the last 10 calls missed. (if you are subscribed to the caller ID service). When you access this menu, the last missed calls are displayed.

To...	Press ...
Select entry	navigation key
Dial the selected entry	TALK
View the details	OK

When you press **OK**, you can view the date/time stamp for the selected entry. If there is a Phone Book match, the name and the label display.

Press **MENU** to access **Options**. The following options are available:

Talk: dials the selected number.

Show Entry (or **Save** if the phone number is not currently stored in the Phone Book): shows the phone book entry (or stores the number) in the Phone Book.

Prepend: allows to add an area code or feature code to the number before calling the number.

Outgoing Calls

Menu 1-2

The phone stores up to 10 outgoing calls you dialed. When you access this menu, the list of outgoing calls is displayed.

To ...	Press ...
Select an entry	up or down navigation key
Dial the selected entry	TALK
View the details	OK

When you press **OK**, you can view the date/time stamp for the selected entry. If there is a Phone Book match, the name and the label display.

Press **MENU** to access **Options**. The following options are available:

Talk: dials the selected number.

Show Entry (or **Save** if the phone number is not currently stored in the Phone Book): shows the phone book entry or stores the number in the Phone Book.

Prepend: allows to add an area code or feature code to the number before calling the number.

Incoming Calls

Menu 1-3

This option lets you view the last 10 calls received. (if you are subscribed to the caller ID service). When you access this menu, the last incoming calls are displayed.

To...	Press ...
Select entry	up or down navigation key
Dial the selected entry	TALK
View the details	OK

When you press **OK**, you can view the date/time stamp for the selected entry. If there is a Phone Book match, the name and the label display.

Press **MENU** to access **Options**. The following options are available:

Talk: dials the selected number.

Show Entry (or **Save** if the phone number is not currently stored in the Phone Book): shows the phone book entry (or stores the number) in the Phone Book.

Prepend: allows to add an area code or feature code to the number before calling the number.

Erase History

Menu 1-4

You can erase the numbers stored in the Call Log memory.

Missed Calls: The numbers you missed are erased.

Outgoing Calls: The numbers you called are erased.

Incoming Calls: The numbers you received are erased.

All Calls: All calls you dialed and received are erased.

Contacts

The Phone book allows you to store frequently used phone numbers and the associated names in your personal directory to make it easy for you to make a call without having to remember or enter the phone number. You can store up to 500 entries including the voice dial entries.

Find

Menu 2-1

This option allows you to find an entry.

Note: You can access this menu by pressing the up navigation key in Standby mode.

1. Press left or right navigation to scroll to the desired method.

By Name: enter the character(s) you want with the desired Input mode. Then the phone shows the entries containing that character(s).

By Group: Select the group containing the entry you want to find using left or right navigation key. The phone lists all entries in the selected group.

By Entry: enter the location by pressing the numeric keys.

- When the desired entry is highlighted, press **OK** to access the entry.
- The phone shows the details on the name.
Press **TALK** to place a call or press **MENU** to see the following options.

Talk: allows you to place a call.

Edit: allows you to edit phone number, name, location number, label category and so on.

Erase: erases the entry.

When the desired entry is highlighted press **MENU** to access the following options:

Edit: allows you to edit phone number, name, location number, label category and so on.

Erase: erases the number.

Add New: allows you to add a new entry.
Refer to **Add New Entry** menu(2-2) for details.

Add New Entry

Menu 2-2

This menu allows you to store a number with a name in your Phone Book. You can save a person's various numbers, such as workplace number, mobile number and fax number, into one entry. Using this feature, you can keep someone's information together. It also helps you to find numbers easily in the Phone Book.

Creating a New Entry

- Enter a phone number and press **OK**.
- Press **OK** to add a new entry.
- Select the type to save the phone number using navigation key and press **OK**.
- Enter a name and press **OK**.
- Highlight the desired option you want to customize by using the navigation key. The following options are available:

- **Entry:** The first available location displays. If necessary, enter the location number using the number keys.
- **Mobile/Home/Office/Pager/Fax/No label:** Select the label to edit the number.
- **No Label:** To enter the desired name. You can enter up to 12 characters.
- **Speed Dial:** To set the speed dial for the number.
- **E-Mail:** To edit the e-mail address.

- **Group:** To set the group containing the entry.
- **Name Ringer:** Select the unique ring type for the entry. By selecting different tones, incoming voice calls which have caller ID can be distinguished from those that do not.
- **Birthday:** To edit the birthday.
- **Secret:** To set the number in secret, select **On**. This prevents a number from being displayed or dialled when it is accessed by unauthorized user. When you have made the number secret, only a person with your phone's lock code can view the number.
- **Image:** To set the image.

4. Press **MENU** to edit the setting for the selected option.

5. Repeat steps 5 to customize another option.

6. Press **OK** to save the entry.

After storing, the phone displays the phonebook entry number you saved and the remaining entries you can further store phone numbers.

Storing Phone Numbers at Call End

To store a phone number at your call end:

1. Press **END** to end the call. The call time and the phone number display.

2. To store the phone number, press **OK**.

3. To complete storing the number, follow the instructions in "Creating a New Entry."

My Phone

Menu 2-3

This option displays the phone number of the phone being used.

Speed Dial #s

Menu 2-4

Once you have stored phone numbers in contacts, you can dial them quickly. This option allows you to edit the the phone number stored in contacts.

Group Setting

Menu 2-5

This option allows you to edit the name of the group and the ringer type.

1. Scan through the list using navigation key.
2. Press **MENU** to show the options and select one of the options, **Rename/ Ringer**. and then press **OK**.
3. If you select Rename, edit the group name. If you select Ringer, select the ringer type.
4. Press **OK** to save it.

Services

Menu 2-6

Account Info: allows you to call for account information.

Sprint Customer Care: allows you to call Sprint Customer Service.

Dir Assit: allows you to call information.

Messages

Send Message

Menu 3-1

1. Enter the number or e-mail address of the recipient and press **OK**.
2. Enter your message using the keypad. Press the **Option** soft key. A pop-up menu appears in the display. Also use the navigation key to choose the text format, or if you wish to Add Media such as a picture, animation, melody, or a canned message.
4. Once you're finished entering your message, press **OK**.
5. Press the **Send** soft key. Your message is sent to the intended recipient.

Text

Menu 3-2

You can use following options in this menu :

Inbox

New messages are stored in your inbox.

1. Use the navigation key to highlight the message you wish to view.
2. Press **OK** to view the contents of the message.

Outbox

Your phone stores messages in Outbox, regardless of whether the message was successfully transmitted

Drafts

Draft messages are those that have been composed but never sent. You can return to the Draft folder at any time to view, edit, or send a draft message.

Send Message

You can send message from Inbox. For further details, see “Send Message” on page 43.

Picture Mail

Menu 3-3

You can send or receive picture mail in this menu.

VoiceSMS

Menu 3-4

You can send or receive Voice SMS in this menu.

E-mail

Menu 3-5

You can access the e-mail server and read or send e-mail messages.

Instant Message

Menu 3-6

You can send or receive Instant message in this menu.

Voicemail

Menu 3-7

When the voice mail list display, press navigation key to scroll to a voice message and press the **Select** soft key to review the message.

Settings

Menu 3-8

In this menu, you can preset several options for using the messaging feature.

Pictures

Camera

Menu 4-1

In this menu, you can take a picture. The camera produces JPEG pictures.

My Pictures

Menu 4-2

In this menu option, you can review the pictures you have taken.

Online Albums

Menu 4-3

Using this menu option, you can manage the pictures uploaded to the wireless web page assigned to you from the server when you are subscribed to the associated service.

Order Print

Menu 4-4

In this menu option, you can print the pictures you have taken.

Account Info

Menu 4-5

Using this menu option, you can change information about your web page account.

Accessing the **Online Albums** menu option connects your phone to the wireless web. Once you are connected to the web, the setting options displays.

Cam. Key Guard

Menu 4-6

This option allows you to set the phone to lock camera key so that a photo will not be taken, even if the key is pressed by mistake when the phone closed.

Downloads

Games

Menu 5-1

You can download game.

Ringers

Menu 5-2

You can download melody.

Screen Savers

Menu 5-3

You can download image.

Applications

Menu 5-4

You can download application software.

Web

Your phone comes equipped with a web browser which makes it possible for you to access the wireless web.

Launch

Menu 6-1

In standby mode, press the right navigation key. If this is the initial launch of Mobile Web, you're prompted to enable security before proceeding.

Voice Memo

Record

Menu 7-1

You can record up to 30 voice memos in 4 minutes. When recording, a 60-second timer displays and an alert sounds to indicate when recording time expires.

When you speak into the phone to record the voice memo, press **OK** to stop recording.

The record finished screen is displayed with the following choices:

Review: to review the voice memo. The screen displays the length of the recording with the date and time.

Rerecord: to rerecord the voice memo.

Save: to save the voice memo and add a title.

Quit: to quit the voice mem without saving.

You can to enter this menu by pressing the right navigation key in standby mode.

Review

Menu 7-2

When a list of your stored voice memo displays, scroll to the desired entry and press **OK** to play the voice memo.

Erase All

Menu 7-3

This option erases all entries in the Voice Memo list.

Tools

Today

Menu 8-1

You can schedule up to 9 events for the current day indicating each event's start and end time. You can even have your phone's calendar alert you before an event is to start. Events scheduled for future dates automatically appear on your Today events schedule on that day.

Scheduler

Menu 8-2

This option allows you to view in calendar format the current month, or a past or future month. In this option, the current date is highlighted on the calendar. Days with the scheduled events are underlined.

Creating a New Event

Scroll to the desired date in the calendar using the navigation keys and volume keys and then press to confirm the selected date. And schedule a new event referring "Today".

Adding, Editing, or Erasing a Event

When a stored memo is displayed, press **MENU** to access the **Options**.

For further details on Options, refer "Today".

World Time

Menu 8-3

This menu allows you to check the current time for Greenwich Mean Time (GMT) and 24 major cities around the world:

Select the city corresponding to your time zone by pressing the navigation keys one or more times. The local date and time are displayed.

Alarm Clock

Menu 8-4

Your phone has an alarm clock function with three separate alarms. Each alarm can be set to go off once, or daily at a set programmed time. Once you set an alarm, it is easy to change its time or to turn it off.

1. Select the alarm you want to set by pressing the navigation key. Your choices are **Once**, **Daily**, or **Off**.
2. Press the **OK** to select the desired alarm.
3. Follow the prompts to save the alarm setting of choice.
4. Press the **CLR** to return to the previous menu.

Task List

Menu 8-5

This feature allows you to draw up a list of tasks to be done and assign a priority and deadline to each task.

Memo Pad

Menu 8-6

This feature allows you to write down memos. You can enter up to 60 characters for each memo.

If memos are already saved, scroll to the desired item by pressing up or down navigation key.

The following options available when you press **MENU**.

Add new: allows you to add a new memo.

Edit: allows you to edit a saved memo.

Erase: allows you to erase a selected memo.

Erase All: allows you to erase memos.

After you select an option, press **OK**. Then follow the screen prompt.

Calculator

Menu 8-7

Using this feature, you can use the phone as a calculator. The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.

Using the Calculator

1. Enter the first number using the numeric keys.
2. Press the navigation key to set the operator for your calculation until the required arithmetic symbol appears: + (add), - (subtract), x (multiply), / (divide).
3. Enter the second number.
4. To calculate the result, press **OK**.

5. Repeat steps 1 to 4 as many times as required.

Each time you change the operator, the previous calculation is performed and the result is displayed as the top number in the display.

Notes:

- To erase any mistakes and clear the display, press **CLR**.
- Use * to enter a decimal point and # to change the sign of a number to a negative (-).

Countdown

Menu 8-8

This menu help you know how much time it takes you to do something, or how many months, days, hours and minutes until a specific day. You can create up to 20 Count down timers using this menu.

To create a new count down timer;

1. Enter a name for your new Count down item and press **OK**.
2. Enter the date and time that you want to Count down to or from.

Notes: You can enter the years between 1980 and 2099 for dates.

3. Press **OK** to save the item.

If a Count Down timer is already defined when you select the **Countdown** menu option, the defined Count Down timer is displayed.

If there are more than one items defined in the menu, scroll to the desired item by pressing left or right soft key.

The following options are available when you press **MENU**.

Add new: allows you to create a new item.

Edit : allows you to edit the item.

Erase : allows you to delete the item.

Erase All: allows you to erase all items.

After you select an option, press **OK**. Then follow the screen prompt.

Settings

Many different features of your phone can be customized to suit your preferences.

Display

Menu 9-1

Screen saver

You can select an image to be displayed in idle mode.

Slide Show

You can show pictures or images in slide show.

Menu Style

You can select an menu style to be displayed when press **MENU** key.

Incomig Call

To display the picture for all incoming calls. You can select either **With Caller ID** or **No Caller ID**

Greeting

The banner option allows you to edit the greeting displayed on the standby screen. Enter your greeting using the alphanumeric keys.

Backlight

You have several options for setting how the LCD, keypad backlight operates. Remember that backlight use drains your battery faster.

LCD: allows you to set how long the LCD backlight stays on.

Flip up: The backlight comes on when the flip up.

30 seconds: The backlight comes on when you press a key or receive a call and switches off 30 seconds after the last key is pressed.

15 seconds: The backlight comes on when you press a key or receive a call and switches off 15 seconds after the last key is pressed.

8 seconds: The backlight comes on when you press a key or receive a call and switches off 8 seconds after the last key is pressed.

KeyPad: allows you to set how long the keypad backlight stays on.

Off: The backlight remains off.

File up, 30,15, 8 Seconds is same to LCD option.

Pwr Save Mode: allows you to set power save mode for display.

LCD Contrast

This menu allows you to adjust the brightness of the LCD screens.

Service light

This menu allows you to select whether or not the service light on.

Sounds

Menu 9-2

Ringer Volume

This menu option allows you to adjust the ringer volume.

Calls: allows you to adjust the ringer volume for the incoming calls.

Messages: allows you to adjust the ringer volume for the messages.

Alarms: allows you to adjust the ringer volume for the alarms.

Press up or down navigation key to adjust the volume or select the type.

Volume Level: adjust the volume level (the more bars, the louder).

Vibrate: switches the phone to vibration mode. An incoming call vibrates the phone.

1 Beep: sounds a beep.

Off: does not sound the ring.

Ringer Type

This option allows you to set a unique ring for voice calls, messages, data/fax, alarm, and planner. Select a unique ring tone for each status. As you change it, it sounds for a few seconds.

Note: You can download 5 melodies using PC Link.

Voice Calls: allows you to set a unique ring for an incoming voice call.

Messages: allows you to have a distinctive ring for a voice mail, page, text message or browser message.

Schedule: allows you to have a distinctive ring for a planner alarm.

Alerts

Minute Beep: With this menu option set to **ON**, the phone sounds an alert 10 seconds before each elapsed minute to remind you of the length of the current call.

Service : With this menu option set to **ON**, the phone beeps when you exit service area or when you return to a service area.

Connect: You can set your phone to sound the connect tone when your call is connected to the system.

Disconnect: You can set your phone to sound the disconnect tone when your call is disconnected to the system.

Key tone

Using this menu, you can set up the keypad tone that the phone sounds when you press a key.

Tone Length

The tone length setting enables you to select **Short** or **Long** DTMF (dual-tone multi-frequency) tones. When you use a teleservice (such as your bank account) and press the keys to enter numbers into the teleservice, you are sending DTMF tones. The system used by the bank or other service determines if you need short or long DTMF tones. If the service is digital (which most are these days) short DTMF will almost always work. However, some new systems and almost all older (analog) systems require you to use long DTMF tones. Many home answering machines require long DTMF tones.

App. Volume

This menu option allows you to adjust the ringer volume.

Volume Level: adjust the volume level (the more bars, the louder).

Vibrate: switches the phone to vibration mode. An incoming call vibrates the phone.

Silence All: does not sound the ring.

PCS Vision

Menu 9-3

To access detailed instructions on using PCS Vision services, visit www.sprintpcs.com/manage and download your phone's complete User's Guide.

With PCS Vision, you will have access to applications that let you stay in touch with family and friends, have fun, stay informed on the go, and make your phone unique.

Features such as Web access, graphically-enriched games, and sending/receiving digital pictures will be available on select PCS Phones through the Sprint Nationwide PCS Network.

Voice Service

Menu 9-4

Adapt Digits

Allows you to further train digit dialing to better recognize voice.

Reset Digits

Allows you to reset digit dial back to factory default recognition.

Set Active

Talk Only: voice dial activates when you press and hold **TALK**.

Talk and Flip: voice dial activates when the flip up and press and hold **TALK**.

Choice List

Allows you to enable or disable the **Digit Dial**, **Name Dial**, or **Name Lookup**.

Help

You can get the voice help about how to use the Voice Dial feature.

Security

Menu 9-5

Your phone provides many security options, including a user-programmable lock code and call restriction features.

To access the security menu, you must enter a four-digit lock code. The lock code is preset to **0000** at factory.

Lock Phone

When the phone is locked, you cannot operate the phone until you enter the lock code.

The following options are available:

Never: the phone remains unlocked.

On power up: the phone locks automatically at the next time your phone turned on.

Now: the phone locks immediately.

Lock Pictures

When the picture is locked, you cannot enter the camera mode until you enter the lock code.

Change Lock

This feature allows you to change your current lock code to a new one. The lock code is preset to 0000 at factory.

Enter a new, four-digit lock code, then press **OK**.

Special

Your phone provides the option of storing emergency numbers. All emergency numbers can be manually dialed at any time even when your phone is locked or all default priority numbers are depending on your service provider.

To store an emergency number, select a location using a numeric keys or up or down navigation key and enter the desired number. Each priority number can be up to 32 digits long. The number already stored in the location is automatically deleted when you enter the new number.

To make an emergency call in Lock mode, simply enter the emergency number, then press **SEND**.

Erase Contacts

This menu allows you to erase all the numbers in your Contacts and the voice dial.

When a confirmation message displays, press **OK** to clear the memory.

Erase Downloads

This menu allows you to erase all the downloads in the memory.

Erase Pictures

This menu allows you to erase all the pictures in my pictures.

Reset Phone

Resetting the phone erases all of your saved options and returns them to the factory default settings. Your Phone Book, Call Logs, and SMS messages remain.

The phone reboots (turns itself off then on), restores the default settings, and then returns to Standby mode.

Reset Picture Account

Resetting the Account Info erases all of your saved options and returns them to the factory default settings.

Airplane Mode

Menu 9-6

When your phone is in Airplane Mode, it cannot send or receive any calls or access online information. You may still use the phone's other features, such as Games, Memo Pad, Voice Memos, etc. When Airplane Mode is enabled, a message (phone off) is displayed on screen.

Launch Pad

Menu 9-7

The Navigation Keys can be used as shortcut keys. In stanby mode, they allow you to access specific menu directly.

To assign a shortcut to a key.

1. Select the key to be used as a shortcut key by pressing the navigation keys, and then press the OK key.
2. Select the menu to be assigned to the key by pressing the navigation keys.
3. Press the OK key to save the selection.

Others

Menu 9-8

Abbrev. Dial: Sets the abbreviation dialling on or off.

Contacts Match: Contacts Match allows you to enter the last 3-6 digits of a phone number stored in the Contacts and press **TALK** key to dial without having to enter the remaining digits.

Restriction: Allows you to limit the phone from making outgoing calls to only those listed in the phonebook or programmed in special #'s.

Call Answer: Allows you to determine what action will answer

Flip up or TALK: You can answer by flipping up or pressing **TALK**.

Flip up Only: You can answer only when the flip up.

TALK Only: You can answer only when you press **TALK**.

Auto Answer: With this menu option activated, the phone automatically answers calls after predefined time. This option is useful while driving, for instance.

Language: Sets the language of voice prompts, menus and key input.

Select the desired language by pressing the navigation key.

Location: Your PCS Phone is equipped with a Location feature for use in connection with location-based services that may be available in the future.

Phone Info

Menu 9-9

Allows you to view phone number, icon glossary, s/w and h/w version and advanced information.



Health and Safety Information

Exposure to Radio Frequency (RF) Signals

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on the safety standards that were developed by independent scientific organizations through periodic and through evaluation of scientific studies.

The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless phones employs a unit of measurement known as Specific Absorption Rate (SAR). The SAR limit set by the FCC is 1.6W/kg *

*In the U.S. and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID printed in the label on the phone.

For Body Operation

To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 1.5 cm. separation distance between the user's body and the back of the phone, including the antenna. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not

satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. Non compliance with the above conditions may violate FCC RF exposure guidelines.

For more Information concerning exposure to radio frequency signals, see the following websites:

Federal Communications Commission (FCC)
<http://www.fcc.gov>

Cellular Telecommunications Industry Association (CTIA):<http://www.wow-com.com>

U.S. Food and Drug Administration (FDA)
<http://www.fda.gov/cdrh/consumer>

World Health Organization (WHO)
<http://www.who.int/peh-emf/en>

Precautions When Using Batteries

- Never use any charger or battery that is damaged in anyway.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Battery charging time depends on the remaining battery charge, the type of battery and the charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source.
Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.

- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).

- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and – terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Shortcircuiting the terminals may damage the battery or the object causing the short-circuiting.

- Dispose of used batteries in accordance with local regulations. Always recycle. Do not dispose of batteries in a fire.

Road Safety

Your wireless phone gives you the powerful ability to communicate by voice - almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, on that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands free device. If possible, add an additional layer of convenience and safety to your wireless phone with one of the many hands free accessories available today.
3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
5. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.

6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.

7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.

8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies. Remember, it is a free call on your wireless phone!

9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.

10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.

Operating Environment

Remember to follow any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference of danger.

When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. consult the manufacturer to discuss alternatives.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 cm) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent

with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should always keep the phone more than 6 inches (15cm) from their pacemaker when the phone is switched on;
- Should not carry the phone in a breast pocket;
- Should use the ear opposite the pacemaker to minimize the potential for interference.
- If you have any reason to suspect that interference is taking place, switch off your phone immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch off your phone in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch off your phone in any facility where posted notices so require.

Potentially Explosive Atmospheres

Switch off your phone when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch off the phone while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats; chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powders; and any other area where you would normally be advised to turn off your vehicle engine.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions which cannot guarantee connection in all conditions. Therefore, you should never rely solely upon any wireless phone for essential communications (for example, medical emergencies).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.
2. Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
3. Press the <SEND> key.

If certain features are in use (keyguard, restrict calls, etc.), you may first need to turn those features off before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident - do not cut off the call until given permission to do so.

Other Important Safety Information

- Only qualified personnel should service the phone, or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty which may apply to the unit.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch off your phone before boarding an aircraft. The use of wireless phones in aircraft may be dangerous to the operation of the aircraft, and may be illegal.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

Care and Maintenance

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you to fulfill any warranty obligations and allow you to enjoy this product for many years. When using your phone, battery, charger, or any accessory:

- Keep it and all its parts and accessories out of small children's reach.
- Keep it dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use or store it in dusty, dirty areas as its moving parts can be damaged.
- Do not store it in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store it in cold areas. When the phone warms up (to its normal operating temperature), moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake it. Rough handling can break internal circuit boards.

- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean it. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint it. Paint can clog the device's moving parts and prevent proper operation.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications of attachments could damage the phone and may violate regulations governing radio devices.
- If the phone, battery, charger, or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

Acknowledging Special Precautions and the FCC and Industry Canada Notice

Cautions

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **FCC Compliance Information**

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received. Including interference that may cause undesired operation.

Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Appendix A: CERTIFICATION INFORMATION (SAR)

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on safety standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR limit set by the FCC is 1.6 W/kg. SAR Tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

The highest SAR values for this model phone as reported to the FCC are Head: 0.694 W/Kg(CDMA), 1.04 (PCS), 0.896 W/Kg(AMPS), Body-worn: 0.664 W/Kg(CDMA), 0.353 (PCS), 0.815 W/Kg(AMPS).

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID A3LSPHA840.

In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kilogram(W/kg) averaged over one gram of tissue.

The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Appendix B: Guide to Safe and Responsible Wireless Phone Use

Cellular Telecommunications & Internet Association

“Safety is the most important call you will ever make.”

A Guide to Safe and Responsible Wireless Phone Use

TENS OF MILLIONS OF PEOPLE IN THE U.S. TODAY TAKE ADVANTAGE OF THE UNIQUE COMBINATION OF CONVENIENCE, SAFETY AND VALUE DELIVERED BY THE WIRELESS TELEPHONE. QUITE SIMPLY, THE WIRELESS PHONE GIVES PEOPLE THE POWERFUL ABILITY TO COMMUNICATE BY VOICE-ALMOST ANYWHERE, ANYTIME-WITH THE BOSS, WITH A CLIENT, WITH THE KIDS, WITH EMERGENCY PERSONNEL OR EVEN WITH THE POLICE. EACH YEAR, AMERICANS MAKE BILLIONS OF CALLS FROM THEIR WIRELESS PHONES, AND THE NUMBERS ARE RAPIDLY GROWING.

But an important responsibility accompanies those benefits, one that every wireless phone user must uphold. When driving a car, driving is your first responsibility. A wireless phone can be an invaluable tool, but good judgment must be exercised at all times while driving a motor vehicle-whether on the phone or not.

The basic lessons are ones we all learned as teenagers. Driving requires alertness, caution and courtesy. It requires a heavy dose of basic common sense-keep your head up, keep your eyes on the road, check your mirrors frequently and watch out for other drivers. It requires obeying all traffic signs and signals and staying within the speed limit. It means using seatbelts and requiring other passengers to do the same.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

But with wireless phone use, driving safely means a little more. This brochure is a call to wireless phone users everywhere to make safety their first priority when behind the wheel of a car. Wireless telecommunications is keeping us in touch, simplifying our lives, protecting us in emergencies and providing opportunities to help others in need. When it comes to the use of wireless phones, safety is your most important call.

Wireless Phone “Safety Tips”

Below are safety tips to follow while driving and using a wireless phone which should be easy to remember.

1. Get to know your wireless phone and its features such as speed dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most phones offer, including automatic redial and memory. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.
2. When available, use a hands free device. A number of hands free wireless phone accessories are readily available today. Whether you choose an installed mounted device for your wireless phone or a speaker phone accessory, take advantage of these devices if available to you.
3. Position your wireless phone within easy reach. Make sure you place your wireless phone within easy reach and where you can grab it without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.

4. Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.

5. Do not take notes or look up phone numbers while driving. If you are reading an address book or business card, or writing a “to do” list while driving a car, you are not watching where you are going. It’s common sense. Don’t get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.

6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip or attempt to coincide your calls with times you may be stopped at a stop sign, red light or otherwise stationary. But if you need to dial while driving, follow this simple tip-dial only a few numbers, check the road and your mirrors, then continue.

7. Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix-they are distracting and even dangerous when you are behind the wheel of a car. Make people you are talking with aware you are driving and if necessary, suspend conversations which have the potential to divert your attention from the road.

8. Use your wireless phone to call for help. Your wireless phone is one of the greatest tools you can own to protect yourself and your family in dangerous situations with your phone at your side, help is only three numbers away. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident, road hazard or medical emergency. Remember, it is a free call on your wireless phone!

9. Use your wireless phone to help others in emergencies. Your wireless phone provides you a perfect opportunity to be a "Good Samaritan" in your community. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.

10. Call roadside assistance or a special wireless nonemergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call for emergency services. But you still can use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.

Careless, distracted individuals and people driving irresponsibly represent a hazard to everyone on the road.

Since 1984, the Cellular Telecommunications Industry Association and the wireless industry have conducted educational outreach to inform wireless phone users of their responsibilities as safe drivers and good citizens. As we approach a new century, more and more of us will take advantage of the benefits of wireless telephones. And, as we take to the roads, we all have a responsibility to drive safely.

"The wireless industry reminds you to use your phone safely when driving."

Cellular Telecommunications & Internet Association
For more information, please call 1-888-901-SAFE.
For updates: <http://www.wowcom.com/consumer/issues/driving/articles.cfm?ID=85>

Appendix C: Consumer Update on Wireless Phones

U.S. Food and Drug Administration

1. What kinds of phones are the subject of this update?

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called cell, mobile, or PCS phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

2. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level

RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

3. What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

Support needed research into possible biological effects of RF of the type emitted by wireless phones; Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

National Institute for Occupational Safety and Health
Environmental Protection Agency
Federal Communications Commission
Occupational Safety and Health Administration
National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well. FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the primary subject of the safety questions discussed in this document.

4. What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF).

FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

5. What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

6. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

7. Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

8. Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike “hand-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

9. What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that that no interference occurs when a person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

10. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones,

so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures.

However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

11. What research is needed to decide whether RF exposure from wireless phones poses a health risk? A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but

10 or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones.

Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

12. Which other federal agencies have responsibilities related to potential RF health effects?

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations.

FCC RF Safety Program:
<http://www.fcc.gov/oet/rfsafety/>

Environmental Protection Agency (EPA):
<http://www.epa.gov/radiation/>

Occupational Safety and Health Administration's (OSHA):
<http://www.oshaslc.gov/SLTC/radiofrequencyradiation/index.html>

National Institute for Occupational Safety and Health (NIOSH):
<http://www.cdc.gov/niosh/emfpg.html>

World Health Organization (WHO):
<http://www.who.int/peh-emf/>

International Commission on Non-Ionizing Radiation Protection:
<http://www.icnirp.de>

National Radiation Protection Board (UK):
<http://www.nrpb.org.uk>

Updated 4/3/2002: US Food and Drug Administration
<http://www.fda.gov/cellphones>