

SGH-T589W

**P O R T A B L E Q U A D - B A N D
M O B I L E P H O N E**

User Manual

**Please read this manual before operating your
phone, and keep it for future reference.**



Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

©2012 Samsung Electronics Canada, Inc.

SAMSUNG is a registered trademark of Samsung Electronics Co., Ltd. and its related entities.

Nuance[®], VSuite[™], T9[®] Text Input, and the Nuance logo are trademarks or registered trademarks of Nuance Communications, Inc., or its affiliates in the United States and/or other countries.

ACCESS[®] and NetFront[™] are trademarks or registered trademarks of ACCESS Co., Ltd. in Japan and other countries.

The Bluetooth[®] word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

microSD[™] and the microSD logo are Trademarks of the SD Card Association.

Openwave[®] is a registered Trademark of Openwave, Inc.

Google, the Google logo, Android, the Android logo, Android Market, Gmail, Google Mail, Google Maps, Google Talk, Picasa, and YouTube are trademarks of Google Inc.

Wi-Fi is a registered trademark of the Wireless Fidelity Alliance, Inc.

Swype and the Swype logos are trademarks of Swype, Inc. © 2010 Swype, Inc. All rights reserved.

Open Source Software

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:

<http://opensource.samsung.com>.

Dynamic Noise Suppression from Audience

Your phone is equipped with an advanced voice processing chip that delivers clear mobile calls by suppressing background noise, intermittent sounds (like a siren or nearby conversation), and echoes, allowing you to hear and be heard nearly anywhere.

How Does It Work?

Based on the intelligence of the human hearing system, the technology:

- Captures, evaluates and distinguishes all the sound signals surrounding your phone, and the person you're speaking with.
- Then isolates the primary voice in conversation and filters out the background noise - so the person you're calling hears only your voice, without disturbing background noise.
- Dynamically equalizes and adjusts voice volume to optimize your calling experience, so you can hear clearly and don't need to speak louder to overcome surrounding noise.

The noise suppression technology is built-in and already enabled in your new mobile phone. So it's ready to provide unsurpassed voice clarity with every call.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Table of Contents

Section 1: Getting Started 1

Understanding this User Manual	1
Battery Cover	2
Battery	5
Accessing the QWERTY Keyboard	7
Extending Your Battery Life	8
Power Control	8
Switching the Phone On or Off	9
Locking and Unlocking the Phone	9
Creating a New Google Account	10
Signing into Your Google Account	11
Retrieving your Google Account Password	11
Voice Mail	11
Task Manager	12

Section 2: Understanding Your Phone 14

Features of Your Phone	14
Front View	15
Back View of Your Phone	17
Phone Display	17
Status Bar	18
Function Keys	22
Home Screen	24
Screen Navigation	26
Menu Navigation	28

Applications	29
Customizing the Screens	34

Section 3: Memory Card 38

Using the SD Card	38
-------------------------	----

Section 4: Call Functions 41

Displaying Your Phone Number	41
Making a Call	41
Ending a Call	41
Answering a Call	42
Dialing Options	42
Speed Dialing	44
In Call Options	46
Call Log Tab	50

Section 5: Entering Text 54

Text Input Methods	54
Selecting the Text Input Method	54
Using the Samsung Keypad	55
Configuring Samsung Keypad Settings	57
Using the Swype Keyboard	58
Entering Text Using the QWERTY Keyboard	62

Section 6: Contacts 65

Contacts List	65
Finding a Contact	67
Contact List Options	69

Contact Menu Options	70
Contact Entry Options	70
Joining Contact Information	71
Sending a Namecard	73
Copying Contact Information	74
Synchronizing Contacts	74
Display Options	75
Get Friends	76
My Profile	77
Additional Contact Options	77
Groups	78
The History Tab	79
The Updates Tab	80
Section 7: Messages	81
Types of Messages	81
Creating and Sending Messages	81
Messaging Key	82
Message Options	82
Viewing Newly Received Messages	83
Deleting Messages	85
Message Search	85
Messaging Settings	85
Email	86
Microsoft Exchange Email (Outlook)	88
Using Gmail	91
Google Talk	93
Messenger	93

Section 8: Multimedia	94
Using the Camera	94
Camera and Camcorder Options	95
Using the Camcorder	99
Files	101
The Gallery	102
Music	102
Using Playlists	104
Creating a Playlist	104
Transferring Music Files	105
Removing Music Files	105
YouTube	105
Section 9: Applications	106
Applications	106
Calculator	106
Calendar	106
Camera	107
Clock	107
Contacts	107
Downloads	108
Email	108
Files	108
Gallery	108
Gmail	108
Google+	109
Google Search	109
Internet	109

Latitude	109
Maps	110
Memo	112
Messenger	113
Music	113
Navigation	113
News & Weather	115
Places	115
Play Books	115
Play Store	116
Samsung Apps	117
Settings	118
Talk	118
Task Manager	118
Voice Recorder	119
Voice Search	119
YouTube	119
Section 10: Connections	121
Internet	121
Bluetooth	126
Enable Downloading for Internet Applications	129
PC Connections	129
Wi-Fi	130
Mobile AP	132
Section 11: Time Management	134
Calendar	134
Clock	135

Section 12: Changing Your Settings	137
Wireless and networks	137
Call Settings	142
Sound Settings	144
Display Settings	145
Messaging Key	146
Location and Security	146
Screen Unlock Pattern Settings	146
Applications	149
Android Development	151
Accounts and Synchronization	151
Privacy Settings	153
SD Card & Phone Storage	154
Search Settings	154
Locale and Text Settings	155
Accessibility Settings	158
Date and Time	158
About Phone	159
Index	161

Section 1: Getting Started

This section explains how to get started with your phone by installing and charging the battery, installing the SIM card and optional memory card, and setting up your voice mail.

Before using your phone for the first time, you'll need to install and charge the battery and install the SIM card. The SIM card is loaded with your subscription details, such as your PIN, available optional services, and many other features. If desired, you can also install an SD card to store media for use with your phone.

Understanding this User Manual

The sections of this manual generally follow the features of your phone. A robust index for features begins on page 161.

This manual provides navigation instructions according to the default display settings. If you select other settings, navigation may be different.

Unless otherwise specified, all instructions in this manual assume you are starting from the Home screen and using the available keys.

Note: Instructions in this manual are based on default settings, and may vary from your phone, depending on the software version on your phone, and any changes to the phone's Settings.

Unless stated otherwise, instructions in this User Manual start with the phone unlocked, at the Home screen.

All screen images in this manual are simulated. Actual displays may vary, depending on the software version of your phone and any changes to the phone's Settings.

Special Text

Throughout this manual, you'll find text that is set apart from the rest. These are intended to point out important information, share quick methods for activating features, to define terms, and more. The definitions for these methods are as follows:

- **Notes:** Presents alternative options for the current feature, menu, or sub-menu.
- **Tips:** Provides quick or innovative methods, or useful shortcuts.
- **Important:** Points out important information about the current feature that could affect performance.
- **Warning:** Brings to your attention important information to prevent loss of data or functionality, or even prevent damage to your phone.

Text Conventions

This manual provides condensed information about how to use your phone. To make this possible, the following text conventions are used to represent often-used steps:

- Arrows are used to represent the sequence of selecting successive options in longer, or repetitive, procedures.

Example: From the Home screen, press  (Menu) → Settings → Wireless and networks → Bluetooth settings.


Battery Cover

The battery, SIM card and SD card are installed under the battery cover.

Important! Before removing or replacing the battery cover, make sure the phone is switched off. To turn the phone off, hold down the  key until the power-off image displays, then tap **Power off**.

To remove the battery cover:

1. Hold the device firmly and locate the cover release latch.
2. Place your fingernail in the opening and firmly “pop” the cover off the device.



To replace the battery cover:

1. Position the battery cover over the battery compartment and press down until you hear a click.
2. Press down along the edges of the cover to verify it is secured.

SIM Card Overview

Important: Before removing or replacing the battery cover, make sure the phone is switched off. To turn the phone off, hold down the  key until the power-off image displays, then tap **Power off**.


The SIM card is loaded with your subscription details such as your telephone number, PIN, available optional services, and many other features.

Important: The SIM card and its information can be easily damaged by scratching or bending, so be careful when handling, inserting, or removing the card. Keep all SIM cards out of reach of small children.

Installing and Removing the SIM card

To install the SIM card:

1. Confirm the battery is not currently installed within the battery compartment. The battery blocks the proper installation of the SIM card into the slot.



- Carefully slide the SIM card into the SIM card socket until the card is secured into place. Make sure that the card's gold contacts face down and that the upper-left angled corner of the card is positioned as shown.

To remove the SIM card:

- If installed, remove the battery from its compartment (1). The battery will block the proper removal of the SIM card from the slot.
- Carefully slide the SIM card out of the SIM card socket (2).

Note: If the card is not inserted correctly, the phone will not detect it and no service will be available. If this happens, turn off the phone, remove the card, and reinstall the card in the correct orientation.

Installing the microSD Memory Card

Your phone accepts an optional microSD™ or microSDHC™ memory card for storage of media such as music, pictures, video and other files.

Note: microSD memory cards include capacities of up to 2GB; microSDHC™ memory cards range from 4GB to 16GB.

Note: This device supports up to a 16GB microSDHC memory card.

- Remove the battery cover.
- Orient the card with the gold contacts facing down.



- Firmly press the card into the slot until it locks into place. For more information on how to use the SD card see "Using the SD Card" on page 38.

Important! Be sure to align the gold contact pins on the card with the phone's contacts.

Removing the microSD Memory Card

1. Remove the battery cover.
2. Firmly press the card into the slot and release it. The card should pop partially out of the slot.
3. Remove the card from the slot.



Battery

Before its initial use, install the battery and charge it fully.

Important! Before removing or replacing the battery cover, make sure the phone is switched off. To turn the phone off, hold down the  key until the power-off image displays, then tap **Power off**.

Installing the Battery

1. Slide the battery into the compartment (1) so that the tabs on the end align with the slots at the bottom of the phone, making sure the connectors align.
2. Gently press down to secure the battery (2).



Removing the Battery

1. Place your finger into the battery groove (1).
2. Grip the battery at the top end (2) and lift it up and out of the battery compartment (3).

Charging the Battery


Your phone is powered by a rechargeable Li-ion battery. A wall charger, which is used for charging the battery, is included with your phone. Use only approved batteries and chargers. Ask your local Samsung dealer for further details. Before using your phone for the first time, you must fully charge the battery. A discharged battery recharges fully in approximately 4 hours.

Note: Verify that the battery is installed prior to connecting the wall charger. If the wall charger is connected and the battery is not installed, the handset will power cycle continuously and prevent proper operation. Failure to unplug the wall charger before you remove the battery can damage the phone.

Important! Although the battery comes partially charged, it is recommended that you fully charge the battery before its initial use.

1. Slide open the Charger/Accessory jack cover (1).
2. Insert the USB cable into the device's Charger/Accessory jack.

3. Plug the charger into a standard AC power outlet. The device turns on with the screen locked and indicates both its charge state and percent of charge.



Note: This illustration displays both the **correct** and **incorrect** orientation for connecting the charger. If the charger is incorrectly connected, damage to the accessory port will occur, voiding the phone's warranty.

4. When charging is finished, first unplug the charger's power plug from the AC wall outlet, then disconnect the charger's connector from the phone.

Important! The touch screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch screen may damage the tempered glass surface and void the warranty.

Low Battery Indicator

When the battery level is low and only a few minutes of talk time remain, a warning tone sounds and the "Low battery" message repeats at regular intervals on the display. In this condition, your phone conserves its remaining battery power, by dimming the backlight. When the battery level becomes too low, the phone automatically turns off.

Note: Some applications which serve the purpose of showing battery life may not display an accurate battery percentage.

Accessing the QWERTY Keyboard

Your phone has a full, slide-out QWERTY keyboard. The keyboard is located beneath the display screen and is accessed by sliding it open. This orients the phone's display to Landscape (widescreen) mode. With the QWERTY keyboard, you can easily type letters,

numbers, punctuation, and other special characters into text entry fields and other applications.

1. Rotate the phone 90 degrees counter-clockwise.
2. Slide the top section of the phone up to open, as shown in the illustration. When you slide it open, the display rotates from a vertical viewing mode (Portrait) to a horizontal viewing mode (Landscape).



Extending Your Battery Life

Active applications, light levels, Bluetooth usage, and GPS functionality all act to drain your battery. The following is a list of helpful tips that can help conserve your battery power:

- Use the Power Control shortcut bar.
- Reduce your backlight on time.
- Turn Bluetooth off when not in use.
- Turn Wi-Fi off when not in use.
- Deactivate the GPS when not needed. Most applications using this function will periodically query the GPS satellites for your current location; each query drains your battery.
- Do not wait until your battery is completely depleted before charging your device. Repeating this process of a complete discharge and recharge can over time reduce the storage capacity of any battery.
- Turn off Automatic application sync.
- Use the Power Control Widget to deactivate hardware functions such as Wi-Fi, Bluetooth, GPS, Synchronization, or LCD brightness setting.
- Check the Battery use screen to review what features or functions have been consuming your battery resources.
- Check the Running Services and close any unnecessary applications.
- Use the Task Manager feature to end/shutdown background applications that are still running. These minimized applications can, over time, cause your device to “slow down”.

- Animated wallpapers use processing power, memory, and more power. Change your Live Wallpaper to a non-animated Wallpaper gallery or Gallery image.

Power Control

Active applications, Wi-Fi, Bluetooth, GPS, Synchronization, Location consent, and the LCD Brightness functionality all act to drain your battery.

The Power Control shortcut bar allows you to quickly activate (turn on), or deactivate (turn off) those functions or applications that use the most battery power.

1. From the Home screen, touch and hold an empty area until the **Add to Home screen** menu displays.
2. Tap **Widgets** → **Power control**. The Power Control shortcut is added to the current screen.
3. Tap any of the icons on the Power Control shortcut bar to activate/deactivate the feature.



Note: A green bar displayed beneath the icon means the application is active (turned on). The green bar is removed from beneath the icon when the feature is deactivated (turned off).

Switching the Phone On or Off

If you do not have a SIM card installed the first time you turn on the device, the **Insert SIM card to make calls** message displays and an animated tutorial shows you how to install the SIM card.

At this point you can make an emergency call with the phone but normal cell phone service is not available.

Dialing Options Without a SIM card installed

1. Press  and then tap .
2. Enter the phone number to dial then press .
3. If you enter a non-emergency number, you are notified there is no network available.
– or –

If you enter an emergency number, your call is passed along to emergency services.

Dialing Options With a SIM card installed

1. Press and hold  until the phone switches on.
The phone searches for your network and after finding it, you can make or receive calls.
2. Press  and then tap .
3. Enter the phone number to dial then press .

Note: The display language is preset to English at the factory. To change the language, use the Language menu. For more information, refer to “*Locale and Text Settings*” on page 155.

Locking and Unlocking the Phone

By default, the phone screen locks when the backlight turns off.

- ▶ To display the lock screen when the display is turned off, press  or .

To unlock your phone from this lock screen:

- ▶ Touch and drag anywhere on the screen.

– or –

Slide the QWERTY keyboard out.



Creating a New Google Account

You should create a Google™ Account when you first use your device in order to fully utilize the functionality. This account provides access to several device features such as Gmail, Google Maps, Google Search, and the Android Market applications. Before you are able to access Google applications, you must enter your account information. These applications sync between your device and your online Google account.

To create a new Google Account from your phone:

1. From the Home screen, tap  (Settings) → Accounts and Sync → Add account → Google.
2. Read the introduction and tap **Next** → **Create** to begin.
3. Follow the on-screen instructions to create a Google Account.

Note: If you already have a Google account, you only need to sign in.

Note: You can choose to configure lock settings to prevent unauthorized use of your phone. For more information, refer to “Setting up SIM Card Lock” on page 148.

To create a new Google Account from the Web:

1. From a computer, launch a Web browser and navigate to www.google.com.
2. On the main page, click **Sign-in** → **Create an account now**.
3. Follow the on-screen prompts to create your free account.
4. Look for an email from Google in the email box you provided, and respond to the email to confirm and activate your new account.

Signing into Your Google Account

1. Launch an application that requires a Google account (such as Play Store or Gmail).
2. Click **Next** → **Sign in**.
3. Tap the **Username** and **Password** fields and enter your information.
4. Tap **Sign in**. Your device communicates with the Google servers to confirm your information.
5. If prompted, create a new Gmail username by entering a prefix for your **@gmail.com** email address.

Retrieving your Google Account Password

A Google account password is required for Google applications. If you misplace or forget your Google Account password, use an Internet browser to navigate to <http://google.com/accounts> and follow the onscreen instructions to retrieve it:

Voice Mail

Setting Up Your Voice Mail

Your device automatically transfers all unanswered calls to voicemail, even if your device is in use or turned off. As soon as your battery is charged and the SIM card inserted, activate your voicemail account.

Important! Always use a password to protect against unauthorized access.

For new users, follow the instructions below to set up voice mail:

Note: Voicemail setup may be different depending on your network.

1. From the Home screen, tap  and then touch and hold the  key until the phone dials voice mail.
You may be prompted to enter a password.
2. Follow the tutorial to create a password, a greeting, and a display name.

Accessing Your Voice Mail

To access your Voice Mail:

1. From the Home screen, tap  and then touch  or touch and hold  until the phone dials voice mail.
2. When connected, follow the voice prompts from the voice mail center.

Accessing Your Voice Mail From Another Phone

1. Dial your wireless phone number.
2. When you hear your voicemail greeting, press the asterisk on the phone you are using.
3. Enter your passcode.

Task Manager

Your phone can run applications simultaneously, with some applications running in the background.

Sometimes your device might seem to slow down over time, and the biggest reason for this is background applications. These are applications that have not been closed or shutdown and are still active but minimized. The Task Manager not only lets you see which of these applications are still active in the background but also easily lets you choose which applications are left running and which are closed.

Note: The greater the number of applications running on your phone, the greater the energy drain on your battery.

Task Manager Overview

- ▶ From the Home screen, tap  (Applications) → Task Manager ().

– or –

Press and hold  (Home) then tap **Task manager**. This screen contains the following tabs:

- **Active applications** display those currently active applications running on your phone.

- **Downloaded** displays any installed applications that are taking up memory space. Tap **Uninstall** to remove them from your phone.
- **RAM**, which displays the amount of RAM (Random Access Memory) currently being used and allows you to **Clear memory**.
- **Storage** displays a visual graph indicating the available and used space within the Random Access Memory (RAM), Program, and External SD card.
- **Help** provides additional battery saving techniques.

Shutting Down a Currently Active Application

1. From the Home screen, tap  → **Task Manager** ().
2. From the **Active applications** tab, tap **Exit** to close selected applications or tap **Exit all** to close all background running applications.

Section 2: Understanding Your Phone

This section outlines key features of your phone. It also describes the phone's keys, screen and the icons that display when the phone is in use.


Features of Your Phone

Your phone is lightweight, easy-to-use and offers many significant features. The following list outlines a few of the features included in your phone.

- Touch screen with virtual (on-screen) QWERTY keyboard
- 4-row QWERTY keyboard
- Android 2.3, Gingerbread
- Supports social networking applications such as Facebook[®], Twitter[®] and MySpace[®]
- Support for photo management applications such as Picasa[®]
- Compatible with Adobe[®] Flash[®]
- Wi-Fi[®] capability
- USB tethering-capable
- Bluetooth enabled
- Full integration with Google applications (Gmail, YouTube, Google Maps)
- Multiple messaging options: Email, Instant Messaging, Picture Messaging, Google Talk, Google Search, Text Messaging
- Supports synchronizing with a corporate email account
- 3.0 Megapixel camera and video recorder with autofocus, multi shot, and digital zoom
- Pre-loaded games
- MP3 player with multitasking features
- Assisted GPS
- Full HTML browser
- Downloadable applications from Google Play (formerly Android Market)
- Up to 32GB expandable memory slot
- Mobile Hotspot capability

Front View

The following illustrations show the main elements of your phone:




The following list correlates to the illustrations.

1. **Receiver** allows you to hear a caller and the different ring tones or sounds offered by your phone.
2. **Strap holder** is used to connect a carrying strap to the phone.
3. **Volume key** allows you to adjust the ringer volume in standby mode or adjust the voice volume during a call. When receiving an incoming call:
 - Pressing the volume key down mutes the ring tone.
 - Pressing and holding the volume key rejects the call.
4. **microSD card slot** allows you use a microSD card to expand the memory of your phone.
5. **Menu key** displays a list of options available for the current screen. From the Home screen it displays Add, Wallpaper, Search, Notifications, Edit, and Settings options.
6. **Home key** displays the Home screen when pressed. View recently used apps and access Task manager by holding down the key.

7. **Microphone** is used during phone calls and allows other callers to hear you clearly when you are speaking to them. It is also used to make voice note recordings.
8. **Quick search** is used to search the device for applications or contact information, or searches the internet for information.
9. **Back key** redisplay the previous screen or clears entries.
10. **Display** shows all the information needed to operate your phone, such as the connection status, received signal strength, phone battery level, and time.
11. **Power/End key** ends a call or switches the phone off and on. Press and hold for two seconds to turn off Silent, initiate Flight mode, or to turn the phone on or off.
12. **USB Power/Accessory connector** allows you to connect a power cable or optional accessories such as a USB/data cable.
13. **Light sensor** lets you use the ambient light level to adjust the screen brightness/contrast.
 - In a bright light condition (outdoors), the sensors cause the device to increase the brightness and contrast for better viewing.
- In dim light conditions, the device reduces the screen brightness to compensate.
14. **Headset jack** allows you to connect a hands-free headset so you can listen to music.
15. **Proximity sensor** detects how close an object is to the surface of the screen. This is typically used to detect when your face is close to the screen, such as during a phone call.
 - While talking on the phone, the sensor detects talk activity and locks the keypad to prevent accidental key presses.

Back View of Your Phone

The following illustration shows the rear elements of your phone:



1. **Camera lens** is used to take photos.
2. **Flash** provides an additional light source for pictures and videos during low-light conditions.
3. **External speaker** allows you to hear ringers, music, and other sounds provided by your phone.

Phone Display

Your phone's display provides information about the phone's status, and is the interface to the features of your phone. The display indicates your connection status, signal strength, battery status and time. Icons display at the top of the phone when an incoming call or message is received and also alerts you at a specified time when an alarm was set. The screen also displays notifications, and an Application (or shortcut) bar with four icons: Phone, Contacts, Messaging, and Applications.



Display settings

In this menu, you can change various settings for the for the wallpaper, cube, brightness or backlight.

- ▶ From the Home screen, tap  (Applications) →  (Settings) → Display. For more information, refer to “Display Settings” on page 145.

Status Bar

The Status Bar shows information about the connection status, signal strength, phone battery level, and time, and displays notifications about incoming messages and calls and other actions.

The following list identifies the icons you see on your phone's display screen:

Indicator Icons

This list identifies the symbols you'll see on your phone's display and Indicator area:

	Displays your current signal strength. The greater the number of bars, the stronger the signal.
	Indicates that Flight Mode is active. You cannot send or receive any calls or access online information.



Indicates there is no signal available.



Displays when there is no SIM card in the phone.



Displays when there is a system error or alert.



Displays when there is an active call.



Displays when an active call has been muted.



Displays when a call is on hold.



Displays when you have missed an incoming call.



Displays when the speakerphone is on.



Displays when Call forwarding is set to Always forward. For more information, refer to “Configuring Call Forwarding” on page 143.

	Displays your battery charge level. Icon shown is fully charged.
	Displays when your battery is charging.
	Device Power Critical – Shows your current battery only has three percent power remaining and will immediately shutdown.
	Displays when your connection to an EDGE network is active.
	Displays when your phone is communicating with an EDGE network.
	Displays when your connection to a 3G network is active.
	Displays when your phone is communicating with a 3G network.
	Displays when the phone is connected to a computer using a supported USB cable connection.
	Displays when a new text or multimedia message is received.

	Displays when Email is received.
	Displays when a new voice mail is received.
	Displays in the notifications window when there is a new Email message.
	Displays when an alarm is set. For more information, refer to “ <i>Setting an Alarm</i> ” on page 135.
	Displays when the date for a Calendar Event has arrived.
	Roaming (outside of normal service area)
	Displays when the Sound profile is set to Silent mode and Vibrate is set to Never or Only when not in silent mode.
	Displays when the Sound profile is set to Silent mode and Vibrate is set to Always or Only in silent mode.

	Displays when Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP).
	Displays when Wi-Fi is active but there is a communication issue with the target Wireless Access Point (WAP).
	Bluetooth activated.
	Bluetooth headset connected.



Displays when the Mobile AP Hotspot feature is active and communicating. For more information, refer to “*Mobile AP*” on page 132.



Displays when the USB Tethering feature is active and communicating. For more information, refer to “*Tethering*” on page 139.



Displays when GPS is active and acquiring a signal.



Displays when the SD card has been unmounted.




Displays when there is a system error or alert.

For more details on configuring your phone's settings, see “*Changing Your Settings*” on page 137

Notification Bar

The Notification area indicates new message events (data sync status, new messages, calendar events, call status, etc). You can expand this area to provide more detailed information about the current on-screen notification icons.

1. Tap and hold the Status bar to reveal the Notifications tab, and then drag the tab to the bottom of the screen to open the Notifications panel (1).
2. Tap a notification entry to open the associated application (2).



Note: The Notifications panel can also be opened on the Home screen by pressing  and then tapping **Notifications**.


Clearing Notifications

To clear all notifications from the Notification panel:

1. Tap the status bar to reveal the Notifications tab, and then drag the tab to the bottom of the screen to open the Notifications panel
2. Tap **Clear**. The notifications are cleared from the panel.

Accessing Additional Panel Functions

In addition to notifications, this panel also provides quick and ready access to five device functions. These can be quickly activated or deactivated.



The following functions can either be activated (green) or deactivated (white): **Wi-Fi**, **Bluetooth**, **GPS**, **Sound**, or **Auto rotation**.

Function Keys

Your phone comes equipped with four main function keys that can be used from any screen: **Menu**, **Home**, **Back**, and **Search**.

Menu Key

The **Menu** key () activates an available menu function for the current screen or application. When on the Home screen, the following menu options are available:

- **Add** () lets you add one of the following functions to a selected screen: Widgets, Shortcuts, Folders or Wallpapers.
- **Wallpaper** () lets you to customize the current screen's wallpaper image by choosing from either Gallery, Live wallpapers or Wallpaper gallery).
- **Search** () displays the Google Search box that you can use to search for a key term both on the phone and online.
- **Notifications** () expands the popup notifications area to provide more detailed information about the current on-screen notification icons.

- **Edit** () allows you to add or remove extended screens from your device. You can have up to eight extended screens.
- **Settings** () provides quick access to the device's settings menu.
 - The Settings menu can also be accessed by pressing  (**Home**) and then tapping  → **Settings**.

Home Key

The **Home** key () takes you back to the last viewed Home screen.

- ▶ Press and hold to launch the Task Manager. For more information, refer to “*Accessing Recently-Used Applications*” on page 29.

Back Key

The **Back** key () returns you to the previously active screen. If the on-screen keyboard is currently open, this key closes the keyboard.

Search Key

The **Search** key () displays the Google Search box that can be used to search for either a key term both on the phone and online. In some instances, this key opens a search box specific only to the current application.



Using Google Search

Use the Google Search box to manually search for a term on both your device and on the Web.

1. Press  to launch the Google Search box.
– or –
From the main home screen tap the Google Search bar.
2. Enter a search term and tap a match from the list of suggestions, phone search results, or previously chosen search matches. Once touched, the item opens in the appropriate application.
– or –

Tap () to use Google Voice Search. For more information, refer to “Voice Search” on page 119.

Using Additional Voice Search Functions

Voice actions (such as: [your query]) allow you to perform various phone functions by speaking the parameters. For more information, refer to:

<http://www.google.com/mobile/voice-actions/>.


From an open Voice Search dialog, speak the following words to access additional features:

- **listen to [artist/song/album]** plays the selected song.
- **send text to [recipient] [message]** opens the Messaging screen.
- **navigate to [address/city/business name]** provides directions via Google Maps™. Use either an Address name, Business name, business type, or other navigation information to get the desired directions.
- **call [name]** opens the phone and automatically dials the contact.
- **send email to [recipient] [subject]** opens your email account ready to compose a new email message to the recipient.
- **map of [location]** provides a map of an area via Google maps. Use either an Address name, Business name, zip code, or other navigation information.
- **go to [website]** opens the browser and navigates to the chosen website.
- **note to self [message]** allows you to save a note to your Memo Pad.

- **directions to [location]** provides directions from your current location to a selected destination.

Home Screen

The Home screen is the starting point for using the applications on your phone. There are seven panels available, some populated with default shortcuts or applications. You can customize each of these panels.



- **Notification area** displays icons associated with end-user notifications, such as: new email, calls (missed, call in progress), new voicemail, upcoming event, USB connection, and new Text/MMS messages.
 - These notifications appear at the top-left of the screen (within the Status bar area) and display important user information.
 - More information can be accessed by either swiping down from the Status bar (page 21) or by accessing the Notifications panel [ > **Notifications** ()].
- **Status area** displays icons associated with the status of the device, such as communication, coverage, Bluetooth, 3G and Wi-Fi communication, battery levels, GPS, etc.
- **Home Screen** is a customizable screen that provides information about notifications and device status, and allows access to application Widgets.
- **Extended Home Screens** extend beyond the current visible screen width to provide more space for adding icons, widgets, and other customization features.
 - The default is five screens with Home occupying the third screen.
 - The maximum number of screens is seven.
 - All screens share the use of the four Primary Shortcuts.
 - The current screen is indicated at the top by a number in a circle.

Note: Both the status bar and primary shortcuts are visible across all screens.

- **Google search** is an on-screen Internet search engine powered by Google™. Enter a search term or access the Voice Search feature where you can verbally enter a search term and initiate an online search.
- **Widgets** are self-contained on-screen applications (not shortcuts). These can be placed onto any of the available screens (Home or extended).
- **Shortcuts** are icons that launch available device applications such as Camera, YouTube, Voicemail, Contacts, Phone, Email, Market, etc. Shortcuts can be removed from a screen and added to a screen any number of times (see “Customizing the Screens” on page 34).
- **Primary Shortcuts:** are four shortcuts present throughout all of the available screens that can be used to launch the following functions:
 - **Phone** () accesses phone-related functions (Keypad, Call Log, Favorites, and Contacts).
 - **Contacts** () accesses the Contacts-related functions (Contacts, Groups, History, and Updates).
 - **Messaging** () launches the Messaging menu (create new messages or open an existing message string).
 - **Applications/Home** toggles opening of the Home and Application screens.
 - Tap  (**Applications**) to access the Application screens that allow access to every available local application.

- While in the Applications screens, tap the **Home** icon () to return to the Home screen.

As you transition between home screens, the screen counter (located at the top) displays the current panel number in a circle.



Screen Navigation

Using the touch screen display and the keys, you can navigate the features of your phone and enter characters. The following conventions are used in this manual to describe the navigation action in the procedures.

Navigating Through the Screens

The following terms describe the most common hardware and on-screen actions.

Press and hold



Tap



Touch and hold



- **Press and hold:** Pressing relates to use of the hardware keys and buttons to select or activate an item. Some buttons and keys require you to press and hold them to perform a function, for example, you press and hold the Lock key to turn the phone on and off.
- **Tap:** Use a brief touch to select items on the display or to enter text on the virtual QWERTY keyboard. For example: touch an Application icon to open the application. A light touch works best.
- **Touch and hold:** Touch and hold an icon or key to open the available options, or to access a pop-up menu. For example: press and hold the Home screen to access a menu of customization options.
- **Drag:** Press your finger on the screen and move it vertically or horizontally across the screen. Do not release your finger until you have reached the target position.
- **Swipe or slide:** Quickly drag your finger vertically or horizontally across the screen. This allows you to move the area of focus or to scroll through a list. For example: slide your finger left or right on the Home screen to scroll among the seven panels.
- **Flick:** Move your finger in lighter, quicker strokes than swiping. This finger gesture is always used in a vertical motion, such as when flicking through contacts or a message list.



Flick

Swipe or slide
and Drag

Rotate

- **Rotate:** Automatically change the screen orientation from portrait to landscape by turning the device sideways. For example: rotate to landscape orientation when entering text, to provide a larger keyboard, or when viewing web content to minimize scrolling.

- **Pinch:** Place your thumb and forefinger on the screen and “pinch” the screen (move fingers together) to zoom out when viewing a picture or a Web page.
- **Spread:** Place your thumb and forefinger on the screen and “spread” them apart to zoom in when viewing a picture or a Web page.

Pinch (Zoom Out)



Spread (Zoom In)



Menu Navigation

You can tailor the phone's range of functions to fit your needs using both menus and applications. Menus, sub-menus, and features are accessed by scrolling through the available on-screen menus.

Navigating Through the Application Menus


There are four default Application Menus available. As you add more applications from the Android Marketplace, more screens are created to house these new apps.

1. Press  and then tap  (Applications). The first Application Menu displays.
 - To close the Applications screen, tap  or press .
2. Sweep the screen to access the other menus.
3. Tap any of the on-screen icons to launch the associated application.

Using Sub-Menus

Sub-menus are available from within most screens and applications.

1. Press . A sub-menu displays at the bottom of the phone screen.
2. Tap an option.




Sub-Menu items

Using Context Menus

Context menus (also called pop-up menus) contain options that apply to a specific item on the screen. They function similarly to menu options that appear when you right click the mouse on a desktop computer.

- ▶ Touch and hold an item on-screen to open its context menu.



Accessing Recently-Used Applications

1. Press and hold  to open the recently-used applications window.

Note: This recent applications screen also provides access to the **Task manager**.

2. A pop-up displays the six most recently used applications.
3. Tap an icon to open the recent application.

Applications

The Application menu provides quick access to all applications. Applications display on each of the three panels on the Applications screens.

The following table contains a description of applications available via both the Primary shortcuts area and via the Applications screens. If the application is already described in another section of this user manual, then a cross reference to that particular section is provided. For information on navigating through the Applications icons, see “*Navigating Through the Application Menus*” on page 28.

Note: Depending on your service provider, your phone may include additional applications not described in this list.



Calculator

Launches the on-screen calculator application. The calculator provides the basic arithmetic functions; addition, subtraction, multiplication, and division. You can also use this as a scientific calculator.

For more information, refer to “*Calculator*” on page 106.



Calendar

Launches a calendar application that syncs to your Facebook™, Google™, or Microsoft Exchange work calendars.

For more information, refer to “*Calendar*” on page 134.



Camera

Launches the built-in 3.0 megapixel camera application from where you can take a picture using the rear facing camera.

Note: An SD card must be inserted before the camera will take and store photos.

For more information, refer to “*Using the Camera*” on page 94.



Clock

Allows you to set an alarm, configure and view the World clock, use a stopwatch, or set a timer. The applications display in a tabular format and quickly accessed with the touch of a finger.

For more information, refer to “*Clock*” on page 107.



Contacts

The default storage location for saving phone numbers to your Contacts List is your phone’s built-in memory.

For more information, refer to “*Contacts List*” on page 65.



Downloads: The Downloads application allows you to manage all of your downloads from the Market and the Browser. For more information, refer to “*Downloads*” on page 108.



Email

Provides access to both your Outlook (Exchange Server-based) work email and Internet email accounts (such as Gmail and Yahoo! Mail). For more information, refer to “*Email*” on page 86.



Files

Lets you view supported image files and text files on your microSD card. Organize and store data, images, and more in your own personal file folders. Files are stored to the memory card in separate (user defined) folders.

For more information, refer to “Files” on page 101.



Gallery

Displays a Gallery of camera images and video stored in the microSD card. For more information, refer to “The Gallery” on page 102.



Gmail

Provides access to your Gmail account. Google Mail (Gmail) is a web-based email service. Gmail is configured when you first set up your phone. For more information, refer to “Using Gmail” on page 91.



Google+

Google+ (Google Plus) is a social networking and identity service operated by Google Inc.



Internet

Open the browser to start surfing the web. The browser is fully optimized and comes with advanced functionality to enhance the Internet browsing feature on your phone.

For more information, refer to “Internet” on page 121.



Latitude

Lets you see your friends' locations and share yours with them. The application also lets you see your friends' locations on a map or in a list. It also lets you send instant messages and emails, make phone calls, and get directions to your friends' locations.

For more information, refer to “Latitude” on page 109.



Maps

Launches a Web-based dynamic map that helps you find local businesses, locate friends, view maps and get driving directions. For more information, refer to “Maps” on page 110.



Memo

Creates new text memos. For more information, refer to “Memo” on page 112.



Messaging

Provides access to text and multimedia messaging (SMS and MMS). For more information, refer to “*Creating and Sending Messages*” on page 81.



Messenger

Messenger allows you to bring groups of friends together into a simple group conversation. When you get a new conversation in Messenger, Google+ sends an update to your phone. For more information, refer to “*Messenger*” on page 93.



Music

Launches the built-in Music Player that allows you to play music files that you have stored on your microSD card. You can also create playlists. For more information, refer to “*Music*” on page 113.



Navigation

Launches a Web-based navigation application.

Caution! Traffic data is not real-time and directions may be wrong, dangerous, prohibited, or involve ferries.

For more information, refer to “*Navigation*” on page 113.



News & Weather

Launches a Web-based news and weather feed based on your current location. For more information, refer to “*Places*” on page 115.



Places

Displays location information on a layer of Google Maps. When viewing an area you can quickly locate a business or person, find out more information about the business, see coupons, public responses, and more. For more information, refer to “*Places*” on page 115.



Play Books: Choose from millions of titles on Google Play including new releases, best sellers, up-and-coming authors, and free books.

For more information, refer to “*Play Books*” on page 115.



Play Store

Google Play (formerly Android Market) allows you to find and download free and for-purchase applications. For more information, refer to “*Downloading a New Google Application*” on page 116.



Samsung Apps: Samsung Apps allows you to easily download an abundance of useful applications to your phone.



Settings

Accesses the device's built-in Settings menu. For more information, refer to "*Changing Your Settings*" on page 137.



Talk

Launches a Web-based Google Talk application that lets you chat with family and friends over the Internet for free. For more information, refer to "*Google Talk*" on page 93.



Task Manager

Use Task Manager to see which applications are running on your phone, and to end running applications to extend battery life.

For more information, refer to "*Task Manager*" on page 118.



Voice Recorder

Allows you to record an audio file up to one minute long and then immediately send it as a message. For more information, refer to "*Voice Recorder*" on page 119.



Voice Search

Launches your phone's built-in voice recognition software and initiates a Google search based on the recognized text. For more information, refer to "*Voice Search*" on page 119.



YouTube

Launches the YouTube webpage via the browser. For more information, refer to "*YouTube*" on page 105.

Customizing the Screens

You can customize the Home screens (panels) to display various Widgets, Shortcuts, Folders, or Wallpapers. For example, one screen could contain the Music Player shortcut and other forms of media, while another screen might contain communication apps such as Gmail and IM.

You can customize your Home screen by doing the following:

- Adding, Deleting, and Rearranging screens
- Adding and Removing Shortcuts
- Adding and Removing Widgets
- Creating Folders
- Changing the Background (Wallpapers)

Adding and Deleting Screens

Your phone can display up to seven screens. You can add, delete and rearrange these screens at any time.

Important! Your phone can provide up to seven screens and the minimum number is one screen.

To delete a screen:

1. Press  →  and then tap  (Edit).
2. Touch and hold, then drag the undesired screen down to the **Remove** tab ().
3. Press  to return to the main Home screen.

To add a screen:

1. Press  →  and then tap  (Edit).
2. Tap the **Add** icon (). The newly added screen appears as the last page.
3. Press  to return to the main Home screen.



Rearranging the Screens

1. Press  →  and then tap  (**Edit**).
2. Touch and hold a screen and then drag it into its new location.

Adding and Removing Primary Shortcuts

By default, the device provides four Primary shortcuts: Phone, Contacts, Messaging, and Applications/Home. As long as the menu is displayed in a **Customizable grid**, you can replace these shortcuts with other applications that you use most frequently.

1. Press  and then tap  (**Applications**).
2. Press  and then tap **View type** → **Customizable grid**.
3. Press  and then tap **Edit**. A box outline then appears around the application icons.
4. Scroll through the list and locate the desired application.
5. Touch and hold the on-screen icon, then drag it over one of the four primary shortcuts to replace it.
 - The new primary shortcut displays at the bottom of the screen. The previous primary shortcuts switches places with your selected icon.
6. Press  and then tap **Save**.
7. Tap  to return to the Home screen.

Managing Shortcuts

Note: To move a shortcut from one screen to another, carefully touch and hold the shortcut and slowly drag it to the edge of the screen. As the shortcut turns light blue, you can begin to move it to the adjacent screen. Alternatively, delete it from its current screen. Activate the new screen and then add the selected shortcut.

To add a shortcut from the Applications screen:

1. Press  to go to the Home screen.
2. Select a location (screen) for your new shortcut by scrolling through your available screens.
3. Tap  (**Applications**) to reveal all your current available applications. By default, applications are displayed as an Alphabetical grid.
4. Scroll across the screens and locate your desired application.
5. Touch and hold the on-screen icon. The new shortcut then appears to hover over the current screen.
6. While still holding the on-screen icon, position it on the current screen. Once complete, release the screen to lock the shortcut into its new position.

To add a shortcut via the Add to Home screen:

1. Press  to go to the Home screen.
2. Touch and hold an empty area of the screen.
3. From the **Add to Home screen** window tap **Shortcuts**.
4. Tap a selection from the available list.

To delete a shortcut:

1. Press  to go to the Home screen.
2. Touch and hold the desired shortcut. This unlocks it from its location on the current screen.
3. Drag the shortcut over the **Remove** tab () and release it.

Adding and Removing Widgets


Widgets are self-contained applications that can be placed on any screen. Unlike shortcuts, widgets appear as applications.

To add a Widget:

1. Press  to go to the Home screen.
2. Touch and hold an empty area of the screen.
3. From the **Add to Home screen** window tap **Widgets**.
4. Tap an available Widget to place it on your current screen.

To remove a Widget:

1. Touch and hold a Widget until it unlocks from the current screen.
2. Drag the widget over the **Remove** tab () and release it.
 - As you place the Widget into the Trash, it turns red.
 - This action doesn't delete the Widget, it just removes it from the current screen.



To place a widget onto a different screen:

1. Touch and hold the widget until it becomes transparent.
2. Drag it to the edge of your screen.
3. Slowly drag it past the edge of the screen until it turns light blue.
4. Drag the widget to its desired position on the new screen.
5. Repeat these steps to continue moving it to other screens.

Creating and Managing a Folder

Folders hold items that you want to organize and store together on the workspace.

To create a new on-screen folder:

1. Press  to go to the Home screen.
2. Touch and hold an empty area of the screen.
3. From the **Add to Home screen** window tap **Folders**.
4. Tap an available folder type and place it on the current screen.

To rename a folder:

1. Tap the desired folder you want to rename.
2. With the folder open, touch and hold the Folder title bar (top of the Folder window) until the **Rename folder** pop-up displays.
3. Tap the folder name field, enter a new title for this folder and tap **OK**.

To delete a folder:

1. Touch and hold a desired folder. This unlocks it from its location on the current screen.

2. Drag the folder over the **Remove** tab () and release it.

Managing Wallpapers

Wallpapers (screen background images) can be chosen from Gallery images (user taken), Live wallpapers (animated backgrounds), or Wallpaper gallery (default phone wallpapers).

Note: The use of animated Live wallpapers will require additional battery power.

To change the current wallpaper:

1. Press  to go to the Home screen.
2. Touch and hold an empty area of the screen.
3. From the **Add to Home screen** window tap **Wallpapers**.
4. Select a Wallpaper:
 - Tap **Gallery** to select from a user image stored in the camera image gallery, crop the image, and tap **Save**.
 - Tap **Live wallpapers** to select from a list of animated backgrounds, once done tap **Set wallpaper**.
 - Tap **Wallpaper gallery**, scroll through the images, tap a wallpaper image, then tap **Set wallpaper**.

Section 3: Memory Card

Your phone lets you use a microSD™ or microSDHC™ card (also referred to as a memory card) to expand available memory space. This secure digital card enables you to exchange images, music, and data between SD-compatible devices. This section addresses the features and options of your device's SD functionality.

- microSD card storage: up to 2GB in size
- microSDHC card storage: up to 32GB in size

Using the SD Card

There are two main uses for an SD card:

1. Connecting to your PC to store files (such as music, videos, or other types of files and media).
2. To activate the camera, video, music player, and other dependant media or applications.

Important! Camera, Music Player, and Video functionality require a mounted SD card.

microSD Icon Indicators

The following icons show your microSD card connection status at a glance:



- the card has been unmounted (released from use).



- the card is being prepared for use and for mounting.



- the card has been improperly removed.

Important! **DO NOT** remove a microSD card while the device is accessing or transferring files. Doing so will result in loss or damage of data. Make sure your battery is fully charged before using the microSD card. Your data may become damaged or lost if the battery runs out while you are using the microSD card.

Mounting an SD Card

An SD card must be mounted before it can be used with your phone. An inserted SD card is automatically mounted for use in

the phone. A card that has been unmounted but not removed from the phone must be remounted before it can be used.

To manually mount an SD card:

1. Press  →  and then tap  (**Settings**) → **SD card and phone storage**.
2. Tap **Mount SD card**.

Unmounting an SD card

Unmounting the SD card prevents corruption and damage to the SD card while removing it from the slot.

1. Press  →  and then tap  (**Settings**) → **SD card and phone storage**.
2. Tap **Unmount SD card** → **OK**.
3. When the “**SD card will be unmounted**” message displays and the **Mount SD card** now appears in the menu list, open the phone and remove the SD card. For more information, refer to “*Installing the microSD Memory Card*” on page 4.

PC Connection to an SD card

Important! If access to the external SD card is not available, download and install the appropriate USB drivers on the computer.

1. Insert the SD card into the SD card slot (For more information, refer to “*Installing the microSD Memory Card*” on page 4.)
2. Connect the USB cable to the phone and connect the cable to the computer.
3. Open the notifications panel and select **USB connected**. The “**USB Mass Storage**” screen is displayed.
4. Tap **Connect storage to PC** → **OK**. Both the phone and computer display icons to show that the device is mounted. As soon as the connection is established the computer assigns a drive letter the phone's storage device.
5. You can now use the computer to move files between the card and computer.
6. To close the connection between the phone and your computer, tap **Disconnect storage from PC**.

SD card Memory Status

To view the memory allocation for your SD card:

- ▶ Press  →  and then tap  (**Settings**) → **SD card and phone storage**. The available memory displays under the Total space and Available space

headings.

Format an SD card

You can erase all files from an SD card by reformatting the card.

1. Press  →  and then tap  (**Settings**) → **SD card and phone storage** → **Unmount SD card** → **OK**.
2. Tap **Format SD card** → **Format SD card** → **Erase everything**.
The SD card is formatted, erasing all the data stored on it.

Section 4: Call Functions

This section describes features and functionality associated with making or answering calls.

Displaying Your Phone Number

- ▶ Press  →  and then tap  (**Settings**) → **About phone** → **Status**. Your phone number displays in the **TELEPHONE** field.

Note: The phone's **Settings** menu can also be activated by pressing  and then tapping  →  (**Settings**).

Making a Call

1. Press  and then tap .
 2. Enter the phone number to dial then press .
- ▶ If you make a mistake while dialing, touch  to clear the last digit. Touch and hold  to clear the entire sequence.


Ending a Call

- ▶ Briefly tap  key to end the call.

Note: To redial a recent number, slide the number from the Call Log list to the right.

If you exit the current call screen and return to the Home screen, You are visually notified that you are still on an active call by the phone icon within the Status bar.

- ▶ Slide the status bar down to access the phone features.




Answering a Call

When somebody calls you, the phone rings and displays the incoming call image.

The caller's phone number, picture, or name if stored in Contacts List, displays.

- ▶ At the incoming call screen:
 - Touch and slide  to the right to answer the call.
 - Touch and slide  to the left to reject the call.



Pressing the Volume down button mutes the ringer.


If the incoming call is from a number stored in your Contacts, the contact's name is displayed. You may also see the caller's phone number, if available. For more information, refer to "Contacts" on page 65.

Dialing Options

When you enter numbers on the Keypad, you will see three on-screen options.

From the keypad screen, use one of the following options:

- **Call** () to call the entered number.
- **Delete** () to delete digits from the current number.
- **Voice Dialer** () to launch the voice recognition application.
- **Voice Mail** () to access your Voice Mail service.



To view additional dialing options:

- ▶ Tap  and select one of the following:
 - **Add to Contacts** to add the current number to either a new or existing Contacts entry.

- **Speed dial setting** to access the Speed Dialing menu where you can assign a speed dial location to a current Contacts entry.
- **Send message** to send a message (SMS/MMS) to the current phone number.
- **Add 3 sec pause** to insert a three-second delay within a number string (the phone continues dialing after 3 seconds without any additional keys being pressed).
- **Add wait** to insert a hard pause within the number string (the phone waits for your input). A wait requires that any consecutive numbers be manually sent by tapping **Send**.

International Calls

1. From the Home screen, tap , then touch and hold . The + symbol displays.
2. Use the on-screen keypad to enter the country code, area code, and phone number.
 - If you make a mistake, tap  once to delete a single digit.
 - Touch and hold  to delete all digits.
3. Tap .

Pause Dialing

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or financial phone numbers.

- **3-Second Pause** automatically sends the next set of numbers after a three-second pause. This is indicated in the number string as a comma (,).

1. From the Home screen, tap  and use the on-screen keypad to enter the phone number.
2. Press  and then tap **Add 3 sec pause**. This feature adds an automatic three-second pause.
3. Use the keypad to enter the additional numbers that will be dialed automatically after the second pause.

Tip: You can create pauses longer than three seconds by entering multiple 3-sec pauses.

4. Tap .

Wait Dialing

Inserting a Wait (;) into your dialing sequence means that the phone waits until you tap **Send** before proceeding with the next sequence of numbers.

1. From the Home screen, tap  and use the on-screen keypad to enter the phone number.
2. Press  and then tap **Add wait**. This feature causes the phone to require your acceptance before sending the next set of entered digits.
3. Tap .
4. Once prompted, tap **Send** to dial the remaining digits.

Redialing the Last Number

The phone stores the numbers of the calls you've dialed, received, or missed if the caller is identified.

To recall any of these numbers:

1. From the Home screen, tap .
2. Tap the **Call Log** tab to display the list of recent calls.
3. Tap the name/number and tap **Call**.

Speed Dialing

Once you have stored phone numbers to your Contacts List, you can set up to eight speed dial entries and then dial them easily whenever you want, simply by touching the associated numeric key.

Setting Up Speed Dial Entries

Important! Speed dial location #1 is reserved for Voicemail. No other number can be assigned to this slot.

1. From the Home screen, tap .
2. Press  and then tap **Speed dial setting**. The **Speed dial** screen displays a virtual keypad with the numbers 1 through 9.
3. Tap an unassigned number. The **Contacts** screen displays.



4. Tap a contact and select a number to assign to the speed dial location. The selected contact number/image is then displayed in the speed dial number box.

Changing a Speed Dial Entry

1. From the Home screen, tap .
2. Press  and then tap **Speed dial setting**.

Important! The number 1 is reserved for Voicemail and another number cannot be assigned to this slot.

3. Press  and then tap **Change order**.
4. In a single motion, touch and drag an entry over another location on the virtual keypad.
5. Tap **Save** to store the new assignment.
6. Press  to return to the previous screen.

Removing a Speed Dial Entry

1. From the Home screen, tap .
2. Press  and then tap **Speed dial setting**.

3. Touch and hold an on-screen speed dial location and select **Remove** from the context menu.

– or –

Press  and then tap **Remove**. Tap an entry and select **Remove**.


4. Press  to return to the previous screen.

Making a Call Using Speed Dial

1. From the Home screen, tap .
2. Touch and hold a speed dial location (numbers 2-9, or 1 if you are dialing voice mail) until the number begins to dial.
3. If you are not certain of the speed dial location, tap  →  → **Speed dial setting** and touch a speed dial number to view the assigned phone number.

In Call Options

Your phone provides a number of features that are available for use during a call.



Adjusting the Call Volume

During a call, use the Volume keys on the left side of the phone to adjust the earpiece volume.

- ▶ Press the **Up** volume key to increase the volume level and the **Down** volume key to decrease the level.

– or –

From the screen during a call, press the **Up** Volume key.

From the Home screen, you can also adjust the ringer volume using these keys.

Placing a Call on Hold

You can place the current call on hold whenever you want. If your network supports this service, you can also make another call while a call is in progress.

To place a call on hold:

1. Tap **Hold** to place the current call on hold.
2. Tap **Unhold** to activate the call that is on hold.

To make a new call while a call is in progress:

1. Enter the new phone number that you wish to dial or look it up in Call history.
2. Tap **Add call** to dial the second call.
3. Dial the new phone number and tap .

To switch between the two calls:

- ▶ Tap **Swap**.

The active call number appears large on screen. The caller on hold appears smaller and to the side reads "On hold".

Turning the Speakerphone on and off

While on a call, you can use your Speakerphone by following these steps:

1. Tap  (**Speaker off**) to turn the speakerphone on.
2. Tap  (**Speaker on**) to turn the speakerphone off.

Tip: When the speaker is turned **On**, a green bar appears in the speakerphone key. When the speaker is turned **Off**, the color of the bar is gray.

Muting a Call

1. Tap  (**Mute off**) to active mute so the other participant cannot hear you speaking.
2. Tap  (**Mute on**) to turn mute off and resume your conversation.

Switching to Bluetooth Headset

1. While on a call, switch to the Bluetooth headset instead of speaker by tapping **Headset**.
2. At the prompt, tap **Yes** to enable Bluetooth if it is not already activated.

More In-call Options

During a call you can search for information in the Contacts list, or create a Memo.

Viewing the Contacts List

During a call you can look up a number in the Contacts list.

1. Press  and then tap **Contacts**.
2. Browse the Contacts list for the information you need.
3. Press  to return to the active call.

Multi-Party calls

Making a Multi-Party Call

A multi-party call is a network service that allows up to six people to participate in a multi-party or conference call.

For further details about subscribing to this service, contact T-Mobile customer service.

Setting up a Multi-Party Call



1. From the Home screen, tap .
2. Dial the number for the first participant and tap . Wait for the call to be answered.
3. Tap **Add call**, enter the second phone number and tap . The first caller is placed on hold.
4. Wait for the second caller to answer the incoming call and tap **Merge calls**. The two calls are now joined into a multi-party call and display in the order in which they were called.

Important! A maximum of two callers can be joined to a single multi-party line at a time. Additional callers will participate in a new Multiparty session and held in conjunction with the previous multiparty call. You can swap or place each multi-party call on hold.

Having a Private Conversation With One Participant

When you have two or more participants in a multi-party session, it might be necessary to place those participants on hold so that a private conversation can be held with a single caller. While you are in a multi-party call:

1. Tap **Manage**.
2. Tap  adjacent to the participants you would like to split from the current call. The list displays the callers in the order they were dialed.



3. Tap the number for the participant you want to speak to privately.
You can now talk privately to that person while the other participants can continue to converse with each other. If there is only one other participant, that person is placed on hold.
4. To return to the multi-party call, tap **Merge calls**. All of the multi-party call participants can now hear each other.

Dropping One Participant

1. Tap **Manage** →  to the right of the number to drop a caller. The participant is disconnected and you can continue the call with the remaining participant.
2. Tap  to end the current call.

Call Waiting

You can answer an incoming call while you have a call in progress, if this service is supported by the network and you have previously set the Call waiting option to **Activate**.

You are notified of an incoming call by a call waiting tone. For more information, refer to “*Configuring Additional Call Settings*” on page 143.

To answer a new call while you have a call in progress:

1. In a single motion, touch  and slide it to the right to answer the new incoming call.
2. Select **Hold XXX** if you wish to place the previous caller on Hold. You can also choose to end your previous call and start a new one (**End XXX**).

Note: The new caller appears at the top of the list. The previous caller is placed on hold and appears at the bottom of the list.

3. Tap **Swap** to switch between the two calls. This places the new caller on hold and activates the previous call. The active call displays with a green background.
4. Tap **Swap** again to switch back.

Call Log Tab

The Call Log tab provides a list of the phone numbers (or Contacts entries) for calls you placed, accepted, or missed. The Call Log tab makes redialing a number fast and easy. It is continually updated as your device automatically adds new numbers to the beginning of the list and removes the oldest entries from the bottom of the list.

The Notification area of the Home screen (upper-left) displays phone notifications, status, or alerts such as:



Displays when a call is in progress.



Displays when a call was missed.

Accessing the Call Log Tab

1. From the Home screen, tap  → Call logs tab.
2. Tap an entry to view available options.

Note: The Call logs tab only records calls that occur while the phone is turned on. If a call is received while the phone is turned off, it will not be included in your calling history.

Each entry contains the phone number (if it is available) and Contacts entry name (if the number is in your Contacts).



Indicates outgoing call made from your device.



Indicates received call that was answered.



Indicates a missed call.

Accessing Call Logs from The Notifications Area

1. Touch the Status bar to reveal the Notifications tab, and then drag the tab to the bottom of the screen to open the Notifications panel (1).
2. Tap the Missed call entry to open the Call Log screen (2).




Tip: Press  and tap **Notifications** to open the panel.



This list provides easy access to redial an entry, send a message, or add the number to Contacts.

Call Log - Caller Overview

Call options (tap)



Call Log screen



Entry-specific
context menu
(touch and hold)

- Tap a contact entry name or number to reveal the **call options** screen:
 - **Call** allows you to redial the entry by name or number.
 - **Send message** allows you to create a new text message to the selected entry.
 - **Send email** allows you to create a new email that is then addressed to the entry's available email address.
 - **Time** provides the time and date of the call and its duration.
 - **Add to Contacts** to save the number if it is not already in your Contacts.
- Touch and hold an entry to display the entry-specific context menu:
 - **Call [Number]** to redial the current phone number.
 - **Send message** allows you to create a new text message to the selected entry.
 - **Edit number before call** to make alterations to the current phone number prior to redial.
 - **Add to Contacts** to save the number if it is not already in your Contacts.
 - **View contact** to view the information for the currently stored Contacts entry.
 - **Send contact information** to send the Log entry information via text message.
 - **Delete** to delete the entry from the Logs list.

Altering Numbers from the Call Log

If you need to make a call from the Call logs screen and you need to alter the number prior to dialing, you can add the appropriate prefix by prepending the number.

1. Tap  → **Call Log** tab.
2. Touch and hold an entry to access the entry-specific context menu.
3. Tap **Edit number before call**.
4. Edit the number using the on-screen dialpad or delete digits by pressing  to erase the numbers.
5. Tap  once the number has been changed.

Quick Dialing a Number from the Call Log

The Call Log can also be used to quickly call back a selected number by simply sliding the number across the entry.

1. Locate the desired number from the Call Log list.
2. In a single motion, touch and slide your finger over the number from left to right. This action places a call to the current recipient.

Quick Messaging a Number from the Call Log

The Call Log can also be used to quickly text message a selected number by simply sliding the number across the entry.

1. Locate the desired number from the Call Log list.
2. In a single motion, touch and slide your finger over the number by going to the left. This action addresses a new text message to the recipient.



Erasing the Call Log

You can delete either an individual call log entry or all current entries from the Call logs list.

To clear a single entry from the list:

1. Tap  → Call Log tab.
2. Touch and hold an entry and select **Delete**.

To clear all entries from the list:

1. Tap  → Call Log tab.
2. Press  → **Delete**.
3. Tap **Select all** → **Delete** → **OK**.

Section 5: Entering Text

This section describes how to select the desired text input method when entering characters into your phone. This section also describes the predictive text entry system that reduces the number of key strokes associated with entering text. Your phone is equipped with an orientation detector that can tell if the phone is being held in an upright (Portrait) or sideways (Landscape) position and adjusts the screen orientation to suit.

Text Input Methods

There are three text input methods available:

- **Samsung keypad:** an on-screen QWERTY keypad that can be used in both portrait and landscape orientation.
- **Swype** (default): a new way to enter text on touch screens. Instead of tapping each key, use your finger to trace over each letter of a word.
- **QWERTY keyboard:** located below the screen, can be used at any time to enter text and override the current text input method. For more information, refer to “*Locale and Text Settings*” on page 155.

The on-screen QWERTY keypad works the same in both portrait and landscape mode.

Selecting the Text Input Method

The Text Input Method can be assigned from two different locations:

Selecting from the Settings Menu:

- ▶ Press  →  and then tap  (Settings) → Locale and text → Select input method.

Selecting from the Text Input field:

1. From a screen where you can enter text, touch and hold the text input field to open the context menu and select **Input method**.
2. Select an input method (**Samsung keypad** or **Swype**).



Default On-screen
Text Input Method

Important! At any time, you can access the QWERTY keyboard and directly enter text.

Using the Samsung Keypad

This on-screen keypad can be used to enter text while in portrait orientation.

Enabling Samsung Keypad

This device has a built-in on-screen QWERTY keypad that is available in portrait mode. Using the QWERTY keypad/ keyboard, you can type letters, numbers, punctuation, and other characters.

To use the Samsung keypad you must first configure the settings to use the Samsung keypad.

1. Press  →  and then tap  → **Locale and text** → **Select input method** → **Samsung keypad**.

– or –

From a screen where you can enter text, tap and hold the text input field and tap **Input method** → **Samsung keypad**.

2. The on-screen keyboard is then assigned to the Samsung keypad configuration for all subsequent text input.

Changing the Text Input Mode in Keypad

1. From a screen where you can enter text, tap the text input field to reveal the on-screen keyboard.
2. With Samsung keypad as your text entry method, select one of the following text mode options:
 - **ABC**  to use alphabetic characters from the on-screen keyboard. In this mode, the text mode button displays .
 - **SYM** (Symbol)  to enter numbers by pressing the numbers selecting them on the onscreen keyboard. In this mode, the text mode button displays .

Using ABC Mode in Samsung Keypad

1. From a screen where you can enter text, tap the text input field to reveal the on-screen keyboard.

Note: An on-screen landscape keyboard is not available since in this orientation you can use the QWERTY keyboard found below the screen.

2. Tap  to configure the keyboard for ABC mode. Once in this mode, the text input type shows .

Note: After typing an initial uppercase character, the  key changes to  and all letters that follow in the same sentence are in lower case. The first letter of every new sentence is displayed as uppercase.

3. Enter your text using the on-screen keyboard.
 - If you make a mistake, tap  to erase a single character. Touch and hold  to erase an entire word.
4. Tap  to send the message.



All lowercase

Displays when all characters are entered in lowercase.



Initial Uppercase

The first character of a sentence is entered as uppercase but all subsequent characters are lowercase.



All Uppercase

Displays when all characters will be entered as uppercase characters (tap and hold the key).

By default, the first letter of a new entry is capitalized and the following letters are lowercase. After a character is entered, the cursor automatically advances to the next space.

Using Symbol Mode in Samsung Keypad

Use Symbol Mode to add numbers, symbols, or emoticons. While in this mode, the text mode key displays .

1. From a screen where you can enter text, tap the text input field to reveal the on-screen keyboard.

Note: An on-screen landscape keyboard is not available since in this orientation you can use the QWERTY keyboard found below the screen.

2. Tap  to configure the keyboard for Symbol mode. Once in this mode, the text input type shows . Tap a number, symbol, or emoticon character.
3. Tap  to return to ABC mode (key shows .

To enter symbols:

1. Tap  to enter ?123 mode.
 2. Tap the appropriate symbol key.
 - or –
 - Tap  to select from additional pages of symbol characters.
- The first number on this key indicates which page (1, 2, or 3) of additional characters is active.

Configuring Samsung Keypad Settings

1. Press  →  and then tap  → **Locale and text**
→ **Samsung keypad**.

– or –

From within an active text entry screen, tap  from the bottom of the screen to reveal the Samsung keypad settings screen.

2. Set any of the following options:
 - **Keypad types** allows you to choose a keypad configuration (Qwerty Keypad [default], 3x4 Keypad).
 - **Writing language** sets the input language. Tap a language from the available list. The keyboard is updated to the selected language.
 - **XT9** enables predictive text entry mode. This must be enabled to gain access to the advanced settings.
 - **XT9 advanced settings** allows configuration of more advanced XT9 features. For more information, refer to “Using XT9 Predictive Text” on page 57.
 - **Keypad sweeping** automatically moves the screen in the direction your finger moves along the screen.
 - **Auto-capitalization** automatically capitalizes the first letter of the first word in each sentence (standard English style).

- **Voice input** activates the Voice input feature. This is an experimental feature that uses Google’s networked speech recognition application.
- **Auto-full stop** automatically inserts a full stop by tapping the space bar twice.
- **Tutorial** launches a brief onscreen tutorial covering the main concepts related to the Samsung keypad.

Using XT9 Predictive Text

XT9 is a predictive text system that has next-letter prediction and regional error correction, which compensates for users pressing the wrong keys on QWERTY keyboards.

Note: XT9 is only available when ABC mode is selected. XT9 advanced settings are available only if the XT9 field has been selected.

1. Press  →  and then tap  → **Locale and text**
→ **Samsung keypad**.

– or –

From within an active text entry screen, tap  at the bottom of the screen to access the **Samsung keypad settings** screen.

2. Tap the **XT9** field. A checkmark indicates activation.

3. Tap **XT9** and configure any of the following advanced options:

- **Word completion** tells your device to attempt to predict how to complete the word you have started. (A green check mark indicates the feature is enabled.)
- **Word completion point** sets how many letters have to be entered before a word prediction is made. Choose from 2 letters, 3 letters, 4 letters, or 5 letters.
- **Spell correction** enables the automatic correction of typographical errors by selecting from a list of possible words that reflect both the characters of the keys you touched, and those of nearby characters. (A green check mark indicates the feature is enabled.)
- **Next word prediction** predicts the next word you are like to enter. (A green check mark indicates the feature is enabled.)
- **Auto-append** automatically adds predictions to the word you are typing. (A green check mark indicates the feature is enabled.)
- **Auto-substitution** allows the device to automatically replace misspelled or miskeyed words. This option reduce "typos." (A green check mark indicates the feature is enabled.)
- **Regional correction** automatically tries to correct errors caused when you tap keys adjacent to the correct keys. (A green check mark indicates the feature is enabled.)
- **Recapture** sets the device to redisplay the word suggestion list after selecting the wrong word from the list.

- **XT9 my words** allows you to add new words to the built-in XT9 dictionary.
 - Tap **Add word**.
 - Use the **Register to XT9 my words** field to enter the new word.
 - Tap **Done** to store the new word.
 - **XT9 auto-substitution** allows you create a word rule by adding words for automatic substitution during text entry (for example youve becomes you've).
 - Tap the XT9 auto-substitution field. Flick up or down to review the current list of word substitutions.
 - Press  and tap **Add**.
 - Enter the original word that will be replaced in the **Shortcut** field (for example, youve).
 - Enter the substitute word that will be used in the **Substitution** field (for example, you've).
 - Tap **Done** to save the substitution rule.
4. Press  to return to the previous screen.

Using the Swype Keyboard

Swype™ is the default on-screen text input method that allows you to enter a word by sliding your finger from letter to letter, lifting your finger between words. SWYPE uses error correcting algorithms and a language model to predict the next word. SWYPE also includes a touch predictive text system.

Enabling and Configuring SWYPE

If you have configured another text input method (Samsung keypad) you must enable SWYPE before using the SWYPE keyboard. Even when SWYPE is enabled, you can still use both the physical and on-screen keyboard functionality.

1. Press  →  and then tap  (Settings) → Locale and text.

Tap **Select input method** → **Swype**.

Enter text via Swype

This example shows a user entering the word “there”. Put your finger down on the “t”, and without lifting, glide it to the “h”, and then to the “e”, and then over to the “r”, and back to the “e”. When complete, lift your finger off the screen to allow the device to determine the closest word match.



Note: If multiple word choices exist for your Swype entry, an on-screen popup appears to provide additional word choices.

Swype Keyboard Overview



- **Text Input field:** a field where text, number, or other characters can be entered.
- **CAPS/ALT key:** When in ABC mode, this key changes the capitalization of the subsequent entered characters. When in += mode, this key can show additional symbol characters.

- **Text Input mode:**
 - **ABC** mode contains alphanumeric characters and a few common punctuation marks. Text mode button indicates **+!=**.
 - **+!=** mode contains only symbols and numbers. Text mode button indicates **ABC**.
- **Word Selection/Settings key:** Tap to select the highlighted word in the dictionary list, tap and hold to open the Settings screen.

Using ABC Mode in SWYPE

In **ABC** mode, you can enter letters, numbers and some common symbols from the onscreen keyboard.

1. From a screen where you can enter text, tap the text input field to reveal the on-screen keyboard.

Note: An on-screen landscape keyboard is not available since in this orientation you can use the QWERTY keyboard found below the screen.

2. If necessary, tap  to configure the keyboard for ABC mode (showing letters and numbers on the onscreen keys). Once in this mode, the text input type shows .
3. Swipe your finger continuously over the letters to form a word, then lift your finger from the screen.
 - If you make a mistake, tap  to erase a single character. Touch and hold  to erase an entire word.

Repeat as required to enter each additional word.

- By default, the first letter of an entry is capitalized and the following letters are lower case.
 - After a word is entered and you lift your finger, the cursor automatically adds a space after the word.
4. To enter the secondary character (above the main one on the same key), touch and hold the key or trace a circle around the key with your finger.
 5. To enter additional characters associated with a key, tap and hold the key until the pop-up box containing all characters appears, then tap the character.



Lowercase

Displays when characters will be entered in lowercase.



Uppercase

Displays when characters will be entered as uppercase characters.

Note: After typing an initial uppercase character, the  key changes to  and all letters that follow in the same sentence are in lower case. The first letter of every new sentence is entered as uppercase.

Entering Symbols in SWYPE

1. From a screen where you can enter text, tap the text input field to reveal the on-screen keyboard.
2. If necessary, tap  to configure the keyboard for += mode. Once in this mode, the text input type shows .
3. Tap the on-screen key for the number or symbol you want to enter. To enter the secondary symbol (above the main one on the same key), touch and hold the key or trace a circle around the key with your finger.
4. Tap  to choose from additional symbols.

Swype Text Entry Tips

- Create a squiggle (like an S shape) to create a double letter (such as **pp** in apple).
- Touch and hold a key to view the punctuation menu then make a selection.
- Move your finger over the apostrophe to enter contractions.
 - Double-touch on the word you want to change to correct a misspelled word, then touch the delete key to erase one character. Touch and hold the delete key to erase an entire word.

SWYPE Settings

1. Press  →  and then tap  → **Locale and text**

→ **Swype.**

2. Locate the **Preferences** section to alter these settings:
 - **Audio feedback:** turns on sounds generated by the Swype application.
 - **Vibrate on keypress:** phone vibrates when keys are pressed.
 - **Show tips:** turns on a flashing indicator for quick help.
 - **Auto-spacing:** automatically inserts a space between words. When you finish a word, just lift your finger and start the next word.
 - **Auto-capitalization:** automatically capitalizes the first letter of a sentence.
 - **Show complete trace:** sets whether the word trace line remains on-screen as you swipe across the screen.
 - **Word suggestion:** sets the amount of times the word choice selection window displays on screen. Move the slider between **Never** or **Always** and tap **OK**.
 - **Speed vs. accuracy:** sets how quickly Swype responds to on-screen input. Move the slider between **Fast Response** (speed) or **Error Tolerant** (accuracy) and tap **OK**.
 - **Language:** allows you to select the current text input language. Default language is **US English**.
 - **Reset Swype's dictionary:** Delete all words you have added to Swype's dictionary.
 - **Version:** displays the current software version.

Entering Text Using the QWERTY Keyboard

Your phone has a full, slide-out QWERTY keyboard. The keyboard is located beneath the display screen and is accessed by sliding it open. This orients the phone's display to Landscape (widescreen) mode. With the QWERTY keyboard, you can type letters, numbers, punctuation, and other special characters into text entry fields or other applications as easily as on your computer.

To open the device and access the keyboard:

1. Rotate the phone 90 degrees counter-clockwise.
2. Slide the top section of the phone up to open, as shown in the illustration. When you slide it open, the display rotates to a horizontal viewing mode (Landscape).



To reveal additional QWERTY text editing options:

1. Touch and hold an active text entry field.
2. From the Edit text context menu, tap an available function:
 - **Select word:** selects the tapped word.
 - **Select all** highlights all characters in the text message field.
 - **Select text/Stop selecting text** lets you manually highlight characters in the text message field.
 - **Cut** cuts all characters in the current text message field.
 - **Copy** copies selected characters in the current text message field.
 - **Cut all** cuts all characters in the current text message field.

- **Copy all** copies all characters in the current text message field.
- **Paste** inserts the previously cut or copied text into the message field.
- **Input method** selects the text input method used when the QWERTY keyboard is not open (Swype or Samsung keypad).

Using the QWERTY Keyboard

In this section we'll cover the steps necessary to enter text using the QWERTY keyboard. Using your phone's QWERTY keyboard is just like using any standard computer keyboard. The following keys perform special functions when entering text:



Alt: Allows you to use the alternate characters displayed at the top of the QWERTY keys. Examples: +, @, #.



Shift: Changes the text input mode between Upper/Lower/Mixed case mode.



Up/Go to: Press to move up. Press **Alt** and this key to open the browser and access the chosen homepage. For more information, refer to "Browser Options" on page 121.



Sym: Allows you to insert a symbol by providing you with an on-screen page of available symbols.



Space: Inserts an empty space.



OK: Press to confirm a highlighted selection.



Enter: Moves the insertion point to the next line in a message.



Left/Messaging: Press to move left. Press **Alt** and this key to launch the Messaging screen (by default). It can also be configured to launch other messaging applications.



Down/Search: Press to move down. Press **Alt** and this key to display the Quick Search box that can be used to search for a key term both on the phone or online.



Right/Emoticons: Press to move right. Press **Alt** and this key to launch the Emotions page. Scroll down and tap an entry from the extensive list of emotions.



Delete: Deletes the previous character, similar to the backspace key on a computer keyboard.

Entering Symbols and Smileys

Most symbols and punctuation marks appear as alternate characters above the primary letters and numbers on the QWERTY keyboard. To enter a symbol, press **Alt** and then press the appropriate key. To enter a series of symbols, press **Alt** **Alt**, press the appropriate keys, then press **Alt** again.

Emoticons (Smileys) are accessed by pressing **Alt**  and selecting an image from the Emoticons page that is then inserted at your current cursor position.

To enter symbols:

1. Position the cursor where you want the symbol to appear within your message.
2. Press **Alt** and then press the key corresponding to the symbol you want to insert.
 - For example, to enter “#1,” you could use the keyboard sequences shown below.



To enter “smileys” (emoticons):

1. Position the cursor where you want the emoticon to appear within your message.
2. Press **Alt** and  to open the onscreen Emoticons page.
3. Scroll through the list and select a smiley by touching the onscreen icon.

Section 6: Contacts

This section explains how to use and manage your Contacts List. You can save phone numbers to your phone's memory.

Contacts List

Creating a Contact

The default storage location for saving phone numbers to your Contacts List is your phone's built-in memory.

If existing Google and Corporate email accounts have been synchronized to your phone, these will be made available to your device during the creation of new entries. These new Contacts entries can be assigned or saved to synced accounts such as Phone, SIM, Google, or Microsoft Exchange ActiveSync.



Note: If the phone is ever reset to its factory default parameters, contacts stored on the phone can be lost.

- **SIM** contacts are stored within the SIM Card.
- **Google** contacts are shared with your existing Google account and can also be imported to your phone after you have created a Google Mail account.
- **Microsoft Exchange ActiveSync** contacts are shared with either an Exchange Server or from within Microsoft® Outlook®.

Note: When storing an entry into your SIM card, note that only the Name and Number are saved. To save additional information for a particular contact, such as notes, email, dates, etc., it is important to save that Contact into your phone's onboard memory.

1. From the Home screen, tap  (**Contacts**).
2. Tap  to create a contact.

Note: You can also add a new contact by entering a number from the keypad and pressing  and then tap **Add to Contacts** →  (**Create contact**). Continue with step 3.

3. If necessary, tap a destination (**Phone**, **SIM**, **Google**, or **Microsoft Exchange ActiveSync**).
4. Tap the **Given name** and **Family name** fields, and enter a name for this contact using the displayed keypad.

5. Tap the image icon and select a photo for this contact.
Selections are: **Album**, or **Take photo**.
6. Tap the label button (to the left of the **Phone number** field) to select a category such as **Mobile** (default), **Home**, **Work**, **Work Fax**, **Home Fax**, **Pager**, **Callback**, **Other**, or **Custom**.

Note: These labels can change and are dependant on the selected destination type (for example: Google does not offer Callback as an option).

7. Tap a phone number field and enter a phone number.
 - Tap  on the keypad to correct the entered phone number.
 - Tap  to enter an additional phone number
 - Tap  to remove a previously entered phone number.
8. Enter additional information such as: **Email**, **IM**, **Groups**, **Ringtone**, **Postal address**, **Organization** or **More**.
 - The **More** field provides options such as: Notes, Nickname, Website, Birthday and Anniversary.
 - Use your finger to drag the page up or down to see additional fields and categories.
9. Tap **Save** to complete and store the new entry.

To save a Number from your Keypad:

1. From the Home screen, tap  (**Phone**).

2. Enter a phone number using the on-screen dialpad.
3. From the dialer screen press  and then tap **Add to Contacts** →  (**Create contact**) or select the Contact entry from the on-screen list.
 - If you're updating an existing contact, tap the entry from the list and proceed to step 5.
4. Tap a destination type (**Phone**, **SIM**, **Google**, or **Microsoft Exchange ActiveSync**).
5. Tap the **Given name** and **Family name** fields, and enter a name for this contact.
6. Tap the label button (to the left of the **Phone number** field) to select a category such as **Mobile** (default), **Home**, **Work**, **Work Fax**, **Home Fax**, **Pager**, **Callback**, **Other**, or **Custom**.

Note: These labels can change and are dependant on the selected destination type (for example: Google does not offer Callback as an option).

7. Tap **Save** to complete and store the new entry.

Note: For further details about how to enter characters, see “*Text Input Methods*” on page 54.

Finding a Contact

You can store phone numbers and their corresponding names on your SIM card, in your phone's built-in memory, or in an external location (such as Google or Exchange). They are all physically separate but are used as a single entity, called Contacts.

Depending on the storage size of the particular SIM card, the maximum number of phone numbers the card can store may differ.

1. From the Home screen, tap  (**Contacts**).
2. Swipe up or down until you see the contact displayed.


– or –

Tap the **Search contacts** field and begin entering the contact's name. Matching entries are then displayed. This process filters through all of your current account Contact entries to only show you the matching entries.

– or –

In a single motion, touch and hold the letter tab area (on the right) until on-screen letters appear, then scroll through the list. You are then taken to that section of the Contacts list.

Touch the contact entry.




Editing Contact Information

1. From the Home screen, tap .
2. Tap a contact name from the list.
3. Press  and select **Edit**.

Note: You can also access an entry's context menu by touching and holding an entry then tapping **Edit**.


4. Edit the contact information then tap **Save**.



Adding a Number to an Existing Contact

1. From the Home screen, tap .
2. Touch and hold an entry and select **Edit** to reveal the Contact entry's details screen (page 70).
3. Touch a phone number field and enter a phone number.

- Tap  on the QWERTY keyboard to remove a previously entered phone number.



Contact Details Screen

- Tap  to enter an additional phone number
 - Tap  to remove a previously entered phone number.
4. Enter additional information such as: **Email**, **IM**, **Ringtone**, **Postal address**, **Organization** or **More** fields to input additional category information.

- The **More** field provides options such as: Notes, Nickname, Website, Birthday and Anniversary.
 - Use your finger to slide the page up or down to see additional fields and categories.
5. Tap **Save** to complete and store the new entry.

Deleting Contacts

This option allows you to delete your contacts. You can delete all your entries from your phone's memory, your SIM card, or All.

Important! Once Contacts List entries are deleted, they cannot be recovered.

1. From the Home screen, tap  .
2. Touch and hold a contact name from the list and select **Delete** → **OK**.

Contact List Options

1. From the Home screen, tap  .
2. Press  . The following options display:
 - **Search**: allows you to search for a contact entry.
 - **Delete**: allows you to delete 1 or more of your contacts.
 - **My profile**: allows you to set up a new contact entry that is a profile for yourself.


- **Import/Export**: imports or exports contacts to or from the SIM card or microSD card.
- **Get friends**: allows you to get contacts from your friends on Facebook, Twitter, or MySpace. You can also get contacts from Exchange Activesync or Google accounts.
- **More**:
 - **Accounts**: allows you to add and manage mobile accounts on Facebook, Twitter, or MySpace. You can also add Microsoft Exchange Activesync or Google accounts.
 - **Speed dial**: allows you to set up speed-dialing.
 - **Send email**: allows you to send an email using your email or Gmail account.
 - **Send message**: allows you to send a text or picture message.
 - **Display options**: allows you to choose to only display contacts that have phone numbers, sort by given or family name, display contacts given name first or family name first, display contacts stored to your SIM card, display contacts stored on your phone, and/or display contacts stored to other accounts.
 - **Settings**: allows you to configure where you save new contacts and view your Own numbers or Service numbers.

Contact Menu Options

1. From the Home screen, tap .
2. Touch and hold an entry to reveal the context menu.

The following options display:


- **Edit:** allows you to edit the currently selected Contacts entry.
- **Delete:** allows you to delete the currently selected Contacts entry.
- **Join contact:** allows you to link the current contact to another current contact. Similar to a “see also” feature. If you can’t remember a contact’s information, linking entries can help you find the person you are looking for.
- **Send contact information:** allows you to send the current entry info via text message.
- **Add to favorites:** allows you to copy the current Contacts entry to the list within the Favorites tab.
- **Remove from favorites:** allows you to remove the current Contacts entry from the Favorites tab.



- **Add to group:** allows you to add the current Contacts entry to an existing group.
- **Mark as default:** allows you to assign default numbers, email, etc. for a selected Contact. For more information, refer to “Marking a Contact as Default” on page 72.
- **Send namecard via:** allows you to send the current Contact entry’s information to an external recipient via either **Bluetooth**, **Email** (Exchange or Internet), **Gmail**, or **Messaging**.

Contact Entry Options

1. From the Home screen, tap .
2. Touch an entry to reveal the **Contact entry’s Overview Screen**. This screen contains Name, contact numbers, email, and linked contact information.
3. Press  to reveal the context menu specific to this entry.
4. Tap an available option.



Contact Overview Screen

Joining Contact Information

Most people now maintain multiple email accounts, social networking logins, and other similar account information. For example, a Facebook account login name might differ from a corporate email account login because they are maintained separately and for different groups of people.

This device can synchronize with multiple accounts (such as Facebook, Twitter, MySpace, Microsoft Exchange, or Google). When you synchronize your phone with those accounts, each account creates a separate contact entry in the Contacts list.

If one of your contacts (Amy Smith) has a regular email account that you maintain in Gmail, but also has a Facebook account under her maiden and married name, when you merge those accounts into your Contacts list you can join all of her entries and view the information in one record.

Joining contact information makes sending messages easy. You can select any account email address or information all from one screen, versus searching multiple, individual screens to locate the desired account information.

Next time you synchronize your phone with your accounts, any updates made to email account names, email addresses, etc. automatically update in your contacts list.

For more information about synchronizing accounts, see “Get Friends” on page 76.

To link contact entries:

1. From the Home screen, tap .
2. Tap a contact name (the name you want to link to another entry).

Note: Typically this is the same contact with a different name or account information.

3. Press  and then tap **Join contact**.
4. Tap the second contact entry. The second contact is now linked with the first and the account information is merged into one screen.

Note: The information is still maintained in both entries, but displays in one record for easier viewing when you link the contacts.

Important!: The second contact image that is displayed for both, but the first contact's name is used.
For example: If Amy (original entry) is joined with Julie (second entry), one entry appears under the name Amy. Tap the Amy entry (showing the Julie image) to view information from both.

5. Tap the main linked contact to view the contact information you linked. The contacts and information displays with an icon next to the contact name to indicate what type of account information is contained in the entry.

Unjoining a Contact

1. From the Home screen, tap .
2. Tap a contact name (the account name from which you want to unjoin an entry). This reveals the details for the entry.
3. Tap the **Joined contacts** area.
4. Tap  next to the entry you want to unjoin. The contacts are “unjoined” or separated and no longer display in the merged record screen. Both contacts return to being separately displayed.

Marking a Contact as Default

When you use applications such as a voice dialer or other messaging type applications, the application needs to know which information is primary (default) in a contact entry list. For example, when you say “Call John Smith”, if you have three phone records for John Smith, the voice dialer is looking for the “default” number or entry.

The **Mark as default** option marks one entry in a contact record to use as the default.

1. From the Home screen, tap .
2. Tap a Contact entry.
3. Press  and then tap **Mark as default**. The Mark as default screen displays radio buttons next to the contact name, phone number, or other contact information.
4. Tap the radio button next to the entry information you want to be the primary information (such as name, phone number, or email) and select **Save**.

Sending a Namecard

A Namecard contains contact information, and can be sent to recipients as a Virtual Business Card (V-card) attachment using Bluetooth, Gmail, or as a message.

1. From the Home screen, tap  .
2. Tap a Contact entry.
3. Press  and then tap **Send via** and select a delivery method: **Bluetooth**, **Email**, **Gmail**, or **Messaging**.

The Namecard attaches to the selected message type and is delivered when you send the message.

Sending All Current Namecards

Rather than selecting once Contact entry at a time, you can send all of your current entries at once.

1. From the Home screen, tap  .
2. Press  and then tap **Import/Export → Send namecard via**.
3. Tap **Select all** to place a check mark alongside all currently displayed Contact entries.
4. Tap **Send** and select a delivery method:

- **Bluetooth** to transmit this contact to another bluetooth-compatible device.
- **Email** to attach the contact card to a new outgoing email (Exchange or Internet).
- **Gmail** to attach the contact card to a new outgoing Internet-based email.
- **Messaging** to attach the contact card to a new outgoing text message.

Sending a namecard using Bluetooth

1. From the Home screen, tap  .
2. Touch and hold a contact entry to reveal the on-screen context menu.
3. Tap **Send namecard via → Bluetooth**.

Important! You must activate Bluetooth to use this feature.

4. Tap the Bluetooth device to receive this name card. Bluetooth forwards the namecard to the recipient.

Copying Contact Information

Copying Contact Information to the SIM Card

The default storage location for saving phone numbers to your Contacts list is your phone's built-in memory. This procedure allows you to copy numbers saved to the phone's memory onto the SIM card.

Note: These must be contacts stored on the phone. External entries (Google, Exchange, etc...) can not be transferred in this manner.

1. From the Home screen, tap .
2. From the Contacts List, press  and then tap **Import/Export → Export to SIM card**.
3. Tap **Select all** to choose all current phone contact entries.
– or –
Select a specific entry by touching an entry. A check mark indicates a selection.
4. Tap **Export**. The name and phone number for the selected contacts are copied to the SIM.

Copying Contact Information to the microSD Card

This procedure allows you to copy entry information saved in the phone's memory onto the microSD card.

1. Verify you have a properly mounted microSD card located within the microSD card slot.

Note: If your SD card is not properly mounted, you will not receive an option to export contacts to the SD card.

2. From the Home screen, tap .
3. From the Contacts List, press  and then tap **Import/Export → Export to SD card**.
4. Tap **Yes** to choose all current phone contact entries.

Synchronizing Contacts

Syncing data from your managed accounts allows you to add and manage a new or existing contact from your online or remote accounts to your phone. Prior to syncing, you must first have an active Google or Microsoft Exchange account with current Contact entries, and be signed into your account via the phone.

With syncing, any Contacts entries (with phone numbers, email addresses, pictures, etc.) are updated and synced with your phone. For more information about syncing existing managed accounts, see “Accounts and Synchronization” on page 151.

1. Press  →  and then tap  → **Accounts and sync**.
2. Locate the email account containing the contacts you wish to synchronize.
3. Tap  within the adjacent account field to reveal the account's synchronization settings screen.
4. To synchronize Contacts, tap **Sync Contacts**. A green checkmark indicates the feature is enabled.

Note: The process of updating your Contacts can take several minutes. If after 10-20 minutes, your list has not been updated, repeat step 2-3.

5. Your **Contacts** tab then reflects any updated Contact information.

Note: Syncing of contacts requires you are logged into your Gmail and Corporate accounts via the device.

Display Options

The Display options menu allows you to choose whether to display contacts saved to the Phone, SIM, external source or all; select the categories of contacts to display; and configure how contacts are displayed.

1. From the Home screen, tap .
2. Press  and then tap **More → Display options**. Configure any of the following options:
 - **Only contacts with phones** allows you to display only those contacts containing phone numbers.
 - **Sort by** defines how the current list of Contacts are sorted: **Given name** or **Family name**.
 - **Display contacts by** defines how the current list of Contacts are listed: **Given name first** (ex: Steve Smith) or **Family name first** (Smith, Steve).
 - **Select contacts to display** allows selection of the location of contacts to display.
3. Tap **Done**.

Get Friends

When you synchronize applications such as Facebook, Twitter, MySpace, a corporate email account, or Google, using the Get Friends option synchronizes the data from the selected account type with your Contacts list.

1. From the Home screen, tap .
2. Press  and then tap **Get friends** → **Add account** → **Add account**.
3. Determine which type of account information you want to synchronize with your Contact list. Selections are: **Facebook, Twitter, MySpace, Microsoft Exchange ActiveSync, or Google**.
4. Tap an account type to add.
5. Follow the prompts. The selected account type synchronizes with your Contacts list.
6. After synchronizing accounts you may want to link contact information. For more information, refer to “*Joining Contact Information*” on page 71.

To add Facebook content to your Contacts list:

You can now add your Facebook contact information, such as pictures, email, and phone numbers, directly to your Contacts list. All of their current contact information is then migrated over to your phone. If a Contacts entry already exists with a slightly different name, separate entries are created and can later be linked (joined) together into a single entry.

Important! Along with your contact information, this process also synchronizes your status, events, and more.

1. From the Home screen, tap .
2. From the Contacts tab, press  and then tap **Get friends** → **Add account** → **Add account**.
3. Tap **Facebook** from the **Integrated contact accounts** section of the **Add an account** screen.
 - This process adds your Facebook account to the list of managed and synchronized accounts. In this case, your Facebook contacts are synchronized with your phone's Contacts list.
4. Tap **Next** and enter your account's **Email** and **Password** information.
5. Tap **Log in** to begin the synchronization process.
6. Select a sync interval (from **None** to **Once a day**) and tap **Next**.

7. Tap those settings you wish to synchronize (all are enabled by default). A green checkmark indicates the feature is enabled.
 - Choose from: **Sync contacts**, **Add all friends**, or **Sync calendar**.
8. Tap **Done** to save these settings and return to Accounts and sync screen.
9. Tap  to confirm your Facebook contacts are now synchronized and appear in your Contacts list.

My Profile

You can send this Virtual Business Card (V-card) to other contacts as an attachment. My Profile is the first Contact listed in the Contacts list.

Note: As with any profile, your profile can be associated with a group.

To create My Profile:

1. From the Home screen, tap .
2. Press  and then tap **My profile**.
3. Enter information into the various fields.
4. Tap **Save** to store the new entry.

To edit My Profile:

1. With My profile displayed, press  and then tap **Edit**.
2. Modify any of the information contained in My Profile, then tap **Save**.

Additional Contact Options

Sending an Email to a Contact

Note: Contacts must contain an email account and address before you can use the Send email feature.

1. From the Home screen, tap .
2. Press  and then tap **More** → **Send email**. Contacts that contain an email address display.
3. Tap the contact to which you want to send an email. A check mark displays next to the selection.

Note: The select contact must have an email as part of their details screen.

4. Tap **Add**.
5. Select an email account type.
6. Compose the email and tap **Send**.

Export/Import

For more information, refer to “Copying Contact Information” on page 74.

Contact List Settings

From this menu you can determine the default storage location for Contacts, display your phone's primary number, and view service numbers listed in your Contact list.

1. From the Home screen, tap .
2. Press  and then tap **More** → **Settings**.
3. Select one of the following options:
 - **Save new contacts to:** defines the default storage location of new Contacts. Choose from: **Always ask**, **Phone**, **SIM**, **Google**, or **Microsoft Exchange ActiveSync**.
 - **Own numbers:** displays the number for this device.
 - **Service numbers:** displays the list of Service Dialing Numbers (SDN) assigned by your service provider. These numbers include emergency numbers, customer service numbers and directory inquiries.

Groups

This feature allows you to add a new or existing contact to a call group. This group can be one of the already present groups (Family, Friends, or Work) or a user-created group.

Creating a New Caller Group

1. From the Home screen, tap  → **Groups** tab.
2. Press  and then tap **Create**.
3. Tap the **Group name** field and use the on-screen keypad to enter a new group name. For more information, refer to “Text Input Methods” on page 54.
4. Tap **Ringtone** and select a ringtone for the group. Selections are: **Default ringtone**, **Sound** or **Phone ringtone**.
5. Tap **Save** to store the newly created group

Adding an Existing Entry to a Current Caller Group

1. From the Home screen, tap  → **Groups** tab.
2. Tap a group entry and then tap  (**Add member**).

Note: Some Group types (such as those with Google) can only be updated with new members remotely or online.

3. From the list of contacts, tap the contact(s) you want to add. A checkmark displays next to contact entry.
4. Tap **Add**. The selected contacts are added to the group.

Removing an Entry From a Caller Group

1. From the Home screen, tap  → **Groups** tab.
2. Touch a group entry.
3. Press  and then tap **Remove member**.
4. Tap all of the contacts you want to remove from this group. A checkmark displays next to contact entry.
5. Tap **Remove**. The contacts are removed from the group.


Editing a Caller Group

To edit a Group entry, there must be at least one member as part of the selected group.

1. From the Home screen, tap  → **Groups** tab.
2. Touch a group entry.
3. Press  and then tap **Edit group**.
4. Make modifications to the **Group name** or **Ringtone** fields. For more information, refer to “*Creating a New Caller Group*” on page 78.
5. Tap **Save**.

Sending a Message to a Group

1. From the Home screen, tap  → **Groups** tab.
2. Tap an existing group, and press  and then tap **Send message**.
3. Select the recipients of the new message (indicated by a green checkmark). If an entry contains multiple phone numbers, each must be selected individually.
4. Tap **Add**.
5. Type your message, and tap **Send**.



The History Tab

The History tab is a list of the phone numbers of calls that have been received, missed, and returned. For more information, refer to “*Call Log Tab*” on page 50.

1. From the Home screen, tap  .

2. Tap the **History** tab.
3. Press . The following options are available:
 - **Delete**: allows you to delete calls or messages from History. Select a call or message and tap **Delete**.
 - **View by**: allows you to select the type of displayed calls, messages, or emails. Selections are: Call, Message, Email, Facebook, MySpace, Twitter, or Select all. Tap the items you want to display then tap **Done**.

The Updates Tab

From the Updates tab you can view updated contact information that was synchronized with Facebook, Myspace, or Twitter.

1. From the Home screen, tap .

Note: You must log in to an SNS account (Facebook, Myspace or Twitter) before you can view the Updates.

2. Tap the **Updates** tab. The updates display.

Section 7: Messages

This section describes how to send or receive different types of messages. It also explains the features and functionality associated with messaging.

Types of Messages

Your phone provides the following message types:

- Text Messages
- Multimedia (Picture, Video, and Audio) Messages
- Email and Gmail Messages
- Google Talk

Message Icons on the Status Bar

Icons are displayed on the Status Bar at the top of the display when new messages are received. For more information, refer to “Status Bar” on page 18.

Creating and Sending Messages

The Short Message Service (SMS) lets you send and receive text messages to and from other mobile phones or email addresses. To use this feature, you may need to subscribe to your service provider’s message service.

The Multimedia Messaging Service (MMS) lets you send and receive multimedia messages (such as picture, video, and audio

messages) to and from other mobile phones or email addresses. To use this feature, you may need to subscribe to your service provider’s multimedia message service.

Important! When creating a message, adding an image, a sound file, or a video clip to a text message changes the message from a text message to a multimedia message.

Messaging icons are displayed at the top of the screen and indicate when messages are received and their type. For more information, refer to “Indicator Icons” on page 18.

1. From the Home screen, tap  (Messaging) → **New message**.
2. Tap on the **To** field to manually enter a recipient or select one of the following:
 - **Recent**: to select a recipient from a list of recently sent messages.
 - **Contacts**: to select a recipient from your Contacts list (valid entries must have a wireless phone number or email address).
 - **Groups**: to select a recipient from the Group list.
3. If adding a recipient from either Recent, Contacts, or Group, touch the contact to place a checkmark then tap **Add**. The contact displays in the recipient field.

Note: For the Group option, if the number of recipients is less than 10, all members in the group are added. Delete any unnecessary members in the list by selecting the trash can icon and deleting unwanted entries.

4. Tap the **Tap to compose** field and enter a message. For more information, refer to “*Text Input Methods*” on page 54.
 5. Review your message and tap **Send**.
-

Note: If you exit a message before you touch Send, the message is automatically saved in Drafts.

Messaging Key

When using the QWERTY keyboard, the left/messaging key  provides you with quick access to messaging functionality without having to go into Applications menu.

► Press   to access the messaging function.

Message Options

1. From the Home screen, tap  (**Messaging**).
2. Tap a message to open it.
3. Press  to display messaging options:
 - **View contact:** reveals the current Contact’s overview screen.
 - **Add/Remove subject:** inserts or deletes a Subject field in your message.
 - **Attach:** allows you to attach the following:
 - **Slideshow:** allows you to create up to a 10 page slideshow to attach to the message.
 - **Pictures:** allows you to choose an existing picture file and add it to your message. When you have selected the desired file, you can attach it.
 - **Videos:** allows you to choose an existing video file and add it to your message. When you have selected the desired file, you can attach it.
 - **Audio:** allows you to choose an existing audio file and add it to your message by tapping **OK**.
 - **Capture picture:** allows you to temporarily exit the message, take a photo with phone’s camera, then add it to your message by tapping **Save**.
 - **Capture video:** allows you to temporarily exit the message, record a video clip using the phone’s video camera, then add it to your message by tapping **Save**.

- **Record audio:** allows you to temporarily exit the message, record an audio clip using the phone’s microphone, then add it to your message by tapping  → **Add**.
- **Contacts:** allows you to tap on an existing Contacts entry to add their contact info to your message.
- **Calendar:** allows you to tap on an existing Calendar event and add it to your message.
- **Memo:** allows you to tap on an existing Memo and add it to your message.
- **Add text:** allows you to add text items from sources such as: Contacts, Calendar, and Memo.
- **Insert smiley:** lets you insert an emoticon into the message.
- **More:** provides the following additional options: Delete message, Discard, Call.

Viewing Newly Received Messages

When you receive a message, your phone notifies you by displaying  within the Notification area at the top left of your Home screen.

To read a message:

1. Open the Notification Bar and select the message. For more information, refer to “Notification Bar” on page 21.

– or –

From the Home screen, tap  then tap the new message to view. The selected message displays on the screen.

2. Tap  to play a multimedia message.
3. In a single motion, touch and scroll up or down the page to scroll through the message (if additional pages were added).

Message Threads

Sent and received text and picture messages are grouped into message threads. Threaded messages allow you to see all the messages exchanged with a specific contact (similar to a chat program). Messages are listed in the order in which they were received, with the latest message displayed at the top.

To reply to a message:

1. From the Home screen, tap .
2. Tap a message thread to open it.
3. Tap the **Tap to compose** field.

4. Compose your reply.

Your messages are colored blue and the other person's are yellow.

- Grey boxes indicate a message that failed to be delivered.
 - To attach a file, tap **Attach**. For more information, refer to *"Message Options"* on page 82.
 - Press  and then select one of these messaging options: **Add subject**, **Attach**, **Add text**, **View contact**, **Insert Smiley** or **More** (Delete messages, Discard, or Call).
5. Tap **Send** to send the message.



To access additional Bubble options:

- ▶ Touch and hold the message bubble to display the following options:
 - **Delete message:** deletes the currently selected message bubble from the thread.
 - **Add to Contacts:** adds the current caller to your Contacts list.
 - **Copy message text:** copies the currently selected message bubble from the thread.
 - **Lock/Unlock message:** locks or unlocks the currently selected message bubble from being accidentally deleted.
 - **Forward:** allows you to forward the currently selected message bubble to an external recipient.
 - **Copy to SIM:** copies the currently selected message bubble as a single text message within the SIM card.
 - **View message details:** displays details for the currently selected message bubble.

Deleting Messages

Deleting a single message

1. From the Home screen, tap .
2. Access the desired message thread, touch and hold the message bubble and select **Delete message** from the pop-up menu.
3. At the prompt, tap **OK** to delete or **Cancel** to cancel.

Deleting multiple messages

1. From the Home screen, tap .
2. Press  and then tap **Delete threads**.
3. Tap each message thread you want to delete. A checkmark displays beside each selected message.
4. Tap **Delete**.
5. At the prompt, tap **OK** to delete or **Cancel** to end the process.

Message Search

You can search through your messages by using the Message Search feature.

1. From the Home screen, tap .

2. Press  and then tap **Search**.
3. Use the on-screen keypad to enter a word or phrase to search for, then tap .
4. All messages that contain the entered search string display.

Messaging Settings

To configure the settings for text messages, multimedia messages, Voice mails, and Push messages.

1. From the Home screen, tap .
2. Press  and then tap **Settings**.

The following Messaging settings are available:

- **Message skin:** choose a message display style.

Storage settings

- **Delete old messages:** deletes old messages automatically when the message limit is reached, rather than providing an error message.
- **Text message limit:** allows you to set a limit on the number of text messages allowed in one conversation.
- **Multimedia message limit:** allows you to set a limit on the number of multimedia messages allowed in one conversation.

Text message settings

- **Delivery reports:** allows you to request a delivery report for each message sent.

- **Manage SIM card messages:** allows you to manage the messages stored on the SIM card.
- **Message centre:** displays the number of your message center where your messages reside while the system is attempting to deliver them.
- **Input mode:** allows you to set the input mode for your text messages. Choose GSM Alphabet, Unicode, or Automatic.

Multimedia message (MMS) settings

- **Delivery reports:** allows you to request a delivery report for each message sent.
- **Read reports:** allows you to request a read report for each message sent.
- **Auto-retrieve:** allows the message system to automatically retrieve messages.
- **Roaming auto-retrieve:** allows the message system to automatically retrieve message while roaming.
- **Creation mode:** allows you to select the creation mode: Restricted, Warning, or Free
 - **Restricted:** you can only create and submit messages with content belonging to the Core MM Content Domain.
 - **Warning:** the phone will warn you via pop up messages that you are creating a multimedia message which does not fit the Core MM Content Domain.
 - **Free:** you may add any content to the message.

Notification settings

- **Notifications:** allows you to see message notifications on your status bar.
- **Select ringtone:** allows you to set the ringtone for your message notifications.

Email

Your phone's Email application lets you access and manage multiple email accounts simultaneously in one convenient location. You can also receive text message alerts when you receive an important email.

To send and receive email messages through an ISP (Internet Service Provider) account, or if you wish to use your device to access your corporate email through a VPN (Virtual Private Network), you will first need to set up an IMAP or POP account.

- **IMAP** (Internet Message Access Protocol) - This protocol is frequently used in large networks and commercial settings. IMAP4 is the current standard.
- **POP** (Post Office Protocol) - This protocol is supported by most ISPs (Internet service providers) and common among consumer applications. POP3 is the current standard.

You can also send and receive email messages using Internet-based email services such as Gmail and Yahoo! Mail, or using Microsoft Exchange ActiveSync for email, contact, and calendar synchronization using an Outlook Exchange Server.

Creating an Email Account

1. From the Home screen, tap  (Applications) →  (Email). The Set up email screen displays.
2. Enter your email address in the **Email address** field.
3. Enter your password in the **Password** field.
4. Tap **Next** to have the phone attempt automatic setup of your account or tap **Manual setup** to configure your connection settings manually (POP3 or IMAP). Follow the on-screen prompts and enter the information specific to your email provider.
5. Enter an account name and your name (displayed on outgoing messages, then tap **Done**.
 - The unique account name is used to differentiate this account from other email accounts accessed by your device.

Opening an Email

1. From the Home screen, tap  →  (Email).
 - To switch email accounts, press , tap **Accounts** and select an email account.
2. Tap an email message.

Refreshing Email messages

1. From the Home screen, tap  →  (Email).
2. Select an email account.
3. Press  and then tap **Refresh**.

Composing an Email message

1. From the Home screen, tap  →  (Email).
 - To switch email accounts, press , tap **Accounts** and select an email account.
2. Tap **Inbox** and press .
3. Tap **Compose**.
4. Enter the message recipient's email address in the **To** field.
 - Tap **Recent**, **Contacts** or **Group** to select one or more existing contacts.
 - If you are sending the email message to several recipients, separate the email addresses by a comma or semicolon. You can add as many message recipients as you want.
 - To carbon copy additional recipients, press  and select **Add Cc/Bcc**. Use the **Cc** field to carbon copy additional recipients. Use the **Bcc** field to blind copy additional recipients.
5. Tap the **Subject** field and enter the email subject.
6. Tap the email text field and compose your email message.

- To add a picture attachment, tap **Attach** and make a selection.
7. Once complete, tap **Send**.

Configuring Internet Email Settings

1. From the Home screen, tap  →  (Email).
2. Press  and then tap **Accounts**.
3. Select an account.
4. From the email list screen, press  and then tap **More** → **Account settings**.
5. Alter any of the following settings:
 - **Account name:** displays your uniquely created account display name.
 - **Your name:** displays the name used in the From field of your outgoing email messages.
 - **Email check frequency:** Adjust the time interval used by your device to check your email account for new email messages.
 - **Default account:** Assign this account as the default email account used for outgoing messages.
 - **Security policy list:** Lists applicable security policies, which can restrict some email functions.
 - **Email notifications:** Activates the email notification icon to appear within the Notifications area of the status bar when new email messages are received.

- **Select ringtone:** Plays a selected ringtone when a new email message is received.
- **Vibrate:** Activates a vibration when a new email message is received.
- **Incoming settings:** Lets you specify incoming email settings, such as username, password, IMAP or POP3 server, Port, Security type, Delete email from server, and IMAP path prefix.
- **Outgoing settings:** Lets you specify outgoing settings, such as SMTP server, Port, Security type, Require sign-in, User name, and password.
- **Recent messages:** Lets you choose the number of recent messages that are displayed on-screen.
- **Forward with files:** Lets you include attachments when forwarding an email.
- **Add signature:** Lets you attach a customized signature to the bottom of all outgoing emails.
- **Signature:** Lets you create an email signature for your outgoing email messages.

Microsoft Exchange Email (Outlook)

Your phone also provides access to your company's Outlook Exchange server. If your company uses either Microsoft Exchange Server 2003 or 2007, you can use this email application to wirelessly synchronize your email, Contacts, and Calendar information directly with your company's Exchange server.

Note: Consult your Network or IT Administrator for further details and support.

Setting Up a Microsoft Exchange Email account

1. From the Home screen, tap  →  (Email).
2. If you already have other email account setup:
 - Press  and then tap **Accounts**.
 - Press  and then tap **Add account**.
3. Enter your **Email address** and **Password** information.
4. Tap **Manual Setup** and then **Microsoft Exchange ActiveSync**.
5. Enter a **Domain**, and confirm your **Email address**, **Username**, and **Password** information. If your network requires SSL encryption, tap the Use secure connection (SSL) field to place a check mark in the box and activate this additional level.

Important! If your exchange server requires this feature, leaving this field unchecked can prevent connection.

6. Tap **Next**.

7. If prompted with a connection error, manually enter your **Exchange server** information within the appropriate field. Obtain this information from your company network administrator. Do not accept the default entry as this is a guess based on returned information. Tap **Next**.
8. Read the on-screen activation disclaimer and tap **Yes**.
9. Adjust the various on-screen configuration fields and tap **Next**.
10. Identify your new account with a unique name and provide the outgoing name text, then tap **Done**.

Opening an Exchange Email

1. From the Home screen, tap  →  (Email).
2. Press  and then tap **Accounts**.
3. Select an exchange email account and tap an email message.

Refreshing Exchange Email

1. From the Home screen, tap  →  (Email).
2. Press  and then tap **Accounts**.
3. Select an exchange email account.

4. Press  and then tap **Refresh**.

Composing Exchange Email

1. From the Home screen, tap  →  (Email).
2. Press  and then tap **Accounts**.
3. Select an exchange email account.
4. Tap **Inbox** and press  and then tap **Compose**.
5. Enter the message recipient's email address in the **To** field.
 - If you are sending the email message to several recipients, separate the email addresses by a comma or semicolon. You can add as many message recipients as you want.
 - Use the **Cc** field to carbon copy additional recipients.
 - Use the **Bcc** field to blind copy additional recipients.
6. Tap the **Subject** field and enter the email subject.
7. Tap the email text field and compose your email message.
 - To add a picture attachment, tap **Attach** and make a selection.
8. Once complete, tap **Send**.

Deleting an Exchange Email Message

- ▶ Touch and hold an email (from your inbox list) and select **Delete** from the on-screen context menu.
- or –

With the email message displayed, press  and then tap **Delete**.

Configuring Microsoft Exchange Email Settings

1. Press  →  and then tap  → **Accounts and sync**.
 2. Tap  within the Microsoft Exchange account field to reveal the account's synchronization settings screen.
 3. Toggle either the **Sync Contacts** or **Sync Calendar** fields to force the device to manually resync either the exchange Contacts or Calendar entries.
- or –
- Tap **Account settings** and specify any other email settings:
- **Account name** displays the name used by the device to track the account.
 - **Your name** displays the name used in the From field within your outgoing email messages.
 - **Amount to synchronize** to assign the sync range for your incoming and outgoing email messages between your phone and your external exchange server. How many days worth of email messages should the phone and server synchronize. Choose from: **1 day, 3 days, 1 week, 2 weeks, or 1 month**.

- **Default account** assigns this account as the default used when sending out new email messages.
- **Out of office settings** assigns this account's out of office settings.
- **Empty server trash:** allows you to delete your email account's trash bin remotely.
- **Sync schedule** allows you to configure your email sync schedule.
- **Email size** configures the incoming email size allowed to pass through to your phone automatically without user interaction. Larger emails will have to be retrieved manually.
- **Security Policy list:**
- **Email notifications** enables the phone to display a status bar icon when new email messages have been received.
- **Select ringtone** assigns an audible ringtone when a new or upcoming event is pending.
- **Vibrate** assigns a vibration when a new or upcoming event is pending.
- **Exchange server settings** provides access to the Domain, password, and exchange server settings.
- **Sync Contacts** synchronizes the contacts between your phone and the remote exchange server.
- **Sync Calendar** synchronizes your exchange calendar entries between your phone and the remote exchange server.
- **Period to sync Calendar** assigns a period for your phone to sync calendar events.

- **Add signature** activates the email signature feature.
- **Signature** allows you to create an outgoing email signature attached to new email messages sent from your phone.

4. Press  to return to the previous page.

Using Gmail

Gmail is Google's web-based email service. When you first setup the phone, Gmail is configured. Depending on the synchronization settings, email is automatically synchronized with your Gmail account.

Signing into Gmail

1. From the Home screen, tap  →  (Gmail).

Note: You must sign in to your Gmail account in order to access features such as Gmail and Android Market.

2. Tap **Next** to add a Google account.
3. Tap **Create** if you do not have a Google account. Enter the required information and press **Next**.

– or –

Tap **Sign in** if you have a Google account. Enter the required information and press **Next**.
The Inbox loads conversations and email.

Opening Gmail

1. From the Home screen, tap  →  (Gmail).
2. Tap an existing email message.

Refreshing Gmail

- ▶ From within the Gmail message list, press  and then tap **Refresh** to send and receive new emails and synchronize your email with the Gmail account.

Composing a Gmail Message

1. From the Home screen, tap  →  (Gmail).
2. From the Gmail Inbox, press  and then tap **Compose**.
3. Enter the recipient's Email address in the **To** field.

Tip: Separate multiple recipient email addresses by a comma or semicolon.

4. Press  and select **Add Cc/Bcc** to add a carbon or blind copy.
5. Enter the subject of this message in the **Subject** field.
6. Tap the **Compose Mail** field and begin composing your message.
7. Once complete tap  (**Send**).

Viewing a Gmail Message

1. From the Gmail Inbox, touch a message to view. The following options are available:
 - **Archive**: archives the selected Email.
 - **Delete**: deletes the Email.
 - **<**: displays older Emails.
 - **>**: displays newer Emails.
2. Press  to select one of the following additional options:
 - **Change labels**: changes the label on the email or conversation.
 - **Mark/Not important**: click to mark as important/not important.
 - **Mark unread**: unread messages or threads with unread messages display in boldface text in the Inbox.
 - **Go to Inbox**: displays the Google Mail Inbox.
 - **Mute**: mutes the conversation.
 - **More**:
 - **Add/remove star**: click a message's star icon to add or remove the star.
 - **Report spam**: reports the Email message as spam.
 - **Select text**: allows you to select text to copy and paste.
 - **Settings**: allows you to configure the General, or Notification settings.
 - **Help**: launches the browser and displays Google Mobile Help information.

Google Talk

Google Talk™ is a free web-based application for instant messaging offered by Google. Conversation logs are automatically saved to a Chats area in your Gmail account. This allows you to search the logs and store them in your Gmail accounts.

1. From the Home screen, tap  →  (**Talk**).
2. Tap **Next** to add a Google account.
3. Tap **Create** if you do not have a Google account.
– or –
Tap **Sign in** if you have a Google account.
4. After entering your user name and password, tap the **Down** Navigation key.
5. Tap **Sign in**.
6. Begin using Google Talk.

Note: The Network confirms your login and processes. This could take up to 5 minutes to complete.

Messenger

Messenger allows you to bring groups of friends together into a simple group conversation. When you get a new conversation in Messenger, Google+ sends an update to your phone.

1. Sign on to your Google account. For more information, refer to “*Creating a New Google Account*” on page 10.
2. From the Home screen, tap  → **Messenger** .
– or –
From the Google+ application, select **Messenger**.
3. Select the account you want to use to sign in to Google+.
– or –
Tap **Create a new account** to create another account.
4. At the **Messenger** screen, tap  to start a new message.
5. In the upper text field, enter a name, email address, or circle.
6. In the bottom message field, enter a message then tap .
7. From the **Messenger** screen, tap **Learn more** for more detailed information.

Section 8: Multimedia

This section explains how to use the multimedia features of your phone, including the Camera/Camcorder and Music Player, and how to manage your photos, images and sounds.

Using the Camera

This section explains how to use the camera on your phone. You can take photographs and shoot video by using the built-in camera functionality. Your camera produces photos in JPEG format.

Important! Do not take photos of people without their permission.
Do not take photos in places where cameras are not allowed.
Do not take photos in places where you may interfere with another person's privacy.

Taking Photos

Taking pictures with your device's built-in camera is as simple as choosing a subject, pointing the camera, then pressing the camera key.

Note: The camera stores all photos on a microSD card only, so a card must be present in the phone before the camera will operate.

1. From the Home screen, tap  (**Camera**).

2. Using the phone's main display screen as a viewfinder, adjust the image by aiming the camera at the subject.
 - Zoom in or out using the Up and Down Volume keys. You can magnify the picture up to 3X.
 - Touch the left tab to access various camera options and settings. For more information, refer to “*Camera and Camcorder Options*” on page 95.
3. Press the **Camera** key until the shutter sounds. The picture is automatically stored on your microSD card.



Camera and Camcorder Options

Camera Options

The following options are available for the camera:

Note: The options disappear after a few seconds. Touch the screen to display the tab, then touch the tab to view these options.

1. **Shooting mode:** allows you to set the following options:
 - **Single shot:** takes a single photo when the camera key is pressed.
 - **Smile shot:** takes a single photo when the subject smiles.
 - **Continuous:** takes a series photos by pressing and holding the Camera key.
 - **Panorama:** takes a landscape photo by taking an initial photo and then adding additional images to the file. Slowly move the phone in any direction and align the green guide box with the viewfinder. When you have aligned the frame and viewfinder, the camera will automatically take the next photo. Repeat this step for up to 8 segments.
2. **Scene mode:** selects a camera setting for better image capture under different lighting environments. Choose from: None (default), Portrait, Landscape, Night, Sports, Party/Indoor, Beach/Snow, Sunset, Dawn, Fall colour, Firework, Candlelight and Backlight.

3. **Flash:** adjusts the camera's flash. Choose from Off, On, or Auto flash.
4. **Settings:** displays two types of settings, Camera () and General ().

Camera settings:

- **Exposure value:** allows you to adjust the exposure.
- **Timer:** allows you to set a time delay before the camera takes the photo (Off, 2 sec, 5 sec, or 10 sec). When you press the Camera key, the camera takes the photo after the specified time elapses.
- **Resolution:** sets the photo resolution to: 2048x1536, 1600x1200, 1280x960, or 320x240.
- **White balance:** allows you to set the colour balance from the following choices: Auto, Cloudy, Fluorescent, Daylight, or Incandescent.
- **Effects:** allows you to change the color tone or apply special effects to the photo. Options include: Normal, Black and White, Negative, or Sepia.
- **ISO:** determines light meter sensitivity. Choose from Auto, 100, 200, 400, or 800. Use a lower ISO number to make your camera less sensitive to light, a higher ISO number to take photos with less light, or Auto to let the camera automatically adjust the ISO for each of your shots.
- **Metering:** allows you to set how the camera measures or meters the light source: Centre-weighted, Spot, or Matrix.

- **Image quality:** allows you to set the image quality to: Superfine, Fine, or Normal.
- **Adjust:** allows you to adjust the Contrast, Saturation and Sharpness for this photo.

General settings:

- **Guidelines:** displays alignment and framing guidelines to help compose your photos.
 - **Review:** displays the photo for review. Selections are: Off, 2 sec, or On.
 - **GPS:** records GPS information onto the image file.
 - **Shutter sound:** allows you to select whether a tone is played when the camera's takes a photo. Sound selections are Sound 1 or Off.
 - **Reset:** resets the camera settings to the default settings.
5. **Camera / Camcorder Mode:** allows you to switch between Camera and Camcorder mode. Once you change the mode, the corresponding indicator appears at the top left of the display.
 6. **Camera button:** takes a photo when pressed.
 7. **Quick view:** displays the photo for quick viewing.

Picture Viewer Options

While viewing a photo you have just taken, the following options are available.

- **Share:** allows you to share a picture using Bluetooth, Email, Gmail, Messaging, or Picasa.
- **Set as:** sets the photo as a Contact icon, Home screen Wallpaper, or Lock screen Wallpaper.
- **Delete:** deletes this photo.

Camera Gallery Options

The Gallery is where you can access the Gallery of stored camera images.

1. From the Home screen, tap  (Applications) →  (Gallery).
2. Select one or more albums by tapping and holding to place a green check mark on the file.
3. Press  from this main Gallery screen to reveal gallery-specific options:

- **Share:** allows you to share the selected album(s) using Bluetooth, Gmail, Google+ or Picasa.
- **Delete:** allows you to delete the selected album(s).
- **More:** displays details about the selected album(s).



Camera Image Options


When you take a picture, the file is saved in the Photo folder. You can view your pictures immediately or view them anytime in the Photo folder.

1. From the Home screen, tap  (Applications) →  (Gallery).
2. Select a folder location and tap a file to open it in the Image viewer. Touch and drag a picture to the left to see the next picture or to the right to see the previous picture.
3. Tap **Slideshow** to initiate an on-screen slideshow displaying every image in the current folder.

– or –

Tap **Menu** to display the following image menu options:

- **Share:** allows you to share a picture using Bluetooth, Gmail, Google+, Messaging, or Picasa.
- **Delete:** allows you to delete the current image.



- **More:** provides you with the additional options:
 - **Details:** displays file details such as Title, Type, Date taken, Album, Location, Latitude, Longitude, and Size.
 - **Show on map:** if the file was geo-tagged when it was taken, its location can be revealed on a map.
 - **Set as:** allows you to assign a picture to one of three locations: Contact icon, Home screen Wallpaper, or Lock screen Wallpaper.
 - **Crop:** provides an on-screen box that allows you to crop the current picture. Tap **Save** to update the image with the new dimensions or **Cancel** to ignore any changes.
 - **Rotate left:** allows you to rotate the view of the current image in a counterclockwise direction.
 - **Rotate right:** allows you to rotate the view of the current image in a clockwise direction.

Assigning an Image as a Contact Icon

1. From the Home screen, tap  (Applications) →  (Gallery).
2. Select a folder location and tap a file to open it in the Image viewer.
3. With the image displayed, tap **Menu** → **More** → **Set as** → **Contact icon**.
4. Tap a contact to make a selection.
5. Crop the image and tap **Save**.

Assigning an Image as a Wallpaper

1. From the Home screen, tap  (Applications) →  (Gallery).
2. Select a folder location and tap a file to open it in the Image viewer.
3. With the image displayed, tap **Menu** → **More** → **Set as**.
4. Select one of the options:
 - **Contact icon**: assigns the current image as the icon for a specific contact.
 - **Home screen Wallpaper** assigns the current image to the home screen background. This image is spread across all available screens.
 - **Lock screen Wallpaper** assigns the selected image to the background for the lock screen.
5. Touch and drag the crop box anywhere on the picture.
Touch and drag the sides of the crop box to zoom in or out to create a cropped area.
6. Tap **Save** to assign the wallpaper image.
– or –
Tap **Cancel** to stop without updating the wallpaper image.

Using the Camcorder

In addition to taking photos, the camera also doubles as a camcorder that allows you to record, view, and send videos.

Note: The camera stores all videos on a microSD card only, so a card must be present in the phone before the camera will operate. To ensure the Camcorder can record the video, use an SDHC memory card.

Shooting Video

Tip: When shooting video in direct sunlight or in bright conditions, it is recommended that you provide your subject with sufficient light by having the light source behind you.

1. From the Home screen, tap  (Applications) →  (Camera) to activate the camera mode.
2. If necessary, tap the camera icon in the upper-right of the screen to toggle to the camcorder mode.

Note: To return to the camera mode tap the camcorder icon from the upper-right of the screen.

3. Using the phone's main display screen as a viewfinder, adjust the image by aiming the camcorder at the subject.
4. Press the record video key () to begin shooting video.

5. Touch  to pause the recording or touch  to stop the recording and save the video file to your Photo folder.
6. If the Review option is turned on (see General Settings below), the Preview screen appears. Tap **Play** to play your video for review.
7. Press  to return to the viewer.

Camcorder Options

Camcorder options are represented by icons along both sides of the screen.

Camcorder Options

The following camcorder options are available:



1. **Recording mode:** Normal or Limit for MMS.
2. **Flash:** selects whether the camcorder uses the flash for additional light while capturing video. Choose Off or On.
3. **Settings:** displays two types of settings, Camcorder () and General ().

Camcorder settings:

- **Timer:** allows you to set a time delay before the camcorder records the video (Off, 2 sec, 5 sec, or 10 sec). When you press the Camera key, the camcorder records the video after the specified time elapses.
- **Resolution:** sets the video resolution to: 320x240 or 176x144.
- **White balance:** allows you to set this option from the following choices: Auto, Daylight, Cloudy, Incandescent, or Fluorescent.
- **Effects:** allows you to change the color tone or apply special effects to the photo. Options include: Normal, Black and White, Negative, or Sepia.
- **Video quality:** allows you to set the video quality to: Superfine, Fine, or Normal.
- **Adjust:** allows you to adjust the Contrast, Saturation and Sharpness for this video.

General settings:

- **Guidelines:** displays alignment and framing guidelines to help compose your videos.

- **Audio recording:** selects whether audio is recorded with the video file.
 - **Review:** set to **On** to review the recorded video.
 - **Reset:** resets the camcorder settings to the default settings.
4. **Camcorder / Camera Mode:** allows you to switch between Camcorder and Camera mode. Once you change the mode, the corresponding indicator appears at the top left of the display.
 5. **Camcorder button:** records a video when pressed.
 6. **Quick view:** displays the video for quick viewing.

Video File Options

While viewing a video you have just taken, the following options are available.

- **Share:** allows you to share a picture using Bluetooth, Gmail, Messaging or YouTube.
- **Play:** plays the current video using the Video Player.
- **Delete:** deletes this video.

Accessing Videos

When you shoot a video, the file is saved in the Camera folder. You can view your videos immediately or view them anytime in the Camera folder.

1. From the Home screen, tap  (Applications) →  (Gallery).
2. Select a folder location and tap a video icon to begin video playback.
 - or –

Touch and hold the video icon from the main Gallery to select the video (green check mark) and display the following video menu context options:

 - **Share:** allows you to share a picture using Bluetooth, Email, Gmail, Messaging or YouTube.
 - **Delete:** allows you to delete chosen/selected videos. Touch the check mark, to turn it green, next to any file or folder you want to delete, then touch Delete.
 - **More:** provides you with the additional options:
 - **Details:** displays video file information.

Files

Files allows you to manage your sounds, images, videos, and other memory card data in one convenient location. This application allows you to launch a file if the associated application is available on your phone (e.g.: MP4).

- ▶ From the Home screen, tap  (Applications) →  (Files).

Note: Navigation in this viewer works on a hierarchy structure with folders, subfolders, etc.

Navigating File Folders

1. From the Home screen, tap  (Applications) →  (Files).
2. Tap a folder and scroll down or up until you locate your selected file.
 - **Up tab** allows you to return to a higher directory.
 - **Home tab** allows you to return to the root directory.
 - Press  and then tap **View by** to change the way the files are displayed on-screen. Choose from: **List**, **List and details**, or **Thumbnail**.
 - Press  for these additional options: **Share**, **Create folder**, **Delete**, **View by**, **List by**, and **More** (Move, Copy, Rename, Bluetooth visibility and Settings).
3. Once you have located your file, tap the file name to launch the associated application.

Note: The DCIM folder is the default location for pictures and video taken by the phone's camera and camcorder.

The Gallery

The Gallery is where you view photos and play back videos. For photos, you can also perform basic editing tasks, view a slideshow, set photos as wallpaper or caller image, and share in a picture message.

Note: If the phone displays a memory full message when accessing the Gallery, open **Files** and remove some of the media files from the folders, and then open the Gallery.

Opening the Gallery

- ▶ From the Home screen, tap  (Applications) →  (Gallery). For more information, refer to “Camera Gallery Options” on page 97.

Music

Playing Music

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap a tab to select the music category: **Artists**, **Albums**, **Songs**, or **Playlists**.
3. Scroll through the list and tap an entry to begin playback.
4. The following Music Player controls are available:

-  Pause the song.
-  Start the song after pausing.
-  Press and hold to rewind the song. Tap to go to previous song.
-  Press and hold to fast-forward the song. Tap to go to next song.
-  Displays your list of songs.
-  shuffles the current list of songs randomly.
-  songs play in order and are not shuffled.
-  Repeat off (plays songs only once).
-  Repeats the currently playing song.
-  Replays the current list when the list ends.

Note: The 5.1 channel sound effect works when earphones or sound is connected through the earphone port only.

Making a Song a Phone Ringtone

1. From the Home screen, tap  (Applications) →  (Music).

2. Tap the **Songs** tab.
3. Touch and hold a song from the list to reveal the on-screen context menu.
4. Tap **Set as phone ringtone**.

Music Player Options

The Music Player Settings menu allows you to set preferences for the music player such as whether you want the music to play in the background, sound effects, and how the music menu displays.

- ▶ With the music player application displayed, press  and select one of the following options:
 - **Library:** view your current audio library.
 - **Party shuffle on/off:** activates/deactivates the random song shuffle function.
 - **Add to playlist:** adds the selected music file to the current playlist or a new playlist.
 - **Settings:** allows you to activate or deactivate the 5.1 channel mode and select an available music equalizer configuration such as: Normal, Rock, Jazz, Classic, Dance, Pop, Live, Concert hall, Wide, Music clarity, Bass enhancement, or Externalisation.
 - **Set as ringtone:** sets the current song as your phone ringtone.
 - **Delete:** permanently deletes the current song from the SD card.

Using Playlists

Playlists are used to assign music files into groups for playback. These Playlists can be created using the Music player on this device, or using a third-party application (such as Windows Media Player) and downloading those files to an SD card inserted into the device.

Creating a Playlist

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap and hold the first song you want to add to the new playlist and select **Add to playlist** → **New** from the pop-up menu.
3. Enter a name for this playlist, then tap **Save**.

Adding Music to a Playlist

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Artists**, **Albums** or **Songs** tab.
3. Touch and hold a song title and select **Add to playlist**.
4. Tap the name of the playlist.

Removing Music from a Playlist

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Playlists** tab.
3. Tap the name of the playlist.
4. Touch and hold a song from the playlist to reveal the on-screen context menu.
5. Tap **Delete** → **OK**.

Editing a Playlist

Besides adding and removing music files in a playlist, you can also delete or rename the playlist.

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Playlists** tab.
3. Touch and hold a playlist entry to reveal the on-screen context menu.
4. To rename the playlist, tap **Rename**, enter a new name for this playlist and tap **Save** or to delete the playlist, tap **Delete**.

Transferring Music Files

Music files can be downloaded to the phone via a direct USB connection. Music files are stored into a Music folder on the SD card.

Removing Music Files

Deleting a Music File

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Songs** tab.
3. Touch and hold a song entry to reveal the on-screen context menu.
4. Tap **Delete** → **OK**. The music file is deleted.

Deleting an Album

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Albums** tab.
3. Touch and hold the album name to reveal the on-screen context menu.
4. Tap **Delete** → **OK**. The album is deleted.

Deleting an Artist

1. From the Home screen, tap  (Applications) →  (Music).
2. Tap the **Artists** tab.
3. Touch and hold the name of the artist to reveal the on-screen context menu.
4. Tap **Delete** → **OK**. All songs by the selected artist are deleted.

YouTube

YouTube is a video sharing website on which users can upload and share videos, and view them in MPEG-4 format.

1. From the Home screen, tap  (Applications) →  (YouTube).
2. Tap **Accept** to accept the Terms and Conditions.
3. When the screen loads you can search and view posted videos.
4. Press  → **Settings** → **High quality on mobile** if you prefer high quality output.

Section 9: Applications

This section outlines the various applications that are available on your phone.

Applications

The Applications list provides quick access to all the available applications on the phone.

Refer to the application table on page 29 for a description of each Application, its function, and how to navigate through that particular application. If the application is already described in another section of this user manual, then a cross reference to that particular section is provided.

Calculator

Using this feature you can use the phone as a calculator. The calculator provides the basic arithmetic functions; addition, subtraction, multiplication, and division. You can also use this as a scientific calculator.

1. From the Home screen, tap  (Applications) →  (Calculator).
2. Enter the first number using the numeric keys.
3. Enter the operation for your calculation by touching the **Plus**, **Minus**, **Multiplication**, or **Division** key.

4. Enter the next number.
5. To view the result, tap the = (**equals**) key.
6. Repeat steps 1 to 4 as many times as required.
7. Press  and tap **Advanced panel** to reveal additional scientific functions.

Calendar

With the Calendar feature, you can consult the calendar by day, week, or month; create events; and set alarms to act as reminders. Google Calendar is built into the phone and synchronizes both new and existing entries between your phone and your online Google account.

Important! You must have previously added an account (Facebook, Microsoft Exchange ActiveSync, or Google) prior to using the Calendar.

1. From the Home screen, tap  (Applications) →  (Calendar).
2. Press  and select one of the following options:
 - **Day**: displays the Day view.
 - **Week**: displays the Week view.

- **Month:** displays the Month view (default view).
- **Agenda:** displays events for the selected Month, Week, or Day.
- **Today:** displays the current date highlighted with a Blue box.
- **More:** allows you to select additional options such as: Create, Go to, Calendars, and Settings.
 - **Create:** creates a new Event.
 - **Go to:** displays a specific date.
 - **Calendars:** accesses the My calendars feature, where you can select which calendars are synced.
 - **Settings:** displays a list of configurable settings.

To manually sync calendar events:

1. Press  →  and then tap  → **Accounts and sync**.
2. Locate the account containing the events you wish to synchronize.
3. Tap  within the adjacent account field to reveal the account's synchronization settings screen.
4. Tap **Sync Calendar** to activate the synchronization of calendar events between your device and the remote server. A green checkmark indicates the feature is enabled.

Camera

Use your 3.0 megapixel camera feature to produce photos in a JPEG format.

Note: An SD card must be inserted before the Camera will take and store photos.

- ▶ From the Home screen, tap  (**Applications**) →  (**Camera**).

For more information, refer to “Using the Camera” on page 94.

Clock

Here you can set alarms, view a slideshow, or access the music player. Icons for the applications display at the bottom of the screen and are quickly accessed with the touch of a finger. For more information, refer to “Clock” on page 135.

- ▶ From the Home screen, tap  (**Applications**) →  (**Clock**).

Contacts

The default storage location for saving phone numbers to your Contacts List is your phone's built-in memory.

For more information, refer to “Contacts List” on page 65.

Downloads

The Downloads application allows you to manage all of your downloads from the Market and the Browser.

1. From the Home screen, tap  (Applications) → Downloads . All of your downloads are listed.
2. Tap the **Internet Downloads** tab to see all of the downloads you have made from the Browser.
3. Tap the **Other Downloads** tab to see all other downloads.
4. Tap  → **Sort by size** to see your downloads sorted in size order.
5. Tap  → **Sort by time** to see your downloads sorted in time order.

Email

Email enables you to review and create email using most email services. The device alerts you when you receive an email message.

- ▶ From the Home screen, tap  (Applications) →  (Email).

For more information, refer to “Email” on page 86.

Files

Organize and store data, images, and more in your own personal file folders. Files are stored to the memory card in separate (user defined) folders.

- ▶ From the Home screen, tap  (Applications) →  (Files).

For more information, refer to “Files” on page 101.

Gallery

The Gallery is where you view photos and play back videos. For photos, you can also perform basic editing tasks, view a slideshow, set photos as wallpaper or caller image, and share as a picture message.

- ▶ From the Home screen, tap  (Applications) →  (Gallery).

For more information, refer to “The Gallery” on page 102.

Gmail

Gmail (Google Mail) is a web-based email service. Gmail is configured when you first set up your phone. Depending on your synchronization settings, Gmail can automatically synchronize with your Gmail account on the web.

For more information, refer to “Using Gmail” on page 91.

Google+

Google+ (Google Plus) is a social networking and identity service operated by Google Inc.

Google Search

Google Search is a web-based search engine that uses text-based queries to search for content on web pages.

- ▶ Press  to launch the Google Search box and enter the search text.

– or –

Touch the microphone on the Google Search bar and say the search information. For more information, refer to “Search Key” on page 23. For more information, refer to “Using Google Search” on page 23.

Internet

Opens the browser to start surfing the web. The browser is fully optimized and provides advanced functionality to enhance the Internet browsing feature on your phone.

- ▶ From the Home screen, tap  (Applications) →  (Internet).

For more information, refer to “Internet” on page 121.

Latitude

Google Latitude allows you and your friends share locations and status messages with each other. It also lets you send instant messages and emails, make phone calls, and get directions to your friends’ locations.

1. From the Home screen, tap  (Applications) →  (Latitude).

The device automatically joins Latitude.

2. Select  → **Select from Contacts** or **Add via email address**.
3. Select a friend you want to add, or enter an email address and select Add friends.
4. Select **Yes**.

When your friend accepts your invitation, you can share locations.

Latitude Options

- ▶ From the map display, press  to display the following options:
 - **Search:** allows you to search for a place of interest.

- **Directions:** displays navigation directions to a location from a starting point.
 - **Clear Map:** allows you to remove all markings and layers from the map.
 - **More:** allows you to view the following:
 - **Map:** displays the map view.
 - **Places:** opens Google Places (see “Places” on page 115).
 - **Navigation:** opens Google Map Navigation (see “Navigation” on page 113).
 - **Latitude:** lets you find family and friends.
 - **Location history:** lets you store your location history and charts various statistics.
 - **My Places:** allows you to see locations you have marked as favorites. Press and hold on a location and when the screen displays with the address, tap the star in the upper-right corner. It will be listed in your Starred Places.
 - **Settings:**
 - **Cache Settings:** allows you to set options to pre-fetch map tiles when not using WiFi and to clear the cache that holds the map tiles.
 - **Location Settings:** allows you to set options for location reporting, history, location sharing, and check-ins.
 - **Labs:** this is a testing ground for experimental features that aren't ready for prime time. They may change, break or disappear at any time. Click on a Lab to enable or disable it.
 - **Terms, Privacy & Notices:** displays the Terms and Conditions, Privacy Policy, or Legal Notices information. Select the desired information from the pop-up menu.
 - **About:** displays general information about Google maps such as Version, Platform, Locale, Total data sent, Total data received, Free memory, etc.
5. **Help:** displays the Google Mobile Help web page where you can receive help on Google Maps.

Maps

Google Maps allow you to track your current location, view real-time traffic issues, and view detailed destination directions. There is also a search tool included to help you locate places of interest or a specific address. You can view locations on a vector or aerial map, or you can view locations at the street level.

Important! Before using Google Maps you must have an active data (3G) or Wi-Fi connection.

Note: The Maps application does not cover every country or city.

- From the Home screen, tap  (Applications) →  (Maps).

Enabling a Location source

Before you use Google Maps to find your location or search for places of interest, you must enable a location source. To enable the location source you must enable connection to a wireless network and/or GPS satellites.

Important!: The more location determining functions are enabled, the more accurate the determination of your position.

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Use wireless networks** to enable location determination using nearby cell towers.
3. Tap **Use GPS satellites** to enable location determination using GPS satellites.

Tip: Location determination using GPS satellites is more accurate than using cellular towers but requires a clear view of the sky and uses more battery power.

Opening Maps

1. From the Home screen, tap  (**Applications**) →  (**Maps**).

2. Icons in the top row of the application access the following options:
 - **Search Maps:** allows you to search for a place of interest.
 - **Layers:** allows you to switch map views:
 - **Traffic:** (available only in selected areas) Real-time traffic conditions are displayed over roads as color-coded lines.
 - **Satellite:** displays Google Earth satellite image. Satellite images are not real-time.
 - **Terrain:** displays a topographical view of the terrain around the current map location.
 - **Transit Lines:** adds transit lines to your map.
 - **Latitude:** allows you to see your friend's locations and share your location with them.
 - **My Maps:** displays a list of your preferred maps.
 - **Bicycling:** adds cycling trails to your map.
 - **Wikipedia:** displays any Wikipedia markers and info on your map. **My Location:** when touched, shows your current location on the map with a blinking blue dot.
 - **My Location:** when touched, the location displays on the map with a blinking blue dot.
3. Press  and select one of the following options:
 - **Search:** allows you to search for a place of interest.
 - **Directions:** displays navigation directions to a location from a starting point.

- **Clear Map:** after viewing or following directions, this option resets the map.
- **More:** allows you to view the following:
 - **Map:** displays the map view.
 - **Places:** opens Google Places (See “Places” on page 115).
 - **Navigation:** opens Google Map Navigation (See “Navigation” on page 113).
 - **Latitude:** lets you find family and friends.
 - **Location history:** lets you store your location history and charts various statistics.
- **Settings:**
 - **Cache Settings:** allows you to set options to pre-fetch map tiles when not using WiFi and to clear the cache that holds the map tiles.
 - **Location reporting:** allows you to set options for location reporting, history, location sharing, and check-ins.
 - **Labs:** this is a testing ground for experimental features that aren't ready for prime time. They may change, break or disappear at any time. Click on a Lab to enable or disable it.
 - **Terms, Privacy & Notices:** displays the Terms and Conditions, Privacy Policy, or Legal Notices information. Select the desired information from the pop-up menu.
 - **About:** displays general information about Google maps such as Version, Platform, Locale, Total data sent, Total data received, Free memory, etc.
- **Help:** displays the Google Mobile Help web page where you can receive help for Google Maps.

Memo

This feature allows you to create memos that can be retrieved at a later time.

1. From the Home screen, tap  (Applications) →  (Memo).
2. Tap **Create memo**.
 - or –
 - Press  and then tap **Create**.
3. Compose the memo and touch **Save**.
4. Before you save your new memo, you can also press  and adjust the memo's background color.

For more information, refer to “Text Input Methods” on page 54.

Memo options

While viewing the list of Memos, press  and select one of the following options:

- **Create:** allows you to create a memo.
- **Maximize:** maximizes the amount of the memo displayed on the phone's screen.
- **Delete:** allows you to delete one or more memos.
- **Search:** allows you to search within the current set of memos.

To send a memo to someone else, touch and hold the memo in the memo list, select **Send via** and choose the method to send this memo: **Bluetooth**, **Email** or **Messaging**.

Messenger

Messenger allows you to bring groups of friends together into a simple group conversation. When you get a new conversation in Messenger, Google+ sends an update to your phone.

For more information, refer to “*Messenger*” on page 93.

Music

Music Player allows you to play music files that you have stored on your microSD card. You can also create playlists.

- ▶ From the Home screen, tap  (Applications) →  (Music).

For more information, refer to “*Music*” on page 102.

Navigation

Google Maps Navigation (Beta) is an internet-connected turn-by-turn, GPS navigation system with voice guidance.

Caution! Traffic data is not real-time and directions may be wrong, dangerous, prohibited, or involve ferries.

Important! To receive better GPS signals, avoid using your device in the following conditions:

- inside a building or between buildings
 - in a tunnel or underground passage
 - in poor weather
 - around high-voltage or electromagnetic fields
 - in a vehicle with tinted windows
-

- ▶ From the Home screen, tap  (Applications) →  (Navigation).

Enabling GPS Location

1. Press  →  and then tap  (Settings) → **Location and security**
2. Tap **Use wireless networks**. A green check mark indicates the GPS location feature has been enhanced by using Wi-Fi and/or mobile networks to increase accuracy.
3. Tap **Use GPS satellites**. A green check mark indicates the GPS location feature is enabled.

Navigation options

1. From the Home screen, tap  →  (Navigation).
2. Read the on-screen disclaimer and tap **Accept**.
3. Choose from the following on-screen options:


- **Driving/Walking:** configures the method of travel.
 - Driving mode enables the **Settings** feature that allows you to configure your Route options: **Avoid highways** or **Avoid tolls**.
- **Map:** enables the on-screen real-time map functionality.
- **Speak destination:** allows you to use the voice recognition feature to search for matching locations in your area.
- **Type destination:** allows you to manually enter a destination address (via the on-screen keypad).
- **Contacts:** allows you to receive turn-by-turn directions to the address stored for a selected Contacts entry.
- **Starred places:** allows you to obtain directions to locations that have been starred within Google maps (maps.google.com).

Navigation Map options

From the map screen, press  to access the following features:

- **Set Destination:** lets you choose a destination: Speak Destination, Type Destination, Contacts, or Starred Places.

- **Search:** manually search for a destination address, place, name of business, or even a type of business.
- **Layers:** allows you to switch map views:



- **Traffic view:** (available only in selected areas) Real-time traffic conditions are displayed over roads as color-coded lines. Each color represents how fast the traffic is moving.
- **Satellite:** Maps uses the same satellite data as Google Earth. Satellite images are not real-time. Google Earth acquires the best imagery available, most of which is approximately one to three years old.
- **Parking:** displays parking information relative to your current location.
- **Gas stations:** displays gas station location relative to your current location.
- **ATMs & banks:** displays ATM and Bank locations relative to your current location.

- **Restaurants:** displays restaurant and eatery locations relative to your current location.
- **Mute:** allows you to mute the audio readout and directional information.
- **Exit navigation:** terminates the application.
- **More:** provides additional application information: Help and Terms, Privacy & Notices.

Caution!: Navigation is a beta product.

News & Weather

You can get weather, news, sports and entertainment information from the web.

1. From the Home screen, tap  (Applications) → **News & Weather**.
2. Drag the screen left or right to view the categories at the top of the screen. Touch a headline to open the associated story.

Places

Google Places displays company locations on a layer of Google Maps. When viewing an area you can quickly locate a business or person, find out more information about the business, see coupons, public responses, and more.

1. From the Home screen, tap  (Applications) →



(Places).

2. Use the **Find places** field to manually enter a desired place or choose from among the various categories. Matches are filtered by those closest to your current location.
3. Locate and tap one of the listed places (Restaurants, Cafes, Bars, Attractions, Entertainment, ATMs, Gas stations, Hotels, Post office, Taxi. A list of places within this category displays.
4. Tap the Maps icon (upper-right) to launch the related maps feature.

Play Books

With Google Play Books, you can find more than 3 million free e-books and hundreds of thousands more to buy in the eBookstore.

1. From the Home screen, tap  (Applications) →  (Play Books).
2. Log on to your Google account.
3. Follow the on-screen instructions for using the Play Books application.

Play Store

Google Play (formerly Android Market) provides access to downloadable applications, games, books and movies to install on your phone.

Accessing the Market

1. From the Home screen, tap  (Applications) →  (Play Store).
2. If not already logged in with your Google account, tap **Next**, Tap **Sign in** and enter your Google account information.
3. Tap **Accept** to agree to the terms of service.

Downloading a New Google Application

Google Play provides several ways to find applications. The home page provides links to Apps (applications), Games, Books and Movies.

1. From the Home screen, tap  (Applications) →  (Play Store) → **Apps**.
2. Browse through the categories, find an application you're interested in, and tap the name to view the description.
3. Tap **Download (for free items)** or the button indicating the price.

Important! If the selected application requires access to data or control of a function on your phone, Market displays the information the application will access.

Touch **OK** if you agree to the conditions of the application. Once you touch **OK** you are responsible for using this application on the phone and the amount of data it uses. Use with caution.

Note: Use caution with applications that request access to any personal data, functions, or significant amounts of data usage times.

4. If prompted, follow the on-screen instructions to pay for the application.
5. Check the progress of the current download by opening the Notifications panel.

6. After the item is downloaded and installed on your phone, the content download icon  appears in the notification area of the status bar.

The newly downloaded application displays on the Home screen or other selected panel.

Note: A data plan is required to use this feature. Charges may apply. Please contact your service provider for further details.

Launching an Installed Application

1. From the Home screen, tap  (Applications).
2. Tap the newly installed application. This application is typically located on the last Applications page.

Unknown sources

This feature allows the installation of applications from locations other than Play Store and is typically used for Android application development.

Press  →  and then tap  (Settings) → Applications → **Unknown sources**.

A green check mark indicates that apps can be downloaded from sources other than Play Store.

Samsung Apps

Samsung Apps allows you to easily download useful applications to your phone and to keep them updated. Featuring a wealth of games, news, reference, social networking, widgets, health related applications, and more, Samsung Apps gives you instant access to a huge selection of mobile experiences.

- To use Samsung Apps, your phone must be connected to the internet using a cellular connection or Wi-Fi.

1. From the Home screen, tap  (Applications) → **Samsung Apps**.
2. Search for and download applications as required.

Note: This feature might not be available in your region. For details, visit www.samsungapps.com.

All Samsung Apps applications are made available to you subject to the Samsung Apps Terms and Conditions (<http://www.samsungapps.com/common/term.as>) and Samsung Account Terms and Conditions (<http://www.samsungapps.com/common/terms4account.as>). Please read through these and ensure you understand the basis on which these applications are provided to you. Samsung may collect personal information from you in order to deliver the applications to your device. This is done in accordance with the Samsung Apps privacy policy

(<http://www.samsungapps.com/common/privacy.as>). In order to receive any of the applications, you must select the “Accept” button indicating that you agree to the terms and conditions and the use of your personal data in accordance with the privacy policy.

Note: You might incur additional charges when accessing the internet or downloading applications.

Note: Available applications, widgets, and updates might differ depending on your region.

Settings

This icon navigates to the settings menus for your phone.

- ▶ From the Home screen, tap  (Applications) →



– or –

Press  →  and then tap  (Settings).

For more information, refer to “*Changing Your Settings*” on page 137.

Talk

You can instant message with Google Talk. Google Talk allows you to communicate with other people who are also connected with Google Talk on the phone or on the web.

- ▶ From the Home screen, tap  (Applications) →  (Google Talk).

For more information, refer to “*Google Talk*” on page 93.

Task Manager

Sometimes your phone might seem to slow down over time, and the biggest reason for this are background applications. These are applications that are active but minimized. The Task Manager lets you see which applications are active in the background and lets you choose which applications are left running and which are closed.

Shutting Down Applications

- ▶ From the Home screen, tap  (Applications) →  (Task Manager).

– or –

Press and hold  then tap **Task manager**. This screen contains the following tabs:

- **Active applications** display those currently active applications running on your phone.
- **Downloaded** displays any installed packages or applications from the Market that are taking up memory space. Tap **Uninstall** to remove them from your phone.
- **RAM**, displays the amount of RAM (Random Access Memory) currently being used and allows you to **Clear Memory**.

- **Storage** displays a visual graph indicating the available and used space within the internal System storage and external SD card.
 - **Help** provides additional battery saving techniques.
3. From the **Active applications** tab, tap **End** to close selected applications or tap **End all** to close all background running applications.

Voice Recorder

The Voice Recorder allows you to record an audio file for later playback. You can also send it as a message.

1. From the Home screen, tap  (**Applications**) →  (**Voice Recorder**).
2. Tap the **Record** icon to record an audio file.
3. Tap **Stop** to stop recording. The file automatically saves to the Voice list.
4. To share this audio file, press , tap **Share** and select a delivery method: Bluetooth, Email, Gmail or Messaging.

Voice Search

The Voice Search feature is a voice-activated application that allows you to speak search terms that the phone uses to perform a Google search.

For more information, refer to “Using Additional Voice Search Functions” on page 23.

1. From the Home screen, tap  (**Applications**) →  (**Voice Search**).
2. Tap **Speak now** and speak your search terms slowly and clearly. Google searches for the information and displays related information in the browser.

YouTube

YouTube is a video sharing website on which users can upload and share videos, and view them in MPEG-4 format.

1. From the Home screen, tap  (**Applications**) →  (**YouTube**).
2. When the screen loads you can begin searching and viewing posted videos.

To configure YouTube Settings:

- ▶ Press  → **Settings** and configure the following parameters:
 - **High quality on mobile**, when enabled, allows you to start all videos in high quality mode while you are connected to a mobile network.

- **Caption front size** allows you to set the font size used by on-screen captions. Choose from: Small, Medium, Large, or Extra Large.
- **Clear search history** allows you to clear any previous YouTube searches from appearing within the search box.
- **SafeSearch filtering** allows you to configure block settings for videos containing restricted content. This option blocks these videos from appearing within your search results. Choose from: Don't filter, Moderate, or Strict blocking.
- **Help** provides answers to most YouTube questions.
- **Feedback** allows you to provide user feedback to YouTube.
- **Google Mobile Terms of Service**
- **YouTube Terms of Service**
- **Google Mobile Privacy Policy**
- **YouTube Privacy Policy**
- **Application version** displays the software version for the current YouTube application.

To watch a high quality video:

- ▶ While playing a video, press  → **Settings** → **High quality on mobile**.

Section 10: Connections

Your phone is equipped with features that allow you to quickly connect to the web.

Internet

Your phone is equipped with an Internet browser to navigate the mobile web. This section explains how to navigate the browser and use the basic features.

Accessing the Internet

To access the Browser:

- ▶ From the Home screen, tap  (Applications) →  (Internet).

Entering a URL

You can access a website quickly by entering the URL. Websites are optimized for viewing on your phone.

To enter a URL and go to a particular website:

- ▶ Tap the **URL** field at the top of the screen, enter the URL and tap **Go**.

Navigating with the Browser

1. To select an item, touch an entry.

2. To scroll around on a website, sweep the screen with your finger in a vertical or horizontal motion.
3. To return to the previous page, press .

Browser Options

1. With a web page open, press  to access the following options:
 - **New window:** displays a new window so you can browse multiple URLs. For more information, refer to “*Adding and Deleting Windows*” on page 122.
 - **Windows:** displays a list of the windows you have open.
 - **Refresh:** reloads the current page.
 - **Forward:** forwards the browser to another web page.
 - **Add bookmark:** allows you to add a URL to your bookmark list.
 - **More:** displays the following additional options:
 - **Add shortcut to Home:** adds a shortcut to your web2go homepage on your phone’s Home screen.
 - **Add RSS feeds:** adds RSS feeds to your browser.
 - **Find on page:** allows you to search in the current page.
 - **Page info:** displays information about the selected page.

- **Share page:** allows you to share the page using Gmail or as a message.
- **Downloads:** displays the download history.
- **Settings:** allows you to change the way you view your web pages by changing these options. See “Browser Settings” on page 124.

Search the Internet

To perform an internet search using keywords:

1. Tap the **URL** field, enter the keyword(s) to search using the on-screen keypad (When entering the keyword(s) to search in the URL field, Google works as a default search engine).
2. Tap **Go**. A list of search results displays.
3. Tap a link to view the website.

Adding and Deleting Windows

You can have up to eight Internet windows open at one time. To add a new window, follow these steps:

1. From your browser, press  and then tap **New Window**.
– or –
Press  and then tap **Windows** → **New Window**.
2. A new browser window displays.

3. Press  and then tap **Windows** to see a list of all open windows.

Note: This icon will display a number that corresponds to the current number of active browser windows,

4. Scroll across the screen to view the currently active windows and tap an entry to launch the selected Internet window.
5. Tap  next to the listing to close the window.

Using Bookmarks

While navigating a website, you can bookmark a site to quickly and easily access it at a future time. The URLs (website addresses) of the bookmarked sites display in the Bookmarks page. From the Bookmarks page you can also view your Most visited websites and view your History.

1. On the browser screen, tap . The **Bookmarks** page displays. Additional pages include **Most visited** and **History**.
2. Press  to display the following options:
 - **Bookmark last-viewed page:** Creates a new bookmark for the last webpage that you viewed.

- **List/Thumbnail view:** Select **Thumbnail view** (default) to view a thumbnail of the webpage with the name listed, or select **List view** to view a list of the bookmarks with Name and URL listed.
 - **Create folder:** Creates a new folder in which to store new bookmarks.
3. Tap a bookmark to view the webpage, or touch and hold a bookmark for the following options:
 - **Open:** Opens the webpage of the selected bookmark.
 - **Open in new window:** Opens the webpage in a new window.
 - **Edit bookmark:** Allows you to edit the name or URL of the bookmark. For more information, refer to “*Editing Bookmarks*” on page 123.
 - **Add shortcut to Home:** Adds a shortcut to the bookmarked webpage to your phone’s Home screen.
 - **Share link:** Allows you to share a URL address via Bluetooth, Email, Gmail, or Messaging.
 - **Copy link URL:** Allows you to copy the URL address to use in a message.
 - **Delete bookmark:** Allows you to delete a bookmark. For more information, refer to “*Deleting Bookmarks*” on page 123.
 - **Set as homepage:** Makes the bookmark your homepage.

Adding Bookmarks

1. On the browser screen, tap  → **Add**.

2. Use the on-screen keypad to enter the name of the bookmark and the URL.
3. Assign a folder location. **Home** is the default.
4. Tap **OK**. The new save page now appears on the Bookmarks page.

Editing Bookmarks

1. From the Bookmarks page, touch and hold the bookmark you want to edit.
2. Tap **Edit bookmark**.
3. Use the on-screen keypad to edit the name of the bookmark or the URL.
4. Tap **OK**.

Deleting Bookmarks

1. From the Bookmarks page, touch and hold the bookmark you want to delete.
2. Tap **Delete bookmark**.
3. At the confirmation window, tap **OK**.

Emptying the Cookies

A cookie is a small file placed on your phone by a visited website. In addition to containing some site-specific information, a cookie can also contain some personal information (such as a username and password) which might pose a security risk if not properly managed. You can clear cookies from your phone at any time.

1. On the browser screen, press  and then tap **More** → **Settings** → **Clear all cookie data**.
2. Tap **OK** to delete the cookies or tap **Cancel** to exit.

Using Internet History

The History list displays a list of the most recently viewed websites. These entries can be used to return to previously unmarked web pages.

1. On the browser screen, tap  → **History** tab.
A list of the most recently viewed websites displays.

2. Tap an entry to display the webpage.

– or –

Press  and then tap **Clear history** to delete the current History list.

Using Most Visited

The Most visited list provides you with a list of the most visited websites. These entries can be used to return to previously unmarked web pages.

1. From the Home webpage, tap  → **Most visited** tab.

A list of your most frequently visited webpages displays, starting with the most frequently visited site.

Tap any entry to display the selected webpage.

Browser Settings

To configure browser settings:

1. From the Home screen, tap  (**Applications**) →  (**Internet**).
2. Press  and then tap **More** → **Settings**.
3. Choose from the following on-screen options:
 - **Default zoom:** Adjusts the zoom feature. Set to Far, Medium, or Close.
 - **Open pages in overview:** Displays an overview of newly opened web pages.
 - **Text encoding:** Adjusts the current text encoding.

- **Block pop-up windows:** Prevents popup advertisements or windows from appearing on-screen. Remove the check mark to disable this function.
- **Load images:** Allows web page images to load along with the text components of a website.
- **Auto-fit pages:** Allows web pages to be resized to fit as much of the screen as possible.
- **Landscape view only:** Displays the browser in only the horizontal position.
- **Enable JavaScript:** Enables javascript for the current Internet page. Without this feature, some pages may not display properly. Remove the checkmark to disable this function.
- **Open in background:** New pages are launched in a separate page and displayed behind the current one. Remove the checkmark to disable this function.
- **Set home page:** Sets the current home page for the Internet browser.
- **Default storage:** Sets the default file storage location.
- **Clear cache:** Deletes all currently cached data. Tap **OK** to complete the process.
- **Clear history:** Clears the browser navigation history. Tap **OK** to complete the process.
- **Accept cookies:** Allows sites to save and read cookies from your device.
- **Clear all cookie data:** Deletes all current browser cookie files.
- **Remember form data:** Allows the device to store data from any previously filled out forms. Remove the checkmark to disable this function.
- **Clear form data:** Deletes any stored data from previously filled out forms. Tap **OK** to complete the process.
- **Enable location:** Allows websites to request access to your location.
- **Clear location access:** Clears location access for all websites. Tap **OK** to complete the process.
- **Remember passwords:** Stores usernames and passwords for visited sites. Remove the checkmark to disable this function.
- **Clear passwords:** Deletes any previously stored usernames or passwords. Tap **OK** to complete the process.
- **Show security warnings:** Notifies you if there is a security issue with the current website. Remove the checkmark to disable this function.
- **Select search engine:** Allows you to choose a default search engine for your phone. Choose from: **Google**, **Yahoo!**, or **Bing**.
- **Website settings:** View advanced settings for individual websites.
- **Reset to default:** Clears all browser data and resets all settings to default.

Bluetooth

About Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds, computers, printers, and wireless devices. The Bluetooth communication range is usually up to approximately 30 feet.

Turning Bluetooth On and Off

To turn Bluetooth on:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Bluetooth settings**.
2. Tap the **Bluetooth** field to activate the feature (checkmark indicates active). When active,  displays in the Status area.

To turn Bluetooth off:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Bluetooth settings**.
2. Tap the **Bluetooth** field to deactivate the feature (remove checkmark).

Bluetooth Status Indicators

The following icons show your Bluetooth connection status at a glance:



Displays when Bluetooth is active.



Displays when Bluetooth is connected (paired) and communicating.

Bluetooth Settings

The Bluetooth settings menu allows you to set up many of the characteristics of your device's Bluetooth service, including:

- Entering or changing the name your device uses for Bluetooth communication and description
- Setting your device's visibility (or "discoverability") for other Bluetooth devices
- Displaying your device's Bluetooth address

To access the Bluetooth Settings menu:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Bluetooth settings**.
2. Verify Bluetooth is active. Indicated by a green check mark in the Bluetooth field.

To change your Bluetooth name:

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap **Device name**.
3. Enter a new name.
4. Tap **OK** to complete the rename process.

To make your phone discoverable:

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, tap **Discoverable**.

Making your device discoverable allows other devices to pair and communicate.

Note: Your device is visible for up to 120 seconds (2 minutes). This value appears as a countdown within this field.

To scan for Bluetooth devices:

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap **Scan devices** to search for visible external Bluetooth-compatible devices such as headsets, devices, printers, and computers.

Pairing Bluetooth Devices

The Bluetooth pairing process allows you to establish trusted connections between your device and another Bluetooth device. When you pair devices, they share a passkey, allowing for fast, secure connections while bypassing the discovery and authentication process.

Note: Pairing between two Bluetooth devices is a one-time process. Once pairing is established the devices continue to recognize their partnership and exchange information without entering a passcode.

To pair your device with another Bluetooth device:

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap **Discoverable**.
Your device must be discoverable to successfully pair with an external device.
3. Tap **Scan devices**. Your device displays a list of discovered in-range Bluetooth devices.
4. Tap a device from the list to initiate pairing.
5. Enter the passkey or PIN code, if needed, and tap **OK**.
6. The external device must accept the connection and enter your device's PIN code.

Once successfully paired to an external device,  displays in the Status area.

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth-compatible devices.

Disconnecting a Paired Bluetooth Device

Disconnecting a paired device breaks the connection between the device and your phone, but retains the knowledge of the pairing. At a later point when you wish to reconnect the device, there is no need to setup the connection information again.

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, touch the previously paired device (from the bottom of the page).
3. Tap **OK** to confirm disconnection.
– or –

From the Bluetooth settings page, touch and hold the name of the previously paired device, and select **Disconnect**.

Note: Disconnections are manually done but often occur automatically if the paired device goes out of range of your phone or it is powered off.

Deleting a Paired Bluetooth Device

Deleting or “unpairing” a device from your list removes its connection record and reconnection will require that you re-enter all the previous pairing information.

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, touch and hold the name of the previously paired device (from the bottom of the page). This opens the connected device’s menu options.
3. Tap **Unpair** to delete the paired device.

Sending Contacts via Bluetooth

Depending on your paired devices’ settings and capabilities, you may be able to send pictures, contact information, or other items using a Bluetooth connection.

Note: Prior to using this feature, Bluetooth must first be enabled on both your phone and the external device, and the recipient’s device must be visible.

Only a Contact’s information can be sent via Bluetooth. No other file type (video, image, or audio) can be sent using Bluetooth.

1. Verify your Bluetooth is active and your phone is visible.
2. From the Home screen, tap  (**Contacts**).

3. Touch and hold the entry from the list to display the on-screen context menu.
4. Tap **Send namecard via** → **Bluetooth** and select a paired external Bluetooth device.

Note: The external Bluetooth device must be visible and communicating for the pairing to be successful.

5. A Bluetooth share notification displays in your notifications list.

Enable Downloading for Internet Applications

Important! Before you can download a web application you must insert a microSD card into the phone and enable the **Unknown sources** feature (enables downloading). For more information, refer to “Installing the microSD Memory Card” on page 4. Also, see “Mounting an SD Card” on page 38.

1. Press  →  and then tap  (**Settings**) → **Applications**.
2. Tap the **Unknown sources** check box.
3. Tap **OK** to allow install of non-Market applications.
Tap again to remove the checkmark and disable the installation of non-market applications.

Warning! Not all web applications are safe to download. In order to protect your phone and data, use Android Market to install web applications. For more information, refer to “Downloading a New Google Application” on page 116.

PC Connections

You can connect your device to a PC using an optional PC data cable using various USB connection modes. Mass storage is the default connection method.

Mass storage: allows you to use the onboard storage capacity of the phone to store and upload files. This option allows your computer to detect the phone as a removable storage drive.

Connecting as a Mass Storage Device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can also access the files directory from the memory card by using the device as a memory card reader.

Note: The file directory of the memory card displays as a removable disk, separate from the internal memory.

1. Insert a memory card into the device to transfer files from or to the memory card.
2. Press  to return to Idle mode.

3. Connect the multifunction jack on your device to a PC using an optional PC data cable.
A pop-up window displays on the PC when connected.
4. Open the folder to view files.
5. Copy files from the PC to the memory card.

Enabling USB Debugging

USB debugging is intended for development purposes.

1. Press  →  and then tap  (**Settings**) → **Applications** → **Development**.
2. Tap the **USB debugging** field to place a check mark in the selection box.

Wi-Fi

About Wi-Fi

Wi-Fi (short for "wireless fidelity") is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to an existing and accessible Wireless Access Point (WAP). A WAP can either be Open (unsecured) or Secured (requiring knowledge of the router name and password).

Activating Wi-Fi

By default, your device's Wi-Fi feature is turned off (deactivated). Activating Wi-Fi allows your device to discover and connect to compatible in-range WAPs (Wireless Access Points).

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Tap **Wi-Fi** to activate the feature. A checkmark indicates that Wi-Fi is active. The device scans for available in-range wireless networks and displays them under Wi-Fi networks on the same screen.

Connecting to a Wi-Fi Network

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.

The network names and security settings of detected Wi-Fi networks display in the Wi-Fi networks section.

2. Tap the network you wish to connect to.

Note: When you select an open network you are automatically connected.

3. Enter a wireless password (if necessary).

Manually Add a New Network Connection

1. Tap **Add Wi-Fi network**.
2. Enter the Network SSID (the name of your Wireless Access Point).
3. Tap the **Security** field and select a security option. This must match the current security setting on your target WAP.
4. Enter your WAP's password if the WAP is secure.
5. Tap **Save** to store the new information and connect to the target WAP.

Note: No prompt to enter the WAP key displays if you have previously connected to the wireless network. The WAP key is required when the device is reset using factory default settings.

Deactivating Wi-Fi

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Tap the **Wi-Fi** field to deactivate the feature. The checkmark grays.

Note: Use of wireless data connections such as Wi-Fi and Bluetooth can reduce battery life and use times.

Manually Scan for a Wi-Fi Network

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Press  and then tap **Scan**.

Wi-Fi Status Indicators

The following icons indicate the Wi-Fi connection status:



Displays when Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP).



Displays when Wi-Fi is active and there are open networks available.

Wi-Fi Advanced Settings

The Wi-Fi settings - Advanced menu allows you to set up many of the device's Wi-Fi services, including:

- Setting the Wi-Fi sleep policy
- Viewing the device's MAC Address
- Configuring use of either a DHCP or Static IP

To access the Wi-Fi Advanced Settings menu:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.

2. Press  and then tap **Advanced**.

Mobile AP

This feature allows you to turn your phone into a Wi-Fi hotspot. The feature works best when used in conjunction with 3G data services.

Important! The Mobile AP service can not be active at the same time as Wi-Fi. Close your Wi-Fi connection prior to launching the Mobile AP service.

To activate the Mobile AP service:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Tethering and portable hotspot**.
2. Tap **Mobile AP settings** → **Mobile AP** to activate the service (indicated by a green checkmark in the selection field).
3. Tap **Configure mobile AP** to continue with the setup process.
4. Enter a Network SSID name. The default is **AndroidAPxxxx**.
5. Select a security option (Open or WPA2 PSK)
6. Confirm the Mobile AP service icon  appears at the top of the screen.

Note: By default, the connection is open and not secured. It is recommended that you access the Mobile AP settings and create a secure connection by using a password for communication.

Note: Using your 3G service and Mobile AP Hotspot drains your phone's battery at a much faster rate than when using any other feature combination. The best way to keep using the phone as a hotspot is to have it connected to a power supply.

To connect to the Hotspot:

1. Enable Wi-Fi (wireless) functionality on your target device (laptop, media device, etc.).
2. Scan for Wi-Fi networks from the device and select your phone hotspot from the network list.
 - The default name for your phone's hotspot is **AndroidAP**.
3. Select this Hotspot and follow your on-screen instructions to complete the connection.
4. Launch your Internet browser to confirm you have an Internet connection.

To secure the Mobile AP service:

The use of a secure Wi-Fi connection is recommended in order to prevent unauthorized access to your hotspot. To enable security (WPA2 PSK) and set a password:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Tethering and portable hotspot** → **Mobile AP settings** → **Configure mobile AP**.
2. Tap the **Security** field and select **WPA2 PSK**.
3. Enter a password into the **Password** field.
 - To see the password characters as you type them, tap **Show password**. This is beneficial as you will not be able to match an incorrectly entered password on the connecting devices.

Important! The more complex the password, the harder it will be for intruders to break your security. It is recommended that you not use names, birthdays, or other personal information.

4. Tap **Save** to store the new settings.

Section 11: Time Management

This section describes how you can manage time using time-related applications such as the Calendar, Alarm Clock, Analog or Digital clock, and the World clock.

Calendar

With the Calendar feature, you can consult the calendar by day, week, or month; create events; and set alarms.

1. From the Home screen, tap  (Applications) →  (Calendar).
2. Press  and select one of the following options:
 - **Day**: displays the Day view.
 - **Week**: displays the Week view.
 - **Month**: displays the Month view.
 - **Agenda**: displays events in List view. This view allows you to search for events for the selected Month, Week, or Day or you can look for events for a future date.
 - **Today**: displays events for the current date.
 - **More**: provides access to additional calendar functions:
 - **Create**: creates a new Event.
 - **Go to**: displays a specific date.
 - **Calendars**: provides access to various calendar accounts.

– **Settings**: displays a list of configurable settings.

Creating a Calendar Event

1. From the Home screen, tap  (Applications) →  (Calendar).
2. Press  → **More** → **Create**.
– or –
Touch and hold an on-screen calendar day and select **Create**.

Calendar Settings

Using the Calendar settings you can select the day of the week you want the calendar to begin. You also select the default view (Month, Week, or Day), and manage events, notifications, sounds, and reminders.

1. From the Home screen, tap  (Applications) → .
2. Press  → **More** → **Settings**.
3. Tap **Hide declined events** to activate this option. A check mark indicates selection.
4. Tap **First day of week** and select either **Sunday** or **Monday**.

5. **Lock time zone:** allows you to lock the event times and dates to the time zone that you select.
6. **Select time zone:** allows you to set the time zone to which event times and dates will be locked.
7. Tap **Set alerts and notifications** to adjust the event notification method. Choose from: **Alert**, **Status bar notification**, and **Off**.
8. Tap **Select ringtone** to assign a ringtone to a calendar event notification.
9. Tap **Vibrate** to activate this notification option. Selections are: **Always**, **Only in Silent mode**, or **Never**.
10. Tap **Default reminder time** to activate this event reminder time value. Choose from: **None**, **1minute**, **5minutes**, **10 minutes**, **15 minutes**, **20 minutes**, **25 minutes**, **30 minutes**, **45 minutes**, **1 hour**, **2 hours**, **3 hours**, **12 hours**, **24 hours**, **2 days**, or **1 week**.
11. The **Build version** displays the calendar software version.


Clock

This feature allows you to create an alarm to ring at a specified time, view a slideshow, and use the music player.

- ▶ From the Home screen, tap  (Applications) →  (Clock).

Setting an Alarm

1. From the Home screen, tap  (Applications) →  (Clock).
2. Tap  (Alarm) →  (Add alarm).
3. Use the plus and minus symbols to enter the hour and minutes, if necessary tap **AM** or **PM** to toggle the setting, and select **Set**.
4. Tap the **Repeat** field and select the days you want this alarm to activate. Select **Never** (alarm sounds once only) or tap each day of the week that you want this alarm to repeat (indicated by green check mark), then tap **OK**.



Clock

Slideshow

Music

Home

5. Tap the **Ringtone** field and select an audio ringtone for this alarm. This can be used to differentiate between various alarm events.
6. Tap the **Vibrate** field to activate a vibration function to this alarm event.
7. Tap the **Label** field and enter a new name for the alarm and tap **OK**.
8. Tap **Done** to save the new alarm event.

To disable an alarm:

- ▶ From the Alarms listing page, tap the alarm clock icon to remove the green bar below it. This green bar indicates the alarm event is active.

To enable an existing alarm:

- ▶ From the Alarms listing page, tap the alarm clock icon to activate the green bar below it. This green bar indicates the alarm event is active.

Section 12: Changing Your Settings

This section explains the various settings for your phone, such as: sound, display, security, and memory.

Wireless and networks

Using Flight mode

Flight mode allows you to use many of your phone's features, such as Camera and Games, when you are in an airplane or in any other area where making or receiving calls or data is prohibited.

Important! When your phone is in Flight mode, it cannot send or receive any calls or access online information or applications.

1. Press  →  and then tap  (**Settings**) → **Wireless and networks**.
2. Tap **Flight mode**. A check mark displayed next to the feature indicates Flight mode is active.

Activating Wi-Fi

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Tap **Wi-Fi**. A check mark displayed indicates Wi-Fi is active.

Wi-Fi settings

Once set up for Wi-Fi connectivity, your phone automatically uses Wi-Fi, when available, for all your mobile phone services.

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Configure the settings as desired.

The available connection types displayed with a security type displayed next to them.

Network Notification

By default, when Wi-Fi is on, you receive notifications in the Status bar any time your phone detects an available Wi-Fi network. You can deactivate this feature if you do not want to receive notifications.

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Wi-Fi settings**.
2. Tap **Network notification**. A check mark displayed next to the feature indicates Network notification is active.
3. Tap **Network notification** again to remove the check mark and deactivate this feature.

Manually Adding a Wi-Fi Network

1. Press  →  and then tap  (Settings) → Wireless and networks → Wi-Fi settings.
2. Tap **Wi-Fi** to turn it on (indicated by green check mark).
3. Tap **Add Wi-Fi network**.
4. Enter the SSID (Service Set Identifier) and Security settings then tap **Save**.

Note: An SSID is a unique key which identifies a wireless LAN. Its purpose is to stop other wireless equipment from accessing your LAN — whether accidentally or intentionally. To communicate, wireless devices must be configured with the same SSID.

Bluetooth settings

In this menu you can activate Bluetooth, view or assign a device name, activate your phone so other Bluetooth devices can discover it, or scan for other, available Bluetooth devices with which to pair.

Activating Bluetooth

- ▶ Press  →  and then tap  (Settings) → Wireless and networks → Bluetooth settings and tap **Bluetooth** to turn it on.

Note: Bluetooth must be enabled prior to use.

Changing the Device Name

1. Activate Bluetooth.
2. Press  →  and then tap  (Settings) → Wireless and networks → Bluetooth settings → Device name. The assigned device name displays.
3. Press  to erase the current device name and enter a new name for this device using the keyboard.
4. Tap **OK** to confirm your setting.

Make Device Discoverable

- ▶ Press  →  and then tap  (Settings) → Wireless and networks → Bluetooth settings → Discoverable.

The phone is now activated for discovery for 119 seconds so you can pair with another device. After 119 seconds the phone becomes undiscoverable again.

Scanning for Devices

This option allows you to scan for active Bluetooth devices so you can pair with them.

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Bluetooth settings** → **Scan devices**.

Your phone begins scanning and lists any discovered devices in the Bluetooth devices section.

2. Tap a device name to pair with the device.

Important! Some Bluetooth devices are secured and require a PIN number to confirm and pair with them.

3. Enter a PIN to pair with the device, if one is required, and tap **OK**.

Tethering

This option allows you to share your phone's mobile data connection via a direct USB connection between your phone and computer. The Mobile AP feature provides a wireless version of this same functionality.

Note: You can not mount your phone's microSD card to your computer while using the USB tethering feature.

Note: If additional software or USB drivers are required, navigate to: <http://www.samsung.ca>.

1. Plug in the USB cable between your computer and your phone.
2. When prompted for a USB mode, press  to exit the menu.
3. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Tethering and portable hotspot** → **USB tethering**. This places a green check mark next to the entry and activates the feature. A Tethering or Hotspot active notification briefly appears on the screen. Look for the Tethering active icon  in the Status bar area of the screen.

To disconnect tethering:

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Tethering and portable hotspot**.
2. Tap **USB tethering** from the Tethering menu to remove the check mark and deactivate the feature.
3. Remove the USB cable from the phone.

Mobile AP

For more information, refer to “Mobile AP” on page 132.

VPN settings

The VPN settings menu allows you to set up and manage Virtual Private Networks (VPNs).

Important! Before you can use a VPN you must establish and configure one.

Adding a VPN

Before you add a VPN you must determine which VPN protocol to use: PPTP (Point-to-Point Tunneling Protocol), L2TP (Layer 2 Tunneling Protocol), L2TP/IPSec PSK (Pre-shared key based L2TP/IPSec), or L2TP/IPSec CRT (Certificate based L2TP/IPSec).

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **VPN settings**.
2. Tap **Add VPN**.

To establish a PPTP (Point-to-Point Tunneling Protocol):

1. Establish a VPN name (a name for this connection).
2. Set the VPN server.
3. Enable encryption (if desired).
4. Set the DNS search domains.

To establish a L2TP (Layer 2 Tunneling Protocol):

1. Establish a VPN name (a name for this connection).
2. Set the VPN server.
3. Enable L2TP secret.
4. Set L2TP secret.
5. Set the DNS search domains.

To establish a L2TP/IPSec PSK (Pre-shared key based L2TP/IPSec):

1. Establish a VPN name (a name for this connection).
2. Set the VPN server.
3. Set IPSEc pre-shared key.
4. Enable L2TP secret.
5. Set L2TP secret.
6. Set the DNS search domains.

To establish a L2TP/IPSec CRT (Certificate based L2TP/IPSec):

1. Establish a VPN name (a name for this connection).
2. Set the VPN server.
3. Enable L2TP secret.
4. Set L2TP secret.

5. Set user certificate.

Note: A user certificate must be installed to use this setting.

6. Set CA certificate.

Note: A CA certificate must be installed to use this setting.

7. Set the DNS search domains.

Mobile networks

Before you use applications such as Google Maps and find your location or search for places of interest, you must enable the Mobile networks options.

- ▶ Press  →  and then tap  (Settings) → **Wireless and networks** → **Mobile networks**.

The following options display:

Use packet data

Allows you to activate or deactivate data usage on your phone.

- ▶ Press  →  and then tap  (Settings) → **Wireless and networks** → **Mobile networks** → **Use packet data**.

Data Roaming

Data roaming allows you to connect to your service provider's partner networks and access data services when you are out of your service providers area of coverage.

1. Press  →  and then tap  (Settings) → **Wireless and networks** → **Mobile networks**.
2. Tap **Data roaming**.

Access Point Names

- ▶ Press  →  and then tap  (Settings) → **Wireless and networks** → **Mobile networks** → **Access Point Names**. A list of wireless Access point names displays. The active access point is indicated by a green button to the right of the name.

Network Operators

Using this feature you can view the current network connection. You can also scan and select a network operator manually, or set the network selection to Automatic.

Important! You must deactivate data service prior to searching for an available network.

Note: Connecting to 2G networks slows the data transfer speed and time.

Your phone default is set to Automatic (to automatically search for an available network. You can set this option to Manual to select a network each time you connect.

1. Press  →  and then tap  (**Settings**) → **Wireless and networks** → **Mobile networks** → **Network operators**.
2. Tap **Default setup**.
3. Tap **Manual** to locate and connect to a network manually.
– or –
Tap **Automatic** to allow the device to automatically select a network.

Call Settings

To access the Call settings menu:

- ▶ Press  →  and then tap  (**Settings**) → **Call settings**.
- or –
From the Home screen, tap  → **Settings** → **Call settings**.

Fixed Dialing Numbers

Fixed Dial Number (FDN), allows you to restrict outgoing calls to a limited set of phone numbers.

Enabling FDN

1. Press  →  and then tap  (**Settings**) → **Call settings** → **Fixed Dialing Numbers**.
2. Tap **Enable FDN**.
3. At the prompt, enter your PIN2 code and tap **OK**.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering an incorrect PIN2 code multiple times can cause the phone to lock. Contact customer service for assistance.

Changing the PIN2 Code

1. Press  →  and then tap  (**Settings**) → **Call settings** → **Fixed Dialing Numbers** → **Change PIN2**.
2. At the prompt, enter your old PIN2 code.
3. At the prompt, enter a new PIN2 code.
4. Confirm your PIN2 code.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering an incorrect PIN2 code multiple times can cause the phone to lock. Contact customer service for assistance.

Managing the FDN List

When this feature is enabled, you can make calls only to phone numbers stored in the FDN list on the SIM card.

1. Press  →  and then tap  (**Settings**) → **Call settings** → **Fixed Dialing Numbers** → **Enable FDN**.
2. At the prompt, enter your PIN2 code and tap **OK**. FDN is enabled.
3. Tap **FDN list** then press  and then tap **Add contact** or edit the contacts that were stored.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering an incorrect PIN2 code multiple times can cause the phone to lock. Contact customer service for assistance.

Voicemail

You can view or change your voicemail number from this menu.

1. Press  →  and then tap  (**Settings**) → **Call settings** → **Voicemail service**.
2. Select **Voicemail number** to view your number within the Voicemail number field.

Configuring Call Forwarding

Call forwarding re-routes incoming calls to a secondary number that you specify.

1. From the Home screen, tap  → **Settings** → **Call settings** → **Call forwarding**. Select the condition for the call forwarding option:
 - **Always forward:** all incoming calls are re-routed to a secondary number that you specify.
 - **Forward when busy:** forward all incoming calls to another number or voicemail when your phone is busy.
 - **Forward when unanswered:** automatically forwards incoming calls to another number when the phone is not answered.
 - **Forward when unreachable:** automatically forwards incoming calls when the phone is not in service, or is turned off.

Configuring Additional Call Settings

Configure the general call settings using this option.

1. From the Home screen, tap  → **Settings** → **Call settings** → **Additional settings**.
2. Tap one of the following options:
 - **Caller ID:** configures the way your outgoing calls are displayed. Choose from Network default, Hide number, or Show number.
 - **Call waiting:** enables call waiting functionality (notifies you of incoming calls while on a call). When deactivated, all incoming calls are directed to your voicemail if you are already on an active call.
 - **Turn on proximity sensor:** Saves power by turning off the screen when you answer a call.

Sound Settings

From this menu you can control the sounds on the phone.

- ▶ Press  →  and then tap  (**Settings**) → **Sound**.

The following options display:

Silent mode

Silent mode is convenient when you wish to stop the phone from making any noise, in a theater for example. In Silent Mode the speaker is muted and the phone does not notify you of incoming calls or vibrates only.

1. Press  →  and then tap  (**Settings**) → **Sound**.
2. Tap **Silent mode**.

– or –

From the Home screen, press and hold the **Lock** key until **Phone options** displays then tap **Silent mode** to activate or deactivate this mode (the current mode displays).

Setup Phone Vibration

1. Press  →  and then tap  (**Settings**) → **Sound**
2. Tap **Vibrate** and select a vibration mode. Choose from: **Always**, **Never**, **Only in Silent mode**, or **Only when not in Silent mode**.

Note: The Phone vibrate setting is independent of other call sounds settings. For example, if you have Silent mode enabled with Phone vibrate, your phone won't play a ringtone, but will vibrate for an incoming call.

Adjusting the Volume Settings

The Volume menu provides access to various volume settings within one on-screen popup menu.

1. Press  →  and then tap  (**Settings**) → **Sound** → **Volume**.
2. Touch and drag the on-screen slider to assign the volume setting for **Ringtone** or **Media**.
3. Tap **OK** to assign the volume levels.

Setup the Voice Call Ringtone

1. Press  →  and then tap  (**Settings**) → **Sound**.
2. Tap **Phone ringtone**.
3. Tap a ringtone from the available list. The ringtone briefly plays when selected.
4. Tap **OK** to assign a ringer.

Setting a Notification Ringtone

1. Press  →  and then tap  (**Settings**) → **Sound** → **Notification ringtone**.
2. Tap one of the ringtones and tap **OK**.

Audible Tone Settings

The Audible touch tones and Audible selection options are used when you use the dialing pad or making a screen selection. Each time you press a key or make a selection the selected tone sounds.

1. Press  →  and then tap  (**Settings**) → **Sound**.
2. Tap **Audible touch tones** or **Audible selection**. A check mark displayed next to these features indicates active status.

Screen Lock Sounds

The screen lock sounds option is used to activate/deactivate sounds when locking and unlocking the screen.

1. Press  →  and then tap  (**Settings**) → **Sound**.
2. Tap **Screen lock sounds**. A check mark displayed next to these features indicates active status.

Display Settings

In this menu, you can change various settings for the display such as the font, orientation, pop-up notifications, puzzle lock feature, animation, brightness, screen timeout, power saving mode, and tv out settings.

- ▶ Press  →  and then tap  (**Settings**) → **Display**. The following options display:

- **Wallpapers**: assigns the Home screen and Lock screen wallpaper images.
- **Font style**: sets the fonts used on the LCD display. The default selection is: Default font. Tap **Get fonts online** to download additional fonts.
- **Brightness**: configures the LCD Brightness levels.
- **Auto-rotate screen**: when enabled, the phone automatically switches from portrait to landscape orientation and vice versa. When this setting is disabled, the phone displays in portrait mode only.

- **Animation:** determines whether some or all of the window elements animate. Selections are: No animations, Some animations, or All animations.
- **Screen timeout:** adjusts the delay time before the screen automatically turns off. Selections are: 15 seconds, 30 seconds, 1 minute, 2 minutes, 10 minutes, and 30 minutes.

Messaging Key

Changes the function of the left/messaging key  on the QWERTY keyboard.

1. Press  →  and then tap  (**Settings**) → **Messaging key**.
2. Tap a selection (**Messaging, Gmail** or **Talk**).

Location and Security

The Location and Security settings allow you to configure phone location and security settings.

Use Wireless Networks

Before you use applications such as Google Maps to find your location or search for places of interest, you must enable the use of wireless networks or GPS satellites.

1. Press  →  and then tap  (**Settings**) → **Location and security**.

2. Tap **Use wireless networks** to enable location information using the wireless network.

Enabling the GPS Satellites

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Use GPS satellites** enable the GPS satellite.

Screen Unlock Pattern Settings

To secure data and limit phone access, you can set the phone to require a screen unlock pattern each time you turn on the device, or every time the phone wakes up from sleep mode (when the screen automatically turns off).

Setting an Unlock Pattern

Creating a screen unlock pattern increases security on the phone.

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Set screen lock** → **Pattern**.
3. Read the instructions then tap **Next**.
4. Review the animated procedure for drawing a pattern and tap **Next** when you are ready to draw a pattern.

5. Draw your pattern by touching the first on-screen point. Then, **without removing your finger from the screen, drag your finger over adjacent points until the gray trace line overlaps each point** and they are highlighted by a green circle.
6. When you have connected at least four dots in a vertical, horizontal or diagonal direction, lift your finger from the screen and tap **Continue**.
7. Confirm the new pattern by redrawing it and then tapping **Confirm**. The Unlock pattern is set.

Changing the Screen Lock Pattern

This feature allows you to change the previously stored unlock pattern and update it if necessary. This process is similar to changing your password from time to time.

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Change screen lock**.
3. Retrace your current pattern on the screen.
4. Tap **Pattern** and repeat steps 3 - 7 from the previous section.

Using Visible a Pattern

When enabled, this feature displays the unlock pattern as you draw it with your finger.

PIN Lock and Unlock

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Set screen lock**.
3. Tap **PIN**.
4. Enter a PIN number using the numeric keypad and touch **Continue** to confirm the password.
5. Confirm the PIN by re-entering it and tap **OK** to confirm.
Your phone now requires you to enter this PIN number in order to unlock the phone.

Password Lock and Unlock

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Set screen lock**.
3. Tap **Password**.

4. Enter a password using the keypad and tap **Continue** to confirm the password.
5. Re-enter the password and tap **OK** to confirm.

Setting up SIM Card Lock

Prevent another user from using your SIM card to make unauthorized calls or from accessing information stored on your SIM card by protecting the information using a PIN code.

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Set up SIM card lock**.
3. Tap **Lock SIM card**, enter your SIM PIN code, then touch **OK**.

Note: You must activate Lock SIM card before you can change your SIM PIN code.

To change an existing SIM Card PIN:

1. Tap **Change SIM PIN**.
2. Enter the old SIM PIN code and tap **OK**.
3. Enter the new SIM PIN code and tap **OK**.
4. Re-type the new SIM PIN code and tap **OK**.

Passwords

When you create a phone password you can also configure the phone to display the password as you type it instead of using an asterisk (*).

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Visible passwords** to activate this feature.

Device Administration

Activating this feature allows a Google Apps administrator to enforce security policies and remotely wipe phones that are lost or stolen.

1. Press  →  and then tap  (**Settings**) → **Location and security**.
2. Tap **Select device administrators** to configure the setting.
3. Select an administrator and follow the prompts.

Credential Storage

This option allows certain applications to access secure certificates and other credentials. Certificates and credentials can be installed to the SD card and password protected.

1. Press  →  and then tap  (**Settings**) → **Location and security**.

2. Tap **Use secure credentials** to activate this feature. A check mark displayed next to the feature indicates secure credentials is active.
3. Tap **Install from SD card** to install encrypted certificates from the memory (SD) card.
4. Tap **Set password** to set or change the credential storage password.
5. Tap **Clear storage** to clear the storage (SD card or phone memory) of all contents and reset the credentials password.

Applications

Unknown Sources

This feature must be enabled in order to download applications from locations other than the Android Market.

1. Press  →  and then tap  (**Settings**) → **Applications**.
2. Tap **Unknown sources** to activate this feature.

Note: If you are notified that you can not download a Market application because it comes from an “Unknown source”, enabling this option corrects this issue.

Quick Launch

Allows you to set keyboard shortcuts to launch assigned applications.

1. Press  →  and then tap  (**Settings**) → **Applications**.
2. Tap **Quick launch** to activate this feature.
3. Tap an onscreen letter from the list.
4. Select an available application. This changes the selected hotkey to now launch the new application.

Managing Applications

This feature allows you to manage your phone's applications.

You can also view the amount of memory or resources used as well as the remaining memory and resources for each of the applications on your phone, and clear the data, cache, or defaults.

- ▶ Press  →  and then tap  (**Settings**) → **Applications** → **Manage applications**.

Clearing Application Cache and Data

1. Press  →  and then tap  (**Settings**) → **Applications** → **Manage applications**.
2. Tap the **Downloaded** tab and select your desired application.
3. Tap **Clear data** or **Clear cache**.

Uninstalling Third-party Applications

Important! You must have downloaded applications installed to use this feature.

1. Press  →  and then tap  (**Settings**) → **Applications** → **Manage applications**.
2. Tap the **Downloaded** tab and select your desired application.
3. Tap **Uninstall**.

4. At the prompt, tap **OK** to uninstall the application.

Moving Third-party Applications to your SD Card

Your phone's built in memory can be augmented by using a microSD card to store additional data. When the phone's built-in memory capacity is reached, it is possible to move some applications to the internal microSD card. Freeing up memory space on the phone can help avoid sluggish performance when the phone has to work harder to manage memory resources.

Important! Not all downloaded applications are capable of being moved from phone to card.

1. Press  →  and then tap  (**Settings**) → **Applications** → **Manage applications**.
2. Tap the **Downloaded** tab and select your desired application.
3. Tap **Move to SD card**.

Once the application has been moved to the microSD card, this button now reads "Move to phone".

Running Services

The Running services option allows you to view and control all currently running services.

1. Press  →  and then tap  (**Settings**) → **Applications** → **Running services**

The screen displays all the processes that are running.

2. Tap a process to open the Stop service? screen, where you can tap Stop to force the process to stop running.

When you stop the process the service or application will no longer run until you start it again.

Important!: Stopping a process might have undesirable consequences on the application.

Android Development

This phone can be used for Android development. You can write applications using the Android SDK and install them on this device, then run the applications using the hardware, system, and network. This feature allows you to configure the device for development.

- ▶ Press  →  and then tap  (**Settings**) → **Applications** → **Development**.

Important!: These features are used for development purposes only.

USB Debugging

This feature is used for development purposes only. The phone enters Debug mode when USB is connected.

Stay awake

This feature is used to prevent the phone from entering sleep mode while it is charging.

Allow Mock Locations

This feature is used for development purposes only.

It allows the entry of “mock” GPS coordinates in order to test GPS applications.

Accounts and Synchronization

Your phone provides the ability to synchronize data from a variety of different sources or sites, including Google, a Corporate Microsoft Exchange Email Server, and social sites such as Facebook, Twitter, and MySpace. Corporate and Google accounts provide the ability to synchronize Calendar events and Contacts.

To enable the auto-sync feature:

1. Press  →  and then tap  (**Settings**) → **Accounts and sync**.

2. Tap **Background data**. A green checkmark indicates the feature is enabled. This lets applications sync, send, and receive data at any time.
3. Tap **Auto-sync**. A green checkmark indicates the feature is enabled. This allows automatic synchronization of data between your phone and external sites or servers.
 - The three main components are Contacts, Email, and Calendar Events. Before these can be synchronized, they must be added to the managed accounts list.

Synchronizing a Google Account

By default, there are no accounts managed by the device. These must be manually added.

To manage an existing Google account:

1. Press  →  and then tap  (**Settings**) → **Accounts and sync**.
2. Tap **Add account** → **Google**.
3. Tap **Next** → **Sign in**.

Note: If you do not already have a Google account, tap **Create** and follow the on-screen prompts to create your new account.

4. Touch the **Username** (@gmail.com) and **Password** fields and enter your information.
5. Tap **Sign in**. Your phone then communicates with the Google servers to confirm your information. Your existing Gmail account then appears within the **Manage accounts** area of the screen.
 - Any changes or updates to your Gmail account are then automatically updated to your device.

To configure the Google management settings:

1. Press  →  and then tap  (**Settings**) → **Accounts and sync**.
2. Tap  within the Google account field to reveal the account's synchronization settings screen.
3. Tap the parameters you wish to synchronize (**Sync Instant Upload**, **Sync Books**, **Sync Contacts**, **Sync Gmail**, **Sync Picasa Web Albums**, or **Sync Calendar**). A green checkmark indicates the feature is enabled.
4. Press  to return to the previous screen. For more information, refer to "Synchronizing Contacts" on page 74.

Synchronizing Your Corporate Account

By default, there are no Corporate Calendar events managed by the device. These must be manually added.

Note: Once a corporate email account is created, it is automatically added as a managed account.

Use the following procedure to configure your phone to synchronize with a corporate email account.

1. From the Home screen, tap  (Applications) → **Settings** → **Accounts and sync**.
– or –
Press  →  and then tap  (**Settings**) → **Accounts and sync**.
2. Locate the email account containing the events you wish to synchronize.
3. Tap  within the adjacent account field to reveal the account's synchronization settings screen.
4. Toggle the check mark adjacent to either the Sync Contacts or Sync Calendar fields to manually sync the account.

Privacy Settings

Set data backup and restore configurations, or reset the phone to erase all personal data.

- ▶ Press  →  and then tap  (**Settings**) → **Privacy**.

Backup and Restore

The phone can be configured to back up your current settings, application data and settings.

1. Press  →  and then tap  (**Settings**) → **Privacy**.
2. Tap **Back up my data** to create a backup of your current phone settings and applications.
3. Tap **Automatic restore** to assist in the re-installation of a previously installed application (including preferences and data).

Factory Data Reset

From this menu you can reset your phone and sound settings to the factory default settings.

1. Press  →  and then tap  (**Settings**) → **Privacy**. (You will see a disclaimer.)

2. Touch **Factory data reset** → **Reset phone**.
3. If necessary, enter your password and touch **Erase everything**.
The phone resets to the factory default settings automatically and when finished displays the Home screen.

SD Card & Phone Storage

From this menu you can view the phone's available memory space, the total and available space on an inserted memory card, and mount or unmount the SD card.

For more information about mounting or unmounting the SD card, see "Using the SD Card" on page 38.

To view the memory allocation for your external SD card:

- ▶ Press  →  and then tap  (**Settings**) → **SD card and phone storage**. The available memory displays under the Total space and Available space headings.

Search Settings

You can use your phone's search preferences to configure some aspects of Google Internet search (for example, whether it makes suggestions below the Quick Search Box as you type), and what phone features you want to include in searches.

1. Press  →  and then tap  (**Search**).
2. Press  → **Search settings**.
3. Tap any of the following search parameters to alter the settings:
 - **Searchable items**: opens a screen where you can choose the phone applications included in device searches: **Google, Apps, Browser, Contacts, Google Play Books, Messaging, Music, or Play Store**.
 - **Clear on-device history**: erases the history for recently selected search results.
 - **Use My Location**: Use your location to improve Google Search results and other Google services.
 - **Search on google.com**: Using your local domain (www.google.ca).
 - **Terms of Service**: displays the Google terms of service.
 - **Open Source Licenses**: displays the applicable open source licenses.

Locale and Text Settings

This setting allows you to configure the language in which to display the menus and keyboard. You can also set on-screen keyboard options.

- ▶ Press  →  and then tap  (Settings) → Locale and text.

Language Settings

To set the language that the menus and keyboard display on the phone:

1. Press  →  and then tap  (Settings) → Locale and text → Select locale.
2. Select a language from the list.

On-screen Keypad

This feature, when active, allows you to use either the on-screen or slide-out QWERTY keyboard to enter text and configure your text input method.

When deactivated, this feature forces you to use only the slide-out QWERTY keypad. While deactivated, you are not presented with an on-screen keypad for use and you can not change the text input method on-screen.

1. Press  →  and then tap  (Settings) → Locale and text.
2. Tap **On-screen keypad** to activate or deactivate the feature (green check mark indicates that it is active).

Select Input Method

There are two on-screen input methods available: Swype and Samsung keypad.

1. Press  →  and then tap  (Settings) → Locale and text → Select input method.
2. Select an input method.

Swype Settings

For more information, refer to “SWYPE Settings” on page 61.

1. Press  →  and then tap  (Settings) → Locale and text → Swype.
2. Tap one of the following Swype settings to activate the setting:
 - **Select Input Method:** allows you to switch between Samsung keypad and Swype.
 - **How to Swype:** provides tips on how to learn to use Swype.

- **Personal dictionary:** Allows you to setup and manage your own dictionary.
- **Preferences:** Allows you to view and modify the following Swype options:
 - **Audio feedback:** When enabled, plays sounds as you enter text.
 - **Vibrate on keypress:** check this field to have the phone vibrate each time you touch a key on the keyboard.
 - **Show tips:** When enabled, the device displays helpful tips.
 - **Auto-spacing:** When enabled, inserts spaces automatically when you pause entering text.
 - **Auto-capitalization:** When enabled, automatically capitalizes the first letter of the first word in a sentence.
 - **Show complete trace:** When enabled, briefly display the Swype trace.
 - **Word suggestion:** When enabled, suggests possible matching words as you enter text.
 - **Speed vs. accuracy:** Send the sensitivity of Swype text recognition.
 - **Reset Swype's dictionary:** Deletes all of the words you have added and loads the default dictionary.
 - **Version:** View the current Swype software version.
- **Language Options:** Allows you to set the language that you will be using.

Samsung Keypad Settings

For more information, refer to “Using the Samsung Keypad” on page 55.

1. Press  →  and then tap  (**Settings**) → **Locale and text** → **Samsung keypad**.
2. Tap **Keypad types** and select a text input method:
 - Qwerty Keypad
 - 3x4 Keypad
3. Tap **Writing language** and select a language.
4. Tap **XT9** to use XT9 Predictive text method. For more information, refer to “Text Input Methods” on page 54. For XT9 advance settings, see “XT9” on page 157.
5. Tap the **Keypad sweeping** field if you want to sweep the keypad to change from ABC to ?123 mode. For more information, refer to “Text Input Methods” on page 54.
6. Tap the **Auto-capitalization** field to automatically capitalize the first letter of a sentence.
7. Tap **Voice input** to activate the Voice input feature. This is an experimental feature that uses Google’s networked speech recognition application.

8. Tap **Auto-full stop** to automatically insert a full stop by tapping the space bar twice.
9. Tap the **Tutorial** field to view a short tutorial on use of the Samsung keyboard.

XT9

The following XT9 settings are available when the XT9 field is selected.

1. Tap the **XT9** field to select XT9 (predictive text) mode, then tap **XT9**.
2. Tap the **Word completion** field to enable word completion. Your phone predicts how to complete the word typed.
3. Tap the **Word completion point** field then touch **2 letters**, **3 letters**, **4 letters**, or the **5 letters** radio button. Word completion begins after 2 or more (depending on your selection).
4. Tap the **Spell correction** field. This option corrects typographical errors by selecting from a list of possible words that reflect the characters of the keys you touched as well as the characters of nearby keys.
5. Tap the **Next word prediction** field to enable word prediction.
6. Tap the **Auto-append** field to automatically add predictions.
7. Tap the **Auto-substitution** field to automatically replace words that you are typing. This option assists with correcting misspelled words.
8. Tap the **Regional correction** field. This option sets the device to automatically correct mistyped words according to normal spelling for your region.
9. Tap the **Recapture** field. This option sets the device to re-display the word suggestion list when you select the wrong word from the list.
10. To add a new word to the T9 dictionary:
Tap the **XT9 my words** field, then press  and then tap **Add**. Enter the new word in the **Register to XT9 my words** field, then tap **Done**.
11. Tap **XT9 auto-substitution** to add words to substitute (for example youve becomes you've). A list of substitutions displays.
12. If you do not see the substitution you want, press  and then tap **Add**, then input the Shortcut word and Substitution word.

13. Tap Done.

Device Keyboard Settings

For more information, refer to “Entering Text Using the QWERTY Keyboard” on page 62.

1. Press  →  and then tap  (Settings) → **Locale and text** → **Device keyboard**.
2. Tap **Auto-replace** to automatically correct mistyped words.
3. Tap **Auto-cap** to automatically capitalize the first letter in a sentence.
4. Tap **Auto-punctuate** to automatically punctuate within a sentence by pressing the space key twice.

Accessibility Settings

Lets you enable and disable downloaded accessibility applications that aid in navigating your Android device, such as TalkBack (uses synthesized speech to describe the results of actions), KickBack (provides haptic feedback for actions), and SoundBack (plays sounds for various actions). Also lets you enable use of the power key to end calls.

Enabling Accessibility Applications

Note: Accessibility applications are not provided with the phone; they must be downloaded from Android Market.

1. Press  →  and then tap  (Settings) → **Accessibility**.
2. Tap Accessibility to enable the use of accessibility applications (indicated by green check mark).

Power key

To allow use of the power key to end calls:

1. Press  →  and then tap  (Settings) → **Accessibility**.
2. Select **The power key ends calls** field to activate this feature (indicated by green check mark).

Date and Time

This menu allows you to change the time and date displayed.

1. Press  →  and then tap  (Settings) → **Date and time**.

2. Tap **Automatic** to allow automatic setting of the date and time (indicated by green check mark) or disable automatic setting.

If automatic date and time setting has been deactivated, manually adjust the settings as required:

3. Tap **Set date** and use the plus and minus icons to set the **Month**, **Day**, and **Year** then touch **Set**.
4. Tap **Select time zone**, then touch a time zone.
5. Tap **Set time** and use the plus and minus icons to set **Hour** and **Minute**. Touch **PM** or **AM** to toggle the setting, then tap **Set**.
 - To display the time in 24-hour format, tap **Use 24-hour format**. If this is not enabled, the phone automatically uses a 12-hour format.
6. Tap **Select date format** and touch the required date format.

About Phone

This menu contains phone status information, battery use information, legal information, and other phone information such as the model number, Android version, baseband version, kernel version, and software build number.

To access phone information:

- Press  →  and then tap  (**Settings**) → **About phone**. The following information displays:

- **Status:** displays the battery status, phone number for this device, the network connection, signal strength, mobile network type, service state, roaming status, mobile network state, IMEI number, IMEI SV, Wi-Fi MAC address, Bluetooth address, and Up time.
- **Battery use:** displays the percentage of battery use by various applications and services.
- **Legal information:** This option provides links to the applicable Open source licenses and Google legal information for this phone. This information clearly provides copyright and distribution legal information and facts as well as Google Terms of Service, Terms of Service for Android-powered Phones, and much more pertinent information as a reference.
- **Model number:** displays the phone's model number.
- **Android version:** displays the firmware version loaded on this handset.
- **Baseband version:** displays the baseband version loaded on this handset.
- **Kernel version:** displays the kernel version loaded on this handset.
- **Build number:** displays the software build number.

Note: Firmware, baseband, kernel and build numbers may be required by a service representative when troubleshooting service problems or when selecting the appropriate updates for the handset.

A

Accessing

- Recently-used Applications 29
- Voice Mail 12

Add 3 sec Pause 43

Add Call 47

Adjusting

- Call volume 46

Alarm

- Disable Existing 136
- Enable Existing 136
- Setting 135

Answering a call 42

Application Menus

- Navigating through 28

Applications 29

- Android Market 32
- Browser 31, 109
- Calculator 30, 106
- Calendar 30
- Camera 30, 107
- Clock 30
- Contacts 30

Email 30, 108

Files 31

Gallery 31

Gmail 31, 108

Google Maps 31, 110

Google Play 116

Google Search 31

Latitude 31

Maps 31

Memo 31, 112

Messaging 32

Music 32

Navigation 32

Places 32

Task Manager 33

Using the Camcorder 99

Using the Camera 94

Voice Recorder 33, 119

Voice Search 33, 119

YouTube 33, 119

Applications and Development 106

Auto-sync

- Enabling 151

B

Back up

- My Data 153

Backup and Restore 153

Battery

- Charging 6
- Extending Life 8
- Installing 5
- Low Battery Indicator 7
- Removal 6
- Saving Power 8
- Wall Charger 6

Battery Cover

- Removal 2
- Replace 3

Battery Life

- Extending 8

Bing

- Set Search Engine 125

Bluetooth

- About 126
- Change Name 127
- Deleting a Paired Device 128

- Disable 126
- Disconnecting a Paired Device 128
- Enable 126
- Paring Devices 127
- Scan for Devices 127
- Sending Contact Information 128
- Sending Contacts Via 128
- Set Visibility 127
- Settings 126
- Status indicators 126
- Switching to Headset during call 47
- Turning on and off 126

Browser

- Adding bookmarks 123
- Deleting bookmarks 123
- Emptying cookies 124
- Entering a URL 121
- Navigation 121
- Options 121
- Select Search Engine 125
- Settings 124

Bubble

- Options 84

C

Calendar 134

- Creating an event 134
- Manually Sync Events 107
- Settings 134

Call Forwarding 143

Call Functions 41

- Answering 42
- Ending 41
- Ending a Call 41
- Making a Multi-Party Call 48
- Pause Dialing 43
- Redialing the last number 44
- Wait dialing 44

Call Log 50

- Accessing 50
- Accessing from Notifications 51
- Altering Numbers 52
- Caller Overview 51
- Quick Dialing 52
- Quick Messaging 53

Call Logs

- Erasing 53

Call Settings 142

- Additional 143

Call Forwarding 143

Call Waiting 144

Caller ID 144

Call Volume

Adjusting 46

Call Waiting 49, 144

Caller ID 144

Hide Number 144

Calls

Making a 41

Multi-party 48

Muting 47

Camcorder 99

Accessing the Video Folder 101

Camcorder Options 100

Options 100

Settings 100

Shooting Video 99

Camera 94

Camera Options 95

Options 95

Taking Pictures 94

Charging Battery 6

Connections

Accessing the Internet 121

Contact

- Copying to microSD Card 74
- Copying to SIM Card 74
- Creating a New 65
- Joining 71
- New From Keypad 66

Contact Entry

- Options 70

Contact List

- Options 69

Contact Menus

- Options 70

Contacts

- Adding a Number to Existing 68
- Adding Your Facebook Friends 76
- Additional Options 77
- Default Storage Location 78
- Deleting 69
- Display Options 75
- Displaying Contacts by Name 75
- First Name First 75
- Groups 78
- Last Name First 75
- Sending 73
- Sending All 73

- Setting Default Location 69

- Settings 78

Context Menus 67, 70

- Navigation 29

- Using 29

Cookies

- Emptying 124

Copying Contact 74

Corporate Email

- Account Synchronization 153

- Add Account 153

Creating a Playlist 104

Creating and sending

- Messages 81

Customizing

- Home screens 34

D

Data Roaming 141

Deleting

- Multiple messages 85

- Single message 85

Deleting a contact 69

Device Keyboard

- Settings 158

Dialing

- With a SIM 9

- Without a SIM 9

Display

- Icons 18

- Settings 18

- Status Bar 18

Displaying your phone number 41

Downloading

- New Application 116

Downloads 108

E

Email 86

- Composing 87

- Configuring Settings 88

- Creating an Internet Email Account 87

- Internet Email 87

- Opening 87

- Refreshing Messages 87

- Sending 77

Emoticons 64

Ending

- A call 41

Entering Text 54

Using SWYPE 58

Erasing files from

Memory card 40

Exchange Email 88

Account Setup 89

Composing 90

Configuring Settings 90

Deleting Message 90

Opening 89

Refreshing Messages 89

F**Factory data reset** 40, 153**Fixed Dialing Numbers** 142**Folder**

Creating and Managing 37

Deleting 37

Renaming 37

Font

Style 145

Font Size

Caption 120

G**Gallery**

Folder Options 97

Image Options 97, 101

Opening 102

Get Friends 76**Getting Started** 1

Battery 5

Battery Cover 2

Locking/Unlocking the Phone 9

microSD card 4

SIM Card 3

Switching Phone On/Off 9

Voice Mail 11

Gmail 91, 108

Composing a message 92

Opening 92

Refreshing 92

Signing In 91

Viewing 92

Google

Account Management Settings 152

Account Synchronization 152

Add Account 152

Adding a Sync Account 152

Create New Account 10

Retrieving Password 11

Set Search Engine 125

Signing into Your Account 11

Google mail

see Gmail 92

Google Maps

Enabling a location source 111

Opening a map 111

Google Talk 33, 118**Google+** 109**Groups**

Adding an Member to an Existing

Group 78

Creating a new caller group 78

Editing a caller group 79

Removing an Entry 79

Settings 79

H**Hide Number** 144**History tab** 79**Hold**

Placing a call on hold 46

Home 24**Home Key** 22**Home Screen**

Overview 24

Home Screen Wallpaper 145

Set as 98

Setting 96

Home screens

Customizing 34

I

Icons

Description 18

Indicator 18

Status 18

Images

Assigning as a Contact icon 98

Assigning as wallpaper 99

Importing and Exporting

To SIM card 78

In call

Options 46, 47

Indicator Icons 18

International Call 43

International calls

Making 43

Internet 121

History 124

Search 122

Internet applications

enable downloading 129

J

Joining

Contact information 71

L

Lock Screen Wallpaper 145

Set as 98

Setting 96

Low Battery Indicator 7

M

Making

International calls 43

New call 41

Managing Applications 150

Clearing Application Cache 150

Moving Third-party Applications to
Card 150

Uninstalling Third-party Applications
150

Marking contact

As a default 72

Media Volume

Setting 144

Media volume

Ringtone 144

Memo

Options 112

Memory card

Erasing files from the 40

Merge Calls 48

Message

Deleting a Message 85

Failure to Send 84

Gallery 84

Options 82

Read 83

Reply 84

Threads 83

Message Search 85

Message threads 83

Messaging

Creating and sending 81

Creating and Sending Text
Messages 81

Gmail 91

Icons on the Status Bar 81

Key 82, 146

Options 82

- Settings 85
- Signing into Google Mail 91
- Types of Messages 81
- Viewing new 83
- microSD Card**
 - Insertion 4
 - Removal 5
- Microsoft Exchange** 65
- Mobile AP** 132
 - Activating 132
 - Connecting 132
 - Securing 133
- Mobile Networks** 141
 - Data Roaming 141
- Mobile Web** 121
 - Entering Text in the Mobile Web
 - Browser 121
 - Navigating with the Mobile Web 121
 - Using Bookmarks 122
- mounting the SD card** 38
- Move to SD card** 150
- Multi-Party Call** 48
 - Dropping One Participant 49
 - Private conversation 48

- Multi-party call**
 - Setting up 48
- Multi-party calls** 48
- Music** 102
 - Adding music 104
 - Creating a playlist 104
 - Editing a Playlist 104
 - Making a Song a Ringtone 103
 - Options 103
 - Playing Music 102
 - Removing music 104
 - Using Playlists 104

My Profile 77

N

Namecard

- Send Via 73
- Sending 73
- Sending All 73

Navigating

- Application Menus 28
- Sub-Menus 28
- Through Screens 26

Network connection

- Adding a new 131

New Applications

- Downloading 116

Notification Bar 21

- Using 21

O

On/Off Switch 9

On-screen Keypad 155

Organizer

- Calculator 106

Outlook

- Synchronizing 153

Overview

- Home Screen 24

P

Pause Dialing 43

Phone

- Icons 18
- Switching on/off 9

Phone number

- Finding 41

Phone Options 144

Phone Ringtone 145

- Set as 103

Photos

- Options 96, 97, 101

- Setting As 96
- Sharing 96, 97, 101
- Play Books** 115
- Play Store** 116
- Power Control** 8
- Predictive text**
 - Using XT9 57
- Primary Shortcuts** 25
 - Adding and Deleting 35
- Q**
- Quick Launch** 149
- QWERTY**
 - Keyboard 54
- R**
- Recently-used Applications**
 - Accessing 29
- Redialing the last number** 44
- Reset** 153
- Restore** 153
- Ringtone**
 - Phone 145
- S**
- Samsung Keypad** 55
 - ABC Mode 55
 - Changing the Input Type 55

- Enabling 55
- Entering Symbols 56
- Settings 156
- SYM Mode 56
- Save a Number**
 - From Keypad 66
- Screen**
 - Home 24
 - Navigation 26
- Screen Lock** 146
- Screen Rotation**
 - Auto-Rotate 145
- Screen Timeout** 146
- Screens**
 - Adding and Deleting 34
 - Customizing 34
 - Rearranging 35
- SD card**
 - Connecting to 39
 - mounting the 38
 - Unmounting 39

- Search Engine** 125
- Select Language** 155
- Sending a Namecard** 73
- Setting an alarm** 135
- Setting Up**
 - Voicemail 11
- Settings** 137
 - Browser 124
 - Contact list 78
 - Display 18
 - Enabling the GPS Satellites 146
 - Enabling wireless network locations 146
 - Messaging 85
- Shortcuts**
 - Adding from Application Screen 35
 - Adding from Home Screen 36
 - Deleting from a Screen 36
 - Managing 35
 - Primary 25
- SIM Card**
 - Changing Existing PIN 148
 - Importing and Exporting 78
 - Insertion 3
 - Lock 148

- Removal 4
- SIM Card Lock**
 - Setting Up 148
- Song**
 - Set as 103
- Speakerphone**
 - Turning on and off 47
- Speed Dial**
 - Changing an entry 45
 - Making a call 45
 - Removing an entry 45
 - Setting up entries 44
- Status Bar** 18
- Stay Awake** 151
- Sub-Menus**
 - Navigation 28
- Swap** 47
- Switching to a Bluetooth**
 - During a call 47
- Swype**
 - Entering Text 59
 - Entering text using 58
 - Settings 61, 155
- Swype Keyboard**
 - Using 58

T

- Tethering** 139
 - Activating 139
 - Active Icon 139
 - Disconnecting 139
- Text Input**
 - Methods 54
- Text Input Method**
 - Selecting 54
- Third-Party Applications** 150
- Time Management**
 - Calendar 134
- Tools**
 - Camera 94
- Transferring Music Files** 105

U

- Understanding Your Phone** 14
 - Back View 17
 - Display 17
 - Features 14
 - Front View 15
 - Home 24
- Unknown Sources** 149
- Unmounting**
 - SD card 39

- Updates tab** 80
- USB Connection**
 - As mass storage device 129
- USB Settings**
 - As mass storage device 129
- Use GPS Satellites** 111, 146
- Use Packet Data** 141
- Use Wireless Networks** 111, 146
- Using Favorites**
 - Adding Favorites 123
 - Deleting a Favorite 123
 - Editing Favorites 123

V

- Vibrate** 144
- Vibration**
 - Setup 144
- Video Player** 101
- Voice Actions** 23
- Voice Mail**
 - Accessing 12
 - Accessing from Another Phone 12
- Voice mail**
 - Setting Up 11
- Volume Settings**
 - Adjusting 144

VPN

Adding 140

Settings 140

W

Wait 44

Wait Dialing 44

Wallpapers

Changing 37

Managing 37

Widgets

Adding and Removing 36

Google Talk 33

Moving to a Different Screen 36

Settings 33, 118

Wi-Fi

About 130

Activating 130

Advanced settings 131

Connecting to 130

Deactivating 131

Manually scan for network 131

Status icons 131

WPA2 PSK 133

Y

Yahoo! 125

YouTube

High Quality 105

Settings 119