

Samsung GALAXY LEGEND™

A N D R O I D S M A R T P H O N E

User Manual

**Please read this manual before operating your
phone and keep it for future reference**



Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the “Phone System”), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Open Source Software

Some software components of this product, including but not limited to 'PowerTOP' and 'e2fsprogs', incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:

<http://opensource.samsung.com>.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Modification of Software

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.

USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.

IF YOUR CARRIER PROHIBITS THIS, IF YOU ATTEMPT TO DOWNLOAD SOFTWARE ONTO THE DEVICE WITHOUT AUTHORIZATION, YOU WILL BE NOTIFIED ON THE SCREEN THAT THE PHONE WILL NO LONGER OPERATE AND BE INSTRUCTED TO POWER DOWN THE DEVICE. YOU MUST THEN CONTACT YOUR CARRIER TO RESTORE THE DEVICE TO THE CARRIER AUTHORIZED SETTINGS.

SAFE™ (Samsung Approved For Enterprise)

SAFE™: "SAFE™" (Samsung for Enterprise) is a mark for a Samsung device which has been tested against Samsung's own internal criteria for interoperability with certain third party security-related solutions for MDM and VPN. The testing includes field testing with local network connection and menu tree testing which tests functionality of the solutions in conjunction with the Samsung device. During the testing, the device is tested with the security solutions to see if the solutions work with the device as described by the third party security solution providers. The testing, for example, includes field testing with local network connection and menu tree testing which tests functionality of the solutions in conjunction with the Samsung device. For more information about Samsung's SAFE™ program, please refer to www.samsung.com/us/safe.

Disclaimer of Warranties: EXCEPT AS OTHERWISE PROVIDED IN THEIR STANDARD END USER LICENSE AND WARRANTY, TO THE FULL EXTENT PERMITTED BY LAW SAMSUNG ELECTRONICS CO., LTD., SAMSUNG TELECOMMUNICATIONS AMERICA, LLC, AND THEIR AFFILIATES (COLLECTIVELY REFERRED TO HEREIN AS THE "SAMSUNG ENTITIES") EXPRESSLY DISCLAIM ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY OR NON-INFRINGEMENT, WITH RESPECT TO INFORMATION TECHNOLOGY SECURITY PROTECTION, SAFE™ DEVICES AND APPLICATIONS TESTED WITH SAFE™ DEVICES. IN NO EVENT SHALL THE SAMSUNG ENTITIES BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES OF ANY KIND WHATSOEVER WITH RESPECT TO INFORMATION TECHNOLOGY SECURITY PROTECTION, SAFE™ DEVICES OR APPLICATIONS TESTED WITH SAFE™ DEVICES. In addition, information technology security protection will be affected by features or functionality associated with, among other things the e-mail platform, master data management, and virtual private network solutions selected by the software provider, solution provider or user. Choice of an e-mail, master data management, and virtual private network solution is at the sole discretion of the software provider, solution provider or user and any associated effect on information technology security protection is solely the responsibility of the software provider, solution provider or user. For complete statement of limited warranty, please refer to www.samsung.com/us/safe, available on the web and where Samsung smartphone and Galaxy Tab™ devices are sold. [101212]

Samsung Telecommunications America (STA), LLC

Headquarters:

1301 E. Lookout Drive

Richardson, TX 75082

Customer Care Center:

1000 Klein Rd.

Plano, TX 75074

Toll Free Tel: 1.888.987.HELP (4357)

Internet Address:

<http://www.samsung.com>

©2013 Samsung Telecommunications America, LLC. Samsung is a registered trademark of Samsung Electronics Co., Ltd.

Do you have questions about your Samsung Mobile Phone?

For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at:

www.samsung.com/us/support

The Bluetooth® word mark, figure mark (stylized “B Design”), and combination mark (Bluetooth word mark and “B Design”) are registered trademarks and are wholly owned by the Bluetooth SIG.

Nuance®, VSuite™, T9® Text Input, and the Nuance logo are trademarks or registered trademarks of Nuance Communications, Inc., or its affiliates in the United States and/or other countries.

microSD™, microSDHC™ and the microSD logo are Trademarks of the SD Card Association.

DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

DivX Certified® to play DivX® video up to HD 720p, including premium content.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in License settings under Settings > About phone > Legal information > License settings > DivX@VOD. Go to vod.divx.com for more information on how to complete your registration.

Wi-Fi®, the Wi-Fi CERTIFIED logo, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.

Google, Google Play and other marks are trademarks of Google, Inc.

©Samsung Telecommunications America, LLC (“Samsung”). Samsung, Super AMOLED, and AllShare are all trademarks of Samsung Electronics Co., Ltd. and/or its related entities. Other company names, product names and marks mentioned herein are the property of their respective owners and may be trademarks or registered trademarks. Appearance of device may vary.

©Verizon Wireless. Verizon Wireless, the Verizon Wireless logos, and Legend™ are trademarks of Verizon Trademark Services LLC. All company names, trademarks, logos and copyrights not property of Verizon Wireless are the property of their respective owners.

Table of Contents

Section 1: Getting Started5

Understanding this User Manual	5
Battery	6
Turning Your Phone On and Off	9
Setup Wizard	10
Help	10
Your Phone Number	10
Your Google Account	10
Your Samsung Account	10
Voicemail	11
TTY Mode	11
Roaming	11
Task Manager	12
Memory Card	12
Securing Your Phone	13

Section 2: Understanding Your Phone15

Features	15
Front View	16
Side Views	17

Back View	18
Display	19
Home screen	20
LED Indicator	21
Navigation	22
Notifications	22
Status Bar	23
Apps and widgets	26
Folders	27
Wallpaper	27
Entering Text	28

Section 3: Calling32

Making Calls	32
Answering Calls	35
Recent calls	36
Call Settings	37

Section 4: Contacts and Accounts43

Accounts	43
Contacts	45

Speed Dials	53	Google Settings	76
Section 5: Messaging	55	Google+	77
Types of Messages	55	Help	77
Text and Multimedia Messaging	56	Internet	77
Emergency Alerts	60	Local	79
Email	60	Maps	79
Gmail	62	Media Hub	80
Voicemail	63	Memo	80
Google Talk	64	Messaging	80
Google+ Messenger	64	Messenger	80
Section 6: Applications	65	Music Player	81
Managing Applications	65	My Files	83
Calculator	67	My Verizon Mobile	83
Calendar	67	Navigation	83
Camera	68	Phone	84
Clock	73	Play Books	84
Contacts	73	Play Magazines	84
Downloads	74	Play Movies & TV	84
Email	74	Play Music	84
Gallery	74	Play Store	85
Gmail	76	Polaris Office	85
Google	76	S Voice	85

Settings	85	Display	105
Setup Wizard	86	Storage	107
Talk	86	Power saving mode	108
Video Player	86	Battery	108
Voice Recorder	87	Application manager	108
Voice Search	87	Location services	109
VZ Navigator	87	Lock Screen	111
YouTube	87	Security	113
Section 7: Connections	88	Language and input	116
Wi-Fi	88	Back up and reset	121
Bluetooth	90	Accounts	122
VPN	91	Accessory	122
Nearby devices	92	Date and time	123
Connecting to a Computer	93	Accessibility	123
Section 8: Settings	94	Developer options	126
Accessing Settings	94	About phone	128
Home screen mode	94	Section 9: Health and Safety Information	129
Airplane mode	95	Exposure to Radio Frequency (RF) Signals	129
Wi-Fi	95	Specific Absorption Rate (SAR) Certification	
Bluetooth	98	Information	134
Data usage	99	FCC Part 15 Information to User	136
Sound	102	Commercial Mobile Alerting System (CMAS)	137

Smart Practices While Driving	137
Battery Use and Safety	138
Samsung Mobile Products and Recycling ...	140
UL Certified Travel Charger	141
Display / Touch-Screen	141
GPS	142
Emergency Calls	142
Care and Maintenance	143
Responsible Listening	144
Operating Environment	146
FCC Hearing Aid Compatibility (HAC)	
Regulations for Wireless Devices	148
Restricting Children's Access to Your	
Mobile Device	151
FCC Notice and Cautions	151
Other Important Safety Information	151
Section 10: Warranty Information	153
Standard Limited Warranty	153
End User License Agreement for Software ..	158
Index	166

Section 1: Getting Started

This section helps you to quickly start using your phone.

Understanding this User Manual

The sections of this manual generally follow the features of your phone. A robust index for features begins on page 153.

Also included is important safety information beginning on page 129, that you should know before using your phone.

This manual gives navigation instructions according to the default settings. If you select other settings, navigation steps may be different.

Unless otherwise specified, all instructions in this manual assume that you are starting from the Home screen. To get to the Home screen, you may need to unlock the phone. For more information, see *“Securing Your Phone”* on page 13.

Note: Instructions in this manual are based on default settings, and may vary from your phone, depending on the software version on your phone, and any changes to the phone’s Settings.

Unless stated otherwise, instructions in this User Manual start with the phone unlocked, at the Home screen.

All screen images in this manual are simulated. Actual displays may vary, depending on the software version of your phone and any changes to the phone’s Settings.


Special Text

In this manual, you'll find text that is set apart from the rest. These are intended to point out important information, share quick methods for activating features, to define terms, and more. The definitions for these methods are as follows:

- **Notes:** Additional information about the current topic.
- **Tips:** Quick or innovative methods, or useful shortcuts.
- **Important:** Information about the current topic that could impact performance.
- **Warning:** Information to prevent loss of data or functionality, or even prevent damage to your phone.

Text Conventions

This manual provides condensed information about how to use your phone, including these conventions:

- Arrows represent the sequence of selections in procedures. For example:
From the Home screen, touch  **Menu** → **Settings** → **Wi-Fi**.



Many settings use an ON/OFF toggle. Touch the ON/OFF toggle to turn a setting ON or OFF. This graphic is used to represent the ON/OFF toggle.

Battery

Your phone is powered by a rechargeable, standard Li-Ion battery. A Wall/USB Charger (Charging Head and USB cable) are included with the phone, for charging the battery.


The battery comes partially charged. You must fully charge the battery before using your phone for the first time. A fully discharged battery requires up to 4 hours of charge time. After the first charge, you can use the phone while charging.

Warning! Use only Samsung-approved charging devices and batteries. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

Non-Supported Batteries

Using a non-approved battery may damage your phone. Samsung phones do not support non-approved batteries. Samsung charging accessories, such as the Wall/USB Charger, will only charge approved batteries.

Battery Indicator

The battery icon  in the Status Bar shows battery power level. Before the battery becomes too low to operate, the empty battery icon will flash and a tone will sound. If you continue to operate the phone without charging, the phone will power off.

Tip: For settings you can configure to extend battery life, see “Power saving mode” on page 108.

For information about what’s using battery power, see “Battery” on page 108.

Battery Cover

The battery is installed under a removable cover on the back of the phone.

Removing the battery cover

- Pull up using the slot provided, while lifting the cover off the phone.




Installing the battery cover

- Align the cover and press it firmly into place, making sure it snaps into place.

Installing and Removing the Battery

Installing the battery

1. Remove the battery cover.
2. Insert the battery into the phone, aligning the gold contacts on the battery with the gold contacts in the phone.
3. Replace the battery cover.



Removing the Battery

1. Remove the battery cover.
2. Lift the battery out of the phone, using the slot provided.
3. Replace the battery cover.

Charging the Battery

Your phone comes with a Wall/USB Charger (Charging Head and USB cable) to charge your phone from any 110/220 VAC outlet.

Note: The battery comes partially charged. You must fully charge the battery before using your phone for the first time. After the first charge, you can use the phone while charging.

1. Insert the USB cable into the USB/Accessory port.



2. Connect the USB cable to the charging head.
3. Plug the charging head into a standard AC power outlet.
4. When charging is complete, unplug the charging head from the power outlet and remove the USB cable from the phone.

Turning Your Phone On and Off


Turning Your Phone On

- Press and hold the  **Power/Lock Key** for a few seconds, until the start-up sequence begins.

While powering on, the phone connects with the network, then displays the Home screen and active alerts.





Turning Your Phone Off

1. Press and hold the  **Power/Lock Key** until the Phone options menu appears.
2. At the Phone options menu, select **Power off**.

Setup Wizard



The first time you turn your phone on, the Setup wizard will prompt you to customize your phone. Follow the prompts to set.

You can also access Setup wizard at any time:



- From the Home screen, touch  **Apps** →  **Setup wizard**.

Help

Get information about using your phone.



- From the Home screen, touch  **Apps** →  **Help**.

Your Phone Number

- From the Home screen, touch  **Apps** →  **Settings** → **About phone** → **Status**. Your phone number displays under **My phone number**.

Your Google Account



Your new phone uses your Google account to fully utilize its Android features, including Gmail, Google Talk and Android Market. When you turn on your phone for the first time, set up a connection with your existing Google account, or create a new Google account.

- From the Home screen, touch  **Apps** →  **Gmail**. Follow the prompts.

Your Samsung Account

Create a Samsung account, for access to Samsung apps on your phone.

To create a Samsung account, or set up a Samsung account on your phone, use:



1. From the Home screen, touch  **Apps** →  **Settings** → **Add account**.
2. Touch **Samsung account** and follow the prompts.

Voicemail


All unanswered calls to your phone are sent to voicemail, even if your phone is turned off, so you'll want to set up your voicemail and personal greeting as soon as you activate your phone.

For more information, see *"Voicemail"* on page 63.

TTY Mode

Your phone is TTY-compatible, allowing you to connect a TTY device to the phone's headset jack. Before you can use your phone with a TTY device, you'll need to enable TTY Mode in Call Settings, at  **Phone** →  **Menu** → **Call settings** → **TTY mode**.

Roaming


When you travel outside your home network's coverage area, your phone can roam to acquire service on other compatible digital networks. When Roaming is active, the  Roaming icon appears in the Status Bar of the display.

Tip: You can set your phone's roaming behavior. For more information, see *"Mobile networks"* on page 100.

During roaming, some services may not be available. Depending on your coverage area and service plan, extra charges may apply when making or receiving calls. Contact Verizon Wireless for more information about your coverage area and service plan.

Task Manager

Your phone can run apps simultaneously, with some running in the background. Use Task manager to see apps running on your phone, end running apps to extend battery life, uninstall apps, and see how memory is used by applications.

1. From any screen, touch and hold  **Recent**, then select **Task manager**.
2. Touch the **Active applications** tab to view applications running on your phone. Touch **End**, or **End all** to close applications.
3. Touch the **Downloaded** tab to view information about applications you've installed on your phone. Touch **Uninstall** to remove an application from your phone.
4. Touch the **RAM** tab to display the amount of RAM (Random Access Memory) in use. Touch **Clear Memory** to clear processes to increase available RAM.
5. Touch the **Storage** tab for System and SD card statistics.
6. Touch the **Help** tab for tips for extending battery life.

Tip: Touch and drag your finger on the tabs to scroll the tabs.

Memory Card

Your phone supports removable microSD™ or microSDHC™ memory cards of up to 64GB capacity, for storage of music, pictures, and other files.






Important! To prevent damage to information stored on the memory card, always unmount the card before removing it from the phone.

Installing a Memory Card

1. Open the memory card cover.
2. With the gold contacts facing down, slide the memory card into the slot, pushing gently until it clicks into place.
3. Close the memory card cover.

Unmounting and Removing a Memory Card

Important! To prevent damage to information stored on the memory card, unmount the card before removing it from the phone.



1. From the Home screen, touch  **Apps** →  **Settings** → **Storage** → **Unmount SD card**.
2. At the prompt, read the warning and select **OK** to continue. Wait for the  **SD card removed** icon to appear in the Status bar and Notification panel.
3. Open the memory card cover.
4. Gently press on the memory card, then release so that it pops out from the slot, and carefully pull the card out.
5. Close the memory card cover.

Securing Your Phone

Use your phone's security features to secure your phone.

Note: Instructions in this manual are based on default settings, and may vary from your phone, depending on the phone's software version, and any changes to Settings.

Unless stated otherwise, instructions in this User Manual start with the phone unlocked, at the Home screen.

To set a personal screen lock, touch  **Apps** →  **Settings** → **Lock screen** → **Screen lock**. For more information, see “*Lock Screen*” on page 111.

For other settings related to securing your phone and information, touch  **Apps** →  **Settings** → **Security**. For more information, see “*Security*” on page 113.

Locking the phone

- By default, the phone locks automatically when the screen times out.

– or –

Lock the phone by pressing the  

Power/Lock Key.

Tip: When the phone is locked with a personal screen lock, the Emergency call feature is available on the lock screen, to allow emergency calls even while the phone is locked.

Unlocking the phone

Unlock the phone using one of the default unlock screens, or for increased security, use Face Unlock, Face and voice unlock, a pattern, a PIN, or password.

- Press the   **Power/Lock Key**, then swipe the screen to unlock.

Tip: Special notification icons display for missed calls or new messages. Drag a missed call or message icon to view the message or call log.

Section 2: Understanding Your Phone

Features


- 4-inch 800x480 WVGA touch screen
- CDMA 1X/EV-DO Rev-A /3G Wireless Technology
- Android[®] 4.1.2 platform
- Google[®] applications, including Google Talk[®] and Gmail[®]
- Google Play[™] Store, plus pre-loaded applications
- Connections
 - Wi-Fi[®] 802.11 a/b/g/n
 - Bluetooth 4.0
 - VPN
- Messaging
 - Text
 - Picture
 - Video
 - Voice
 - Email
 - Chat
- 3.2 Megapixel Camera/Camcorder + 1.3 Megapixel Front camera
- DivX Certified[®] to play DivX[®] video up to HD 720p, including premium content
- Speakerphone
- Support for microSD[™] and microSDHC[™] Memory Cards up to 64GB capacity

Front View



- **1.3 Megapixel Front Camera:** Captures pictures or video.
- **Proximity and Light Sensors:** Detects the presence of nearby objects to control screen display, such when you hold the phone to your ear during a phone call. Detects ambient light to determine screen brightness when the Automatic brightness setting is enabled, and when taking pictures with the Front Camera.
- **Earpiece:** Plays sounds during calls.
- **LED Indicator:** Flashes or glows for alerts or phone status.
- **Back:** Touch to return to the previous screen or option.
- **Home:** Touch to display the Home screen.
- **Recent:** Touch to choose from a list of recent apps or screens, or to launch Task Manager.
- **Menu:** Touch to display a context-sensitive menu of options for the current screen.

Side Views



- **Volume Key:** From the Home screen, press to adjust master volume. During calls or media playback, press to adjust volume. Press to mute the ringtone of an incoming call.
- **Memory Card Slot:** Install an optional memory card (not included), for additional storage of files.
- **Power / Lock Key:** Press and hold to turn the phone on or off. Press to lock the phone, or to wake the screen for unlocking.

Back View



- **3.5mm Headset Jack:** Plug in an optional headset or TTY equipment (not included).
- **3.2 MP Camera:** Captures pictures or video.
- **Microphones (top and bottom):** Captures sound during recording, calls, and video chat.
- **USB/Accessory Port:** Connect a USB cable for charging or to sync music and files.
- **External Speaker:** Plays ringtones, call audio when in Speakerphone mode, music and other sounds.

Display



- **Status bar:** Presents icons to show phone status and notifications.
- **Widgets:** Apps that run on the Home screen. These widgets appear on the Home screen by default, and you can add your favorites. For more information about adding widgets to the Home screen, see “*Apps and widgets*” on page 26.
- **App Shortcuts:** Shortcuts to apps. These shortcuts appear on the Home screen by default, and you can add more shortcuts to your favorite apps. For more information about adding apps to the Home screen, see “*Apps and widgets*” on page 26.

Note: Unless stated otherwise, instructions in this User Manual start with the phone unlocked, at the Home screen. All screen images in this manual are simulated. Actual displays may vary, depending on the software version of your phone and any changes to the phone’s Settings.

Home screen

The Home screen consists of the Home page, plus pages that extend beyond the display width to provide more space for adding shortcuts, widgets and folders.



Slide your finger horizontally across the screen to scroll to the left or right side pages. As you scroll, the indicator at the bottom of the display shows your current position.

Home screen mode

Your phone offers two Home screen modes:

- **Starter mode** provides an easier experience for the first-time smartphone user.
- **Standard mode** provides a conventional layout for apps and widgets on the Home screen.

The first time you turn your phone on, the default mode is Standard, however you'll be prompted with the option to change the mode in the Setup Wizard. You can also choose to change the mode at any time in Settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Mode change**.
2. Select a mode, then touch **Apply**.


Customizing the Home Screen

Customize the Home screen to suit your preferences.


- **Add Apps and widgets:** For more information, see “*Apps and widgets*” on page 26.
- **Add Folders:** For more information, see “*Folders*” on page 27.
- **Change the Wallpaper:** For more information, see “*Wallpaper*” on page 27.

Adding and removing Home screen pages

You can customize the Home screen to include up to the seven default pages, and set the page order.

1. From the Home screen, touch  **Menu** → **Edit page**.

– or –

Pinch the Home screen, then choose  **Add to Home screen** to add a page.

2. Touch and drag pages to change their order, and use these controls to configure pages:




Remove: Touch and hold a page, then drag it to **Remove**.



Add: Touch to add a page, to a total of seven.



Home: The page with this icon displays when you touch  **Home**.

Tip: You can also “pinch” the screen to display options for editing the Home screen.

LED Indicator

The LED indicator , on the front of the phone above the screen (see “*Front View*” on page 16) animates or glows to show alerts or phone status.

- **Blue:**
 - Pulsates in multi-color blue while the phone is turning On or Off.
 - Blinks blue for a missed call, message or other notification.
- **Red:**
 - Glows red when the phone is connected to a charger and charging.
 - Blinks red when the phone is connected to a charger and there is a problem with charging.
 - Blinks red when battery power is low (phone not connected to charger).
- **Green:**
 - Glows green when the phone is connected to a charger and the battery is fully charged.

Navigation

Touch

Touch items to select or launch them. For example:

- Touch the onscreen keyboard to enter characters or text.
- Touch an item to select it.
- Touch an app icon to launch the application.

Touch and Hold

Activate items by a touch and hold gesture. For example:

- Touch and hold a widget on the Home screen to move it.
- Touch and hold a field to display a pop-up menu of options.

Swipe

Swipe your finger across the screen. For example:

- Unlocking the screen
- Scrolling the Home screen or a menu
- Combine touch and hold with swipe to drag an item.

Pinch


Using two fingers, make a pinch motion on the screen. For example:

- Pinch in to zoom in on pictures or screens.
- Pinch out to zoom out on pictures or screens.

Notifications

Notifications gives information about connections, alerts and other items.

- Drag your finger downward from the top of the screen.




World Clock

While displaying Notifications, touch the time in the Status bar to display a World clock. Add cities to the clock to display the time in different zones around the world.

Using Notifications

While viewing Notifications, use these options:

- Touch a notification to launch the app or feature.
- **Clear:** Touch to clear all notifications
- **Settings:** Control popular settings. Slide your finger right and left to access all the settings.
 - Touch  to go to **Settings**.
 - **Bluetooth:** Turn Bluetooth on or off.
 - **GPS:** Turn Standalone GPS services on or off.
 - **Sound:** Switch between your Sound settings, and the two Silent modes, Mute and Vibrate.
 - **Screen rotation:** Enable or disable the Auto rotation setting, to control whether the screen automatically updates when you rotate the phone.
 - **Airplane Mode:** Turn airplane mode on or off.
 - **Mobile data:** Activate or deactivate your phone's access to the mobile data network.
 - **Power saving:** Enable or disable Power saving mode.
 - **Driving mode:** Enable or disable Driving mode, to have incoming caller ID and text messages read out.
 - **Sync:** Enable or disable synchronization with your accounts.

Status Bar

The Status Bar shows network and battery status and other details, including these icons.



Airplane Mode Active: All wireless communications are disabled. See “Airplane mode” on page 95.



USB Connected: The phone is connected to a computer using a USB cable. For more information about transferring data between your phone and a computer, see “*Transferring Data*” on page 93.



Voice Call: A voice call is in progress.



Speakerphone: Speakerphone is enabled.



Missed Call: Displays when there is a missed call.



Mute: Voice or playback volume is muted.



Battery Level: Shown fully charged.



Battery Charging: Battery is charging.



Device Power Critical: Battery has very little power remaining. Charge immediately.



GPS Location Active: One or more GPS location services are active. See “Location services” on page 109.



No Network: No wireless network is available.



3G connection: Phone is active on a 3G system. The arrows are colored when data is being transferred.



Signal Strength: Current signal strength. The greater the number of bars, the stronger the signal.



Signal Strength Roaming, Open: Current signal strength, when the phone is roaming. The greater the number of bars, the stronger the signal.



Signal Strength Roaming, CDMA: Current signal strength, when the phone is roaming on CDMA networks. The greater the number of bars, the stronger the signal.



Wi-Fi Active: Wi-Fi is active, and connected to a Wi-Fi network. The greater the number of rays, the stronger the signal. The arrows are colored when data is being transferred. For more information about configuring Wi-Fi, see “*Wi-Fi*” on page 88.



Wi-Fi Action Needed: Action needed to connect to Wi-Fi network. For more information about configuring Wi-Fi, see “*Wi-Fi*” on page 88.



New Message: You have new message(s).



New Voicemail: You have new voicemail. A number indicates the number of new messages.



New Email Message: You have new email.



Download Successful: A file was downloaded successfully.



Update Available: An update is available for an installed app.



Update Successful: An update was installed for an app.



Alarm: An alarm is set.



Silent mode: All sounds except media and alarms are silenced, and Vibrate is not active. See “Mute” on page 102.



Vibrate: Vibrate Silent mode is active. See “Mute” on page 102.



Music Playing: Music is playing, but the app is in the background. You can control playback from Notifications, or from Music player.



Music Paused: Music playback is paused. You can control playback from Notifications, or from Music player.



SD Card Ready: A memory card scan is underway, to prepare the card for use. For more information about using memory cards, see “Memory Card” on page 12.



SD Card Safe to Remove: A memory card was unmounted, and it is safe to uninstall it. For more information about using memory cards, see “Memory Card” on page 12.



SD Card Removed: A memory card was uninstalled. For more information about using memory cards, see “Memory Card” on page 12.



Bluetooth Active: Bluetooth is turned on. For more information, see “Turning Bluetooth On or Off” on page 90.



Bluetooth Paired: Your device is paired with another Bluetooth device. For more information, see “Pairing with a Bluetooth Device” on page 90.




TTY: TTY Mode is active.



ECB: Emergency Call Back Mode is active.

Apps and widgets

Customize the Home screen by adding or removing apps and widgets.

Access apps or widgets directly from the Home screen, or touch  **Apps**, then select from the Apps or Widget tabs.

Primary apps

Primary apps appear at the bottom of the Home screen.

You can exchange the primary apps with other apps.

- From the Home screen, touch and hold an app, then drag it to replace a primary app.

– or –

Touch and hold an app, then drag it from the primary apps area to a Home screen page. Then, you can drag another app to the now-empty space.


Arranging Apps and widgets on the Home screen

- Touch and hold an app, then drag it to a new location.


Adding Apps and widgets to the Home screen

1. Navigate to a Home screen panel.
2. Touch and hold the screen, select **Apps and widgets** from under the **Add to Home screen** menu, then touch an app or widget to add it to the Home screen.

– or –

Touch  **Apps**, then touch and hold an app or widget to place it on the Home screen.


Removing Apps and widgets from the Home screen

- Touch and hold the app or widget until  **Remove** appears, then drag it to the Delete icon.


Folders

Place Folders on the Home screen to organize items. After placing a folder, touch it to name it, and drag apps or widgets to the folder to store them in the folder.

Creating Folders on the Home screen

1. Navigate to the desired Home screen.
2. Touch and hold the screen, select **Folder** from under the **Add to Home screen** menu.
– or –
Touch  **Menu** → **Create folder**.
3. Touch the new folder to give it a name.

Removing Folders

- Touch and hold the Folder until  **Remove** appears, then drag the Folder to the Delete icon.

Wallpaper

Choose a background for the the Home screen. You can choose from pre-loaded wallpapers, or select a picture from Gallery.

1. From the Home screen, touch and hold the screen to select **Set Wallpaper** from under the **Home screen** menu. Choose from **Home screen**, **Lock screen**, or **Home and lock screens**.
2. Choose a source for images:
 - **Gallery**: Access the Gallery to choose a picture from an installed memory card. Touch a picture to select it, then use the crop tool to resize the picture, if desired. Touch **Done** to save the picture as wallpaper.
 - **Live wallpapers**: Choose from pre-loaded animated wallpapers. Touch a wallpaper to see an example, then touch **Set wallpaper**.
 - **Wallpapers**: Choose from pre-loaded wallpaper images. Touch a wallpaper, then touch **Set wallpaper**.

Note: You can also choose Wallpaper in Settings.

Touch  **Apps** →  **Settings** → **Display** → **Wallpaper**.

Entering Text

Your phone offers three text input methods, Samsung keyboard, Google voice typing, and Swype:

- Samsung keyboard: Enter text on a virtual QWERTY keyboard.
- Google voice typing: Speak your inputs.
- Swype: Swype, Speak, Write, or Tap your input.


Using Samsung Keyboard

Samsung keyboard is a virtual QWERTY keyboard for text entry, featuring optional predictive text. Input characters by tapping the on-screen keys with your finger.

You can enable predictive text, to have the Samsung keyboard match your key touches to common words and displays them. Select a word from the display to insert it into your text.

Configuring Samsung keyboard

Configure the Samsung keyboard to your preferences.


- From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Samsung keyboard**. For more information, see “*Samsung keyboard*” on page 117.
- While entering text with Samsung keyboard, touch and hold , then select  from the pop-up menu.



Entering Upper and Lower Case Letters

The default case is lower case (abc). Enter upper and lower case alphabet letters by touching the Shift key to toggle the case, before touching the letter key(s).

- Touch once to switch from abc to Abc mode
- Touch and hold to switch to ABC mode

Entering Symbols and Numbers

To enter common symbols, touch  to switch to symbol mode, then touch the corresponding key.

To enter less-common symbols, touch  → , then touch the corresponding key.

Enter numbers by touching , then touching the number keys.

Using Predictive text

By using Predictive text, you can have next-letter prediction and regional error correction, which compensates for pressing the wrong keys on the QWERTY keyboard.


Note: Enable Predictive text in Samsung keyboard settings, to have the Voice Input appear on the keyboard. For more information, see “*Samsung keyboard*” on page 117.

- While entering characters, potential word matches display in the Predictive text area above the keyboard. Touch a word to insert it into your text.

Using Google Voice Typing



Use your voice to enter text using the Google Voice typing feature.

When you enable the Google voice typing setting, you can access Google Voice Typing from the Samsung keyboard.

- From the Samsung keyboard, touch , then speak your input.



Configuring Google voice typing

Configure the Samsung keyboard to your preferences.

1. From the Home screen, touch  **Apps** →  **Settings** → **Samsung keyboard**.
2. Touch **Google voice typing**. A checkmark indicates selection.

Note: For more information, see “*Google voice typing settings*” on page 117.

– or –

While entering text, touch and hold , then select  from the pop-up menu.

Using Swype

With Swype, you have the ability to switch seamlessly between four different input modes - Swype, Speak, Write, or Tap.

Configuring Swype


- From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Swype**.

Editing Text


Use the text selection tools to select text or position a cursor for inserting text, then use the editing tools to select, cut, copy and paste text.

Note: Some applications do not support editing, or may offer other ways to select and modify text.


Inserting new text

- Touch the text to display the  insertion cursor (touch and drag the cursor into position in the text if needed).


Selecting text

- Touch and hold the text you want to select to display the  selector cursors, then touch and drag the cursors to highlight the text you want to select.

– or –



Touch and hold text, then touch  **Select** from the pop-up text editing menu.

Copying or Cutting Text

1. Touch and hold on the text you want to select to display the  selector cursors. Touch and drag the cursors to highlight the text you want to cut or copy.

Touch  **Cut** or  **Copy** from the pop-up text editing menu.

Pasting Copied or Cut Text

1. Touch in a text entry field to display the  insertion cursor (touch and drag the cursor into position in the text, if needed).
2. Touch  to display a pop-up menu. Touch **Paste** to paste the last copied item, or touch **Clipboard** to select other copied items.




Section 3: Calling

Making Calls

Your phone offers multiple ways to make calls:

- Use the touch screen **Keypad** to enter the phone number or speed dial number.
- Call a contact from **Contacts**.
- Call a contact from **Favorites**.
- Return a call, or call a recent caller, from **Recent**.
- Voice dial using **S Voice**.

Making Calls Using the Phone Keypad

1. From the Home screen, touch  **Phone**.
2. Touch the digits of the telephone or speed dial number on the **Keypad**. If you enter an incorrect number while dialing, touch  to backspace to clear it.
3. Touch  to place the call.

Making Calls using Speed Dials

Speed Dials are 1-, 2-, or 3-digit shortcuts (1 to 100) you assign to contacts, to allow you to quickly call the contact.

For more information about setting speed dials, see “*Speed Dials*” on page 53.

Note: Some speed dials are reserved by default, and cannot be assigned:


Speed dial 1 is reserved for Voicemail.

Speed dial 97 is reserved for balance inquiries.

Speed dial 98 is reserved for minutes inquiries.

Speed dial 99 is reserved for payment inquiries.


Speed dial 100 is reserved for data usage inquiries.

-
1. From the Home screen, touch  **Phone**.
 2. Touch the digits of the speed dial number on the **Keypad**, holding the last digit until the number dials.

Making Calls from Contacts

A contact is an entry that you have created to store the name, numbers, and other information for people or groups of interest.



For more information, see “*Contacts*” on page 45.

1. From the Home screen, touch  **Contacts**.
2. Slide your finger across the contact item, left to right.
– or –

Touch a contact to display its Contact entry, then touch a phone number to dial .

Making Calls using S Voice

Place a call by speaking the name or number.

1. From the Home screen, touch  **Phone**, then touch  **S Voice**.
2. Touch **Confirm** after reading the Samsung Disclaimer.
3. Touch **Agree** to accept the Terms of Service.
4. Touch **Next** and read the tutorial informat and follow the prompts.



5. At the beep, speak a command, for example:

- **Call <Name or #>**: Call an entry in your Contacts list or a spoken phone number. Ex: Call Charlie mobile.
- **Dial <Name or #>**: Call an entry in your Contacts list or a spoken phone number.
- **Redial <Name or #>**: Repeat a recent call.

Making Calls using Favorites

Favorites are contacts that you designate as favorites by adding a ★ **Star** to their contact record.


For more information about creating favorites, see “Favorites” on page 51.

1. From the Home screen, touch  **Phone**.
2. Touch the  **Favorites** tab to display favorites.
3. Slide your finger across a favorite, left to right, to dial the default number for the contact.

– or –

Touch and hold a favorite, then select **Call** from the pop-up menu.



– or –

Touch a contact to display its Contact entry, then touch a phone number to dial it or touch  to dial the default number for the contact.

Making Calls from Recent calls

Return a call, or call a number from a recent call.

For more information about Recent calls, see “Recent calls” on page 36.




1. From the Home screen, touch  **Phone**.
2. Touch the  **Recent** tab to display recent calls.
3. Slide your finger left-to-right across a recent call.

– or –

Touch the recent call to view its details, then touch .


Making Multi-party Calls

Merge calls to set up a multi-party call between you and two other parties.

1. Establish a call, either by dialing or answering an incoming call.
2. Touch  **Add Call**. The first call is placed on hold, and the **Keypad** displays.
3. Enter the second phone number, then touch .
4. Touch  **Merge**. The calls are joined into a multi-party call.

Answering Calls

You can answer incoming calls when the phone is locked or unlocked.

- Touch and drag  **Answer**.

Tip: To silence the ringtone for an incoming call, press the **Volume Key**.

Sending Calls to Voicemail

When your phone alerts you to an incoming call, you can reject the call to send the caller to voicemail, or reject the call and send a message to the caller.

Ignoring a call

- Touch and drag  **Reject**.


Ignoring a call with a message

- Touch and drag  **Reject call with message**, then choose a message or create a new message.

Note: For information about creating ignore messages, see “*Set reject messages*” on page 38.







Answering Call-Waiting Calls

When you receive a call while on a call:

- Touch and drag  **Answer** to answer the incoming call. The original call is placed on hold, and remains on hold until you end the second call, or swap calls back to the original call.
- Touch **Swap** to place a call on hold and return to the other call.

In-Call Options

While in a call, you can use these features:

- : Place the current call on hold, and display the keypad to set up a multi-party call.
- : Display the keypad to enter numbers.
- : End the phone call.
- : Enable or disable speakerphone.
- : Mute or unmute your voice on the call.
- : Switch the call's audio to a Bluetooth headset (headset must be already paired with the phone).



Ending a Call

- Touch .

Recent calls




When you place, answer, or miss a call, a record of the call is saved in the Recent calls.

Accessing Recent calls



- From the Home screen, touch  **Phone** →  **Recent**.

Sending Messages using Recent calls

Create a new message, with the phone number from a recent call entered in the To list.

1. From the Home screen, touch  **Phone** →  **Recent**.
2. Slide your finger right-to-left across a recent call.
– or –
Touch the recent call to view its details, then touch .
3. Continue creating the message. For more information, see *“Creating and Sending Messages”* on page 56.




Adding or Updating Contacts Using Recent calls

1. From the Home screen, touch  **Phone** →  **Recent**.
2. Touch and hold a call record, then select **Add to Contacts** from the pop-up menu, then touch **Create contact** or **Update existing**.
– or –
Touch the recent call to view its details, then touch **Create contact** or **Update existing**.
3. At the **Save contact to** prompt, touch an account for saving the contact (available options depend on the accounts you have set up).
4. Continue entering contact information. For more information, see *“Contacts”* on page 45.




Managing Recent calls

Review and delete call records.

Deleting Recent call records




1. From the Home screen, touch  **Phone** →  **Recent**.
2. While viewing Recent calls, touch  **Menu** → **Delete**.
3. Touch call records to mark them for deletion, or touch **Select all**.
4. Touch **Delete** to delete marked records.

Filtering Recent call records

1. From the Home screen, touch  **Phone** →  **Recent**.
2. While viewing recent calls, touch  **Menu** → **View by**, then select a type of call or message.

Viewing Recent call durations

View the length of the recent calls.




1. From the Home screen, touch  **Phone** →  **Recent**.
2. While viewing the Call log, touch  **Menu** → **Call duration**.

Call Settings

Configure settings for calling with your phone.



Call restriction

Create and manage a list of phone numbers, to have your phone automatically reject calls you receive from those numbers.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Select **Call restriction** for these options (Incoming call, Outgoing call):
 - **Auto reject mode:** Touch  to turn Auto reject mode **ON** or **OFF**. When ON, calls from numbers on the Auto reject list will be rejected. Touch **All numbers** or **Auto reject numbers**.
 - **Auto reject list:** Enter telephone numbers to be rejected if Auto reject mode is ON. Turn on **Unknown number** to reject calls with no caller ID. Touch **Create**, then follow the prompts to enter numbers to reject, or select them from Contacts. Touch **Match criteria** to set options for using the reject number list.


Set reject messages

Create and manage text messages to send to callers when rejecting incoming calls. Messages you create here are available from the incoming call screen when you use the Reject with message option.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Set reject messages**.
3. Manage messages:
 - To create new messages, touch **Create**, then follow the prompts.
 - To modify an existing message, touch the message, then edit the text.



Ringtones and keypad tones

Choose tones and/or vibration to play for incoming calls and keypad touches.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Ringtones and keypad tones**.
3. Configure settings:
 - **Device ringtone:** Choose a ringtone to play for incoming calls.
 - **Device vibration:** Choose a vibration pattern, or create your own pattern, to play for incoming calls when Incoming call vibration is turned On. Vibration plays along with the ringtone, if Silent mode is not enabled.
 - **Vibrate when ringing:** When enabled, the Device vibration plays for incoming calls.
 - **Keypad tones:** When enabled, sounds play when you touch the Phone keypad.



Call alert

Set options for sounds and vibrations to occur during calls.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Call alert**.
3. Configure options:
 - **Call vibrations:** Enable **Vibrate on connection to network** to so the phone vibrates when it connects to the network. Enable on **Call-end vibration** to have the phone vibrate when the other caller ends the call.
 - **Call status tones:** Choose options for sounds to play during calls. Enable **Call connect tone** to have the phone play a tone when the other caller answers a call. Enable **Minute minder** to have a tone play once per minute during a call. Enable **Call end tone** to have the phone play a tone when the other caller ends the call. Touch **OK** to save the settings.
 - **Alerts on call:** Enable to have notifications for alarms and new messages play during phone calls. When disabled, these notifications will be muted during a call.



Answering/ending calls

Manage settings for answering and ending calls.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Answering/ending calls**.
3. Configure these options:
 - **The home key answers calls:** When enabled, you can answer an incoming call by pressing the Home Key.
 - **Answer calls using voice:** When enabled, you can answer an incoming call using a voice command.
 - **The power key ends calls:** When enabled, pressing the Power/Lock Key ends a call.



Turn off screen during calls

When enabled, the screen automatically turns off during phone calls, and the proximity sensor on the front of the phone is used to turn the screen back on when the phone is moved or brought close to another surface, such as when you move the phone to your ear.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Touch **Turn off screen during calls** to enable or disable the option.



Call accessories

Configure headset options for calls.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Call accessories**.
3. Configure settings:
 - **Automatic answering:** When enabled, and you have a headset connected to the Headset Jack, incoming calls are answered automatically after a delay, set at Automatic answering timer.
 - **Automatic answering timer:** Choose a time period to delay before automatically answering an incoming call when Automatic answering is enabled and a headset is connected to the phone.
 - **Outgoing call conditions:** When the phone is paired with a Bluetooth headset, you can choose to make calls even when the phone is locked.

My call sound



This option applies a sound equalizer to the call audio, in cases where you might need the sound softer or more clear, or optimized for your right or left ear.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **My call sound**.
3. Touch **My call sound settings** and select a sound settings for calls.
4. Touch **Personalize call sound** so you can find the best call sound to use during calls.
 - Connect your headphones and touch **Start** after reading the Notice.

Note: Close all multimedia applications before testing your personalized call sound.



Use extra volume for calls

When enabled, the call screen displays a volume control, for adjusting call volume during calls.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Touch **Extra volume on calls** to enable or disable the option.

Increase volume in pocket



When enabled, the phone uses the proximity sensor to detect when the phone is in a pocket or other close-fitting location such as a purse or bag, and increases the volume for incoming call ringtones.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Touch **Increase volume in pocket** to enable or disable the setting.

Additional settings



Noise reduction

When enabled, the effect of background noise is suppressed, to help you and the other caller hear better.




1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings** → **Additional settings**.
3. Touch **Noise reduction** to enable or disable the option.

Voicemail

Configure options for voicemail.

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Configure options:
 - **Voicemail service:** By default, your phone uses your wireless service provider's voicemail service. If you have another option for voicemail installed, select it here.
 - **Voicemail settings:** By default, the speed dial for calling voicemail for your service provider is *86 (*VM). If you wish to use another speed dial, touch Voicemail number to set a new one.
 - **Ringtone:** Choose a ringtone to play for a voicemail notification.
 - **Vibrate:** Choose an option for vibration to play for a voicemail notification.

Other call settings

1. From the Home screen, touch  **Phone**.
2. Touch  **Menu** → **Call settings**.
3. Configure options:
 - **Assisted dialing:** Set options to make dialing easier when using your phone while traveling (roaming). Enter the Country code and other codes, to be automatically dialed before any numbers you dial. Touch  to turn Assisted dialing ON or OFF. Touch **Assisted dialing** to configure codes.
 - **Auto retry:** When enabled, the phone will automatically redial a call if it receives a busy signal from the network.
 - **TTY mode:** Choose a TTY mode to enable TTY mode, for use with optional TTY equipment (not included).
 - **DTMF tones:** Set the length of Dual-tone Multi-frequency tones, which play when you use the keypad during a call, such as when navigating phone menus.
 - **Voice privacy:** Enable or disable Enhanced voice privacy, to improve the security of phone calls.

Section 4: Contacts and Accounts

Accounts

Your phone provides the ability to synchronize information, from a variety of accounts, including Email, Facebook, Google, and your Samsung account. Depending on the account, you can choose to synchronize your calendar, contacts, and other types of content.



Contacts from your accounts appear in your phone's Contacts.

With synchronization, you can ensure that information on your phone is updated with any information that changes in your accounts.

Controlling Synchronization

You can choose to have your phone automatically sync with your accounts, or manually synchronize each account when you want to check messages.

You may also choose to limit automatic or background synchronization to extend battery life.

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Under **Accounts**, select the account to manually sync an individual account and then touch **Sync now**. Configure automatic sync options with the account's settings.


– or –

To sync all accounts of the same type (such as multiple email accounts), select any account and touch **Sync all**.

Tip: You can also control synchronization from Notifications, with the Sync setting. For more information, see *“Using Notifications”* on page 23.

Setting Up Your Accounts



Set up and manage your accounts with the Accounts and sync settings.

For information about setting up other, non-synchronized email accounts, see “*Setting Up Email Accounts*” on page 60. When you set up email accounts, the accounts appear in  **Email**.



Tip: For more information on setting up your email, visit the Smartphone Resource Center at:

<https://smartphones.verizonwireless.com>



Adding an account

1. From the Home screen, touch  **Apps** →  **Settings** → **Add account**.
2. Select an account provider, then follow the prompts to enter your credentials and sign in.
3. The phone communicates with the provider’s server to set up your account on the phone.



Managing accounts

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Select an account, then touch a setting to enable or disable synchronization. When enabled, a check mark appears in the check box.

Adding a Microsoft Exchange ActiveSync account

1. From the Home screen, touch  **Apps** →  **Settings** → **Add account**.
2. Touch **Microsoft Exchange ActiveSync**, then follow the prompts to enter your credentials and other details.
3. The phone communicates with the provider’s server to set up your account on the phone.

Adding a Facebook account

1. From the Home screen, touch  **Apps** →  **Settings** → **Add account**.
2. Touch **Facebook**, then follow the prompts to enter your credentials and other details.
3. The phone communicates with the Facebook server to set up your account on the phone.

Contacts

Use Contacts to store information for your friends, family and colleagues, to make contacting them easy.



To access Contacts:







- From the Home screen, touch  **Contacts**.

Contact tips:

- Swipe your finger left-to-right across a contact to make a call to the contact.
- Swipe right-to-left across a contact to create a message addressed to the contact.

Creating Contacts

1. From the Home screen, touch  **Contacts** → .
2. At the prompt, select a save option for the contact (options depend on accounts set up):
 - **Phone**: Save to the phone's Contacts.
 - **Google**: Save to your Google account.
 - **Add new account**: Create new account and save.

3. Touch contact fields to enter information. While entering information, touch  to add information to an existing field, or  to delete a field. Touch **Add another field** to create a new field for the contact.
 - Touch  **Photo ID** to choose a picture to identify the contact.
 - Touch **Name** to enter a name for the contact. Touch  to enter **Name prefix**, **First name**, **Middle name**, **Last name**, or **Name suffix**.
 - Touch **Phone number** to enter a phone number, then touch  to choose a label, from **Mobile**, **Home**, **Work**, **Work Fax**, **Home Fax**, **Pager**, **Other**, **Custom** or **Callback**.
 - Touch **Groups** to assign the contact to a group. For more information about Groups, see *"Groups"* on page 51.
 - Touch **Ringtone** to choose a ringtone for the contact.
 - Touch **Message Alert** to choose a ringtone for alerts.
 - Touch **Vibration pattern** to choose a vibration pattern to play with the ringtone when this contact calls or sends a message.
 - Touch **Add another field** to add more fields, including **Phonetic name**, **Organization**, **Email**, **IM**, **Address**, **Notes**, **Nickname**, **Website**, or **Relationship**.
4. Touch  **Save** to save the contact.


Creating Contacts from Recent calls


Save a phone number from a recent call to create a new contact, or update an existing contact.

For more information, see *“Adding or Updating Contacts Using Recent calls”* on page 36.

Creating Contacts from the Phone Keypad




Enter a phone number with the Phone Keypad, then save it.

1. From the Home screen, touch  **Phone**.
2. Touch the digits of the phone number on the **Keypad**.
3. Touch **Add to Contacts**, then select **Create contact** from the pop-up menu.
4. Continue entering contact information. For more information, see *“Creating Contacts”* on page 45.

Tip: While entering a phone number, you can add waits or pauses. Enter the number up to the pause or wait, then touch  **Menu** to select **Add 2-sec pause** or **Add wait**.


Updating Contacts

Make changes to update an existing contact.

1. From the Home screen, touch  **Contacts**.
2. Touch a contact to display it, then touch  **Edit**.
3. Continue entering contact information. For more information, see *“Creating Contacts”* on page 45.
4. Touch  **Save** to save the contact.

Updating Contacts from the Phone Keypad

Enter a phone number with the Phone Keypad, then save it.



1. From the Home screen, touch  **Phone**.
2. Touch the digits of the phone number on the **Keypad**.
3. Touch **Add to Contacts**, then select **Update existing** from the pop-up menu.
4. Select a contact to update, then continue entering contact information. For more information, see *“Creating Contacts”* on page 45.

Updating Contacts from Recent calls


Save a phone number from a recent call to create a new contact, or update an existing contact.

For more information, see *“Adding or Updating Contacts Using Recent calls”* on page 36.



Choosing Contacts to Display

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Contacts to display**:
 - Choose **All contacts** to show all contacts.
 - Choose an account to only display contacts from that account.
 - Touch **Phone** to show only show contacts saved to the phone.
 - Choose **Customized list** to select contact types for each account, or the phone.

Contacts Settings

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Settings**:
 - Select **Only contacts with phones** to show contacts with at least one stored phone number.
 - Touch **List by** to sort contacts by first or last name.
 - Touch **Display contacts by** to list contacts by first or last name.
 - Touch **Contact sharing settings** to set your preference for transferring contacts by Bluetooth contacts. For more information about sending contacts, see “*Sending Namecards (vCards)*” on page 50.

Other Contacts Options


1. From the Home screen, touch  **Contacts**.
2. Touch a contact to display it, then touch  **Menu**:
 - **History**: View calls and messages to and from this contact.
 - **Edit**: Modify contact information. For more information, see “*Updating Contacts*” on page 46.
 - **Delete**: Erase the contact record.
 - **Join contact/Separate contact**: Manage multiple contacts as one. For information, see “*Joining Contacts*” on page 49.
 - **Mark as default**: Set a default phone number or other field (such as IM or email address). Defaults are the contact method used when creating a message or calling a contact. You can also set a default by touching and holding on a contact field.
 - **Share namecard via**: Send the namecard. For information, see “*Sending Namecards (vCards)*” on page 50.
 - **Add to reject list**: Mark the contact so that calls or messages from the contact are rejected automatically. To remove a contact from the reject list, touch and hold the contact in the main contacts screen, then choose **Remove from reject list**.
 - **Print contact info**: Print the namecard via Bluetooth to a compatible Samsung Bluetooth-enabled printer (not included).

- **Add shortcut to home**: Add shortcut to this contact to the Home screen.

My Local Profile



My local profile is your own contact record, listed under ME in Contacts. You can send My local profile as a vCard via Bluetooth or as an attachment.

Creating My Local Profile

1. From the Home screen, touch  **Contacts**.
2. Touch **Set up profile**, then enter your information in the contact fields. For more information, see “*Creating Contacts*” on page 45.

Sending My Local Profile

You can send your profile as a vCard via Bluetooth to other Bluetooth devices, as an attachment, or via Wi-Fi Direct.


1. From the Home screen, touch  **Contacts**.
2. Touch your profile to display your contact information.
3. Touch  **Menu** → **Share namecard via**.
4. Choose a sending method, then follow the prompts to send the profile.

Joining Contacts



Your phone can synchronize with multiple accounts, including Google, Corporate, and other providers, plus social networking sites like Facebook. When you synchronize contacts from these accounts with your phone, you may have multiple contacts for one person.

Joining contact records allows you to see all the contact's numbers and addresses together. Joining also helps you keep your contacts updated, because any changes to information in the respective accounts is automatically updated the next time you synchronize with the account.

Joining contacts

1. From the Home screen, touch  **Contacts**.
2. Touch and hold a contact, then select **Join contact**.
3. Select a contact to join to the selected contact.

Separating contacts

1. From the Home screen, touch  **Contacts**.
2. Touch a contact to display its information.
3. Under the **Connection** heading, phone icons show how many contacts are joined to this one. Touch the **Connection** field to display joined contacts.
4. Touch  next to a contact to remove it from the displayed contact.

Exporting and Importing Contacts

You can export your contact list to and from USB storage (your phone's memory), or an installed memory card. Contacts are exported and imported as a special VCF file, and contacts are sent as vCards.



1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Import/Export**.

3. Select an option, then follow the prompts to complete the operation:
 - **Import from USB storage:** Copy contacts that are saved in phone memory.
 - **Export to USB storage:** Copy contacts to phone memory.
 - **Import from SD card:** Copy contacts from an installed memory card.
 - **Export to SD card:** Copy contacts to an installed memory card.
 - **Share namecard via:** Share contacts as vCards. For more information, see “*Sending Namecards (vCards)*” on page 50.

Sending Namecards (vCards)

You can send a contact namecard as a vCards via Bluetooth to other Bluetooth devices, or as an attachment via Gmail or Email.



Important! Not all Bluetooth devices will accept contacts, and not all devices support transfers of multiple contacts. Check the target device’s documentation.

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Import/Export** → **Share namecard via**.
3. Touch contacts to mark them for sending, or touch **Select all** to mark all contacts. A check mark appears in the check box for marked contacts.
4. Touch **Done**. At the prompt, choose a sending method, then follow the prompts to send the namecard:
 - **Bluetooth:** For more information about sending via Bluetooth, see “*Bluetooth*” on page 90.
 - **Email:** For more information about sending email, see “*Composing and Sending Email*” on page 62.
 - **Gmail:** For more information about sending Gmail, see “*Composing and Sending Gmail*” on page 63.
 - **Messaging:** For more information about sending messages, see “*Creating and Sending Messages*” on page 56.
 - **Wi-Fi Direct:** For more information about using Wi-Fi Direct, see “*Wi-Fi Direct*” on page 97.

Backing Up Contacts

Use Backup Assistant Plus to save a copy of your Contacts to a secure web site.

For more information, see “Backup Assistant Plus” on page 122.


1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Backup**.
3. Follow the prompts to log in to your Backup Assistant account.

Favorites

Mark contacts with a ★ star to identify them as Favorites.

Favorites display on the Favorites tab in the Phone and Contacts for fast dialing or messaging, and are indicated by the ★.

Creating Favorites

1. From the Home screen, touch  **Contacts**.
2. Touch and hold a contact, then select **Add to Favorites** from the pop-up menu.


– or –

Touch a contact to display it, then touch ★ at the top right of the screen.



Groups

Assign contacts to Groups to make searching for contacts faster, or to quickly call or send messages to group members. Your phone comes with pre-loaded groups you can use to add your contacts, or you can create new groups.



Accessing Groups

- From the Home screen, touch  **Contacts** → **Groups**.



Creating a New Group

1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch  **Menu** → **Create**, then enter information:
 - Touch **Group name** to enter a Group Name.
 - Touch **Group ringtone** to choose a ringtone for calls from members of this group.
 - Touch **Vibration pattern** to choose a vibration to play for calls from members of this group.
 - Touch **Add member** to select members from Contacts.
3. Touch **Save** to save the new group.



Editing a Group

1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch a Group to display it.
3. Touch  **Menu** → **Edit**, then update information for the group. For more information, see “*Creating a New Group*” on page 51.



Deleting a Group

1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch  **Menu**, then touch **Delete Groups**.
3. Touch a group to mark it for deletion, or touch **Select all** to mark all groups. When selected, a check mark appears in the check box. You cannot delete pre-loaded groups.
4. Touch **Delete**, then choose **Group only** or **Group and group members**.

Adding Contacts to a Group



1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch a **Group** to display it, then touch .
3. Touch contact(s) to mark them for addition, or touch **Select all** to mark all contacts. When selected, a check mark appears in the check box.
4. Touch **Done** to add the selected contact(s).

Removing Contacts from a Group

1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch a **Group** to display it.
3. Touch  **Menu** → **Remove member**.
4. Touch contact(s) to mark them for removal, or touch **Select all** to mark all contacts. When selected, a check mark appears in the check box.
5. Touch **Done** to remove the selected contact(s).

Sending a Message or Email to Group Members

Create a new text or email message, addressed to the group's members.

1. From the Home screen, touch  **Contacts** → **Groups**.
2. Touch a **Group** to display it.
3. Touch  **Menu** → **Send message** or **Send email**.
4. Touch contacts to mark them as recipients for the new message, then touch **Done**.
5. The new message opens, with the marked contacts as recipients. Continue creating the message, as desired. For more information, see “*Creating and Sending Messages*” on page 56, or see “*Composing and Sending Email*” on page 62.

Speed Dials

Speed dials are 1-, 2-, or 3-digit shortcuts (1 to 100) you assign to contacts, to allow you to quickly call the contact.

For more information about calling using speed dials, see “*Making Calls using Speed Dials*” on page 32.

Note: Some speed dials are reserved by default, and cannot be assigned:

Speed dial 1 is reserved for Voicemail.



Speed dial 97 is reserved for balance inquiries.

Speed dial 98 is reserved for minutes inquiries.




Speed dial 99 is reserved for payment inquiries.

Speed dial 100 is reserved for data usage inquiries.



Assigning Speed Dials

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Speed dial setting**.
3. A list of speed dials displays. Touch a speed dial, then touch a contact to assign the contact to the speed dial.

Removing or Reassigning a Speed Dial

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Speed dial setting**.
3. Touch  **Menu**, then choose an option:
 - **Change order:** Touch an assigned speed dial, then touch a new speed dial location to change the order.
 - **Remove:** Touch a speed dial to remove it.

Merging Contacts with Google

1. From the Home screen, touch  **Contacts**.
2. Touch  **Menu** → **Accounts**.
3. Tap the Gmail account name, tap the **Sync Contacts** checkbox, and then tap **Sync now**.
The merged contacts display in the Contacts list.

Section 5: Messaging

Types of Messages

Your phone supports these types of messages:






- **Text messages:** Send and receive simple messages containing text to other mobile phones or email addresses (also known as SMS).
- **Multimedia messages:** Send and receive text messages with pictures, video, and/or sound to other mobile phones or email addresses (also known as MMS).
- **Email:** Send and receive email from your email accounts, including Corporate email.
- **Gmail:** Send and receive Gmail from your Google account.
- **Emergency alerts:** Wireless Emergency Alerts from the Commercial Mobile Alert Service (CMAS). Emergency Alerts are geographically-targeted, and alert customers of imminent threats to their safety within their area. There is no charge for receiving an Emergency Alert
- **Voicemail:** Retrieve voice messages from callers.
- **Google Talk:** Chat with other Google Talk users.
- **Google+ Messenger:** Chat with other Google+ members.

Note: Messaging service availability depends on your network and service plan. Multimedia Messaging charges apply per your Calling Plan. Monthly plans are available. Higher rates apply for International Multimedia Messaging (when available). Compatible Device required. Consult Verizon Wireless for more information.

Text and Multimedia Messaging

Your phone can send and receive text and multimedia messages.



Creating and Sending Messages

1. From the Home screen, touch  **Messaging**.
2. Touch  **New message**.
3. Touch **Enter recipient** and enter a name, phone number or email address, or touch  to add recipients from Groups, Favorites, Contacts or Recent. As you enter text, matching contacts appear. Touch a contact to add it to the list.
4. Touch **Enter message**, then enter the message. While entering the message, use these options (available options depend on attachment):
 - Touch  **Attach** to add media or content to the message (converts the message to MMS).
 - Touch  **Menu** for options:
 - **Insert smiley**: Add a text emoticon to the message.
 - **Add text**: Select text from Memo, Calendar, Location, Contacts or Text templates to add.

- **Preview**: Displays the contents of the message prior to sending.
 - **Add to Contacts**: If the recipients are not saved in Contacts, save the information as a new contact or update an existing contact.
 - **Add slide/Delete slide**: Add or delete a slide. Slides hold pictures or other media, and adding a slide converts the message to MMS.
 - **Add subject**: Add a subject field (converts the message to MMS.)
 - **Duration (5 sec)**: Adjust the duration for viewing slides, default is 5 sec. (MMS messages only).
 - **Layout (bottom)**: Choose whether the message text appears after (Text on bottom) the attachment(s).
 - **Priority level**: Set the urgency of the message.
 - **Discard**: Deletes this message.
5. Touch **Send** to send the message.

Managing Messages



Messages you send and receive to the same contact, number or address are grouped together as a “thread”, so you can see all the messages you exchanged with a recipient in one place, like a conversation.

1. From the Home screen, touch  **Messaging**.
2. Message threads display by contact, number, or address. While viewing message threads, you have these options:
 - Touch and hold a thread to choose options, including:
 - **View Contact/Add to Contacts:** View the contact record, or save the sender/recipient’s information.
 - **Delete thread:** Erase the entire message thread.
 - **Save messages:** Saves the entire message thread.
 - Touch  **Menu** for options, including:
 - **Search:** Enter characters to search messages and recipients.
 - **Delete threads:** Touch message threads to mark them for deletion, or touch **Select all** to mark all message threads.
 - **Draft messages:** Displays all draft messages.
 - **Locked messages:** Displays all locked messages.

- **Saved messages:** Touch message threads to mark them for saving, or touch **Select all** to mark all message threads.
- **Settings:** Configure Messaging settings.
- **About:** View information about Messaging.

Message Settings

Configure settings for message storage, delivery, or alerts.

1. From the Home screen, touch  **Messaging**.
2. Touch  **Menu** → **Settings** for options:
 - **Display:**
 - **Bubble style:** Choose the appearance of messages in a message thread. Touch a bubble style for each side of the conversation, then touch **Save**.
 - **Background style:** Choose the appearance of the screen behind message threads. Touch a style, then touch **Save**.
 - **Use the volume key:** When enabled, you can press the Volume Key to change the size of message text while viewing the message.

- **General settings:**

- **Restore messages:** Restore saved messages to your inbox.
- **Delete old messages:** When enabled, messages are automatically erased when storage reaches default limits. When disabled, the phone will prompt you to delete old messages to make room.
- **Text message limit:** Set the number of SMS messages per conversation.
- **Multimedia message limit:** Set the number of MMS messages per thread.
- **Text templates:** Text templates are phrases that you can add to your messages. Use a pre-loaded text template, or create your own.

- **Text message (SMS) settings:**

- **Delivery reports:** When enabled, you receive a delivery report for text messages you send.

- **Multimedia message (MMS) settings:**

- **Delivery reports:** When enabled, you receive a delivery report for multimedia messages you send.
- **Auto-retrieve:** When enabled, MMS messages download automatically. When disabled, the phone prompts for download.

- **Roaming auto-retrieve:** When enabled, MMS messages download and display automatically when roaming. When disabled, the phone prompts you to download new MMS messages.
- **MMS alert:** When enabled, your device alerts you when a message changes from SMS to MMS, such as when you attach a picture.
- **Group conversations:** When you enter multiple recipients, the message is considered a group message. When this option is enabled, replies to the original message are sent to all recipients.

- **Notification settings:**

- **Notifications:** When enabled, message alerts display in the Status bar.
- **Select ringtone:** Choose a sound for message alerts.
- **Vibrate:** Configure vibration for message alerts.
- **Message alert repetition:** Choose the frequency of alerts for new messages.
- **Preview message:** When enabled, a preview of new messages appears in the Status Bar with the message notification.

- **Emergency message settings:**
 - **Emergency alerts:** This device is designed to receive Wireless Emergency Alerts from the Commercial Mobile Alert Service (CMAS), including Presidential Alerts, Imminent Alerts (Severe or Extreme), and AMBER Alerts (missing persons). You may choose not to receive Imminent and AMBER alerts, but Presidential Alerts cannot be disabled. All alerts are enabled by default (checkmark shown). For more information about Emergency Alerts see “*Emergency Alerts*” on page 60.
 - **Emergency notification preview:** Listen to an example of a Emergency Alert tone (and vibration, if enabled). The Emergency Alert tone plays at the same volume as your call ringtone.
 - **Vibrate:** Configure vibration for Emergency Alerts.
 - **Alert reminder:** Choose whether, and at what interval, your phone plays a sound to notify you of an Emergency Alert after the Emergency Alert tone has stopped.
- **Signature:**
 - **Add signature:** When checked, the Signature text is included in messages you send.
 - **Signature text:** Create a text signature to add to messages you send.
- **Callback number:**
 - **Enable callback number:** When enabled, the Callback number is included in messages you send.
 - **Callback number:** Enter a telephone number to include in messages.

Emergency Alerts



This device is designed to receive Wireless Emergency Alerts from the Commercial Mobile Alert Service (CMAS).

Emergency Alerts are geographically-targeted, and alert customers of imminent threats to their safety within their area. There is no charge for receiving an Emergency Alert.

There are three types of Emergency Alerts:

- Presidential
- Imminent (Severe or Extreme)
- AMBER Alerts (missing person alert)

Customers may choose not to receive Imminent Alerts and AMBER Alerts. Presidential Alerts can not be disabled. To disable Imminent Threat Alerts (Extreme and Severe) and AMBER Alerts, follow these instructions:





1. From the Home screen, touch  **Messaging**.
2. Touch  **Menu**, then touch **Settings** → **Emergency alerts**.
3. All alerts are enabled by default (checkmark showing). To disable alerts, touch an alert to remove the checkmark.

Email

Send and receive email using popular email services.

Setting Up Email Accounts





You can configure Email for most accounts in just a few steps.

1. From the Home screen, select  **Apps** →  **Email**.
2. The first time you set up an email account, select your email provider.
– or –
For subsequent accounts, touch  **Menu** → **Settings** → , then select your email provider.
3. Follow the prompts to set up your email account.

Note: For more information on setting up your email, visit the Smartphone Resource Center at:




<https://smartphones.verizonwireless.com>

Deleting Email Accounts

1. From the Home screen, select  **Apps** →  **Email**.
2. Touch  **Menu** → **Settings** →  .
3. Select email account(s) for deletion, then touch **Delete**.

Syncing Email Accounts



Syncing refreshes your phone with the account's servers. When you set up an email account, you can choose whether the account syncs in the background, or manually.


- From the Home screen, select  **Apps** →  **Email** →  **Sync**.

Email Settings







Use settings to configure handling of your email.

Note: Available settings depend on the email provider.

1. From the Home screen, select  **Apps** →  **Email**.



2. Touch  **Menu** → **Settings** → **General preferences**:
 - **Auto-advance**: Choose the screen to display after you delete or move a message.
 - **Message preview line**: Choose the number of lines of email text to display in the preview screen.
 - **Title line in list**: Choose how emails are titled in the preview screen.
 - **Confirm deletions**: When enabled, email will prompt you to confirm when you delete messages.
 - **Quick responses**: View and manage text phrases you can insert into emails.
 - **Priority senders**: Add list of senders with priority.
 - **Email notifications**: When enabled, email notification will appear in the status bar.
 - **Select ringtone**: Choose from list of ringtones.
 - **Vibrate**: Enable vibrate when email arrives.
3. Touch an account to configure specific settings. Available options depend on the account.

Composing and Sending Email

1. From the Home screen, select  **Apps** →  **Email**.
2. If you have multiple accounts set up, choose an account from the menu at the top of the screen.
3. Touch , then touch fields to enter recipients and the email text.
4. While composing a message, use these options:
 - Touch  **Menu** for options. Available options depend on the type of email account.
 - Touch  **Attach** to add a file to the message. Available options depend on the type of email account.
5. Touch  **Send** to send the message.



Gmail


Send and receive emails via Gmail, Google's web-based email.

- From the Home screen, select  **Apps** →  **Gmail**.

Setting Up Your Gmail Account

The first time you launch Gmail, your phone will prompt you to set up your Google account, if you haven't already set it up. If you set up your Google account on your phone, Gmail is set up automatically

1. From the Home screen, select  **Apps** →  **Gmail**.
2. Follow the prompts to sign in, or create a new account.
3. The phone communicates with the Google server to set up your account and synchronize your email.

Note: You can use more than one Google account on your phone. To add another account, use the  **Menu** → **Settings** → **Add Account** option.




Refreshing Your Gmail Account

Syncing refreshes your phone with the account's servers. When you set up an email account, you can choose whether the account syncs in the background, or manually.






- From the Home screen, select  **Apps** →  **Gmail** →  **Sync**.

Gmail Settings

Use settings to configure your Gmail preferences.

1. From the Home screen, select  **Apps** →  **Gmail**.
2. Touch  **Menu** → **Settings** for options.

Composing and Sending Gmail



1. From the Home screen, select  **Apps** →  **Gmail**.
2. Touch  **Compose**, then touch fields to compose the message. While composing, touch  **Menu** for options.
3. To send the message, touch  **Send**.

Voicemail



All unanswered calls to your phone are sent to voice mail, even if your phone is turned off, so you'll want to set up your voice mail and personal greeting as soon as you activate your phone.

Visual Voice Mail is a feature that allows you to review your voicemails on your phone, including the option to listen to your voicemail in any order. There is a monthly charge for Visual Voice Mail, and airtime charges may apply. For more information, contact Verizon Wireless.

Setting up Voicemail

1. From the Home screen, touch  **Phone**, then touch and hold .
2. Follow the automated instructions to set up your password and record a greeting.

Checking Voicemail

1. From the Home screen, touch  , then touch and hold .
2. Follow the automated instructions to manage voicemail.

Clearing Voicemail Notifications



When you have new voicemail, your phone alerts you by displaying an icon in the Status bar, and, depending on your settings, by playing sound and vibration. If you want to remove the icon from the Status bar, use the Clear notifications option.

1. From the Home screen, swipe downward from the top of the screen to display the Notifications panel.
2. Tap **Clear** from the Notifications field to clear voicemail notifications.

Google Talk



Chat with other Google Talk users.

Note: Talk requires that you have a Google account set up on your phone. For more information, see *“Setting Up Your Accounts”* on page 44. If you set up your Google account, you are automatically logged in.

- From the Home screen, select  **Apps** →  **Talk**.

Google+ Messenger

Chat with other Google+ members. When accessing Google+ Messenger, Hangouts is seen.

- From the Home screen, select  **Apps** →  **Messenger**.

Section 6: Applications

Managing Applications


Apps displays all applications installed on your phone, including apps you download and install.

From Apps, you can change the way apps appear on the screen, uninstall apps you've downloaded, and share apps with friends. When you install new apps, new screens are added to hold them.

Tip: You can place shortcuts to apps on the Home screen, for quick access to the application. For more information, see “*Apps and widgets*” on page 26.





Downloading and Installing Apps

Find new apps to download and install on your device:

-  **Play Store:** For more information, see “*Play Store*” on page 85.

Uninstalling Apps



You can uninstall apps you download and install. Pre-loaded apps cannot be uninstalled.

1. From the Home screen, touch  **Apps**.
2. Touch  **Menu** → **Uninstall**.
3. Apps that can be uninstalled show  on their icon. Touch , then follow the prompts to uninstall the app. Pre-loaded apps cannot be uninstalled.





Customizing the Apps Screens

Choosing a view

By default, app icons appear in Grid view. You can change the view to list view.

1. From the Home screen, touch  **Apps**.
2. Touch  **Menu** → **View type**.
3. Choose an option:
 - **Customizable Grid:** The default view, which allows you to touch and hold apps to move them from screen to screen.
 - **Alphabetical grid:** Icons are arranged in a grid, in A-Z order.
 - **Alphabetical list:** Icons display in a list, sorted from A-Z.



Apps screen options

1. From the Home screen, touch  **Apps**.
2. Touch  **Menu** for options:
 - **Play Store:** Launch Google Play™ Store, to browse for new apps to download.
 - **Edit:** Touch and hold an app icon for these options:
 - Drag it to a new location.
 - Drag it to  to create a new folder to contain the icon.
 - Drag it to  to create a new apps screen and place the icon on it.

- Drag it to  to launch the Application manager to view information about the app. For more information, refer to “*Application manager*” on page 108.
 - Drag to  (if available) to remove the icon. The trashcan is only available for apps you’ve installed. Pre-loaded apps cannot be removed.
- **Create folder:** Creates a folder (which you title) and places it on the home screen.
 - **Uninstall:** Remove an app that you downloaded from your phone. Preloaded apps cannot be uninstalled.
 - **Downloaded applications:** Display all apps you’ve downloaded.
 - **View type:** Configure the apps screen.
 - **Share apps:** Select apps you’ve downloaded (not available for pre-loaded apps) to share via Bluetooth, Email, Gmail, Google, Google+, Messaging, Memo, or Wi-Fi Direct.
 - **Hide applications/Show hidden applications:** Control whether app icons are visible in Apps. Hiding an icon does not remove the app from your phone.

Calculator



Use your phone's Calculator to perform mathematical calculations.

- From the Home screen, touch  **Apps** →  **Calculator**.

Calendar




Record events and appointments to manage your schedule.

Tip: A Calendar widget is available in Widgets. For more information about placing widgets on the Home screen, see “*Apps and widgets*” on page 26.

1. From the Home screen, touch  **Apps** →  **Calendar**.
2. Touch , then select a view, from **Year**, **Month**, **Week**, **Day**, **List**, or **Task**.
3. Touch  **Menu** for options:
 - **Go to:** Display a specific date.
 - **Delete:** Delete an event.
 - **Search:** Search for calendar events.
 - **Sync:** Refresh calendar with events from your accounts.
 - **Settings:** Customize the calendar.

Sending Events

Send events as vCalendar files to other Bluetooth devices, as message attachments, or via Wi-Fi Direct.

1. From the Home screen, touch  **Apps** →  **Calendar**.
2. Touch an event to display its details.
3. Touch  **Menu**, then touch **Share via**, then follow the prompts to select a sharing method and share the event.

Camera


Use the Camera to take pictures and record video.

Important! Do not take photos of people without their permission.
Do not take photos in places where cameras are not allowed.
Do not take photos in places where you may interfere with another person's privacy.

Taking Pictures

1. From the Home screen, touch  **Apps** →






 **Camera.**



2. Using the display as a viewfinder, compose your picture by aiming the lens at the subject. You can rotate the phone to any position, and the screen controls rotate to make taking pictures easy.
3. As you compose a picture, the Camera automatically focuses the shot (the focus bracket turns green), or:
 - Touch the screen to focus on the area you touched.
 - “Pinch” the screen, or press the Volume Key, to zoom in or out.
 - Configure other options. For more information, see “*Picture Options*” on page 69.
4. Touch **Capture** to take the picture.





Gallery

After taking a picture, review the picture in Gallery, and use options to modify or share the picture.

1. From the Home screen, touch  **Apps** →  **Camera**.
2. Touch Gallery, then use these options:
 - “Pinch” the screen to zoom in or out, or double-tap to zoom all the way in or out. When zoomed in, touch and drag your finger on the screen to move the picture around on the screen.
 - Touch  **Camera** to launch the viewfinder and take a picture.
 - Touch  **Share** to send the picture.
 - Touch  **Menu** for options:
 - **Slideshow**: Create a slideshow with pictures and videos from Gallery.
 - **Delete**: Deletes the selected photo.
 - **Face tag**: When enabled, identifies faces with a yellow box, so you can touch to add tag information.
 - **Copy to clipboard**: Create a copy, to paste into other apps.
 - **Rotate left/Rotate right**: Change the picture’s orientation.
 - **Crop**: Change the picture’s size.
 - **Set as**: Assign the picture as a Contact photo, or as wallpaper.

- **Buddy photo share**: Send the picture to the people tagged in the picture.
- **Print**: Print the picture via Wi-Fi to a compatible Samsung printer (not included).
- **Rename**: Change the picture’s filename.
- **Scan for nearby devices**: If DLNA file sharing is enabled, search for devices to share photos. For more information about sharing via DLNA see “*Nearby devices*” on page 92.
- **Details**: View information about the picture.

Picture Options

1. From the Home screen, touch  **Apps** →  **Camera**.
2. Use these options to configure the camera:
 -  **Self portrait**: Switch between the back camera and the front camera, for self-portraits.
 -  **Shooting mode**: Choose an automatic shooting mode. Some modes are not available for Self-portraits.
 - **Single shot**: Take a single photo.
 - **Panorama**: Touch the Camera button to take a picture, then use the on-screen guideline to move the viewfinder and take the next 7 shots automatically.

- **Smile shot:** Touch the Camera button to focus on the subject's face. If a smile is detected, the picture is taken automatically.
- ✨ **Effects:** Apply an effect to pictures.
- ⚙️ **Settings**
 - **Edit shortcuts:** Choose shortcuts to appear on the toolbar. Touch and drag shortcuts between the toolbar and the list.
 - **Self-portrait:** When On, the Camera takes pictures with the front Camera.
 - **Shooting mode:** Choose the default mode for taking pictures.
 - **Effects:** Apply an effect to pictures.
 - **Scene mode:** Choose a mode to match the kind of pictures you're taking.
 - **Exposure value:** Set the default brightness level.
 - **Focus mode:** Set the default focus mode.
 - **Timer:** Set a delay to wait between touching the Camera button and taking a picture.
- **Resolution:** Choose a size for the image.
- **White balance:** Choose a setting for the light source.
- **Metering:** Select a method for measuring light.
- **Guidelines:** Enable or disable an on-screen grid to aid in photo composition.
- **GPS Tag:** Add GPS location information to photo details.
- **Take photos using voice:** When activated, takes a photo using a verbal command.
- **Save as flipped:** Flips the images from the front camera left-to-right so photos and videos are oriented as though they were recorded by the rear camera.
- **Image quality:** Choose a quality setting for photos.
- **Storage:** If an optional memory card (not included) is installed, set the default storage to Memory card or Phone.
- **Reset:** Set all Camera settings to the defaults.


Recording Videos



Use the Camera to record video.


Important! Do not take videos of people without their permission.
Do not take videos in places where cameras are not allowed.
Do not take videos in places where you may interfere with another person's privacy.

1. From the Home screen, touch  **Apps** →

 **Camera** →  **Camera/Camcorder**.










2. Using the display as a viewfinder, compose your shot by aiming the lens at the subject. You can rotate the phone to any position, and the screen controls rotate to make recording easy.
3. As you compose a shot, the Camcorder automatically focuses the shot (the focus bracket turns green), or:
 - “Pinch” the screen to zoom in or out.
 - Configure options. For more information, see “*Video Options*” on page 72.
4. Touch **Record** to start recording.
5. Touch the  **Stop** button to stop recording.
6. After recording, touch **Gallery** to view the video. While viewing the video, touch  **Menu** for options:
 - **Scan for nearby devices:** If DLNA file sharing is enabled, search for devices to share videos. For more information about sharing via DLNA see “*Nearby devices*” on page 92.
 - **Share via:** Select a sharing method to share this video.
 - **Trim:** Cut frames from this video.
 - **Via Bluetooth:** Share this video to another Bluetooth-enabled device.

- **Video auto off:** Select a time to automatically turn off videos. Select Off, After playing, After 15 mins, 30 mins, 1 hr, 1 hr 30 mins, or 2 hrs.
- **Settings:** Configure the Play speed, SoundAlive, and Subtitles.
 - **Play speed:** Use the slider to adjust the playback speed.
 - **SoundAlive:** Activates SoundAlive effects when wearing headphones.
 - **Subtitles:** Select subtitles while playing a video.
- **Details:** View information about the video.
- Touch  **Back** to return to the Camcorder to record more videos.

Video Options



Configure the camcorder.

1. From the Home screen, touch  **Apps** →  **Camera** →  **Mode**.
2. Use these options to configure the camcorder:
 -  **Self recording:** Record video with the front lens.
 -  **Recording mode:** Choose a recording mode, from:
 - **Normal:** Record a video of any length.
 - **Limit for MMS:** Restrict the length of the video so it can be sent as a message attachment.
 -  **Effects:** Apply an effect to videos.
 -  **Settings:**
 - **Edit shortcuts:** Choose shortcuts to appear on the toolbar. Touch and drag shortcuts between the toolbar and the list.
 - **Self-recording:** When On, the Camcorder records with the front Camera.
 - **Recording mode:** Choose the default recording mode.
 - **Effects:** Apply an effect to videos.
 - **Exposure value:** Set the default brightness level.
 - **Timer:** Set a delay to wait between touching the Camera button and taking a picture.

- **Resolution:** Choose a size for the image.
- **White balance:** Choose a setting for the light source.
- **Guidelines:** Enable or disable an on-screen grid to aid in photo composition.
- **Save as flipped:** Flips the images from the front camera left-to-right so photos and videos are oriented as though they were recorded by the rear camera.
- **Video quality:** Choose a quality setting for videos.
- **Storage:** Choose the default save location for videos, if an optional memory card is installed.
- **Reset:** Set all settings to the defaults.

Clock



The Clock application includes these features:

- **Alarm:** Create alarms to go off once, or to repeat.
- **World clock:** Display the time and date in any time zone.
- **Stopwatch:** Record lap times.
- **Timer:** Measure elapsed time.
- **Desk clock:** Display the date and time in large format, for easy viewing.
 - From the Home screen, touch  **Apps** →  **Clock**.

Contacts



Use Contacts to store information for your friends, family and colleagues, to make contacting them easy.

For more information, see “*Contacts*” on page 45.

- From the Home screen, touch  **Apps** →  **Contacts**.

Downloads

View and manage files and other items you download to your phone.



1. From the Home screen, touch  **Apps** →  **Downloads**.
2. Touch an item to open it (if an appropriate application is installed.)

Note: Applications you download in Google Play™ Store are managed in Play Store, and will not appear in Downloads.

Email

Send and receive email using popular email services.




For more information, see “*Email*” on page 60.

- From the Home screen, select  **Apps** →  **Email**.




Gallery

Use Gallery to view and manage pictures and videos.

Viewing Videos







1. From the Home screen, touch  **Apps** →  **Gallery**.
2. Touch an album, then touch a video to play it.
3. While viewing videos, touch  **Menu** for options.

Viewing Pictures

1. From the Home screen, touch  **Apps** →  **Gallery**.
2. Touch an album, then touch a picture to view it.
3. While viewing a picture, touch the screen, or touch  **Menu** for options.




Sharing pictures and video

You can share pictures and videos via Email, Messaging, Bluetooth or popular sharing services.

1. From the Home screen, touch  **Apps** →  **Gallery**.
2. Touch an album to display thumbnails, then select items for sharing:
 - To select an entire album, touch  **Menu** → **Select album** while viewing albums. Touch the album to select all pictures in the album, then touch  **Share**.
 - To select multiple pictures or videos from an album, touch  **Menu** → **Select album** while viewing the thumbnails. Touch thumbnails to mark them for sharing, then touch  **Share**.
3. Touch an option and follow the prompts.




Setting a Picture as a Contact Photo

Set a picture as a contact's photo. The contact's photo will appear with notifications to calls or messages from the contact.

1. From the Home screen, touch  **Apps** →  **Gallery**.
2. Touch an album, then touch a picture to select it.
3. Touch  **Menu** → **Set as** → **Contact photo**.
4. Select a contact, or create a new contact, with the selected picture as the contact's photo.

Setting a Picture as Wallpaper



Set a picture as the wallpaper for the Home and Lock screens.

1. From the Home screen, touch  **Apps** →  **Gallery**.
2. Touch an album, then touch a picture to select it.
3. Touch  **Menu** → **Set as**.
4. Select an option, from Home screen, Lock screen, or Home and lock screens. Use the crop tool to edit the picture, then touch **Done**.

Gmail


Send and receive emails via Gmail, Google's web-based email.



For more information, see “*Gmail*” on page 62.

- From the Home screen, touch  **Apps** →  **Gmail**.

Google

Use Google Search to search the Web.

1. From the Home screen, touch the  **Google Widget**.
– or –



From the Home screen, touch  **Apps** →  **Google**.

2. Enter search criteria. Search results display automatically. Touch a search result to display it in a browser window.

Google Settings

Google Settings provides a quick access to settings for Apps with Google+ Sign-In, Google+, Play Games, Location, Search, Ads, and Android Device Manager.

You must be signed in to the application in which you want to configure (ex: Google+ to configure Google+ settings).



1. From the Home screen, touch  **Apps** →  **Google Settings**.
2. Touch a category to configure (for example, Google+), and configure the settings.

Note: You must be signed in to the app before you can configure it through settings.

Google+




Google+ makes messaging and sharing with your friends a lot easier. Set up Circles of friends, visit the Stream for updates from your Circles, use Messenger, or use Instant Upload to automatically upload photos and videos from your phone to your private album on Google+.

For more information, visit: www.google.com/+

- From the Home screen, touch  **Apps** →  **Google+.**


Help



Get information about using your phone, including videos, useful tips, and a user manual.

- From the Home screen, touch  **Help.**
– or –
From the Home screen, touch  **Apps** →  **Help.**

Internet

Your phone is equipped with a full HTML Browser, which allows you to access the internet.

- From the Home screen, touch  **Internet.**
– or –

From the Home screen, touch  **Apps** →  **Internet.**

Navigating the Internet

Command Keys

- Touch  **Back** to return to the previous page.

Touching and dragging

- Touch and drag your finger on the screen to navigate pages, and to reposition pages within the screen.

Entering text in a field

- While browsing, touch a text field to display the virtual QWERTY keyboard to enter text.

Zoom

- Tap the screen twice to zoom in or out.


Selecting items on a page

While browsing pages, use gestures and menus to navigate:

- Touch an item to select it.
- Touch a hyperlink to follow the link.
- Touch and hold a hyperlink for options.






Entering a URL

Access a website quickly by entering the URL.

1. From the Home screen, select  **Internet**.
2. Touch the **URL** field at the top of the screen to enter the URL using the virtual QWERTY keyboard, then touch **Go**.

Using Windows




You can have multiple windows open at one time, and you can switch between windows.

- To open a new window, touch  **Windows** →  **Add**.
- To switch to another open window, touch  **Windows**, then touch a window to display it.
- To close a window, touch  **Windows**, then touch  beside a window to close it.

Using Bookmarks

While browsing, bookmark a site to quickly access it later.

Creating a bookmark

1. From the Home screen, touch  **Internet**.
2. Browse to the desired website, then touch  **Bookmarks** →  **Add bookmark**.
3. Confirm the Name and Folder for the bookmark, then touch **Save**.

Accessing bookmarks and history


Launch a bookmarked page, or reload recent pages.

1. From the Home screen, touch  **Internet**.
2. Touch  **Bookmarks** to display bookmarks, then use these options:
 - Touch an item to load the page.
 - Touch and hold an item for options.
 - Touch  **Menu** for more options.

Local

Google Places is now Google Local, to use your location to help you find destinations, such as restaurants, bars, hotels, attractions, ATMs and gas stations, or you can enter a location.



Note: You must enable location services to use Local, and some features require Standalone or Google location services. For more information, see *“Location services”* on page 109.

- From the Home screen, touch  **Apps** →  **Local**.

Maps

Use Google Maps to find your current location, plus get directions and other location-based information.

Note: You must enable location services to use Maps, and some features require Standalone or Google location services. For more information, see *“Location services”* on page 109.

- From the Home screen, touch  **Apps** →  **Maps**.

Navigating the Map

Zooming

- Double-tap on the screen to zoom in or out.

Scrolling

- Touch and drag on the screen to reposition the map in the display.

Touch

- Touch an icon on the map to display information about the location.



Media Hub

Samsung Media Hub is your one stop for the hottest movie and TV content. Preview, rent, or buy blockbuster hits as well as classic movies and TV shows.

For more information, visit:



<http://www.samsung.com/us/mediahub/>

Note: Renting or purchasing content in Media Hub requires a Samsung account.

1. From the Home screen, select  **Apps** →  **Media Hub**.
2. Browse content, then follow the prompts to buy or rent. You must have a Samsung account to rent or buy media.

Memo

Create text notes, for updating your status, sharing with friends, or printing on a Samsung printer (not included) via Wi-Fi.



- From the Home screen, touch  **Apps** →  **Memo**.

Messaging

Send and receive text and multimedia messages.

For more information, see “*Text and Multimedia Messaging*” on page 56.



- From the Home screen, touch  **Messaging**.
– or –

From the Home screen, touch  **Apps** →  **Messaging**.

Messenger



Google+ Messenger lets you chat and coordinate with any of your friends, all at the same time.

For more information, visit: www.google.com/+

- From the Home screen, touch  **Apps** →  **Messenger**.




Music Player

Music Player plays songs stored on your phone or an installed memory card.



1. From the Home screen, select  **Apps** →  **Music Player**.
2. Music Player scans for songs stored in phone memory, or on an installed memory card and displays your songs on the **All**, **Playlists**, **Albums**, **Artists**, **Music Square**, and **Folders** tabs.
3. Touch a music file to begin playback. During playback, use the sound and playlist controls:
 -  **Volume**: Touch to activate on-screen volume control, then touch and drag on the scale to set volume, or press the Volume Key on the side of the phone to adjust playback volume. If you have motion settings turned on, place the phone screen-down to mute playback.
 -  **Shuffle**: When enabled, songs play in random order. When disabled, songs play in the order they appear in List view.
 -  **Repeat**: Touch to repeat the current song, repeat all songs, or disable repeat mode.

-  **Music Square**: Touch a square near a description of the song playing to categorize it as Passionate, Exciting, Joyful, or Calm.
- Touch  to choose SoundAlive.
-  **List** /  **Now Playing**: Touch **List** to switch to a list view of songs. Touch **Now Playing** to display the current song title and details.
- Touch  to advance to the next song. Touch and hold  to scan forward through the current song.
- Touch  to go back to the previous song. Touch and hold  to scan backward through the current song.
- Touch  to pause playback. Touch  to resume playback.




Creating a Playlist

1. From the Home screen, select  **Apps** →  **Music Player** → **Playlists**.
2. Touch  **Menu** → **Create Playlist**, then enter a name for the playlist.
3. Touch **OK**, then touch **Add music** to choose music for the playlist, then touch **Done**.

Adding a song to a playlist



1. From the Home screen, select  **Apps** →  **Music Player**.
2. Touch and hold a song, then choose **Add to playlist** from the pop-up menu.
3. Touch a playlist to add the selected song to it, or touch **Create playlist** to create a new playlist and add the selected song to it.

Adding multiple songs to a playlist

1. From the Home screen, select  **Apps** →  **Music Player**.
2. Touch  **Menu** → **Add to playlist**.
3. Touch songs to select them, or touch **Select all**, then touch **Done**.
4. Select a playlist, or touch **Create playlist** to create a new playlist.






Setting a Song as a Ringtone

You can set a song as a ringtone for all voice calls, for calls from an individual contact, or as an alarm tone.

1. From the Home screen, select  **Apps** →  **Music Player**.
2. Touch and hold a song, then touch **Set as** and choose from these options:
 - **Phone ringtone**: Set the song as the default ringtone for all incoming voice calls.
 - **Caller ringtone**: Choose a contact to set the song as the ringtone for calls from the contact.
 - **Alarm tone**: Set the song as the alarm ringtone for a new alarm, or for an existing alarm.

My Files

Find, view and manage files stored on an installed memory card. If the file is associated with an application on your phone, you can launch the file in the application.

1. From the Home screen, touch  **Apps** →
 **My Files**.
2. Tap a folder and swipe your finger on the screen to browse files.
3. Touch a file to open it (if the file is associated with an application).
4. While browsing files, use these controls:
 - Touch  **Up** to go back up to a higher directory.
 - Touch  **Home** to go back to the root directory.
 - Touch  **Menu** for options.

My Verizon Mobile

View details and manage your Verizon Wireless account.



Note: No airtime or minute charges apply when accessing My Verizon Mobile.

- From the Home screen, touch  **Apps** →
 **My Verizon Mobile**.

Navigation

Use Google Navigation to search for locations, and get turn-by-turn directions.

Note: You must enable location services to use Navigation, and some features require Standalone or Google location services. For more information, see “*Location services*” on page 109.

- From the Home screen, touch  **Apps** →
 **Navigation**.

Phone



Place calls, review recent calls, or dial a number to send a message.

For more information, see “*Calling*” on page 32.

- From the Home screen, touch  **Phone**.



Play Books

Google Books is now Google Play™ Books. Discovering your favorite books and authors has never been easier. With Google Play Books, you can shop the world's largest selection of ebooks and read them anywhere you like - on a tablet, phone, ereader, or the Web.

- From the Home screen, touch  **Apps** →
 **Play Books**.



Play Magazines

Subscribe to your favorite magazines and have them available to read on your device any time, in any place.

- From the Home screen, touch  **Apps** →
 **Play Magazines**.



Play Movies & TV

With Google Play Movies & TV, you can rent thousands of different movies and TV shows to watch instantly, or download for offline viewing later. You'll need to have a Google account set up on your device to download content.

- From the Home screen, touch  **Apps** →
 **Play Movies & TV**.



Play Music

With Google Play™ Music, you can play music you've downloaded, and music you copied from your computer. You'll need to have a Google account set up on your phone to download a new application.

- From the Home screen, touch  **Apps** →
 **Play Music**.



Play Store

Android Market is now Google Play™ Store, where all your favorite books, movies, apps, and games are all in one place that's accessible from the Web and your Android device. You'll need to have a Google account set up on your phone to download a new application.

1. From the Home screen, select  **Apps** →  **Play Store**.
2. Browse for applications to download, then follow the prompts.






Polaris Office

Read and edit documents in various formats on your device.

- From the Home screen, select  **Apps** →  **Polaris Office 4.0**.



S Voice

Use S Voice to speak commands to perform operations on your phone, and to speak criteria for searches and other operations. Just speak naturally, and S Voice understands what you're looking for. Use the power of S Voice to find everything from directions to trivia answers to the current weather forecast.

1. From the Home screen, select  **Apps** →  **S Voice**.
2. Say "Hi Galaxy", or touch  to wake up S Voice, then speak a command or question. Touch  for a list of commands, then touch a command to see examples.
3. Touch  **Menu** → **Settings** to configure settings to your preferences.



Settings

Configure your phone to your preferences. For more information, see "Settings" on page 94.

- From the Home screen, touch  **Apps** →  **Settings**.

Setup Wizard



Use the Setup wizard to quickly configure your phone.

- From the Home screen, touch  **Apps** →  **Setup wizard**.

Talk



Chat with other Google Talk users.









Note: Talk requires a Google account. For more information, see “*Setting Up Your Accounts*” on page 44. When you set up your Google account on your device, you are automatically logged in.

- From the Home screen, select  **Apps** →  **Talk**.

Video Player



Use Video Player to view and manage videos stored on the phone or an (optional) installed memory card.

1. From the Home screen, select  **Apps** →  **Video Player**.
2. Video Player scans for videos stored in phone memory, or on an installed memory card, and displays your videos on the Thumbnails, List, and Folders tabs.

3. Touch a video to play it. While playing a video, touch the screen to display or hide on-screen controls:
4. During playback, use the sound and playlist controls:
 -  **Volume:** Touch to activate on-screen volume control; then touch and drag on the scale to set volume, or press the Volume Key on the side of the phone to adjust playback volume.
 -  **Full screen:** Touch to switch to viewing the video in full screen mode.
 -  **Play:** Touch to play the video
 -  **Forward:** Touch to advance to the next video. Touch and hold to scan forward through the current video.
 -  **Reverse:** Touch to go back to the previous video. Touch and hold to scan backward through the current video.
 -  **Pause:** Touch to pause playback.
 -  **Capture:** Touch to capture a screenshot of the current video image.
5. While playing a video, touch  **Menu** for options.



Voice Recorder

Record your voice or other sounds, and share recordings via Bluetooth, Messaging, Email, Wi-Fi Direct, or Gmail.

- From the Home screen, touch  **Apps** →  **Voice Recorder.**

Voice Search



Use voice commands to search the web with Google.

- From the Home screen, touch  **Apps** →  **Voice Search.**


VZ Navigator

Use VZ Navigator[®] to find, share and navigate to millions of locations, avoid traffic and drive or walk with ease.

Note: VZ Navigator requires service activation. Contact Verizon Wireless for more information.



- From the Home screen, touch  **Apps** →  **VZ Navigator.**

– or –

From a Home screen, touch the  **VZ Navigator** shortcut.

YouTube

View and upload YouTube videos, right from your phone.

- From the Home screen, select  **Apps** →  **YouTube.**

Section 7: Connections

Wi-Fi

Wi-Fi is a wireless networking technology that provides access to local area networks.

Wi-Fi communication requires access to an existing Wi-Fi network. Wi-Fi networks can be Open (unsecured), or Secured (requiring you to provide login credentials).

Your phone supports the 802.11 a/b/g/n Wi-Fi protocols.




Configuring Wi-Fi Settings

Configure your phone's Wi-Fi settings. For more information, see *“Wi-Fi Settings”* on page 96.

Turning Wi-Fi On or Off




Turn your phone's Wi-Fi service on or off. When you turn Wi-Fi service on, your phone automatically searches for nearby available Wi-Fi networks.

Tip: When you turn Wi-Fi service on, your phone automatically searches for available networks and displays them.

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Touch **Wi-Fi**  to turn Wi-Fi On or Off.

Scanning and Connecting to a Wi-Fi Network

When you turn on Wi-Fi, your phone searches for available Wi-Fi connections, then displays them.

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Touch **Wi-Fi**  to turn Wi-Fi On.
3. When your phone completes a scan, touch a Wi-Fi network to connect. If the Wi-Fi network is open, you will be automatically connected. If the Wi-Fi network is secured, enter the password at the prompt to connect.
4. Touch **Scan** to rescan for an available Wi-Fi network.


Adding a Wi-Fi Network Manually

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Touch **Wi-Fi**  to turn Wi-Fi On.
3. When your phone completes a scan, touch **Add Wi-Fi Network** (below the scanned networks), then enter these fields:
 - **Network Name (SSID)**: Enter the name of the Wi-Fi network.
 - **Security**: Select the type of security used by the Wi-Fi network.
 - **Password**: If the network is secured, enter the password.
4. Touch **Connect** to save the settings and connect to the network now, or **Save** to save the network settings for future use.

Bluetooth

Note: For Hearing Aid Compatibility Information, see page 148.

Bluetooth is a short-range wireless communications technology for exchanging information over a distance of about 30 feet. You don't need to line up the devices to send information with Bluetooth. If the devices are in range, you can exchange information between them, even if they are in different rooms.




Your device can use Bluetooth to share photos, contacts and other content with other Bluetooth devices. Many of the apps on your device provide options for sharing via Bluetooth under  **Menu**.

Configuring Bluetooth Settings

Configure your phone's Bluetooth settings. For more information, see *"Bluetooth settings"* on page 99.

Note: Bluetooth profiles are specifications for services supported by individual devices. For a list of profiles your phone supports, see *"Bluetooth profiles"* on page 98.

Turning Bluetooth On or Off


1. From the Home screen, touch  **Apps** →  **Settings**.
 2. Touch **Bluetooth**  to turn Bluetooth On or Off.
-



Tip: You can also turn Bluetooth On or Off on Notifications. From almost any unlocked screen, sweep your finger down from the Status bar to display Notifications.

Pairing with a Bluetooth Device

Search for a Bluetooth device and pair with it, to exchange information between your phone and the device.

After pairing, your phone and the target device will recognize each other and exchange information without a passcode or PIN.

Note: When paired, the  **Bluetooth paired** icon displays in the Status Bar. If you receive a new request for pairing while paired with a Bluetooth headset, a new Bluetooth icon displays at the left of the Status bar and Notifications displays the pairing request.

1. From the Home screen, touch  **Apps** →  **Settings** → **Bluetooth**.
2. Touch **Bluetooth**  to turn Bluetooth On.
3. Activate the target device's discoverable mode.
4. Touch **Scan**.
5. From the list of scanned devices, touch the target device, then follow the prompts to complete the pairing:
 - If the target device requires a PIN, enter a PIN for the target device and touch **OK**. When prompted, enter the PIN on the target device.
 - If the device allows automatic or smart pairing, your phone will attempt to pair with the phone automatically. Follow the prompts on your phone and the target device to complete the pairing.

VPN



When access to VPN, Basic VPN and Advanced IPsec VPN are seen, you can use your phone's VPN (Virtual Private Network) feature to connect to VPNs.

Configuring VPN Settings

Configure your phone's VPN settings. For more information, see “VPN” on page 100.

Note: You must enable at least Pattern security before setting up a VPN. If you have not yet enabled security, you'll be prompted to do so the first time you launch VPN settings.

Adding a VPN

1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **VPN**.
2. Touch **Basic VPN** or **AdvancedIPsec VPN** and follow the prompts to set up a connection to a VPN. Available settings depend on the type of VPN.




Nearby devices

Share files with nearby devices using DLNA (Digital Living Network Alliance) standards, over Wi-Fi.

To share with nearby devices, you must connect to a Wi-Fi network. The devices you wish to share files with must also be connected to the same Wi-Fi network and must support DLNA.

Important! Use care when enabling file sharing for nearby devices. When enabled, other devices can access data on your device.

Turning File sharing On or Off

1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **Nearby Devices**.
2. Touch **File sharing**  to turn sharing On or Off.

Configuring File Sharing

1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **Nearby Devices**.
2. Under **Advanced**, touch options to control how content is shared from your device:
 - **Shared contents:** Choose the type of content to share, from **Videos, Photos, or Music**.
 - **Device name:** View or modify your device's name.
 - **Allowed devices list:** View and manage devices allowed to connect to your device.
 - **Not-allowed devices list:** View and manage devices restricted from connecting to your device.
 - **Download to:** Choose a location to save downloaded content, from USB storage (phone memory) or SD card.
 - **Upload from other devices:** Choose how to handle incoming files from other devices, from **Always accept, Always ask, or Always reject**.

Connecting to a Computer

Connect your device to a computer to transfer data between your device and the computer. Use the USB cable that comes with your device, or use one of the pre-loaded apps on your device to connect wirelessly.

Transferring Data

Connect your device to a computer, via USB cable, to transfer data as a Media device using MTP (Media Transfer Protocol), or as a Camera using PTP (Photo Transfer Protocol).

1. Attach your phone to the computer with a USB data cable. Your phone recognizes the connection as the last connection method you used, and displays a connection alert in the Status bar and Notifications.
2. From the Home screen, sweep your finger downward to display Notifications, then touch the alert.

3. Select a connection method:
 - **Media device (MTP):** Transfer media files with Windows, or using Android file transfer on a Mac (see www.android.com/filetransfer).
 - **Camera (PTP):** Transfer photos using camera software, and transfer files to computers that do not support MTP.
4. On your computer, choose a method for accessing your device. Available options depend on the programs installed on your computer.
5. Transfer files to the memory card. When finished, you can disconnect the USB cable.


Section 8: Settings

Accessing Settings

From the Home screen

- Touch  **Apps** →  **Settings**.
– or –
Touch  **Menu** → **Settings**.

From Notifications



- Touch and drag downward from the top of the screen to display notifications, then touch .

Home screen mode

Your phone offers two Home screen modes:




- **Starter mode** provides an easier experience for the first-time smartphone user.
- **Standard mode** provides a conventional layout for apps and widgets on the Home screen.


The first time you turn your phone on, you'll be prompted to choose a mode, or you can choose a mode at anytime in Settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Mode change**.
2. Touch a mode, and then touch **Apply**.

Airplane mode

When airplane mode is enabled, all your phone's wireless connections are disabled, and you cannot make or receive calls or messages or connect to networks. While in airplane mode, you can use other features of your phone, such as playing music, watching videos, or other applications.

- From the Home screen, touch  **Apps** →  **Settings** and touch the **Airplane mode**  to enable or disable airplane mode.

Tip: Airplane mode can also be controlled from Notifications, and from Device options when you press and hold the  **Power/Lock Key**.

Wi-Fi

Set up and manage your phone's connections to Wi-Fi networks. Your phone supports Wi-Fi a/b/g/n.




For more information about using Wi-Fi, see “*Wi-Fi*” on page 88.

Turning Wi-Fi On or Off

Turn your phone's Wi-Fi service on or off. When you turn Wi-Fi service on, your phone automatically searches for available Wi-Fi networks.




Tip: When you turn Wi-Fi service on, your phone automatically searches for available networks and displays them.

You can also turn Wi-Fi On or Off from Notifications.




1. From the Home screen, touch  **Apps** →  **Settings**.
2. Touch **Wi-Fi**  to turn Wi-Fi On or Off.

Wi-Fi Settings

Set up and manage wireless access points.

1. From the Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Touch settings to configure:
 - **Notify me:** When enabled, your phone notifies you of Wi-Fi networks when you launch a high data-usage application.
 - **Add Wi-Fi Network:** Connect to a new Wi-Fi network. For more information, see “*Adding a Wi-Fi Network Manually*” on page 89.
 - **Scan:** Search for available Wi-Fi networks.
 - **Wi-Fi Direct:** Configure Wi-Fi Direct Settings.
3. Touch  **Menu**, then touch each option to configure:
 - **Advanced:** View and configure your phone’s Wi-Fi settings.
 - **Manage networks:** Touch each connected Wi-Fi networks to view and edit settings.
 - **WPS push button:** Set up WPS on your router.
 - **WPS PIN entry:** Display the WPS PIN for setting up your router.



Advanced Wi-Fi settings

1. From the Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**
2. Touch  **Menu** → **Advanced**.
3. Configure settings:
 - **Auto-connect:** When enabled, your phone will automatically connect to known Wi-Fi networks when you launch a high data-usage application, even if Wi-Fi is turned off. A known Wi-Fi network is one that you previously added.
 - **Keep Wi-Fi on during sleep:** Specify when to switch from Wi-Fi to mobile data for data communications, when the phone goes to sleep (when the backlight goes out). This setting can affect your data usage, and the behavior of devices you connect to your phone, such as when tethering.
 - **MAC address:** (Not configurable) View your phone’s MAC address, needed for connecting to some secured networks.
 - **IP address:** (Not configurable) View your phone’s IP address.

Wi-Fi Direct

Wi-Fi Direct allows devices to connect to each other directly via Wi-Fi, without a Wi-Fi network or hotspot, and without having to set up the connection. For example, your phone can use Wi-Fi Direct to share photos, contacts and other content with other Wi-Fi Direct devices.

Turning Wi-Fi Direct On or Off

1. From the Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Touch **Wi-Fi Direct** to turn Wi-Fi Direct On or Off.

Configuring Wi-Fi Direct

1. From the Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Touch **Wi-Fi Direct** to configure settings:
 - When you turn on Wi-Fi Direct, your device automatically searches for available Wi-Fi Direct devices. Touch **Scan** to start a new search.
 - After scanning for devices, touch a device to connect to it, then follow the prompts to complete the connection.
 - Touch **Multi-connect** to create a connection to devices that support multi-connect. Touch **Scan** to search for available multi-connect devices, then touch the devices you want to connect to and follow the prompts to complete the connection.

Bluetooth

Your phone supports Bluetooth® 4.0.

Bluetooth profiles

Bluetooth profiles are specifications for services supported by individual devices. Profiles improve the ability of different devices to work together. Your phone supports these Bluetooth profiles:




- **Headset:** HSP v1.2 profile supports use of compatible Bluetooth headsets for mono voice.
- **Serial Port:** SPP profile supports setting up emulated serial cable connections with other Bluetooth devices.
- **Handsfree:** HFP v1.5 profile supports Bluetooth headsets, and may also support other compatible Bluetooth devices with speakerphone capabilities.
- **Stereo:** A2DP v1.2, AVRCP v1.0, GAVDP 1.2, AVCTP 1.3 and AVDTP 1.2 profiles support delivery of stereo audio to compatible Bluetooth devices.
- **Object Exchange:** OPP v1.0 profile allows sending and receiving of contact name cards (vCard 2.1) and calendar events (vCalendar) between devices. PBAP v1.2 supports exchange of Phone Book Objects.

- **Human Interface Devices:** HID v1.0 profile supports certain interface devices.
- **Personal Area Networking:** PAN 1.0 supports exchange of data with other devices.

Note: This device does not support all Bluetooth profiles.

For vehicle/accessory compatibility, visit www.verizonwireless.com/bluetoothchart.

Turning Bluetooth On or Off

1. From the Home screen, touch  **Apps** →  **Settings**.
2. Touch **Bluetooth**  to turn Bluetooth On or Off.

Tip: You can also turn Bluetooth On or Off on Notifications.

Bluetooth settings

Pair with other Bluetooth devices, manage your Bluetooth connections, and control your device's visibility to other devices.



Note: Bluetooth must be turned On to access Bluetooth settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Bluetooth**.
2. Touch a setting to configure Bluetooth:
 - Touch  to turn Bluetooth On or Off.
 - Touch your phone's name to control its visibility to other devices' Bluetooth searches. Available when Bluetooth is turned On.
 - Touch **Scan** to search for visible Bluetooth devices. After searching, touch a device to pair with it. For more information, see *"Pairing with a Bluetooth Device"* on page 90.

Data usage

Control your device's connection to mobile data service, and monitor your data usage.

Turning Mobile data On or Off



1. From the Home screen, touch  **Apps** →  **Settings** → **Data usage**.
2. Touch **Mobile data** to turn mobile data On or Off.
3. Touch **Limit mobile data usage**, then use the slider on the data usage graph to set a limit.
4. Touch **Alert me about data usage**, then use the slider on the data usage graph to set a warning limit.
5. View **Data usage cycle** for the current month or **Change cycle** to view other cycles.

Tip: You can also turn Mobile Data On or Off on Notifications.

Mobile networks

Set options for network selection and data service.



Important! Depending on your service plan, changes you make to mobile networks settings may incur extra charges. Consult Verizon Wireless for more information.

1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **Mobile networks**.
2. Set these options:
 - **Mobile data:** Enable or disable your phone's connection to the mobile data network. You can also control this setting at Notifications with the Mobile data toggle.
 - **Global Data Roaming Access:** Enable or disable connection to data services when your device is roaming on another network. For more information about roaming, see “*Roaming*” on page 11.
 - **Roaming:** (Not configurable) View the current roaming status.
 - **Signal strength:** (Not configurable) View the current signal strength.

VPN

When access to VPN, Basic VPN and Advanced IPsec VPN are seen, you can use your phone's VPN (Virtual Private Network) feature to connect to VPNs. For more information about using VPNs, see “*VPN*” on page 91.

Adding a VPN

1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **VPN**.
2. Touch **Basic VPN** or **AdvancedIPsec VPN** and follow the prompts to set up a connection to a VPN. Available settings depend on the type of VPN.

Note: You must enable at least pattern , PIN, or password security before setting up a VPN. If you have not yet enabled security, you'll be prompted to do so the first time you launch VPN settings.



Nearby devices

Share files with devices using DLNA (Digital Living Network Alliance) standards, over Wi-Fi.

To use devices for sharing, you must connect to a Wi-Fi network. The devices you wish to share files with must also be connected to the same Wi-Fi network and must support DLNA.

For more information about connecting to Wi-Fi, see “*Wi-Fi*” on page 95.

Important! Use care when enabling file sharing for devices. When enabled, other devices can access data on your device.


1. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **Nearby devices**.
2. Touch **File sharing** to turn file sharing via DLNA On or Off. A Wi-Fi connection will be needed to share files.

3. Under **Advanced**, touch options to control how content is shared from your device:
 - **Shared contents:** Choose the type of content to share, from **Videos**, **Photos**, or **Music**.
 - **Device name:** View or modify your device's name.
 - **Allowed devices list:** View and manage devices allowed to connect to your device.
 - **Not-allowed devices list:** View and manage devices restricted from connecting to your device.
 - **Download to:** Choose a location to save downloaded content, from USB storage (phone memory) or SD card.
 - **Upload from other devices:** Choose how to handle incoming files from other devices, from **Always accept**, **Always ask**, or **Always reject**.

Sound

Mute

Use Mute to temporarily silence the sounds your phone makes, except for media playback and alarms, or replace them with vibration.

- Press and hold the  **Power/Lock Key** and touch Mute, or Vibrate.
 - **Mute:** Enable Mute mode, to silence all sounds.
 - **Vibrate:** Enable Vibrate mode, to replace sounds with vibration. You can also enable Vibrate mode by pressing the Volume Key down from the Home screen, by touching and holding the # key on the Phone keypad, or from Notifications.

Tip: Vibrate and Mute Silent modes are also available from Notifications.

Volume




Set the system volume level, and set default volume for call ringtones, notifications, and media playback.

Note: You can also set System volume from the Home screen by pressing the **Volume Key**.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Volume**.
2. Touch and drag the sliders for:
 - **Music, video, games, and other media:** Set the default volume level for audio playback. You can also adjust volume from this default inside the apps.
 - **Ringtone:** Set the volume for incoming call ringtones.
 - **Notifications:** Set the volume for notifications, such as new messages and event reminders.
 - **System:** Set the volume for all other system sounds, such as keytones played for screen touches. You can control whether tones play for screen touches with other sound settings.
3. Touch  to save your settings.

Device ringtone


Choose a ringtone for incoming calls.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Device ringtone**.
2. Touch a ringtone to select it. As you touch ringtones, a sample plays, unless you have a Silent mode enabled.
3. Touch  to save your settings.

Tip: You can also set songs as ringtones for all calls, or for a selected contact. For more information, see “*Setting a Song as a Ringtone*” on page 82.

Device vibration

Choose a vibration pattern to use when vibration is enabled.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Device vibration**.

2. Touch a vibration to select it. As you touch vibrations, a sample plays.




– or –

To create your own vibration, touch **Create**. On the **Tap to create** area of the screen, tap your vibration, then touch **Stop**. Touch **Save** to save your vibration.

3. Touch  to save your settings.

Default notifications



Choose a default sound to play for notifications, such as for new messages and event reminders.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Default notifications**.
2. Touch a sound to select it. As you touch sounds, a sample plays.
3. Touch  to save your settings.

Tip: You can also set songs as ringtones for notifications. For more information, see “*Setting a Song as a Ringtone*” on page 82.

Vibrate when ringing



When enabled, the Device vibration plays for incoming calls.

- From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Vibrate when ringing**.

A green check mark indicates activation.



Keytones

Keytones are sounds that play when you touch keys on the Phone keypad.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound**.
2. Touch **Keytones** to turn key sounds On or Off.



Touch sounds

Touch sounds play when you touch items on the screen, such as when making a selection.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound**.
2. Touch **Touch sounds** to turn sounds On or Off.



Screen lock sound

Screen lock sound plays when you lock or unlock the screen.

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound**.
2. Touch **Screen lock sounds** to turn sounds On or Off.

Emergency tone



You can set your phone to play an alert tone or vibrate during an emergency call (for example, calls to 911).

1. From the Home screen, touch  **Apps** →  **Settings** → **Sound** → **Emergency tone**.
2. Touch **Alert** or **Vibrate**, or touch **Off** for no emergency tone.

Display

Wallpaper

Customize the background of the Home and Lock screens.

1. From the Home screen, touch  **Apps** →  **Settings** → **Wallpaper**.
2. Select a screen, from **Home screen**, **Lock screen**, or **Home and Lock screens**.
3. Select a source for wallpaper, from **Gallery**, **Live wallpapers**, or **Wallpapers**.
4. Follow the prompts to set the picture or wallpaper.

Note: You can also set Wallpaper by touching and holding on the Home screen.

LED Indicator




The LED indicator on the front of the phone displays when the phone is locked (the screen is off), to notify you of status changes and events. Use LED indicator settings to configure how the LED functions.

1. From the Home screen, touch  **Apps** →  **Settings** → **LED indicator**.

2. Select options:
 - **Charging:** When turned On, the LED glows red during charging, and green when the battery is fully charged.
 - **Low battery:** When turned On, the LED blinks red to indicate low battery charge.
 - **Notifications:** When turned On, the LED blinks orange to show that you have missed calls, messages, or application events.
 - **Voice recording:** When turned On, the LED glows blue when you are recording voice while the screen is off.



Brightness

Set the default screen brightness.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display** → **Brightness**.
2. Touch and drag the slider to set the brightness, or touch **Automatic brightness** to allow the phone to adjust brightness in response to light conditions.
3. Touch  to save the setting.

Auto-rotate screen



When enabled, the screen's orientation automatically changes when you rotate the phone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display**.
2. Touch **Auto-rotate screen** to turn the feature On or Off.

Tip: You can also set Auto rotate from Notifications with the Screen rotation setting.



Screen timeout

Set the length of delay between the last key press or screen touch and the automatic screen timeout (dim and lock).

1. From the Home screen, touch  **Apps** →  **Settings** → **Display** → **Screen timeout**.
2. Touch a setting to select it.


Font style

Set the font for screen displays.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display** → **Font style**.
2. Select a font, or touch **Get fonts online** to browse and download a new font.



Font size

Set the font size for screen displays.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display** → **Font size**.
2. Select a font size.



Touch key light duration

Set the length of time the Menu and Back Keys remain lit after you touch them.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display** → **Touch key light duration**.
2. Choose a time period, or **Always off** or **Always on**.

Display battery percentage

When On, the battery's charge level displays in the Status bar next to the Battery icon.

1. From the Home screen, touch  **Apps** →  **Settings** → **Display**.
2. Touch **Display battery percentage** to turn the setting On or Off.



Storage

Manage the use of memory resources in your phone's Device memory, and on an installed memory card.



Device memory

View usage for your phone's internal memory.

Note: This setting cannot be configured.




1. From the Home screen, touch  **Apps** →  **Settings** → **Storage**.
2. Under **Device memory**, view memory usage for various categories. Touch a category for more information.

SD card

1. From the Home screen, touch  **Apps** →  **Settings** → **Storage**.
2. Under **SD card**, view memory usage for various categories. Touch a category for more information.
3. Touch **Unmount SD card** to prepare the memory card for safe removal or formatting. For more information, see *"Unmounting and Removing a Memory Card"* on page 13.
4. Touch **Format SD card** to permanently remove all content from an installed memory card.



Power saving mode

Configure Power saving settings to conserve battery power.

1. From the Home screen, touch  **Apps** →  **Settings** → **Power saving mode**.
2. Touch **Power saving mode**  to turn the setting On or Off. The setting must be On to configure options.
3. Touch **Power saving mode settings** to configure options. Touch an option to turn it On or Off:
 - **CPU power saving:** When On, the phone's maximum performance is limited. This does not affect normal usage, such as browsing and video playback.
 - **Screen power saving:** When On, the screen uses reduced frame refresh rate and lower brightness.
 - **Learn about power saving mode:** View details about Power saving options.

Battery

See what's using battery power.



1. From the Home screen, touch  **Apps** →  **Settings** → **Battery**.

2. View battery usage for applications and services currently running. Touch an item for more information, or to configure options for managing power use.

Application manager

You can download and install applications from the Google Play™ Store, or create applications using the Android SDK and install them on your phone. Use Application manager to manage applications on your phone.

Warning! Because this device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

1. From the Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch **Downloaded**, **Running**, or **All** to view the status of applications and services. Touch an app or service for more information, and for app options, such as stopping or uninstalling.



Location services

Location services control your device's use of GPS signals. Some apps may require one or more location services be turned On for full app functionality.

GPS signals may be affected by your surroundings, including:



- Buildings
- Tunnels or underground structures
- Weather conditions
- High-voltage or electromagnetic fields
- Tinted windows

Important! Verizon Wireless values your privacy. Because of this, your phone is defaulted to only acquire your location when you dial 911. To use Location-Based Services, you must first enable location services on your phone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Location services**.
2. Touch the **Access to my location** slider to enable or disable the Verizon Wireless and Google location services.
3. Touch **Agree** to the Location consent information displayed.

E911

E911 location service is standard on all mobile phones, to allow sharing of your GPS location with emergency personnel when you make a call to emergency services (such as 911). This setting is not configurable.



- From the Home screen, touch  **Apps** →  **Settings** → **Location services** → **E911**.

GPS and Verizon location services

Your phone can share your approximate location with applications such as maps, shopping, and weather.

Determining your location requires access to the mobile network and data use applies.

Important! By selecting VZW location services, you are enabling Verizon Wireless and third-party authenticated and validated location services to access certain location information available through this device and/or the network.

1. From the Home screen, touch  **Apps** →  **Settings** → **Location services**.
 2. Touch **GPS & Verizon location services** to enable or disable Verizon location services.
-


Note: Verizon location activates in step 3 of Location services when you touch **Agree**.

Google Wi-Fi and Mobile Network Location

Enable or disable location services from Google location services.

Google location services must be enabled to use some applications.

Important! Consenting to grant location information allows Google's location service to collect anonymous location data. Some data may be stored on your device. Collection may occur even when no apps are running.

1. From the Home screen, touch  **Apps** →  **Settings** → **Location services**.
 2. Touch **Google Wi-Fi & Mobile network location** to enable or disable Google location services.
-

Note: Google location activates in step 3 of Location services when you touch **Agree**.

Lock Screen

Screen lock

Choose settings for locking and unlocking your phone.

For more information about using the lock and unlock features, see “*Securing Your Phone*” on page 13.

1. From the Home screen, touch  **Apps** →

 **Settings** → **Lock screen** → **Screen lock**.





2. Touch one of the following settings:

- **Swipe:** When enabled, you unlock the phone by swiping your finger across the screen. This is the default screen lock, and offers no security, but you can set special lock screen options; see “*Lock screen options*” on page 112.
- **Face unlock:** When enabled, you unlock the phone by looking at the screen. This option offers low security, because someone who looks similar to you could unlock your phone. Touch the option for more information, and to set up Face unlock.
- **Face and voice:** When enabled, you unlock the phone by looking at the screen and speaking. This option offers low security, because someone who looks and/or sounds similar to you could unlock your phone. Touch the option for more information, and to set up Face unlock.

- **Pattern:** When enabled, you draw a pattern, which you create, on the screen to unlock the phone. Touch the option, then follow the prompts to create or change your screen unlock pattern.
- **PIN:** When enabled, you enter a numeric PIN (Personal Identification Number), which you create, to unlock the phone.
- **Password:** When enabled, you enter an alphanumeric password, which you create, to unlock the phone.
- **None:** Disable all custom screen lock settings, to use the default swipe unlock screen.

Lock screen options



When the Screen lock is set to Swipe or Motion, set options for unlocking the screen.

1. From the Home screen, touch  **Apps** →  **Settings** → **Lock screen** → **Lock screen options**.
2. Configure these options:
 - **Shortcuts:** Touch  to control display of app shortcuts at the bottom of the lock screen. Touch **Shortcuts** to choose shortcuts to display: touch and drag a shortcut to a new position, or to the trash can to remove it, and touch **+** to select a new shortcut.
 - **Clock:** Touch the check box to control display of a digital clock on the lock screen.
 - **Dual clock:** Touch  to control display of a dual clock to show the time in two zones when you're traveling. Touch **Dual clock** to set a home city. When you have location services turned on while traveling, the dual clock will display the time in your home city and current location.
 - **Help text:** Touch the check box to control display of tips as you use the lock screen.

- **Wake up in lock screen:** Touch the check box to enable or disable unlocking by spoken wake-up command.
- **Set wake-up command:** Configure wake-up commands, to be used when the Wake up in lock screen option is enabled. You can configure commands to wake up the phone, or other popular features.

Owner information

Enter text to display on the Lock screen.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security** → **Owner information**.
2. Enter Owner information text. For more information about entering text, see see *“Entering Text”* on page 28.
3. Touch **Show owner info on lock screen** to enable display of Owner information on the Lock screen.

Security

Encryption

As a security measure, you can encrypt the contents of your phone or an installed memory card, and require a password each time you turn on the phone or access the memory card.

Encryption may take an hour or more to complete. Start with a charged battery, and attach the charger until encryption is complete. Loss of power or other interruption may cause the loss of some or all data.



Encrypt device

As a security measure, you can encrypt the contents of your device and require a password to access the contents each time you turn it on.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Encrypt device** to start encryption. Follow the prompts to complete encryption.



Encrypt external SD card

As a security measure, you can encrypt the contents of an installed SD card, and require a password each time you access the card.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Encrypt external SD card** to start encryption. Follow the prompts to complete encryption.

Passwords

When enabled, password characters display briefly as you enter them.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Make passwords visible** to enable or disable brief displays of password characters.

Device administration



View or disable device administrators. Some applications, such as Corporate email, may require you allow access to your device by device administrators in certain circumstances, such as if your phone is lost or stolen.

Some features a device administrator might control include:

- Setting the number of failed password attempts before the phone is restored to factory settings
- Automatically locking the phone.
- Restoring factory settings on the phone.



Device administrators

View, add or remove device administrators.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Device administrators**, then touch device administrators.

Unknown sources

When enabled, you can install applications from sources other than Google Play[®] Store, or Verizon Apps.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Unknown sources** to enable or disable the option.



Warning! Because this device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

Credential storage

Trusted credentials

You can install credentials from an installed memory card, and use the Credential storage settings to allow applications to access the secure certificates and other credentials.



Trusted credentials

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Trusted credentials** to view certificates you've installed.

Install from device storage

Install encrypted certificates from an installed memory card.



Note: You must have installed a memory card containing encrypted certificates to use this feature.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Install from device storage**, then choose a certificate and follow the prompts to install.

Clear credentials

Clear stored credentials and reset the password.



Note: This setting is only available if you have installed certificates.

1. From the Home screen, touch  **Apps** →  **Settings** → **Security** → **Clear credentials**.
2. Follow the prompts to clear stored credentials and reset the password.

Language and input

Language

Set the language used by your phone's screens.

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Language**.
2. Select a language from the list.

Personal dictionary

Create and manage a list of words for use in text entry, for matching your key touches with words.



1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Personal dictionary**.
2. Manage your word list:
 - Select  to enter new words.
 - Touch a word to **Edit** the word.
 - Touch  to delete a word.

Keyboards and input methods

Configure text entry options to your preferences.

Default




Choose the default method for entering text. From the factory, the default method is Samsung keyboard. If you install other text entry apps, you can set them as default here.

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Default**.
2. Touch an input method.

Google voice typing settings

Configure Google voice input settings. When you enable Google voice in Settings, it is available for text entry when you touch a text field to enter text.




For more information, see *“Using Google Voice Typing”* on page 29.

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input**.
2. Touch **Google voice typing** to enable it.
3. Touch  beside **Google voice typing** to configure options:
 - **Choose input languages:** Select languages for Google voice typing. Select **Automatic** to use the Default language exclusively, or choose other language(s).
 - **Block offensive words:** When enabled, words many people find offensive are not shown in results of Google voice searches. Offensive words are replaced in results with a placeholder (####).
 - **Download offline speech recognition:** Enables voice input while offline. Touch the All tab to download speech recognition for other languages.


Samsung keyboard

Configure Samsung keypad settings. When you enable Samsung keyboard in Settings, it is available for text entry when you touch a text field to enter text.

For more information, see *“Using Samsung Keyboard”* on page 28.

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input**.
2. **Samsung keyboard** is enabled by default. Touch  to configure options:
 - **Portrait keyboard types:** Choose the default keypad when the screen is in portrait mode, from QWERTY or 3x4 keyboard (similar to a phone keypad).
 - **Input language:** Select languages for the Samsung keyboard.

Tip: When you have more than one language selected, you can slide your finger on the space bar while entering text to switch languages.




- **Predictive text:** Touch  to enable predictive text, to have predictive text suggest words matching your text entries and optionally, complete common words automatically. Touch **Predictive text** to configure options:
 - **Word completion:** When enabled, predictive text automatically completes words matching your key touches.
 - **Word completion point:** When Word completion is enabled, choose the number of letters predictive text uses to predict words for automatic completion.
 - **Spell correction:** Enable for automatic spelling check and correction.
 - **Next word prediction:** When enabled, the system predicts the next word based on common usage patterns.
 - **Auto-append:** When enabled, the most common predicted word is automatically added to your text.
 - **Auto-substitution:** When enabled, predictive text automatically replaces words you enter with words from the auto substitution list.
 - **Regional correction:** When enabled, predictive text automatically changes the spelling of words based on norms for your default language.

- **Recapture:** When enabled, predictive text re-displays matching words when you make corrections to a word inserted automatically.
- **My word list:** Add words to your predictive text predictive text dictionary.
- **Auto substitution list:** Manage the list of words predictive text uses for auto-substitution (Auto-substitution setting must be enabled).
- **T9 Trace:** Enter text by sliding your finger across the keyboard without lifting it.
- **Voice input:** When enabled, the voice input key appears on the keyboard.
- **Auto capitalization:** When enabled, predictive text automatically capitalizes words in your text based on common usage, such as at the beginning of sentences.
- **Auto-punctuate:** When enabled, a period and space are automatically entered to end a sentence, when you tap the space bar twice.
- **Character preview:** When enabled, characters available on the key you touch display briefly as you enter text.

- **Key-tap sound:** When enabled, a sound plays for your key touches.
- **Tutorial:** View help for using predictive text.
- **Reset settings:** Touch to reset Samsung keyboard settings to the defaults, except for your personal dictionary and the Auto substitution list.

Swype



To configure Swype settings:

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input**.
2. Touch  next to **Swype** to configure settings:
 - **How to Swype** Displays an on-screen manual for Swype.
 - **Gestures:** Displays helpful information on using gestures while using Swype.
 - **Preferences:** Configure basic Swype settings.
 - **Language Options:** Touch the Language field to select a language (English is the default). Touch Living Language to automatically update Swype with popular new words.

- **Swype Connect:** Requires you to register to create a Swype account. Touch **Contribute usage data** to allow Nuance to collect usage information so it can provide better predictions. Touch **Cellular data** to enable cellular data Swype updates, language, downloads and other Swype Connect features over the data connection.
- **Personalization:** Personalize the Dictionary, or your experience using Facebook, Twitter, or Gmail.
- **Updates:** Provides updates to Swype.




Speech

Voice search

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Voice search**.
2. Set options:
 - **Language:** Choose a language for voice searching.
 - **Speech output:** Always provides audible readout of text, or only when using Hands-free functions.
 - **Block offensive words:** When enabled, words many people find offensive are not shown in results of Google voice searches. Offensive words are replaced in results with a placeholder (####).
 - **Hotword detection:** When enabled, saying the word Google launches voice search.
 - **Download offline speech recognition:** Enable voice input while offline. Touch the All tab to download speech recognition for other languages.
 - **Personalized recognition:** Improves speech recognition accuracy.
 - **Bluetooth headset:** Record audio through the Bluetooth headset.



Text-to-speech output

Text-to-speech (TTS) provides audible readout of text, for example, the contents of text messages, and the Caller ID for incoming calls.

1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Text-to-speech output**.
2. Touch a setting to configure:
 - **Preferred TTS engine**
 - Select **Google Text-to-speech Engine**, or **Samsung TTS**.
 - **General**
 - **Speech rate:** Choose a rate at which text readouts are spoken.
 - **Listen to an example:** Play a sample of speech synthesis.
 - **Driving mode:** When enabled, incoming calls and new notifications are read out automatically. Touch  to enable. Touch **Driving mode** to choose items for readout when Driving mode is enabled.

Mouse/trackpad

Customize the response of your screen swipes.



1. From the Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Pointer speed**.
2. Touch and drag along the scale to set the pointer speed.

Back up and reset

Set options for backing up your information and resetting your device.



Back up my data

When enabled, app data, Wi-Fi passwords, and other phone settings are backed up to Google servers.

1. From the Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Back up my data** to enable or disable back-up.



Backup account

Sign in to a Google account to use for backing up settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Backup account**, then follow the prompts to sign in to a Google account.



Automatic restore

Use Automatic restore to have previous app settings and data automatically update from the backup when you reinstall the app.

1. From the Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Automatic restore** to enable or disable the setting.

Factory data reset

Use Factory data reset to return all settings to the defaults, and remove all data from the phone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Factory data reset**, then follow the prompts.


Important! Settings and data erased in a Factory data reset cannot be recovered. To save your settings, you can use Back up my data settings before a reset.



Accounts

Set up and manage accounts, including Samsung, Google, email and your social networking accounts.

Backup Assistant Plus

Backup Assistant Plus is a new service that integrates the features and capabilities of Backup Assistant, V CAST Media Manager, and Sync & Connect. Back up contacts, photos, music, documents and videos to a secure, online storage cloud.

- From the Home screen, touch  **Apps** →  **Settings** → **Backup Assistant Plus**.

Tip: You can also launch Backup Assistant Plus from  **Contacts**. From Contacts, touch  **Menu** to select **Backup**.



Add Account

Set up a Samsung account, Email account, Facebook account, Google account, LDAP account, or Microsoft Exchange Active Sync account.

For more information about setting up, syncing, and managing accounts, see “Accounts” on page 43.



Accessory

Configure your phone’s behavior when it is connected to optional accessories (not included).

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessory**.
2. Configure settings:
 - **Dock sound:** When enabled, a sound plays when you insert and remove the phone from the dock.
 - **Audio output mode:** When enabled, audio plays through the dock speakers when the phone is docked.
 - **Desk home screen display:** When enabled, displays a special screen when the phone is docked.
 - **Audio applications:** Displays applications in the Quick panel when you plug in headphones.

Date and time

By default, your phone receives date and time information from the wireless network. When you are outside network coverage, you may want to set date and time information manually using the Date & time settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Date and time**.
2. Touch a setting to configure:
 - **Automatic date and time:** When enabled, the phone takes date and time updates from the wireless network.
 - **Set date:** Enter the current date (only available when Automatic date and time is disabled).
 - **Set time:** Enter the current time (only available when the Automatic setting is disabled).
 - **Automatic time zone:** When enabled, the phone takes the time zone from the wireless network.
 - **Select time zone:** Choose your local time zone (only available when the Automatic setting is disabled).
 - **Use 24-hour format:** Set the format for time displays.
 - **Select date format:** Set the format for date displays.



Accessibility

Your phone offers features to make using the phone easier for those with certain physical disabilities. Use the Accessibility settings to activate these services.

System

Auto-rotate screen



When enabled, the screen's orientation automatically changes when you rotate the phone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Auto-rotate screen** to turn the feature On or Off.

Tip: You can also set Auto rotate from Notifications with the Screen rotation setting.



Screen timeout

Set the length of delay between the last key press or screen touch and the automatic screen timeout (dim and lock).

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility** → **Screen timeout**.
2. Touch a setting to select it.



Lock automatically

Set the length of time between the automatic screen timeout and locking the phone. **Screen lock** must be set for this option to appear.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility** → **Lock automatically**.
2. Touch a setting to select it.



Speak passwords

When enabled, you can speak passwords for log-ins.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Speak passwords** to turn the feature On or Off.



Answering/ending calls



This manages call answering or ending settings.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Answering/ending calls** and touch an option:
 - **The home key answers calls:** Answers incoming calls when you press the Home key.
 - **Answer calls using voice:** Answers incoming calls when you use a voice command.

- **The power key ends calls:** To enable or disable answering incoming calls by pressing the Power/Lock Key.



Accessibility shortcut

When enabled, a link to Accessibility settings displays on the Device options menu, which appears when you press and hold the   **Power/Lock Key**. This provides quick access to accessibility settings, to make changes as you use the phone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Accessibility shortcut** to enable or disable the setting.

TalkBack



Enable or disable accessibility services.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **TalkBack** to enable or disable readout of menu options, application titles, contacts, and other items when scrolling and making selections.

Vision



Font size

Set the font size for screen displays.



1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility** → **Font size**.
2. Select a size.

Negative colors



When enabled, screen colors are reversed.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Negative colors** to enable or disable reversal of screen colors.

Text-to-speech output

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Text-to-speech output** and select the preferred TTS engine to set voice output settings.



Enhance web accessibility

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Enhance web accessibility** to enable or disable the service.
3. Touch **Allow** to allow applications to install scripts from Google that make their Web content more accessible.

Hearing



Mono audio

When enabled, sound is delivered as mono, to support listening with one earphone.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Mono audio** to enable or disable the service.

Turn off all sounds



When enabled, all sounds are disabled, including the voice portion of calls.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Turn off all sounds** to enable or disable the service.

Mobility


Tap and hold delay

Set the length of time the phone considers a screen touch before interpreting a touch as touch-and-hold.

1. From the Home screen, touch  **Apps** →  **Settings** → **Accessibility** → **Tap and hold delay**.
2. Touch a setting to select it.

Developer options

Set options for use when developing apps for devices.

1. From the Home screen, touch  **Apps** →  **Settings** → **Developer options**.
2. Touch these options for development:
 - **Desktop backup password**: enter the current and new passwords. Touch Set backup password to save your settings.
 - **Stay awake**: When enabled, the screen will not shut off while the phone is charging.
 - **Protect SD card**: When enabled, apps must request permission to read the SD card.

Debugging options

- **USB debugging**: When enabled, connecting your device to a computer with a USB data cable launches the debugging mode.
- **Allow mock locations**: Allows your phone to mock locations for testing.
- **Select app to be debugged**: Touch an application to debug.
 - **Wait for debugger**: The application selected in the Select app to be debugged option opens when the debugger attaches.

Input options

- **Show touches:** Displays visual feedback for touch interactions.
- **Show pointer location:** When enabled, the current pointer location shows on a screen overlay.

Drawing options

- **Show layout boundaries:** When enabled, clip boundaries, margins, and other layout details display.
- **Show GPU view updates:** When enabled, views are flashed inside windows when they are drawn with the GPU.
- **Show screen updates:** When enabled, areas of the screen flash as they update.
- **Window animation scale:** Choose a scale for window animations.
- **Transition animation scale:** Choose a scale for screen transitions.
- **Animator duration scale:** Choose a scale for animators.
- **Disable hardware overlay:** When enabled, the GPU is always used for screen compositing.
- **Force GPU rendering:** When enabled, 2D hardware acceleration is used in applications.

Monitoring options

- **Strict mode:** When enabled, the screen flashes while apps perform long operations.
- **Show CPU usage:** When enabled CPU usage displays on a screen overlay.
- **GPU rendering profile:** When enabled, rendering time is measured in adb shell `dumpsys gfxinfo`.
- **Enable traces:** Choose traces.

Apps options

- **Do not keep activities:** When enabled, activities are destroyed as soon as the user leaves them.
- **Limit background processes:** Choose options for processes running in the background.
- **Show all ANRs:** When enabled, an App Not Responding dialog displays for apps running in the background.

About phone

View information about your phone, including status, legal information, hardware and software versions, and a tutorial.

1. From the Home screen, touch  **Apps** →  **Settings** → **About phone**.
2. Touch items to view details:
 - **Software update:** Check availability and install updates.
 - **Status:** View information about your phone's current status.
 - **Legal information:** Display open source licenses, configure license settings, including your DivX[®] VOD registration, and Google info.
 - **Model number:** View your phone's model number.
 - **Android version:** View the firmware version of your phone.
 - **Baseband version:** View the baseband version of your phone.
 - **Kernel version:** View the kernel version of your phone.
 - **Build number:** View the build number of your phone.
 - **Hardware version:** View the hardware version of your phone.

Section 9: Health and Safety Information

This device is capable of operating in Wi-Fi™ mode in the 2.4 and 5 GHz bands. The FCC requires that devices operating within 5.15-5.25 GHz may only be used indoors, not outside, in order to avoid interference with Mobile Satellite Services (MSS). Therefore, this device is restricted from being used outdoors when operating in frequencies between 5.15-5.25 GHz.

This section outlines the safety precautions associated with using your phone. The terms “mobile device” or “cell phone” are used in this section to refer to your phone. **Read this information before using your mobile device.**

Exposure to Radio Frequency (RF) Signals

The U.S. Food and Drug Administration (FDA) has published information for consumers relating to Radio Frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

Do cell phones pose a health hazard?

Many people are concerned that cell phone radiation will cause cancer or other serious health hazards. The weight of scientific evidence has not linked cell phones with any health problems.

Cell phones emit low levels of Radio Frequency (RF) energy. Over the past 15 years, scientists have conducted hundreds of studies looking at the biological effects of the radio frequency energy emitted by cell phones. While some researchers have reported biological changes associated with RF energy, these studies have failed to be replicated. The majority of studies published have failed to show an association between exposure to radio frequency from a cell phone and health problems.

The low levels of RF cell phones emit while in use are in the microwave frequency range. They also emit RF at substantially reduced time intervals when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects.

The biological effects of radio frequency energy should not be confused with the effects from other types of electromagnetic energy.

Very high levels of electromagnetic energy, such as is found in X-rays and gamma rays, can ionize biological tissues. Ionization is a process where electrons are stripped away from their normal locations in atoms and molecules. It can permanently damage biological tissues including DNA, the genetic material.

The energy levels associated with radio frequency energy, including both radio waves and microwaves, are not great enough to cause ionization of atoms and molecules.

Therefore, RF energy is a type of non-ionizing radiation. Other types of non-ionizing radiation include visible light, infrared radiation (heat), and other forms of electromagnetic radiation with relatively low frequencies.

While RF energy does not ionize particles, large amounts can increase body temperatures and cause tissue damage. Two areas of the body, the eyes and the testes, are particularly vulnerable to RF heating because there is relatively little blood flow in them to carry away excess heat.

Research Results to Date: Is there a connection between RF and certain health problems?

The results of most studies conducted to date say no. In addition, attempts to replicate and confirm the few studies that have shown a connection have failed.

The scientific community at large therefore believes that the weight of scientific evidence does not show an association between exposure to Radio Frequency (RF) from cell phones and adverse health outcomes. Still the scientific community has supported additional research to address gaps in knowledge. Some of these studies are described below.

Interphone Study

Interphone is a large international study designed to determine whether cell phones increase the risk of head and neck cancer. A report published in the International Journal of Epidemiology (June, 2010) compared cell phone usage for more than 5,000 people with brain tumors (glioma and meningioma) and a similar number of healthy controls.

Results of this study did NOT show that cell phones caused brain cancer. In this study, most people had no increased risk of brain cancer from using cell phones. For people with the heaviest use of cell phones (an average of more than ½ hour per day, every day, for over 10 years) the study suggested a

slight increase in brain cancer.

However, the authors determined that biases and errors prevented any conclusions being drawn from this data.

Additional information about Interphone can be found at http://www.iarc.fr/en/media-centre/pr/2010/pdfs/pr200_E.pdf.

Interphone is the largest cell phone study to date, but it did not answer all questions about cell phone safety. Additional research is being conducted around the world, and the FDA continues to monitor developments in this field.

International Cohort Study on Mobile Phone Users (COSMOS)

The COSMOS study aims to conduct long-term health monitoring of a large group of people to determine if there are any health issues linked to long-term exposure to radio frequency energy from cell phone use. The COSMOS study will follow approximately 300,000 adult cell phone users in Europe for 20 to 30 years. Additional information about the COSMOS study can be found at <http://www.ukcosmos.org/index.html>.

Risk of Brain Cancer from Exposure to Radio Frequency Fields in Childhood and Adolescence (MOBI-KIDS)

MOBI-KIDS is an international study investigating the relationship between exposure to radio frequency energy from communication technologies including cell phones and brain cancer in young people.

This is an international multi-center study involving 14 European and non-European countries. Additional information about MOBI-KIDS can be found at http://www.creal.cat/programes-recerca/en_projectes-creal/view.php?ID=39.

Surveillance, Epidemiology, and End Results (SEER) Program of the National Cancer Institute

The National Cancer Institute (NCI) actively follows cancer statistics in the United States to detect any change in rates of new cases for brain cancer. If cell phones play a role in risk for brain cancer, rates should go up, because heavy cell phone use has been common for quite some time in the U.S. Between 1987 and 2005, the overall age-adjusted incidence of brain cancer did not increase. Additional information about SEER can be found at <http://seer.cancer.gov/>.

Cell Phone Industry Actions

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the cell phone industry to take a number of steps, including the following:

- Support-needed research on possible biological effects of RF for the type of signal emitted by cell phones;
- Design cell phones in a way that minimizes any RF exposure to the user; and
- Cooperate in providing users of cell phones with the current information on cell phone use and human health concerns.

The FDA also is working with voluntary standard-setting bodies such as the Institute of Electrical and Electronics Engineers (IEEE), the International Commission on Non-Ionizing Radiation Protection (ICNIRP), and others to assure that safety standards continue to adequately protect the public.

Reducing Exposure: Hands-Free Kits and Other Accessories

Steps to Reduce Exposure to Radio Frequency Energy

If there is a risk from being exposed to radio frequency energy (RF) from cell phones - and at this point we do not know that there is - it is probably very small. But, if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your RF exposure.

- Reduce the amount of time spent using your cell phone;
- Use speaker mode or a headset to place more distance between your head and the cell phone.

Hands-Free Kits

Hands-free kits may include audio or Bluetooth® headsets and various types of body-worn accessories such as belt-clips and holsters. Combinations of these can be used to reduce RF energy absorption from cell phones.

Headsets can substantially reduce exposure because the phone is held away from the head in the user's hand or in approved body-worn accessories. Cell phones marketed in the U.S. are required to meet RF exposure compliance requirements when used against the head and against the body.

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used for convenience and comfort. They are also required by law in many states if you want to use your phone while driving.

Cell Phone Accessories that Claim to Shield the Head from RF Radiation

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that accessories which claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone.

Studies have shown that these products generally do not work as advertised. Unlike “hands-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption.

Children and Cell Phones

The scientific evidence does not show a danger to any users of cell phones from RF exposure, including children and teenagers. The steps adults can take to reduce RF exposure apply to children and teenagers as well.

- Reduce the amount of time spent on the cell phone;
- Use speaker mode or a headset to place more distance between the head and the cell phone.

Some groups sponsored by other national governments have advised that children be discouraged from using cell phones at all. For example, The Stewart Report from the United Kingdom made such a recommendation in December 2000. In this report, a group of independent experts noted that no evidence exists that using a cell phone causes brain tumors or other ill effects. Their recommendation to limit cell phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations (updated 10/1/2010):

- FCC RF Safety Program:
<http://www.fcc.gov/oet/rfsafety/>.
- Environmental Protection Agency (EPA):
<http://www.epa.gov/radtown/wireless-tech.html>.
- Occupational Safety and Health Administration (OSHA):
<http://www.osha.gov/SLTC/radiofrequencyradiation/>.
(Note: This web address is case sensitive.)
- National Institute for Occupational Safety and Health (NIOSH):
<http://www.cdc.gov/niosh/>.
- World Health Organization (WHO):
<http://www.who.int/peh-emf/en/>.
- International Commission on Non-Ionizing Radiation Protection:
<http://www.icnirp.de>.
- Health Protection Agency:
<http://www.hpa.org.uk/Topics/Radiation/>.

- US Food and Drug Administration:
<http://www.fda.gov/Radiation-EmittingProducts/RadiationEmittingProductsandProcedures/HomeBusinessandEntertainment/CellPhones/default.htm>.

Specific Absorption Rate (SAR) Certification Information

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for Radio Frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government.

These FCC RF exposure limits are derived from the recommendations of two expert organizations: the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The RF exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body

expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

The FCC SAR limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum reported value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the SAR limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body-worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device a minimum of 1.0 cm from the body.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The FCC has granted an Equipment Authorization for this mobile device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. This mobile phone has an FCC ID number: A3LSCHI200 [Model Number: SCH-i200] and the specific SAR levels for this mobile phone can be found at the following FCC website:

<http://www.fcc.gov/oet/ea/>.

The SAR information for this device can also be found on Samsung's website:

<http://www.samsung.com/sar>.

SAR information on this and other model phones can be accessed online on the FCC's website through <http://transition.fcc.gov/oet/rfsafety/sar.html>. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional SAR information can also be obtained at <http://www.fcc.gov/encyclopedia/specific-absorption-rate-sar-cellular-telephones>.

FCC Part 15 Information to User

Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Commercial Mobile Alerting System (CMAS)

This device is designed to receive Wireless Emergency Alerts from CMAS. If your wireless provider has chosen to participate in CMAS, alerts are available while in the provider's coverage area. If you travel outside your provider's coverage area, wireless emergency alerts may not be available. For more information, please contact your wireless provider.

Smart Practices While Driving

On the Road - Off the Phone

The primary responsibility of every driver is the safe operation of his or her vehicle.

Responsible drivers understand that no secondary task should be performed while driving whether it be eating, drinking, talking to passengers, or talking on a mobile phone - unless the driver has assessed the driving conditions and is confident that the secondary task will not interfere with their primary responsibility.

Do not engage in any activity while driving a moving vehicle which may cause you to take your eyes off the road or become so absorbed in the activity that your ability to concentrate on

the act of driving becomes impaired. Samsung is committed to promoting responsible driving and giving drivers the tools they need to understand and address distractions.

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. For example, only hands-free use may be permitted in certain areas.

Before answering calls, consider your circumstances. Let the call go to voicemail when driving conditions require. Remember, driving comes first, not the call!

If you consider a call necessary and appropriate, follow these tips:

- Use a hands-free device;
- Secure your phone within easy reach;
- Place calls when you are not moving;
- Plan calls when your car will be stationary;
- Do not engage in stressful or emotional conversations;
- Let the person with whom you are speaking know that you are driving and will suspend the call if necessary;
- Do not take notes or look up phone numbers while driving;

Notice regarding legal restrictions on mounting this device in an automobile:

Laws in some states may prohibit mounting this device on or near the windshield of an automobile. In other states, the law may permit mounting this device only in specific locations in the automobile. Be sure to consult the state and local laws or ordinances where you drive before mounting this device in an automobile. Failure to comply with these restrictions could result in fines, penalties, or other damages.

Never mount this device in a manner that will obstruct the driver's clear view of the street and traffic.

Never use wireless data services such as text messaging, Web browsing, or e-mail while operating a vehicle.

Never watch videos, such as a movie or clip, or play video games while operating a vehicle.

For more information, go to <http://www.ctia.org>.

Battery Use and Safety

Important! Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries and, particularly, from the continued use of damaged batteries.

- **Do not disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.** Do not put a high degree of pressure on the battery. This can cause leakage or an internal short-circuit, resulting in overheating.
- **Do not let the phone or battery come in contact with liquids.** Liquids can get into the phone's circuits, leading to corrosion. Even when the phone appears to be dry and appears to operate normally, the circuitry could slowly corrode and pose a safety hazard. If the phone and/or battery get wet, have them checked by your service provider or contact Samsung, even if they appear to be working properly.
- **Do not place your battery in or near a heat source.** Excessive heating can damage the phone or the battery and could cause the phone or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron, or radiator. Avoid leaving your phone in your car in high temperatures.
- **Do not dispose of the phone or the battery in a fire.** The phone or the battery may explode when overheated.

- **Do not handle a damaged or leaking battery.** Do not let leaking battery fluid come in contact with your eyes, skin or clothing. For safe disposal options, contact your nearest Samsung-authorized service center.
- **Avoid dropping the cell phone.** Dropping the phone or the battery, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- **Never use any charger or battery that is damaged in any way.**
- **Do not allow the battery to touch metal objects.** Accidental short-circuiting can occur when a metallic object (coin, key, jewelry, clip, or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.

Important! Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers which are specifically designed for your phone.

WARNING!

Use of a non-Samsung-approved battery or charger may present a risk of fire, explosion, leakage, or other hazard. Samsung's warranty does not cover damage to the phone caused by non-Samsung-approved batteries and/or chargers.

- **Do not use incompatible cell phone batteries and chargers.** Some websites and second-hand dealers not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier-recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- **Misuse or use of incompatible phones, batteries, and charging devices could result in damage to the equipment and a possible risk of fire, explosion, or leakage, leading to serious injuries, damages to your phone, or other serious hazard.**

Samsung Mobile Products and Recycling

Samsung cares for the environment and encourages its customers to recycle Samsung mobile devices and genuine Samsung accessories.

Proper disposal of your mobile device and its battery is not only important for safety, it benefits the environment. Batteries must be recycled or disposed of properly.

Recycling programs for your mobile device, batteries, and accessories may not be available in your area.

We've made it easy for you to recycle your old Samsung mobile device by working with respected take-back companies in every state in the country.

Drop It Off

You can drop off your Samsung-branded mobile device and batteries for recycling at one of our numerous Samsung Recycling Direct (SM) locations. A list of these locations may be found at:

http://pages.samsung.com/us/recyclingdirect/usactivities_environment_samsungrecyclingdirect_locations.jsp

Samsung-branded devices and batteries will be accepted at these locations for no fee.

Consumers may also recycle their used mobile device or batteries at many retail or carrier-provided locations where mobile devices and batteries are sold. Additional information regarding specific locations may be found at: <http://www.epa.gov/epawaste/partnerships/plugin/cellphone/index.htm> or at <http://www.call2recycle.org/>.

Mail It In

The Samsung Mobile Take-Back Program will provide Samsung customers with a free recycling mailing label. Just go to

http://www.samsung.com/us/aboutsamsung/citizenship/usactivities_environment_samsungrecyclingdirect.html?INT=STA_recycle_your_phone_page and follow the instructions to print out a free pre-paid postage label and then send your old mobile device or battery to the address listed, via U.S. Mail, for recycling.

Dispose of unwanted electronics through an approved recycler.

To find the nearest recycling location, go to our website:

www.samsung.com/recyclingdirect

Or call, (877) 278-0799.

Follow local regulations regarding disposal of mobile devices and batteries

Dispose of your mobile device and batteries in accordance with local regulations. In some areas, the disposal of these items in household or business trash may be prohibited. Help us protect the environment - recycle!

Warning! Never dispose of batteries in a fire because they may explode.

UL Certified Travel Charger

The Travel Charger for this phone has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines:

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

Display / Touch-Screen

Please note the following information when using your mobile device:

WARNING REGARDING DISPLAY

The display on your mobile device is made of glass or acrylic and could break if your mobile device is dropped or if it receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.

WARRANTY DISCLAIMER: PROPER USE OF A TOUCH-SCREEN MOBILE DEVICE

If your mobile device has a touch-screen display, please note that a touch-screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch-screen may damage the tempered glass surface and void the warranty. For more information, please refer to the “Standard Limited Warranty”.

GPS

Certain Samsung mobile devices can use a Global Positioning System (GPS) signal for location-based applications. A GPS uses satellites controlled by the U.S. Government that are subject to changes implemented in accordance with the Department of Defense policy and the 2008 Federal Radio navigation Plan (FRP). Changes may affect the performance of location-based technology on your mobile device.

Even with GPS, when you make an emergency call:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the mobile device for as long as the emergency responder instructs you.

Navigation

Maps, directions, and other navigation-data, including data relating to your current location, may contain inaccurate or incomplete data, and circumstances can and do change over time. In some areas, complete information may not be available.

Therefore, you should always visually confirm that the navigational instructions are consistent with what you see before following them. All users should pay attention to road conditions, closures, traffic, and all other factors that may impact safe driving or walking. Always obey posted road signs.

Emergency Calls



This mobile device, like any wireless mobile device, operates using radio signals, wireless and landline networks, as well as user-programmed functions, which cannot guarantee connection in all conditions, areas, or circumstances.

Therefore, you should never rely solely on any wireless mobile device for essential communications (medical emergencies, for example). Before traveling in remote or underdeveloped areas, plan an alternate method of contacting emergency services personnel. Remember, to

make or receive any calls, the mobile device must be switched on and in a service area with adequate signal strength.

Emergency calls may not be possible on all wireless mobile device networks or when certain network services and/or mobile device features are in use. Check with local service providers.

To make an emergency call:

1. If the mobile device is not on, switch it on.
2. From the Home screen, tap  **Phone**.
3. On the Keypad, key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
4. Touch  to place the call.

If certain features are in use (call blocking, for example), you may first need to deactivate those features before you can make an emergency call. Consult your User Manual and your local cellular service provider. When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your mobile device

may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

Care and Maintenance

Your mobile device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years:

Keep your Samsung Mobile Device away from:

Liquids of any kind

Keep the mobile device dry. Precipitation, humidity, and liquids contain minerals that will corrode electronic circuits. If the mobile device does get wet, do not accelerate drying with the use of an oven, microwave, or dryer, because this may damage the mobile device and could cause a fire or explosion.

Do not use the mobile device with a wet hand. Doing so may cause an electric shock to you or damage to the mobile device.

Extreme heat or cold

Avoid temperatures below 0°C / 32°F or above 45°C / 113°F.

Microwaves

Do not try to dry your mobile device in a microwave oven. Doing so may cause a fire or explosion.

Dust and dirt

Do not expose your mobile device to dust, dirt, or sand.

Cleaning solutions

Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the mobile device. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.

Shock or vibration

Do not drop, knock, or shake the mobile device. Rough handling can break internal circuit boards.

Paint

Do not paint the mobile device. Paint can clog the device's moving parts or ventilation openings and prevent proper operation.

Responsible Listening

Caution! Avoid potential hearing loss.

Damage to hearing occurs when a person is exposed to loud sounds over time. The risk of hearing loss increases as sound is played louder and for longer durations. Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss.

Some scientific research suggests that using portable audio devices, such as portable music players and cell phones, at high volume settings for long durations may lead to permanent noise-induced hearing loss.

This includes the use of headphones (including headsets, earbuds, and Bluetooth® or other wireless devices). Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound, and distorted hearing. Individual susceptibility to noise-induced hearing loss and potential hearing problem varies. Additionally, the amount of sound produced by a portable audio device varies depending on the nature of the sound, the device settings, and the headphones

that are used. As a result, there is no single volume setting that is appropriate for everyone or for every combination of sound, settings, and equipment.

You should follow some common sense recommendations when using any portable audio device:

- Always turn the volume down before plugging the earphones into an audio source.
- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.
- Be aware that you can adapt to higher volume settings over time, not realizing that the higher volume may be harmful to your hearing.
- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.
- Do not turn the volume up to block out noisy surroundings. If you choose to listen to your portable device in a noisy environment, use noise-cancelling headphones to block out background environmental noise. By blocking background environment noise, noise cancelling headphones should allow you to hear the music at lower volumes than when using earbuds.

- Limit the amount of time you listen. As the volume increases, less time is required before your hearing could be affected.
- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss. Temporary hearing loss might cause unsafe volumes to sound normal.
- Do not listen at any volume that causes you discomfort. If you experience ringing in your ears, hear muffled speech, or experience any temporary hearing difficulty after listening to your portable audio device, discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:

American Academy of Audiology

11730 Plaza American Drive, Suite 300
Reston, VA 20190

Voice: (800) 222-2336

Email: info@audiology.org

Internet:

<http://www.audiology.org/Pages/default.aspx>

**National Institute on Deafness and Other
Communication Disorders**

National Institutes of Health
31 Center Drive, MSC 2320
Bethesda, MD 20892-2320
Email: nidcdinfo@nih.gov

Internet:

<http://www.nidcd.nih.gov/>

**National Institute for Occupational Safety
and Health (NIOSH)**

395 E Street, S.W., Suite 9200
Patriots Plaza Building
Washington, DC 20201
Voice: 1-800-35-NIOSH
(1-800-356-4674)
1-800-CDC-INFO (1-800-232-4636)
Outside the U.S. 513-533-8328

Email: cdcinfo@cdc.gov

Internet:

[http://www.cdc.gov/niosh/topics/noise/
default.html](http://www.cdc.gov/niosh/topics/noise/default.html)

1-888-232-6348 TTY

Operating Environment

Remember to follow any special regulations in force in any area, and always switch your mobile device off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the mobile device or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

Using Your Mobile Device Near Other Electronic Devices

Most modern electronic equipment is shielded from Radio Frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless mobile device. Consult the manufacturer to discuss alternatives.

Implantable Medical Devices

A minimum separation of six (6) inches should be maintained between a handheld wireless mobile device and an implantable medical device, such as a pacemaker or implantable cardioverter defibrillator, to avoid potential interference with the device.

Persons who have such devices:

- Should ALWAYS keep the mobile device more than six (6) inches from their implantable medical device when the mobile device is turned ON;
- Should not carry the mobile device in a breast pocket;
- Should use the ear opposite the implantable medical device to minimize the potential for interference;
- Should turn the mobile device OFF immediately if there is any reason to suspect that interference is taking place;
- Should read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless mobile device with an implantable medical device, consult your health care provider.

For more information see: <http://www.fcc.gov/oet/rfsafety/rf-faqs.html#>.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your mobile device off in health care facilities when any

regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle before using your mobile device in a motor vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch your mobile device off in any facility where posted notices require you to do so.

Potentially Explosive Environments

Switch your mobile device off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised to switch the mobile device off while at a refueling point (service station).

Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants, or where blasting

operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

When your Device is Wet

Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service center.

FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices

The U.S. Federal Communications Commission (FCC) has established requirements for digital wireless mobile devices to be compatible with hearing aids and other assistive hearing devices.

When individuals employing some assistive hearing devices (hearing aids and cochlear implants) use wireless mobile devices, they may detect a buzzing, humming, or whining

noise. Some hearing devices are more immune than others to this interference noise, and mobile devices also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless mobile devices to assist hearing device users find mobile devices that may be compatible with their hearing devices. Not all mobile devices have been rated. Mobile devices that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated mobile device successfully. Trying out the mobile device with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Wireless mobile devices rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. M4 is the better/higher of the two ratings. M-ratings refer to enabling acoustic coupling with hearing aids that do not operate in telecoil mode.

T-Ratings: Mobile devices rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. T4


is the better/higher of the two ratings. T-ratings refer to enabling inductive coupling with hearing aids operating in telecoil mode.

Hearing devices may also be rated. Your hearing aid manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise.

Under the current industry standard, American National Standards Institute (ANSI) C63.19, the hearing aid and wireless mobile device rating values are added together to indicate how usable they are together. For example, if a hearing aid meets the M2 level rating and the wireless mobile device meets the M3 level rating, the sum of the two values equals M5.

Under the standard, this should provide the hearing aid user with normal use while using the hearing aid with the particular wireless mobile device. A sum of 6 or more would indicate excellent performance.

However, these are not guarantees that all users will be satisfied. T ratings work similarly.



The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

HAC for Newer Technologies

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids.

It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Restricting Children's Access to Your Mobile Device

Your mobile device is not a toy. Do not allow children to play with it because they could hurt themselves and others, damage the mobile device, or make calls that increase your mobile device bill.

Keep the mobile device and all its parts and accessories out of the reach of small children.

FCC Notice and Cautions

FCC Notice

The mobile device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the mobile device if such interference cannot be eliminated. Vehicles using liquefied petroleum gas (such as propane or butane) must comply with

the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association.

Cautions

Any changes or modifications to your mobile device not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas, and chargers. The use of any unauthorized accessories may be dangerous and void the mobile device warranty if said accessories cause damage or a defect to the mobile device.

Although your mobile device is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.

Other Important Safety Information

- Only qualified personnel should service the mobile device or install the mobile device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Ensure that any mobile devices or related equipment installed in your vehicle are securely mounted.

- Check regularly that all wireless mobile device equipment in your vehicle is mounted and operating properly.
- When using a headset in dry environments, static electricity can build up in the headset and cause a small quick static electrical shock. To minimize the risk of electrostatic discharge from the headset avoid using the headset in extremely dry environments or touch a grounded unpainted metal object to discharge static electricity before inserting the headset.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the mobile device, its parts, or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including installed or portable wireless equipment near or in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your mobile device off before boarding an aircraft. The use of wireless mobile devices in aircraft is illegal and may be dangerous to the aircraft's operation. Check with appropriate authorities before using any function of a mobile device while on an aircraft.
- Failure to observe these instructions may lead to the suspension or denial of cell phone services to the offender, or legal action, or both.
- While using your device, leave some lights on in the room and do not hold the screen too close to your eyes.
- Seizures or blackouts can occur when you are exposed to flashing lights while watching videos or playing games for extended periods. If you feel any discomfort, stop using the device immediately.
- Reduce risk of repetitive motion injuries. When you repetitively perform actions, such as pressing keys, drawing characters on a touch screen with your fingers, or playing games, you may experience occasional discomfort in your hands, neck, shoulders, or other parts of your body. When using your device for extended periods, hold the device with a relaxed grip, press the keys lightly, and take frequent breaks. If you continue to have discomfort during or after such use, stop use and see a physician.
- If your device has a camera flash or light, do not use the flash or light close to the eyes of people or pets. [122011]

Section 10: Warranty Information

Standard Limited Warranty

What is covered and for how long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC (“SAMSUNG”) warrants that SAMSUNG’s handsets and accessories (“Products”) are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase by the first consumer purchaser and continuing for the following specified period of time after that date:

Device	1 Year
Battery(ies)*	1 Year
Case/Pouch/Holster*	90 Days
Other Device Accessories*	1 Year

*If applicable.

What is not covered?

This Limited Warranty is conditioned upon proper use of the Product.

This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, dampness, sand or dirt, neglect, or unusual physical, electrical or electromechanical stress; (b) scratches, dents and cosmetic damage, unless caused by SAMSUNG; (c) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (d) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (e) ordinary wear and tear; (f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning, earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source; (i) defects or damage resulting from cellular signal reception

or transmission, or viruses or other software problems introduced into the Product; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery; (ii) any of the seals on the battery are broken or show evidence of tampering; or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's obligations?

During the applicable warranty period, provided the Product is returned in accordance with the terms of this Limited Warranty, SAMSUNG will repair or replace the Product, at SAMSUNG's sole option, without charge. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product, or may replace the Product with a rebuilt, reconditioned or new Product.

Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Products will be warranted for a period equal to the

remainder of the original Limited Warranty on the original Product or for ninety (90) days, whichever is longer. All replaced Products, parts, components, boards and equipment shall become the property of SAMSUNG. Except to any extent expressly allowed by applicable law, transfer or assignment of this Limited Warranty is prohibited.

What must you do to obtain warranty service?

To obtain service under this Limited Warranty, you must return the Product to an authorized phone service facility in an adequate container for shipping, accompanied by the sales receipt or comparable proof of sale showing the original date of purchase, the serial number of the Product and the seller's name and address.

To obtain assistance on where to deliver the Product, please call SAMSUNG Customer Care at 1-888-987-4357. If SAMSUNG determines that any Product is not covered by this Limited Warranty, you must pay all parts, shipping, and labor charges for the repair or return of such Product.

You should keep a separate backup copy of any contents of the Product before delivering the Product to SAMSUNG for warranty service, as some or all of the contents may be deleted or reformatted during the course of warranty service.

What are the limits on SAMSUNG's liability?

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF SAMSUNG'S RESPONSIBILITIES, AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCTS.

ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SAMSUNG BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES; OR DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE

OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Products. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of SAMSUNG regarding the Products or this Limited Warranty.

This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

What is the procedure for resolving disputes?

ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCTS SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY.

Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's Product or claim, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty.

For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant SAMSUNG its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and SAMSUNG shall pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction. This arbitration provision also applies to claims against SAMSUNG's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

You may opt out of this dispute resolution procedure by providing notice to SAMSUNG no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product. To opt out, you must send notice by e-mail to optout@sta.samsung.com, with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the Product was purchased; (c) the Product model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the Product box; (ii) on the Product information screen, which can be found under "Settings;" (iii) on a label on the back of the Product beneath the battery, if the battery is removable; and (iv) on the outside of the Product if the battery is not removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and you will continue to enjoy the benefits of the Limited Warranty.

Severability

If any portion of this Limited Warranty is held to be illegal or unenforceable, such partial illegality or unenforceability shall not affect the enforceability of the remainder of the Limited Warranty.

Precautions for Transfer and Disposal

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the **Samsung Customer Care Center** for details.

Important! Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

Samsung Telecommunications America, LLC
1301 E. Lookout Drive
Richardson, Texas 75082
Phone: 1-800-SAMSUNG
Phone: 1-888-987-HELP (4357)

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice. [111611]

End User License Agreement for Software

IMPORTANT. READ CAREFULLY: This End User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Samsung Electronics Co., Ltd. ("Samsung") for software, owned by Samsung and its affiliated companies and its third party suppliers and licensors, that accompanies this EULA, which includes computer software and may include associated media, printed materials, "online" or electronic documentation in connection with your use of this device ("Software").

This device requires the use of preloaded software in its normal operation. BY USING THE DEVICE OR ITS PRELOADED SOFTWARE, YOU ACCEPT THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THESE TERMS, DO NOT USE THE DEVICE OR THE SOFTWARE.

1. **GRANT OF LICENSE.** Samsung grants you the following rights provided that you comply with all terms and conditions of this EULA: You may install, use, access, display and run one copy of the Software on the local hard disk(s) or other permanent storage media of one computer and use the Software on a single computer or a mobile device at a time, and you may not make the Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the Software in machine readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.

Certain items of the Software may be subject to open source licenses. The open source license provisions may override some of the terms of this EULA. We make the applicable open source licenses available to you on the Legal Notices section of the Settings menu of your device.

2. RESERVATION OF RIGHTS AND OWNERSHIP. Samsung reserves all rights not expressly granted to you in this EULA. The Software is protected by copyright and other intellectual property laws and treaties. Samsung or its suppliers own the title, copyright and other intellectual property rights in the Software. The Software is licensed, not sold.

3. LIMITATIONS ON END USER RIGHTS. You may not reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code or algorithms of, the Software (except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation), or modify, or disable any features of, the Software, or create derivative works based on the Software. You may not rent, lease, lend, sublicense or provide commercial hosting services with the Software.

4. CONSENT TO USE OF DATA. You agree that Samsung and its affiliates may collect and use technical information gathered as part of the product support services related to the Software provided to you, if any, such as IMEI (your device's unique identification number), device number, model name, customer code, access recording, your device's current SW version, MCC (Mobile Country Code), MNC (Mobile Network Code). Samsung and its affiliates may use this information solely to improve their products or to provide customized

services or technologies to you and will not disclose this information in a form that personally identifies you. At all times your information will be treated in accordance with Samsung's Privacy Policy, which can be viewed at: <http://account.samsung.com/membership/pp>.

5. SOFTWARE UPDATES. Samsung may provide to you or make available to you updates, upgrades, supplements and add-on components (if any) of the Software, including bug fixes, service upgrades (parts or whole), products or devices, and updates and enhancements to any software previously installed (including entirely new versions), (collectively "Update") after the date you obtain your initial copy of the Software to improve the Software and ultimately enhance your user experience with your device. This EULA applies to all and any component of the Update that Samsung may provide to you or make available to you after the date you obtain your initial copy of the Software, unless we provide other terms along with such Update. To use Software provided through Update, you must first be licensed for the Software identified by Samsung as eligible for the Update. After the Update, you may no longer use the Software that formed the basis for your Update eligibility. The updated Software version may add new functions and, in some limited cases, may delete existing functions.

While the Update will be generally available, in some limited circumstances, the Software updates will only be offered by your network carrier, and such Software updates will be governed by your contractual relationship with your network carrier.

With the “Automatic Update” function enabled (as in the default setting in the System Update menu in the Setting), your device downloads some Updates automatically from time to time. Your device will, however, ask for your consent before installing any Update. If you choose to disable the “Automatic Update” function, then you can check the availability of new Updates by clicking on the “Check Update” menu in the Setting. We recommend that you check availability of any new Updates periodically for optimal use of your device. If you want to avoid any use of network data for the Update downloads, then you should choose the “Wi-Fi Only” option in the Setting. (Regardless of the option you choose, the “Automatic Update” function downloads Updates only through Wi-Fi connection.)

6. Some features of the Software may require your device to have access to the internet and may be subject to restrictions imposed by your network or internet provider. Unless your device is connected to the internet through Wi-Fi connection, the Software will access through your mobile

network, which may result in additional charges depending on your payment plan. In addition, your enjoyment of some features of the Software may be affected by the suitability and performance of your device hardware or data access.

7. **SOFTWARE TRANSFER.** You may not transfer this EULA or the rights to the Software granted herein to any third party unless it is in connection with the sale of the mobile device which the Software accompanied. In such event, the transfer must include all of the Software (including all component parts, the media and printed materials, any upgrades, this EULA) and you may not retain any copies of the Software. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the Software must agree to all the EULA terms.

8. **EXPORT RESTRICTIONS.** You acknowledge that the Software is subject to export restrictions of various countries. You agree to comply with all applicable international and national laws that apply to the Software, including all the applicable export restriction laws and regulations.

9. **TERMINATION.** This EULA is effective until terminated. Your rights under this License will terminate automatically without notice from Samsung if you fail to comply with any of the

terms and conditions of this EULA. Upon termination of this EULA, you must cease all use of the Software and destroy all copies, full or partial, of the Software.

10. DISCLAIMER OF WARRANTY. UNLESS SEPARATELY STATED IN A WRITTEN EXPRESS LIMITED WARRANTY ACCOMPANYING YOUR DEVICE, ALL SOFTWARE PROVIDED BY SAMSUNG WITH THIS MOBILE DEVICE (WHETHER INCLUDED WITH THE DEVICE, DOWNLOADED, OR OTHERWISE OBTAINED) IS PROVIDED "AS IS" AND ON AN "AS AVAILABLE" BASIS, WITHOUT WARRANTIES OF ANY KIND FROM SAMSUNG, EITHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT POSSIBLE PURSUANT TO APPLICABLE LAW, SAMSUNG DISCLAIMS ALL WARRANTIES EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY OR WORKMANLIKE EFFORT, FITNESS FOR A PARTICULAR PURPOSE, RELIABILITY OR AVAILABILITY, ACCURACY, LACK OF VIRUSES, QUIET ENJOYMENT, NON INFRINGEMENT OF THIRD PARTY RIGHTS OR OTHER VIOLATION OF RIGHTS. SOME JURISDICTIONS DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM

SAMSUNG OR ITS AFFILIATES SHALL BE DEEMED TO ALTER THIS DISCLAIMER BY SAMSUNG OF WARRANTY REGARDING THE SOFTWARE, OR TO CREATE ANY WARRANTY OF ANY SORT FROM SAMSUNG.

11. THIRD-PARTY APPLICATIONS. Certain third party applications may be included with, or downloaded to this mobile device. Samsung makes no representations whatsoever about any of these applications. Since Samsung has no control over such applications, you acknowledge and agree that Samsung is not responsible for the availability of such applications and is not responsible or liable for any content, advertising, products, services, or other materials on or available from such applications. You expressly acknowledge and agree that use of third party applications is at your sole risk and that the entire risk of unsatisfactory quality, performance, accuracy and effort is with you. It is up to you to take precautions to ensure that whatever you select to use is free of such items as viruses, worms, Trojan horses, and other items of a destructive nature. References on this mobile device to any names, marks, products, or services of any third-parties are provided solely as a convenience to you, and do not constitute or imply an endorsement, sponsorship, or recommendation of, or affiliation with the third party or its products and services. You agree that Samsung shall not be

responsible or liable, directly or indirectly, for any damage or loss, including but not limited to any damage to the mobile device or loss of data, caused or alleged to be caused by, or in connection with, use of or reliance on any such third party content, products, or services available on or through any such application. You acknowledge and agree that the use of any third-party application is governed by such third party application provider's Terms of Use, License Agreement, Privacy Policy, or other such agreement and that any information or personal data you provide, whether knowingly or unknowingly, to such third-party application provider, will be subject to such third party application provider's privacy policy, if such a policy exists. SAMSUNG DISCLAIMS ANY RESPONSIBILITY FOR ANY DISCLOSURE OF INFORMATION OR ANY OTHER PRACTICES OF ANY THIRD PARTY APPLICATION PROVIDER. SAMSUNG EXPRESSLY DISCLAIMS ANY WARRANTY REGARDING WHETHER YOUR PERSONAL INFORMATION IS CAPTURED BY ANY THIRD PARTY APPLICATION PROVIDER OR THE USE TO WHICH SUCH PERSONAL INFORMATION MAY BE PUT BY SUCH THIRD PARTY APPLICATION PROVIDER.

12. SAMSUNG APPLICATIONS. Certain Samsung applications and services may be included with, or downloaded to, this mobile device. Many of them require Samsung Services

membership registration ("Samsung Account"), and your rights and obligations will be set forth in separate Samsung Account terms and conditions and privacy policies. There are non-Samsung Account applications and services that require your consent to their separate terms and conditions and privacy policies. You expressly acknowledge and agree that your use of such applications and services will be subject to the applicable terms and conditions and privacy policies.

13. LIMITATION OF LIABILITY. SAMSUNG WILL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND ARISING OUT OF OR RELATING TO THE USE OR THE INABILITY TO USE THE SOFTWARE OR ANY THIRD PARTY APPLICATION, ITS CONTENT OR FUNCTIONALITY, INCLUDING BUT NOT LIMITED TO DAMAGES CAUSED BY OR RELATED TO ERRORS, OMISSIONS, INTERRUPTIONS, DEFECTS, DELAY IN OPERATION OR TRANSMISSION, COMPUTER VIRUS, FAILURE TO CONNECT, NETWORK CHARGES, IN-APP PURCHASES, AND ALL OTHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NOTWITHSTANDING

THE FOREGOING, SAMSUNG ELECTRONIC CO.'S TOTAL LIABILITY TO YOU FOR ALL LOSSES, DAMAGES, CAUSES OF ACTION, INCLUDING BUT NOT LIMITED TO THOSE BASED ON CONTRACT, TORT, OR OTHERWISE, ARISING OUT OF YOUR USE OF THE SOFTWARE OR THIRD PARTY APPLICATIONS ON THIS MOBILE DEVICE, OR ANY OTHER PROVISION OF THIS EULA, SHALL NOT EXCEED THE AMOUNT PURCHASER PAID SPECIFICALLY FOR THIS MOBILE DEVICE OR ANY SUCH THIRD PARTY APPLICATION THAT WAS INCLUDED WITH THIS MOBILE DEVICE. THE FOREGOING LIMITATIONS, EXCLUSIONS, AND DISCLAIMERS (INCLUDING SECTIONS 10, 11, 12 AND 13) SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EVEN IF ANY REMEDY FAILS ITS ESSENTIAL PURPOSE.

14. U.S. GOVERNMENT END USERS RESTRICTED RIGHTS. The Software is licensed only with "restricted rights" and as "commercial items" consisting of "commercial software" and "commercial software documentation" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Products are provided only with "restricted rights" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Software and Products are provided subject to Federal Acquisition Regulation (FAR) 52.227.19.

15. APPLICABLE LAW. This EULA is governed by the laws of the jurisdiction where you are a resident or, if a resident of the United States, by the laws of the state of Texas, without regard to its conflict of law provisions. This EULA shall not be governed by the UN Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded.

16. DISPUTE RESOLUTION.

(a) Non-United States residents. If a dispute, controversy or difference arising in any way from this EULA or your use of the Software is not amicably settled, it shall be subject to the non-exclusive jurisdiction of the courts of the jurisdiction where you are a resident. Notwithstanding the foregoing, Samsung may apply for injunctive remedies (or an equivalent type of urgent legal relief) in any jurisdiction.

(b) United States residents. ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS EULA OR YOUR USE OF THE SOFTWARE SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with any other person's or entity's claim or dispute, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class

action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the EULA and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the EULA. For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant Samsung its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and Samsung shall pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims,

exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction. This arbitration provision also applies to claims against Samsung's employees, representatives and affiliates if any such claim arises from the licensing or use of the Software. You may opt out of this dispute resolution procedure by providing notice to Samsung no later than 30 calendar days from the date of the first consumer purchaser's purchase of this device. To opt out, you must send notice by e-mail to optout@sta.samsung.com, with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the device was purchased; (c) the device model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the device box; (ii) on the device information screen, which can be found under "Settings;" (iii) on a label on the back of the device beneath the battery, if the battery is removable; and (iv) on the outside of the device if the battery is not

removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the device and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect your use of the device or its preloaded Software, and you will continue to enjoy the benefits of this license.

17. ENTIRE AGREEMENT; SEVERABILITY. This EULA is the entire agreement between you and Samsung relating to the Software and supersedes all prior or contemporaneous oral or written communications, proposals and representations with respect to the Software or any other subject matter covered by this EULA. If any provision of this EULA is held to be void, invalid, unenforceable or illegal, the other provisions shall continue in full force and effect. [050113]

A

Accounts

- adding a Corporate account 44
- adding a Facebook account 44
- adding a Google account 44
- setting up 44

Airplane mode 95

Applications

- downloading new 85

Apps

- installing 65
- uninstalling 65

B

Backup Assistant 67

Battery

- charging 8
- cover, removing & installing 7
- indicator 7
- installing 8
- non-supported batteries 6
- removing 8

Battery Use & Safety 138

Bluetooth

- pairing with a device 90
- profiles 98
- settings 99
- turning on or off 90

C

Calculator 67

Calendar 67

Calls

- answering 35
- call-waiting 35
- from Call log 34
- from Contacts 33
- from Favorites 34
- in-call options 35
- recent 36
- rejecting 35
- sending to voice mail 35
- settings 37
- three-way 34
- using S Voice 33

- using the Keypad 32

Camera

- picture options 69
- recording video 71
- taking pictures 68

Care and Maintenance 143

Children and Cell Phones 133

Clock 73

Commercial Mobile Alerting System (CMAS) 137

Contacts

- backing up 51, 67
- Backup Assistant 51
- creating 45
- creating from Call log 46
- creating from the Keypad 46
- exporting and importing 49
- groups 51
- joining 49
- My Profile 48
- namecards 50

- setting a picture as contact icon 75
- speed dials 53
- starred contacts 51
- updating 46
- updating from Call log 46
- updating from Keypad 46
- updating from Recent calls 36

Corporate Email accounts 44

D

Display / Touch-Screen 141

Display settings

- brightness 105
- font style and size 106
- screen timeout 106

Do cell phones pose a health hazard? 129

E

Email

- account settings 61
- combined Inbox 61
- composing and sending 62
- configuring accounts 60
- Corporate accounts 44

167

- refreshing your accounts 61

Emergency Calls 142

Entering Text

- Google voice typing 29, 30
- Samsung keyboard 28

Exchange account 44

Exposure to Radio Frequency (RF)

- Signals** 129

F

Facebook

- adding an account 44

FCC Hearing Aid Compatibility (HAC)

- Regulations for Wireless**

- Devices** 148

FCC Notice and Cautions 151

G

Gallery

- sharing pictures and video 75
- viewing pictures and video 74
- viewing videos 74

Gmail

- composing and sending 63
- configuring your account 62
- managing your account 63

- refreshing your account 63

Google

- Gmail 62
- Local 79
- managing an account 44
- Maps 79
- Navigation 83
- Play Store 85
- setting up an account 44
- Talk 64
- YouTube 87

GPS 142

Groups

- adding contacts 52
- creating 51
- sending a message 53

H

Health and Safety Information 129

Home screen

- adding shortcuts 26
- customizing 20
- folders 27
- primary shortcuts 26
- wallpaper 27

I

- Icons**
 - Status Bar 23
- Internet** 77

M

- Maps** 79
- Memory Card**
 - installing 13
 - unmounting and removing 13
- Memory settings**
 - internal phone storage 107
- Messages**
 - creating and sending 56
 - email 60
 - Gmail 62
 - managing 57
 - settings 57
 - Talk 64
 - types 55
- Mobile networks**
 - settings 100
- Music**
 - creating a playlist 81
 - Music Player 81

- setting a song as a ringtone 82

- Mute all sounds** 102
- My Files** 83
- My Profile** 48
 - sending 48
- My Verizon Mobile** 83

N

- Namecards**
 - sending 50
- Navigation**
 - command keys 26
 - touch gestures 22
- Notification Panel** 22

O

- Operating Environment** 146
- Other Important Safety Information** 151

P

- Pairing with Bluetooth** 90
- Phone settings**
 - date & time 123
 - language 116

- Picture ID**
 - setting 75
- Pictures**
 - setting as wallpaper 75
 - sharing 75
 - taking 68
- Play Store** 85
- Playlists**
 - creating 81
- Powering On and Off** 9

R

- Recent calls** 36
 - creating/updating contacts 36
 - managing 37
 - sending messages 36
- Reducing Exposure**
 - Hands-Free Kits and Other Accessories 132
- Responsible Listening** 144
- Restricting Children's Access to Your Mobile device** 151
- Ringtones**
 - setting a song as a ringtone 82

Roaming 11
settings 100

S

Samsung keyboard
configuring 28
entering text 28

Samsung Mobile Products and Recycling 140

Security

locking and unlocking 13
screen lock 111

Security settings

credential storage 115

Settings 94

Setup Wizard 10, 86

Smart Practices While Driving 137

Sound settings

mute 102

Specific Absorption Rate (SAR) Certification Information 134

Speed Dials

assigning 53
removing or reassigning 54

Standard Limited Warranty 153

Storage

settings 107

Synchronization settings

background data 122

T

Task Manager 12

Text

entering 28

Text settings

default 116
Google voice typing 117
Samsung keyboard 117

TTY Mode 11

Turning Your Phone On and Off 9

U

UL Certified Travel Charger 141

V

Video

options 72

Videos

recording 71
sharing 75

Voicemail

checking 63
setting up 63

Volume

key 17

VPN

adding 91
settings 100

W

Wallpaper

setting 75

Warranty Information 153

Wi-Fi

adding a connection manually 89
scanning and connecting 89
settings 95
turning on or off 88

Wireless Networking

Bluetooth 90
VPN 91
Wi-Fi 88

Y

YouTube 87