


3 SCHLAGE LiNK™ System Setup



The lock should already be installed on your door. If not, use the installation instructions (document number ②) to install the lock and then come back to this document.



OR

Important Information

Lock Programming Code

six (6) digits

Bridge MAC ID


twelve (12) characters

Web Support: testmydoorlock.com

Customer Service: (877) 288-7707


1 Locate the programming code, on top of document ②. Write the programming code in the “Important Information” box at the top of this page.

- The programming code is six digits long and is located on the yellow sticker on the installation sheet that is packed in the box.
- The programming code can be changed. If you have changed your programming code, the code that is printed on the label will not work. (See Manual Programming and Troubleshooting at testmydoorlock.com.)
- If you don't remember your programming code, you can reset your lock, which will restore the original programming code. (See Manual Programming and Troubleshooting at testmydoorlock.com.)




2 Locate the bridge MAC ID. Write the MAC ID in the “Important Information” box at the top of this page.

- The MAC ID is 12 characters long and is located on the yellow label inside the battery compartment of the bridge.




3 Install the light module.

- The light module also repeats the Z-Wave signal. If the final location of the bridge (where it can be connected to your router) is more than 60 feet (18 meters) from the lock, use an outlet that is approximately half way between the lock and the bridge.
- The light module should be installed into any indoor, three-prong, 120 volt A/C outlet.




4 Plug a lamp into the Z-Wave side of the light module.

- There are two outlets on the light module. One of the outlets has only two prongs and is labelled with a Z-Wave sticker. A lamp (25 watts minimum and 300 watts maximum) must be plugged in to the Z-Wave side of the light module for proper operation.
- Use only an incandescent light bulb in the lamp that is plugged into the light module. DO NOT use a CFL (compact fluorescent light bulb).
- The other outlet has three prongs and can be used simply as an outlet (1500 watts maximum). It is not controlled by the system, and the system is not affected when it is used.




5 Install the 9 volt battery into the bridge.

- Use the 9 volt battery that is included in the box.
- Use any premium quality 9 volt battery for replacement.



6 Enroll the light module into the bridge.

- Hold the bridge within 6 feet (1.8 meters) of the light module throughout all of step 6.
- Press and release the plus (+) button on the bridge.
- Double-click the button on the light module.
- Observe the lights on bridge. The orange light will blink while enrollment is taking place. Enrollment is complete when the orange light becomes solid.



7 Enroll the lock into the bridge.

- Hold the bridge within 6 feet (1.8 meters) of the lock throughout all of step 7.
- Press and release the plus (+) button on the bridge. **You have 30 (thirty) seconds to complete the remainder of the steps.**
- On the lock keypad, press the six-digit programming code (located in the "Important Information" box).
- Wait for the lock to beep three times and the Schlage button on the lock to flash orange three times.
- On the lock keypad, press the Schlage button and then the 0 (zero) button. The lock will begin to beep.
- On the lock keypad, observe the Schlage button. If the Schlage button flashes green, enrollment was successful. If the Schlage button flashes red, enrollment was unsuccessful and you should start over at step 7a.
 - If enrollment is unsuccessful multiple times, call customer service (877-288-7707).
- Observe the lights on bridge. The orange light will blink while enrollment is taking place. Enrollment is complete when the orange light becomes solid.



This portion of the setup is complete. For the next portion, please ensure that you have one of the following browsers installed on your computer:

- Internet Explorer 7.0 (<http://www.microsoft.com/windows/downloads/ie/getitnow.msp>)
- Firefox 3.0 (<http://www.mozilla.com>)

For troubleshooting, see testmydoorlock.com.

4 Using either Internet Explorer 7.0 or Firefox 3.0, browse to www.schlagelink.com and follow the on-screen instructions.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: P2GBE369
FCC ID: P2GFE369
FCC ID: P2GBR100

PATENT NOTICE

Schlage® products and those of its subsidiary companies and licensees may be covered by both issued and pending U.S. and foreign patents, copyrights and trademarks. Manufactured items are covered by one or more of the following patents:

5070715	5765412	6523375	D372417	D458829
5152558	5769472	6533336	D372854	D467155
5308131	5809816	6540274	D406056	D472788
5395144	5816086	6581426	D406528	D487388
5593193	5820290	6802546	D426452	D520331
5598726	5881590	6905773	D428324	D520332
5640863	5918916	6926319	D450558	D537702
5683127	6286347	7143477	D457048	D541620
5715717	6297725	7159424	D457049	D543435

Lifetime Limited Mechanical and Finish Warranty and 1-Year Limited Electronics Warranty

Subject to the terms and conditions of this warranty, Schlage extends a lifetime limited mechanical and finish warranty and a one-year limited electronics warranty to the original consumer user ("Original User") of our Schlage brand product ("Product") against defects in material and workmanship, as long as the Original User occupies the residential premises upon which the Product was originally installed.

What Schlage will do: Upon return of the defective Product to Schlage, Schlage's sole obligation, at its option, is to either repair or replace the Product, or refund the original purchase price in exchange for the Product.

Original User: This warranty only applies to the Original User of Products. This warranty is not transferable.

What is not covered: The following costs, expenses and damages are not covered by the provisions of this limited warranty: (i) labor costs including, but not limited to, such costs as the removal and reinstallation of Product; (ii) shipping and freight expenses required to return Product to Schlage; (iii) failures, defects, or damage (including, but not limited to, any security failure or loss of data) caused by any third party product, service, or system connected or used in conjunction with the Product; and (iv) any other incidental, consequential, indirect, special and/or punitive damages, whether based on contract, warranty, tort (including, but not limited to, strict liability or negligence), patent infringement, or otherwise, even if advised of the possibility of such damages. Some local laws do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

The provisions of this warranty do not apply to Products: (i) used in commercial applications; (ii) used in common area applications; (iii) used for purposes for which they are not designed or intended; (iv) which have been subjected to alteration, abuse, misuse, negligence or accident; (v) which have been improperly stored, installed, maintained or operated; (vi) which have been used in violation of written instructions provided by Schlage; (vii) which have been subjected to improper temperature, humidity or other environmental conditions; or (viii) which, based on Schlage's examination, do not disclose to Schlage's satisfaction non-conformance to the warranty. Additionally, this warranty DOES NOT COVER scratches, abrasions, or deterioration due to the use of paints, solvents or other chemicals.

Exclusions: Oil Rubbed Bronze finish (613) is designed to improve over time and change in appearance, creating a living finish through daily use and thus, finish discoloration is not applicable to the above warranty.

Additional terms: Schlage does not authorize any person to create for it any obligation or liability in connection with the Product. Schlage's maximum liability hereunder is limited to the original purchase price of

the Product. No action arising out of any claimed breach of this warranty by Schlage may be brought by the Original User more than one (1) year after the cause of action has arisen.

How local law applies: This warranty gives you specific legal rights, and you may also have other rights as otherwise permitted by law. If this Product is considered a consumer product, please be advised that some local laws do not allow limitations on incidental or consequential damages or how long an implied warranty lasts, so that the above limitations may not fully apply. Refer to your local laws for your specific rights under this warranty.

Guaranteed Fit Program: Schlage products are designed to fit standard residential door preparations and retrofit existing tubular locks. Note: Mortise locks and preparations are not considered standard and are not guaranteed under this program. During the initial installation, if there is a problem with the Product's performance, the Original User may simply contact Schlage Customer Service at 888-805-9837 in the U.S. and Canada or 800-506-7866 in Mexico for assistance.

Program and warranty claims: If you encounter a residential door preparation or fit issue under the Guaranteed Fit Program or have a claim under this warranty, please contact Schlage Customer Service for repair, replacement or refund of the original purchase price in exchange for the return of the Product to Schlage



Security Technologies

©2008 Schlage Lock Company
link system setup Rev. 10/08-7