Sensoro SmartBeacon-4AA Pro

Outlook

The Sensoro SmartBeacon-4AA Pro is built for commercial deployment and is specially suited to outdoor situations because its protection against various environmental conditions.



Ingress Protection Criterion

The Sensoro SmartBeacon-4AA Pro achieves a professional -grade waterproof and dustproof rating of IP67. The IP67 rating guarantees total protection from dust and from submersion in between 15cm to 1m of water despite featuring an external power button and screwless design.



IP is an abbreviation of International Protection Marking, sometimes called Ingress Protection. The IP rating for electrical equipment enclosure classifies and rates the degree of protection against intrusion by dust, accidental contact, and water. The rating classification is published by the International Electrotechnical Commission (IEC) standard IEC 60529, the standard adopted in 2004 by the American National Standards Institute. The IP rating format for enclosure and protection of electrical equipment is IPXX, where XX is the two digits, the first digit representing the contact protection level against external particles, and the second digit representing the waterproofing protection level.

The Sensoro SmartBeacon-4AA Pro's rating of IP67 guaranteest, no ingress of dus complete protection against contact, and protection while submerged in up to 1 meter of water.

Features

1. Ultra-Low Power

A Bluetooth® 4.0 (Bluetooth® low energy) Nordic NFR51822 chip with ultra-low power consumption is used.

Bluetooth low energy with intelligent energy-saving programs allows the beacon to work for three to five years on four AA batteries.

2. Compatibility

Software and firmware are fully compatible with Apple's iBeacon and Google's Eddystone (include EID) technical requirements, and can be applied to systems including:

iOS 7.0 or above:

iPhone 4S, iPhone 5, iPhone 5S, iPad 3, iPad mini, iPad air.

Android 4.3 or above:

Samsung Galaxy S III, Galaxy S IV, Galaxy Note II, Galaxy Note III and Motorola RAZR, HTC ONE, etc.

3. Demo App and Configuration App

The "Yunzi" (demo) app allows you to experience our beacons, while the "Sensoro" app (configuration tools) puts you in control of all of their features.

Scan the QR code to download:



Signal Stability and Data Transmission

1. Transmission Stability and Distance

To achieve signal stability and long-distance data transmission requirements, the Sensoro SmartBeacon-4AA Pro underwent extensive testing and modification. Its signal remains stable even in complex deployment locations. Radius frequency (RF) power demand configuration can be adjusted to a maximum radius of 80 meters. The RF power demand configuration can reduce its radius to a minimum of 0.15 meters, which covers an area of 0.225 square meters. However, it is possible that no signal will be obtained if the

RF power is adjusted to a minimum.

2. Enterprise Class Device Management Support for Enterprises

Mass management of device status is an essential component of our enterprise class cloud software solutions. Our patented beacon devices can be deployed to collect bulk data, and using the Sensoro cloud, your organization has the essential tools needed to seamlessly manage large-scale deployments. Centralized management on your phone or computer is made easy by enterprise class software solutions.

Specifications

| Property | Specifications | | | |
|--------------------------|-----------------------------|--|--|--|
| Chip | Nordic | | | |
| Dimensions | 72.69mm x 70.00mm x | | | |
| | 29.76mm (Including the wall | | | |
| | mount kit) | | | |
| Weight | 92g | | | |
| Material | Polycarbonate | | | |
| Three-Layered Protection | Water/Dust/Shock Proof | | | |

| IP Level | IP67 | | | |
|----------------------------|---------------------------------|--|--|--|
| Protocol Standards | Bluetooth 4.0 iBeacon and | | | |
| | Eddystone Authorization | | | |
| Compatible Systems | iOS 7.0 or above, Android 4.3 | | | |
| | or above | | | |
| Upgrades | Supports wireless upgrades | | | |
| Security | Supports password access | | | |
| Sensors | Temperature | | | |
| LED | 1 LED light bulb | | | |
| Emission Strength | -30dBm to +4dBm(Can be | | | |
| | adjusted to optimize signal | | | |
| | strength) | | | |
| Transmission Distance | 0.15~80m | | | |
| Radio Frequency | Adjustable (100 | | | |
| (Transmission Broadcast | milliseconds~1.285 seconds) | | | |
| Interval) | | | | |
| Broadcast Time Electricity | 7.58 * 10 -6 mAh (-8dB | | | |
| Consumption | Emission Power) | | | |
| Supply Voltage | 3.0V | | | |
| Battery | No. 5 battery (4 batteries, not | | | |
| | included) | | | |
| Operation Life | 2-5 years | | | |

Sensoro App's Configuration Tools

The Sensoro app is available for developers to check on and configure the parameters of all nearby Sensoro beacons. The Sensoro app is compatible with iOS 7.0 or above (iPhone 4S, iPhone 5, iPhone 5S, iPad 3, iPad mini, iPad air) and Android 4.3 or above (Samsung Galaxy S III, Galaxy S IV, Galaxy Note II, Galaxy Note III and Motorola RAZR, HTC ONE, etc.). Using the Sensoro app, you can deploy beacons one at a time, and then view all nearby beacons if you want to make changes. If you would like to deploy and configure beacons in bulk, please use the "Deploy" app.

Open the Sensoro app, and the Device List of all nearby beacons will appear. The information for each beacon includes Major, Minor, as well as other basic information including an animated display of the RSSI strength.



All nearby Sensoro beacons will be listed by order of when the app detected their presence. By changing the Major, Minor values, we can differentiate beacons. Since Major, Minor consists of two values, we recommend grouping associated beacons using the Major value, and labeling individual beacons using the Minor value. For example, beacons at a museum might all have the 00FF code for Major, and each individual beacon placed at different locations throughout the museum would have a unique Minor code. If you would like to view the tags of all devices in range, please log into the Sensoro Cloud on the Inspection app.

The Device Detail page displays the real-time details of each of the beacon's sensors, battery life, and RSSI signal. Touch the device box on the Device List to enter the Device Detail page.

You can also locate an individual beacon on the Device List by scanning the device's QR code. Touch the scanning icon on the top right of the device list. Once the device is scanned, it will take you to the Device Detail page.



Swipe left on the top of the Device Detail page to bring up the realtime RSSI line display graph. This more detailed RSSI graph allows developers to accurately understand the signal changes in the device, as show below.



Swipe left again to view whether the device being viewed is using iBeacon or Eddystone protocol.



The Sensoro app supports setup of beacon's basic information (including UUID, Major and Minor) as well as the modification of device transmitting power, radio frequency, and other parameters.

For Google Eddystone, UID, URL, TLM and EID are fully supported by Sensoro app now. Moreover, you can also use this app to ONE-wayswitch the beacon mode into the standard Eddystone Configuration GATT service.

*Notice:

1. Currently setting up the EID is only available on Android (download link: http://www.sensoro.com/en/download/), which needs a full installation of Google-Play-Service and Google Service Framework, and Nexus 5/6 are recommended.

2. We also have another "Full Eddystone GATT" special version firmware available, which was built to work with Google's Beacon Tool App. Please contact our sales team (seattle@sensoro.com) if you'd like to order this special version.

3. Currently switching to the standard Eddystone Configuration GATT service is a ONE way feature, and a third-party tool is needed when switching back to Sensoro Configuration service. Manual for Mode Switch download link:

http://www.sensoro.com/static/Manual_for_Mode_Switch.pdf

| | ę | 20:44 | • * | ••••• | (îr | 20:44 | ● ≯ | |
|--------|-------|-----------|------------|---------|------------|------------|------------|-----|
| Cancel | | Settings | Sav | e Cance | el | Settings | S | av |
| iBeaco | n | | | Eddys | stone | | | |
| iBeac | on | | Enabled > | UID | | | Disabled | |
| UUID | 23A01 | AF0-232A- | 4518-9 > | URL | | | Disablec | |
| Major | | | 0x387D > | TLM | | | Disablec | |
| Minor | | | 0x68D7 > | NID | 5DC3 | 3487F02E | 477D4058 | } |
| Eddyst | one | | | BID | | 0117 | C59B3C19 | |
| UID | | | Disabled > | URL | http | ://www.ser | nsoro.com, | |
| URL | | | Disabled > | TLM | Interval | Or | ne per One | ž į |
| TLM | | | Disabled > | Swite | ch to ed | dystlly sı | upport mo | de |
| NID | 5DC33 | 3487F02E4 | 77D4058 > | Broad | lcast | | | |
| BID | | 0117C | 59B3C19 > | Tran | smit Pov | wer | Level 8 | } |
| | http: | | | Adve | ertisina l | nterval | 417.5 ms | 5 |



Security

The device is made secure by a hardware level password, used also by the US military, which prevents unauthorized modification of Sensoro SmartBeacon-4AA Pro parameters. Sensoro SmartBeacon-4AA Pro allows you to enjoy rich functionality and stability without security concerns.

Quality Assurance

Having passed FCC (FCC certification number: 2ADYO-S0002D), CE, and MIC certification, each device has rigorously undergone factory defect, spectrum, power, and stability testing.



Customer Service

Tell : +86 010-8416 1077 Email : seattle@sensoro.com

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator &you body.