

総合お問い合わせ先<ドコモ インフォメーションセンター>

■ドコモの携帯電話からの場合 ■一般電話などからの場合

 (局番なしの) **151** (無料)  **0120-800-000**

※一般電話などからはご利用いただけません。※一部のIP電話からは接続できない場合があります。

受付時間 午前9:00～午後8:00 (年中無休)

●番号をよくご確認の上、お間違いないようにおかけください。
●各種手続き、故障・アフターサービスについては、上記お問い合わせ先にご連絡いただくか、ドコモホームページ、iモードサイトにてお近くのドコモショップなどにお問い合わせください。
ドコモホームページ <http://www.nttdocomo.co.jp/>

海外での紛失、盗難、精算などについて <ドコモ インフォメーションセンター> (24時間受付)

ドコモの携帯電話からの場合

滞在国の国際電話
アクセス番号 **-81-3-6832-6600*** (無料)

*一般電話などでかけた場合には、日本向け通話料がかかります。
※SH-09Bからご利用の場合は、+81-3-6832-6600でつながります。
(「+」は「0」ボタンを1秒以上押します。)

一般電話などからの場合

<ユニバーサルナンバー>

ユニバーサルナンバー用
国際識別番号 **-8000120-0151***

*滞在国内通話料などがかかる場合があります。
※主要国の国際電話アクセス番号/ユニバーサルナンバー用国際識別番号については、ドコモの「国際サービスホームページ」をご覧ください。

- 紛失・盗難などにあわれたら、速やかに利用中断手続きをお取りください。
- お客様が購入されたFOMA端末に故障が発生した場合は、ご帰国後にドコモ指定の故障取扱窓口へご持参ください。



マナーもいっしょに携帯しましょう。

◎公共の場所で携帯電話をご利用の際は、周囲の方への心くばりを忘れずに。

故障お問い合わせ先

■ドコモの携帯電話からの場合 ■一般電話などからの場合

 (局番なしの) **113** (無料)  **0120-800-000**

※一般電話などからはご利用いただけません。※一部のIP電話からは接続できない場合があります。

受付時間 24時間 (年中無休)

iモードサイト i Menu ▶お客様サポート ▶ドコモショップ

海外での故障について <ネットワークオペレーションセンター> (24時間受付)

ドコモの携帯電話からの場合

滞在国の国際電話
アクセス番号 **-81-3-6718-1414*** (無料)

*一般電話などでかけた場合には、日本向け通話料がかかります。
※SH-09Bからご利用の場合は、+81-3-6718-1414でつながります。
(「+」は「0」ボタンを1秒以上押します。)

一般電話などからの場合

<ユニバーサルナンバー>

ユニバーサルナンバー用
国際識別番号 **-8005931-8600***

*滞在国内通話料などがかかる場合があります。
※主要国の国際電話アクセス番号/ユニバーサルナンバー用国際識別番号については、ドコモの「国際サービスホームページ」をご覧ください。

販売元 株式会社NTTドコモ

製造元 シャープ株式会社

‘10.5(評価完了版)
TINSJA710AFZZ
10E MS108①



環境保全のため、不要になった電池は
NTTドコモまたは代理店、リサイクル
協力店などにお持ちください。



大豆油インキを使用しています。

再生紙を使用しています

NTT
docomo

SH-09B

取扱説明書 '10.5

docomo SMART series



指示

FOMA端末をアダプタに接続した状態で長時間連続使用される場合には特にご注意ください。

充電しながら i アプリやテレビ電話、ワンセグ視聴などを長時間行うとFOMA端末や電池パック・アダプタの温度が高くなる場合があります。温度の高い部分に直接長時間触れるとお客様の体質や体調によっては肌に赤みやかゆみ、かぶれなどが生じたり、低温やけどの原因となる恐れがあります。

FOMA端末の取り扱いについて



警告



禁止

赤外線ポートを目に向けて送信しないでください。

目に悪影響を及ぼす原因となります。



禁止

赤外線通信使用時に、赤外線ポートを赤外線装置のついた家電製品などに向けて操作しないでください。

赤外線装置の誤動作により、事故の原因となります。



禁止

ピクチャーライトの発光部を人の目に近づけて点灯発光させないでください。

視力障害の原因となります。また、目がくらんだり驚いたりしてけがなどの事故の原因となります。

注意事項：

当製品に使用されているピクチャーライト 光源LEDは、指定されていない調整などの操作を意図的に行った場合、眼の安全性を超える光量を放出する可能性がありますので分解しないでください。

EN60825-1:1994 A1:2002 & A2:2001



ピクチャーライト



禁止

FOMA端末内のFOMAカードやmicroSDカード挿入口に水などの液体や金属片、燃えやすいものなどの異物を入れないでください。

火災、やけど、けが、感電の原因となります。



禁止

自動車などの運転者に向けてライトを点灯しないでください。

運転の妨げとなり、事故の原因となります。



指示

航空機内や病院など、使用を禁止された区域では、FOMA端末の電源を切ってください。

電子機器や医用電気機器に悪影響を及ぼす原因となります。また、自動的に電源が入る機能を設定している場合は、設定を解除してから電源を切ってください。

医療機関内における使用については各医療機関の指示に従ってください。

また、航空機内での使用などの禁止行為をした場合、法令により罰せられます。



指示

ハンズフリーに設定して通話する際や、着信音が鳴っているときなどは、必ずFOMA端末を耳から離してください。

また、イヤホンマイクをFOMA端末に装着し、ゲームや音楽再生をする場合は、適度なボリュームに調節してください。

音量が大きすぎると難聴の原因となります。また、周囲の音が聞こえにくいと、事故の原因となります。

Earphone Signal Level

The maximum output voltage for the music player function, measured in accordance with EN 50332-2, is 46.0 mV.



指示

心臓の弱い方は、着信バイブレータ(振動)や着信音量の設定に注意してください。

心臓に悪影響を及ぼす原因となります。

Quick Manual

CAUTION

Use only the battery packs and adapters specified by NTT DOCOMO for use with the FOMA terminal.

May cause fires, burns, bodily injury or electric shock.

Do not throw the battery pack into a fire.

The battery pack may catch fire, explode, overheat or leak.

Do not dispose of used battery packs in ordinary garbage.

May cause fires or damage to the environment. Place tape over the terminals to insulate unnecessary battery packs, and take them to a docomo Shop, retailer or institution that handles used batteries in your area.

Avoid using the handset in extremely high or low temperatures.


Use the FOMA terminal within the range of a temperature between 5°C and 35°C and a humidity between 45% and 85%.

Charge battery in areas where ambient temperature is between 5°C and 35°C.


Do not point the illuminated light directly at someone's eyes.

Do not use Picture Light near people's faces. Eyesight may be temporarily affected leading to accidents.

EN60825-1:1994 A1:2002 & A2:2001



Picture Light



CAUTION:

Use of controls, adjustments or performance of procedure other than those specified herein may result in hazardous radiation exposure. As the emission level from Picture Light LED used in this product is harmful to the eyes, do not attempt to disassemble the cabinet. Servicing is limited to qualified servicing station only.


Picture light source LED characteristics

- a) Continuous illumination
- b) Wavelength
White: 400-700nm
- c) Maximum output
White: 215 μ W (inside FOMA terminal 0.62mW)



Before Use

Inserting UIM (FOMA card) and battery pack


- 1 Push the back cover in the direction of the arrow (1), slide approximately 3 mm (2) and remove the back cover (3)




- 2 Pull out the tray straight (1). Set the UIM on the tray with the IC (gold) side turned up (2) and push the tray all the way in (3)



- 3 Turn a recycle mark side up, match tabs and attach the battery pack



- 4 Place the back cover to the FOMA terminal slot with the back cover open approximately 3 mm, push it (1) and slide it to the direction of arrow to insert (2)




- Perform with the FOMA terminal turned off and closed while holding with your both hands. Note that excessive force may damage the FOMA terminal, UIM and battery pack.

- Securely close the back cover. If not closed securely, the back cover may come off and the battery pack may fall out due to vibration.




Charging

- 1 Insert the AC adapter into the connector terminal of the desktop holder
- 2 Insert the AC adapter power plug into an outlet
- 3 Place the FOMA terminal in the desktop holder in the direction of the arrow until it clicks (1)
 - Charge start sound is heard, charging LED illuminates, and charging starts.



- 4 Hold the desktop holder and lift the FOMA terminal out when charging is complete
 - Charge end sound is heard and charging LED turns off when charging is complete.

- Pull the AC adapter out of the outlet when left unused for a long period of time.
- When charge start sound is not heard or when charging LED does not illuminate, check that the FOMA terminal is placed securely in the desktop holder (except when terminal is turned off, manner mode is set or charge start sound is silent).
- When placing the FOMA terminal in the desktop holder, be careful not to catch a strap, etc.




- 1 Earpiece
- 2 Display
- 3 : i-mode/Operation guidance key
- 4 : Mail/Operation guidance key
- 5 : Start/Hands-free key
- 6 and : Dial/Character entry keys
- 7 : Multi/Quick search/VeilView key
- 8 Mouthpiece/Microphone
- 9 Infrared port
- 10 Brightness sensor
- 11 : Multi-guide key
- 12 : Camera/TV/Operation guidance key
- 13 : Phonebook/Operation guidance key
- 14 : i-Channel/Clear key
- 15 : Power/End key
- 16 : Dictionary key
- 17 Charger terminal
- 18 FOMA antenna
- 19 1Seg antenna
- 20 Called/Charging LED
- 21 External connector terminal
- 22 : mark
- 23 Camera
- 24 Strap hole
- 25 Picture Light
- 26 Speaker
- 27 microSD Card slot
- 28 Back cover

その他

● Key illustrations are examples and may look different from actual keys.

Viewing Display/Icon



Icon display area

Main icons

	Signal status (Strong → Weak) ● When appears, the handset is outside the service area or in a place with no signal.
	Battery level (High → Low)
	i-mode/Full Browser
	i-appli
	Ir communication
	i-mode mail/SMS/Area Mail received
	microSD Card
	1Seg being recorded
	Record message
	Silent
	Vibrator
	Manner mode
	Public mode (Drive mode)
	IC card lock
	Restriction

	Hands-free
	Alarm
	Music&Video Channel program reservation
	UIM error
	Self mode
	VeilView
	3G/GSM
	ToruCa
	Information received

Basic Operations

Turning power on/off

- Turning power on
- 1 (for at least 2 seconds)
- Turning power off
- 1 (for at least 2 seconds)

Changing screen display to English

- 1 [設定] ▶ [一般設定] ▶ [Bilingual] ▶ [English]

Making initial setting

The initial setting screen automatically appears when the power is turned on for the first time. Make the initial setting according to instructions on the screen.

- ※ Terminal security code (four to eight digits) is set to [0000] by default but can be changed by user.

Checking your own phone number

1 Custom [O]

Character entry

※ Operate in the character entry screen.

■ Switching entry modes

1 [] ▶ select the entry mode with [] ▶ []

■ Switching upper/lower case

1 Enter a character ▶ []

■ Deleting characters

1 Move the cursor to the character and [CLR]

- To delete all characters: At the end of the message, [CLR] (for at least 1 second)

■ Using phrases

1 [] (for at least 1 second) ▶ select a phrase ▶ [] ▶ confirm the phrase ▶ []

■ Entering pictograms/symbols

1 []

- To switch between pictogram and Deco-mail pictogram: []
- To switch between single- and double-byte symbols: []

2 Select a pictogram/symbol ▶ []

■ Entering emoticons

1 [] (for at least 1 second) ▶ select an emoticon ▶ []

■ Character entry example

Ex.) When entering “電話”

- 1 [] ▶ [あ] with []
- 2 [4] (four times) ▶ [] (once) ▶ [] (three times) ▶ [] ▶ [] (once)
- 3 [] ▶ to move the cursor to the conversion candidates field
- 4 Select “電話” ▶ []

Changing ring tone

1 Custom [Settings] ▶ [Snd/Vibrator/Manner] ▶ [Select sound]

2 Select an item ▶ []

3 Select a ring tone ▶ []

Lock/Security

Changing terminal security code

- 1 Custom [Settings] ▶ [Security] ▶ [Change security code] ▶ enter the current terminal security code ▶ []
- 2 Enter the new terminal security code ▶ [] ▶ enter the new terminal security code again ▶ []

Changing network security code

- 1 Stand-by [] ▶ [お客様サポート] ▶ [各種設定 (確認・変更・利用)] ▶ [ネットワーク暗証番号変更]

Changing i-mode password

- 1 Stand-by [] ▶ [English] ▶ [Options] ▶ [Change i-mode Password]

Changing PIN1/PIN2 code

- 1 Custom [Settings] ▶ [Security] ▶ [UIM Settings] ▶ enter the terminal security code ▶ []
- 2 Select the PIN1 or PIN2 code ▶ []
- 3 Enter the current PIN code ▶ []
- 4 Enter the new PIN code ▶ [] ▶ enter the new PIN code again ▶ []

Various lock functions

- All lock
- 1 Custom [Settings] ▶ [Security] ▶ [Lock settings] ▶ enter the terminal security code ▶ [] ▶ [All lock] ▶ [Yes]
- Keypad dial lock
- 1 Custom [Settings] ▶ [Security] ▶ [Lock settings] ▶ enter the terminal security code ▶ [] ▶ [Keypad dial lock] ▶ select the setting ▶ []
- Function lock
- 1 Custom [Settings] ▶ [Security] ▶ [Lock settings] ▶ enter the terminal security code ▶ [] ▶ [Function lock] ▶ select an item to lock ▶ [] ▶ []
- Self mode
- 1 Custom [Settings] ▶ [Phone settings] ▶ [Self mode] ▶ select the setting ▶ [] ▶ [Yes]
- Multi lock
- 1 Stand-by [] (for at least 1 second) ▶ [Multi lock] ▶ [Yes]

■ IC card lock

1 **Stand-by** (for at least 1 second) **>** [IC card lock] **>** [Yes]

■ Omakase Lock

Omakase Lock is a service to lock the personal data and IC card functions in case of loss, etc. by only your request to DOCOMO via phone.

- This is a paid service. Refer to "Mobile Phone User's Guide [i-mode] FOMA version" for details on Omakase Lock.

Set/Release Omakase Lock

0120-524-360 **Office hours: 24 hours (in Japanese only) (open all year round)**

※ Unavailable from part of IP phones.

※ Omakase Lock can also be set/released from the My docomo website using PCs.

Incoming call restriction

■ Rejecting a call with no caller ID

1 **Custom** [Settings] **>** [Security] **>** [Accept/Reject calls] **>** enter the terminal security code **>**

2 Select the reason **>**

3 Select the setting **>**

■ Rejecting a call from a caller unset in phonebook

1 **Custom** [Settings] **>** [Security] **>** [Accept/Reject calls] **>** enter the terminal security code **>** **>** [Reject unknown]

2 Select the setting **>**

Voice/Videophone Calls

Making a voice/videophone call

1 **Stand-by** **>** enter a phone number

2 (Phone)/ (V.phone)

3 to end the call

Receiving a voice/videophone call

1 When a call is received, the ring tone sounds and the called LED flashes

2

3 to end the call

Making a call with redials/received calls

1 **Stand-by** (Redial)/ (Received calls)

2 Select a phone number **>**

3 (Phone)/ (V.phone)

Overseas use

■ Making a call outside your country of stay (including Japan)

1 **Stand-by** (for at least 1 second) **>** enter the country code, area code (city code) and other party's phone number **>** (Phone)/ (V.phone)

- When the area code (city code) begins with "0", omit the "0" when dialing (Include "0" when making a call to some countries or regions such as Italy).

■ Making a call in your country of stay

1 **Stand-by** **>** enter a phone number

2 (Phone)/ (V.phone)

■ Making a call to a WORLD WING subscriber overseas

Even when making a call to the phone in your country of stay, make an international call to Japan if the call recipient is a WORLD WING subscriber overseas.

1 **Stand-by** (for at least 1 second) **>** enter "81" **>** enter the other party's mobile phone number excluding the first "0" **>** (Phone)/ (V.phone)

Mail

Composing and sending i-mode mail

- 1 **Stand-by** [Compose message] select the [To] field [Direct input]^{*1} enter an address
- 2 Select the [Sub] field enter a subject [Message] enter messages
^{*1} To select a recipient from a phonebook, select [Search phonebook].
^{*2} To attach a file, select the attachment field select the file to attach.

Checking new i-mode mail

- 1 **Stand-by** [Check new messages]

Replying to i-mode mail

- 1 In the received mail details screen, [Reply/Forward]
- 2 Select the reply method
- 3 Compose and send a mail

Forwarding i-mode mail

- 1 In the received mail details screen, [Reply/Forward] [Forward]
- 2 Enter an address and send a mail

Displaying a mail in Inbox/Outbox/Unsent messages

- 1 **Stand-by** [Inbox/Outbox/Unsent messages]
 - 2 Select the mailbox
 - 3 Select a mail
- ※ [New] appears in the stand-by display when a mail is received.

Phonebook

Adding entries to phonebook

- 1 **Stand-by** [New] [Phone]
 - 2 Enter a name [Phone] enter a phone number select a phone type icon [Mail] enter a mail address select a mail address type icon
- ※ Other items can be saved as well.

Camera

Shooting still pictures

- 1 **Custom** [Camera] [Shoot still pic]

Shooting moving pictures

- 1 **Custom** [Camera] [Shoot movie] [Save]

Displaying still pictures

- 1 **Custom** [Data box] [My picture] select a still picture

Playing moving pictures

- 1 **Custom** [Data box] [i-motion/Movie] select a moving picture

Watching 1Seg

Performing automatic channel setting

- 1 **Custom** [1Seg] [Channel setting]
- 2 Select the number to save [Auto channel set] [Yes]
- 3 Select an area select a prefecture/district [Yes]

Selecting a channel list

- 1 **Custom** [1Seg] [Channel setting] select a channel list

Watching 1Seg

- 1 **Custom** [1Seg] [Activate 1Seg]
 - To record a video of 1Seg programs: While watching 1Seg, [Record] (for at least 1 second) [Record]
 - To record 1Seg programs as a still picture: While watching 1Seg, [Still]

Watching Videos

- 1 **Custom** [Data box] [1Seg]
- 2 [Video] folder select a video

Music Playback

The Music&Video Channel service is provided in Japanese.

Using Music&Video Channel

1 **Custom** [MUSIC] ▶ [Music&Video ch] ▶ select a program ▶

Using MUSIC Player

1 **Custom** [Data box] ▶ [MUSIC] ▶ select music data ▶

Network Services

Setting Voice Mail Service

Voice Mail Service is a paid option (monthly fees apply) that requires subscription.

1 **Custom** [Settings] ▶ [NW Services] ▶ [Voice Mail]
2 [Activate VoiceMail] ▶ [Activate VoiceMail] ▶ [Yes]

Setting Call waiting service

Call waiting service is a paid option (monthly fees apply) that requires subscription.

1 **Custom** [Settings] ▶ [NW Services] ▶ [Call waiting]
2 [Activate] ▶ [Yes]

Setting Call Forwarding Service

Call Forwarding Service is a free option (no monthly fees) that requires subscription.

1 **Custom** [Settings] ▶ [NW Services] ▶ [Call Forwarding]
2 [Activate] ▶ [Activate] ▶ [Yes]

Osaifu-Keitai

Hold the mark of the FOMA terminal over the scanning device to use as electronic money or railway tickets, or retrieve ToruCa.

- When the FOMA terminal is stolen or lost, immediately contact your provider of Osaifu-Keitai compatible service for handling methods.

General Notes

Introduction of options and related devices

- Battery Pack SH23
- FOMA AC Adapter 01 for Global use
- FOMA AC Adapter 01/02
- Desktop Holder SH33

Main specifications

Size			\$\$ (H) × \$\$ (W) × \$\$ (D) mm (\$\$ at thickest point) (when folded)*
Weight			\$\$ g (with battery pack attached)*
Continuous talk time	FOMA/3G		Voice call: \$\$ min* Videophone: \$\$ min*
	GSM		Voice call: \$\$ min*
Continuous stand-by time	FOMA/3G	3G/GSM setting: 3G	When mobile: \$\$ hr*
		3G/GSM setting: AUTO	At rest: \$\$ hr*
	GSM	3G/GSM setting: AUTO	At rest: \$\$ hr*
Charge time	FOMA AC Adapter 01/02		\$\$ min*
	FOMA DC Adapter 01/02		\$\$ min*

* Approximate value

Specific Absorption Rate (SAR) of mobile phone

This model phone SH-09B meets the MIC's* technical regulation for exposure to radio waves.

The technical regulation established permitted levels of radio frequency energy, based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The regulation employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit is 2 watts/kilogram (W/kg)** averaged over ten grams of tissue. The limit includes a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The value of the limit is equal to the international guidelines recommended by ICNIRP***.

All phone models should be confirmed to comply with the regulation, before they are available for sale to the public. The highest SAR value for this model phone is 0.514 W/kg. It was taken by the Telecom Engineering Center (TELEC), a Registered Certification Agency on the Radio Law. The test for SAR was conducted in accordance with the MIC testing procedure using standard operating positions with the phone transmitting at its highest permitted power level in all tested frequency bands. While there may be differences between the SAR levels of various phones and at various positions, they all meet the MIC's technical regulation. Although the SAR is determined at the highest certified power level, the actual SAR of the phone during operation can be well below the maximum value. For further information about SAR, please see the following websites:

World Health Organization (WHO)

<http://www.who.int/peh-emi/en/>

ICNIRP

<http://www.icnirp.de/>

MIC

<http://www.tele.soumu.go.jp/e/sys/ele/index.htm>

TELEC

http://www.telec.or.jp/ENG/Index_e.htm

NTT DOCOMO

<http://www.nttdocomo.co.jp/english/product/sar/>

SHARP Corporation

<http://www.sharp.co.jp/products/menu/phone/cellular/sar/index.html>

(in Japanese only)

* Ministry of Internal Affairs and Communications

** The technical regulation is provided in Article 14-2 of the Ministry Ordinance Regulating Radio Equipment.

*** International Commission on Non-Ionizing Radiation Protection

European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines.

These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 0.592 W/kg*.

As SAR is measured utilizing the device's highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices.

They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a hands-free device to keep the mobile phone away from the head.

* The tests are carried out in accordance with international guidelines for testing.

Declaration of Conformity

CE 0168

Hereby, Sharp Telecommunications of Europe Ltd, declares that this SH-09B is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

A copy of the original declaration of conformity can be found at the following Internet address:

<http://www.sharp.co.jp/k-tai/> (in Japanese only)

FCC Notice

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Information to User

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient/relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information

Your handset is a radio transmitter and receiver.

It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The guidelines are based on standards that were developed by independent scientific organisations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless handsets employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.

The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model handset when tested for use at the ear is 0.651 W/kg and when worn on the body, as described in this user guide, is 0.684 W/kg.

Body-worn Operation; This device was tested for typical body-worn operations with the back of the handset kept 1.5 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5 cm separation distance between the user's body and the back of the handset. The use of beltclips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.


The FCC has granted an Equipment Authorization for this model handset with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model handset is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/ea/fccid/> after searching on FCC ID APYHRO00122.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Website at <http://www.ctia.org/>.

Inquiries

General inquiries <docomo Information Center>


(Business hours: 9:00 a.m. to 9:00 p.m.)

 **0120-005-250 (toll free)**

- ※ Service available in: English, Portuguese, Chinese, Spanish, Korean.
 - ※ Unavailable from part of IP phones.
- (Business hours: 9:00 a.m. to 8:00 p.m. (open all year round))

From DOCOMO mobile phones

(In Japanese only)

 **(No prefix) 151 (toll free)**

- ※ Unavailable from land-line phones, etc.

From land-line phones

(In Japanese only)

 **0120-800-000 (toll free)**

- ※ Unavailable from part of IP phones.
- Please confirm the phone number before you dial.

Repairs

(Business hours: 24 hours (open all year round))

From DOCOMO mobile phones

(In Japanese only)

f (No prefix) 113 (toll free)

※ Unavailable from land-line phones, etc.

From land-line phones

(In Japanese only)

☎ 0120-800-000 (toll free)

※ Unavailable from part of IP phones.

- Please confirm the phone number before you dial.
- For Applications or Repairs and After-Sales Service, please contact the above-mentioned information center or the docomo Shop etc. near you on the NTT DOCOMO website or the i-mode site.

NTT DOCOMO website: <http://www.nttdocomo.co.jp/english/>

i-mode site: iMenu ▶ お客様サポート (user support) ▶ ドコモショップ (docomo Shop) (In Japanese only)

Loss or theft of FOMA terminal or payment of cumulative cost overseas <docomo Information Center>

(available 24 hours a day)

From DOCOMO mobile phones

International call access code for the country you stay -81-3-6832-6600* (toll free)

* You are charged a call fee to Japan when calling from a land-line phone, etc.

※ If you use SH-09B, you should dial the number +81-3-6832-6600 (to enter "+", press the "0" key for at least 1 second).

From land-line phones

<Universal number>

Universal number international prefix -8000120-0151*

* You might be charged a domestic call fee according to the call rate for the country you stay.

※ For international call access codes for major countries and universal number international prefix, refer to DOCOMO International Services website.

Failures encountered overseas <Network Support and Operation Center>

(available 24 hours a day)

From DOCOMO mobile phones

International call access code for the country you stay -81-3-6718-1414* (toll free)

* You are charged a call fee to Japan when calling from a land-line phone, etc.

※ If you use SH-09B, you should dial the number +81-3-6718-1414 (to enter "+", press the "0" key for at least 1 second).

From land-line phones

<Universal number>

Universal number international prefix -8005931-8600*

* You might be charged a domestic call fee according to the call rate for the country you stay.

※ For international call access codes for major countries and universal number international prefix, refer to DOCOMO International Services website.

- If you lose your FOMA terminal or have it stolen, immediately take the steps necessary for suspending the use of the FOMA terminal.
- If the FOMA terminal you purchased is damaged, bring your FOMA terminal to a repair counter specified by DOCOMO after returning to Japan.