




8. Messages

then press the **6** key three times for "o".
Pressing the **0** key gives a space. The ***** key changes between uppercase and lowercase letters. To switch to numeric input mode, press and hold down the ***** key. Press the **#** key once quickly to insert smart punctuation, or press and hold the **#** key to choose from the whole range of symbols. To enter symbols, press the **1** key once quickly. You can correct a mistyped letter or number by using the **CLEAR** key to remove it.

- **Numeric** - *Numeric input mode.*
- **Symbols** - *Symbols input mode.*
Press the **^/√** to select desired symbols, then press appropriate number key.



Creating a Short Message (MENU 3-3)

Message can be created and sent.

- 1 Enter a text message, and press **↵**.
- 2 Enter the number directly or select the Phone Book using **MENU**, display desired number, and press **↵**.
- 3 Select **Save** (the screen will ask you to send the message after saving it), or select **Send** to send it without saving it.

NOTE:

- You can also create a text message using the Phone Book.
Refer to "Using T9 Predictive Text Input" on page 36.

Message Settings (MENU 3-4)

Storing Service Centre Number (MENU 3-4-1)

You need to store the phone number of the Short Message Service Centre before sending messages.

Enter the phone number of the Service Centre in full international format, and press **↵**.

Message Alert (MENU 3-4-2)

You can enable or disable the message alert.
To activate the message alert, select **On**.





8. Messages

Message Lifetime (MENU 3-4-3)

You can select one of 8 message lifetimes.

You can select desired setting from:

One hour, Two hours, Six hours, One day, Two days, One week, Four weeks, and Six months.

Message Format (MENU 3-4-4)

You can select the format or protocol ID of a message, if your service provider supports it.

You can select desired setting from:

Normal, Fax, Voicemail, ERMES, Nation'l paging, X. 400, and Internet.

Initially, **Normal** will be selected.

Voicemail (MENU 3-5)

You can receive a voicemail if your service provider supports it.

You will need to set the voicemail number settings as above beforehand.

Get a voicemail (MENU 3-5-1)

You can call the registered voicemail number, connect to the voicemailbox, then listen to your voicemail.

Voicemail No. (MENU 3-5-2)

Input the voicemailbox number you received from your service provider, then press ↵.

To change the voicemailbox number:

1 From the voicemailbox number input screen, press **CLEAR**, then input the new telephone number.

2 Press ↵.

Information message (MENU 3-6)

You can receive messages on various topics such as weather and traffic information from your service provider, where such services are available.

Reviewing Information Messages (MENU 3-6-1)

You can review all Information messages received.

Settings (MENU3-6-2)

Allows the necessary settings for receiving information messages.





Language Selection (MENU 3-6-2-1)

This function sets the language for receiving various information services.




Always set this service first before receiving an information service.

NOTE:

- *When Insert or Add to end is selected, if no language has been set yet, "List empty" is displayed.*




Insert:

You can use this submenu when no language has been set and you want to add a new language to the list of selected languages.

- 1 Press .
- 2 Select **Insert**, then press the .
- 3 The list of registered languages is displayed.
- 4 Select your preferred language, then press .



Add to end:

You can use this submenu to add a new language to the end of the list of set languages.

- 1 Press .
- 2 Select **Add to end**, then press .
- 3 The list of already registered languages is displayed. Press .

Delete:

This removes a language from the list of set languages.





- 1 Select the name of the language to delete, then press .
- 2 Select **Delete**, then press .

Subject Selection (MENU 3-6-3-2)

You can obtain messages by selecting your preferred subjects from the subject list on your phone. Also, you can add your preferred subjects to the Subject list.

Create Subject (MENU 3-6-3-2-1)

You can register an information service not included among those pre-registered.

- 1 Press , then select **Add**.
- 2 Press , then input the Subject code.
- 3 Press , input the service name, then press  again.





8. Messages

Editing registered information

- 1 Select the service to be edited with \wedge/\vee , then press \blacktriangleleft .
- 2 Select **View/Edit**, then press \blacktriangleleft .
- 3 The Subject code editing screen is displayed. Input the new code, then press \blacktriangleleft .
- 4 The name editing screen is displayed. Input the new name, then press \blacktriangleleft .

For details on entering and editing service names, see "Keys" on page 46.

Deleting registered information

- 1 Select the service to be deleted with \wedge/\vee , then press \blacktriangleleft .
- 2 Select **Delete**, then press \blacktriangleleft .

Current list (MENU 3-6-3-2-2)

You can register up to two information services into your phone from those registered.

Registering/adding information services

- 1 Press \blacktriangleleft , then select **Add**.
- 2 A list of the pre-registered information services is displayed, so select the desired service from this list with \wedge/\vee .
- 3 Press \blacktriangleleft .

Deleting an information service

- 1 Select the service to be deleted with \wedge/\vee , then press \blacktriangleleft .
- 2 Select **Delete**, then press \blacktriangleleft .





9. Call Diverting (MENU 4)

This feature allows your phone to divert (forward) incoming calls to a preset number. You can select Divert Call function setting for the following cases where such services are available:

Press **MENU** and select **Divert calls**, and press . See page 18 for general information on the menu functions.

Divert All Calls (MENU 4-1)

1 Select one of the following items, and press .

- On:** Select to enable this feature.
The screen will ask you to enter the phone number to which the calls will be diverted, press .
- Off:** Select to disable this feature.
- Status:** Select to review the current status.
- By service:** You can select which of multiple call diverting services you want to use.
 - 1 Select the desire service from **All services, Voice calls, Data, Fax, Messages, and All except msgs.**, then press .
 - 2 The screen will ask you to enter the phone number to which calls will be diverted, so input that number, then press .

NOTES:

- *When setting menu item 4-3(MENU 4-3), set the phone number to divert (forward) to, then set the delay from when a call is received until it is diverted (forwarded). Then, press .*
- *To check the contents you have set for Divert Calls, select Status with menu item 4-1(MENU 4-1) and follow / or the soft key guidance.*





9. Call Diverting

Divert when your phone is busy (MENU 4-2)

1 Follow steps 1 and 2 in section "Divert for All Calls (MENU 4-1)".

Divert when you do not answer (MENU 4-3)

1 Follow steps 1 and 2 in section "Divert for All Calls (MENU 4-1)".

Divert when your phone is out of range (MENU 4-4)

1 Follow steps 1 and 2 in section "Divert for All Calls (MENU 4-1)".

Cancel All (MENU 4-5)

1 Press . Then, all the divert settings will be cleared.





10. Clock (MENU 5)

Your phone provides clock and alarm functions.

Press **MENU** and select **Clock**, and press .
See page 21 for general information on the menu functions.



Alarm Clock Settings (MENU 5-1)

Once you have set the clock and date (refer to page 44), you can set an alarm clock in various ways. In addition to the normal alarm clock which will be activated by specifying the time and date, you can repeat the alarm at the selected interval. Also you can show a text message with an alarm, as a reminder. Note that, to use an alarm clock, you need to set the Alarm Status to on. When an alarm is issued, will appear on the top of the standby screen with an alarm tone.

Setting an Alarm Clock (MENU 5-1-1)

Select your desired item from the following, and press .
Date, Time, Tone, Message, Repeat, and Alarm state.
When you have set an item mentioned here, the screen will return to the original screen to allow other alarm settings.



- When **Date** is selected:
Enter the date for the alarm (e.g. 30/12/2001), and press .
- When **Time** is selected:
Enter the time for the alarm (e.g. 17:30), and press .
- When **Tone** is selected:
Select your desired tone from several tones, and press .
(The selected tone will sound. You can also set it to **Off**.)
- When **Message** is selected:
Enter a message, and press .
- When **Repeat** is selected:
Select your desired item (**None, Daily, Weekly** or **Monthly**), and press .
- When **Alarm state** is selected:
Select one of the following items, and press .
Enabled : alarm will go on at set time
Disabled : set off the alarm



- After finishing the above settings, press .
- The following items will be displayed:
- To save the new alarm settings, select **Save**, and press .
 - To cancel the current alarm settings, select **Cancel**, and press .
 - To exit without saving the alarm settings, press .

For details on entering messages, see "Keys" on page 46.





10. Clock

NOTES:

- Up to four different alarms can be set. Once four alarms have been set, the system will no longer go into alarm setting mode (MENU 5-1-1).
- You can set multiple alarm clock settings. The settings are stored in your phone according to the time and date being set.
- When you select Disabled in Alarm state, no alarm will be activated.
- Please check the Date and the Time when you switch from Disabled to Enabled in the Alarm State.

Alarm List Review (MENU 5-1-2)

You can review the current alarm list with the ^ / v keys. Select the alarm to delete/edit, then press ↵.

- To review and edit the alarm, select **View/Edit**, and press ↵.
- To delete the alarm from the list, select **Delete**, and press ↵.

Alarm Clear (MENU 5-1-3)

You can clear all alarm settings at one time.

"Clear all alarms?" will be displayed.

To clear all alarm settings, press ↵.

Clock and Date Settings (MENU 5-2)

Time/Date Format Settings (MENU 5-2-1/5-2-2)

You can select desired setting from 12 hour and 24 hour and date format (D:M:Y, M:D:Y or Y:M:D).

The new setting will be displayed.

Time and Date Display Selection (MENU 5-2-3)

You can select desired setting from **Time only**, **Date only**, **Date & Time** and **Off**.

The new setting will be displayed.

NOTE:

- The time and date will be displayed at the top right of the standby screen. If Date & time is selected, they are alternately displayed on the screen.





10. Clock

Daylight Saving Adjustment (MENU 5-2-4)

You can use the daylight saving feature which will move the current time forward by one hour.

You can select desired setting from **Off** and **On**. The new setting will be displayed.



NOTE:

- *When you disable this feature, the clock display will return to the normal setting.*

Time and Date Settings (MENU 5-3/5-4)

Enter time/date, and press ↵.

Each time you press the dial key for an entry, the cursor scrolls for each digit.

Time example: 17:30 (for 24-hour time format)

05:30 PM (for 12-hour time format)

Date example: 30/12/2001 (for D:M:Y date format)

NOTE:

- *Please change the AM/PM indication using the * key.*



Time Zone Setting (MENU 5-5)



By setting the time zone (difference in time), you can obtain the local time without changing the time setting for the clock.

Enter the time difference.

To move the clock backward by *hh:mm*, enter *hh:mm (-hh:mm)*. ("-" is already set.)

To move the clock forward by *hh:mm*, press the * key to change the sign to "+", then enter *hh:mm (+hh:mm)*.

To enter it, press ↵.

Then, the clock will shift by the amount you entered.

