



# AirCard<sup>®</sup> 800 Series Wireless Network Cards

## Installation Guide



**Includes:**

- AirCard 880 Wireless Modem
- AirCard 881 Wireless Modem
- AirCard 880 Express Card Wireless Modem
- AirCard 881 Express Card Wireless Modem
- AirCard 875 Wireless Modem
- AirCard 860 Wireless Modem
- AirCard 850 Wireless Modem

2130623  
Rev 3.7A



## Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless or its affiliates. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY. NOTWITHSTANDING THE FOREGOING, IN NO EVENT SHALL SIERRA WIRELESS AND/OR ITS AFFILIATES' AGGREGATE LIABILITY ARISING UNDER OR IN CONNECTION WITH THE SIERRA WIRELESS PRODUCT, REGARDLESS OF THE NUMBER OF EVENTS, OCCURRENCES OR CLAIMS GIVING RISE TO LIABILITY, BE IN EXCESS OF THE PRICE PAID BY THE PURCHASER FOR THE SIERRA WIRELESS PRODUCT.

## Patents

Portions of this product may be covered by some or all of the following US patents:

5,515,013	5,629,960	5,845,216	5,847,553	5,878,234
5,890,057	5,929,815	6,169,884	6,191,741	6,199,168
6,339,405	6,359,591	6,400,336	6,516,204	6,561,851
6,643,501	6,653,979	6,697,030	6,785,830	6,845,249
6,847,830	6,876,697	6,879,585	6,886,049	6,968,171
6,985,757	7,023,878	7,053,843	7,106,569	D442,170
D459,303				

and other patents pending.

This product includes technology licensed from:

QUALCOMM® 3G

Licensed by QUALCOMM Incorporated under one or more of the following United States patents and/or their counterparts in other nations:

4,901,307	5,056,109	5,101,501	5,109,390	5,228,054
5,267,261	5,267,262	5,337,338	5,414,796	5,416,797
5,490,165	5,504,773	5,506,865	5,511,073	5,535,239
5,544,196	5,568,483	5,600,754	5,657,420	5,659,569
5,710,784	5,778,338			

Manufactured or sold by Sierra Wireless or its licensees under one or more patents licensed from InterDigital Group.

## Copyright

© 2007 Sierra Wireless. All rights reserved.

## Trademarks

AirCard modem<sup>®</sup> and Heart of the Wireless Machine<sup>®</sup> are registered trademarks of Sierra Wireless.

Sierra Wireless, the Sierra Wireless logo, the red wave design, the red-tipped antenna, and Watcher are trademarks of Sierra Wireless.

Other trademarks are the property of the respective owners.

All product specifications are subject to change without notice.

## Contact Information

Sales Desk:	Phone:	1-604-232-1488
	Hours:	8:00 AM to 5:00 PM Pacific Time
	E-mail:	<a href="mailto:sales@sierrawireless.com">sales@sierrawireless.com</a>
Post:	Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4	
Fax:	1-604-231-1109	
Web:	<a href="http://www.sierrawireless.com">www.sierrawireless.com</a>	

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases:

[www.sierrawireless.com](http://www.sierrawireless.com)

# »» | Table of Contents

<b>Introducing the AirCard 800 Series Wireless Network Cards</b> .....	<b>7</b>
AirCard 800 Series wireless network cards .....	7
Services supported .....	7
Your account and coverage area .....	8
AirCard modem software .....	9
Frequency band support .....	9
<b>AirCard Installation</b> .....	<b>11</b>
System requirements .....	11
The SIM Card and Your Account .....	11
Attach the antenna to your AirCard modem .....	12
Install Watcher software .....	13
Setting Internet Explorer to use the AirCard modem .....	14
Configuring Your Account .....	14
Setting up a profile .....	15
The AirCard modem as a network card .....	16
<b>Watcher Basics</b> .....	<b>17</b>
Launching Watcher .....	17
Frequency band selection .....	18
<b>Care and Maintenance of Your Network Card</b> .....	<b>19</b>
Stopping and ejecting the AirCard modem .....	20
Removing a SIM card .....	20
AirCard 850 and 860 modems .....	20
AirCard 875, 88x, and 88xE modems .....	21

<b>Regulatory and Safety Information</b> .....	<b>23</b>
Important notice .....	23
Safety and hazards .....	23
Important safety/compliance information for North American users.....	24
Information pertaining to OEM customers .....	25
EU regulatory conformity.....	27
<b>Technical Specifications</b> .....	<b>29</b>
LEDs .....	29
Radio frequency and electrical specifications .....	29
Environmental specifications .....	30



# 1: Introducing the AirCard 800 Series Wireless Network Cards

1

- AirCard 800 Series wireless network cards
- Your account and coverage area
- AirCard modem software

---

*Caution: Do not insert your AirCard modem into your PC / Express Card slot before installing the software.*

---

## AirCard 800 Series wireless network cards

The AirCard 800 Series 3G wireless network cards are modems for your PC that allow you to connect to the Internet, send and receive e-mail, connect to a corporate network/VPN, or view streaming video, without the need of a network cable or phone line.

The AirCard PC Card modem (AirCard 850 / 860 / 875 / 88x) fits into a standard (Type II) PC Card slot available on notebook PCs.

The AirCard Express Card modem (AirCard 88xE) fits into a standard Express Card-34 slot available on notebook PCs.

## Services supported

The services supported on your AirCard modem depends on the model of AirCard (see [www.sierrawireless.com](http://www.sierrawireless.com) for details) and your service provider.

When establishing a connection, your AirCard modem uses the fastest available service. If, for example, you are using an AirCard modem in an area that has GPRS and EDGE service but not UMTS or HSDPA service, the AirCard modem connects using EDGE service.

Once the connection is established, you have access to all Internet services.

---

*Note: If you purchased the AirCard modem from a GSM service provider, you may already have an account. Otherwise, your retailer should be able to provide you with the names of companies that provide this service.*

---

---

*Note: The fee for service is usually higher when you are “roaming” (connected to a network other than the one belonging to your service provider).*

---

## Your account and coverage area

You must have an account with a GSM service provider to use the AirCard modem. To use the modem’s 3G capability, your account must be with a service provider who offers HSDPA or UMTS service. (The AirCard modem is backward-compatible to 2G service.)

When you obtain your account, you are given a SIM card, also called a “smart card” or “smart chip”. (Depending on how you purchased your AirCard modem, you may already have an account, and your SIM card may have been included in your package.) The SIM card contains account information and must be inserted in the AirCard modem anytime you use it.

Before you can use the AirCard modem, you must install the AirCard modem software and ensure that your AirCard modem is configured to use your account.

Once the AirCard modem is installed and configured, you can connect to the Internet with the AirCard modem in any area in which you can obtain GPRS, EDGE, UMTS, or HSDPA service.

Your ability to obtain service depends on these factors:

- **Proximity to a GSM network**—You must be within the coverage area of a GSM network in order to use the AirCard modem.
- **Service provider**—If you are within the coverage area of a network that is not operated by your own service provider, you can only obtain service if there is a roaming agreement between your service provider and the network operator.
- **Account provisions**—Your account may restrict your usage to certain networks or limit the amount of time you can use the network.
- **Frequency band**—You cannot connect to networks operating in bands not supported by your AirCard modem, regardless of roaming agreements or account provisions.

Most service providers have coverage maps on their web sites.



## AirCard modem software

The AirCard modem comes with this software (made by Sierra Wireless):

- The Watcher program that you use to manage the AirCard modem and monitor your connections
- The driver software that forms the interface between the network card and your Windows operating system

## Frequency band support

The following table shows the frequency bands supported by the various AirCard products

**Table 1-1: Frequency band support**

Technology	Bands	Products	Location
<b>2G</b>	850 MHz (cellular band)	All	North America
	900 MHz	All	Europe
	1800 MHz	All	Europe and Asia
	1900 MHz (PSC band)	All	North America
<b>3G</b>	WCDMA 850 <sup>ab</sup>	AirCard88x AirCard88xE AirCard875 AirCard860	North America
	WCDMA 1900 <sup>b</sup>	AirCard88x AirCard88xE AirCard875 AirCard860	North America
	WCDMA 2100 <sup>a</sup>	AirCard88x AirCard88xE AirCard875 AirCard850	Europe, Asia, and Australia

a. Receive diversity (AirCard 880 and 880E)

b. Receive diversity (AirCard 881 and 881E)



## 2: AirCard Installation

- System requirements
- Install Watcher software
- Setting Internet Explorer to use the AirCard modem

### System requirements

The AirCard modem is supported on:

- Windows® Vista™
- Windows XP (Home and Professional versions)
- Windows 2000

For information on using the AirCard modem with other operating systems, contact Sierra Wireless Technical Support ([support@sierrawireless.com](mailto:support@sierrawireless.com)).

To install the AirCard modem, you require these system resources:

**Table 2-1: System resource requirements**

Card slots	1 Type II PCMCIA (PC Card) slot for AirCard 850, 860, 875, 88x
	1 Express Card-34 slot for AirCard 88xE
Disk drive	CD-ROM
I/O resources	1 IRQ, 40 bytes I/O space
Memory	32 MB

### The SIM Card and Your Account

To use your AirCard modem, you need a GSM account and a SIM (Subscriber Identity Module) card. The SIM card is a small chip (about the size of a postage stamp) that you insert into the AirCard modem. The SIM contains account information used by the network to validate your access.

Depending on how you purchased your AirCard modem, you may already have an account. In this case, the SIM should be included in your package. Otherwise, your retailer should direct you to a local company that provides GSM service.

---

*Note: Without a valid SIM card and a valid account, your AirCard modem will not work.*

---

---

*Note: Keep a written record, in a secure place, of the account information that your service provider gives you. Instructions on creating a profile are in the section “Configuring Your Account” on page 21.*

---

To activate an account, the service provider needs from you:

- Billing information (such as a credit card number) used to collect payment for your network usage
- Possibly the IMEI (International Mobile Equipment Identity), depending on your service provider. This number, printed on the AirCard modem box and on the AirCard modem label, identifies your device (AirCard modem model) on the GSM network.

If you change GSM service providers (such as if you move to a new city), you will need a new SIM card from your new service provider. You will also need to set up a new profile.

## Attach the antenna to your AirCard modem

---

*Note: This section applies only to the AirCard 850 modem and AirCard 860 modem.*

---

If your AirCard modem has an external antenna, the antenna attaches to the gold-plated connector on the end of the AirCard modem.




Figure 2-1: Attaching the antenna to the AirCard modem

## Install Watcher software

*Note: Users of Windows 2000 must be logged in with administrative privileges. Users of Windows XP may require administrative privileges.*

*Note: If you are running Windows 2000, Windows Installer Redistributable 2.0 must be installed. This is available on the Microsoft web site, [www.microsoft.com](http://www.microsoft.com).*

*Note: You may require your Windows CD. Ensure you have the CD before proceeding.*

1. If the AirCard modem CD is not already in your CD-ROM drive, insert it. The CD should autostart and display a menu.  
If the CD does not autostart, select **Start > Run** and enter **d:\setup.exe** where **d** is the drive letter of your CD-ROM drive.
2. From the CD start-up menu, select your language, then **notebook installation**, and then the link under **notebook software installation** to launch the installer.
3. Use the **Next** and **Back** buttons to navigate through the installer.
4. If the SIM is not already inserted in your AirCard modem, insert it.
5. For the AirCard 850 modem / AirCard 860 modem:  
If the antenna is not yet attached, attach it. (See [page 13](#).)
6. With the label facing up, insert the AirCard modem into your PC / Express Card slot.

*Note: Do not forcefully insert the AirCard modem. This may damage connector pins. If you have more than one PC / Express Card slot, you may obtain better signal strength using the top slot.*




Figure 2-2: Inserting the AirCard modem

To close the CD start-up menu, click the **exit** option in the lower right corner of the window.

Watcher should launch automatically when the AirCard modem is inserted. If your AirCard modem has not yet been configured to use your account, you are prompted to do so. See ["Setting up a profile"](#) on page 22.

## Setting Internet Explorer to use the AirCard modem

If you are using Internet Explorer as your browser, and it is set to connect to the Internet through a dial-up modem, you must set it to use a LAN (local area network) card.

To set Internet Explorer version 5 or 6 to use a LAN, follow these steps:

1. In Internet Explorer, select **Tools > Internet Options**.
2. Click the **Connections** tab.
3. Click **Setup** to run the Internet Connection wizard.
4. Select the option **"I want to set up my Internet connection manually, or I want to connect through a local area network (LAN)."** Click **Next**.
5. Select **"I connect through a local area network (LAN)"**. Click **Next**.
6. Ensure no check boxes are selected in the **"Local area network Internet configuration"** window and click **Next**.
7. Select **No** when prompted to set up an Internet mail account and click **Next**.
8. Click **Finish** to exit the wizard.

## Configuring Your Account

Profiles contain account information used by the AirCard modem to establish connections. At least one profile must be set up on the AirCard modem before you can use it. The profile(s) may have been stored on the AirCard modem before you purchased it. Otherwise, your service provider should give you all the information you need to set up the profile(s) you require.

Depending on your service provider, some or all of this information must be entered into your profile:

- User Name
- Password
- APN (Access Point Name)


- IP (Internet Protocol) Address (if the address is not automatically assigned by the network)
- Use of IP header compression
- DNS (Domain Name Server) address or addresses

Your service provider may give you only one APN in which case you require only one profile. Some service providers assign separate APNs for separate purposes. For example, some service providers supply one APN to use for Internet browsing and a different APN to use with a VPN. In this case you must set up multiple profiles. The AirCard modem allows for up to sixteen profiles.

Most service providers have one or two standard profiles that all or most of their subscribers are expected to use. Most of these standard profiles have been pre-defined in Watcher, allowing you to select a standard profile, rather than creating it manually.

One of your profiles must be set as the “default” profile. This is the one that is used if you select the **Connect** button without selecting a profile. The default profile is also used if you set the AirCard modem to autoconnect. If you are using the AirCard modem to access a network that requires you to provide a password each time you connect, you must set the connection mode for your profile to prompt for password (in which case you must connect manually).

## Setting up a profile

1. Insert the SIM into the AirCard modem if it is not already inserted.
2. Insert the AirCard modem into the PC / Express Card slot if it is not already inserted. (See [page 13](#).)
3. If Watcher is not running, start Watcher by selecting **Start > Programs > Sierra Wireless > 3G Watcher > 3G Watcher** or double-clicking the desktop shortcut .

If Watcher detects that no profile has been set up, you are prompted, “Would you like to configure a profile now?” Select **Yes**.

If this prompt does not appear, your AirCard modem may have been preconfigured. You can verify that you have a profile by selecting **Tools > Connections** to access the AirCard modem tab of the Connections window, which lists all profiles.

---

*Note: You must install the software before you can set up a profile. (See [page 11](#).)*

---

## The AirCard modem as a network card

The AirCard modem can be configured to provide the “always-on” data connection that an Ethernet card or other wired LAN card provides. That is, you can set options in Watcher™ (a program that comes with the AirCard modem) that causes the AirCard modem to establish a network connection whenever you insert it, assuming GSM, GPRS, EDGE, UMTS, or HSDPA service is available. Otherwise, you can configure Watcher to connect only when you click the Connect button.

The AirCard modem connection provides access to the Internet. Once the connection is established, you can open your browser and connect to any web site available on the Internet, or access other Internet services (such as e-mail).



## >> 3: Watcher Basics

- [Launching Watcher](#)
- [Frequency band selection](#)

---

*Note: It takes up to 20 seconds for Watcher to become fully functional after launch.*

---


Watcher is the program you use to manage and monitor your AirCard modem connections. Watcher allows you to:

- Create an account profile.
- Determine signal strength, roaming status, GPRS / EDGE / UMTS / HSDPA availability, and other network connection parameters
- Monitor the status of the AirCard modem and GSM service
- Initiate data connections
- Make and receive phone calls
- Send and receive SMS messages
- Enable or disable SIM security that prevents others from using your SIM card if it is lost or stolen
- Set options related to notifications and the Watcher window

If you set your account profile to autoconnect, you do not need to run Watcher when you use the AirCard modem, but Watcher does provide useful status information.

### Launching Watcher

Unless the feature has been disabled, Watcher launches automatically anytime you insert the AirCard modem. You can also launch Watcher by:

- Double-clicking the desktop shortcut,  or
- Selecting **Start > Programs > Sierra Wireless > 3G Watcher > Watcher**

Depending on how your profile is configured, your browser, VPN, or other program may launch automatically anytime you launch Watcher.

To view the 3G Watcher online help, press <F1> or select **Help > Help Topics**.

## Frequency band selection

Watcher has two options that affect your ability to obtain GPRS, EDGE, UMTS, or HSDPA service in any given area. You can select:

- The frequency band you want to use
- The network you want to use, if you are within the coverage area of more than one network

Every GSM network operates on one set of frequency bands. The AirCard modem is designed to change frequency bands automatically as required to obtain network service. You can also change frequency bands manually from the Network tab of the Options window (**Tools > Options... > Network**).

---

*Note: Unless your service provider specifies otherwise, it is recommended that you use the **Auto** setting.*

---

## 4: Care and Maintenance of Your Network Card

---

*Note: Do not insert the AirCard modem before installing the software. See “AirCard Installation” on page 11. Protect the card from liquids, dust, and excessive heat (see “Environmental specifications” on page 30 for details).*

---

You can ensure reliable operation and long life of your AirCard modem by adhering to these guidelines in storage and use:

- Do not apply adhesive labels to the AirCard modem or SIM. This may cause the AirCard modem or SIM to become jammed inside the slot, or prevent it from being inserted properly.
- When not installed in your computer, store the AirCard modem and SIM in a safe place.
- The AirCard modem should fit easily into your computer’s PC / Express Card slot. Forcing the AirCard modem into the slot may damage the connector pins.
- For AirCard modems with external antennas, optimal signal strength is usually obtained when the antenna is pointing straight up. The antenna should bend easily at the hinge. Do not forcefully bend the antenna.



*Figure 4-1: Proper positioning of the AirCard modem antenna for AirCard 850 modem / AirCard 860 modem*

## Stopping and ejecting the AirCard modem

To remove the AirCard modem:

1. Close Watcher if it is open.
2. Click the PC Card icon in the status area to display the option to stop the card.
3. Click the appropriate option, depending on your operating system and the model of AirCard modem.
4. If a dialog box appears notifying you that it is safe to remove the card, click **OK**.
5. Push the PC Card eject button beside the PC / Express Card slot on your computer to eject the card.
6. Grasp the AirCard modem and remove it from the slot.

## Removing a SIM card

The procedure for removing the SIM card depends on the model of AirCard modem you have.

### AirCard 850 and 860 modems

To remove the SIM card, you need a pen.

1. Place the AirCard modem on a smooth, hard surface such as a tabletop.
2. Position the pen above the eject hole, which is on the top surface of the AirCard modem housing, just to the right of the SIM card slot. (See [Figure 4-2](#).)
3. Press down gently (without excessive force) on the eject hole. The SIM card should pop out of its slot.




Figure 4-2: Ejecting the SIM card

4. Gently pull the SIM card from the slot until it slides free.

### **AirCard 875, 88x, and 88xE modems**

To remove the SIM/USIM card, you need a pen.

1. Place the AirCard modem on a smooth, hard surface such as a tabletop, or hold it face down.
2. Gently insert the pen into the end of the eject slot farthest from the SIM slot. Slide the pen towards the SIM slot. The SIM card pops out of its slot.




Figure 4-3: Ejecting the SIM card

3. Gently pull the SIM card from the slot until it slides free.



## 5: Regulatory and Safety Information

- Important notice
- Important safety/compliance information for North American users
- EU regulatory conformity

### Important notice

Because of the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (that is, have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless network card are used in a normal manner with a well-constructed network, the Sierra Wireless network card should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless and its affiliates accept no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless network card, or for failure of the Sierra Wireless network card to transmit or receive such data.

### Safety and hazards

Do not operate your AirCard modem:

- In areas where blasting is in progress
- Where explosive atmospheres may be present including refuelling points, fuel depots, and chemical plants
- Near medical equipment
- Near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the AirCard modem **MUST BE POWERED OFF**. Otherwise, the AirCard modem can transmit signals that could interfere with this equipment.

In an aircraft, the AirCard modem **MUST BE POWERED OFF**. Otherwise, the AirCard modem can transmit signals that could interfere with various onboard systems and may be dangerous to the operation of the aircraft or disrupt the cellular network. Use of a cellular phone in an aircraft is illegal in some jurisdi-

cations. Failure to observe this instruction may lead to suspension or denial of cellular telephone services to the offender, or legal action or both.

Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. The AirCard modem may be used normally at this time.

## Important safety/compliance information for North American users

**CAUTION:** Unauthorized modifications or changes not expressly approved by Sierra Wireless, Inc. could void compliance with regulatory rules, and thereby your authority to use this equipment.

The design of the AirCard 850 / 860 / 875 / 880 / 881 / 880E / 881E modem complies with U.S. Federal Communications Commission (FCC) and Industry Canada (IC) guidelines respecting safety levels of radio frequency (RF) exposure for portable devices, which in turn are consistent with the following safety standards previously set by Canadian, U.S. and international standards bodies:

- ANSI / IEEE C95.1-1999, *IEEE Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3kHz to 300 GHz*
- National Council on Radiation Protection and Measurements (NCRP) Report 86, -1986, *Biological Effects and Exposure Criteria for Radio Frequency Electromagnetic Fields*
- Health Canada, Safety Code 6, 1999, *Limits of Human Exposure to Radio frequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz*
- International Commission on Non-Ionising Radiation Protection (ICNIRP) 1998, *Guidelines for limiting exposure to time-varying electric, magnetic, and electromagnetic fields (up to 300 GHz)*

These devices are only authorized to be used in laptop computers that are identical or substantially similar to those in its grant application.

These devices comply with Part 15 of the FCC Rules. Operation is subject to the condition that these devices do not cause harmful interference.



Where appropriate, the use of the equipment is subject to the following conditions:

**WARNING (EMI) – United States FCC Information –** This equipment has been tested and found to comply with the limits pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in an appropriate installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

If you have purchased this product under a United States Government contract, it shall be subject to restrictions as set forth in subparagraph (c)(1)(ii) of Defense Federal Acquisitions Regulations (DFARs) Section 252.227-7013 for Department of Defense contracts, and as set forth in Federal Acquisitions Regulations (FARs) Section 52.227-19 for civilian agency contracts or any successor regulations. If further government regulations apply, it is your responsibility to ensure compliance with such regulations.

### **Information pertaining to OEM customers**

The AirCard 850 / 860 / 875 / 880 / 881 / 880E / 881E wireless network cards have been granted modular approval for mobile applications. Integrators may use the AirCard 850 / 860 / 875 / 880 / 881 / 880E / 881E wireless network cards in their final products without additional FCC / IC certification if they meet the following conditions. Otherwise, additional FCC / IC approvals must be obtained.

1. At least 20 cm separation distance between the antenna and the user's body must be maintained at all times.
2. The AirCard 850 / 860 / 875 / 880 / 881 / 880E / 881E wireless network cards and their antennas must not be

colocated with any other transmitter or antenna within a host device.

3. A user manual with the end product must clearly indicate the operating requirements and conditions that must be observed to ensure compliance with current FCC / IC RF exposure guidelines.
4. The end product with an embedded AirCard 850 / 860 / 875 / 880 / 881 / 880E / 881E wireless network card must pass the unintentional emission testing and properly authorized per FCC Part 15 requirements where applicable.

---

*Note: If these wireless network cards are intended for use in a portable device, you are responsible for separate approval to satisfy the SAR requirements of FCC Part 2.1093 and IC RSS-102.*

---

#### **AirCard 850 / 860 wireless network cards**

1. To comply with FCC / IC regulations limiting both maximum RF output power and human exposure to RF radiation, the maximum antenna gain must not exceed 8 dBi in the Cellular band and 4 dBi in the PCS band.
2. A label must be affixed to the outside of the end product into which the AirCard wireless network card is incorporated, with a statement similar to the following:
  - For an end product with an embedded AirCard 850 wireless network card:  
**This device contains FCC ID: N7NAC850.**
  - For an end product with an embedded AirCard 860 wireless network card:  
**This device contains FCC ID: N7NAC860.**  
**This equipment contains equipment certified under IC: 2417C-AC860.**

#### **AirCard 875 / 880 / 881 / 880E / 881E**

1. To comply with FCC / IC regulations limiting both maximum RF output power and human exposure to RF radiation, the maximum antenna gain must not exceed 5 dBi in the Cellular band and 4 dBi in the PCS band.
2. A label must be affixed to the outside of the end product into which the AirCard wireless network card is incorporated, with a statement similar to the following:
  - For an end product with an embedded AirCard 875 wireless network card:  
**This device contains FCC ID: N7NAC875.**

**This equipment contains equipment certified under IC: 2417C-AC875.**

- For an end product with an embedded AirCard 880 wireless network card:

**This device contains FCC ID: N7NAC880.**

- For an end product with an embedded AirCard 881 wireless network card:

**This device contains FCC ID: N7NAC881.**

**This equipment contains equipment certified under IC: 2417C-AC881.**

- For an end product with an embedded AirCard 880E Express Card wireless network card:

**This device contains FCC ID: N7NAC880E.**

- For an end product with an embedded AirCard 881E Express Card wireless network card:

**This device contains FCC ID: N7NAC881E.**

**This equipment contains equipment certified under IC: 2417C-AC881E.**

## EU regulatory conformity

Sierra Wireless hereby declares that the AirCard 850 / 875 / 880 / 880E wireless network cards conform to all the essential requirements of Directive 1999/5/EC:

**CE 0682**


AirCard 875 and AirCard 880 Wireless Network Card  
AirCard 880E Express Card

**CE 0984**

AirCard 850 Wireless Network Card

The Declaration of Conformity made under Directive 1999/5/EC is available for viewing at the following location in the EU community:

Sierra Wireless (UK), Limited  
Lakeside House  
1 Furzeground Way, Stockley Park East  
Uxbridge, Middlesex  
UB11 1BD  
England



# 6: Technical Specifications

This chapter provides technical data for the AirCard modem.

## LEDs

For a description of LED functionality, see the 3G Watcher online help.

## Radio frequency and electrical specifications

**Table 6-1: Radio frequency and electrical specifications for AirCard 850 / 860 / 875 modems**

<b>Compliance</b>	GSM Release 5
<b>Transmit</b>	<i>PCS:</i> 1850 to 1910 MHz <i>DCS1800:</i> 1710 to 1785 MHz <i>EGSM900:</i> 880 to 915 MHz <i>GSM850:</i> 824 to 849 MHz <i>WCDMA2100: (AirCard 850, 875, 88x, 88xE modems)</i> 1920 to 1980 MHz <i>WCDMA850: (AirCard 850, 875, 88x, 88xE modems)</i> 824 to 849 MHz <i>WCDMA1900: (AirCard 850, 875, 88x, 88xE modems)</i> 1850 to 1910 MHz
<b>Receive</b>	<i>PCS:</i> 1930 to 1990 MHz <i>DDCS1800:</i> 1805 to 1880 MHz <i>EGSM900:</i> 925 to 960 MHz <i>GSM850:</i> 869 to 894 MHz <i>WCDMA2100: (AirCard 850, 875, 88x, 88xE modems)</i> 2110 to 2170 MHz <i>WCDMA850: (AirCard 850, 875, 88x, 88xE modems)</i> 869 to 894 MHz <i>WCDMA1900: (AirCard 850, 875, 88x, 88xE modems)</i> 1930 to 1990 MHz
<b>Channel spacing</b>	200 kHz (GSM) 5 MHz (WCDMA)
<b>Channel raster</b>	200 kHz

**Table 6-1: Radio frequency and electrical specifications for AirCard 850 / 860 /875 modems (cont.)**

<b>Frequency stability</b>	0.1 ppm
----------------------------	---------

## Environmental specifications

**Table 6-2: Environmental specifications**

<b>Operating temperature</b>	-20°C to +60°C (-4°F to +140°F)
<b>Storage temperature</b>	-30°C to +85°C (-22°F to +185°F)
<b>Humidity</b>	95%, non-condensing
<b>Vibration</b>	15 g peak 10 to 2000 Hz (non-operating)

# »» Index

## A

- account 8
- always-on data connection 16
- antenna
  - attaching 12, 13
- APN 14

## C

- care and maintenance 19
- channel raster 29
- channel spacing 29
- copyright information 3
- coverage area 8

## D

- DNS 14
- driver 9

## E

- ejecting a SIM card 20, 21
- ejecting the AirCard modem 20
- electrical specifications 29
- environmental specifications 30

## F

- frequencies
  - receive 29
  - transmit 29
- frequency bands
  - selection 18
- frequency stability 30

## H

- humidity 30

## I

- I/O space (input/output space) 11
- IMEI 12
- inserting
  - AirCard modem
    - Windows 98, 2000, Me 13
- installation 13–14
- Internet Explorer, setting to use the card 14
- IP address 14

- IRQ (interrupt request) 11

## L

- launching Watcher 17
- LEDs 29
- liability, limitation of 3

## M

- maintenance 19
- memory required 11

## N

- network
  - overview 8
- notebook PC
  - inserting AirCard modem 13
  - removing the AirCard modem 20
  - system requirements 11

## P

- password
  - overview 14
- PC / Express Card slots required 11
- profile
  - default 15
  - determining if one is set up 15
  - overview 14

## R

- radio frequency specifications 29
- receive frequencies 29
- regulatory information 23
- removing
  - AirCard modem 20
  - SIM card 20, 21
- RF specifications 29
- roaming 8

## S

- safety notice 23
- SIM card
  - removing 20, 21
- specifications 29–30
  - electrical 29
  - environmental 30

- radio frequency [29](#)
- storage
  - temperature [30](#)
  - when not using card [19](#)
- system requirements, notebook PCs [11](#)

## T

- technical specifications [29–30](#)
- temperature [30](#)
- trademarks [4](#)
- transmit frequencies [29](#)

## U

- user name [14](#)

## V

- vibration [30](#)

## W

- Watcher

- introduction [17](#)
  - launching [17](#)

- Windows 2000

- as a supported operating system, service pack [11](#)
  - inserting the card [13](#)

- Windows 98

- as a supported operating system [11](#)

- inserting AirCard modem [13](#)

- Windows Me

- inserting the card [13](#)





