

X-TREK PRO

REVOLUTION IN RACING

EI-1001
Instruction Manual

Key feature

- Full function radio control.
- Digital proportional speed and steering.
- Tri-band user-selectable.
- Digital-trimming control.
- Front wheel suspension.
- Quick charging powered by transmitter.
- Variety of car styles for collection.
- With side lights equipped.(optional)
- Straightness and initial speed adjustable.

WARNING:
CHOKING HAZARD – Small parts.
Not for Children under 3 years.

"This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC."



Safety Precautions:

- Parents, this toy is recommended for children. To ensure that your child's play is both safe and fun, please review the operating instructions with your children.
- **DO NOT** pick up moving vehicle.
- Keep hands, hair and loose clothing away from the tires and the wheel hubs when power switch is turned ON.
- Remove battery from transmitter and Track Station when not in use.
- **DO NOT** operate your vehicle on street. Avoid hitting people, pets or home furnishings.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Battery Cautions:

- Do not recharge the battery if it's hot. Allow it to cool before recharging.
- Do not charge the battery that shows leakage or corrosion.
- Do not disassemble the battery. The battery is a sealed NIMH(Nickel-Metal Hydride) battery.
- Do not dispose of the batteries in fire.

Cautions:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged. (For Transmitter and Track Station only)
- Rechargeable battery are only to be charged by an adult.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

Care and Maintenance:

- Always remove batteries from the toy when it is not being used for a long period of time.
- Wipe the toy gently with a clean damp cloth.
- Keep the toy away from direct sunlight and/or direct heat.
- Do not submerge the toy into water that can damage the electronic assemblies.

Note:

- Parental guidance is recommended when installing or replacing batteries.
- You are advised to replace with new batteries as soon as the function becomes impaired.
- Users should keep and retain this information for future reference.
- Users should keep strict accordance with the instruction manual while operation the product.
- Under the environment with electrostatic discharge, the sample may malfunction and require user to reset the sample.

Special Note to Adults:

- Regularly examine for damage to the recharging terminal, enclosure and other parts. In the event of any damage, the toy must not be used with the detachable power charger until the damage has been repaired.
- This toy must only be used with the recommended transmitter.

Battery requirement for Transmitter:


- Power Supply :
- Rating : DC 6 V, 4.2 W
- Batteries : 4 x 1.5 V "AA"/LR6/AM3
- Requires 4 x 1.5 V "AA" size batteries (not included)

Battery requirement for Vehicle:

- Power Supply :
- Rating : DC 2.4 V, 1.0 W
- Battery : 2 x 1.2 V Ni-MH batteries
- Requires 2 x 1.2 V Ni-MH batteries (included)

Battery requirement for Track Station:

- Power Supply :
- Rating : DC 6 V, 4.2 W
- Batteries : 4 x 1.5 V "AA"/LR6/AM3
- Requires 4 x 1.5 V "AA" size batteries (not included)



FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Index to parts



Transmitter




Track Station




Vehicle



Transmitter Battery Cover



Track Station Battery Cover



Tri-Band Selector

Silverlit®

Silverlit Toys (U.S.A.) Inc. P.O. Box 1237, Walnut, CA91788
©2005 Silverlit Toys Manufactory Limited. All rights reserved.



Getting Started

Batteries:

- The Vehicle is powered by 1.2V rechargeable battery.
- The Transmitter is powered by 4 x 1.5 V "AA" size batteries.
- The Track Station is powered by 4 x 1.5 V "AA" size batteries.



Battery Installation: Track Station

1. Use a phillips head(Cross-Head) screwdriver to loosen screw in counter-clockwise (pic.1).
2. Insert new "AA" size batteries with "+" & "-" signs as shown(pic.2). Close the battery cover using a phillips head(Cross-Head) screwdriver.





Battery Installation: Transmitter

- Make sure the power switch is on "OFF" position
1. Use a phillips head(Cross-Head) screwdriver to loosen screw in counter-clockwise (pic.3).
 2. Insert new "AA" size batteries with "+" & "-" signs as shown inside battery drawer(pic.4). Close the battery cover using a phillips head(Cross-Head) screwdriver.



Battery Charging: Vehicle

1. Put the vehicle on backboard of transmitter, make sure the charging plate which is assembled in the chassis of vehicle connect the charging wire of transmitter(pic.5).
2. The charging LED indicator will light up which is on the cover of the transmitter(green light).(pic.6)




Remark : The vehicle can be operated up to 3 minutes after about 90 seconds of recharging.

Playing With Your Track Station:

Drive the vehicle into the Track Station slowly ,The charging LED indicator will turn on when the charging plate contact the charging wire. (red LED indicator located under the track).

Note : In order to have accurate contact with the sensor in the Track Station, vehicle should reduce speed while passing through.

Remark : The vehicle can be operated up to 3 minutes after about 90 seconds of recharging.




Driving your X-Terk PRO vehicle

1. Screw the antenna on Transmitter.
2. Set transmitter power button "ON/OFF" to "ON", the LED indicator of power will light up.
3. Set Vehicle power button "ON/OFF" to "ON".
4. Set Transmitter channel as the same as that on vehicle (Note: The channel is the affix of the frequency, such as A, B or C).
5. Pull or push the Transmitter trigger to control your vehicle to go forward and backward. Driving speed depends on the accelerator trigger moving distance.
6. Turn the steering wheel clockwise or counter clockwise to control your vehicle to run right or left. Running radius depend on degree of rotating angle.
7. Steering adjusting: If your vehicle cannot go straight, you can tune the "ST trim" button left or right to adjust it.
8. Initial Speed adjustment: If your vehicle cannot be controlled smoothly, you can tune the "SP trim" button to achieve better performance. To obtain the fastest initial speed, you can adjust the "SP trim" clockwisely to the end.
9. You can press the light button once to enable the side light and press again to turn it off. (Note: It only works for the vehicles with side lights enabled version.)

Note : Turn off the vehicle before you want to change the band in A, B or C channel.

Steering driving:

Accelerator Trigger	Steering Wheel	Action
←□□□	↙	↑ Forward and accelerate
□□□→	↘	↓ Backward and accelerate
←□□□	↙↘	↖ Forward left
←□□□	↘↙	↗ Forward right
□□□→	↙↘	↖ Backward left
□□□→	↘↙	↗ Backward right



Driving Tips:

- The acceleration varies at different trigger position.
- Steering angle varies at different steering wheel position.
- The turning radius may vary at different position combination of trigger and steering wheel.
- Operate only on flat, smooth (but not slippery), dry surfaces and low pile carpet, as hair, carpet or dirt can affect the operation of the vehicle.
- Don't drive your vehicle in sand or through water or snow, if your vehicle get wet, wipe with a towel and allow to dry completely.
- When your vehicle runs erratically, the problem is usually the result of interference caused by high tension wires, radios or other R/C cars running close by on the same frequency as yours. You may have to choose an alternate place to race.
- Do not operate near concrete walls which may disturb transmission.

Trouble Shooting:

Symptom	Cause	Correction
Vehicle does not react, or react poorly to operation by transmitter.	<ul style="list-style-type: none"> • High-frequency interference occurred near to high-voltage lines, transformers and some types of building. • Transmitter and vehicle in different channel 	<ul style="list-style-type: none"> • Avoid these if possible, or choose another place to operate the vehicle. • Set transmitter and vehicle to the same channel through Tri-Band Selector.
Loss of control.	<ul style="list-style-type: none"> • Another radio control vehicle using the same frequency and channel is operated near your vehicle. • Out of the control range of distance. 	<ul style="list-style-type: none"> • Race against other vehicles using different frequencies or channel. • Move to another place where without radio frequency interference from another device. • Ensure the antenna is fully extended. The vehicle runs minimum distance of 10 meters or 30 feet in open space.
Vehicle runs slowly erratically or does not run.	<ul style="list-style-type: none"> • Loose battery connection. • Main power switch is not in "ON" position. • Batteries are not placed in compartment correctly. • Hair, carpet or dirt might be trapped between wheels. 	<ul style="list-style-type: none"> • Check battery connection. • Switch on the power. • Check the battery polarity. • Replace all old batteries with new ones. • Carefully remove such foreign materials.