

EI-1057a Instruction Manual



### CONTENT

- 1:16 Enzo Ferrari
- Transmitter
- 6V Ni-MH Battery Pack
- 9 V battery
- AC/DC Charger
- Instruction manual

### **Key features:**

- Full function radio control vehicle with digital proportional technology
- Tri-band User-selectable at each frequency
- Proportional speed and steering control
- Front and rear wheel suspension
- Real headlight, brake light & signal light

### **Safety Precautions:**

- Parents, this toy is recommended for children. To ensure that your child's play is both safe and fun, please review the
  operating instructions with your children.
- DO NOT pick up moving vehicle
- Keep hands, hair and loose clothing away from the tires and the wheel hubs when power switch is turned ON.
- Remove battery from the toy when not in use
- DO NOT operate your vehicle on street. Avoid hitting people, pets or home furnishings.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Battery Cautions:**

- -Do not recharge the battery if it's hot. Allow it to cool before recharging.
- -Do not charge the battery that shows leakage or corrosion.
- -Do not disassemble the battery.
- -Do not dispose of the batteries in fire.

#### Cautions

- -Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- -Rechargeable battery are only to be charged by an adult.
- Different types of batteries or new and used batteries are not to be mixed.
- -Only batteries of the same or equivalent type as recommended are to be used.
- -Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- -The supply terminals are not to be short-circuited.
- -Do not mix old and new batteries.
- -Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

## Care and Maintenance:

- -Always remove batteries from the toy when it is not being used for a long period of time.
- -Wipe the toy gently with a clean damp cloth.
- -Keep the toy away from direct sunlight and/or direct heat.
- -Do not submerge the toy into water that can damage the electronic assemblies.

### Note:

- -Parental guidance is recommended when installing or replacing batteries.
- -You are advised to recharge the battery pack as soon as the function becomes impaired.
- -Users should keep and retain this information for future reference.
- -Users should keep strict accordance with the instruction manual while operation the product.
- -Under the environment with electrostatic discharge, the sample may malfunction and require user to reset the sample.

#### Special Note to Adults:

-Regularly examine for damage to the plug, enclosure and other parts. In the event of any damage,

the toy must not be used with the power charger until the damage has been repaired.

-This toy is not intended for children under 3 years old. The charger is not a toy.

-This toy must only be used with the recommended charger.

### Note:

-New and alkaline batteries are recommended to use in this toy to obtain best and maximum performance.

#### Battery requirement for Transmitter:

Power Supply : \_\_\_\_\_ Rating : DC : gy Battery : 1 x s

Rating : DC 9 V, 0,135 W
Battery : 1 x 9 V 6LF22 / 6AM6
Requires 1 x 9 V battery (included)

Battery requirement for Vehicle:



Requires 1 x 6 V Ni-MH battery pack & Charger (included)

Sîlverlît®

Silverlit Toys (U.S.A.) 20803 Valley Blvd., Suite #109, Walnut, CA. 91789 ©2005 Silverlit Toys Manufactory Limited. All rights reserved.



#### WEEE

When this appliance is out of use, please remove all batteries and dispose of them separately. Bring electrical appliances to the local collecting points for waste electrical and electronic equipment. Other components can be disposed of in domestic refuse. "This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC."

# ⚠ WARNING:

CHOKING HAZARD - Small parts. Not for Children under 3 years.



## **FCC Statements**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: 1)This device may not cause harmful interference, and

2)This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# **Index to parts**





## 1:16 Enzo Ferrari





■ DIGIT PRO 🗐

Transmitter Battery Cover



# **Getting Started**


### **Batteries:**


- -The 1:16 Enzo Ferrari is powered by 6 V Ni-MH battery pack.
- -The Transmitter is powered by 1 x 9 V battery.

### **Battery Installation: Transmitter**

Make sure the power switch is on "OFF" position

- 1. Pull out the battery cover (pic.1)
- 2. Insert new "9 V" size battery with "+" & "-" signs as shown inside battery compartment.(pic.2) Close the battery cover.







## Battery Installation: 1:16 Enzo Ferrari

Make sure the power switch is on "OFF" position

- 1. Make the "LOCK" turn to open position.(pic.3)
- 2. Insert charged battery pack inside the battery compartment. (pic.4) Then turn the lock to "LOCK" position.






# **Charging Battery Pack:**

The 6 V battery pack has to be charged before being used for the first time, please proceed as follows:

- Rechargeable battery pack are charged under adult supervision.
- Insert the battery pack inside the charger, (pic.5) then plug the charger to the A.C. socket.
- Battery pack must be charged for 6 hours.
- After charging, plug out of the socket and disconnect the charger.(pic.6) The specifications of the utilized unit must be absolutely observed.

Warning: In order to obtain the battery with maximum performance. Do not charge the battery pack over 8 hours.







## Driving your 1:16 Enzo Ferrari:

- 1. Raise the antenna on transmitter.
- 2. Set transmitter power button "ON/OFF" to "ON", the LED indicator will light up.
- 3. Set vehicle power button "ON/OFF" to "ON".
- 4. Set transmitter and vehicle in the same channel (Note: The channel is shown with mark of A, B or C).
- 5. Steer the vehicle by adjusting the control stick of transmitter in different combinations to perform different action.
- Press the light button on transmitter to trigger the lighting.
- 7. You can tune the steering pin on bottom of the vehicle for better forward straightness.(pic.7)



# Steering driving:

Throttle stick	Direction stick	Action
宜		Forward and accelerate
1		Backward and accelerate
宜		Forward left
宜		Forward right
	(2001	Backward left
具	mor'>	Backward right



## **Driving Tips:**

- 1. The acceleration varies at different lever position.
- 2. The turning speed and radius may vary at different lever position combination.
- 3. Don't touch (hold) the antenna of transmitter.
- Operate only on flat, smooth (but not slippery), dry surfaces and low pile carpet, as hair, carpet or dirt can affect the operation of the vehicle.
- For the best result, hold the antenna up, do not point down toward the vehicle.
- Don't drive your vehicle in sand or through water or snow, if your vehicle get wet, wipe with a towel and allow to dry completely.
- 7. When your vehicle runs erratically, the problem is usually the result of interference caused by high tension wires, radios or other R/C cars running close by on the same frequency as yours. You may have to choose an alternate place to race.
- 8. Do not operate near concrete walls which may disturb transmission.

# **Trouble Shooting:**

Symptom	Cause	Correction
Vehicle does not react, or react poorly to operation by transmitter.	High-frequency interference occurred near to high-voltage lines, transformers and some types of building.	- Avoid these if possible, or choose another place to operate the vehicle.
Loss of control.	Another radio control vehicle using the same frequency and channel is operated near your vehicle.      Out of the control range of distance.	Race against other vehicles using different frequencies or channel.     Move to another place where without radio frequency interference from another device.     Ensure the antenna is fully extended. The vehicle runs minimum distance of 20 meters or 60 feet in open space.
Vehicle runs slowly erratically or does not run.	Loose battery connection.     Main power switch is not in "ON" position.     Batteries are not placed in compartment correctly.     Hair, carpet or dirt might be trapped between wheels.	- Check battery connection Switch on the power Check the battery polarity Replace all old batteries with new ones Carefully remove such foreign materials.