


Driving your Vehicle :

1. Set vehicle power switch to "ON".
2. Set transmitter and vehicle to the same channel (Note: The channel is shown with mark of A, B or C).
3. Steer the vehicle by adjusting the joysticks of transmitter in different combinations to perform different action.
4. Press Stunt A button to move the car back and forth.
5. Press Stunt B button to swing the car left and right.

Steering:

Left joystick	Right joystick	Action
↑	↑	Forward
↓	↓	Backward
←	←	Left
→	→	Right
↖	↖	Forward left
↗	↗	Forward right
↙	↙	Backward left
↘	↘	Backward right


**Driving Tips:**

1. The acceleration varies at different joystick position.
2. The turning speed and radius may vary at different joystick position combination.
3. Don't touch (hold) the antenna of transmitter.
4. Operate only on flat, smooth (but not slippery), dry surfaces and low pile carpet. Hair, carpet or dirt can affect the operation of the vehicle.
5. For the best result, hold the antenna up, do not point down toward the vehicle.
6. Don't drive your vehicle in sand or through water or snow, if your vehicle get wet, wipe with a towel and allow to dry completely.
7. When your vehicle runs erratically, the problem is usually the result of interference caused by high tension wires, radios or other R/C toys running close by on the same frequency as yours. You may have to choose an alternate place to race.
8. Do not operate near concrete walls which may disturb transmission.



Trouble Shooting:

Symptom	Cause	Correction
Vehicle does not react, or react poorly to operation by transmitter.	- High-frequency interference occurred near to high-voltage lines, transformers and some types of building. - Channel selection is not correct. - Weak power of transmitter.	- Avoid these if possible, or choose another place to operate the vehicle. - Reset the correct channel. - Change new battery in transmitter.
Loss of control.	- Another radio control vehicle using the same frequency and channel is operated near your vehicle. - Out of the control range of distance.	- Race against other vehicles using different frequencies or channel. - Move to another place where without radio frequency interference from another device. - The vehicle runs minimum distance of 12 meters (40 feet) in open space.
Vehicle runs slowly erratically or does not run.	- Loose battery connection. - Main power switch is not in "ON" position. - Batteries are not installed correctly. - Hair, carpet or dirt might be trapped between wheels.	- Check battery connection. - Switch on the power. - Check the battery polarity. - Carefully remove such foreign materials.

WARNING:
CHOKING HAZARD - Small parts.
Not for Children under 3 years.

**FCC Statements**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Part Identification**Transmitter****Mega Force Truck**

For ages 5+

Delivery contents

- Mega Force Truck
- Transmitter
- Instruction manual
- Traffic cone x 2

Main features:

- Full function radio control vehicle
- Tri-band user-selectable at each frequency

Safety Precautions:

- Parents, this toy is recommended for children. To ensure that your child's play is both safe and fun, please review the operating instructions with your children.
 - Stop the vehicle through the transmitter before picking it up.
 - Keep hands, hair and loose clothing away from the moving parts, e.g. tires and the wheel hubs, when toy is switched on.
 - Always remove batteries from the toy when it is not being used for a long period of time.
 - Do not operate the remote controlled vehicle on streets. Avoid hitting people, pets or home furnishings.
- Warning:** Conversion or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Cautions:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable battery are only to be charged by an adult.
- Different types of batteries or new and used batteries are not to be mixed. (Vehicle only)
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries. (Vehicle only)
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. (Vehicle only)

Care and Maintenance:

- Always remove batteries from the toy when it is not being used for a long period of time.
- Wipe the toy gently with a clean cloth.
- Keep the toy away from direct heat.
- Do not submerge the toy into water that can damage the electronic assemblies.

Note:

- Parental guidance is recommended when installing or replacing batteries.
- You are advised to recharge the battery pack as soon as the function becomes impaired.
- Keep this instruction manual for future reference.
- Users should keep strict accordance with the instruction manual while operation the product.
- Under the environment with electrostatic discharge, the toy may malfunction and require user to reset the toy.

TIPS

New alkaline batteries are recommended to use in this toy to obtain best and maximum performance.

Battery requirement for Transmitter:

- Power Supply : DC 9 V, 1.08 W
- Rating : 1 x 9 V 6LR61 (not included)

Battery requirement for Vehicle:

- Power Supply : DC 6 V, 7.8 W
- Rating : 4 x 1.5 V "AA" LR6/AM3 (not included)

Silverlit Silverlit Toys (U.S.A.) Inc. 20803 Valley Blvd., Suite #109, Walnut, CA. 91789, U.S.A. Tel: 1-800-707-1159
©2010 Silverlit Toys Manufactory Limited. All rights reserved.





MARVEL, Marvel Super Hero Squad, Spider-Man, Iron Man and the distinctive likeness(es) thereof is/are trademark(s) of Marvel Entertainment, Inc. and its subsidiaries, and is/are used with permission. Copyright © 2010 Marvel Entertainment, Inc. and its subsidiaries. Licensed by Marvel Characters B.V. www.marvel.com. All rights reserved.

Getting Started**Batteries:**

- The vehicle is powered by 4 x 1.5 V "AA" size batteries.
- The transmitter is powered by 1 x 9 V battery.

Battery Installation: Transmitter

1. Pull out the battery cover. (P 1)
2. Insert new "9 V" size battery with "+" & "-" signs as shown inside battery compartment. (P 2)
3. Close the battery cover.

**Note:**

When the power indicator on the transmitter starts blinking, replace the batteries.

Battery Installation: Vehicle

Make sure the power switch is on "OFF" position.

1. Use a screwdriver to loosen screw on the battery case in anti-clockwise. (P 3)
2. Before inserting the batteries, lay the ribbon across the battery compartment. Place the batteries above the ribbon. This way the batteries can be easily removed by pulling one end of the ribbon.
3. Put 4 AA size battery in the battery compartment as per the polarity shown inside. (P 4)
4. Tighten the screw in clockwise.

