

SHOCKWAVE



INSTRUCTION MANUAL

Thank you for choosing SKLZ SHOCKWAVE. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to drop us an email (customerservice@sklz.com) or give us a call (**1-877-225-7275**).

BEFORE YOU BEGIN:

- » Read all setup and usage instructions carefully before using. If the setup and/or instructions are not followed correctly, it could result in injury or damage to the product.
- » Adult assembly recommended.
- » Make sure you have all of the SHOCKWAVE components. Please contact SKLZ customer service toll free at **1-877-225-7275** if you are missing anything.

▲ WARNING:

Do not climb or hang on the SHOCKWAVE.

Keep away from fire and heat sources.

Not suitable for children under 3 years of age.

Regularly check for wear and tear. Stop using SHOCKWAVE if any part of it breaks or tears. Failure to do so could result in injury.

SHOCKWAVE is a rebounder and will propel the ball towards the thrower at high speeds. Be sure that the user and observers are safety positioned before using.

The net will be under extreme tension and must be attached carefully. Adult assembly is strongly recommended.

To avoid pinching hazards, keep fingers clear when connecting poles and net hooks during assembly, and push button adjustments on the rear frame.


SHOCKWAVE

SHOCKWAVE IS PERFECT FOR:
» **BASEBALL** » **SOFTBALL**



SHOCKWAVE PARTS:

G NET




H GROUND STAKES (4)



I NET HOOKS



A FEMALE L-SHAPED TUBE (2)



B MALE L-SHAPED TUBE (2)



C CURVED SHAPED TUBE (4)



D FRAME TO LEG CONNECTOR (2)



E FEMALE LEG L-SHAPED TUBE



F MALE LEG L-SHAPED TUBE



LIMITED WARRANTY

REGISTER YOUR PRODUCT AT SKLZ.COM
TO ENSURE WARRANTY
COVERAGE, GET NEW PRODUCT
INFORMATION AND SPECIAL DEALS
FROM SKLZ


Pro Performance Sports (PPS) / SKLZ warrants to the original consumer purchaser of any PPS/SKLZ product it manufactures that the product will be free of defects in materials or workmanship for 90 days (unless specified in alternate warranties) from the date of purchase. If defective and purchased from a retail store, return the product along with receipt to the retail store where the product was purchased. If the item was purchased from PPS/SKLZ, return the product along with the packing slip (proof of purchase) postage prepaid to the address below for replacement consideration. Label: Attn: Returns

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise. Only valid in the USA. All returns sent to PPS/SKLZ require a Return Merchandise Authorization number (RMA). For returns to PPS/SKLZ and for all other Customer Service inquiries, please call toll free, 1-877-225-7275 for a return authorization number for any exchange.

Made in China. ©2012 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports, 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ, SKLZ Pro Grade, SKLZ Chrome and Sport-Brella are registered trademarks of Pro Performance Sports, LLC. Its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.


IDEA SUBMISSION
If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.

SHOCKWAVE ASSEMBLY




STEP 1
LAY OUT FRAME

Lay out all of the frame components as shown in illustration.



STEP 3
ATTACHING THE NET


1. Once the frame is completely assembled, lay the Net (G) out to ensure it will be correctly positioned on the frame.
- NOTE: Before connecting the Net Hooks (I) to the frame, see illustration #2 demonstrating the proper way to attach the Hooks.
2. Identify each corner hex loop. Using 2 hooks attach each corner hex loop to the frame corner. See illustration #2.
3. After each corner of the net is attached to the frame begin attaching the rest of the net. Starting with the top and then move to the bottom of the frame, use the hooks to connect every other hex loop.
4. Once the net is attached to the top and bottom, begin attaching the net to the sides of the frame. Attach each hex loop on the outer edge of the net to the sides of the frame. See illustration #4.



STEP 2
BUILD THE FRAME



Assemble the frame by connecting the male ends to the female ends. Make sure to secure the poles with the push buttons as seen in the illustration.

When assembling the frame, make sure the concave curve is on the top of the frame and convex is on the bottom as shown in the illustration.




STEP 4
GROUND STAKES

Place SHOCKWAVE in the desired location and ensure it is on level ground. Secure frame with included Ground Stakes (H), by utilizing hand, foot or mallet.




SHOCKWAVE USAGE



ADJUSTING THE REAR FRAME ANGLE

Adjust the angle of the rear frame by using the push button on each side of the frame. It is recommended to lay the frame down on it's side when adjusting.



REBOUNING PATTERNS

The unique shape of the net allows for a variety of different throwing and fielding opportunities.

1. By throwing the ball at the top 20% of the net, the player can practice fielding ground balls.
2. By throwing the ball in the middle 60% of the net, the player can practice fielding pop flies.
3. By throwing the ball at the bottom 20% of the net, the player can practice fielding line drives.

Throwing the ball to the outside corner will cause the ball to bounce in an unexpected manner and force the player to react quickly to the misdirected.

Adjusting the net in the lower angle secondary position will provide more pop up practice.

Over time it is normal that the Shockwave net will stretch slightly, reducing the rebound speed. To increase the rebound speed adjust the tension of the net by decreasing the net width by one hex. To do this perform the following steps along one side of the Shockwave:

1. Starting at the top, pull the second net hex loop toward the hook and reattach.
2. Repeat this process with the next hook down until one side of the net has been tightened.

STORE YOUR SHOCKWAVE

To store, press push button on back leg joint to fold the legs onto the frame.
Do not store outside.