




Note :

Product Overview



Additional Information

Limited Warranty

Skypower warrants this Product to be free from defects in material and workmanship at the time of its original purchase by a consumer, and for a subsequent period of one (1) year.

If, during the warranty period, this Product fails to operate under normal use and service, due to improper materials or workmanship, Skypower subsidiaries, authorized distributors or Skypower Service Partners will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein.

Conditions


The warranty is valid only if the original receipt issued to the original purchaser by the dealer, specifying the date of purchase and serial number, is presented with the Product to be repaired or replaced. Skypower reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.

- This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with Skypower's instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, modification or adjustment, acts of God, improper ventilation or damages resulting from liquid.
- This warranty does not cover Product failure due to improper repair installations, modifications or service performed by a non-Skypower Service Partner or opening of the Product by non certified persons.
- THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SKYPOWER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY

Quick Start
Recharging the battery

A high density Li Polymer battery allows you maximum talk time between recharges. To recharge the EZadapt™ - connect the AC/DC adaptor to the socket on the EZadapt™. The LED will light RED continuously until the battery is fully charged. When the LED turns GREEN - the battery is fully charged and you may disconnect the charger. Note: If the LED blinks RED or GREEN (rather than being continuous) - it shows you that the EZadapt™ is ON, ready to receive calls (even while being recharged).

How to fit EZadapt to your phone



Making a call

Press shortly twice button ON. You hear a confirmation tone (low tone followed by high tone). Thereafter -
- If the mobile phone has the feature of voice dialing - simply 'voice dial' as you normally would (but talk to the Headset's microphone rather than the phone's microphone). Alternatively,
- Dial from the mobile phone as you normally would (key-in the number, or dial from phone's memory). When the other party answers - simply talk.
Ending a call
When you finish your call and wish to 'hang-up' - press once button ON. You hear 2 confirmation beeps. Both the Headset and the phone 'hang-up'. IMPORTANT: Do not end the call using the mobile phone button, because in such case the Headset will not 'know' that the call ended, the Bluetooth link will remain active and the batteries of both Headset and EZadapt will be drained fast.
Receiving a call
When an incoming call arrives - you will be alerted by your mobile phone (not by the Headset). To take the call - press twice button ON of the Headset. Wait a few seconds (for the Bluetooth link

to get active), and thereafter talk. **Low battery indication**
When the battery is low and requires recharging, the LED flashes RED (rather than GREEN).

Bluetooth™ Wireless Adaptor

User Guide



Item#: 23011

Table of Content - English

Product Review	2
Introduction	3
Quick Start	4
Recharging the Battery	4
Using EZclip	5
Additional Information	8

NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS, TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damage, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under national legislation in force, nor does it affect the consumer's rights against the dealer arising from their sales/purchase contract.

FCC statement
This device complies with part 15 of FCC rules. Operation is subject to the following two conditions :
(1) this device may not cause harmful interference and
(2) this device must accept any interference received including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by Skypower will void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

All right reserved.
Skypower Wireless Ltd.
Publication number: UG-23011-020926

Introduction

EZadapt™ - Mobile Phone Bluetooth Adaptor
Skypower's Bluetooth Headsets are truly certified Bluetooth V1.1 Headsets. They link to any mobile phone that is truly Bluetooth V1.1 compatible, allowing you full flexibility to choose your own preferred Bluetooth mobile phone.
If your mobile phone does not support Bluetooth - you still can connect Skypower's Headset to the mobile phone by 'Bluetooth-enabling' your mobile phone with Skypower's Bluetooth adaptor - the EZadapt™.
EZadapt™ - connects to almost any¹ mobile phone and at the same time acts as your mobile phone click-on-belt holder.

¹ May require plug adaptor for some models.

Using EZadapt

Pairing - Headset with EZadapt™
'Pairing' is a Bluetooth common term for the simple setup of matching your Headset with your phone, so that your Headset will 'listen' only to your mobile phone (through the EZadapt™), and your mobile phone will 'talk' only to your Headset (and no one else can listen to your conversation).
To pair - proceed as follows:
1. Make sure that both the Headset and EZadapt™ are switched OFF.
2. Press and hold button ON on the Headset for more than 8 sec. At first you see the LED blinking YELLOW, but after about 5 sec it changes to blinking RED and GREEN alternatively. Now release the button.
3. Press and hold the single button on the EZadapt™ for more than 8 sec. At first you see the LED blinking YELLOW, but after about 5 sec it changes to blinking RED and GREEN alternatively. Now release the button.
4. Wait and watch for a few seconds. If the LEDs on both Headset and EZadapt™ change to blinking

green - the pairing is successful, both ready for taking and making calls.

Switch ON
If the EZadapt™ is OFF and you wish to switch it ON - press and hold button ON for about 3 sec. until you see the LED blinking YELLOW. Then release the button.
Now EZadapt™ tries to link with the Bluetooth Headset. If the Headset has been switched on beforehand, and if that Headset and the EZadapt™ were already paired previously - then the Bluetooth link will be established automatically and the LEDs on both Headset and EZadapt™ will blink GREEN. If linking is not successful, the LEDs in both EZadapt™ and Headset continue to blink YELLOW. If after 3 minutes the Headset and EZadapt™ are still unsuccessful to link - each will shut down eventually (to conserve battery).

Switch OFF
Press and hold the button for about 3 sec. until the LED goes off (no more blinking).

Low battery indication
When the battery is low and requires recharging, the LED flashes RED (rather than GREEN).
Lost connection - automatic re-link
If, for whatever reason, the connection between the Headset and EZadapt™ is lost - the LED flashes YELLOW on the EZadapt™. You cannot make or take calls then with your Headset.
Reconnection -
- If the Headset recognizes the lost link (LED on Headset blinks yellow), then simply wait for a short while (no more than 20 seconds) till the link is re-established. Then the LEDs on both EZadapt™ and Headset will blink green (or blink red, if the battery is low).
- If the Headset does not recognize the lost link (LED on Headset still blinks green) - simply switch OFF the Headset, and after a few seconds switch back to ON. Then the LEDs on both EZadapt™ and Headset blink YELLOW at first, and after re-pairing successfully will blink green again (or blink red, if the battery is low).
If no Bluetooth link is restored within 3 minutes, then each the Headset and EZadapt™ shuts OFF automatically.

Important notice! This User Guide is updated to the date of its printing. There may have been new software releases requiring certain changes in the product operation from what is described above. Therefore, in the event that you notice a difference between what the response of the Headset is, compared to what this guide says, then please refer to the most updated User Guide available on our Internet Site - www.skypower.com