



## SonicWALL Internet Security Appliance Regulatory Statement and Safety Instructions

Regulatory Model/Type	Product Name
APL11-027	SOHO TZW (North America)
APL11-031	SOHO TZW (International)
APL10-01F	TELE3 SP (Class B)
APL04-01E	TELE3 TZ and PRO 100 (Class B)
APL11-024	TELE3 TZX (Class B)
APL04-022	TELE3 (Class B) and SOHO3 (Class B)
APL04-016	PRO 100 (Class A)
APL04-017	TELE3 (Class A) and SOHO3 (Class A)
1RK05-015	PRO 200 and PRO 300
1RK07-025	PRO 230
1RK08-026	PRO 330

**Models APL04-016, APL04-017, 1RK05-015, 1RK07-025, and 1RK08-026** are FCC Class A devices (for office use only), and the following statement is applicable to these models\*:

### **FCC Part 15 Class A Notice**

**NOTE:** This equipment was tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. And if not installed and used in accordance with the instruction manual, the device may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user is required to correct the interference at his own expense.

Complies with EN 55022 Class A and CISPR22 Class A.

\*Refer to the label on the bottom of the unit for device information including Class A or Class B FCC information.

**Caution:** *Modifying this equipment or using this equipment for purposes not shown in this manual without the written consent of SonicWALL, Inc. could void the user's authority to operate this equipment.*

## BMSI Statement

警告使用者：  
這是甲類的資訊產品，在居住的環境中使用時，  
可能會造成射頻干擾，在這種情況下，使用者會  
被要求採取某些適當的對策。

## VCCI Statement

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI- A

## Canadian Radio Frequency Emissions Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à toutes la norme NMB-003 du Canada.

## CISPR 22 (En 55022) Class A

**Warning:** *This is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.*

### Declaration of Conformity

Application of council Directive	Directive 89/336/EEC (EMC) and 72/23/EEC (LVD)
Standards to which conformity is declared	EN 55022 (1998) Class A EN 55024 (1998) EN 61000-3-2 (1995) + A1, A2, A14 EN 61000-3-3 (1994) EN 60950 (1992) + A1, A2, A4, A11

National Deviations: AT, AU, BE, CH, CN, CZ,  
DE, DK, FI, FR, GB, GR, HU, IE, IL, IN, IT, JP,  
KR, NL, NO, PL, SE, SG, SI



## Class B Information

**Models APL11-027, APL11-031, APL04-01E, APL10-01F, APL04-022, and APL11-024** are Class B devices (for home and office use), and the following statement is applicable to these models\*:

### **FCC Part 15 Class B Notice**

**NOTE:** This equipment was tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. And, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from the receiver connection.
- Consult SonicWALL for assistance.

Complies with EN55022 Class B and CISPR22 Class B.

\*Refer to the label on the bottom of the unit for device information including Class A or Class B FCC information.

## Canadian Radio Frequency Emissions Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à toutes la norme NMB-003 du Canada.

### **Declaration of Conformity**

<b>Application of council Directive</b>	<b>Directive 89/336/EEC (EMC) and 72/23/EEC (LVD)</b>
<b>Standards to which conformity is declared</b>	<b>EN 55022 (1998) Class B EN 55024 (1998) EN 61000-3-2 (1995) + A1, A2, A14 EN 61000-3-3 (1994) EN 60950 (1992) + A1, A2, A4, A11</b>

National Deviations: AT, AU, BE, CH, CN, CZ,  
DE, DK, FI, FR, GB, GR, HU, IE, IL, IN, IT, JP,  
KR, NL, NO, PL, SE, SG, SI

## VCCI Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。  
取扱説明書に従って正しい取り扱いをして下さい。

## FCC part 68 Telecom Information (Model APL10-01F)

Repair Information - According to the FCC, only the modem vendor for the SonicWALL modem is allowed to service the modem. Contact SonicWALL Technical Support for any repairs including the modem.

The FCC has established rules which permits this device to be directly connected to the telephone network. If this device is malfunctioning, it may also cause harm to the telephone network. This device should be disconnected until the source of the problem is determined and the repair is made. If this is not done, the telephone company may temporarily disconnect service.

The telephone company may make changes in its technical operations and procedures. If such changes affect the compatability or use of this device, the telephone company is required to give adequate notice of the changes. If the telephone company requests information on the equipment connected to their lines, inform them of the following:

- Telephone number of the line connected to the device.
- The Ringer Equivalence Number (REN) located on the bottom of the device.
- The device uses an RJ11-type jack.
- The FCC Registration Number located on the bottom of the device.

## FCC RF Radiation Exposure Statement (Model APL11-027 and Model APL11-031)

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters (7.9 inches) between the radiator(antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For more information regarding the above statement, please contact SonicWALL, Inc. at 1160 Bordeaux Dr., Sunnyvale, CA 94089-1209 or 1-408-745-9600.



## Lithium Battery Warning

### All Models

The Lithium Battery used in the SonicWALL Internet security appliance may not be replaced by the user. The SonicWALL must be returned to a SonicWALL authorized service center for replacement with the same or equivalent type recommended by the manufacturer. If, for any reason, the battery or SonicWALL Internet security appliance must be disposed of, do so following the battery manufacturer's instructions.

## Power Supply Information

### Models APL04-016, APL04-017, APL04-01E, and APL04-022

If the power supply is missing from your SonicWALL product package, please contact SonicWALL Technical Support at 408-752-7819 for a replacement. This product should only be used with a UL listed power supply marked "Class 2" or "LPS", with an output rated 5V DC, minimum 1.5 A.

### Model APL11-027, APL11-031, and APL11-024

If the power supply is missing from your SonicWALL product package, please contact SonicWALL Technical Support at 408-752-7819 for a replacement. This product should only be used with a UL listed power supply marked "Class 2" or "LPS", with an output rated 5V DC, minimum 2.4 A.

## Mounting the SonicWALL PRO 200 , PRO 230, PRO 300, and PRO 330

The SonicWALL PRO 200 and SonicWALL PRO 300 are designed to be mounted in a standard 19-inch rack mount cabinet. The following conditions are required for proper installation:

- Use the mounting hardware recommended by the rack manufacturer and ensure that the rack is adequate for the application.
- Four mounting screws, compatible with the rack design, must be used and hand tightened to ensure secure installation. Choose a mounting location where all four mounting holes line up with those of the mounting bars of the 19-inch rack mount cabinet.
- Mount in a location away from direct sunlight and sources of heat. A maximum ambient temperature of 104° F (40° C) is recommended.
- Route cables away from power lines, fluorescent lighting fixtures, and sources of noise such as radios, transmitters, and broadband amplifiers
- Ensure that no water or excessive moisture can enter the unit.
- Allow unrestricted airflow around the unit and through the vents on the side of the unit. A minimum of 1 inch (25.44mm) clearance is recommended.

## Mounting the SonicWALL SOHO TZW

### Wall Mounting the SOHO TZW

Follow the instructions below to mount the SOHO TZW on the wall.

1. Using the mounting plate as a template, mark the places to insert the mounting anchors.
2. Using a #2 Phillips screw driver, press the tip of the anchor into the marked places on the hollow wall.



3. Turn the screwdriver clockwise until the anchor is flush with the wall. Repeat for the second anchor.



4. Insert a #6 x 1 1/4 pan head Phillips self-tapping screw into each anchor leaving a gap for the mounting plate.



5. Hang the mounting plate on the screws.



6. Slide the plate down to the narrowest part of the keyhole so that the mounting plate rests on the screws.
7. Tighten the mounting screws to secure the mounting plate.



8. Snap the SOHO TZW onto the mounting plate.




## Mounting the SOHO TZW on the Ceiling


1. Locate a metal support to hang the SOHO TZW.
2. Using the mounting plate as a template, mark the places to insert the mounting anchors.
3. Drill two holes for #6 x 1-1/4" screws in the marked location.



4. Install the #6 x 1-1/4" self-tapping screws leaving a slight gap for the mounting plate.



5. Hang the mounting plate on the screws.
6. Slide the plate down to the narrowest part of the keyhole so that the mounting plate rests on the screws.
7. Tighten the mounting screws to secure the mounting plate.








8. Snap the SOHO TZW onto the mounting plate.



### Other Considerations for Mounting the SOHO TZW

- Mount in a location away from direct sunlight and sources of heat. A maximum ambient temperature of 104° F (40° C) is recommended.
- Route cables away from power lines, fluorescent lighting fixtures, and sources of noise such as radios, transmitters, and broadband amplifiers
- Ensure that no water or excessive moisture can enter the unit.
- Allow unrestricted airflow around the unit and through the vents on the side of the unit. A minimum of 1 inch (25.44mm) clearance is recommended.



SonicWALL, Inc.  
1143 Borregas Drive  
Sunnyvale, CA 94089  
Tel: (408) 745-9600  
Fax: (408) 745-9300  
E-mail: [info@sonicwall.com](mailto:info@sonicwall.com)  
Web: [www.sonicwall.com](http://www.sonicwall.com)

P/N 232-000330-03  
Rev A. 4/03

