

Contents

Welcome	4	Calculator	58
Getting to know your phone	5	Converter	59
Phone	25	Time.....	59
Messaging.....	30	Timer	60
Contacts.....	35	Stopwatch	60
Calendar	38	Managing files and applications	60
Lunar calendar	40	PC Suite	62
Web.....	41	Connecting to other devices	63
RSS feeds.....	44	Synchronization and backup	65
Media player	46	Setting up Internet, email and MMS.....	67
PlayNow.....	49	Control panel.....	71
Picture gallery and Picture editor... ..	50	Troubleshooting	89
Sound recorder	53	Important information	89
MusicDJ™.....	54	Guidelines for safe and efficient use.....	89
Games	55	Technical data	97
Quickoffice and Pdf+	55	Index.....	98
Notes	57		
Tasks.....	57		

User Guide

This User Guide is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this User Guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User Guide.

©Sony Ericsson Mobile Communications AB, 2006. All rights reserved.

Publication number: EN/LZT 162 014 R1A

The *Bluetooth*™ trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.

Symbian and all Symbian-based marks and logos are trademarks of Symbian Limited.

Memory Stick Micro™ and M2™ are registered trademarks of Sony corporation.

PlayNow™ and MusicDJ™ are trademarks or registered trademarks of Sony Corporation.

Beatnik is a trademark of Beatnik, Inc.

Opera is a trademark of Opera Software ASA.

Quicksheet, Quickpoint, Quickoffice and Quickword are either trademarks or registered trademarks of Quickoffice, Inc.

Adobe and Acrobat are either trademarks or registered trademarks of Adobe Systems Incorporated in the United States and/or other countries/regions.

Microsoft Outlook, Visual Basic, Windows and PowerPoint are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries/regions.

Apple is a trademark of Apple Corporation, Inc.

Lotus Notes is a trademark of International Business Machines Corporation in the United States, other countries/regions, or both.

This product contains software copyright © Beatnik, Inc. 1996-2002.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries/regions. End-user license agreements are for Sun™ Java™ J2ME™.

1. Restrictions: Software is confidential copyrighted information of Sun and title to all copies is retained by Sun and/or its licensors. Customers shall not modify, decompile, disassemble, decrypt, extract, or otherwise reverse engineer Software. Software may not be leased, assigned, or sublicensed, in whole or in part.

2. Export Regulations: Software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries/regions. The Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software. Software may not be downloaded, or otherwise exported or re-exported (i) into, or to a national or resident of, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (as such listing may be revised from time to time) or any country/region to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nations or the U.S. Commerce Department's Table of Denial Orders.

3. Restricted Rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 252.227-7013(c) (1) (ii) and FAR 52.227-19(c) (2) as applicable.

Copyright © SyncML initiative Ltd. (1999-2002). All rights reserved.

Portions of software © PacketVideo Corporation (USA) 1999, 2002. PacketVideo, pvPlayer and the PacketVideo logo are trademarks of PacketVideo Corporation. All rights reserved.

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

Note Some of the services in this User Guide are not supported by all networks. This also applies to the GSM International Emergency Number 112. Please contact your network operator or service provider if you are in doubt whether you can use a particular service or not.

Note: Sony Ericsson advised users to backup their personal data information.

All illustrations are for illustration only and may not accurately depict the actual phone.

Welcome

Thank you for purchasing the Sony Ericsson M608c, the all-in-one entertainment phone and PDA.

Before you start to use your new phone please read these instructions carefully to enjoy maximum performance and a longer life service.

The *Getting to know your phone* chapter in this User Guide gives a quick overview of the main functions of the phone, shortcuts and general information.

The complete user documentation consists of the following parts:

- **Quick Guide** – the information needed to get you started.
- **User Guide** – an overview of the phone with detailed settings information.
- **Help in the phone** – your phone has built-in help texts. In most applications, **Help** is available in the **More** menu. Some dialogs have specific Help available, for example, those where you can make important settings. The dialog Help is available either as a separate touch option or in the **More** menu.
- **Web Guide** – an up-to-date User Guide available on the Internet on www.sonyericsson.com/cn. You can access this from your computer or the browser on your phone.



This icon indicates that the function is network- or operator-dependent. The service may not always be available in all countries/regions or when you are roaming. Please contact your operator for information.

Getting to know your phone

Package




- A. Phone
- B. Charger
- C. Stereo headset
- D. Battery
- E. USB cable
- F. Memory Stick Micro™ (M2™) inserted in the Memory Stick slot. The Memory Stick contains Try & Buy applications.
- G. CD with Sony Ericsson PC Suite
- H. Documentation package

If your package does not include all the listed items above, please contact your retailer.

M608c

Note: Before you can use your phone you need to insert the SIM card, and insert and charge the battery. Always detach the charger before you insert or remove the SIM card.

Overview



- A. On/Off button
- B. Infrared port
- C. Screen
- D. Dual function keyboard
- E. Memory Stick slot
- F. Shortcut button
- G. Loudspeaker
- H. Antenna connector
- I. Connector for accessories and charger

Getting to know your phone 5


- J. Microphone
- K. Back button
- L. Jog Dial
- M. Stylus

Tip You can use a small screwdriver to remove the plastic cap covering the antenna connector.

Before using your phone

SIM card

You receive your SIM card when you register with a network operator. The SIM card keeps track of your phone number, the services included in your subscription and phonebook information..



Remove the battery (if it is in place) and insert the SIM card into the SIM card holder. A PIN code is supplied with the SIM card and must be entered when switching on the phone for the first time.

IMEI number

To avoid unauthorized use of your phone if it is stolen, keep a copy of your IMEI number to enable a complete barring by your operator. The IMEI number is printed at the bottom of the battery compartment. Enter ***#06#** from the standby view (see *Standby view* on page 9) to display the number.

Battery



To open the battery cover press slightly on the upper part and slide it down the phone. Insert the battery and close the cover.

Charging the battery

You need to charge the battery when the indicator light flashes red. Low battery is also indicated by a message on the screen.

Make sure the battery is inserted, then connect the charger to the phone. Connect the charger to the mains. If the phone is off during charging, the red indicator light will be turned off when the battery is fully charged.

Care instructions

Please take care of your phone and follow this advice:

- Use a moist cloth when you clean the screen.
- Only use the stylus provided, or your fingertips, to tap the screen.
- For detailed care instructions, see *Recommendations for safe use of product (mobile phone, battery, charger and other accessories)* on page 90.

First time start-up

Please read *Guidelines for safe and efficient use* on page 89 before you use your phone.

To switch on your phone press the On/Off button. Select **Phone on** when the Power menu opens.

You will be prompted to select a language. Read more about selecting and installing languages in *Language* on page 88.

Turning the phone on and off

Normal operation

To turn the phone on, press the On/Off button located on the top of your phone. You will be prompted to choose between **Phone on** and **Flight mode**. For normal operation, choose **Phone on**.

To turn the phone off, press the On/Off button and choose **Power off**.

Flight mode

If you choose **Flight mode**, the phone's radio functions are switched off. You can still use the organizer applications.

Use Flight mode where mobile phones are prohibited, such as in hospitals and aircrafts. See *Flight mode* on page 81.


Importing phonebook entries

You can import contact information in several ways:

- Copy phonebook entries stored on your SIM card. See *Copying to and from a SIM card* on page 38.
- Transfer phonebook entries from a computer application using the synchronize function. See *Synchronization and backup* on page 65.
- Beam phonebook entries from another phone using, for example, Bluetooth™ wireless technology. See *Connecting to other devices* on page 63.

The screen

The screen is touch-sensitive. You can use the stylus or your fingertips to select items. Some screen area terms and menus are shown in the figure below:




- A.** Status bar, containing status icons
- B.** Status bar menu
- C.** Application title bar
- D.** Application area
- E.** Button bar
- F.** Touch options bar

Navigation

To navigate menus and select items, you can use the Jog Dial, Back button, stylus, keyboard navigation keys, touch options, and even your fingers.

Jog Dial

Rotate the Jog Dial to scroll lists up and down, adjust sound volume or move through a multimedia message. Press the Jog Dial inwards to select a highlighted item.



Back button

You can use the back button on the side of the phone as follows:

- Press – return to the previous screen or menu, or dismiss the current dialog.
- Press and hold – return to the standby view, or lock and unlock the keyboard from the standby view.

Stylus

You can tap the screen with the stylus to navigate and select items, or to pan multimedia pictures.


Finding the applications

Activity menu

The Activity menu is displayed whenever you switch on your phone, and is the starting point for performing a variety of tasks. The Activity menu is operator-dependent and is described in the *Quick Guide*.


M608c

Standby view

The Activity menu screen also functions as the standby view and will be referred to as the standby view in the rest of the User Guide. The standby view is shown when no application is activated. Through shortcuts you can directly reach the most commonly used applications. You can also select the shortcut  to take you to all the applications in the Main menu.

Status bar

The status bar contains icons that indicate the status of the current settings and activities. See *Status bar icons* on page 12.

Select the Status bar menu  to get access to extra settings.

Main menu

In the Main menu, the applications are categorized under folders, as shown below:

Using the applications


Starting an application

You can either tap the application directly, or rotate the Jog Dial to highlight it and either press the Jog Dial or select **Open**.

Leaving an application


You can leave an application in two ways:

Getting to know your phone 9




- Close it by selecting any of the back keys. All data is saved.
- Leave it open, and switch to another application using Task manager, see *Task manager* on page 10. When you switch back to the application, you will return to the same view you were in when you left it.

Closing an application

From the application base view, tap  or press the back button.


Task manager

Task manager helps you switch between applications. Leaving an application via Task manager rather than closing it, lets you return to the same view when you switch back to the application. This is useful, for example, when cutting and pasting text from one application to another. To open Task manager tap  in the status bar or select **More > Task manager**.

On the **Recent** tab, you can switch to recently used applications, or select **Main menu** and open a new application from there. To switch to an application in the list, tap it or highlight it and select **Switch**.

Advanced features are available on the **Open** tab. This tab contains a list of all running applications, as well as those that are closed but still reserve memory. Highlight an application and select **End** to end the application and free up all the memory used by it. From the Task manager menu, you can sort the applications in the list by time, size or name.

Dual function keyboard

Each key has two characters located on the lower part of the key, and these are accessed by pressing the left or right side of the key. Using  you access the characters or symbols at the top of the key, for example numbers 1-9.

General functionality

Some of the keyboard functionality is applicable in many applications, not just when entering text. To read about the keyboard functionality when entering text, see *Dual function keyboard* on page 17.



or



Use the arrow keys for navigation within the application. Press an arrow key, for example, to:

- Access next or previous tab.
- Scroll through contacts with multiple telephone numbers.
- Delete a single character.
- Delete a highlighted entry from, for example, Contacts, Calendar, Notes or Tasks.



Functionality in standby view

In standby view the keyboard is in number entry mode.



- Press - switch to the phone number entry mode. The entered digit “1” and speed contact, if it exists, is shown in the number entry view.
- Press and hold - initiate a call to voicemail.




- Press - switch to the phone number entry mode. Entered digit and speed contact, if it exists, is shown in the number entry view.
- Press and hold - open the Contacts list.



- Press - switch to the phone number entry mode. The entered digit “0” is shown in the number entry view.
- Press and hold - convert the digit to +.



Press  and **Lock keys/Unlock** - lock or unlock the phone.



















- Press - switch to the phone number entry mode.
- Press and hold - put the phone into silent mode.









Status bar icons

You can tap an icon to get more information or to start an application.

<i>Icon</i>	<i>Function</i>
-------------	-----------------

	Battery strength
	Bluetooth headset connected
	Bluetooth activated
	Divert all calls notification
	Email notification
	Flight mode
	Home network
	Infrared on
	Internet connection active (flashes when data is transferred).
	Keylock activated
	Missed call notification
	MMS notification
	Muted microphone
	Predictive text activated
	Current line selection (Alternate Line Service available on the SIM card)
	Ring volume set to zero

<i>Icon</i>	<i>Function</i>
-------------	-----------------

	Signal strength, GPRS available
	Silent mode
	SMS notification
	SMS overflow
	Speakerphone activated
	Status bar menu
	Task manager
	Voicemail notification

Memory Stick Micro (M2)

There are Try and buy applications that represent a wide variety of business and entertainment applications pre-stored on the supplied Memory Stick Micro™ (M2™). There you also find information on how to buy the applications. You can remove the pre-stored applications from the Memory Stick to free up storage space.

The Memory Stick also provides extra storage space where you can store pictures, music, applications, documents and so forth.




To insert the Memory Stick, open the cover and then insert it into the slot.

To release the Memory Stick, press the edge of the Memory Stick inwards and then release it.

Important: Do not remove a “busy” Memory Stick. This may cause the phone to hang or corrupt the file system on the Memory Stick.

You can rename and format Memory Sticks, and also organize data to and from the Memory Stick. See *File manager* on page 60.



Connecting the included accessories

- A. Connect the USB cable to the base of the phone (to connect, for example, a PC).
- B. Connect the headset and other accessories to the base of the phone, or, when charging your phone, to the bottom of the charger.
- C. Connect the charger to the base of the phone.

Updating software

When an improved software version for your phone is introduced, you can update your phone using the Sony Ericsson Update Service on www.sonyericsson.com/cn. The Web page has further instructions and will guide you through the process.

To run an update, you need a PC with an Internet connection. You also need to have the Sony Ericsson PC Suite installed and a USB connection between your phone and the PC.

Note: *Since the phone will be emptied of all data when updated, you should always make a complete backup of your phone before starting an update, see Backing up data on page 66.*

General functions

Send as

From many applications it is possible to exchange items like appointments, contacts and images. Use the command **Send as** in the **More** menu to choose between the transfer options.

- Bluetooth
- Email
- SMS
- MMS
- Infrared

Zooming

In most applications that handle pictures or text, you can select the **Zoom** option in the **More** menu.

Help in the phone

Your phone has built-in help texts. In most applications, **Help** is available in the **More** menu. Some dialogs have specific Help available, for example, those where you can make important settings. The dialog Help is available either as a separate touch option or in the **More** menu.


Organizing information

Using the Folder menu in the More menu

In some applications you use folders to organize information, for example, your contacts, task entries, notes entries, or RSS feeds.

Note: *These applications have their own specific set of folders. A folder created in one application is not visible in another application.*

- A. More** menu with a **View folder** menu option.




- B. Edit folders.** Select this to - rename, delete or add a new a folder.
- C. Unfiled** folder. Each application has its own default folder, so if you do not create folders of your own, your items will be stored in the **Unfiled** folder.
- D. All** folder. When this is selected, entries from all folders are displayed.
Note: *The All folder in Contacts does not display the entries on the SIM card.*

To display entries from a certain folder you select it in the **View folder** menu.

A new entry is created in the folder that is currently active in the application. You can later move an entry to another folder.

Managing your multimedia files

You can organize your media files directly in the respective multimedia application. The media folders are displayed on two tabs.



- A.** Phone memory tab.
B. Memory Stick tab.


When handling files you can select several files in a folder at the same time. You can also add, rename and delete folders.

Managing your files in File manager

Using File manager, you can handle the content and organization of media, both in the phone memory and on the Memory Stick. See *File manager* on page 60.

Text Entry

There are three ways to enter text in the phone:

- Use the dual function keyboard below the screen.
- Use the virtual keyboard  located in the status bar.
- Write directly on the screen using the stylus.

Editing text

Select **More** to access editing functions like copy, paste and cut text, or if applicable to format text (size, style and alignment).


Copy and cut

To get access to copy or cut functions you must first highlight the text. To highlight text with the stylus, hold the stylus on the end of the text, wait a moment, and then drag the stylus across the text you wish to copy or cut. To highlight text with the keyboard, see *Highlighting text* on page 19.

Text options

When you are editing text, select **More > Text options** to:

- **Add symbol** – launch the symbols and punctuation marks table.
- **Auto capitalization** – switch Auto capitalization on and off.

- **Predictive text** – enable or disable enhanced text prediction,  in the status bar.

When the Predictive text is selected you can also select:

- **My words** – view the user dictionary where you can add, edit or delete words.

Predictive text

You can use enhanced text prediction in all three text entry methods: Keyboard, Virtual keyboard and Handwriting recognition. The primary word or next word prediction suggestion is presented where you are writing, additional suggestions are presented in a pre-edit box at the top of the screen. If you mistype or misspell a word, the pre-edit box may also suggest closely matching words in your selected language dictionaries, words you may have typed previously or items that you have put into your *My words* personal dictionary.

Note: *While entering text, you have the option to either select any of the word suggestions displayed, or to ignore them and continue entering text via your chosen method. If a prediction suggestion is displayed when you are sending or saving the text, this word will not be sent or saved.*

Text entry types

There are four text entry types when you enter latin characters:

- **Abc** – latin characters; initial uppercase letter, the rest lowercase.
- **abc** – latin characters; lowercase entry.
- **ABC** – latin characters; uppercase entry.
- **123** – numeric entry only.


There are three text entry types when you enter characters in Chinese:



- **Pinyin** – Chinese characters; Pinyin input.
- **Stroke** – Chinese characters; Stroke input.
- **123** – numeric entry only.


Dual function keyboard

To input latin characters

When you use the dual function keyboard to enter text, if there are additional characters associated with the pressed character, these will be shown in a pre-edit box in the title area:





If the same character is pressed again, the next character in the pre-edit box will be selected. Press the right side of  to delete the character or spaces to the left of the cursor. Press and hold the right side of  to delete several characters and then whole words.

Press  to enter a character space to the right of the cursor.



Changing input type

You can change your text input type as described in the list below. Icons are displayed in the statusbar to show selected input type.




Aa *First letter upper case*

Press  *once* followed by, for example, the left side of  to write a capital **E**. Any additional keys pressed will be displayed in lowercase.

A *All upper case*

Press  *twice* for caps-lock. Any additional keys pressed will be displayed in uppercase until  is pressed again to remove caps-lock.

12 *First character an upper character*

Press  *once* followed by, for example,  to type the number **3**, or for example, the right side of  to type the character **l**. Any additional keys pressed will display the characters on the lower part of the keys.

123 All upper characters

Press **ALT** twice to lock the characters at the top of the keys. Any additional keys pressed will type the upper characters until **ALT** is pressed again.

Note: Simultaneously pressing **⇧** with a character key will insert an uppercase character. Releasing **⇧** after this action will revert the case to lowercase. The same principle applies when **ALT** and a key is pressed to access a symbol from a key.

To input Chinese characters



A: Element bar: The area to display Pinyin/Stroke input by users when the users want to input Chinese through pinyin/stroke input method. Element bar border can be

adjusted with flush right according to the pinyin/stroke input length.

B: Candidates bar: The area which to display the candidates according to Pinyin input by the users. There are at most nine Chinese single character candidates per row.

C: Display Area: The area which to display the characters.

1. If required, select the desired Chinese text entry method.
2. Input elements; the elements are shown to the right, candidates are shown on top. Refer to the mapping below. Continue inputting elements until the correct character is shown.
3. Rotate the Jog Dial to select the correct character.
4. Press the Jog Dial to confirm the correct character.



Inserting symbols

There are a number of ways to insert symbols with the keyboard.




- Press the left side of the **⌘** or **⌘** keys to show additional symbols in the pre-edit box in the title area.
- Use **ALT** to access the symbols on the keys.

- Select **More > Text options > Add symbol** to open the symbol selector table. Use the Jog Dial to scroll within the table, and select the symbol by pressing the Jog Dial. You can also select a symbol by using the stylus.

Navigating within text


Press  or  for horizontal navigation within text entry.

Highlighting text

Press  and  or  simultaneously to highlight text to the left or the right of the cursor.

Virtual keyboard





- Select this icon to open or close the virtual keyboard.
- Drop down menu. Select  > **Setup** to **Cut, Copy** and **Paste**.

- The current input field. Tap the arrows or rotate the Jog Dial to change the input field.
- To change the language of the virtual keyboard.

To input latin and numeric characters

- Select the button representing the characters to input:



 – Latin characters

 – Numeric characters

- Tap the keys on the keyboard; the text will be displayed simultaneously in the text area.

To input Chinese characters

The M608c has two Chinese input methods:

 Pinyin and  Stroke.

Both methods require that you create a character in two steps.

- Select the button representing the input method: Pinyin or Stroke (the Pinyin keyboard is shown by default).
- Tap one or more components of the character in the character component area. The selected components are shown in the element area, and a group of possible character candidates is shown in the candidates area.
- Tap the desired character in the candidates area. The character appears in the text area and the associated characters are shown in the candidates area.

The more you specify the character - the more input you make - the fewer candidates will be left. If there are more candidates than can be displayed at once, use the next candidate ▼ and the previous candidate ▲ buttons to scroll.



Pinyin keyboard




Stroke keyboard

Handwriting recognition

To input latin and numeric characters

Handwriting recognition translates stylus gestures into letters, numbers or other characters, and displays these characters as text. Handwriting recognition is only active in places where text can be entered.




- Write numbers and symbols above the arrow.
- Write uppercase letters in line with the arrow.
- Write lowercase letters below the arrow.
- Arrow that splits the text mode screen into an upper part and a lower part.

To select icons or buttons, tap and hold them using the stylus.

Note: Most letters can be written using different stroke styles. See the tables below. The position on the screen decides case, not the style.

Letters


Lowercase letters are written below the arrow and uppercase letters in line with the arrow.



Note: Start each stroke at the dotted end.


Numbers

Numbers are written above the arrow.



Note: Start each stroke at the dotted end.

To input Chinese characters

1. If required, select the Chinese input button .
2. Write each letter using one or more strokes, in different parts of the screen, depending on the desired letter:



- Write Chinese characters below the arrow.
- Write numbers above the arrow.

- Select a character in the candidates area.
- The association characters are shown in the association area.

Note: *It is important that the strokes are entered in the correct order, otherwise you may not get the character you want.*

The stroke system has the 33 basic strokes in eight stroke categories. These are:


Stroke	Basic stroke	Stroke name	Character
	丿	Long Left Slope	八九丹凤片
ノ	ノ	Straight Left Slope	香千匕后丢
	丶	Short Left Slope	而页面学殷
一	一	Over	王十在七天
	丨	Lift	海红牡状习
丶	丶	Dot	六学雷心性
㇇	㇇	Right Slope	人火又送林
㇏	㇏	Down-Over	山巨屯母凶
㇑	㇑	Left Slope-Over	么去公约能
㇒	㇒	Left Slope-Dot	女要好巡巢

Stroke	Basic stroke	Stroke name	Character
	㇓	Down Hook	衣以饭收长
	㇔	Right Slope-Hook	我或民成伐
㇕	㇕	Over-Hook	心必思忘
	㇖	Down-Over	四西酉酸
	㇗	Down Over-Hook	电也毛兄孔
	㇘	Down Over-Left Slope	专传转
	㇙	Down Over-Down Hook	马与张号费
	㇚	Down Over-Down	鼎籍
	丨	Down	中业上门丑
丨	丨	Down-Hook	小水打子承
	㇛	Short Slope Down	南直真质草
	㇜	Over-Hook	写字皮通免
	㇝	Over-Down	口已户书骨

Stroke	Basic stroke	Stroke name	Character	Stroke	Basic stroke	Stroke name	Character
	㇇	Over-Down-Hook	力习也同永	乙	1	Over-Down-Over	投沿船凹
	㇈	Over-Left Slope	又之登多社		1	Over-Down-Lift	话计认讯
㇇	㇃	Over-Down-Over-Left Slope	及极廷建	Note: Start each stroke at the dotted end.			
	㇄	Over-Down-Curved Hook	阿队陈那部	Chinese punctuation			
	㇅	Over-Down-Over-Down-Hook	乃透聶隼杨	((”	”
	㇆	Over-Down-Over-Down	凸))	,	,
	㇇	Curved Hook	狗豹家逐狂	¥	1 2 3	.	.
	乙	Over-Down-Hook	乙九瓦飞风	,	1 2	?	?
				:	:	!	!
				“	“	→	→


Note: Start each stroke at the dotted end.

Chinese punctuation



Note: Start each stroke at the dotted end.

Numeric characters



Note: Start each stroke at the dotted end.



Extended characters

To write symbols and characters that are not shown in these tables, please consult the *Extended characters* section of the *Handwriting recognition* help topic in your phone or visit www.sonyericsson.com/cn.

Locks


The phone has four security locks that you can set from the Control panel. See *Locks* on page 86.

Key lock




You can lock and unlock the keyboard if you press and hold the back button on the side of the phone, or if you select  > **Lock keys/Unlock**. Another way to turn on the key lock is to tap  in the status bar and select **Turn on Keylock**.

Sound

Adjusting volume

During phone calls the easiest way to adjust the sound level is to rotate the Jog Dial. When using a Bluetooth headset, you can use either the Jog Dial or the volume control on the headset. If you are playing music, you can adjust the volume with the Jog Dial as long as you are in the play view. However, if you listen to music with the Media player minimized, tap  in the status bar and select **Volume** instead.

Silent mode

In standby view press and hold  to switch between normal and silent mode. You can also select **More > Turn on silent** or tap  in the status bar, select **Volume** and mark **Silent mode**. To exit silent mode via the status bar, tap  and unmark **Silent mode**.

Selecting sounds

Select **☑ > Volume > Settings** from the status bar, or select **Tools > Control panel > Device > Sounds & alerts** to access settings such as ringtones, button clicks and equalizer, see *Sounds & alerts* on page 82. You can also set individual ring signals for your contacts, see *Managing contacts* on page 37.

Transferring sound

During an ongoing call or audio playback you can transfer the sound to a connected accessory, for example, from the speaker to a Bluetooth headset. Open the volume dialog by selecting **☑ > Volume** and then select **More > Transfer sound**. The transfer function is also available from the menus within the relevant applications. It may not be possible to transfer sound during playback of copyright-protected material.

Transferring data between phones

If you are upgrading from an old smartphone, you can transfer data, such as calendar entries and tasks to your new smartphone.

To keep data when replacing an old smartphone

1. Using the old Sony Ericsson PC Suite, synchronize your *old* phone with the relevant computer applications and copy other required files to the computer.
2. Uninstall the old Sony Ericsson PC Suite and restart your computer.
3. Install the new Sony Ericsson PC Suite. For more information, see *Installing PC Suite* on page 63.
4. Using the new Sony Ericsson PC Suite, synchronize your *new* phone with the relevant computer applications and copy other required files to the phone. For more information, see *Synchronization and backup* on page 65.

All data from the old phone has now been transferred to the new one.

Phone

The phone application can be used with other functions of the phone, including applications from outside Sony Ericsson.

Making a call

You can make a call from many of the applications. This chapter mainly describes the Phone application calling options.

Making a call from the Phone application



Open **Phone** and enter the desired phone number. Select **Call**.

Making a call from standby view

When no application is open, you can make a call directly from the keyboard. When you press the number keys, the phone application is launched automatically. Enter the desired number and select **Call**.

Features when dialling

Some features available when dialling a number are:

- **Delete characters** – press  to delete characters.
- **International call prefix** – press and hold  to get the international call prefix.
- **Show/hide ID** – select the **Call and show/hide ID** options in the **More** menu to show or hide your number for the called party. You can only select the option after entering the number but before initiating the call.
- **Speed dial** – press the number key corresponding to your speed contact and select **Call** to make a speed dial call.
- **Send DTMF tones** – press keys on the keyboard if you, for example, are calling a bank. See *Controlling tone-based services* on page 28.

More ways to make a call

Making a call from other applications

You can also make phone calls from other applications, for example from Call log, Contacts and Speed contacts.

Making a call using voice control

Start by activating the voice control function in any of the following ways:

- Say the ‘Magic word’ (only supported when a headset, or a car kit, is attached to the phone). See *Voice control* on page 75.
- Press and hold the call button on a headset, or press the button on a Bluetooth headset.
- Press and hold the Jog Dial from the standby view (also supported when no equipment is attached to the phone).

To make the call, wait for the tone to finish, and then say the voice command linked to the contact you want to call. See *Voice control* on page 29.

Making an emergency call

You can make an emergency call as follows:


- Enter the emergency number from the keyboard. Press the Jog Dial or select **Call**.
- Select a pre-defined SOS number in the **More** menu. Press the Jog Dial or select **Call**.

Usually no SIM card or PIN code is required for emergency calls, but this is something you need to check with your operator.

Receiving a call

Handling an incoming call

You can handle an incoming phone call in several ways:

- **Answer** – select **Yes** or answer by voice control.
- **Send busy** – reject the call by pressing  on the side or by using voice control.
- **Reject with SMS** – reject the call by sending an SMS text message to the caller. Select **More > Send SMS**. See *Reject with SMS* on page 74.
- **Reject and create a reminder** – select **No** to reject the call and choose whether you want to create a reminder to follow up the call at a later date. See *Flag Call* on page 74.

Options during or after a call

You can find the following options in the **More** menu:

- **Mute microphone** – disconnect the microphone after you have answered.
- **Speakerphone on** – transfer the sound to the speakerphone during a call.
- **Show contact** – display the corresponding entry in Contacts, or access DTMF tones sequences stored in Contacts.

- **Add call/Hold call/Retrieve call** – add a call during a call, put the active call on hold, or retrieve a call.
- **Transfer sound** – transfer a call to a Bluetooth or a regular headset, or to the speakerphone. See *Handsfree settings* on page 74.
- **Create task** – create a task in Tasks.
- **Make note** – make a note in Notes. (Call data is automatically entered).
- **Call voicemail** – check the messages in your voicemail box. See *Voicemail* on page 76.

Handling two or more calls


You can handle multiple calls at the same time, as follows:

- Put an ongoing call on hold and start a new one, or answer an incoming call.
- Start a conference call during an ongoing call (operator-dependent).
- Extract one party in a conference call for a private talk and put the conference call on hold.
- Make a call on another line (if you have the ALS service on your SIM card). See *ALS settings* on page 76.
- Retrieve a held call, or release it.

Conference calls

A conference call can be started when you have one active call and one on hold. Select **Start conference call** in the **More** menu to start the call. The maximum number of conference parties is five.

Note: *Conference calls are only available if they are supported by your operator.*



Call log

All your calls are being logged in the application **Call log**. Here you can find call information, such as the type of calls, time, date, phone numbers and call lengths.

You can also make phone calls and call notes directly from this application.

Features

Setting up speed dial numbers

Speed dial numbers are abbreviated numbers, number keys **[M][E][R]** to **[N][M]**, which are used to reach your nine Speed contacts from the keyboard. To set up your Speed contacts, see *Creating a speed contact* on page 37.

Controlling tone-based services

You can use your phone for phone banking services or other tone-based services that use DTMF (Dual Tone Multi Frequency).

You can send tones during a call as follows:

- Press the keyboard keys during an active call.
- Include a tone sequence when dialling.
- Use digit sequences stored in Contacts entries.

Always start a tone sequence with **p** and end it with a space. To include a 3-second pause in a tone sequence, use the letter **p** by pressing and holding **[*][0][*]**. To make it easier to use phone services, you can store tone sequences in fields in Contacts. See *Adding a DTMF tone sequence* on page 37.

Voice control

The voice control option lets you manage calls by using your voice. With Voice answer you can use words recorded for “answer” and “busy” to answer, or to send a busy tone to an incoming call. With Voice dialling, you can make a call by saying the contact’s name. See *Voice control* on page 75.

Calling cards

There are two main types of calling cards: corporate and commercial cards. With a corporate card you can use your phone as a corporate phone, and get access to special services since all your calls pass through a corporate switchboard.

A commercial calling card is either a “real” plastic card, containing number information, or just a phone number provided over the Internet. The calls you make pass through a calling card server, which usually allows you to make international phone calls at a lower cost. See *Calling cards* on page 72.

Business phone services

Your mobile phone can be used in a corporate switchboard. For information about setting up business phone services, see *Business phone services* on page 73.





More features

The following Phone features are also available. These are described in more detail in the Control panel chapter:




- **Accept calls** – set a caller filter.
- **Add to contacts** – add new contact data after a call.
- **Call waiting** – call waiting alert option.
- **Divert calls** – divert calls.
- **Flag call** – follow up a rejected call later.
- **Handsfree settings** – choose how to answer a call with a handsfree kit.
- **Reject with SMS** – send an SMS text message automatically to a rejected caller.
- **Restrict calls** – option to set roaming and international call restrictions.
- **Show or hide number** – option to hide or show your number to the called party.
- **TTY settings** – enable the use of a teletype writer.
- **Voice mail** – this is your “answering machine”.
- **ALS settings** – you can have two lines on the SIM card with this service (network-or-subscription-dependent).
- **Call meter** – keep track of the call costs (network-or-subscription-dependent).

Messaging

You can create, send, and receive different types of messages:

-  SMS (Short Message Service), which are text messages.
-  MMS (Multimedia Message Service), which, for example, can include text, pictures and sound.
-  Email messages.
-  Beamed messages, which are files received via infrared or Bluetooth.

You can also receive these types of messages:

-  Auto setup files for configuring Internet, email and MMS.
-  Area information messages, which are text messages broadcast to all subscribers in a network area, for example, local road reports. (Area information services are not available from all service providers.)
-  Wap push messages, which make certain Internet content available in your phone's browser.

Before using Messaging

Before you can send and receive any messages (except for SMS) you need to set up the necessary accounts. See *Setting up Internet, email and MMS* on page 67, and sections describing SMS and area information setup in *Messaging settings on page 85*. You can also find additional settings in Control panel.

Folders

The different types of messages are handled by different accounts. The default account, **Messaging**, handles all messages except email. Email messages are handled by email accounts you create during setup. All accounts consist of a number of folders. You can also create your own, local, folders.

The following folders are used:


- **Inbox** in Messages – contains all received messages except email messages. In Control panel, you can set how you will be notified when a message is received.
- **Inbox** in an email account – contains the received email messages for that particular account. In Control panel, you can set how you will be notified when a message is received.
- **Outbox** – contains messages ready to be sent. You can move a message from this box to the Drafts folder.

- **Drafts** – contains messages that are not ready to be sent. When you are creating a message, and exit the message before sending it, you will be asked if you want to save it. If you select Yes, the message will automatically be stored in this folder.
- **Sent** – contains messages you have sent.
- **SIM** – a folder located on your SIM card.

You may also find the following types of folders:

- Local folders that you have created yourself.
- Remote email folders on your email server that you have subscribed to (these require that you have selected connection type IMAP during setup).

The figure shows the main view in Messaging:



- A. Shortcuts to call voicemail and to create a new message.
- B. Account for all message types except email.

- C. Folder line. Press or , or select the arrow icon to change folder. Select the folder name to open the folder.
- D. Email account. You can have as many email accounts as you like.
- E. Select **More** to find menu options.
- F. A new message has been received.

SMS

A message can contain up to 160 characters. If you create a longer message it will be sent as two or more separate messages (concatenated), but will usually be received as one message. If you add pictures, sounds and other items to your message it becomes an EMS (Enhanced Message Service) message.

You can answer an SMS with an MMS. You can also receive a delivery report, see *SMS* on page 85.


MMS

Multimedia messages can include pictures, video clips, animations and sound, organized like a slide presentation with time-based control of playback. You can answer with an SMS.

If the sending or receiving of messages is interrupted, the sending or receiving will resume when it is possible, without losing information.

Creating and sending MMS

Select **Create new message > MMS**, or **New > MMS**, if you have opened the Messages account.



- A. Menu options. You can select a template, or select what you want to add to the message. (If the menu is not open, select **Add**.)
- B. Entry field (on the detail tab). Create your message here.
- C. Playback buttons.
- D. New page icon. Select this to open a new page.
- E. Time view icon. Select this to open a view where you can adjust when and for how long your added items will be shown.
- F. Attachments tab. Select this to add attachments. The tab is only visible if **Creation mode** is set to **Free** or **Warning**.)
- G. Address tab. Select this to enter the recipient and other details.

You can edit pictures you have added.

When you are ready, select **More > Send**.

Incoming MMS


Select the new message. The first time you open the message it plays automatically. After that, you have to use the playback buttons to play it. You can forward and reply to a multimedia message.

Email

You can create email messages from each email account.

Creating and sending email

Select **Create new message > your email account**, or **New**, if you have opened an email account.



- A. Address field. Select this to enter the address.
- B. Subject field. Select this to enter the message subject.
- C. Entry field (on the detail tab). Write the message here.
- D. Address tab. You can enter the address here and other details, such as message priority.
- E. Attachments tab. Select this to add attachments.

When you are ready, select **Send**. You will have the option to send the message immediately, or to save it to Outbox.

Receiving email

Email messages must be fetched from the email server on the Internet or at your office. This can be done manually using the **Get & send** option on the More menu or automatically by setting your phone to check for new email at certain times.

If you have a special IMAP account, you have the possibility to automatically receive messages from your server. This service is service provider-dependant.

When you forward an email message, you can choose whether to forward the attachment. Large attachments increase the size of an email and the connection time needed to send it.

You can choose not to receive large messages and only to receive a header.

To view the body of an HTML-mail message with MHTML-formatting select **More > Settings > Display MHTML**. To fit the text to the width of the screen also select **Messaging > Settings > Always fit to screen**.

You will see the priority of the messages in the different inboxes.

To view an attachment you need a viewer for that type of file. Your phone comes with pre-installed viewers for Microsoft® Word®, Excel®, PowerPoint®, and Adobe® Acrobat® files.

Deleting email

You can delete a message both locally and on your email server. When you delete it locally, the message body and attachments are deleted but the heading remains. You can fetch the message again later with the **Get & send** option. When you delete the message on your server, it is deleted both in your phone and on your server.

More about Messaging

Some common messaging and email functions are described below.

Finding messages

In the main Messaging view, select **More > Find message** to search through the subject lines, senders' details and the text of the message. In an open message, **Find** searches through the message.

Get and send

To get and send messages for all your accounts, the default Messages account and all your email accounts, select **More > Get & send** in the main Messaging view. To get and send messages from a specific account, for example an email account, first open the account and then select **More > Get & send**.

Saving contact details

When you receive a message, you can save the contact details of the person who sent the message.


Entering more than one recipient

When you create a message, and want to send it to several recipients, type a comma between each address. You can also add addresses and address lists from Contacts.

Full screen view

You can view and edit your email messages and MMS in full screen view.

Disconnecting from the Internet

Select a connection icon, for example , in the status bar. In Connections manager, select your connection and then **Close connection**.

Email synchronization accounts

With these accounts you can create email messages in your phone and let your computer send them. An account for synchronized email is automatically created in your phone when you set up an email synchronization with your computer. When you have created an email message in your phone, it will automatically be sent by your computer the next time you synchronize.

Invitations

If you receive an invitation to an appointment via an email message, you can choose to accept or decline the appointment using your phone. If you accept, your calendar will be updated automatically. You can also reply to and forward an invitation.

Push email

You can install a push email application on your phone. With push email, email messages received in your ordinary mailbox will automatically be sent to your phone. You can send messages from your phone, and also use Calendar and Contacts as if you were using the ordinary email application in your computer. Please consult your email service provider for further details.

Contacts

Contacts is your personal phonebook where you can store names, phone numbers, email addresses, photos, and other contact information. Information stored on the SIM card is also accessible. SIM card entries can be copied to and from Contacts.

Each entry in Contacts can be viewed in four tabs:



Links tab – contains fields for name, title, photo, phone and pager numbers, emails, and Web pages.



Address tab – contains fields for addresses, birthday, city, postcode, company and job title.



Notes tab – make personal notes for each contact.



Audio tab – set a personal ringtone, and a voice command to be used for voice dialling.

You can handle the contacts in three views:

- List view – shows an alphabetical list of contacts when you open Contacts.
- Detail view – shows the details for a contact.
- Edit view – allows you to add to, and change, the contact's information.


Using contacts

Contacting others

Making a call from Contacts

Scroll to the desired contact and press the Jog Dial to open the entry. Scroll to the desired phone number and press the Jog Dial to make a call.

Sending an SMS or MMS to a contact

To send an SMS or MMS to a contact, you can tap the  icon next to a contact's phone number.

Creating an owner card

You can make your own electronic business card, an *owner card*, which you can send to another device. To make your owner card, create a new contact and enter your details. Then select **More > Settings > Set as My card**.

Service numbers

Some operators have stored their Service numbers on the SIM cards. To find these, select **More > View folder > SIM > More > Service numbers**.

Fixed numbers

This service means that only phone numbers that you have collected in a list on your SIM card can be called. To enable the service, select **More > View folder > SIM > More > Fixed dialling > Fixed numbers**.

My numbers

To store your own phone number, or to display it when stored, select **More > View folder > SIM > More > My numbers**.

Creating and editing contacts


Creating a new contact

Select **More > New contact**. You can also use contact data from a recently received voice call or message. Select **Yes** when you get prompted to add to Contacts.

Tip *If you save your contacts' numbers in the international number format, starting with +, you can call directly from Contacts when you are abroad.*

Editing a contact

Adding a field to a contact

In detail view, select the links tab . Select **More > Add field**. Mark the desired field in the list and select **Add**.


Adding or editing a contact on the SIM card

To open your SIM card, select **More > View folder > SIM**. To add a new contact, select **More > New contact**. To edit a contact, highlight the desired contact and press the Jog Dial. Select **More > Edit contact** and press **Edit**.


Adding a photo or a picture to a contact

To add a stored photo or picture to a contact, open the contact in edit view and select the **Picture** field. Select **More > Select picture**, to choose a picture. Select **Save** to store the picture.

Adding a personal ringtone to a contact

You can store a ringtone for each of your contacts. Select the audio tab  to set the desired ringtone.

Adding a birthday reminder

Select the address tab  and enter the date in the contact's birthday field. You will then get the option to set a birthday reminder in **Calendar**. See *Creating calendar entries* on page 38.

Creating a speed contact

This is a way to speed up your dialling. Select **More > View Folder > Speed Contacts**. Select the one you want to create. Select a contact in the list. Select **Save**.



Note: *Copyright-protection may prevent pictures from being displayed in Speed contacts. See Protected files on page 61.*

Adding a voice dialling command

You can make a call by saying the contact's name, if you have stored a voice command.

Adding a DTMF tone sequence

You can add a DTMF tone sequence to a contact's phone number, or store it in a separate field. Always start the sequence with a **p** and end it with a space. To send tones during a call, open the corresponding Contacts entry and select the desired tone sequence.

See *Controlling tone-based services* on page 28.

Managing contacts

Creating a group of contacts

To create a group, select **More > New group**. Select the contacts that should be included in the group by marking them, and select **Done**. Enter the name of the group and select **Save**.

Copying or deleting a contact

To copy a contact from one folder to another, highlight the contact and select **More > Add to > desired folder**. To delete a contact, highlight it and select **More > Delete**.

Sending an entry

Scroll to the desired contact and select **More > Send as >** sending option, to send the contact's details to another contact.

Copying to and from a SIM card

You can copy contacts from your SIM card to Contacts, and vice versa:

To copy from Contacts to the SIM card

1. Mark the desired entries in Contacts.
2. Select **More > Add to > SIM**.

To copy from the SIM card to Contacts

1. Select **More > View folder > SIM** to open the SIM card.
2. Mark the desired entries.
3. Select **More > Copy to Contacts**.

Calendar

Calendar helps you to keep track of appointments, reminders, all-day events and anniversaries. You can use anniversaries for annual reminders of important dates, such as birthdays or celebrations. You can set reminder alarms for the entries.

You can invite attendees to appointments or all-day events. The invitations are sent via email and when recipients open them in

Messages, they can accept them and add them to Calendar, or decline them.

Note: Before you can invite attendees you must set up your email account in the phone, see *Setting up Internet, email and MMS* on page 67.






Viewing calendar entries

Select **More > Set view** to switch between **Month view** and **Week view**. Tap the right or left arrows above the calendar sheet to scroll.

Select a day that already has entries to display the Day view. It can be displayed with or without empty slots. Select an entry to display the entry details. If you select a day where there are no registered entries, a list is displayed where you can specify a new entry type to create.


To quickly switch to any date in the calendar, select **More > Go to date** (or tap the heading above the sheet).

Creating calendar entries

Select **Calendar > New** and then one of the entry types: Appointment , Reminder , All-day event  or Anniversary . You can add comments on the  tab.

Note: *In Contacts, if you enter a contact's birthday, you have the possibility to create a birthday anniversary entry at the same time. See Editing a contact on page 36.*

Invitations

If the entry is an appointment or an all-day event you can invite others to the appointment on the  tab. You invite attendees by entering their email addresses.


Recipients will get invitations which they can accept or decline. If accepted the current calendar application (for example Calendar or Outlook) is updated. An invitation receipt will be generated.

Note: *An invitation receipt from an attendee will be received as a normal email.*

To see if an invitation is accepted open the invitation details and select **Response status** in the **More** menu.

Managing calendar entries

You can search for a certain entry by entering a search text. You can delete a single entry or all entries in a defined period of time. You can copy entries from one date to another in Calendar and move entries to Tasks. You can send an entry or a whole category of calendar entries to other devices, see *Send as* on page 14.

Note: *If you select the note tab , you can mark a calendar entry as **Private** in the **More** menu. Such entries are excluded when sending.*

Managing received invitations

You might receive invitations to appointments when you are fetching email messages from the email server. You have the possibility to accept or decline the invitations and if you accept Calendar is updated automatically. See *Email* on page 32.

Synchronization and backup

You can synchronize Calendar with a corresponding application in your computer. You can also perform a remote synchronization over the telephone network. Select **More > Calendar manager > Synchronize**, see *Remote synchronization* on page 67.

Note: *Information about which folders you use to organize the entries will not be synchronized.*

As a complement to the “normal” Backup application, see *Backing up data* on page 66, you can backup calendar entries on the Memory Stick. Select **More > Calendar manager > Back up**.

Settings

You can, for example, set default values for the alarm, Day view and the duration of appointments. Select **More > Settings > Alarm & display**.

Note: *By specifying the first day of your week you can change the display of both Week and Month. Select **Tools > Control panel > Device > Time & date > More > Set workdays**.*

Lunar calendar

You can look up the Lunar Calendar correspondence for a specified date ranging from January 1 1901 to December 31 2100, where the current day is highlighted in red and public holidays are displayed in red fonts.

To use the Lunar Calendar

- **Click the button in the left of the Month** - Shows the previous month within the current year; and displays information for December of last year if it were January currently.

- **Click the button in the right of the Month** - Shows the next month within the current year; and displays information for January of the following year if it were December currently.
- **Click the Month** - Displays the list of months.
- **Click the button in the left of the Year** - Shows the information for the current month of last year.
- **Click the button in the right of the Year** - Shows the information for the current month of next year.
- **Click the Year** - Displays the list of years.

You can also use Jog Dial for some operations:

- When the Year / Month list appears, rotate **Jog Dial up or down** and then **Jog Dial inwards** to select the desired year or month.

Web


The integrated Opera 8 browser is the entry-point to the Internet in your phone. It supports both frames and JavaScript™.

You can easily switch from portrait to landscape view, and change from normal to full screen presentation. The browser can fit the contents of the page to the width of the screen.

You can save pages to view them offline.

The browser has separate download managers for files that need secure download and for other files. The secure downloads manager is especially useful for downloading commercial media objects.

You can set up the browser to block pop-ups.

The browser can provide a secure encrypted link to the Web site. The  icon in the context bar of the browser window shows when a secure connection is established.

Note: Before you can use the Web application to access the Internet you must set up your Internet accounts in the phone, see *Setting up accounts on page 68*.


The browser can remember a username-password pair that you enter when you log in to a site so that you can use it the next time you log in.

M608c

Working with pages














Select **Multimedia > Web** to open the browser.

- A Sony Ericsson homepage is shown if no page has been set remotely.



- A.** Page icons are shown in the context bar. The icons change when the page has finished loading.
 - Tap to switch page.
 - Tap and hold for a menu of options for the current page. Select **Close page** to close a page.
 - B.** Select the **New** touch option to open a Web page. **Back** and **Stop** are also shown as touch options when appropriate.
 - C.** Select **More** to find menu options.
 - D.** Progress bar, shows the loading progress.
- Navigation is quick and simple:
- For keyboard shortcuts to menu and navigation options press:



Web 41

	and then one of the following keys to:
	Open a Web page.
	Open the bookmarks list.
	Close the current page.
	Go to the homepage.
	Switch between loading and not loading pictures.
	Switch between normal and Full screen display.
	Switch to the next page.
	Open the Configuration menu.
	Add a bookmark for the current page.
	Find (on the Internet or on the current page).
	Stop or Reload the current page.
	Go to the top or bottom of the page.



- Select a link or a bookmark to navigate.
- Tap and hold a link to open a menu of options based on the type of link.
 - If the link is to an RSS feed (see *RSS feeds* on page 44) RSS Feeds opens so that you can subscribe to the feed.

- Use the Jog Dial to scroll a page up or down. Links will be highlighted as you scroll.
- When you want to log in to a site and the username and password fields are highlighted, you can select the touch option **Log in** to use the username-password pair you saved earlier.
- When not in text mode you can slide a page up or down, left or right, with the stylus.
- To change the zoom level select **More > Zoom**, rotate the Jog Dial and then select **Save**.

Working with bookmarks

To open the list of bookmarks select **More > Bookmarks** ( ). Select an entry in the list to open it.

When you highlight a bookmark in the list you can use options on the Bookmarks list **More** menu to delete it, edit it, or set it to always open the bookmark in a new page.

To add a bookmark for the current page, select **More > Current page > Add to bookmarks** ( 

Working with text

To be able to select text on a page, select **More > Settings** and mark **Select text mode**. Select **More > Edit** for text editing options on the selected text.

Settings menu

Select **More > Settings** to find options that you may want to change while working with pages. You can switch the Fit to screen, Full screen, and Landscape modes on or off. You can also select text mode.

Views menu

Select **More > Views** to open list views where you can work with saved pages, history or downloads.

Saving pages

You can save the current page to open it later offline. Select **More > Current page > Save page** to save the page.

Select **More > Views > Saved pages** to see a list of your saved pages. You can open a page in the list, delete it or rename it.

Using the History list

To open a page you have visited earlier select **More > Views > History**. A list is displayed allowing you to view the details and open the page.




Downloading

When you select a download link in the browser and accept the download you will see a new entry in the appropriate download list: **Downloads** or **Secure downloads**.

You can pause and resume the download if required (if the server supports this).

There is no notification when a download has been completed. Return to the appropriate list view to check the status of your downloads. Select **More > Views > Downloads** or **Secure downloads** to return.

Configuring the browser

Select **More > Settings > Configuration** (  ) to open a dialog where you can change the browser's configuration settings.

On the **General** tab you can choose to:

- Add or delete prefixes and suffixes to the list that the browser uses when it suggests a Web address.
- Enable or disable JavaScript. Disabling JavaScript can make pages load faster, but some pages may not function properly.
- Enable the browsers pop-up blocking feature.

On the **Display** tab you can choose to:

- Load and display pictures or not. Pages will load faster if you do not display pictures. You can change the setting at any time by pressing **[ALT] [G5H]**. Switch off the presentation of animations.
- Enable or disable plug-ins.

On the **Advanced** tab you can choose to:

- Allow cookies.
- Configure the cache handling. You can choose cache size as well as have the cache emptied every time you disconnect.
- Delete all cookies.
- Set the browser to show a warning dialog before submitting a form over an insecure Internet connection.
- Enable using the keypad keys as WAP/html access keys. This will disable using them as menu option shortcuts.

To delete private data

Select **More > Settings > Delete private data** to open a dialog where you can mark check boxes to delete:

- All history data (includes internal security data and the list of previously entered Web addresses).
- The contents of the cache.
- All cookies.
- All username-password pairs that you have stored.

RSS feeds

RSS provides a way for Web sites to distribute their content outside of a Web browser. A news Web site might have an RSS feed which contains breaking stories, while a magazine Web site may provide an RSS feed with excerpts of their latest articles.

Note: *Before you can use the RSS feeds application you must set up your Internet accounts in the phone, see Setting up accounts on page 68.*

Subscribing to RSS feeds


To add an RSS feed to your application select **Multimedia > RSS feeds > More > Add feed** and enter the Web address of a feed.

Tip *An easy way to subscribe to a new feed is to navigate to an RSS/XML link in the Web browser. Select the link and the Add feed dialog is opened with the Web address of the feed already entered.*

Reading news items

When you start the application a list of your subscribed RSS feeds is displayed.

- A.** Title of a subscribed RSS feed and time of last update.



- B.** Numbers that appear in parentheses indicate unread feeds.
- C.** Feeds with new news items are displayed in bold.

Select the RSS feed you are interested in to display the news items list. Then select a news item headline to display the full headline and description.



- A.** Move backwards and forwards between the news items.
- B.** Launch more details about the news story in the Web browser by selecting **More > Read more**.

Updating feeds

You can update feeds manually or by scheduled updates. Select **Update** when the feeds list is displayed to update all feeds at the same time.

When the news item list of a certain feed is displayed you can select **Update** to update the current feed.

To schedule the updates you select **More > Settings > Schedule updates**. You can choose to update the feeds by time or by interval. When the feeds are updated automatically a status bar icon **RSS** appears. Tapping the status bar icon launches the RSS application.

Settings

Select **More > Settings > RSS options** to access the following:

- **Save items for** – set how long the items should be saved.
- **Internet account** – set the Internet connection to be used.

Tip Set the Internet account to the same connection as the Web browser.

Media player

With Media player, you can play music and video clips that are stored on your phone. You can also receive streaming video and music from the Internet. For a list of supported media formats, see *Technical data* on page 97.

Music

Note: *Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed by the file name.*

Select **Media player > Music**. The first time you open Music, select **More > Update music** to search the phone memory and the Memory Stick for sound files. This process may take a while, especially if you have a high capacity Memory Stick with a lot of sound files. You can select if this update should be performed automatically each time you open the Media player, or if you want to do it manually. If you select to do it manually, the command **Update music** will be available in the **More** menu. You can also select which types of sound files an update should search for. See *Preferences* on page 47.

All tracks, including those that do not contain any album or artist information, can be found under **Tracks**.

My recordings contain clips that you have recorded with Sound recorder. To further organize your music files, you can create **Playlists**.

Playlists

A playlist is simply a list of links to some of your music files, and it describes which songs to play and in which order. This also means that when you remove a track from a playlist, the sound file itself is not deleted.

A playlist can contain links to tracks both in the phone and on a Memory Stick, and you can add a track to more than one playlist.

Playlists can be moved or copied between the phone memory and a Memory Stick using the File manager. The playlists that you create on the phone are stored in `\Music\playlists`.

To create a playlist

Open **Playlists** and select **New Playlist**.


To add tracks to a playlist

Select **More > Manage > Add to playlist**.

You can add several tracks at once. See *Manage tracks* on page 47.

Playback


To start playback, select an album, artist, playlist or individual track and press the Jog Dial or select **Play**. You can also tap on an individual track to play it.

To pause playback press the Jog Dial, tap  or select the **Pause**.



Tap and drag the progress indicator to move within a track.

When playback is paused, rotating the Jog Dial will browse the tracks from the current playlist, album or artist.

You can leave the Media player but continue to listen to music by selecting **More > Minimize**. Playback will also continue when you switch to another application via Task manager.

To return to Music, tap  in the status bar, or open it via Main menu or Task manager.

Adjust volume and tone

If you are in the playback view, rotate the Jog Dial to adjust volume directly. Otherwise, select  > **Volume**. You can further adjust the sound by selecting **More > Settings > Equalizer** or by tapping .

Manage tracks

If you want to select several tracks at once, scroll to one of the tracks and select **More > Manage > Mark**. You can now select additional tracks by tapping the check boxes.

Within a category, you can sort tracks in different ways.

Preferences

Select **More > Settings > Preferences** to access the following options:

Play

- **Shuffle** – the tracks in a playlist, album or artist are shuffled randomly before playback begins.
- **Loop** – restart the playlist when the last track has been played.
- **Resume audio** – this setting determines how playback should resume after it has been interrupted by, for example, an incoming phone call. **Automatic** means playback resumes automatically when you have finished the call. **Manual** requires that you switch back to Media player and resume playback from there.

Files

- **File update** – select if you want the media player to automatically search for new sound files each time you open Media player, or if you want to do this manually.

- **Filter files** – set a filter to exclude small files or file types with low sound quality from the search. Ringtones and other sounds that are stored in the `\Music\sounds` folder are always excluded.
- **Full update** – a normal update only searches for new sound files. A full update will rebuild the tracks list and look for changes made to existing files, for example, new artist and album information.

Video

Note: *Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed by the file name.*

You can watch clips stored on your phone or Memory Stick as well as streaming video from Internet.

To play a video clip



1. Select **Media player > Video**
2. Navigate to the clip you want to watch.
3. Tap the clip, select **Play** or press the Jog Dial to start playback.

To play streaming video

Provided you have an Internet account set up, you can also watch video streams from the Internet. Select **More > Manage > Open URL** and enter the address to the streaming content. You can save shortcuts to streaming content. These will be stored in the Online folder that you see when you open the Media player.

Playback controls

Rotate the Jog Dial to adjust the sound level.

Tap  to pause playback. Tap  to resume playback.

Tap the playback area or select **More > Expand** to switch to full screen view.

Tap on the progress bar or tap and drag the progress indicator to move backwards and forwards within the clip.

When playback is paused, tap the arrows in the playback area, or rotate the Jog Dial, to select another clip in the current folder.

Playback options

In playback view, select **More > Playback options** to access the following settings:

- **Continuous play** – play all clips in the current folder.
- **Loop** – keep repeating the current clip.

Manage clips

Select how the clips are sorted in **More > Preferences**.

To move, copy, delete or rename clips, select **More > Manage**.

Settings

In playback view, select **More > Settings** to access the following options:

Display tab

- **Default view** – select if you want video clips to open in portrait or landscape view.
- **Size** – video clips intended for larger displays will always be scaled down to fit within the screen of the phone. If you select **Fit to screen**, videos that are smaller than the phone's screen will also be stretched to use as much of the screen as possible, without changing the aspect ratio.

Buffering tab

- **Media buffer** – controls the amount of data that is saved before playback of a stream begins. Normally you would use the default setting. Selecting a higher setting can improve playback, at the expense of higher memory usage.
- **Cache** – cache memory is used to temporarily store streaming video so that data does not have to be downloaded again if you rewind and watch a clip again. Select **Clear cache** to free up memory.

Proxy tab

Use the Internet settings unless you have instructions from, for example, your operator or company IT department to use manual configuration.

Online

Online contains the streaming media links that you have saved from within Video or Music. Media links may also have been preloaded by your operator. Select a link and tap **Open link**, or select **More > New link** and enter the Web address. You must enter the full path to the streaming content.

PlayNow

With PlayNow™ you can download top music hits, videos, games and pictures to your phone. You can then set downloaded files as alarm signals, ringtones, wallpapers, and screen savers, or add them to your contacts.

All content of the PlayNow service is available on a Web page that is updated regularly by Sony Music Entertainment. Before deciding to purchase, you can preview most of the content.

Note: Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed by the file name.


Before using PlayNow

Before you can use PlayNow, ensure that you have the following:

- A phone subscription that supports GPRS.
- An Internet account and the correct settings in your phone, see *Setting up Internet, email and MMS* on page 67.
- Free memory in your phone.

To preview content

1. To open PlayNow, select **Multimedia > PlayNow™**.
2. Select the Web link you wish to preview. The content is downloaded to your phone and images and ringtones can be previewed.

Tip You can return to the PlayNow start page from wherever you are in the PlayNow website by pressing .

To purchase content


1. If you wish to purchase the content, select **Yes**. Your phone bill or prepay phone card will be charged by your network operator, and you will receive a text message confirming that the item is paid for and made available. The content is automatically saved to the folder for that media type.
2. Depending on the type of file, you will be asked whether you wish to install, play or use it now. Select **Yes** and then choose how to use it.

Picture gallery and Picture editor

Picture gallery

In Picture gallery you can view, send and organize all the pictures saved in your phone's internal and external memory. You can do any of the following:


- Send the pictures to others (using MMS messaging or Send as).
- Add pictures to the contacts in your phonebook.
- Use a picture as a background image (wallpaper) or screen saver.
- Show a series of pictures in a slide show.



You can also start Picture editor from Picture gallery in order to edit a picture.

To open Picture gallery select **Main menu > Multimedia > Picture gallery**.

- A. Select one of two tabs and see either the folders and pictures stored on the Memory Stick or those stored internally on the phone.
- B. Rotate the Jog Dial to move through folders and files in the list. To open a detail view of a picture highlighted in the list, select **View**.
- C. Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed.

- D.  – send a highlighted picture by MMS messaging. This is also available in the detail view of a picture.
- E. Select **More** to find menu options.
- F. The list can be sorted by name, size, type, or date, in ascending or descending order. Select **More > Sort by** to change the sorting.

Options for using picture files

You will find options for using pictures under **More > Use**.


Options for managing picture files

Select **More > Manage files** for a menu with options for managing selected files and folders. From this menu you can:

- Open Picture editor to create a new picture.
- Create a new folder.
- Copy, move, rename and delete files.
- Copy or move (Import and Export) camera pictures (EXIF type .jpg files) to and from a folder on a Memory Stick and an internal folder.
- Open **File manager**. For more information, see *File manager* on page 60.

Detail view


Highlight and select a picture in the list to show the detail view. Select **Expand** to go to full screen.

Mark **Zoom** in the More menu to enable zoom. (If the picture is expanded, tap  to open the More menu.) Rotate the Jog Dial to change the zoom level. The Zoom indicator thumbnail shows the part of the whole picture that is shown zoomed. You can move the thumbnail to pan. Unmark **Zoom** to disable zoom.

Slide shows

You can show the contents of a folder as a slide show, moving from picture to picture automatically or manually. Slide shows can have an accompanying sound track and you can choose from different transition styles between the pictures.

Sending pictures using MMS messaging

To send selected pictures as well as a picture in detail view using MMS messaging, select .

Picture editor

The editor can be started from Picture gallery, and Messaging.












Using **Picture editor**, you can crop, rotate and resize images. You can add fun layers such as clipart and frames. There are tools for drawing on the image using the stylus with different pen sizes and colours available, as well as a text tool for formatting and inserting text into the image. There are a number of filters for effects and picture correction.

When you create MMS messages, you use **Picture editor** for editing inserted images with .jpg, .png, .gif and .bmp file extensions as well as for creating simple .jpg images from scratch.

- A. When you select a mode in the tool bar the set of available tools changes.



- B. Select **More** to find menu options.
C. The set of available tools changes according to the mode:

-  **Scribble** – set the pen width with , choose colour with the colour palette  or the colour dropper .
-  **Select rectangle** – fix red-eye removal , copy a selected part of the picture , or crop the picture .
-  **Zoom** – zoom in  or zoom out .

Correcting images

Select **More > Correction** to adjust the brightness, contrast, intensity, or colour balance of a picture. Colour balance is adjusted automatically, use the Jog Dial to adjust the others.

Zoom mode

The Zoom indicator thumbnail view shows the part of the whole picture that is shown zoomed. You can use the stylus to drag the picture on the screen. You can capture the visible part of the picture: select **More > Edit > Crop**.

Editing options

Select **More > Edit** for a menu of editing options. You can rotate, mirror or flip a picture, paste the contents of the clipboard into the picture, and resize it for different uses such as MMS image or as wallpaper. You can undo your changes.

Adding clipart, text or frames

Select **More > Add** to add clipart, formatted text or a frame to a picture. Frames are applied to the whole picture.

Adding effects

Select **More > Effects** to filter a picture.

For some of the filters you can adjust the level of the effect.

Preferences

Select **More > Preferences** to set the size, background colour and quality (**Good**, **Medium** or **High** - this will affect the file size) for new pictures that you create with **Picture editor**.

Sound recorder

Select **Multimedia > Sound recorder**.

Tip You can assign the shortcut button to launch the Sound recorder and to start and stop recording. See **Hardware button on page 81**.

Record

To start a new recording, scroll to **New recording** and press the Jog Dial or tap **Rec**. Recording starts after the beep.

You can also continue previous recordings. Scroll to the desired clip and select **Rec**. Recording will resume at the end of the previously recorded material.

Press **Stop** when you are finished recording.

Playback

Scroll to the desired clip and select **Play**.
Rotate the Jog Dial to adjust the playback volume.

Manage recordings

On the **More** menu you find commands to rename, send and delete recordings.

All recordings that you make with the Sound recorder are also available in **Media player** under **Music > My recordings**.

Tip You can use recordings as ringtones.

Preferences

Select **More > Preferences**. You can choose where to save your recordings. **Memory Stick preferred** means that the recordings are saved on the Memory Stick if one is inserted. Otherwise the recordings will be stored on the phone memory.

MusicDJ™

With MusicDJ™ you can compose melodies to use as ringtones.

A melody consists of four tracks: Drums, Bass, Chords and Accents. You compose the melody by adding prearranged sound samples to the tracks. Each sample is one bar



long. The samples are grouped into Intro, Verse, Chorus and Break.

To compose a melody

1. Select **Entertainment > MusicDJ™**.
2. Select **More > Set tempo** and adjust the tempo of the melody in beats per minute (BPM).
3. Tap a bar in one of the tracks and select a sample to insert. You can also copy and paste samples between bars.

Use the transport bar to play, pause, stop, fast forward or rewind. When composing you can also move between bars by rotating the Jog Dial, or selecting **More > Go to** and entering the numbers of the desired track and bar.

From the **More** menu you can also save, open and send melodies. When you save a melody, you can also select to use it as ringtone.

Games

Your phone comes with two games preloaded in the **Entertainment** folder.

Vijay Singh Pro Golf 2005™ is a 3D game that lets you play golf on one of the most spectacular 18-hole golf courses on the American circuit, the Harbour Town Golf Links at Seapines Resort. The game has a built-in tutorial.

Quadrupop is a puzzle game. Select **Entertainment > Quadrupop > Help** to learn more.

Quickoffice and Pdf+

Quickoffice™ and Pdf+ are found in the Office folder. With Quickoffice you can view and edit Microsoft Word, Excel and

PowerPoint documents as well as text documents. With Pdf+ you can view Adobe Acrobat (PDF) documents.

Quickoffice

In Quickoffice you can see a list of all the Quickoffice or text documents in a folder. Use the tabs to display a list of a certain Quickoffice document type. Use the **Phone memory** menu to switch between phone memory and Memory Stick. You can sort, move, copy and delete documents, and create and delete folders.

Select **View** to specify how to view the document.

Quickword

To create a new Quickword™ document, select **Office > Quickoffice > More > New > Quickword**. Enter the name and location of the new document. You can save documents in Word (.doc) or text (.txt) format.

When you open existing documents you need to select **More > Edit** to enable editing. To save a document after making changes, tap **Save**.

Quicksheet

To create a new Quicksheet™ document, select **Office > Quickoffice > More > New > Quicksheet**.

There are two toolbars available in Quicksheet, the Edit toolbar and the Format toolbar. A quick way to enable the Edit toolbar is to double tap a spreadsheet cell.

To save a spreadsheet after making changes, tap **Save**.

Quickpoint

You can use Quickpoint™ to view Microsoft PowerPoint presentations and to edit text in them, but you cannot create new presentations in Quickpoint.

Quickpoint contains three different views of a slide presentation: Slide, Notes and Outline view.

Pdf+

In Pdf+ you use the two tabs on the top to switch between phone memory and Memory Stick.

In an open PDF document you can control the viewing from the selection keys at the bottom of the screen.

Next

Displays the next part of the screen. If you have selected **More > Display > Column mode** the top of the next column of a page will be displayed. A column is defined as the width of the screen.

More > Bookmarks

Displays the Bookmarks view if the document contains bookmarks. Select a heading to go to the corresponding page. You can also use the Jog Dial to select a bookmark, and then use the button below to go to the corresponding page.

Follow

Takes you to the selected page.

More > Go back

Returns you to the page view.

More > Display > Full screen

Full screen.





To return to the normal view, select the menu icon and unmark the **Full screen** check box.


- More > Display > Wrap** Wraps the document. The text fits the screen, but images and line drawings are not visible.
- Find** Displays the **Find** dialog.
- Full screen menu > Next link** Goes to the next link in the document.

Notes





Notes is a notebook where you can write notes and draw sketches. You can separate notes into different folders, for example work and personal notes.

Creating and managing notes

Select **Office > Notes > New**. A notes entry consists of two tabs,  tab for text and  tab for sketches.

When you create a note, use **a** to make the text bold and  to make a bulleted list. The first words of your notes are displayed in your list of notes.



Drawing sketches


Select the  tab and use your stylus as a pen to draw sketches. Set the pen width with  and choose the colour with the colour palette . Tap  to change to an eraser. Tap the eraser a second time to go back to the pen.

Tasks

With Tasks you can make a list of things you need to do. You can separate task entries into different folders, for example, work and personal activities.

Creating and managing task entries

Select **Office > Tasks > New**. A task entry consists of two tabs,  tab for details about the task and  tab for notes.

Note: *If you select the  tab, you can mark a task as **Private** in the **More** menu. Such entries are excluded when they are sent as messages.*

Synchronization and backup

You can synchronize Tasks with a corresponding application in your computer. You can also perform a remote synchronization over the telephone network. Select **Tasks manager > Synchronize**, see *Remote synchronization* on page 67.

Note: *The Folders will not be synchronized.*

As a complement to the “normal” Backup application (see *Backing up data* on page 66) you can back up task entries on the Memory Stick. Select **Tasks manager > Backup**.

Calculator

With Calculator you can add, subtract, multiply, divide and calculate square roots and percentages. It also has a memory function.

Select **Tools > Calculator**. All calculations, except percentage calculations, are performed in the order they are entered, for example: $5+5 \times 5=50$, not 30.


Percentage calculations are performed backwards. To calculate, for example, 10% of 50, enter $50 \times 10\%$. The result is displayed when you tap the %-key.

Key Functionality

MR Tap once to retrieve a value from the memory and enter it into the screen.
Tap twice to clear the memory.

M+ Tap once to store an entered value in the memory.
If you have already entered a value in the memory, tap once to add the value on the screen to the value in the memory.

M- Tap once to subtract the entered value from the value in the memory. The memory is adjusted but not displayed.

 Tap once to delete the last digit you entered.

C Tap once to reset the screen to 0.

Converter

With Converter you can convert different values of the following categories; Distances, Volumes, Weights, Temperatures, Speeds, Areas and Currencies.

You can add further currencies to the list of currencies to convert and you can enter the exchange rate of different currencies.

Converting units of measurement

If you, for example, want to convert distances from kilometers to nautical miles, you select **Tools > Converter > Distances**, and then the **Metric** tab where you enter the value. Select **Convert** and then the **Nautical** tab to see the result.

Setting converter decimals

You can set the number of decimals for all categories, select **Decimals** in the menu bar.

Converting currencies

Select **Tools > Converter > Currencies** and select the *convert from* and *convert to* currencies from the currency list. Enter the amount of the currency you want to convert and select **Convert**.

Entering exchange rates

The default exchange rates in Converter are set to 0. You have to enter the current rates manually.

Select **More > Exchange rate** to enter the current exchange rate for a currency for example Japanese yen in US Dollars.

Adding currencies

When the phone is delivered Converter contains a few commonly used currencies. Select **More > Add currency** menu to add further currencies and their exchange rates to the currency list.

Time

Select **Tools > Control panel > Device > Time & date** to set the time and date. For more information, see *Time & date* on page 84.

Setting alarms

You can set three different alarms in your phone. You can choose to activate one of the preset alarms, or set a new alarm with your own definitions.

To set a new alarm, tap one of the alarm slots. You can specify when and how often the alarm will go off.

You have two possibilities for what happens when an alarm goes off:

- A sound is played. Choose between one of the sounds stored in your phone.
- A silent alarm. A message is displayed on the screen.

If you select **Default melody**, the settings from **Tools > Control panel > Device > Sounds & alerts > Alarms** will be used.

Alarms require that the phone is turned on.

When the alarm goes off you can select **Snooze** to postpone the alarm for five minutes or **More > Silence** to turn off the alarm. To turn off the alarm completely, tap **Done**.

Timer

Use **Tools > Timer** if you need to be reminded within a certain amount of time. The Timer application is hidden until the time has passed. Select **Continue** to stop the alarm.



Stopwatch

Use **Tools > Stopwatch** if you want to measure how long time an event takes.

If you select **New lap** you can measure the time individually for nine separate events, for example a lap in a race or individual contestants in a race.

Managing files and applications

File manager

File manager is used to manage content and organize media, both within the phone memory and on Memory Sticks. The File manager view is displayed in two tabs;  tab for the phone memory and  tab for the Memory Stick.

Protected files

Downloaded or received files may be copyright-protected. Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed by the file name.

Handling files and folders

With File manager you can view, rename, copy, move and delete files and folders. Select **Tools > File manager**.

Note: *Install applications and other content you use often, for example, ringtones in the phone memory since the Memory Stick is sometimes unavailable when the phone is connected to a computer.*

Many operations in File manager can also be launched from **Tools > Control panel > Other**.

Sharing data with other devices

Your phone creates its own folder structure on the Memory Stick. Other devices must access the same folder structure to interact with your phone files. On a computer you can browse to the required folder on the Memory Stick. With a device that does not allow you to browse folders (for example, a camera) you use File manager to put the required file into a folder accessible by that device.

M608c

Launching media files

You can launch media files direct from File manager by selecting them.

Renaming a Memory Stick

You can rename a Memory Stick to give it a name that is meaningful to you. This name will be shown in the folders menu. Select **Tools > File manager > More > Device > Format Memory Stick > Rename**.

Formatting a Memory Stick

New Memory Sticks are normally formatted the first time they are inserted in a phone.

Note: *Do not remove a Memory Stick during formatting, which may take some time.*

Select **Tools > File manager > More > Device > Format Memory Stick > Format**.

Note: *All information on the Memory Stick will be deleted during formatting.*

Installing applications

You can install the following two types of applications in your phone:

- Applications specifically intended for your phone or compatible with the Symbian operating system. These installation files have the extension .SIS.

Managing files and applications 61

- Java applications compatible with the Symbian operating system. These installation files have the extension .jar or .jad.

Install an application by selecting **Tools > File manager > More > Device > Install**. Select the required application and select **Details** to view information about the certificate. If the signature details are OK, select **Install** and follow the instructions in the phone. The application will be installed in **Tools** folder. You can move it to another folder if you desire.

Note: *Only install applications where the vendor identity and file integrity can be verified. To be sure that a certificate has not been revoked, you can select **Security**, mark **Enable revocation check** and enter the **URL-address** where the certificate can be checked.*

Removing applications

It is sometimes necessary to remove installed applications to free up storage space.

Select **Tools > File manager > More > Device > Uninstall**. Confirm with **Yes**.

Storage wizard

The **Low on storage space** dialog is displayed when your phone has no more storage space available to save or store information. From that dialog you can start Storage wizard to clean up storage space by removing unwanted applications and files.

Whenever required you can also launch Storage wizard from **Tools > File manager > More > Device > Storage wizard** or from **Tools > Control Panel > Device > Storage wizard**.

Note: *Before you clean up storage space, make sure you have a backup copy of information that is important to you.*

PC Suite

Note: *If you are replacing an old smartphone and want to keep data, see **Transferring data between phones** on page 25.*

The **Sony Ericsson PC Suite** is a set of computer software tools delivered with your phone. These tools can be used for a variety of tasks, including:

- Synchronizing, for example, contacts, email, and calendar events between the phone and a computer.
- Backing up phone data to a computer and restoring data to the phone from a backup on the computer.
- Installing new software and languages in the phone.
- Connecting a computer to the Internet via the phone.
- Managing phone files from a computer and exchanging files between the phone and the computer.

For further information on synchronizing, making backups, and restoring from backups, see *Synchronization and backup* on page 65.

Installing PC Suite

Note: *Make sure that no Sony Ericsson equipment is connected to your computer when starting the installation.*

Install the Sony Ericsson PC Suite on your computer by inserting the supplied CD. The installation normally starts automatically, otherwise you can start it by executing the **start.exe** file located on the CD.

Note: *The Sony Ericsson PC Suite CD contains several applications. It does not matter in which order you install them, unless otherwise stated during the installation.*

You can also download the Sony Ericsson PC Suite from www.sonyericsson.com/cn.

Application launcher

The individual applications in the Sony Ericsson PC Suite are started from an application launcher. To reach this, select **Start > Programs > Sony Ericsson > Sony Ericsson PC Suite for Smartphones**.

A connection to the phone can be made using Bluetooth, the infrared port, or the USB cable. Some applications may require a specific connection to be used. For example, Sony Disc2Phone and Adobe Photoshop Album SE both require a USB connection, with the **File transfer** setting, in order to work.

Connecting to other devices

When you want to exchange information between your phone and another device, connect them together using Bluetooth, an infrared link, or a USB cable.

With such a connection you can, for example:

- Send a file (a picture, for example) to a computer or to another phone.
- Use a Bluetooth headset in a phone call.
- Synchronize calendar events and contacts with the corresponding data on a computer.
- Back up phone data onto a computer.
- Use your phone as a computer modem.

For more information on synchronizing and making backups, see *Synchronization and backup* on page 65.

Bluetooth wireless technology

The Bluetooth™ wireless technology uses radio waves to connect devices at a range of up to ten metres.

See *Bluetooth wireless technology* on page 77 for information on how to make the Bluetooth settings.

Sending and receiving files

From any application with a **Send as** option, you can send a file via Bluetooth without first having to pair with the receiving device. To send a file, select **Send as > Bluetooth** in the **More** menu and your phone will search for available devices. Select one of them.

If another Bluetooth device sends an item to your phone, a dialog may appear (operator-

dependent) with options for accepting or rejecting the file transfer. When the transfer is complete, select the file name and choose where to store the file. If the device is paired with your phone, you can mark **Trust this device** to allow it to connect with your phone again in the future without confirmation.

Infrared port

When you connect your phone to another device using an infrared link, the ports of both devices have to be within one metre from each other, in line of sight, and at an angle of no more than about 30 degrees.

See *Infrared port* on page 78 for information on how to activate the infrared port.

WARNING! *Never point an active infrared port at somebody's eye, or at the port of other infrared devices than the one you are connecting to.*

Sending and receiving files

From any application with a **Send as** option, you can send a file over the infrared port. To send a file, select **Send as > IR** in the **More** menu.

When the transfer of a file sent to your phone is complete, select the file name and choose where to store the file.

USB port

With a USB (Universal Serial Bus) cable, you can connect your phone to the USB port of another device.

See *USB* on page 79 for information on how to make the USB settings.

Note: *Before connecting the USB cable to a computer, install the Sony Ericsson PC Suite on the computer.*

USB connection, with the **Phone mode** setting, is required for phone data backup to a computer and for restoring data from a backup.

USB connection, with the **File transfer** setting, is required when using the Sony Disc2Phone and Adobe Photoshop Album SE computer applications to transfer music and image files respectively to and from the phone.

Note: *During data transfer over USB, do not change the USB settings or disconnect the phone from the other device as this may cause a data loss.*

Charging battery over USB

When your phone is connected to, for example, a computer over a USB connection you can select to simultaneously charge the phone's battery.

M608c

Note: *For battery charging from a USB hub, only use a hub with its own power supply.*

Connections manager

Connections manager lets you view and close all open Internet connections and view the logs for both open and closed connections.

Select **Tools > Connections mgr** to display the connections and the logs.

To view the details about a connection or a log, select the connection or the log. If you, for example, want to reset a log, mark it and select the appropriate option in the **More** menu.

Computer modem

Through the Sony Ericsson PC Suite, a computer can use your phone as a modem for connecting to the Internet.

Synchronization and backup

The Sony Ericsson PC Suite lets you synchronize your phone with common computer applications (local synchronization) and make backups of data.

Synchronization and backup 65


Without using the Sony Ericsson PC Suite you can synchronize your phone over a mobile network with a remote server (remote synchronization).

Tip For calendar and task entries there is another backup possibility — to copy these to and from the Memory Stick. See *Synchronization and backup on page 39* and *Synchronization and backup on page 58* respectively for more information.

Local synchronization


Local synchronization is between your phone and a connected computer. Email, contacts, calendar events, tasks, notes (text only), and browser bookmarks can be synchronized this way.

Note: The Sony Ericsson PC Suite must be installed on the computer and the chosen connection method must have been set up in the phone, see *Connections on page 77*.



To synchronize, connect your phone to the computer using a USB, Bluetooth or infrared connection.

Note: If you are using a USB connection, select the **Phone mode** setting.

On the computer, select **Start > Programs > Sony Ericsson > Sony Ericsson PC Suite for Smartphones** to open the Sony Ericsson PC Suite. Select the Sync Manager icon .

Synchronization settings

In the **Sync Manager** window, select **Settings** to define what is to be synchronized and how.

Starting synchronization

In the **Sync Manager** window, select **Synchronize now** to start synchronizing. After each synchronization, you can view the results by displaying the summary.

Backing up data

Use the Sony Ericsson PC Suite to make backups of phone data. Your backups are stored on the computer and can later be restored to the phone. Make backups on a regular basis, and always before having the phone upgraded since upgrading clears all the user data.

Note: Even copyright-protected files are included when backing up data, but the access keys to such files are not. If you, for example, make a Master Reset after a backup you will lose any access keys. You will then have to reorder these keys (and pay for them once again) to be able to use the files.

Restoring data

To restore phone data, select **Backup Manager** as when making a backup, but select the restore option instead. You can restore data manually or have a wizard assist you.

Important: All the phone data is overwritten during the restore process. You may damage your phone if you interrupt the process.

Remote synchronization

Remote synchronization is between your phone and a synchronization server on the Internet or an intranet. This is a way to keep your phone synchronized while on the move. To set up and start remote synchronization, go to **Tools > Remote sync**.

Synchronization services may be offered by mobile operators, third-party service providers or as added capability to corporate applications for personal information management (PIM). Typically, calendar



events, tasks, contacts, email, browser bookmarks, and notes (text only) can be synchronized remotely.

Setting up Internet, email and MMS

With your phone you can access the Internet, send and receive email, and send and receive MMS messages. To do this you need to set up Internet accounts.

Setting up accounts automatically

A convenient way of setting up an account is to ask your service provider to send you an auto setup message. Contact your service provider to find out if such a service is available. You can also visit www.sonyericsson.com/cn where you find setup wizards that can configure accounts with many of the major service providers.

You will find the auto setup messages in **Messaging > Messages > Inbox**. To start an auto setup, select the message and follow the instructions on the screen.

Setting up accounts

You access the Internet using an Internet Service provider (ISP). You need to set up an Internet account to do any of the following:

- Access the Internet.
- Send and receive email messages.
- Send and receive MMS messages.
- Set up and use a Virtual Private Network (VPN).

There are three types of Internet accounts:

- **Data** – uses a packet data connection, on a GSM/GPRS network. You are charged for the amount of data you download or send.

- **Dial up (CSD or HSCSD)** – establishes a circuit-switched data connection. You are charged for the length of time you are connected to the Internet.
- **Bluetooth PAN** – uses a Bluetooth Personal Area Network profile to connect to a device (for example a computer) that is connected to the Internet.

You can create new accounts automatically or manually. The Internet account may already be set up when you buy the phone.

Before setting up

From your service provider, you should have received all the details about the accounts that you have to enter, for example the email account name and password.

Setting up Internet manually

To enter the details manually, or to edit an existing account, select **Tools > Control panel > Connections > Internet accounts**.

Setting up email manually

Before you make the email settings you must have a connection to the Internet, see *Setting up accounts* on page 68.

The email account you wish to set up must support the POP3 or IMAP protocol for receiving email, and the standard SMTP protocol for sending email.

Web-based email services cannot be handled by Messaging. Use the Internet browser to access such services.

To enter the details manually, or to edit an existing account, select **Tools > Control panel > Messaging settings > Email accounts**.

The Email accounts view displays a list of email accounts on your phone. You can add a new account to the list and delete an account. To edit an existing account, select it and make your changes.

Select **More > Preferred account** to select your preferred email account. This account is used when you select **Send as > email** from within an application.

Select **More > New account** to open the dialog used for email settings. You make the settings on three different tabs, and also dialogs you open from the **More** menu.

From your email service provider, you should have received all details about your account which you now have to enter.

Basic tab

Account name – give the account a name for your own reference, for example Home or Office.

Your name – enter the name you want to appear on your outgoing messages.

Email address – this is your email address as supplied by your email service provider. The address always contains the @ character.

Connection type – POP3 and IMAP are connection protocols used when receiving email from the email server. POP3 is the most common. IMAP has expanded functionality, for example, it makes it possible to subscribe to server-based folders. Ask your email service provider which protocol they support.

Allow IMAP idle – if you have an IMAP account, your phone can check for new messages in your mailbox on the server. If there are new messages, these will be sent to your phone.

Inbox tab

Incoming server address – enter the name or IP address of your email service provider's server for incoming email messages. This address identifies the computer where your incoming email messages are stored. Common formats are *pop.example.org* and *123.123.123.123*.

Username, Password – your email service provider supplies you with a username and password for your email account.

Download restrictions – select this to set rules for how messages shall be downloaded and how many messages can be stored in your inbox. If you want to limit the data traffic, you can choose to receive **Just headers** (the sender, subject, and date only) or set a size limit, **Emails smaller than** (if a message is larger than the limit, only the headers are downloaded). You will be prompted to download the rest of a message when you open it.

Smaller than – enter the message size limit, if you have selected **Emails smaller than** above.

Limit number of messages – select this to limit the total number of messages held in your inbox in your phone at any one time. If your inbox is full and you download a new message, the oldest message in your inbox will be removed from your phone. Note, that the message header will remain in the phone, and the whole message will remain on the server.

Limit is set to – enter a limit for messages in your inbox, if you have selected **Limit number of messages** above.

Receive using group – select which Internet group account you want to use to connect to the email server for incoming email messages. If you select **Preferred group**, the phone will use the preferred Internet group account.

Outbox tab

Outgoing server address – enter the name or IP address of your email service provider's server for outgoing email messages (SMTP server). This address identifies the computer through which your outgoing messages are sent. Common formats are *smtpt.example.org* and 123.123.123.123.

Use SMTP authentication – some SMTP servers require authentication also when sending email. If so, mark this check box and enter your **Username** and **Password**.

Use Inbox login details – if the SMTP server accepts using your **Inbox** login information for authentication, mark this check box.

Send using group – select which Internet group account you want to use to connect to the email server for outgoing email messages. If you select **Preferred group** – the phone will use the preferred Internet group account.

Select *your email account* > **More**> **Schedule downloads** to set up automatic downloading of messages.

Schedule download

Schedule download – mark and select either **By interval** and select download intervals between 1 minute and 999 minutes, or **By time** and specify up to three downloads a day.

Note: If you schedule downloads, you should normally also unmark **Show connection dialog** in **Tools > Control panel > Connections > Internet accounts > More > Options**. Otherwise each scheduled download will stop at the **Connect to Internet** dialog and wait until you select **Connect**.

Select your email account > **More > Advanced** to make additional settings.

Advanced – **Incoming** tab

Secure socket – your ISP will tell you if you can use a **Secure socket** or **Secure password authentication** (see below). A secure socket means that all information (including your username, password, and all messages) is encrypted to maximize security while you are connected to the Internet.

Incoming mail port – normally 110 for POP3 servers and 143 for IMAP servers. Use the default value unless your email service provider specifies something else.

Secure password authentication – in contrast to **Secure socket** (see above), secure password means that only your password is encrypted.

Advanced – **Outgoing** tab

Secure socket – see the **Incoming** tab above.

Outgoing mail port – normally 25. Use port 25 unless your email service provider specifies something else.

Use MIME encoding – MIME encoding is a standard that allows non-textual information (for example graphics) and accented characters to be sent in email messages.

Setting up MMS manually

To set up MMS manually, first create an Internet account for MMS, and then proceed with the actual MMS settings. To edit existing MMS accounts, follow the same procedure.

Control panel

Tools > Control panel is the location for all the main settings on your phone that are system-wide and often affect more than one application. This is where you go to initially set up your phone, and to change the settings at any point after that.

Note: Some settings can be locked or hidden by your operator.

Call settings

Accept calls

Select **Tools > Control panel > Call settings > Accept calls** to specify who should be able to reach you, and who should not, by setting the accepted callers.

Controls tab

Specify whether your phone should reply by sending busy signal or by hanging up.

Accept calls from menu

All callers – everyone calling you can reach you.

Listed callers only – only persons (phone numbers) that you have entered in the accepted callers list can reach you.

Contacts – only persons in your Contacts phonebook can reach you.

Speed dial – only contacts from your Speed contacts can reach you.

No-one – no one can reach you.

List tab

Make a list of accepted callers. Select **Add** and then select from **Contacts**, or enter a name and a number.

Add to Contacts

Select **Tools > Control panel > Call settings > Add to Contacts** and mark the check box if you want to be asked to save a new contact every time a new number is used or received.

Calling cards

With a calling card account, your calls go via a calling card server. This means that your phone can act as a corporate telephone. Since your calls will then go through a private company switchboard, PABX features, services such as conference calls, will be available.

Select **Tools > Control panel > Call settings > Calling cards** to make the settings.

Enter the phone lock code (the default phone lock code is 0000) and make the following settings:

- **Calling card mode** – select how to use the selected calling card.
- **Calling cards** – a list of your calling cards.
- **Active card** – set the active calling card.

Please consult your calling card supplier for more details.

Creating a new calling card

Select **New** and enter the following account information.

Access tab

Name – enter a name for the calling card account.

Access number – enter the phone number of the calling card server.

Verification code – enter the verification code.

International prefix – enter the international prefix used by the server.

Set up tab

Sending order – select if the phone number or verification code should be sent first.

Delay for number/code – set the time the phone should wait before it sends the number or code.


Use direct access number – if marked, you are allowed to use a direct access number, if the calling card is a PBX type.

Business phone services

You can set up business phone services by importing a .pbx configuration file that you receive from your Telephony/IT department.

To set up business phone services

1. Create a folder called **Calling cards** in the **Document** folder of your phone or Memory Stick and copy the .pbx configuration file to that folder.
2. Select **Tools > Control panel > Call settings > Calling cards > Import**.
3. Select the .pbx file you want to import and tap **Import**.
4. Activate the card by setting the Calling Card Mode to **Call directly, Always use calling card** or **Prompt before call**.

The calling card icon  will now be visible in the status bar. The .pbx file may be set up so that you can send commands to the switchboard by tapping the calling card icon.

Call waiting

You can choose if you want the phone to alert you when you receive an incoming call during an ongoing call.

Select **Tools > Control panel > Call settings > Call waiting** and set this option to **On/Off**.

If ALS (two lines on the SIM card) is available, you can set this option to **On/Off** on two separate voice lines.

The settings are made in the network. Select **More > Refresh** to receive the current settings.

Divert calls

The phone can divert incoming calls (voice and data & fax calls) to another number if you are busy, not reachable or do not reply. You can also choose to divert all calls.

Select **Tools > Control panel > Call settings > Divert calls** and choose which type of calls that should be diverted and then where to divert them.

Divert options

Lookup in contacts – select an entry from the Contacts phonebook.

Enter number – enter a phone number to be used for diverting calls.

Off – your incoming calls will not be diverted.

All the divert settings are made in the network. Select **More > Refresh** to receive the current settings.

Flag Call

Select **Tools > Control panel > Call settings > Flag call** to enable the feature. If the feature is enabled and you reject a call, you will be asked to set up a reminder to follow it up after a predefined delay that you can choose.

Handsfree settings

Select **Tools > Control panel > Call settings > Handsfree** to set how to answer to an incoming call when handsfree equipment is connected.

Answering mode

Normal – answer calls as normal.

Any key – press any key on the keyboard to answer.

After 5 seconds – the phone answers automatically after five seconds.

Always route answered calls to Bluetooth – mark the check box to route answered calls to a Bluetooth headset.

Reject with SMS

If for some reason you want to reject a call, for example during a meeting, you can set up the phone to send an SMS with a predefined message to the calling party.

Select **Tools > Control panel > Call settings > Reject with SMS** to make the settings. When the feature is enabled and you reject a call, you will be asked whether you want to send an SMS text message.

Restrict calls

This feature allows you to enable or disable certain types of calls, for example international calls. You need a special PIN code from your operator to make the settings in **Tools > Control panel > Call settings > Restrict calls**.

Show or hide number

You can choose whether you want the called party to see your phone number. Select **Tools > Control panel > Call settings > Show or hide number** to make the settings. Marked **Network default** leaves the decision to the network.



TTY Settings

You can enable the use of a teletype writer; an aid for deaf and speech-impaired people. Connect the TTY device to the accessories connector at the base of the phone.


Voice control

You can dial and receive calls by using voice commands. Select **Tools > Control panel > Call settings > Voice control** to make the settings.

Recording voice commands

Before you can make any settings in this dialog, you must previously have recorded the voice command words for *answer*, *busy*, and the *magic word*.

The magic word is a word you must say before the command words, so that the phone “starts listening” for the command. Choose a long unusual word, which can easily be distinguished from ordinary background speech.

Select **More > Edit > Record** to record a highlighted voice command. Select **More > Edit > Play** to listen to a highlighted command. The icon  next to a word indicates that a voice command has been recorded and stored.

Voice control settings

Portable handsfree – voice control, with a handsfree kit connected.

Portable car – voice control, with a car kit connected.

Voice answer – answer by voice control (recorded words for “answer” and “busy”).

Play caller name – the phone plays the recorded name of the calling party, if it is stored in Contacts.

Voice mail

Select **Tools > Control panel > Call settings > Voicemail** and enter the number your phone will call to access the voicemail server. Your voicemail is a service provided by your operator, and works as your private “answering machine”.

ALS settings

ALS (Alternate Line Service) means that you have two separate lines (two phone numbers) on your SIM card.

Call meter

Select **Control panel > Call settings > Call meter** to make the Call meter settings.

This service (also called Advice of Charge, or AoC, by some operators) makes it possible to:

- Keep track of the cost of calls.
- Automatically stop outgoing chargeable calls, if a certain credit limit has been exceeded.

Call meter has two tabs, **Credit** and **Tariff**.

Credit tab

Your setting options on this tab are:

- **Limited credit** – if you mark the check box, all your outgoing chargeable calls will be stopped if the set credit limit has been exceeded. Unmarked check box means unlimited credit, and the call cost is displayed on the screen during a call.
- **Remaining credit** – you can edit this field and set a credit limit. If a credit limit is set, the remaining credit is displayed on the screen during a call.

Tariff tab

Your setting options on this tab are:

- **Display cost in** – select **Currency** or **Units**.
- **Tariff** – set a number between 0.01 and 9999999.
- **Currency** – select the currency type (three letter code).

To be saved, the settings must be followed by the entry of a valid PIN 2 code, provided by your network operator.

Note: *The Call meter service does not work if you have roamed to a network that does not provide charging information.*

Connections

The connection settings control how your phone communicates with other devices.

Bluetooth wireless technology

Select **Tools > Control panel > Connections > Bluetooth** to make the Bluetooth settings and connect to other Bluetooth devices.

Note: *Only connect to trusted devices.*

For all tasks, except for a single file transfer, it is necessary to set up a permanent and trusted relationship between your phone and the other device. This is called pairing (or bonding). Paired devices are remembered by your phone so you do not need to pair with these again. This simplifies future connections and makes them secure, as paired devices have already authenticated each other.

Settings tab

This is where you make all the Bluetooth settings of your phone.

My phone name – enter the name you want to be displayed when your phone is presented to other Bluetooth devices.

Bluetooth on – activates Bluetooth.

Visible to other devices – makes it possible for other Bluetooth devices to find your phone.

Enable power saving – saves power by limiting the activity of your phone. Your phone will no longer accept requests for additional connections from other Bluetooth devices after a Bluetooth connection has been established, but it will still be able to discover other Bluetooth devices and request connections to them.

Devices tab

This is where all devices that your phone has already paired with are listed, even if they are not within reach and Bluetooth-activated for the moment.

Pairing with a device

Select **New device** to pair with a new device. The phone will then search for visible Bluetooth devices within range. To pair with one of the devices, select it in the list and enter the passcode (also called passkey) if you are asked to.


If you are pairing with a Bluetooth headset, the headset may have auto pairing functionality. This means you do not have to initiate pairing, as the headset does so when switched on. It also means you do not have to enter a passcode, but you must still confirm the pairing.

When you select a device from the list, a list of options opens:


Device options

Device name – select to change the name of the device. This only affects how the device is presented in your phone.

Trust this device – allows the device to connect to your phone without your confirmation every time.

Enable as audio – to use the device (for example, a Bluetooth headset) in audio applications. Devices enabled for audio are listed in the audio tab, .

Bluetooth services

The services (sometimes called profiles) supported by the connected device are listed in the detail view for the device. On the  tab, select the device and then select the right **Services** tab.

Audio tab

This is where all paired devices that are marked **Enable as audio** are listed. You can later disable a device for audio to prevent your phone from accidentally transferring sound to it.

Infrared port

Select **Tools > Control panel > Connections > Infrared** to activate the infrared port.

Infrared options

On or **On for 10 minutes** – switches the port on.

Off – switches the port off.

Internet accounts

See *Setting up Internet, email and MMS* on page 67.

Mobile networks

Select **Tools > Control panel > Connections > Mobile networks** to set the way your phone should choose an available network, when you are outside your operator's coverage area. **Mobile networks** has two tabs, **Search** and **Preferred list**.

Search tab

The phone searches for a network. You can choose between **Automatic** or **Manual** search.

More menu options

Select network – start a search for a network.

New search – search for the next network in the preferred list.

Preferred list tab

You can set a list of preferred networks. Your phone will select the network with the highest priority that can be found.

More menu options

Add network – select a network from the list and set priority.

Delete network – delete the highlighted network.

Help file – help information.

Note: *Your operator may not allow you to access all available networks.*

USB

Select **Tools > Control panel > Connections > USB** to display the USB settings of your phone.

USB functionality options

Phone mode – allows synchronization, backup, restore, file transfer, and modem usage.

File transfer – allows transfer of music files and images to and from the phone using computer applications like Sony Disc2Phone and Adobe Photoshop Album SE. Also allows using your phone as a general storage device for a connected computer.

Mark **Allow USB charging** to enable phone battery charging over USB. It is recommended not to use this function when connecting to an un-powered USB hub or to a device only using battery power.

Note: *During data transfer over USB, do not change the USB settings or disconnect the phone from the other device, as this may cause a data loss.*

Device

Backlight

You can select how the display and keyboard backlight should behave for handheld use and when the phone is in a car holder. The lower the brightness you choose, the longer the battery will last before it needs charging. Set the car holder levels low enough so that you sustain natural night vision.

Select **Tools > Control panel > Device > Backlight** to make the settings.

Settings tab

Auto – backlight switches on when you tap the screen, press a key or receive an incoming call. After a short time of inactivity the light switches off.

On – backlight is always on, but after a short time of inactivity it fades to the dimmed level that you can adjust on the Brightness tab.

Brightness tab

Select the backlight mode and adjust the brightness with the slider or the Jog Dial.

Select **Default** to reset all light levels to the factory values.

Device management

Device management enables the remote distribution of settings for your phone, for example Internet, email, SMS and MMS. It also makes it possible to manage (list, install, update and uninstall) themes and client software on the phones. Device management is useful if an enterprise has, for example, defined a set of standard software that should be used on all employees' phones.

To enter the settings or manage software in the phone, a device management session is set up between the phone and a device management server. The session can be initiated from the phone by you or from the server.

Device management dialog

Select **Tools > Control panel > Device > Device management**. The device management server profiles, if any, are listed. The profiles settings describe how the profile will handle the start of a Device management session and the notifications given during the session. In the device management dialog you can:

- Initiate the phone management session by highlighting a profile and selecting **Connect**.
- Create a new device management server profile manually by selecting **More > New profile**.
- Initiate reconfiguration for a new operator by selecting **More > Clear ACL**. This might be necessary if your phone is already configured for another operator.
- Edit or delete device management server profiles.



Note: *A profile may be locked by the operator. If it is, you cannot edit or delete the profile or clear ACL.*

The device management dialog consists of two tabs, the **Details** tab and the **Settings** tab. In the **Details** tab you edit details for the connection, like user name for the account on the device management server and the server ID and address. In the **Settings** tab you set the behaviour of the device management session.

Flight mode

In Flight mode, the phone's radio functions are switched off. You can still use the organizer applications.

Select **Tools > Control panel > Device > Flight mode** and choose whether you want to be prompted to choose between *Flight mode* or *Phone on* whenever you press the On/Off button.

In Flight mode the Flight mode icon  is visible in the status bar. To change mode, you can either tap this icon or, when in Phone mode, the Signal strength icon .

Hardware button

You can personalize the function of the shortcut button. Select **Tools > Control panel > Device > Hardware button** to make the settings.

The shortcut button can be set to open any of the following: Activity menu, Internet, Main menu, Media player, Sound recorder or Task manager.

Location

Select **Tools > Control panel > Device > Location** to set **Current time zone** and **Zone of interest** which appear with their current time and date in the application **Time**. Select the required field and select a time zone or a city in the time zone you want to display.

Home time zone is not actually displayed in Time but makes it easier to reset your current time zone when you return home.

Location menu options

Set updates – when you travel across time zones, your phone can receive information from the network and automatically set the clock to show the local time.

Number formats

Select **Tools > Control panel > Device > Number formats** to set the format used to display distances, decimal separator, thousands separator, currency and symbol position. The default values depend on the language you have selected.

Power save

Select **Tools > Control panel > Device > Power save** to set power save behaviour.

If you have set **Tools > Control panel > Device > Backlight** to **Auto**, the phone will automatically turn the backlight off to save power. If you have set Backlight to **On**, you can still save power by selecting **Power save enabled**. This will make the screen go blank after a period of inactivity.

Active after determines how long after you stop using the phone the screen should go blank.


Screen saver

Select **Tools > Control panel > Device > Screen saver** to select a screen saver. You can select the default screen saver, a picture or a folder of pictures to be used as a slide show.

Sounds & alerts

Ringtones

Select **Tools > Control panel > Device > Sounds & alerts > Ringtones** to choose ringtones for incoming voice and data & fax calls in the drop-down menus. Tap and drag the volume slider, or rotate the Jog Dial, to adjust the ringtone level. To preview a sound

tap . If you select **Increasing ring** the ring signal will start out low and gradually increase in volume.

You can further personalize your phone by assigning different ringtones to different contacts, see *Adding a personal ringtone to a contact* on page 37.

Message alerts

Select **Tools > Control panel > Device > Sounds & alerts > Message alerts** to select sounds to be played when you get different kinds of messages. If you select **Display notification**, a dialog will be displayed on the screen when a message arrives.

Alarms

Select **Tools > Control panel > Device > Sounds & alerts > Alarms** to select sounds and adjust the volume for calendar and clock alarms. Alarms require that the phone is turned on. If you want to hear alarms but not be disturbed by incoming calls or messages, set the phone in Flight mode.

Vibrating alerts

Select **Tools > Control panel > Device > Sounds & alerts > Vibrating alerts** and then select for which events the phone should vibrate. **On if silent** means the phone will vibrate only when it has been set to silent mode. For more information, see *Silent mode* on page 24

Buttons & screen

Select **Tools > Control panel > Device > Sounds & alerts > Buttons & screen** and then select sounds for when you press keys and buttons and tap the screen.

Equalizer

The equalizer changes the frequency balance of the sound from the Media player. Select **Tools > Control panel > Device > Sounds & alerts > Equalizer** to make the settings. The drop-down menu contains presets for different music genres. Mega Bass is a setting that provides more powerful bass tones regardless of volume.

Storage wizard

See *Storage wizard* on page 62.

Text input

Select **Tools > Control panel > Device > Text input** to do the following:

- Change the settings in the text options menu of the text entry applications, see *Text Entry* on page 16.
- Select and set up text input software.

Predictive text – select languages for predictive text entry and select if you want predictive text to be active.

Auto capitalization – select if you want auto capitalization to be active.

Handwriting – select if you want a software for handwriting recognition to be active. The JotPro software is delivered with the phone and is default.

The JotPro software takes handwriting input simultaneously with the keyboard. You may install third party handwriting recognition software, but keyboard input will only be supported if it is enabled in that software. If the software has a setup option you will be able to access it through **Setup** in the **More** menu.

Virtual keyboard – select this if you want the virtual keyboard to be available. Select **Setup** in the **More** menu to select language for the keyboard layout

Themes

With themes you can personalize your phone. Themes control, for example, the colour of the screen and the text, the icons, the wallpaper and the skins. Themes also include a set of sounds to use as ringtones and SMS and MMS alerts.

Select **Tools > Control panel > Device > Themes** to choose a theme from a list and view it. To apply a theme, choose **Select**.

Using the **More** menu you can delete or send a theme. It is not possible to delete a theme that is currently in use or is predefined.

Note: Copyright-protection may prevent content from being copied, modified or transferred. If a file is copyright-protected, or if an access key has expired or is unavailable, an icon is displayed by the file name.

Time & date

Select **Tools > Control panel > Device > Time & date** to set the current time and date. You can also select the date and time format. Select the required field and make the settings.

Time & date menu options

Set updates – when you travel across time zones, your phone can receive information from the network and automatically set its clock to show the local time.

Set workdays – specify the workdays and the first day of the week.

User greeting

Select **Tools > Control panel > Device > User greeting** to choose whether you want a user greeting to be displayed every time the phone is turned on. The maximum number of characters that can be entered is 32.

Wallpaper

Select **Tools > Control panel > Device > Wallpaper** to set a background picture for the standby view. Select **Replace** and browse to the picture you want to use. Use the slider to adjust the size of the image.

Wallpaper menu options

Remove picture – remove the background picture.

Picture from theme – select a picture from a theme.

Tile – mark the check box to fill the screen with additional copies of the chosen image.

Messaging settings

Area information

Area information messages are text messages broadcast to all subscribers in a network area, for example information from your service provider or weather reports. This is an service provider-dependant service. Using the settings described below, you can subscribe to and activate different information channels.

Select **Tools > Control panel > Messaging > Area information** and enter the settings.

Email accounts

See *Setting up Internet, email and MMS* on page 67.

MMS accounts

See *Setting up Internet, email and MMS* on page 67.

SMS

Select **Tools > Control panel > Messaging > SMS account** to set up text messaging, SMS and EMS.

Wap push

Select **Tools > Control panel > Messaging > Wap push** to set the way your phone handles incoming Wap push service loading messages.

WAP push

Automatically – select this to always have a service loading message received and the subscribed content loaded automatically in the Web browser if possible. If the browser is not available a notification is given.

Always ask – select this to be notified that a service loading is available for loading. Service indication messages also give a notification.

Never - All Wap push service loading messages are ignored.

Security

Certificate manager

Digital certificates are used to verify the origin of the Web pages you visit or any software you install. Select **Tools > Control panel > Security > Certificate manager** to view the current certificates in your phone. They have been created and issued by an independent organization that ensures their authenticity.

Locks

The phone has four security locks that you can set from the control panel by selecting **Tools > Control panel > Security > Locks**.

Phone lock

This is a lock code that you can use to protect your phone from unauthorized use. When you start the phone for the first time, the lock code is 0000, but you can change it to any four-to-eight digit code in the **Locks** menu. Your **Phone lock** setting options are:

- **At power on** – you will be requested to enter the code every time you turn the phone on.
- **Off** – the lock is turned off; no code will be requested.
- **When SIM changed** – the code will only be requested if the SIM card has been changed.

SIM card lock

Your PIN (Personal Identification Number) code consists of four to eight digits and is used to protect your SIM card against unauthorized use. It is needed for the access of the SIM card. You get it from your operator with the SIM card, but you can change it in the **Locks** menu. Your **SIM card lock** setting options are:

- **At power on** – you will be requested to enter your PIN code every time you turn the phone on.
- **Off** – the lock is turned off; no code will be requested.

An error message informs you if an incorrect PIN code has been entered. Usually, the SIM card will be blocked after three incorrect attempts (the number of attempts is operator-dependent). To unblock the SIM card you must use your PUK code.

The PUK code consists of eight digits. When you have entered the right PUK code you must enter a new PIN code. You have ten attempts to enter the PUK code. If all ten attempts fail, the SIM card will be unusable and you need to contact your operator. You cannot change the PUK code.

The PIN2 code

Some special SIM card services, such as Call meter and Fixed Numbers, can be protected by a secondary code feature, the PIN2 code. The code properties are:


- **PIN2** cannot be disabled, but the four-to-eight digit code can be changed in the **Locks** menu.
- **PIN2** will be blocked after three incorrect attempts. To unblock the code, a PUK2 code must be entered.

- After 10 unsuccessful PIN2 unblocking attempts, the card can still be used, but access to the PIN2-protected SIM features is permanently barred.
- Not every SIM card has a PIN2 lock.

Inactivity lock

If you mark the **Inactivity lock** check box and enter the requested **Phone lock** code, this lock will be activated. It protects the screen from accidentally being pressed. The screen will automatically become locked after a 60-second period of inactivity. To open it, touch any key to bring up a dialog where you must enter the **Phone lock** code.

Automatic key lock

If you mark the **Automatic key lock** check box, the keyboard becomes automatically locked after a period of inactivity. This is to prevent you from accidentally pressing any key. To unlock the key lock, press and hold the back button on the side, or select  * > **Unlock**.

MIDlet settings

A MIDlet suite is a Java application package. Sometimes MIDlets may want to initiate actions that require your permission. This could be actions such as:

- Opening a connection.

- Automatically starting the MIDlet in response to an incoming connection.
- Sending an SMS.

A **MIDlet permission request** dialog is displayed where you allow or deny the request, perhaps because they involve privacy or network charges.

Select **Tools > Control panel > Security** to access the two applications where you enter MIDlet settings in the phone; **MIDlet accounts** and **MIDlet permissions**.

MIDlet accounts

A MIDlet Suite can be tied to a certain Internet account. In **MIDlet accounts** the currently installed MIDlet Suites are listed. You can change the Internet account of a MIDlet Suite by selecting it and choosing between the Internet accounts and VPN accounts that are set up in the phone.

MIDlet permissions

In **MIDlet permissions** you have the possibility to set the conditions under which a request will be raised in your phone when a MIDlet Suite wants to initiate a certain action. You can change a MIDlet Suite permission by selecting it and modifying the **User Permissions** and how you wish the phone to respond to that user permission, the **Interaction mode**.

VPN accounts

Virtual Private Network (VPN) is a secure way to provide access to an organization's network via the Internet. Select **Tools > Control panel > Security > VPN Accounts** to create a VPN account.

Other

Format disk

See *Formatting a Memory Stick* on page 61.

Install

See *Installing applications* on page 61.

Language

Select a language from the list to change the language in your phone. The language currently in use is highlighted. You can delete all languages except English.

To conserve storage space only a limited set of languages is loaded on your phone at delivery. When you select one of the languages from the list the unused languages in the set are deleted from the memory of your phone. You can download additional languages from www.sonyericsson.com/cn.

Master reset

Use **Master reset** to reset your phone

Important: *All user data, as well as pre-installed media files and application data files (including, for example, backgrounds, ringtones and pictures), will be deleted and settings will be set to the state they were after you selected the language. The selected local language will be restored.*

If you have backed up your user data, you can restore it from the backup, see *Restoring data* on page 67.

You can restore media files and application data files from www.sonyericsson.com/cn.

If you want to keep installed applications, unmark the **Delete user installed applications** check box.

Setup wizard

The Setup wizard is normally run the first time you start your phone. It guides you through basic phone settings and shows some useful tips. Setup wizard can also be accessed from **Tools > Control panel > Other > Setup wizard** at any time. When opened from Control panel, the Setup wizard will also include a step to calibrate the screen.

Uninstall

See *Removing applications* on page 62.

Troubleshooting

To find suggestions for solving possible problems with your phone we advise you to visit www.sonyericsson.com/cn. Select phone to find helpful information.

Your phone also has built-in help texts. In many applications and in some dialogs, for example those where you make important settings, **Help** is available in the **More** menu.

To improve performance, you can update the software of your phone. See *Updating software* on page 13.

Note: *If you need to hand in your phone for repair, please note that you may lose information and content that you have saved in your phone. You are advised to make a copy of such information, see *Backing up data* on page 66.*

Important information

Sony Ericsson Consumer Web site, service and support, safe and efficient use, end user licence agreement, warranty, declaration of conformity.

Sony Ericsson Consumer Web site

On www.sonyericsson.com/cn there is a support section where help and tips are only a few clicks away. Here you find the latest computer software updates and tips on how to use your product more efficiently.

Guidelines for safe and efficient use

Please read this information before using your mobile phone. These instructions are intended for your safety. Please follow these. Please follow these guidelines. If the product has been subject to any of the conditions listed below or you have any doubt of the proper function make sure to have the product checked by certified service partner before charging or using it. Failure to do so might lead to risk for product malfunction or even a potential hazard to your health.



Important: *To avoid hearing impairment when you answer calls, lower the volume before placing the phone to your ear.*

Recommendations for safe use of product (mobile phone, battery, charger and other accessories)

- Always treat your product with care and keep it in a clean and dust-free place.
- May explode if disposed of in fire.
- Do not expose your product to liquid or moisture or humidity.
- Do not expose your product to extreme high or low temperatures. Do not expose the battery to temperatures above +60°C (+140°F).
- Do not expose your product to open flames or lit tobacco products.
- Do not drop, throw or try to bend your product.
- Do not paint your product.
- Do not attempt to disassemble or modify your product. Only Sony Ericsson authorised personnel should perform service.
- Do not use your product near medical equipment without requesting permission.
- Do not use your product when in, or around aircraft, or areas posted "turn off two-way radio".
- Do not use your product in an area where a potentially explosive atmosphere exists, for example, at a gas station, oil depot or chemical plant.



- Do not place your product or install wireless equipment in the area above your car's air bag.



CHILDREN

KEEP OUT OF CHILDRENS REACH. DO NOT ALLOW CHILDREN TO PLAY WITH YOUR MOBILE PHONE OR ITS ACCESSORIES. THEY COULD HURT THEMSELVES OR OTHERS, OR COULD ACCIDENTALLY DAMAGE THE MOBILE PHONE OR ACCESSORY. YOUR MOBILE PHONE OR ITS ACCESSORY MAY CONTAIN SMALL PARTS THAT COULD BE DETACHED AND CREATE A CHOKING HAZARD.

Power supply (Charger)

Connect the AC power adapter only to designated power sources as marked on the product. Make sure the cord is positioned so that it will not be subjected to damage or stress. To reduce risk of electric shock, unplug the unit from any power source before attempting to clean it. The AC power adapter must not be used outdoors or in damp areas. Never alter the cord or plug. If the plug will not fit into the outlet, have a proper outlet installed by a qualified electrician.

Use only Sony Ericsson branded original chargers intended for use with your mobile phone. Other chargers may not be designed to the same safety and performance standards.

Battery

We recommend that you fully charge the battery before you use your mobile phone for the first time. A new battery or one that has not been used for a long time could have reduced capacity the first few times it is used. The battery should only be charged in temperatures between +5°C (+41°F) and +45°C (+113°F).

Use only Sony Ericsson branded original batteries intended for use with your mobile phone. Using other batteries and chargers could be dangerous.

The talk and standby times depend on several different conditions such as signal strength, operating temperature, application usage patterns, features selected and voice or data transmissions when using the mobile phone. Under normal conditions the stand-by time for this battery is up to 340 hours.

Turn off your mobile phone before removing the battery. Do not allow the battery to be put into the mouth. Battery electrolytes may be toxic if swallowed. Do not let the metal contacts on the battery touch another metal object. This could short-circuit and damage the battery. Use the battery for the intended purpose only.

Personal medical devices

Mobile phones may affect the operation of cardiac pacemakers and other implanted equipment. Please avoid placing the mobile phone over the pacemaker, e.g. in your breast pocket. When using the mobile phone, place it at the ear opposite the pacemaker. If a minimum distance of 15 cm (6 inches) is kept between the mobile phone and the pacemaker, the risk of interference is limited. If you have any reason to suspect that interference is taking place, immediately turn off your mobile phone. Contact your cardiologist for more information.

For other medical devices, please consult your physician and the manufacturer of the device.

Driving

Please check if local laws and regulations restrict the use of mobile phones while driving or require drivers to use handsfree solutions. We recommend that you use only Sony Ericsson handsfree solutions intended for use with your product.

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a handsfree kit with an external antenna supports the installation. Always give full attention to driving and pull off the road and park before making or answering a call if driving conditions so require.

Emergency calls

Mobile phones operate using radio signals, which cannot guarantee connection under all conditions. Therefore you should never rely solely upon any mobile phone for essential communications (e.g. medical emergencies). Emergency calls may not be possible in all areas, on all cellular networks, or when certain network services and/or mobile phone features are in use. Check with your local service provider.

Antenna

This phone contains a built in antenna. Use of antenna devices not marketed by Sony Ericsson specifically for this model could damage your mobile phone, reduce performance, and produce SAR levels above the established limits (see below).

Efficient use

Hold your mobile phone as you would any other phone. Do not cover the top of the phone when in use, as this affects call quality and may cause the phone to operate at a higher power level than needed, thus shortening talk and standby times.

Radio frequency (RF) exposure and SAR

Your mobile phone is a low-power radio transmitter and receiver. When it is turned on, it emits low levels of radio frequency energy (also known as radio waves or radio frequency fields).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations, e.g. ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.), through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure for the general population. The levels include a safety margin designed to assure the safety of all persons, regardless of age and health, and to account for any variations in measurements. Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the mobile phone while operating can be well below this value. This is because the mobile phone is designed to use the minimum power required to reach the network.

Variations in SAR below the radio frequency exposure guidelines do not mean that there are variations in safety. While there may be differences

in SAR levels among mobile phones, all Sony Ericsson mobile phone models are designed to meet radio frequency exposure guidelines.

For phones sold in the U.S., before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (that is, at the ear and worn on the body) as required by the FCC for each model. For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when the handset is positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when used with the original Sony Ericsson body worn accessory intended for this phone. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

A separate leaflet with SAR information for this mobile phone model is included with the material that comes with this mobile phone. This information can also be found, together with more information on radio frequency exposure and SAR, on:

www.sonyericsson.com.

Accessible Solutions/Special Needs

For phones sold in the U.S., you can use your TTY terminal with your Sony Ericsson mobile phone (with the necessary accessory). For information on Accessible Solutions for individuals with special needs call the Sony Ericsson Special Needs Center at 877 878 1996 (TTY) or 877 207 2056 (voice), or visit the Sony Ericsson Special Needs Center at www.sonyericsson-snc.com.

Disposal of old electrical & electronic equipment



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office or your household waste disposal service.

Disposing of the battery



Please check local regulations for disposal of batteries or call your local Sony Ericsson Call Center for information.

The battery should never be placed in municipal waste. Use a battery disposal facility if available.

End User Licence Agreement

This wireless device, including without limitation any media delivered with the device, (“Device”) contains software owned by Sony Ericsson Mobile Communications AB and its affiliated companies (“Sony Ericsson”) and its third party suppliers and licensors (“Software”).

As user of this Device, Sony Ericsson grants you a non-exclusive, non-transferable, non-assignable

license to use the Software solely in conjunction with the Device on which it is installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device.

You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any component of the Software. For avoidance of doubt, you are at all times entitled to transfer all rights and obligations to the Software to a third party, solely together with the Device with which you received the Software, provided always that such third party agrees in writing to be bound by these rules.

You are granted this license for a term of the useful life of this Device. You can terminate this license by transferring all your rights to the Device on which you have received the Software to a third party in writing. If you fail to comply with any of the terms and conditions set out in this license, it will terminate with immediate effect.

Sony Ericsson and its third party suppliers and licensors are the sole and exclusive owner of and retain all rights, title and interest in and to the Software. Sony Ericsson, and, to the extent that the Software contains material or code of a third party, such third party, shall be entitled third party beneficiaries of these terms.

The validity, construction and performance of this license shall be governed by the laws of Sweden. The foregoing shall apply to the full extent permitted by, when applicable, statutory consumer rights.

Limited Warranty

Sony Ericsson Mobile Communications AB, S-221 88 Lund, Sweden, (Sony Ericsson), provides this Limited Warranty for your mobile phone and original accessory delivered with your mobile phone (hereinafter referred to as “Product”).

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Call Center (national rates may apply) or visit www.sonyericsson.com to get further information.

What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony Ericsson authorised distributors or service partners, in the country/region* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein.

Sony Ericsson and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads or other information may be lost when your Sony Ericsson Product is repaired or replaced. At present Sony Ericsson may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the

information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

Conditions

1. The warranty is valid only if the original proof of purchase issued to the original purchaser by a Sony Ericsson authorised dealer, specifying the date of purchase and serial number**, for this Product, is presented with the Product to be repaired or replaced. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
2. If Sony Ericsson repairs or replaces the Product, the repaired or replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony Ericsson.
3. This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sony Ericsson instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, acts of God or damage resulting from liquid. A rechargeable

battery can be charged and discharged hundreds of times. However, it will eventually wear out – this is not a defect. When the talk-time or standby time is noticeably shorter, it is time to replace your battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson. Minor variations in display brightness and color may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, services or range of that system.
5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.
6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.
7. Tampering with any of the seals on the Product will void the warranty.
8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A

PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/regions/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you. The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales/purchase contract.

** In some countries/regions additional information is requested. If so, this is clearly shown on the valid proof of purchase.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



Bluetooth wireless technology

Bluetooth Qualified Design ID is B011112.

Declaration of Conformity

We, **Sony Ericsson Mobile Communications AB** of
Nya Vattentorget

S-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type FAB-1022011-BV

and in combination with our accessories, to which

this declaration relates is in conformity with the

appropriate standards 3GPP TS 51.010-1,

EN 301908-1, EN 300328, EN 301489-7,

EN 301489-17, EN 301489-24, EN 60950,

following the provisions of Radio Equipment and

Telecommunication Terminal Equipment directive

99/5/EC with requirements covering EMC directive

89/336/EEC, and Low Voltage directive **73/23/EEC**.

Lund, March 2006

CE 0682 



Shoji Nemoto

Head of Product Business Unit GSM/UMTS

We fulfil the requirements of the R&TTE Directive

(99/5/EC).

Technical data

General

Size	107 x 54 x 15 mm
Weight	112 g with battery
Battery type and capacity	BST-33, 900 mAh
System and power class	E-GSM 900 Class 4 GSM 1800 Class 1 GSM 1900 Class 1
Operating system	Symbian OS v9.1 with UIQ 3.0 user interface and applications environment
Additional storage	Memory Stick Micro™ (M2™), up to 4 GB supported. 64 MB Memory Stick Micro (M2) supplied.

Connectivity

Cable	Fast port USB 2.0 compliant, low speed (1.5 Mbps) and full speed (12 Mbps)
Bluetooth™ wireless technology	This product is manufactured to comply with the Bluetooth specification 2.0
Infrared	IrDA-SIR and IrObex supported

Media formats

Image	BMP (.bmp), GIF (.gif, including animated), JPEG (.jpg), MBM (.mbm), PNG (.png), WMBMP (.wbm)
Audio	3GPP (.3ga), AAC-LC (.aac/.m4a), AAC+ (.aac), E-AAC+ (.aac), AMR-NB (.amr), AU (.au), iMelody (.imy), MIDI (.mid), SP-MIDI (.mid), MP3 (.mp3), Beatnik (.rmf), WAV (.wav), XMF (.mxmf), DLS, Real Audio (.ra), M3U playlists
Video	3GPP (.3gp), MP4 (.mp4), Real Media (.ram, .rm)

Document formats

Microsoft Word	97, 2000, 2002 (XP), 2003
Microsoft Excel	97, 2000, 2002 (XP), 2003
Microsoft PowerPoint	97, 2000, 2002 (XP), 2003
Adobe Acrobat (PDF)	1.0, 1.1, 1.2, 1.3, 1.4, 1.5, 1.6

Index

A

- Accept calls 72
- Accessories
 - connecting 13
- Add to contacts 72
- Alarms 60, 82
- ALS settings 76
- Application launcher 63
- Applications
 - installing 61
 - overview 9
 - removing 62
 - start and leave 9
 - switching between 10
- Area information 30
 - settings 85
- Auto pairing 77
- Auto setup 30, 68

B

- Back light 79
- Backing up data 66
- Backup 65, 66
- Backup Manager 66, 67
- Battery 6
 - charging 79
 - charging via USB 65, 79
- Beamed messages 30

- Bluetooth 64, 77
 - service 78
- Bluetooth wireless technology, see Bluetooth 77
- Bonding 77
- Browser, see Web 41
- Business card, see owner card 36
- Button settings 81

C

- Calculator 58
- Calendar 38
 - invitations 39
- Call log 28
- Call meter 76
- Call settings 72
- Call waiting 73
- Calling cards 29
 - settings 72
- Calls
 - conference calls 28
 - emergency calls 26
 - incoming 27
 - making 25
 - more than one 27
 - outgoing 25
 - receiving 27
- Certificate manager 85
- Charging the battery 7, 65, 79
- Chinese punctuation 23
- Clock, see Time 59
- Compose a melody 54
- Computer modem 65
- Conference calls 28
- Connecting accessories 13
- Connections 77
- Connections manager 65
- Contacts 35
 - copy to and from SIM card 38
 - creating 36
 - editing 36
 - importing entries 8
 - managing 37
 - owner card 36
 - photos in contacts 37
 - voice dialling 37
- Control panel 71, 80
 - call settings 72
 - connections 77, 80
 - device settings 79
 - messaging settings 85
 - other settings 88
 - security 85
 - sounds and alerts 82
- Converter 59

D

- Data
 - transferring between phones 25

Date 84
Declaration of Conformity 96
Device management 80
Device settings 79
Digital business card, see
Owner card 36
Divert calls 74
Document viewers 55
Downloading files 43

E

Email 32
- push email 35
- settings 67, 68
- synchronization accounts
34

Emergency calls 26

EMS, see SMS 31

Entering text 16

- - chinese punctuation 23
- - numeric characters 24
- handwriting recognition
20
- keyboard 17
- virtual keyboard 18, 19

Equalizer 47, 83

F

Fax 31

File manager 60

File transfer 63, 65, 79

Flag call 74

Flight mode 7, 81

Folders 30
- menu 14

Formats 81

Formatting Memory Stick 61

G

Games 55

H

Handsfree
- settings 74

Handwriting recognition 20,
83

Help texts in the phone 14

Hide number 75

HTML-mail 33

I

Icons 12

IMAP account 31, 33

Infrared port 64, 78

Installing applications 61

Internet

- accounts 88
- browsing 41
- settings 67

J

Jog Dial 9

Jotter, see Notes 57

K

Keyboard 17

- virtual 18, 19

Keyboard functions 11

Keylock 24, 87

L

Languages 88

Local synchronization 66

Location 81

Locks 86

M

Master reset 88

Media player 46

Meeting request, see
Invitations 39

Memory Stick Duo 12

- formatting 61
- renaming 61

Messaging 30

- area information 30
- area information settings
85
- auto setup 68
- email 32
- email settings 67, 68
- folders 30
- HTML-mail 33
- IMAP account 31, 33
- MMS 31

- MMS settings 67, 71
- settings 85
- SMS 31
- SMS settings 85

MIDlet settings 87

Migrating data 25

MMS 31

- settings 67, 71

Mobile networks 78

Multimedia files 15

Music

- adjusting sound 47
- managing track 47
- playback 47
- playing 46
- playlist 46

MusicDJ 54

My card 36

N

Navigation 8

Notes 57

Number formats 81

Numeric characters 24

O

On/Off 7

Online 49

On-screen keyboard 18, 19

Organizing information

- file manager 60

- folder menu 14

- multimedia files 15

Other settings 88

Overview 5

Owner card 36

P

Pairing 64, 77

- pairing devices 77

- passcode 77

- passkey 77

PC Suite 62

- telephone as a modem 65

Pdf+ 56

Phone 25

- business phone services 29

- calling cards 29

- speed dial 28

- voice control 26, 29

Phone mode 65, 66, 79

Phone settings 72

Phonebook, see Contacts 35

Pictures 50

- managing picture files 51

Playback 47

Playlist 46

PlayNow 49

Power save 82

Predictive text 83

Predictive text input 16

Q

Quickoffice 55

R

Remote synchronization 67

Resetting phone 88

Restoring data 67

Restrict calls

- settings 75

RSS feeds 44

S

Screen saver 82

Security 85

Send as 14, 64

Services, Bluetooth 78

Setup wizard 88

Silent mode 24

SIM card

- inserting 6

Slideshows 51, 52

SMS 31

- answering with MMS 31

- delivery report 31, 85

- settings 85

Software

- updating 13

Sony Ericsson PC Suite, see

PC Suite 62

Sound in the phone 24

Sound recorder 53

- Speed dial 28
- Stopwatch 60
- Storage wizard 62
- Streaming media 49
- Synchronization 65
 - remote 67
- T
- Task manager 10
- Tasks 57
- Technical data 97
- Text entry 16
- Text input 83
- Text messages, see SMS 31
- Themes 84
- Time 59, 84
- Time & date 84
- Time zones 81
- Timer 60
- To do, see Tasks 57
- To input Chinese characters 21
- Tone-based services 28
- Transferring data 25
- Troubleshooting 89
- Trusting a device 64
- Try and buy applications 12
- TTY
 - settings 75
- U
- Updating software 13
- Upgrading 25
- USB 65, 79
 - charging battery 79
- User greeting 84
- V
- Vibrating alerts 83
- Video
 - managing clips 49
 - playing 48
- Viewers 55
- Virtual keyboard 18, 19, 83
- Voice control 26, 29, 75
- Voice dialling 37
- Voice mail 76
- Volume
 - adjusting 24
- VPN
 - accounts 88
 - settings 67
- W
- Wallpaper 84
- Wap push 85
- Warranty 94
- Web
 - accounts 68
 - blocking popups 43
 - bookmarks 42
- browsing 41
- delete private data 44
- history list 43
- remember password-function 42
- secure (https) connection 41
- settings 67
- viewing pages offline 43
- Z
- Zooming 14