

SONY[®]

T-Mobile

Startup guide

Xperia™ Z
C6606

1274-2702.1

Welcome

Important Information

Before you use your device, please read the *Important Information* provided in your device or in the box.

Water and dust resistance



Ocean water



Swimming pool



Diving



Hot water



Sand/mud



Other liquid
chemicals

Your device has IP (Ingress Protection) ratings of IP5X, IPX5 and IPX7. This means that your device is dust protected and protected against the effects of immersion in water in depths of between 0 to 100 cm for up to 30 minutes, and is also protected against the effects of a low pressure water stream.


The covers for the micro USB port, the micro SD card, the micro SIM card and the headset connector must be firmly closed in order for the device to meet the stated IP rating. More information about IP codes and important details about your device's resistance to water can be found in the User guide for your device and on the Sony Mobile support website.

www.sonymobile.com/support

Assembly


Please use the SIM card included in the box. This new card will allow you to use the Wi-Fi calling feature, ISIS Mobile Wallet feature and other enhanced device features. For help transferring contacts from your previous SIM card, please ask a retail store representative to help you.

To insert the micro SIM card



To insert a memory card



- ! Do not insert a micro SIM card into the MicroSD slot.



- ! Your device does not come with a microSD memory card, but you can purchase one separately.

Basics

Device overview




- | | |
|-------------------------------|-------------------------|
| 1. Front camera lens | 10. Camera lens |
| 2. Ear speaker | 11. Second microphone |
| 3. Ambient light sensor | 12. Camera light |
| 4. Notification light | 13. NFC™ detection area |
| 5. Main microphone | 14. Strap hole |
| 6. Charging dock connector | 15. Speaker |
| 7. MicroSD slot | 16. Volume/Zoom key |
| 8. Port for charger/USB cable | 17. Power key |
| 9. Headset connector | 18. Micro SIM slot |


- ! Use the accessories provided with your device, or other compatible accessories, for optimal performance.

Turning on the device

To turn on the device


- ! Make sure that the battery is charged for at least 30 minutes before you turn on the device for the first time.



- 1 Press and hold down the power key  until the device vibrates.
- 2 Wait a while for the device to start.



Waking up the screen

To activate the screen


- Briefly press the power key .

To unlock the screen



- Drag  up or drag  down.

Using the keys



Back

- Go back to the previous screen
- Close the on-screen keypad, a dialog box, an options menu, or the Notification panel



Home

- Go to the **Home** screen




Task

- Tap to open a window showing your most recently used applications and a small apps bar

Set up your device

What is Android™?



Android is your device's operating system. Since Android is developed by Google™, your device is preloaded with several Google™ services, such as Google Maps™ and Google™ web search. To use some of the services provided by Google™, you need a Google account. Android provides backup options through Gmail™ account sync to restore contacts, Wi-Fi settings, and app data to/from Android devices.


What is different about Android?

Android™ is an open system, which means that you're not limited to using applications and services from only one provider.

Basic settings

The first time you start your device, a setup guide explains basic device functions and helps you enter essential settings. You can also access the setup guide later.

To access the setup guide manually



- 1 From the Home screen, tap .
- 2 Tap **Settings** > **Setup guide**.

Google™ account

With a Google™ account, you can use Gmail™ to send emails, Google Talk™ to chat with friends, and Google Play™ to download applications and games, music, movies and books.

When setting up your device, log in to your Google™ account to sync Gmail™, Contacts, Google calendar, Picasa™ photo albums and restore downloaded applications from the Play Store™. You can also use Google Maps™, download applications from Play Store™, back up your settings to Google servers, and take advantage of other Google services on your device.

To set up a Google™ account on your device

- 1 From your Home screen, tap .
 - 2 Find and tap **Settings** > **Add account** > **Google**.
 - 3 Follow the registration wizard to create a Google™ account, or sign in if you already have an account.
-  You can also sign in to or create a Google™ account from the setup guide the first time you start your device. Or you can go online and create an account at www.google.com/accounts.

Transferring contacts


Transferring contacts to your new device can sometimes be complicated, but help is available. You can transfer contacts from several device brands, including iPhone, Samsung, HTC and Nokia. After signing in to your Google™ account, your device will sync with your Google services, such as Gmail™, Contacts, Google Calendar and Picasa™ photo albums.

Finding your way

Home screen

The Home screen of your device is the equivalent of the desktop on a computer. You can customise your Home screen with widgets, shortcuts, folders, themes, wallpaper and other items.

The Home screen extends beyond the regular screen display width, so you need to flick left or right to view content in one of the screen's four extensions.



The items in the bar at the bottom of the screen are always available for quick access.

To go to the Home screen

- Press .

To browse the Home screen

- Flick right or left.

To change your Home screen wallpaper

- 1 Tap an empty area on your Home screen.
- 2 Tap **Wallpaper** and select an option.

Widgets


Widgets are small applications that you can use directly on your Home screen. For example, the Music player widget allows you to start playing music directly.

Some widgets are resizable, so you can expand them to view more content or shrink them to save space on your Home screen.

Application screen

The Application screen, which you open from your Home screen, contains the applications that come pre-installed on your device as well as the applications you download. The Application screen extends beyond the regular screen width, so you need to flick left and right to view all content.

To open the Application screen



- From your Home screen, tap .

To open an application

- From your Home screen or the Application screen, tap the application.

Applications

An application is a program on your device that helps you perform a task. For example, there are applications to make calls, take photos and download more applications.

Status and notifications

The status bar at the top of your screen shows what's going on in your device. For example, new message and calendar notifications appear here.



Checking notifications and ongoing activities

You can drag down the status bar to open the Notification panel and get more information. For example, you can use the panel to open a new message or view a calendar event. You can also open some applications that run in the background, such as the music player.

To open the Notification panel




- Drag the status bar downwards.

Settings menu

View and change settings for your device from the Settings menu.

To access your device settings

1 From your Home screen, tap .



2 Tap **Settings**.

- 💡 You can also drag the status bar downwards on the Home screen and tap  to access your device settings.

More basics

Calling

To make a call by dialing

- 1 From your **Home** screen, tap .
- 2 Find and tap **Phone**.
- 3 Enter the number of the recipient and tap **Call**. To delete a number, tap .

To end a call

- Tap .







To answer a call



- Drag  to the right across the screen.

MMS and text messaging

To create and send a message

- 1 From your **Home** screen, tap , then find and tap .
- 2 Tap .
- 3 Tap , then select the desired recipients from the **Contacts** list. If the recipient is not listed as a contact, enter the contact's number manually and tap .
- 4 When you are finished adding recipients, tap **Done**.
- 5 Tap **Write message** and enter your message text.
- 6 If you want to add a media file, tap  and select an option.
- 7 To send the message, tap **Send**.

Wi-Fi calling

- ! Wi-Fi calling requires that you use the SIM card that is shipped with your device. A different SIM card may not work if you want to use Wi-Fi calling. Also, you must register your address for 9-1-1. Wi-Fi calling will not work until you have registered for 9-1-1 by logging into your account at www.t-mobile.com. Go to your profile and click **Customer Info**.

About Wi-Fi calling


Wi-Fi calling can improve your coverage and allows you to make phone calls and send messages over a Wi-Fi network (when a Wi-Fi network is available). Unless your rate plan provides otherwise, Wi-Fi calling minutes count the same as T-Mobile cellular calling minutes on your phone bill.


Troubleshooting

My device is not responding

If your device hangs, or if you cannot restart it normally, you can force the device to restart.

To force the device to restart



- 1 Press and hold down both the volume up key and the power key  for five seconds.
- 2 After your device vibrates once, release the keys. The device restarts automatically.

The device does not recognise my wired headset

- Make sure the wired headset that you are using complies to the CTIA standard. Your device supports the CTIA standard, and may not be fully compatible with other standards such as OMTP.
- If you have a wireless headset that is compatible with your device, try using that instead.

Information about safeguarding handsets

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantage of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Remote locking and wiping capabilities are also available to T-Mobile customers that have elected to subscribe to the Mobile Security service offered by our partner, Asurion, along with insurance to help replace lost or stolen devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information, visit:

www.t-mobile.com/devicesecurity and <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

- ! Mobile Security is a service provided by Asurion Mobile Applications and is not an insurance product.

Approved firmware versions

This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function.

Legal information

Sony C6606

Google Play™ is not available in all countries. Some of the services and features described in this Startup guide are not supported in all countries/regions or by all networks and/or service providers in all areas. Without limitation, this applies to the GSM International Emergency Number 112. Please contact your network operator or service provider to determine availability of any specific service or feature and whether additional access or usage fees apply.

This Startup guide is published by Sony Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide.

© 2013 Sony Mobile Communications AB. All rights reserved.

Publication number: 1274-2702.1

Your device has the capability to download, store and forward additional content, e.g. ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony, are entirely responsible for additional content that you download to or forward from your device. Prior to your use of any additional content, please verify that your intended use is properly licensed or is otherwise authorized. Sony does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony be liable in any way for your improper use of additional content or other third party content.

This Startup guide may reference services or applications provided by third parties. Use of such programming or services may require separate registration with the third party provider and may be subject to additional terms of use. For applications accessed on or through a third-party website, please review such websites' terms of use and applicable privacy policy in advance. Sony does not warrant or guarantee the availability or performance of any third-party websites or offered services.

See regulatory information such as the CE mark on the back of the device.

EN © 2013 Sony Mobile Communications AB. All rights reserved. Sony and "make.believe" are trademarks or registered trademarks of Sony Corporation. T-Mobile and the magenta color are registered trademarks of T-Mobile USA, Inc. Android is the registered trademark of Google, Inc. Android robot is licensed under the Creative Commons 3.0 Attribution License. All marks are property of their respective owners.

Visit www.sonymobile.com for more information.

All illustrations are for illustration only and may not accurately depict the actual device.

This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.

Product compliance: This product has been manufactured by or on behalf of Sony Mobile Communications, Mobilvägen, SE-221 88 Lund, Sweden. Inquiries related to product compliance based on national legislation shall be addressed to Sony Mobile Quality Officer, Sony Mobile Communications AB, Mobilvägen, SE-221 88 Lund, Sweden. For any service or guarantee matters, please refer to the contact details provided in the separate service or guarantee documents.

Use of some content and features may incur separate, additional charges and/or require a qualifying plan, or access to a Wi-Fi connection.

Wi-Fi: Device will not transition between Wi-Fi and the cellular network. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile Terms and Conditions.

Messaging/Data: You will be charged for all messages and data sent by or to you through the network, regardless of whether or not data is received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. Your data session, plan, or service may be slowed, suspended, terminated, or restricted if you use your service in a way that interferes with or impacts our network or ability to provide quality service to other users, if you roam for a significant portion of your usage, or if you use a disproportionate amount of bandwidth during a billing cycle. You may not use your plan or device for prohibited uses.

Downloads/Applications: T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, including any changes that may affect your T-Mobile plan, service, or billing, or any content or website you may be able to access through an App.

Hearing Aid Compatibility: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid

compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Mobile Security: Capable phone required; technical limitations may prevent certain features (e.g., LOCK) from working on certain phones. For a list of eligible devices, visit www.T-Mobile.com/mobilesecurity. Enabling the location history features of Mobile Security can cause your phone's battery life to diminish more quickly. Device must be powered on, have text messaging capability, and be within the T-Mobile coverage area for Mobile Security features to function. Data usage applies for download and use of Mobile Security. As with other software, Mobile Security may be disabled or uninstalled by other applications, software, devices or hacking. In this event the protective features of Mobile Security may not function properly. In addition, even though installed, Mobile Security may not function properly due to other prior installed software on your device.

Devices, accessories, and screen images are simulated. See brochures and Terms and Conditions (including arbitration provision) at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi Calling.

Our support to you – Xperia™ Care



User guide


A User guide is available at www.sonymobile.com.



Support in your device

Get user support directly in your device using the Help application.

To access the Help application

- 1 From your Application screen, find and tap .
- 2 Find and tap the required support item.



Support on the web

Visit www.sonymobile.com to access a range of support and get the most from your device.



Customer support

Customer support – if all else fails. Access the relevant support number at www.sonymobile.com by clicking the **Contact us** link at the bottom of the page.

Learn more

Learn more about how we can support you with Xperia™ Care at www.sonymobile.com/support.

Additional support

For more information and additional support, please visit www.t-mobile.com/support where you can:

- Register for my.t-mobile.com to check your minutes, pay your bill, upgrade your device, and change your rate plan. Review your device's User Manual and troubleshooting FAQs.
- View the latest troubleshooting solutions in the Support Forums or ask a question of your own.

If you are a new T-Mobile customer and your service has not yet been activated, call Customer Care at 1-800-937-8997 and a T-Mobile Activation representative will assist you.

You can also access account and device information from your device.

- 1 From your **Home** screen, tap 
- 2 Find and tap **T-Mobile My Account**

Learn more about your device

You can visit the following sites to learn more about your device:

- Help for Setting Up Your New Android Device: <http://support.t-mobile.com/docs/DOC-2501>.
- Help for Your Device: http://support.t-mobile.com/community/phones_data_devices/android.