

## FCC Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been certified to comply with the limits for a class B computing device, pursuant to FCC Rules. In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Caution: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

# **SPORTABLE SCOREBOARDS<sup>®</sup>**

## **900Mhz Wireless Control System**

**SPORTABLE  
SCOREBOARDS<sup>®</sup>**  
88 SPRUCE STREET  
MURRAY KY 42071  
(502)759-1600

## 900MHz WIRELESS SYSTEM QUICK GUIDE

### Installation:

#### The wireless system consists of:

Receiver module in plastic case with cable.  
Transmitter module with antenna.  
Transmitter interface cable.

**CAUTION:** Prior to connecting the receiver cable to the scoreboard **ENSURE THAT THE 120 VOLT AC POWER IS "OFF"**.

1. Attach the receiver on the scoreboard. Route the receiver signal cable into the input connector box on the back of the scoreboard. Attach the color-coded wires with spade lugs from the receiver cable to the connection block. (Fig.1)
2. Plug the small connector of the transmitter interconnection cable into the side of the transmitter module. Plug the large connector of the transmitter interconnection cable into the back of the Keyboard. Attach transmitter to keyboard as shown. (Fig.2)
3. Plug in the wall transformer and turn **ON** the keyboard power switch. If keyboard is battery powered, just turn on the power switch. Wait for the message:

**To Continue Last Game Press Enter**  
**To Start New Game Press Reset.**

4. Press the **RESET** key and wait for the **LCD** display to show the game display. Make sure you are in the desired game. If not, refer to Instruction Manual-Options Menu.
5. If control seems intermittent or the scoreboard is mounted very close to metal, or high powered lighting you may have to move the receiver around to get the best signal.

**NOTE!** If the Scoreboard goes off after 45 seconds, the keyboard is not communicating with the scoreboard. Check your plug-in connections.

### BATTERY OPTION:

Keyboard with the battery option installed should have the charger wall transformer plugged into the keyboard and a live 120VAC-wall outlet when the Keyboard is not in use. Make sure the keyboard power switch is turned OFF. The battery charger is fully automatic and will not overcharge the battery. You should charge the internal battery for a period at least of 8 hours prior to first use.

Refer to the instruction manual for more detailed instruction and information on the operation of your scoreboard.




Fig.1




Fig.2