SINRE &

HOW TO USE THE RF KEYBOARD

- 1. Insert the receiver into the USB port.
- 2. Your operation system will start to install the receiver automatically. And you can see the information as below display in your computer.
- 3. In Win98/Me operation system you need to follow the instructions on your screen. During the install process, the O/S may ask you to put Win98 CD into the CD-ROM.
- 4. After the install process finished, the keyboard will be working.

Better than other competition:

- 1. RF (2.420GHz) Any angle, up to 7 Meters.
- 2. 256 ID and RF-technique to Anti-interference.
- 3. No matter what PC Off or Battery Out, The ID will not be lost.

Notice:

If the keyboard is not working:

- 1. Maybe no power, please check your battery .
- 2. Maybe different ID, please link ID.
 - (1). push the button on Receiver.
 - (2). press "Fn" key on keyboard within 3 SEC .

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Specifications

Electrical/RF KEYBOARD Battery AAA * 4

Power ConsumptionPower: 6VDC, +/-5%Low power:4.4VDCWorking mode : 8mA,MAXStandby mode : 5mASleep mode:80uA(after 3 minutes)

RF specificationFrequency: 2.420GHzModulation mode:G FSKChannel: 1chsID number: 256Link: "Fn" KeyEffective distance: 7M

Mouse function Touch Pad +2 buttons

Compatible with Windows Windows 98/ME/2000/XP

Mechanical specification

Dimension 370(L) * 176(W) * 28.5(H)mm Weight 490g (No battery).

Receiver Specification

Electronics specification Power consumption 5VDC, ±5%,60mA Maximum

RF specificationFrequency: 2.420GHzModulation mode : GFSKChannel: 1chID number: 256Link: "SW" KeyEffective distance : 7M

Compatible with Windows Windows 98/ME/2000/XP

Mechanical specification

Dimension 40(L) * 20(W) * 5(H)mm

Weight 12g max.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.