

SUPERTOYS**RADIO CONTROL****STREET LUGE WITH ARTICULATED FIGURE!**

ITEM/Art # 4271
All Rights World-Wide Reserved
SUPERTOYS U.S.A., INC.
200 57TH AVE., ROOM 201 NEW YORK,
NY 10019 U.S.A.
CAUTION: NOT SUITABLE FOR CHILDREN
UNDER 36 MONTHS DUE TO SMALL PARTS
MADE IN CHINA

Another quality product from **SUPERTOYS**
COLOURS AND DECORATION MAY VARY

INSTALLING BATTERIES

WARNING: Dispose of old batteries promptly and properly. Do not burn or bury them.

CAUTIONS:

- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

If you do not plan to use the Street Luge for a week or more, remove the batteries from both the transmitter and the Street Luge. Batteries can leak chemicals that can destroy electronic parts.

CONTROLLER BATTERY INSTALLATION

Use a Phillips head screw driver to remove the battery compartment cover located on the back of the controller. Insert 1 "9V." alkaline battery in the correct position as marked in compartment. Replace cover and screw.

STREET LUGE INSTALLATION

Your Street Luge uses 4 "AA" batteries or a 6V rechargeable battery pack for power. You can use the AA batteries while the battery pack is charging.

1. Slide OFF/ON on the bottom of the Street Luge to OFF.
2. If you are using AA batteries, place them in the supplied battery box according to the polarity symbols (+ and -) marked inside. Then turn the box over so the batteries face in toward the Street Luge and snap it into the battery compartment. Then slide the box in the direction of arrow.

If you are using a 6V rechargeable battery pack, place it in the battery compartment according to the polarity symbols (+ and -) marked inside. Then slide it in the direction of arrow.

Note: Be sure to line up the metal contacts on the battery pack, or battery box, with the contacts inside the compartment.

3. Turn the battery compartment latch to lock the compartment.

RADIO CONTROL DRIVING

1. Slide ON/OFF to ON. The top button on the driver's suit lights.
2. Fully extend the antenna on the transmitter and slide OFF/ON on the transmitter to ON. The indicator on the transmitter lights.
3. Use the transmitter's control levers to move and steer the Street Luge.
4. When you finish driving the Street Luge, slide OFF/ON on the Street Luge and the transmitter to OFF.



WHEEL ALIGNMENT

If the Street Luge does not drive in a straight line when you release the right control lever, adjust the wheel alignment control between the front wheels on the bottom of the Street Luge.

Turn the control toward L if the Street Luge is pulling to the right, or toward R if the Street Luge pulling to the left.

Helpful hints for maintenance and performance.


1. Check batteries frequently.
2. Always replace with fresh alkaline batteries.
3. Check battery terminals for contact.
4. Always turn switch off when not in use.
5. Run on smooth level surfaces.

**HOW TO RECHARGE THE NI-CD BATTERY PACK**


The newly purchased NI-Cd Pack (6.0V, 620mAh) is not charged. Recharge before starting.

How to use the special charger (6.0V 180mA) for NI-Cd Packs:

- Plug the charger into an ordinary household outlet.
- The (LED) light on the charger should light up when the battery pack is being charged.
- Average recharging time is approximately 4 to 5 hours.



When the recharging is over, remove the charger from the household outlet and disconnect the battery connector from the charger.

**WARNING**

- Do not charge the Battery Pack immediately after use. Wait until it is cooled before charging.
- Be sure to observe the indicated charging time. The NI-Cd Battery Pack and SUPERTOYS Charger (6.0V 180mA) are designed to be charged for 4 to 5 hours. Do not charge for over 5 hours.
- Avoid short circuits. Short circuits will cause overheating, burning of the cords and other damages to the Battery Pack and Charger.
- The NI-Cd Battery Charger should be used for charging one Battery Pack (6.0V, 620mAh). Do not use the Charger for charging more than one Battery Pack at a time, or for charging other types of batteries and battery packs.
- Do not use the Charger as a direct current outlet for other electrical appliances or machines.
- Make sure that the Battery Pack and Charger are kept out of the hands of infants and small children while charging.

- Do not charge near fires, where the temperature is extremely high, or where it is wet or damp.
- The Charger will become slightly heated while charging. Allow sufficient free space around the Charger.
- If the power of the battery pack is weak in spite of proper charging. The batteries may be worn out from repeated use. Replace it with a new NI-Cd battery pack.
- Dispose of used NI-Cd battery packs correctly.
- Disconnect the supply before making or breaking connections to the battery.
- The charger used with the toy are to be regularly examined for damage to the plug, enclosure and other parts, and that in the event of such damage, the toy must not be used with this charger until the damage has been repaired.
- The toy must only be used with the recommended transformer.
- The charger is not a toy.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. **Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.