


Instruction Manual for CQL1450-C

Button Specification:

1. PREVIOUS
2. NEXT
3. ALARM
4. POWER/SNOOZE/  / II
5. CLOCK
6. VOLUME UP
7. VOLUME DOWN

Power for Bluetooth Speaker

- ✧ Use the power adaptor (included) and insert the jack into the micro hole named “Charging” at the back of the unit.
- ✧ The LED screen will display the time (bright white color) once the unit is charging.

Power for Time Memory

- ✧ An internal rechargeable Lithium battery supplies power for time memory. The time track will still go on if the USB cable is plugged out.


To Charge the Unit

- ✧ Use the power adaptor (included), insert the jack into “Charging” jack located at the back of the unit for charging the internal battery. Please charge your speaker fully before first use.

To Charge Out:

- ✧ To charge your digital device, use a USB cable, insert the large end into to the big hole named “USB 5V” at the back and insert the small end of the USB cable to your digital device.

Time Setting



- ✧ Long press “CLOCK” key, the hour will start to blink. Press the “+” & “-” to change the hour figures.
- ✧ Quick press “CLOCK” key immediately after finishing setting the hour. The minutes will start to blink. Press the “+” & “-” to change the minute figures.
- ✧ Quick press the “CLOCK” key one more time to finish the time setting
- ✧ The time format is 12-hour and “PM” on the top left corner will show its afternoon time.
- ✧ When the Bluetooth function is shut down, quick press the “POWER/SNOOZE/  / II” key to turn on/ off the LED CLOCK screen.

Alarm Setting

- ✧ Under the normal mode, press “ALARM” key to enter the alarm setting. The alarm logo located at the bottom left corner on the display will become bright.

- ✧ Long press the “ALARM” key, the hour figure will start to blink quickly for a resetting. Press “+” & “-” to change the hour figures.
- ✧ After the hour is set, quick press “ALARM” key to set the minutes. Press “+” & “-” to change the minute figures.
- ✧ Quick press “ALARM” key one more time to set the alarm time. After 1 second, the LED will automatically go back to the normal CLOCK mode.
- ✧ To check the alarm time you have set at any time, quick press the “ALARM” key. The LED screen will jump to the time set and then back to the normal time mode again.
- ✧ To cancel any alarm you have set, press the “ALARM” key to ensure the alarm logo on the left bottom corner is not bright any more.

Bluetooth Speaker Operation

- ✧ Turn on the unit by pressing the “POWER/SNOOZE/  / II” button. A sound will be heard and a blue light at the back of the unit will start blinking to indicate the speaker is in pairing mode and searching for your Bluetooth mobile device.
- ✧ Bluetooth speaker device name is “CQ-L1450-T”, connect it via the option menu of your mobile device, pairing mode is 0000 if any is required. The Blue light will begin to flash slowly after the pair is complete.
- ✧ Start playing music on your device. Keep your device within 33 feet (10m) of your speaker.
- ✧ Adjust the volume of your device to a comfortable level. Or you can press the “+” & “-” on the speaker to control the volume.
- ✧ Press the “PREVIOUS” and “NEXT” button to skip your previous and next songs you would like to listen.
- ✧ Long press the “POWER/SNOOZE/  / II” button to shut down the Bluetooth function. The blue light in the back of the unit will turn off.

Universal Speaker Operation:


- ✧ For other music devices without Bluetooth, use the auxiliary audio input cable. Insert the 3.5mm jack into the “Aux-in” hole and the earphone hole on your device.
- ✧ Turn on the unit and start playing music.

Wake Up Operation


- ✧ The wake up function will work only if the USB cable is connected and the USB cable supplies power to your Bluetooth speaker.

Wake Up Under Bluetooth Connected:


- a. Turn on the device and connect the device with your phone via Bluetooth.
- b. Set the alarm and activate the alarm function.

- c. If your Bluetooth is connected with your speaker, stop the music, when the alarm time is up, the alarm will play your music again with the same song and same volume. At the same time, the alarm logo at the bottom left corner will start blinking.
- d. Press the “ALARM” key to stop the blinking (To cancel the alarm you have set, you have to press the “ALARM” key one more time to ensure the alarm logo is not bright any more). Press the “POWER/SNOOZE/ / II” key to stop the alarming music.

Wake Up Under Bluetooth Not Connected:

- a. Turn on the speaker.
- b. Set the alarm and activate the alarm function.
- c. When the alarm time is up, the speaker will start to play “BiBi” sound from lower to higher volume. At the same time, the alarm logo at the bottom left corner will start blinking.
- d. Press the “ALARM” key to stop the blinking (To cancel the alarm you have set, you have to press the “ALARM” key one more time to ensure the alarm logo is not bright any more). Press the “POWER/SNOOZE/ / II” key to stop the alarming sound.

Snooze:

- ✧ When the alarm starts to play music or “BiBi”, press the “POWER/SNOOZE/ / II” button to stop the alarm and have 10 minutes’ sleep. After 10 minutes, the alarm will be sounded again. The process will repeat.
- ✧ Press the “ALARM” key to cancel the alarm.

Caution:

- ✧ This is not a toy. Please keep away from children.
- ✧ Please keep away from water/heat.
- ✧ Low power may cause poor connection even no working of Bluetooth.
- ✧ Do not overcharge the battery.

NOTE:

- ✧ The internal lithium battery only supplies power for time memory. The time goes on if the USB cable is not connected with the unit.
- ✧ The USB adaptor supplies power for speaker. During the music is playing, if plugging out the USB cable, the unit will be power-off and music will stop.
- ✧ When the Alarm time is up, the speaker will first try to find the connected mobile phone. If the phone is not found or Bluetooth is not connected, the alarm will start to sound “BiBi” 28 seconds after the time is up.
- ✧ To ensure waking up to the alarming music, please do not mute the music on your phone.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation