

192.168.2.123.

Static Assignment

IP Address 192.168.2. 123

MAC Address 44 : 37 : E6 : 4F : 37 : 3B

Index	IP Address	MAC Address	Delete
1	192.168.2.123	44:37:E6:4F:37:3B	<input type="button" value="Delete"/>

DHCP Client List

Host Name	IP Address	MAC Address	Lease Time
INVE-20130508IP	192.168.2.100	C8:9C:DC:3B:AC:89	23:59:29

Help

The DHCP Client List displays information of devices that have obtained IP addresses from the device's DHCP Server. If you would like some devices on your network to always have the same IP addresses, you can use this feature and manually add a static DHCP Reservation entry for each such device.

Important: To activate new settings, you must click the Save button.

Note: Remember to reboot device after you finish.

Configuration Procedures:

- ① Enter the last number of the IP address you want to reserve, for example, 123.
- ② Enter the MAC address of 44:37:E6:4F:37:3B.
- ③ Click **Add**.
- ④ Click **Save** to save your settings.



Tip

1. If the IP address you have reserved for your PC is currently used by another client, then you will not be able to obtain a new IP address from the device's DHCP server, instead, you must manually specify a different IP address for your PC to access Internet.
2. For PCs that has already obtained IP addresses, you may need to perform the Repair action to activate the configured static IP addresses.

3 Wireless Settings

This section includes the following:

Basic

Security

Access Control

Connection Status

- To configure wireless network name, channel and other basic wireless settings, see **Wireless - Basic**.
- To secure your wireless network, see **Wireless Security**.
- To restrict access to your wireless network, see **Access Control**.
- To see who are connecting to your wireless network, see **Connection Status**.

3.1 Wireless-Basic

Here you can configure the basic wireless settings of the router.



Tip

1. The SSID is Tenda_XXXXXX by default, where XXXXXX is the last six characters in the device's MAC address. You can find it on the label attached on the bottom of the device.
2. If you are not an advanced user, it is advisable to only change the SSID (name of the network) and channel and leave other items unchanged.

Tenda®								
Wizard	Status	Basic	Wireless	Security	Advanced	Bandwidth Control	Tools	
Basic			Wireless					Help This section allows you to config basic wireless settings. It is advisable that you only config the SSID and channel settings and leave other items unchanged. SSID: This is the public name of your wireless network. Broadcast SSID: Wireless clients find your wireless network by performing a scan to see what's available. When enabled, your wireless network is visible to any wireless clients within coverage when they scan for a wireless network; when disabled, your wireless
Security			Enable Wireless	<input checked="" type="radio"/> Enable <input type="radio"/> Disable				
Access Control			802.11 Mode	11b/g/n Mixed Mode				
Connection Status			SSID	Tenda_762038				
			BSSID	C8:3A:35:76:20:38				
			SSID Broadcast	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled				
			Channel	2472MHz (Channel 13)				
			Channel Bandwidth	<input type="radio"/> 20 <input checked="" type="radio"/> 20/40				
			Extension Channel	2452MHz (Channel 9)				
			Save		Cancel			

Configuration Procedures:

- ① **SSID:** This is the public name of your wireless network.
- ② **Channel:** Select a channel or select Auto to let system automatically select one for your wireless network to operate on if you are unsure. The best selection is a channel that is the least used by neighboring networks.
- ③ Click **Save** to save your settings.

**Knowledge Center**-----

1. **Network Mode (802.11 Mode):** Select a correct mode according to your wireless clients.
 - **11b:** This network mode delivers wireless speed up to 11Mbps and is only compatible with 11b wireless clients.
 - **11g:** This network mode delivers wireless speed up to 54Mbps and is only compatible with 11g wireless clients.
 - **11b/g mixed:** This network mode delivers wireless speed up to 54Mbps and is compatible with 11b/g wireless clients.
 - **11b/g/n mixed:** This network mode delivers wireless speed up to 300Mbps and is compatible with 11b/g/n wireless clients.
 2. **BSSID:** This is the MAC address of the device's wireless interface.
 3. **SSID Broadcast:** This option allows you to have your network names (SSIDs) publicly broadcast or if you choose to disable it, the SSIDs will be hidden.
 4. **Channel Bandwidth:** Select a proper channel bandwidth to enhance wireless performance. This option is available only in 802.11b/g/n. Wireless speed in the channel bandwidth of 20/40 is 2 times in 20.
 5. **Extension Channel:** This is used to ensure N speeds for 802.11n devices on the network. This option is available only in 11b/g/n mixed mode with channel bandwidth of 20/40.
-
-

3.2 Wireless Security

Click **Wireless** -> **Security** to enter the Security screen. Here you can define a security key to secure your wireless network against unauthorized accesses.

The screenshot shows the Tenda Wireless Security configuration interface. The top navigation bar includes 'Wizard', 'Status', 'Basic', 'Wireless', 'Security', 'Advanced', 'Bandwidth Control', and 'Tools'. The 'Security' tab is active. The main content area is titled 'Wireless Security' and displays the following settings:

- SSID: "Tenda_762038"
- Security Mode: WPA2-PSK (selected from a dropdown menu)
- WPA Cipher Type: AES (selected with a radio button), TKIP, TKIP&AES
- Security Key: Please enter a valid key. (text input field)
- Key Renewal Interval: 86400 seconds (text input field)

A note at the bottom of the configuration area reads: "802.11n ONLY defines Open=None(Disable), WPA-PSK-AES and WPA2-PSK-AES encryption methods. Other encryptions are not standardized and thus may be incompatible among different manufacturers. Tenda optimizes wireless security. Selecting AES under WPA will effectively protect your network against unauthorized accesses." At the bottom of the page, there are 'Save' and 'Cancel' buttons.

- ① Configure security mode, cipher type and security key.
- ② Click **Save** to save your settings.



Knowledge Center-----

1. **WEP:** WEP is intended to provide data confidentiality comparable to that of a traditional wired network.
2. **Open:** Wireless speed can reach up to 54Mbps if WEP - Open is selected.
3. **Shared:** Wireless speed can reach up to 54Mbps if WEP - Shared is selected.
4. **Mixed WEP:** Compatible with both Open and Shared. Clients can connect to your wireless network either using Open or Shared
5. **Default Key:** Select a key to be effective for the current WEP encryption. For example, if you select Key 2, wireless clients must join your wireless network using this Key 2.
6. **WPA-PSK:** WPA personal, support AES and TKIP cipher types.
7. **WPA2-PSK:** WPA2 personal, support AES, TKIP and TKIP+AES cipher types.

8. WPA/WPA2-PSK mixed: If selected, both WPA-PSK and WPA2-PSK secured wireless clients can join your wireless network.

9. AES: If selected, wireless speed can reach up to 300Mbps.

10. TKIP: If selected, wireless speed can reach up to 54Mbps.

11. TKIP+AES: If selected, both AES and TKIP secured wireless clients can join your wireless network.

12. Key Renewal Interval: Enter a valid time period for the key to be changed.

3.3 Access Control

Specify a list of devices to "Permit" or "Forbid" a connection to your wireless network via the devices' MAC Addresses. Click **Wireless -> Access Control** to enter the configuration screen.

There are three options available: Disable, Deny and Allow.

A. If you want to allow all wireless clients to join your wireless network, select

Disable.

B. If you want to allow ONLY the specified wireless clients to join your wireless network, select

Allow.

C. If you want to disallow ONLY the specified wireless clients to join your wireless network, select

Deny.

Wireless Access Control Application Example:

To only allow your own notebook at the MAC address of C8:3A:35:CC:34:25 to join your wireless network

Tenda

Wizard Status Basic **Wireless** Security Advanced Bandwidth Control Tools

Basic
Security
Access Control
Connection Status

Access Control

Configure the wireless interface MAC address filtering policy.

MAC Filter: Allow

MAC Address: C8 : 3A : 35 : CC : 34 : 25 Action: Add

Index	MAC Address	Delete
1	C8:3A:35:CC:34:25	Delete

Save Cancel

Help

Specify a list of devices to allow or disallow a connection to your wireless network via the devices' MAC addresses. To deactivate this feature, select "Disable"; to activate it, select "Allow" or "Deny".

Configuration Procedures:

- ① Select **Allow**.
- ② Enter the MAC address of the wireless device you want to restrict. Here in this example, enter C8:3A:35:CC:34:25.
- ③ Click **Add** to add the MAC address to the MAC address list.
- ④ Click **Save** to save your settings.




Tip

Up to 16 wireless MAC addresses can be configured.

1. If you don't want to configure the complex wireless security settings and want to disallow others to join your wireless network, you can configure a wireless access control rule to allow only your own wireless device.

3.4 Connection Status

Click **Wireless -> Connection Status**. Here you can see a list of wireless devices connected to the router.



The screenshot shows the Tenda router's web interface. The top navigation bar includes 'Wizard', 'Status', 'Basic', 'Wireless', 'Security', 'Advanced', 'Bandwidth Control', and 'Tools'. The 'Wireless' tab is active. On the left sidebar, 'Connection Status' is selected. The main content area is titled 'Wireless Connection Status' and contains the following text: 'This section displays info of connected clients.' Below this is a 'Currently Connected Clients' section with a 'Refresh' button and a table with columns for 'ID', 'MAC Address', and 'Bandwidth'. To the right, a 'Help' section states: 'This section displays info of connected wireless clients. MAC: Wireless MAC address of a current host.'



Tip

1. The bandwidth here refers to the channel bandwidth instead of wireless connection rate. You can know whether there are unauthorized accesses to your wireless network by viewing the wireless client list.

4 Security

This section includes the following:

Client Filter

MAC Filter

URL Filter

Remote Web Management

- To restrict your LAN PCs to access certain services on Internet via their IP addresses, see **Client Filter**.
- To restrict your LAN PCs to access Internet via their MAC addresses, see **MAC Filter**.
- To restrict your LAN PCs to access certain websites on Internet via URL, see **URL Filter**.
- To enable the remote web management feature, see **Remote Web Management**.

4.1 Client Filter

This section allows you to set the times specific clients can or cannot access the Internet via the devices' assigned IP addresses and service port. Click **Security** to enter the configuration screen.



Knowledge Center

1. Default: The default policy for the client filter. For the packets that do not match the set rule, the default rule is applied.

2. Filter Mode: Specify a filter mode for the rule.

- **Deny:** Disallow the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default policy is applied.
- **Allow:** Allow the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default policy is applied.

Client Filter Application Example:

To prohibit PCs within the IP address range of 192.168.2.110–192.168.2.111 from accessing web pages during the time period of 8:00~18:00 from Monday to Friday.

Configuration Procedures:

Click **Add** to add a filter rule.

Client Filter Setting

Filter Mode:

Description:

IP: ~
(Specify a single IP address or an IP range)

WAN Port Range: ~

Type:

Time: : ~ :

Day: EveryDay Sun Mon Tue Wed Thu Fri Sat

Help

This section allows you to set the times specific clients can or cannot access the Internet via the devices' assigned IP addresses and port numbers. You can set the access restriction or permission in details. Be sure to statically assign IP address of the devices you wish to filter for this function to be consistent. For more information, see User Guide.

Tips: To add a new rule, simply click the Add button ; to edit an existing rule, simply click the Edit or Change button next to it.

Deny: Disallow clients at

- ① **Filter Mode:** Select **Deny**.
 - ② **Description:** Briefly describe the current rule. This field is optional.
 - ③ **IP:** Enter a starting IP address. Here in this example, enter 192.168.2.110. Enter an ending IP address. Here in this example, enter 192.168.2.111.
 - ④ **WAN Port Range:** Enter a service port number. Here in this example, enter 80 (HTTP (port 80) is the standard protocol for web servers.).
 - ⑤ **Traffic Type:** Select a protocol for the traffic. If you are unsure, select **Both**.
 - ⑥ **Time:** Specify a time period for the current rule to take effect. Here in this example, select 8:00~18:00.
- Day:** Select a day, or several days of the week for the current rule to take effect. Here in this example, select Mon, Tue, Wed, Thur and Fri.
- ⑦ Click **Save** to save your settings.
 - ⑧ **Enable Client Filter:** Check to enable or uncheck to disable the client filter feature.
 - ⑨ Select **Allow** from the **Default** drop-down list and then click **Save**.

Client Filter

Enable Client Filter

Default **Allow** Access from clients NOT included in below list to Internet

Mode	IP	Port	Type	Time	Day							Action
					S	M	T	W	T	F	S	
Deny	192.168.2.110-192.168.2.111	80-80	Both	08:00-18:00	x	√	√	√	√	√	x	<input type="button" value="Edit"/> <input type="button" value="Del"/>

Help

This section allows you to set the times specific clients can or cannot access the Internet via the devices' assigned IP addresses and port numbers. You can set the access restriction or permission in details. Be sure to statically assign IP address of the devices you wish to filter for this function to be consistent. For more information, see User Guide.

Tips: To add a new rule, simply click the Add button ; to edit an existing rule, simply click the Edit or Change button next to it.

Deny: Disallow clients at specified IP address(es) to access Internet.



Tip

1. The valid service port number range is from 1 to 65534.
2. Up to 10 filter rules can be configured.
3. If you have not set up the system time for this device, click **Tools -> Time & Date** to set up correct time and date for the rules to be effective.

4.2 MAC Filter

This section allows you to restrict specific clients to access the Internet via the devices' MAC addresses. Each PC has at least an installed network adapter with a unique MAC address. Click **Security -> MAC Filter** to enter the configuration screen.



Knowledge Center

1. Default: The default policy for the URL filter. For the packets that do not match the set rule, the default rule is applied.

2. Filter Mode: Specify a filter mode for the rule.

- **Deny:** Disallow the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default policy is applied.
- **Allow:** Allow only the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default rule is applied.

MAC Filter Application Example:

Your router functions as an active DHCP server and delivers an unsecured wireless network. From time to time, you suffer from slow network speed and start to suspect unauthorized accesses to your network. You can set MAC filter rules to allow only your PC at 00:E4:A5:44:35:69 and your wireless device at 00:E4:A5:44:35:6A to access Internet via this router.

Configuration Procedures:

- ① Click **Add** to add a filter rule.


- ② **Filter Mode:** Select **Allow**.
- ③ **Description:** Briefly describe the current rule. This field is optional.
- ④ **MAC Address:** Specify the MAC address of the computer that you want to restrict, 00:E4:A5:44:35:69.



Tip-----


If the device already connects to your router, you can simply select its MAC address from the MAC address list drop-down list.

- ⑤ **Time:** Use the default settings. When Time is set to 0:00 to 0:00, the rule will be applied 24 hrs/day.
- ⑥ **Day:** Select a day, or several days of the week for the current rule to take effect. Here in this example, select **Everyday**.
- ⑦ Click **Save** to save your settings.
- ⑧ Repeat steps 1-7 to configure a rule for the MAC address "00:E4:A5:44:35:6A".



⑨ **Enable MAC Filter:** Check to enable or uncheck to disable the MAC filter feature.

⑩ Select **Deny** from the **Default** drop-down list and then click **Save**.





Tip

1. Up to 10 MAC filter rules can be configured.
2. If you have not set up the system time for this device, click **Tools -> Time & Date** to set up correct time and date for the rules to be effective.

4.3 URL Filter

This section allows you to control URL access. Click **Security -> URL Filter** to enter the configuration screen.



Knowledge Center

1. Default: The default policy for the URL filter. For the packets that do not match the set rule, the default rule is applied.

2. Filter Mode: Specify a filter mode for the rule.

- **Deny:** Disallow the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default policy is applied.
- **Allow:** Allow only the packets that match the set rule to pass the router. For other packets that do not match the set rule, the default rule is applied.

URL Filter Application Example:

To prevent your home PC (192.168.2.120) from accessing “YouTube” from 8:00 to 18:00 during working days: Monday- Friday.

Configuration Procedures:

- 1 Click **Add** to add a filter rule.

URL Filter Setting

Filter Mode:

Description:

IP: ~

URL String:
Each URL string includes up to 24 characters.

Time: : ~ :

Day: EveryDay Sun Mon Tue Wed Thu Fri Sat

Help

This section allows you to control URL access. You can set the access restriction in details to allow or disallow specified PCs to access certain websites. For more information, see User Guide.

Tips: To add a new rule, simply click the Add button; to edit an existing rule, simply click the Edit or Change button next to it.

Note: Each URL String can include up to 24 characters. Different URL strings must be separated by a comma. Up to 10 rules can be added!

- 2 **Filter Mode:** Select a filter mode. Here in this example, select **Deny**.
- 3 **Description:** Briefly describe the current rule. This field is optional.
- 4 **IP Address:** Enter the IP address you wish to restrict. Here in this example, enter "192.168.2.120".
- 5 **URL String:** Enter part of or the entire domain name of the web site you wish to restrict. Separate different domain names or domain name key words with a comma, for example, "YouTube, Hollywood.com".
- 6 **Time:** Specify a time period for the current rule to take effect. Here in this example, select 8:00~18:00.
- Day:** Select a day, or several days of the week for the current rule to take effect. Here in this example, select Mon, Tue, Wed, Thur and Fri.
- 7 Click **Save** to save your settings.

URL Filter

Enable URL Filter

Default: Deny Access to URL not included in below list

Mode	IP	URL	Time	Day							Action
				S	M	T	W	T	F	S	
Deny	192.168.2.120-192.168.2.120	YouTube	08:00-18:00	x	√	√	√	√	√	x	Edit Del

Delete All Add

Save Cancel

Help

This section allows you to control URL access. You can set the access restriction in details to allow or disallow specified PCs to access certain websites. For more information, see User Guide.

Tips: To add a new rule, simply click the Add button ; to edit an existing rule, simply click the Edit or Change button next to it.

Note: Each URL String can include up to 24 characters. Different URL strings must be separated by a comma. Up to 10 rules can be added!

Note: Rule will be applied 24 hrs/day if Time is set to "0:0" ~ "0:0". Be sure to set the system time correctly in Tools to make this time based function effective.

⑧ **Enable URL Filter:** Check to enable or uncheck to disable the URL filter feature.

⑨ Select **Allow** from the **Default** drop-down list and then click **Save**.



Tip-----

1. Different URL strings must be separated with a comma. To match all websites, use * (asterisk).
2. Up to 10 filter rules can be configured.
3. If you have not set up the system time for this device, click **Tools -> Time & Date** to set up correct time and date for the rules to be effective.

4.4 Remote Web Management

The Remote management allows the device to be configured and managed remotely from the Internet via a web browser. Click **Security -> Remote Web Management** to enter the configuration screen.



Tip-----

1. For better security, configure a port number (between 1025-65535) as remote web management interface, do not use the number of any common service port (1-1024).
2. Make sure your WAN IP address (Internet IP address) is a public IP address. Private IP addresses are not routed on the Internet.
3. It is unsafe to make your router remotely accessible to all PCs on external network. For better

security, we suggest that only enter the IP address of the PC for remote management.

Remote Web Management Application Example:

To access your router (WAN IP address: 102.33.66.88) at your home from the PC (218.88.93.33) at your office via the port number 8090

The screenshot shows the Tenda router's web interface. The top navigation bar includes 'Wizard', 'Status', 'Basic', 'Wireless', 'Security', 'Advanced', 'Bandwidth Control', and 'Tools'. The 'Security' tab is selected. On the left sidebar, 'Remote Web Management' is highlighted. The main content area is titled 'Remote WEB Management' and contains the following settings:

- Enable:**
- Port:**
- IP Address:**

Below the input fields are 'Save' and 'Cancel' buttons. On the right, a 'Help' section provides the following information:

Help

The Remote Web Management feature allows the Router to be managed from the Internet via a web browser. To use this feature, Check the Enable Remote Web Management box and specify a Remote Management Port.

Port: Remote admin port; the port used to access the device from Internet or external networks.

Configuration Procedures:

- ① **Enable:** Check to enable the remote Web management feature.
- ② **Port:** This is the management port to be open to outside access. Here in this example, enter 8090.
- ③ **IP Address:** Specify the IP address for remote management. Here in this example, enter "218.88.93.33".
- ④ Click **Save** to save your settings.

Type "http://102.33.66.88:8090" into your browser's address or location field and you can access the router at your home remotely.



Knowledge Center

1. IP Address: Here you can specify the IP address for remote management (When set to **0.0.0.0**, the device becomes remotely accessible to all the PCs on Internet or other external networks).

2. Port: This is the management port to be open to outside access. The default setting is 8080. This can be changed.

5 Advanced Applications

This section includes the following:

DDNS

Port Forwarding

DMZ Host

UPnP

Routing Table

- To remotely access the device via a domain name or access a server on a LAN PC, see **DDNS**.
- To let an Internet user access a server on your LAN PC, see **Port Forwarding**.
- To let an Internet user access your LAN PC without any restriction, see **DMZ Host**.
- To automatically map the ports between WAN and LAN, see **UPnP**.
- To view routes, see **Routing Table**.

5.1 DDNS

Dynamic DNS or DDNS is a term used for the updating in real time of Internet Domain Name System (DNS) name servers. We use a numeric IP address allocated by Internet Service Provider (ISP) to connect to Internet; the address may either be stable ("static"), or may change from one session on the Internet to the next ("dynamic"). However, a numeric address is inconvenient to remember; an address which changes unpredictably makes connection impossible. The DDNS provider allocates a static host name to the user; whenever the user is allocated a new IP address this is communicated to the DDNS provider by software running on a computer or network device at that address; the provider distributes the association between the host name and the address to the Internet's DNS servers so that they may resolve DNS queries. Thus, uninterrupted access to devices and services whose numeric IP address may change is maintained. Click **Advanced** -> **DDNS** to enter the DDNS screen.



Tip

1. To use the DDNS feature, you need to have an account with one of the Service Providers in the drop-down menu first.

2. This router supports five DDNS service providers: dyndns and no-ip.

DDNS Application Example:

If your ISP gave you a dynamic (changing) public IP address, you want to access your router remotely ([6.5 Remote Web Management](#)) but you cannot predict what your router's WAN IP address will be, and the address can change frequently. In this case, you can use a commercial Dynamic DNS service. It lets you register your domain to their IP address and forwards traffic directed at your domain to your frequently changing IP address.

If you obtain the following account from your dyndns.org service provider:

User Name: tenda

Password: 123456

Domain Name: tenda.dyndns.org.

You want to use the PC at 218.58.98.3 to remotely access this router on port number 8090.

The screenshot shows the Tenda router's web interface. At the top, there's a navigation bar with tabs: Wizard, Status, Basic, Wireless, Security, Advanced (selected), Bandwidth Control, and Tools. Below this is a sidebar with menu items: DDNS (selected), Port Forwarding, DMZ Host, UPnP, and Routing Table. The main content area is titled 'DDNS Config' and contains the following fields and controls:


- DDNS Service: Enable Disable
- DDNS Server Provider: A dropdown menu showing 'dyndns' with a 'Register Now' link next to it.
- User Name: A text input field containing 'tenda'.
- Password: A text input field with masked characters (dots).
- Domain Name: A text input field containing 'tenda.dyndns.org'.
- Buttons: 'Save' and 'Cancel' buttons at the bottom.

On the right side, there is a 'Help' section with the following text: "DDNS makes it possible to associate a stable domain name with a dynamically changing WAN IP address. So you can access or establish web/FTP servers, etc on PCs in LAN without worrying about a changing IP. Before configuring any DDNS settings, click 'Register Now' to register a domain name with your DDNS service provider on its website."

Configuration Procedures:

- ① **DDNS Service:** Select **Enable**.
- ② **Service Provider:** Select your DDNS service provider from the drop-down menu. Here in this example, select **dyndns**.
- ③ **User Name:** Enter the DDNS user name registered with your DDNS service provider. Here in this example, enter **tenda**.
- ④ **Password:** Enter the DDNS Password registered with your DDNS service provider. Here in this example, enter **123456**.

- ⑤ **Domain Name:** Enter the DDNS domain name with your DDNS service provider. Here in this example, enter `tenda.dyndns.org`.
- ⑥ Click **Save** to save your settings.
- ⑦ Click **Security -> Remote Web Management**, enable the Remote Web Management feature, enter **8090** in the **Port** field, **218.58.98.3** in the **IP Address** field and then click **Save** to save your settings.



The screenshot shows the Tenda router's configuration interface. The top navigation bar includes tabs for Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The 'Security' tab is active, and the 'Remote Web Management' sub-tab is selected. The main content area is titled 'Remote WEB Management' and contains the following settings:

- Enable:
- Port:
- IP Address:

At the bottom of the settings area are 'Save' and 'Cancel' buttons. On the right side, there is a 'Help' section with the following text:

Help

The Remote Web Management feature allows the Router to be managed from the Internet via a web browser. To use this feature, Check the Enable Remote Web Management box and specify a Remote Management Port.

Port: Remote admin port; the port used to access the device from Internet or external networks.


When the **Connection Status** on this DDNS page displays **Connected**, you can access your router from the Internet by typing your router's domain name into your browser's address or location field on your PC (218.58.98.3) followed by a colon (:) and the remote management port number. Here in this example, enter `http://tenda.dyndns.org:8090`.

5.2 Port Forwarding

You want to share resources on your PC with your friends who are not in your LAN. But, by default, the router's firewall blocks inbound traffic from the Internet to your computers except replies to your outbound traffic. You can use the Port Forwarding feature to create exceptions to this rule so that your friends can access these files from external networks.

When accessing your PC from Internet, type "protocol://xxx.xxx.xxx.xxx:port number" into your browser's address or location field. The protocol and port are the ones used by the service and "xxx.xxx.xxx.xxx" is the WAN IP address of your router. For example, a FTP server uses the ftp protocol and 21 (standard port number).

Click **Advanced -> Port Forwarding** to enter the configuration screen.



Application Example:

As shown in the figure above, your PC at 192.168.0.10 connects to the router and runs a FTP server on port number 21. Your friends want to access this FTP server on your PC from external network.



Tip

To successfully implement the port forwarding feature, note below:

1. Make sure your WAN IP address (Internet IP address) is a public IP address. Private IP addresses are not routed on the Internet.
2. Make sure you enter correct service port numbers.
3. To ensure that your server computer always has the same IP address, assign a static IP address to your PC.
4. Operating System built-in firewall and some anti-virus programs may block other PCs from accessing resources on your PC. So it is advisable to disable them before using this feature.

Port Forwarding

ID	Start Port - End Port	Private IP	Protocol	Enable	Delete
0.	21 - 21	192.168.2.10	Both	<input checked="" type="checkbox"/>	<input type="checkbox"/>
1.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
2.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
3.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
4.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
5.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
6.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
7.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
8.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
9.		192.168.2.	TCP	<input type="checkbox"/>	<input type="checkbox"/>

Well-known Service Port: DNS(53) Add To ID: 0

Save Cancel

Help

Start Port-End Port: WAN service ports.

Enable: Corresponding rule takes effect only if this option is selected.

Delete: Click to delete corresponding rule. Note that you should still click Save to activate your operation.

Add to: Click to add the selected common service port number to the Start Port/End Port box of the rule ID you select.

Port Forwarding allows you to open a range of WAN service ports and redirect all traffic received through such ports to a LAN server at a designated IP address. It allows remote computers, such as PCs from Internet, to access web servers, ftp servers, e-mail servers, gaming and other

Configuration Procedures:

- ① **Start Port:** Enter the starting port number for the service. Here in this example, enter 21.
- End Port:** Enter the ending port number for the service. Here in this example, enter 21.
- ② **Internal IP:** Enter the IP address of your local computer that will provide this service. Here in this example, enter 192.168.2.10.
- ③ **Protocol:** Specify the protocol required for the service utilizing the port(s).
- ④ Check **Enable** to activate this rule.
- ⑤ Click **Save** to save your settings.

If your WAN IP address is 202.33.56.88, when accessing your FTP server from external network, your friends only need to enter <ftp://202.33.56.88:21> in their browsers.

5.3 DMZ Host

The DMZ (De-Militarized Zone) function disables the firewall on the router for one device for a special purpose service such as Internet gaming or video conferencing applications that are not compatible with NAT (Network Address Translation). Click **Advanced** -> **DMZ Host** to enter the DMZ Host screen.



Note

1. DMZ host poses a security risk. A computer configured as the DMZ host loses much of the protection of the firewall and becomes vulnerable to attacks from external networks.
2. Hackers may use the DMZ host computer to attack other computers on your network.

DMZ Host

Note: Once a PC is set to a DMZ host, it will be completely exposed to Internet, and may be vulnerable to attack as firewall settings become inoperative.

Enable

DMZ Host IP

Save Cancel

Help

The DMZ (De-Militarized Zone) function disables the firewall on the router for one device for a special purpose service such as Internet gaming or video conferencing. Be sure to statically set the IP Address of the DMZ host for this function to be consistent. Enter the static IP address of the PC on your LAN which you want to set as a DMZ host. Once enabled, the DMZ host loses protection from device's firewall and becomes vulnerable to attacks.

Configuration Procedures:

- ① **DMZ Host IP Address:** The IP Address of the device for which the router's firewall will be disabled. Be sure to statically set the IP Address of that device for this function to be consistent.
- ② **Enable:** Check to enable the DMZ host.
- ③ Click **Save** to save your settings.

**Tip**

1. Be sure to statically set the IP Address of the computer that serves as a DMZ host for this function to be consistent.
2. Security softwares such as anti-virus software and OS built-in firewall, etc may affect the DMZ host feature. Disable them if DMZ host fails.

5.4 UPnP

The Universal Plug and Play (UPnP) feature allows network devices, such as computers from Internet, to access resources on local host or devices as needed. UPnP-enabled devices can be discovered automatically by the UPnP service application on the LAN. If you use applications such as multiplayer gaming, peer-to-peer connections, real-time communications such as instant messaging, or remote assistance (a feature in Windows XP), you may need to enable Universal Plug and Play (UPnP) for better experience.

Click **Advanced** -> **UPnP** to enter the UPnP screen. The UPnP feature is enabled by default.

The screenshot shows the Tenda web interface with the 'Advanced' tab selected. The 'UPnP' sub-tab is active, displaying the configuration for Universal Plug and Play. The 'Enable UPnP' checkbox is checked. There are 'Save' and 'Cancel' buttons. A 'Help' section on the right provides information about the UPnP feature.

Tenda

Wizard Status Basic Wireless Security **Advanced** Bandwidth Control Tools

DDNS
Port Forwarding
DMZ Host
UPnP
Routing Table

UPnP

Enable UPnP

Save Cancel

Help

The Universal Plug and Play (UPnP) feature allows network devices, such as computers from Internet, to access resources on local host or devices as needed. UPnP-enabled devices can be discovered automatically by the UPnP service application on the LAN. Presently, it is only supported by operating systems like Windows ME and Windows XP or later.

5.5 Route Table

Click **Advanced** -> **Route Table** to view the router's route table.




Knowledge Center

1. **Destination IP:** The IP address of the final destination. "0.0.0.0" indicates any network segment.
2. **Subnet Mask:** The subnet mask for the specified destination.
3. **Gateway:** This is the next router on the same LAN segment as the router to reach.
4. **Hop:** This stands for the number of routers between your network and the destination.
5. **Interface:** The interface between your router and the final destination.

6 Bandwidth Control

If there are multiple PCs behind your router competing for limited bandwidth resource, then you can use this feature to specify a reasonable amount of bandwidth for each such PC, so that no one will be over stuffed or starved to death. Click **Bandwidth Control** to enter the configuration interface.



Tip

1. 1M=128KByte/s.
2. The volume of uplink traffic/downlink traffic should not be larger than that allowed on your router's WAN (Internet) port. You can ask your ISP to provide the volume of Internet traffic.
3. The bandwidth for ADSL/DSL line usually refers to the download bandwidth.

Bandwidth Control Application Example:

You share a 4M-broadband service with your neighbor (at 192.168.2.125). He always downloads a

large volume of data from Internet, which sharply frustrates your Internet surfing experience; you can use this feature to set limits for the volume of Internet traffic he can get. For example, you can split the 4M into two, so your neighbor can only use up to 2M Internet traffic and you can enjoy 2M.

The screenshot shows the Tenda router's web interface for the Bandwidth Control feature. The navigation tabs include Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The Bandwidth Control page has a left sidebar with 'Bandwidth Control' selected. The main content area is titled 'Bandwidth Control' and contains the following configuration options:

- Enable Bandwidth Control:** Enable
- IP Address:** 192.168.2. ~
- Upload Limit:** KB/s(Max Traffic)
- Download Limit:** KB/s(Max Traffic)
- Enable:**
- Buttons:** Add to List, Save, Cancel

Below the configuration options is a table showing the current rule:

ID	IP Range	Uplink	Downlink	Enable	Edit	Delete
1	192.168.2.125~125	32	256	√	Edit	Delete

On the right side, there is a 'Help' section with the following text:

Help

Use this section to manage bandwidth allocation to devices on your LAN.

Upload/Download Limit: Set a limit to regulate upload/download bandwidth of PCs on the LAN.

Upload/Download Limit: Set a upload/download limit on specified PC(s).

Configuration Procedures:

- ① **Enable Bandwidth Control:** Check the **Enable** box to enable the Bandwidth Control feature.
- ② **IP Address:** Enter the last number of the IP address. Here in this example, enter 125 in both boxes.
- ③ **Upload Limit:** Set a limit to regulate upload bandwidth of PCs on the LAN. Here in this example, enter 32 in both boxes.
- ④ **Download Limit:** Set a limit to regulate download bandwidth of PCs on the LAN. Here in this example, enter 256 in both boxes.
- ⑤ **Enable:** Check to enable the current rule.
- ⑥ **Add to List:** Click to add current rule to the rule list.
- ⑦ Click **Save** to save your settings.

7 Tools

This section explains the following:

Time & Date

Firmware Upgrade

Backup & Restore

Restore Factory Default

Change Password

Logs

Reboot

- To configure system time, see [**Time & Date**](#).
- To upgrade firmware, see [**Firmware Upgrade**](#).
- To backup or restore configurations, see [**Backup & Restore**](#).
- To restore factory default settings, see [**Restore to Factory Default Settings**](#).
- To change login password, see [**Change Password**](#).
- To view system and WAN logs, see [**Logs**](#).
- To restart device, see [**Reboot**](#).

7.1 Time& Date

Click **Tools -> Time & Date** to enter the time screen.



Tip-----

Configured time and date info will be lost if the device gets disconnected from power supply. However, it will be updated automatically when the device reconnects to Internet. To activate time-based features (e.g. firewall), the time and date info shall be set correctly first, either manually or automatically.

A. Sync with Internet time servers

The screenshot shows the Tenda web interface for configuring the Time & Date settings. The interface includes a navigation menu with options: Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The Time & Date section is selected, showing the following configuration options:

- Internet Time Server:
- Sync Interval: 2 hours
- Time Zone: (GMT+08:00)Beijing,Chongqing,H
- Input Time And Date: 2013 - 09 - 28 00 : 56 : 15

Buttons for 'Copy Your PC's Time', 'Save', and 'Cancel' are visible. A Help section on the right provides additional information:

Help

This page is used to set the device's system time. You can choose to set the time manually or get the GMT time from the Internet and the system will automatically connect to NTP server to synchronize the time.

Note: System time will be lost when the device is disconnected from power supply. However, it will be updated automatically when the device reconnects to Internet. To activate time-based features (e.g. firewall), the time and date info shall be set correctly first, either manually or automatically.

Configuration Procedures:

- ① **Internet Time Server:** If enabled, time and date will be updated automatically from the Internet. Check to enable the feature.
- ② **Sync Interval:** Specify a time interval for periodic update of time and date information from the Internet.
- ③ **Time Zone:** Select your current time zone.
- ④ Click **Save** to save your settings.

B. Set Time and Date Manually/Sync with Your PC

The screenshot shows the Tenda web interface for configuring the Time & Date. The navigation menu includes Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The main content area is titled "Time & Date" and contains the following settings:

- Internet Time Server:
- Sync Interval: 2 hours
- Time Zone: (GMT+08:00)Beijing,Chongqing,H
- Input Time And Date: 2013 - 10 - 01 00 : 57 : 15

Buttons for "Copy Your PC's Time", "Save", and "Cancel" are visible. A Help section on the right provides instructions and a note: "Note: System time will be lost when the device is disconnected from power supply. However, it will be updated automatically when the device reconnects to Internet. To activate time-based features (e.g. firewall), the time and date info shall be set correctly first, either manually or automatically."

Configuration Procedures:

- ① **Internet Time Server:** If enabled, time and date will be updated automatically from the Internet. Uncheck to disable the feature.
- ② Specify the time and date manually or click the Copy Your PC's Time to automatically copy your PC's time to the device.
- ③ Click **Save** to save your settings.

And then go to **Status** to make sure the system time is correctly updated.

7.2 Firmware Upgrade

Click **Tools** -> **Firmware Upgrade** to enter the configuration screen. Firmware upgrade is released periodically to improve the functionality of your device and also to add new features. If you run into a problem with a specific feature of the device, log on to our website (www.tendacn.com) to download the latest firmware to update your device. If you run into a problem with a specific feature of the device, log on to our website (www.tendacn.com) to download the latest firmware to update your device.




Note

1. Before you upgrade the firmware, make sure you are having a correct firmware. A wrong firmware may damage the device.
2. It is advisable that you upgrade the device's firmware over a wired connection. **DO NOT** interrupt the power to the router when the upgrade is in process otherwise the router may be permanently damaged.


Configuration Procedures:

- ① Click **Browse**.



- ② Select the upgrade file and click **Open**.

- ③ Click **Update**.



- ④ Click **OK** on the appearing screen and wait for it to complete.

When upgrade is completed, view **Current System Version**. It should display the firmware you load.

7.3 Backup & Restore

Once you have configured the device the way you want it, you can save these settings to a configuration file on your local hard drive that can later be imported to your device in case that the device is restored to factory default settings. Click **Tools -> Back & Restore** to enter the configuration screen.




Tip

The default configuration file name is "RouterCfm.cfg". Do include the file name suffix of ".cfg" when renaming the file name to avoid problems.

Backup Configuration Procedures:


- 1 Click **Backup**.




- 2 Click **OK** on the appearing window.



- ③ Click **Save** on the **File Download** window.




- ④ Select a local hard drive to save the file and click **Save**.




To Restore Configurations:


- 1 Click **Browse**.



- 2 Select the configuration file that is saved previously to your local hard drive and click **Open**.



- ③ Click the **Restore** button to reset your device to previous settings.



7.4 Restore to Factory Default Settings

Click **Tools -> Restore Factory Default** to enter the configuration screen. Here you can reset the device to factory default settings.



Note -----

1. If you enable this option, all current settings will be deleted and be restored to factory default values. You will have to reconfigure Internet connection settings and wireless settings.
2. Do not restore factory default settings unless the following happens:
 - You need to join a different network or unfortunately forget the login password.
 - You cannot access Internet and your ISP or our technical support asks you to reset the router.



The factory default settings are listed below:

- IP Address: 192.168.2.1
- **Subnet Mask:** Enter 255.255.255.0.
- Password: admin

For device's factory default settings, see [Appendix 3 Factory Default Settings](#).

7.5 Change Password

Click **Tools -> Change Password** to enter the configuration screen. It is strongly recommended that you change the factory default login password. Otherwise, anyone in your network can access this utility to change your settings.



Tip-----

1. The default login password is admin.
2. The valid password must be between 3~12 characters and only include letters, numbers and underscore.

The screenshot shows the Tenda web interface. At the top, there is a navigation bar with tabs: Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The 'Tools' tab is selected. On the left, a sidebar menu lists various utilities: Time & Date, Firmware Upgrade, Backup & Restore, Restore Factory Default, Change Password (highlighted), Logs, and Reboot. The main content area is titled 'Password' and contains a 'Note: Password can only include letters, numbers or underscore.' Below the note are three input fields: 'Old Password', 'New Password', and 'Confirm New Password'. At the bottom of the form are 'Save' and 'Cancel' buttons. On the right side of the main content area, there is a 'Help' section with the following text: 'Device's default password is "admin". It is advisable to change it for better security. Otherwise, anyone in your network may access this utility to view or change your settings. Old Password: Enter the old password. If you use the device for the first time, the password is admin by default. Note:Password'.


Configuration Procedures:

- ① **Old Password:** Enter the current login password.
- ② **New Password:** Input a new password.
- ③ **Confirm New Password:** Re-enter the new password for confirmation.
- ④ Click **Save** to save your settings.

7.6 Logs

Click **Tools -> Logs** to enter the logs screen. Here you can view the history of the device's actions upon system startup.

Three types of logs are available: System, snmp and ddns.



The screenshot shows the Tenda web interface. The navigation menu includes Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The Tools menu is active, and the Logs page is displayed. The Logs page features a 'Refresh' button, a 'Clear' button, and a dropdown menu labeled 'Select what type of logs to view:' with 'All' selected. Below this is a table with the following data:


Index	Time	Type	Content
1	2000-01-01 00:00:01	system	Wireless interface up!

Page 1

Help
The Logs option allows you to view all events that occur upon system startup and check whether there are attacks present in your network.
Note: Logs will be cleared automatically once it reaches 15 pages, (namely, 150 entries).

7.7 Reboot

When a certain feature does not take effect or the device fails to function correctly, try rebooting the device.



The screenshot shows the Tenda web interface. The navigation menu includes Wizard, Status, Basic, Wireless, Security, Advanced, Bandwidth Control, and Tools. The Tools menu is active, and the Reboot page is displayed. The Reboot page features a 'Reboot' button and the following text:

Click the button below to restart your router.


Help
Rebooting the device activates new settings. All connections will be disconnected automatically while rebooting.

IV Appendix


1 Configure PC TCP/IP Settings

Windows 7


① Click **Start -> Control Panel**.




② Click **Network and Internet**.




③ Click **Network and Sharing Center**.




④ Click **Change adapter settings**.




⑤ Click **Local Area Connection** and select **Properties**.




⑥ Select **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.



- ⑦ Select **Obtain an IP address automatically** and click **OK**.



- ⑧ Click **OK** on the **Local Area Connection Properties** window to save your settings.



Windows XP


- ① Right-click **My Network Places** and select **Properties**.



- ② Right click **Local Area Connection** and select **Properties**.




- ③ Select **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.



- ④ Select **Obtain an IP address automatically** and click **OK**.



- ⑤ Click **OK** on the **Local Area Connection Properties** window to save your settings.



2 FAQs

This section provides solutions to problems that may occur during installation and operation of the device. Read the following if you are running into problems.

If your problem is not covered here, please feel free to go to www.tendacn.com to find a solution or email your problems to: support@tenda.com.cn or support02@tenda.com.cn. We will be more than happy to help you out as soon as possible.

1. Q: I cannot access the device's management interface. What should I do?

- Make sure the power LED on the device's front panel is on and the SYS LED blinks normally.
- Make sure all cables are correctly connected and the corresponding LAN LED on the device is on.
- Verify that your PC's TCP/IP settings are configured correctly. If you select the "Use the following IP address" option, set your PC's IP address to any IP address between 192.168.2.2~192.168.2.254. Or you can select the "Obtain an IP address automatically" option.
- Delete your browser cache and cookies or use a new browser. Make sure you enter 192.168.2.1 in the address bar.
- Open your browser and click **Tools -> Internet Options -> Connections -> LAN Settings**, uncheck the **Use a proxy server for your LAN** option.
- Press the WPS/RST button for about 10 seconds to restore your device to factory default settings. Then log to your device again.

2. Q: I changed the login password and unfortunately forget it. What should I do?

Press the WPS/RST button for over 7 seconds to restore your device to factory default settings.

3. Q: My computer shows an IP address conflict error after having connected to the device. What should I do?

- Make sure there are no other DHCP servers on your LAN or other DHCP servers are disabled.
- Make sure the device's LAN IP is not used by other devices on your LAN. The device's default LAN IP address is 192.168.2.1.

- Make sure the statically assigned IP addresses to the PCs on LAN are not used by others PCs.

4. Q: I have problems connecting to Internet/Secure websites do not open or displays only part of a web page. What should I do?

This problem mainly happens to users who use the PPPoE or Dynamic IP Internet connection type. You need to change the MTU size. Try changing the MTU to 1450 or 1400. If this does not help, gradually reduce the MTU from the maximum value until the problem disappears.

3 Factory Default Settings

The table below lists the factory default settings of your device.

Item	Default Settings	
Router Login	Login IP Address	192.168.2.1
	Login User Name	admin
	Login Password	admin
Network Settings	Internet Connection Type	Mode Auto-switch Enabled
	MTU	1492 (PPPoE) 1500 (DHCP/Dynamic and Static IP)
	WAN Speed	Auto
	DNS	Disable
LAN Settings (LAN)	IP Address	192.168.2.1
	Subnet Mask	255.255.255.0
	DHCP Server	Enabled
	IP Pool	192.168.2.100~192.168.2.200
	Time Zone	(GMT+08:00)Beijing, Chongqing, Hong Kong, Urumqi
Wireless	Wireless	Enabled
	SSID	Tenda_XXXXXX (where XXXXXX is the last six characters in the device's MAC address) You can find it on the label attached to the device.
	Network Mode	11b/g/n mixed
	SSID Broadcast	Enabled
	Channel	AutoSelect
	Channel Bandwidth	20/40
	Extension Channel	AutoSelect
	Wireless Security	Disabled
Wireless Access Control	Disabled	

Others	Remote Web Management	Disabled
	Bandwidth Control	Disabled
	DMZ Host	Disabled
	UPnP	Enable
	Internet Access Management	Disabled

4 Remove Wireless Network from Your PC


If you change wireless settings on your wireless device, you must remove them accordingly from your PC; otherwise, you may not be able to wirelessly connect to this device. Below describes how to remove a wireless network from your PC.

Windows 7


① Right-click the **Network** icon and select **Properties**.



② Select **Manage Wireless Networks**.



- ③ Select the wireless network and click **Remove network**.




Windows XP


- ① Right-click **My Network Places** and select **Properties**.



- ② Right click **Wireless Network Connection** and then select **Properties**.



- ③ Click **Wireless Networks**, select the wireless network name under **Preferred networks** and then click the **Remove** button.



5 Safety and Emission Statement



CE Mark Warning

This is a Class B product in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. This device complies with EU 1999/5/EC.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.(2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

NOTE:(1)The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.(2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable

NCC Notice

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更設計之特性及功能。

低功率射頻電機之作用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。