
INSTRUCTIONS FOR USE

- 1. Insert 3AA batteries in rear compartment of Receiver and 1 9V battery in rear compartment of Sensor.
- 2. Volume Control. There 4 levels of sound (off, low, medium, loud) which is adjusted one level at a time at (A) upper switch on side of Receiver.
- 3. Ring Tones. There are 32 ring tones, which are set at (B) lower part of switch on side of Receiver. The ring tones may be changed one at a time by pressing the switch. The LED light (C) on the front of the Receiver will flash when the ring tones are playing.
- 4. Screw Mounting Bracket into wall. Slide opposite end of ball-looking part into rear lower section (D) of Sensor. Press ball into Mounting Bracket and adjust angle as needed. *Note:* The Sensor works at an angle of about 100 degrees and with a motion-detection range of about 20 feet. If sensor is detecting more movement than you wish, cover part of Sensor with opaque tape or paper to narrow sensing angle.
- 5. Place Receiver where needed. Note that the fewer walls that separate the Sensor from the Receiver the longer the distance that the Receiver can be placed. Over time, the batteries will weaken and may need to be replaced.
- 6. Adjust On/Off switch (E) on side of Sensor as needed.



ENGLISH

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules.
- Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2)This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/ TV technician for help.