


REVISION HISTORY				
REV.	DATE	MODIFICATIONS	NAME	ECN NO.
A	18 APR 2018	NEW	Kei H.	20063704

## DO NOT PRINT THIS PAGE



### Printing Notes:

**Material:** 20 Pound (US) or 80 GSM (International) bond paper, white  
**Ink:** Black  
**Resolution:** 150 DPI or above  
**Printing method:** 2-side (front & back), Offset Printing  
**Sheet size:** 210 x 297 mm (A4, W x H)  
**Delivered size:** 52 x 74 mm (W x H)



Program: InDesign CS6  
Black

### RELEASED FOR PRODUCTION

<p style="text-align: center;"><b>CONFIDENTIAL</b></p> <p style="font-size: small;">THIS DOCUMENT AND ITS CONTENTS ARE CONFIDENTIAL AND CONSTITUTE TRADE SECRETS PROPRIETARY TO NEWELL BRANDS, WHO RESERVE ALL RIGHTS THEREIN. BY ACCEPTING THIS DOCUMENT, THE RECIPIENT AGREES NOT TO COPY, USE, MANUFACTURE, OR COMMUNICATE TO OTHERS, WHOLLY OR IN PART, THE CONTENTS OF THIS DOCUMENT EXCEPT AS EXPRESSLY AUTHORIZED IN WRITING BY NEWELL BRANDS.</p>				<p style="font-size: small;">3 Glenlake Parkway Atlanta, GA 30328 USA</p>	
DRAWING PREPARED IN ACCORDANCE WITH ASME Y14.5		MATERIAL: SEE NOTES			
TITLE: IM for Power Bank, EN/FR/SP		FINISH: SEE NOTES			
<p style="font-size: x-small;">3RD ANGLE PROJECTION</p> 	DRAWN BY: Kei H. DATE: 18 APR 2018	SCALE: 1 : 1 SHEET 1 OF 1	DRW NO. 4010060497	REV A	




User Manual / User Manual / User Manual

Dual Port Power Bank Charger  
7500mAh

Dual Port Power Bank Charger  
7500mAh

Dual Port Power Bank Charger  
7500mAh

**Power Bank Layout / Power Bank Layout / Power Bank Layout**



**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



U.S.A.: Product manufactured for/Fabricada para/Produit fabriqué pour  
The Coleman Company, Inc.  
3600 North Hydraulic, Wichita, KS 67219 U.S.A.  
1-800-835-3278 TDD: 1-316-832-8707  
[www.coleman.com](http://www.coleman.com)

Canada: Product imported by/Importada por/Produit importé par  
Sunbeam Corporation (Canada) Ltd. DBA Jarden Consumer Solutions  
20B Hereford Street, Brampton, ON L6Y 0M1 1 800 387-6161

© 2018 The Coleman Company, Inc. All rights reserved.

Coleman®, Coleman® and are registered trademarks of The Coleman Company, Inc.

© 2018 The Coleman Company, Inc. Todos los derechos reservados.

Coleman®, Coleman® y son marcas comerciales registradas de The Coleman Company, Inc.

© 2018 The Coleman Company, Inc. Tous droits réservés.

Coleman®, Coleman® et sont des marques déposées alors de commerce de The Coleman Company, Inc.

**IMPORTANT SAFETY INSTRUCTIONS**

**WARNING** – When using this product, basic precautions should always be followed, including the following:

- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Read all the instructions before using the product.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not put fingers or hands into the product.
- Do not expose power bank to rain or snow.
- Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
- Do not use the power bank in excess of its output rating. Overloading outputs above the rating may result in a risk of fire or injury to persons.
- Do not use a power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperatures above 100°C (212°F) may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Switch off the power bank when not in use.
- Do not charge or discharge the power bank in temperatures above 45°C (113 °F)
- Risk of Fire and Burns. Do Not Open or Crush.

**SAVE THESE INSTRUCTIONS**

- The power bank can withstand splashed water but cannot be totally submersed underwater.
- To maximize battery life span, fully charge power bank before first use for 3 to 4 hours.
- Store power bank in a cool and dry place.
- Operating temperature should be between -10°C to 45°C (14 °F - 113 °F).
- If power bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern.
- In normal conditions, the battery performance will decline over several years.
- Do not dispose of power bank in heat or fire.
- Do not clean power bank with harmful chemicals or detergents.
- Misuse, dropping or excessive force may cause product damage.


**Suitable for**

- Most smartphones & tablets
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable devices such as fitness tracker or headset
- eReaders

**Features**


- Rugged & shock proof design for maximum durability
- Water resistant, dust proof and dirt proof rated to IP64
- Dual USB ports for simultaneous charging of two devices
- Four LED indicators to show remaining capacity
- Includes micro USB cable for charging and re-charging
- Built-in over charging and short circuit protection
- Capacity: 7500mAh
- Input: DC 5V/2A
- Output: DC 5V/2A
- Charging Time: 3 to 4 hours
- Size: 114mm (L) x 70mm (W) x 28.5mm (H)

**To Charge Power Bank**



- Using the included USB cable, connect the larger USB connector to an AC wall adapter (not exceeding DC 5V/2A) or USB port on a computer.
- Connect the micro USB connector to the input port on the power bank.
- During charging the LEDs will flash to show charging status.
- When charging is complete all four LED's will be permanently on.

**To Charge Phone or USB Device**



- USB 1 and 2 Outputs are for charging a phone or other USB device.
- USB 2 Output is for fast charging a tablet.
- Using your phone, tablet or other USB device's charging cable, connect the USB Type A connector to USB Output 1 or 2 on the power bank.
- Connect the other end of the cable to your device.
- Press the power button on the power bank to start charging your device.
- If your phone or device uses a standard micro USB Type B connector then you can also use the included cable to charge your device.
- When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating.

**To Check Remaining Capacity**

- Press the On/Off button and the LEDs will light to show remaining capacity.
- Press the On/Off button again to turn off the LEDs.

LED ● On / ○ Off / ● Flashing	Remaining Capacity
●○○○	Less than 5%
●○○○	5% to 25%
●●○○	25% to 50%
●●●○	50% to 75%
●●●●	75% to 100%

**IMPORTANT SAFETY INSTRUCTIONS**

**WARNING** – When using this product, basic precautions should always be followed, including the following:

- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Read all the instructions before using the product.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not put fingers or hands into the product.
- Do not expose power bank to rain or snow.
- Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
- Do not use the power bank in excess of its output rating. Overloading outputs above the rating may result in a risk of fire or injury to persons.
- Do not use a power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperatures above 100°C (212°F) may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Switch off the power bank when not in use.
- Do not charge or discharge the power bank in temperatures above 45°C (113 °F)
- Risk of Fire and Burns. Do Not Open or Crush.

**SAVE THESE INSTRUCTIONS**

- The power bank can withstand splashed water but cannot be totally submersed underwater.
- To maximize battery life span, fully charge power bank before first use for 3 to 4 hours.
- Store power bank in a cool and dry place.
- Operating temperature should be between -10°C to 45°C (14 °F - 113 °F).
- If power bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern.
- In normal conditions, the battery performance will decline over several years.
- Do not dispose of power bank in heat or fire.
- Do not clean power bank with harmful chemicals or detergents.
- Misuse, dropping or excessive force may cause product damage.

**Suitable for**


- Most smartphones & tablets
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable devices such as fitness tracker or headset
- eReaders

**Features**


- Rugged & shock proof design for maximum durability
- Water resistant, dust proof and dirt proof rated to IP64
- Dual USB ports for simultaneous charging of two devices
- Four LED indicators to show remaining capacity
- Includes micro USB cable for charging and re-charging
- Built-in over charging and short circuit protection
- Capacity: 7500mAh
- Input: DC 5V/2A
- Output: DC 5V/2A
- Charging Time: 3 to 4 hours
- Size: 114mm (L) x 70mm (W) x 28.5mm (H)

**To Charge Power Bank**

Charge via USB Wall Charger




Charge via Computer USB Port



- Using the included USB cable, connect the larger USB connector to an AC wall adapter (not exceeding DC 5V/2A) or USB port on a computer.
- Connect the micro USB connector to the input port on the power bank.
- During charging the LEDs will flash to show charging status.
- When charging is complete all four LED's will be permanently on.

**To Charge Phone or USB Device**



- USB 1 and 2 Outputs are for charging a phone or other USB device.
- USB 2 Output is for fast charging a tablet.
- Using your phone, tablet or other USB device's charging cable, connect the USB Type A connector to USB Output 1 or 2 on the power bank.
- Connect the other end of the cable to your device.
- Press the power button on the power bank to start charging your device.
- If your phone or device uses a standard micro USB Type B connector then you can also use the included cable to charge your device.
- When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating.

**To Check Remaining Capacity**

- Press the On/Off button and the LEDs will light to show remaining capacity.
- Press the On/Off button again to turn off the LEDs.

LED ● On / ○ Off / ● Flashing	Remaining Capacity
●○○○	Less than 5%
●○○○	5% to 25%
●●○○	25% to 50%
●●●○	50% to 75%
●●●●	75% to 100%

**IMPORTANT SAFETY INSTRUCTIONS**

**WARNING** – When using this product, basic precautions should always be followed, including the following:

- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Read all the instructions before using the product.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not put fingers or hands into the product.
- Do not expose power bank to rain or snow.
- Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
- Do not use the power bank in excess of its output rating. Overloading outputs above the rating may result in a risk of fire or injury to persons.
- Do not use a power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperatures above 100°C (212°F) may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Switch off the power bank when not in use.
- Do not charge or discharge the power bank in temperatures above 45°C (113 °F)
- Risk of Fire and Burns. Do Not Open or Crush.

**SAVE THESE INSTRUCTIONS**

- The power bank can withstand splashed water but cannot be totally submersed underwater.
- To maximize battery life span, fully charge power bank before first use for 3 to 4 hours.
- Store power bank in a cool and dry place.
- Operating temperature should be between -10°C to 45°C (14 °F - 113 °F).
- If power bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern.
- In normal conditions, the battery performance will decline over several years.
- Do not dispose of power bank in heat or fire.
- Do not clean power bank with harmful chemicals or detergents.
- Misuse, dropping or excessive force may cause product damage.

**Suitable for**


- Most smartphones & tablets
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable devices such as fitness tracker or headset
- eReaders

**Features**


- Rugged & shock proof design for maximum durability
- Water resistant, dust proof and dirt proof rated to IP64
- Dual USB ports for simultaneous charging of two devices
- Four LED indicators to show remaining capacity
- Includes micro USB cable for charging and re-charging
- Built-in over charging and short circuit protection
- Capacity: 7500mAh
- Input: DC 5V/2A
- Output: DC 5V/2A
- Charging Time: 3 to 4 hours
- Size: 114mm (L) x 70mm (W) x 28.5mm (H)

**To Charge Power Bank**

Charge via USB Wall Charger




Charge via Computer USB Port



- Using the included USB cable, connect the larger USB connector to an AC wall adapter (not exceeding DC 5V/2A) or USB port on a computer.
- Connect the micro USB connector to the input port on the power bank.
- During charging the LEDs will flash to show charging status.
- When charging is complete all four LED's will be permanently on.

**To Charge Phone or USB Device**



- USB 1 and 2 Outputs are for charging a phone or other USB device.
- USB 2 Output is for fast charging a tablet.
- Using your phone, tablet or other USB device's charging cable, connect the USB Type A connector to USB Output 1 or 2 on the power bank.
- Connect the other end of the cable to your device.
- Press the power button on the power bank to start charging your device.
- If your phone or device uses a standard micro USB Type B connector then you can also use the included cable to charge your device.
- When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating.

**To Check Remaining Capacity**

- Press the On/Off button and the LEDs will light to show remaining capacity.
- Press the On/Off button again to turn off the LEDs.

LED ● On / ○ Off / ● Flashing	Remaining Capacity
●○○○	Less than 5%
●○○○	5% to 25%
●●○○	25% to 50%
●●●○	50% to 75%
●●●●	75% to 100%