

# modlet<sup>®</sup> gateway

User Guide




 thinkeco

# Hardware

Top View




Bottom View




Wall mounts

Front View



Back View



# LED light overview

## Power LED:

ON when AC/DC power supply is connected and modlet® gateway is powered ON.

OFF when AC/DC power supply is not connected.

To power on the modlet® gateway please verify the AC/DC adapter is properly connected.

## Run LED:

OFF when the modlet® gateway is in IDLE mode

Flashing when the modlet® gateway is in OPERATIVE mode

## Error LED:

ON when the modlet® gateway is in ERROR mode.

To restart the modlet® gateway press Reset Button on the back.

If the modlet® gateway does not exit Error mode please unplug and replug the AC/DC adapter

## USB interface LEDs:

ON when a USB device is connected to the modlet® gateway

## WAN interface LEDs (front and back):

ON (Orange) when a 10/100 Mbps device is connected to the port.

Flashing (Orange) when a 10/100 Mbps device is transmitting or receiving to the port.

ON (Green) when a 1000 Mbps device is connected to the port.

Flashing (Green) when a 1000 Mbps device is transmitting or receiving to the port.

## ZigBee interface LED:

Flashing (Blue) when the imbedded ZigBee module is transmitting or receiving data.

On (Blue) when the imbedded ZigBee module is in IDLE mode.

# Installation

## What you need to get started

- 1 power cord (included)
- 1 Ethernet cord (included)
- IP address of your home/office router (user provides)

To find your router's IP address consult your router's manual or contact the manufacturer

my router  
IP address:

## INSTRUCTIONS

### 1. Plug in modlet gateway

- Plug in the modlet gateway into an electrical outlet using the power cord provided. The green power LED light should turn on.
- Then plug the gateway into your home or office router using the Ethernet cord provided. The WAN interface LED will be flashing and then become solid when connected.

### 2. Access your router's information

- Using an Internet-connected computer, open a new browser window (Internet Explorer, Firefox, Chrome or Safari). Type in the IP address of your router in your browser's address bar and press enter. If you do not know the IP address of your router then consult the router's user manual or contact the manufacturer.
- Once you are connected to the router manager page, look on the left side of the screen for the "Attached Devices" link and click on it.
- Under the list of Devices, look for the device named "THINKECO\_GATEWAY". Write down the IP address written to the left of the THINKECO\_GATEWAY.
- In your browser's address bar, type in the IP address of the THINKECO\_GATEWAY that you just wrote down and press enter. You will be directed to a ThinkEco page.

ThinkEco Gateway  
IP address:

### 3. Register a modlet account

- To create a new account, select the link that says "New User? Create an Account".
- Follow all on screen instructions to register an account.
- On the last screen, click the "Go Back to Router Settings" button. You will be directed back to the ThinkEco page.

my username  
& password:

### 4. Set up your modlet(s)

- Log into your account, using the username and password you just created.
- Then follow all on screen instructions to set up your modlet(s).

# Troubleshooting

If you are connected to the internet and logged into your account, but you're not seeing the latest data, try these tips.

## 1. Check gateway

Make sure your gateway is correctly connected

- AC/DC adapter plugged in (POWER led ON)  
LAN cable plugged in (WAN led flashing)  
ZigBee module in operative mode (ZigBee led ON)

- Next restart gateway  
Restart gateway from Web GUI

if not successful please:  
press reset button and wait system restart

if still not successful please:  
unplug and replug AC/DC power supply

- Check the status of your gateway by clicking on the Modlet Network link in the top right of your screen and then clicking on USB Receiver.

## 2. Be patient

When you first set up your network, or if your computer has been off for a while, the data may take a few minutes to load onto the interface. Check back in 15 minutes.

## 3. Refresh

Try hitting the refresh button on the Energy Usage tab or your browser.

## 4. Verify parameters

- Check the variables you selected for the graph: does the start and end date match when you plugged in your modlet?
- Do you have at least one device selected? Click on the name of the devices you want to graph or select all to see total energy consumption.

## 5. Check devices

- Check the status of your devices on the energy usage tab. A green light next to your device means it has reported data to your computer in the last 24 hours.
- If the light is red, first restart you gateway. Next, verify your devices are labeled correctly and assigned to the correct outlet by clicking Modlet Network and then Modlets.

**For more troubleshooting information, call the modlet tech support center at 1-800-682-0152.**

## Modlet® gateway PACKING LIST

- 1 modlet gateway TE1210
- 1 Cable Ethernet, 6FT min
- 1 AC/DC Power supply, 110V/240V Input, 12V/1A output

## ThinkEco modlet® gateway

Thank you for purchasing your new modlet® gateway!

For more information and to learn about your modlet® gateway please visit [www.themodlet.com](http://www.themodlet.com).

Please read all user guides/manuals provided to you (in both paper and electronic form) including in the software downloaded in connection with the usage of this device and all operating and safety instructions. If you fail to do so this product may not function properly and may lead to damage to the product and to other danger.

### modlet® gateway Specifications

- ZigBee (IEEE 802.15.4) wireless communication
- Power source: 12V DC

### Important Safety Information:

Use indoors in a dry location.

Contains non-user serviceable parts; do not open.

This product is not a toy. Do not allow children to operate it.

### Regulatory Information:

Installation and use of this device must be in strict accordance with the instructions included in the user documentation provided with the product or at [www.thinkeco.com](http://www.thinkeco.com). Any changes or modifications made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. ThinkEco will assume no liability for any damage or violation of government regulations arising from failing to comply with these guidelines.

### RF Exposure Warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 7.9 inches (20cm) between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

### Note: USA-FCC (Federal Communications Commission) statement

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of this device.

### Note: FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or

more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the distance between the equipment and the receiver.
3. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

### LIMITED ONE (1) YEAR WARRANTY

**Warranty:** ThinkEco warrants that the modlet, USB gateway, gateway, smartAC thermostat (collectively “TE Products”) will be free from defects in material and workmanship and perform to ThinkEco’s applicable published specifications for a period of one (1) year from date of delivery to you. The liability of ThinkEco hereunder shall be limited to replacing or repairing, at its option, any defective TE Products which are returned F.O.B. ThinkEco’s corporate address (or, at ThinkEco’s option, refunding the purchase price of such TE Products). In no case are TE Products to be returned without first obtaining permission and a return order number from ThinkEco. You are responsible for the cost of shipment of the defective TE Products to ThinkEco, and ThinkEco is responsible for the cost of shipment of a replacement TE Products to you. In the event you send TE Products back to ThinkEco, and the TE Product is not defective, ThinkEco reserves the right to charge you a fee associated with postage and handling of such TE Product.

**Replacement TE Products:** Replacement TE Products are warranted by ThinkEco pursuant to the warranty set forth above for the longer of (i) thirty (30) days; or (ii) the remaining warranty period for the original Modlet. The replacement TE Product may be refurbished and/or contain refurbished parts.

The following are not covered by this warranty: (i) TE Products which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair, inspection or installation, Acts of God, power surge, wear and tear, mishandling, misapplication, or other causes unrelated to defective materials or workmanship; and (ii) any damages and/or viruses caused by use of a third party device in conjunction with the TE Products. You are responsible for determining if a third party device used in conjunction with any TE Product is suitable for such use and ThinkEco is not liable, and this warranty does not cover, any damages caused by, or to, any third party device. ThinkEco will make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to any custom equipment or goods produced to your specifications except as specifically stated in writing by ThinkEco in the contract for such custom goods.

**Disclaimer & Limitation of Liability:** EXCEPT AS EXPRESSLY PROVIDED ABOVE, THINKECO MAKES NO, AND HEREBY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS, STATUTORY, OR IMPLIED, INCLUDING ANY WARRANTY OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THINKECO MAKES NO REPRESENTATION, WARRANTY OR GUARANTY AS TO THE RELIABILITY, TIMELINESS, QUALITY, SUITABILITY, TRUTH, AVAILABILITY, ACCURACY OR COMPLETENESS OF THE TE PRODUCTS AND DOES NOT REPRESENT OR WARRANT THAT (A) THE USE OF TE PRODUCTS WILL BE SECURE, TIMELY, UNINTERRUPTED OR ERROR-FREE OR OPERATE IN COMBINATION WITH ANY OTHER HARDWARE, SOFTWARE, SYSTEM OR DATA, (B) TE PRODUCTS WILL MEET CUSTOMER’S REQUIREMENTS OR EXPECTATIONS, (C) ANY STORED DATA WILL BE ACCURATE OR RELIABLE, (D), TE PRODUCTS ARE FREE OF VIRUSES OR OTHER HARMFUL COMPONENTS. IN NO EVENT WILL THINKECO BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY LOST PROFITS, USE OF USER INFORMATION, LOSS OF DATA, BUSINESS INTERRUPTION, OR OTHER INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OF ANY NATURE ARISING FROM OR RELATING TO YOUR USE OF TE PRODUCTS, EVEN IF THINKECO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL THINKECO’S TOTAL CUMULATIVE LIABILITY TO YOU, FOR ANY AND ALL CLAIMS UNDER ANY THEORY OF LAW, EXCEED THE ORIGINAL PURCHASE PRICE OF THE TE PRODUCTS IN QUESTION.

To contact ThinkEco regarding this Limited Warranty, please call ThinkEco at 1-800-682-0152. For additional information please visit [www.thinkeco.com/warranty](http://www.thinkeco.com/warranty)



148 Madison Avenue, 8th Floor  
New York, NY 10016  
[www.thinkeco.com](http://www.thinkeco.com)



---

## **FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/ TV technician for help.

### **CAUTION:**

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

### **Labeling requirements**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF exposure warning**

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

---