

NOTE: If you make a mistake, press the DEL/CHAN button to erase a wrong number.

RINGER TONE

1. Press the FLASH/PROG button until *RINGER TONE* ▶ 1 shows in the display. "1" is the default.
2. Use the CALLER ID/VOL (- or +) button or the touch-tone pad on the handset to scroll to 1, 2, or 3.
3. Press FLASH/PROG to save.

DEFAULT SETTING

1. Press the FLASH/PROG button until *DEFAULT* ▶ *NO* shows in the display. "NO" is the default.
2. Use the CALLER ID/VOL (- or +) button on the handset to scroll to *YES* or *NO*.
3. Press FLASH/PROG to save. You will hear a confirmation tone.

CORDLESS PHONE BASICS

CHARGE/IN USE INDICATOR

The phone is ON when the TALK/END/CALLBACK indicator on the handset and the charge/in use indicator on the base is lit. The handset and base indicators flash when you receive a call.

ANSWERING A CALL

1. When the phone rings, pick up the handset and press the TALK/END/CALLBACK button.
2. When finished, press the TALK/END/CALLBACK button or place the handset on the base cradle to hang up.

MAKING A CALL

1. Pick up the handset and press the TALK/END/CALLBACK button. Wait for the dial tone. The call timer starts counting minutes and seconds in the display.
2. Dial a telephone number.
3. When finished, press the TALK/END/CALLBACK button again or place the handset on the base cradle to hang up.

PRE-DIALING

1. Make sure the phone is **OFF** (not in TALK mode).
 2. Dial a telephone number (the number you dial shows in the display).
- NOTE:** If you make a mistake dialing the number, use the DEL/CHAN button to backspace and erase the wrong number, and enter the correct number.
3. Press the TALK/END/CALLBACK button on the handset. The number automatically dials and the call timer starts counting the minutes and seconds in the display.
 4. When finished, press the TALK/END/CALLBACK button again to hang up.

NOTE: You may enter up to 32 pre-dial digits.

REDIAL

While the phone is **ON** (in TALK mode), press the REDIAL button to redial the last number you dialed (up to 32 digits).

OR,

While the phone is **OFF** (in standby mode), press the REDIAL button and then the TALK/END/CALLBACK button to redial the last number.

FLASH

Use the FLASH/PROG button to activate custom calling services such as call waiting, which are available through your local phone company.

TIP: Don't use the TALK/END/CALLBACK button to activate custom calling services such as call waiting, or you'll hang up the phone.

CHANNEL BUTTON

While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the DEL/CHAN button to move to the next clear channel.

EXIT

Press the *EXIT button to cancel any command you initiated.

FINDING THE HANDSET

This feature helps locate a misplaced handset.

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the TALK/END/CALLBACK button on the handset or the page button on the base.

NOTE: You may still page the handset when the ringer is off.

RINGER SWITCH

The ringer switch is located on the side of the handset, it has two positions, On and Off.

VOLUME

When the phone is **ON** (in TALK mode) press the CALLER ID/VOL (- or +) button to adjust the listening level. Choose from four volume settings. VOL 1 is the lowest volume and VOL 4 is the highest volume.


MUTE

Use mute during a phone conversation to speak privately and off-line with a third party.

1. Press the MUTE button. *MUTE* shows in the display. The party on the telephone will not hear you.
2. Press the MUTE button when finished.

CALLER ID (CID)

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 40 calls for later review.



CALL WAITING CALLER ID

Provided you subscribe to Call Waiting Caller ID service from your phone company, you are able to see who is calling while you are on the phone when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- When you hear the call waiting beep in the handset receiver, press the FLASH/PROG button to put the current call on hold and answer the incoming call.

IMPORTANT: In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

RECEIVING AND STORING CID RECORDS

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. *NEW* appears in the display for calls received that have not been reviewed.

NOTE: Check with your local phone company regarding name service availability.

REVIEWING CID RECORDS

As calls are received and stored, the display is updated to let you know how many calls have been received.

- Press the CALLER ID/VOL (-) to scroll through the call records from the most recent to the oldest.
- Press the CALLER ID/VOL (+) to scroll through the call records from the oldest to the newest.