

EXHIBIT A

[FCC Ref. 2.1033(b)(3)]

"Installation and Operating Instructions
Furnished to the User"

Exhibit A(1) - User's Guide

40-Channel 900MHz Call Waiting Caller ID Cordless Telephone User's Guide



FCC REGISTRATION INFORMATION

Your telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1. Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Roaming Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice. In writing, to allow you to maintain uninterrupted service.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services. You must subscribe to one of these services in order to use this unit.

Your Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially.
- Know who called while you were away.

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.


REMEMBER: This product requires a subscription to Caller ID service from your telephone company. Check for name service availability.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

TABLE OF CONTENTS


FCC REGISTRATION INFORMATION	2	MEMORY	18
INTERFERENCE INFORMATION	2	STORING A NUMBER IN MEMORY	18
HEARING AID COMPATIBILITY	2	CHANGING A STORED NUMBER	19
INTRODUCTION	4	DIALING A STORED NUMBER	20
BEFORE YOU BEGIN	5	USING CALL BACK	20
PARTS CHECKLIST	5	CHAIN DIALING FROM MEMORY	21
MODULAR JACK REQUIREMENTS	5	INSERTING A PAUSE IN THE DIALING SEQUENCE	22
DIGITAL SECURITY SYSTEM	5	REVIEWING AND DELETING STORED NUMBERS	22
INSTALLATION	6	HEADSET AND BELT CLIP OPERATION	23
DESKTOP INSTALLATION	6	CONNECTING A HEADSET TO THE HANDSET	23
WALL MOUNT INSTALLATION	7	CONNECTING THE BELT CLIP	23
TELEPHONE BASICS	9	CHANGING THE BATTERY	24
RECEIVING A CALL	9	BATTERY SAFETY PRECAUTIONS	24
MAKING A CALL	9	CAUSES OF POOR RECEPTION	25
REDIAL	9	MESSAGE INDICATORS	26
WHILE THE PHONE IS ON	9	HANDSET SOUND SIGNALS	27
WHILE THE PHONE IS OFF	10	TROUBLESHOOTING TIPS	27
FLASH BUTTON	10	INDEX	30
CHANNEL BUTTON	11	GENERAL PRODUCT CARE	32
TEMPORARY TONE	11	SERVICE	32
FINDING THE HANDSET	11	ACCESSORY ORDER FORM	33
RINGER SWITCH	12	LIMITED WARRANTY	35
TO NE/PULSE DIALING	12		
TO NE	12		
PULSE	12		
VOLUME	13		
VOICE MESSAGING	13		
CALLER ID FEATURES	14		
CALL WAITING CALLER ID	14		
RECEIVING AND STORING CALLS	15		
REVIEWING MESSAGES	15		
DELETING RECORDS	16		
DELETING THE CURRENT RECORD	16		
DELETING ALL RECORDS	16		
DIALING A CALLER ID NUMBER	16		
CHANGING THE NUMBER FORMAT	17		

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



INSTALLATION

NOTE: For desktop charging only, the handset is able to charge facing up or down.



DESKTOP INSTALLATION

1. Set the RINGER switch on the handset to ON.
2. Place the handset in the base.
3. Raise the base antenna.
4. Plug the power supply cord into the base and then into an AC outlet. The CHARGE/USE indicator comes on indicating that the battery is charging.

Allow the phone to charge for 12 hours before using the first time. If you don't charge the phone properly (for 12 hours) when you first set up the phone, performance of the battery will be compromised.

5. After charging, connect the telephone cord to the phone and then to the wall jack.


NOTE: The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing." If you don't know which type of service you have, check with the phone company.

CAUTION: Use only the ATLINKS USA 5-2465 (black) / 5-2464 (white) power supply that came with this unit. Using other power supplies may damage the unit.

BEFORE YOU BEGIN

PARTS CHECKLIST

Make sure your package includes the items shown here.



MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.



INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If such interference continues, move the cordless telephone farther away from the TV or VCR.

DIGITAL SECURITY SYSTEM


Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges to your phone line. When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

5. After charging, remove and reattach the wall mount bracket by inserting the two tabs at the top and then snapping the tab at the bottom into place.

6. Plug the short phone line cord into the phone jack on the back of the unit and then into the wall jack.

7. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)

NOTE: The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing." If you don't know which type of service you have, check with the phone company.



WALL MOUNT INSTALLATION

Because it is necessary to charge the handset for 12 hours prior to connecting the phone for use the first time, it is better to leave the unit on a flat surface during initial charge before attempting to hang it on the wall.




1. Remove the handset hook; turn it upside down, and put it back in the slot. You need to do this so the handset doesn't fall out of the base when it is on the wall.
2. Set the RINGER switch on the handset to ON.
3. Place the handset in the base.
4. Connect the power supply adapter into the base and then into an AC outlet.

The CHARGE/IN USE indicator comes on indicating that the battery is charging.

Allow the phone to charge for 12 hours before using the first time. If you don't charge the phone properly (for 12 hours) when you first set up the phone, performance of the battery will be compromised.

Instructions continued on next page.

! CAUTION: Use only the AIRLINES USA 5-2465 (black) / 5-2464 (white) power supply that came with this unit. Using other power supplies may damage the unit.



WHILE THE PHONE IS OFF

1. Press the REDIAL button. The last number reviewed shows on the display.
2. Press REDIAL again. The number dials automatically.

FLASH BUTTON

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

CHANNEL BUTTON

While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.

TELEPHONE BASICS

RECEIVING A CALL

1. Check the display to see who is calling.
2. Press the TALK button.



MAKING A CALL

To make a call, press the TALK button before you dial and press it again to hang up.

REDIAL

WHILE THE PHONE IS ON

Press the REDIAL button to redial the last number you dialed (up to 32 digits). If you get a busy signal, and want to keep dialing the number, just press REDIAL again (you don't have to turn the phone off and back on).



RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls.

TONE/PULSE DIALING


This adjustment allows you to select tone (touch-tone) or pulse (rotary) mode dialing. The phone is automatically set for touch-tone use.

TONE

1. Turn the phone off.
2. Press and hold the CHANNEL button until the phone beeps.
3. Press TONE*.

PULSE

1. Turn the phone off.
2. Press and hold the CHANNEL button until the phone beeps.
- *3. Press #.



TEMPORARY TONE

This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:



1. Call the bank's information line.
2. Press the TONE button (*) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.

FINDING THE HANDSET

This feature helps to locate a misplaced handset.

Press the PAGE button on the base. The handset beeps continuously for about 2 minutes or until you press any button on the handset.

NOTE: The ringer does not have to be on for this feature to work.



CALLER ID FEATURES


This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 40 calls for later review.

CALL WAITING CALLER ID

Provided you subscribe to Caller ID with Call Waiting service from your phone company, you are able to see who is calling when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- Press the FLASH button to put the current person on hold so that you can answer the incoming call.

VERY IMPORTANT: The Caller ID feature of this product requires a subscription to Caller ID service from your telephone company.





VOLUME

The VOLUME buttons control the volume of the handset's earpiece.

VOICE MESSAGING

Provided your phone company offers voice messaging service and you subscribe to it, the CHARGE/IN USE indicator on the base flashes when the phone is not in use to indicate there is a message waiting. It stops flashing after the message has been reviewed.



DELETING RECORDS

Use the DELETE button to erase the record currently shown in the display or all records.

DELETING THE CURRENT RECORD


1. Use the arrow buttons to display the desired Caller ID record.
2. Press DELETE. The display shows ERASE CALL ID?
3. Press DELETE again to erase the record.

DELETING ALL RECORDS

1. Use the arrow buttons to display the desired Caller ID record.
2. Press and hold DELETE. The display shows ERASE ALL?
3. Press DELETE again to erase all records.

DIALING A CALLER ID NUMBER


1. Make sure the phone is OFF.
2. Use the arrow buttons to display the desired Caller ID record.
3. Press the CALL BACK button. The number dials automatically.



RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID Telephone between the first and second ring. When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed.

NOTE: Check with your local phone company regarding name service availability.



REVIEWING MESSAGES

- As calls are received and stored, the display is updated to let you know how many calls have been received.
- Press the arrow down button to scroll through the call records from the most recent to the oldest.
 - Press the arrow up button to scroll through the call records from the oldest to the newest.


MEMORY

Store up to ten 24-digit numbers in memory for quick dialing. This memory feature is in addition to the 40 Caller ID records that can be stored in memory.

STORING A NUMBER IN MEMORY

The phone must be **OFF** when you store numbers.

1. Press the MEMORY button.
2. Press the memory location number (0-9).
3. Press MEMORY again. The display shows **ENTER NAME**.
4. Use the keypad to store a name (up to 15 characters). More than one letter is stored in each of the number keys. For example, to enter Joe Smith, press 5 for J; press 6 three times for O; press 3 two times for E; press 1 to enter a space before you start entering the last name; press 7 four times for S; press 6 for M; press 4 three times for I; press 8 for T; and 4 two times for H. If you're using two letters consecutively that are stored in the same number key,



NOTE: If you don't want to enter the name, skip step 4.

CHANGING THE NUMBER FORMAT


The **FORMAT** button lets you change the format of the displayed number. The available formats are as follows.

7-digit 7-digit telephone number.

10-digit 3-digit area code +7-digit telephone number.

11-digit long distance code "1" +3-digit area code +7-digit telephone number.

1. Use the arrow buttons to scroll to the number you want to call back.
2. If the number will not dial as shown, press the **FORMAT** button. Repeat if necessary, until the correct number of digits are shown.
3. Press **CALL BACK**.



NOTE: To clear the local area code, press and hold **CHANNEL** until **AREA CODE** appears. Then enter "000".

DIALING A STORED NUMBER


1. Make sure the phone is **ON** by pressing the **TALK** button.
2. Press **MEMORY**.
3. Press the number for the desired memory location (0-9). The number dials automatically.

USING CALL BACK

You can also use **CALL BACK** to dial numbers stored in memory.

1. Make sure the phone is **OFF**.
2. Press **MEMORY**.
3. Use the arrow buttons to scroll through the numbers stored in memory until the desired number is shown or press the number for the desired memory location (0-9).
4. Press **CALL BACK**. The number dials automatically.

IMPORTANT: If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.




You must press **FORMAT** between the letters. For example, if you enter Barb, press **FORMAT** three times for B; press **FORMAT** twice for A; 7 three times for 7 two times for B. You must press **FORMAT** between the letters and the A since they are within the same number.

5. Press **MEMORY**. The display shows **ENTER TEL NUMBER**.
6. Use the keypad to enter the number you want to store (up to 24 digits).
7. Press **MEMORY** again to store the number.
8. Record whose number is in the location on the label provided. You will be able to view the name and number in the phone's memory.


CHANGING A STORED NUMBER

Use the same procedure to change a stored number as you use to store a number—you're just replacing the phone number with a different one.



INSERTING A PAUSE IN THE DIALING SEQUENCE

Press the REDIAL button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.



REVIEWING AND DELETING STORED NUMBERS

1. Press MEMORY, then press the arrow keys to view the entry.
2. While the entry is displayed, press DELETE to delete the entry. The display shows ERASE MEMO?
3. Press DELETE a second time to delete the entry.


CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

1. Make sure the phone is ON.
2. Press MEMORY and then press 7.
3. When you hear the access tone, press MEMORY and then press 8.
4. At the next access tone, press MEMORY and then 9.


TIP: Wait for the access tones before pressing the next memory button, or your call might not go through.



CHANGING THE BATTERY


Make sure the telephone is **OFF** before you replace battery.

1. Remove the battery compartment door.
2. Disconnect the cord attached to the battery pack and remove the battery pack from the handset.
3. Insert the new battery pack and connect the cord into the jack inside the handset.
4. Put the battery compartment door back on.
5. Place handset in the base to charge. If you don't charge the handset battery properly (for 12 hours) when you first set up the phone and/or when you install a new battery pack, the battery's long-term performance will be compromised.



BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.



NOTE: The RBRC seal on the battery used in your ATLINKS USA product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or contact your local recycling center.


HEADSET AND BELT CLIP OPERATION

CONNECTING A HEADSET TO THE HANDSET

For hands free conversation, connect the headset (optional) to the HEADSET jack as shown. The handset receiver and microphone are disabled when the headset is connected.

Adjust the headset to rest comfortably on top of your head and over your ear. Move the microphone to approximately 2 to 3 inches from your mouth.


- Press the TALK button to answer or place a call before using the headset.



CONNECTING THE BELT CLIP

There are two slots, one on each side of the handset.

- Attach the belt clip by inserting the sides of the belt clip into the slots. Snap the ends of the belt clip into place.



MESSAGE INDICATORS

The following indicators show the status of a message or of the unit.

ERROR	Caller information has been interrupted during transmission or the phone is excessively noisy.
ENTER NAME	Prompt telling you to enter name one of the 10 memory locations.
ERASE ALL?	Prompt asking you if you want to erase all Caller ID records.
ERASE CALL ID?	Prompt asking you if you want to erase the current Caller ID record that is shown on the display.
ERASE MEMO?	Prompt asking you if you want to erase one of the 10 numbers stored in the phone's outgoing memory.
END OF LIST	Indicates that there is no additional information in Caller ID memory.
NEW	Indicates call or calls have not been reviewed.
UNKNOWN	The incoming call is from an area not serviced by Caller ID or the information was not sent.
PAGING YOU	Someone has pressed the PAGE button on the base.
BLOCKED	The person is calling from a number that has been blocked from transmission.
REPT	Repeat call message. Indicates that a new call from the same number was received more than once.

CAUSES OF POOR RECEPTION

- Aluminum siding.
- Foil backing on insulation.
- Heating ducts and other metal construction can shield radio signals.
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms.
- Base is installed in the basement or lower floor of the house.
- Base is plugged into an AC outlet with other electronic devices.
- Baby monitor is using the same frequency.
- Handset battery is low.
- You're out of range of the base.

HANDSET SOUND SIGNALS

Signal	Meaning
A long warbling tone (with ringer on)	Signals an incoming call
One short beep, one long beep (3 times)	Page signal
Three short beeps	Out of range
Four short beeps	Low battery warning

TROUBLESHOOTING TIPS

CALLER ID

Problem	Solution
No Display	<ul style="list-style-type: none"> • Is battery fully charged? Try replacing the battery. • Make sure that the unit is connected to a non-switched electrical outlet. Disconnect the unit from the plug and plug it in again. • Did you order Caller ID service from your local telephone company? The display won't work unless you order Caller ID service from your phone company.

Caller ID Error Message	<ul style="list-style-type: none"> • The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first ring. This message indicates either the presence of noises on the line, or that an invalid message has been sent from the telephone company.
-------------------------	--

TELEPHONE

Problem	Solution
No dial tone	<p>Check installation:</p> <ul style="list-style-type: none"> — Is the base power cord connected to a working outlet? <ul style="list-style-type: none"> — Is the telephone line cord connected to the base unit and the wall jack? • Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone in the second phone, the problem might be your wiring or local service. • Is the handset out of range of the base? • Make sure the battery is properly charged (12 hours). • Is the battery pack installed correctly? • Did the handset beep when you pressed the TALK button? Did the CHARGE/IN USE indicator come on? The battery may need to be charged. • Make sure the TONE/PULSE setting is programmed correctly.
Dial tone is OK, but can't dial out	<ul style="list-style-type: none"> • Make sure the RINGER switch on the handset is turned to ON. • You may have too many extension phones on your line. Try unplugging some phones. • See solutions for "No dial tone."
Handset does not ring	<ul style="list-style-type: none"> • Make sure the RINGER switch on the handset is turned to ON. • You may have too many extension phones on your line. Try unplugging some phones. • See solutions for "No dial tone."

INDEX

A	Accessory Order Form 33
B	Battery Safety Precautions 24 Before You Begin 5
C	Call Waiting Caller ID 14 Caller ID Features 14 Causes of Poor Reception 25 Chain Dialing from Memory 21 Changing a Stored Number 19 Changing the Battery 24 Changing the Number Format 17 Channel Button 10 Connecting a headset to the handset 23 Connecting the Belt Clip 23
D	Deleting All Records 16 Deleting Records 16 Deleting the Current Record 16 Desktop Installation 6 Dialing a Caller ID Number 16 Dialing a Stored Number 20 Digital Security System 5
F	FCC Registration Information 2 Finding the Handset 11 Flash Button 10
G	General Product Care 32
H	Handset Sound Signals 27 Headset and Belt Clip Operation 23 Hearing Aid Compatibility 2
I	Inserting a Pause in the Dialing Sequence 22 Installation 6 Interference Information 2 Introduction 4
L	Limited Warranty 35
M	Making a Call 9 Memory 18 Message Indicators 26 Modular Jack Requirements 5
P	Parts Checklist 5 Pulse 12

Problem	Solution
You experience static, noise, or fading in and out	<ul style="list-style-type: none"> • Change channels. • Is handset out of range? Move closer to the base. • Does the base need to be relocated? • Charge battery. • Make sure base is not plugged into an outlet with another household appliance.
Handset beeps continuously, as if the battery is low	<ul style="list-style-type: none"> • Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge battery for 12 hours. • Clean charging contacts on handset and base with a soft cloth, or an eraser. • See solutions for "No dial tone." • Replace battery.
Memory Dialing	<ul style="list-style-type: none"> • Did you program the memory location keys correctly? • Did you follow proper dialing sequence? • Make sure the TONE/PULSE setting is programmed correctly. • Did you reprogram numbers into memory after power outage or battery replacement?

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a clean pen or pencil eraser.

SERVICE

FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by ATLINKS USA could void the user's authority to operate this product. For instructions on how to obtain service, call Consumer Information, 1-800-448-0329.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____ Name of store _____

R	Receiving a Call 9
	Receiving and Storing Calls 15
	Redial 9
	Reviewing and Deleting Stored Numbers 22
	Reviewing Messages 15
	Finger Switch 12
S	Service 32
	Storing a Number in Memory 18
T	Telephone Basics 9
	Temporary Tone 11
	Tone 12
	Tone/Pulse Dialing 12
	Troubleshooting Tips 27
U	Using Call Back 20
V	Voice Messaging 13
	Volume 13
W	Wall Mount Installation 7
	While the Phone is Off 10
	While the Phone is On 9

ACCESSORY ORDER FORM

DESCRIPTION	CATALOG NUMBER		PRICE	QUANTITY	TOTAL
	(white)	(black)			
AC power supply adapter	5-2464	5-2465	\$24.95		
Belt clip	5-2462	5-2463	\$10.85		
Headset	5-2444	5-2425	\$36.35		
Replacement battery	5-2481		\$9.96		

To order, call 1-800-338-0376 (for accessories only) or complete this order form.

*Prices are subject to change without notice.

Total Merchandise.....\$
 Sales Tax.....\$
 We are required by law to collect the appropriate sales tax for each individual state, county, and locality to which the merchandise is being sent. Duties will apply for shipments to Canada.
 Use VISA or Master Card or Discover preferably. Money order or check must be in U.S. currency only. No COD or cash. All accessories are subject to availability. Where applicable, we will ship a superseding model.
 Shipping/handling.....\$5.00
 Total Amount Enclosed.....\$

For credit card purchases
 Your complete charge card number, its expiration date and your signature are necessary to process all charge card orders.
 Copy your complete account number from your VISA card.
 My card expires:

Copy the number above your name on the Master Card
 My card expires:

Copy your complete account number from your
 Master Card or Discover.
 My card expires:

Name _____
 Address _____
 Apt. _____
 City _____ State _____ ZIP _____
 Daytime Phone Number () _____
 Ronka, PA 17573-8418
 P.O. Box B418
 Mail Order Department
 TCE

All order form and money order or check (in U.S. currency) made payable to Thomson Consumer Electronics, Inc. to:

Authorized Signature _____

Please make sure that this form is filled out completely

CUSTOMER: CUT ALONG DOTTED LINE. ✂

LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.
 - For how long after your purchase:
 - One year.
 - (The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)
- ### What we will do:
- Provide you with a new or, at our option, a refurbished unit.
 - The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.
11721 B Alameda Ave.
Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
 - Insure your shipment for loss or damage. Thomson accepts no liability in case of damage or loss en route to Thomson.
 - A new or refurbished unit will be shipped to you freight prepaid.
- ### What your warranty does not cover:
- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
 - Installation and set-up service adjustments.
 - Batteries.
 - Damage from misuse or neglect.
 - Products which have been modified or incorporated into other products.
 - Products purchased or serviced outside the USA.
 - Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.
- How state law relates to this warranty:
 - This warranty gives you specific legal rights, and you may have other rights which vary from state to state.
- If you purchased your product outside the USA:
 - This warranty does not apply. Contact your dealer for warranty information.

ATLINKS USA, Inc.
10330 North Meridian Street
Indianapolis, IN 46250
• 2000 ATLINKS USA, Inc.
Trademark(s) • Registered
Marcatel Registrada(s)

Model 26929
15618500 (Rev. 0 ESI)
00-24
Printed in China