


SETTING THE RINGER SOUND


1. Make sure the phone is **OFF**.
2. Press and release the PROGRAM button on the base until *RINGER SETTING* shows on the display.
3. Press 1 or 2 for the different ringer sounds.
4. Press FORM/HOLD to confirm.

NOTE: You can exit the Program mode at any time by pressing the PGM button.



SETTING THE TIME

1. Make sure the phone is **OFF**.
2. Press and release the PROGRAM button on the base until *12:00 AM* shows on the display.
3. Enter the time using the number keys (0-9) and the arrow buttons.
4. Press FORM/HOLD to confirm.



TELEPHONE OPERATION

RECEIVING A CALL

1. Check the display to see who is calling.
2. Press the TALK button.

MAKING A CALL


After initial set up, put handset in the base for 12 hours to charge the battery.

The cordless phone automatically selects the last line you used. The only two things you need to know to make a call are:

1. Press LINE 1 or LINE 2 to select a line before you dial.
2. Press LINE 1 or LINE 2 when you are finished (whichever line you are talking on).

Otherwise, it works just like any other phone.

NOTE: You can press TALK instead of pressing LINE 1 or LINE 2. The phone defaults to the last line used.



LINE INDICATOR LIGHTS

Above each line button is a red indicator light which informs you the status of each line.


<i>Light</i>	<i>Status</i>
Solid	Line is in use
Blinking	Line on hold

AUTO STANDBY

While the handset is on, place it in the base and it will automatically hang up.

DUAL RINGER TONES

Your cordless telephone has separate and distinct ringer sounds for LINE 1 and LINE 2. This will allow you to determine the line of an incoming call, even in another room. If you are talking on one line and someone calls on the other line, the phone alerts you by sending a signal to the handset's earpiece.




USING THE SPEAKERPHONE

For best speakerphone performance, avoid the following:

- Areas with high background noise. (The microphone might pick up these sounds and prevent the speakerphone from going into the receiving mode when you finish talking.)
- Surfaces affected by vibration.
- Recessed areas such as in a corner, under a cupboard, or next to a cabinet, which can generate an echo effect.

Note the following guidelines when you use the speakerphone:

- The speakerphone works similar to a two-way radio in that you can only listen or talk one at a time.
- Stay reasonably close to the phone so that you can be clearly heard by the person to whom you are speaking.
- The speakerphone indicator light is on when the speakerphone is in use.



ANSWERING AND PLACING CALLS


RECEIVING A CALL

To answer a call when the handset is out of the base, you must press the LINE 1 or LINE 2 button.

SWITCHING BETWEEN SPEAKER AND HANDSET

You can switch between speakerphone and handset after dialing a number, or anytime during a conversation.

- **Speaker to Handset** — Pick up the handset.
- **Handset to Speaker** — Press SPEAKER, then hang up the handset.





INTERCOM

The intercom feature of your cordless phone allows you to have a two-way conversation between the handset and the base unit without tying up the telephone line. Since the telephone line is not being used, you can still receive incoming calls.

USING INTERCOM

FROM THE HANDSET


1. Make sure the phone is **OFF**.
2. Press the INT button. A paging tone sounds at the base. (To cancel intercom, press INT again.)
3. Wait for the person near the base to press the PAGE INTERCOM button.
4. When finished, press INT on the handset (or PAGE INTERCOM on the base) to deactivate the intercom.




FROM THE BASE

1. Make sure the phone is **OFF**.
2. Press PAGE INTERCOM. A paging tone sounds at the handset. (To cancel intercom, press PAGE INTERCOM again.)
3. Wait for the person with the handset to press the INT button.
4. When finished, press PAGE INTERCOM on the base (or INT on the handset) to deactivate the intercom.

NOTE: The handset must be within range of the base unit in order for intercom to function. If the handset is in use, you will hear an soft ring from the base unit.



PAGE INTERCOM button





INT button

WHEN YOU HAVE A CALL

You may want to use the intercom feature while you are on a call.

1. Press the FORM/HOLD button (or HOLD on the base) to put the call on hold. *HOLD* shows on the display.
2. Follow the steps 2-4 in either the handset or base "Using Intercom" section to complete the intercom.
3. When finished, press FORM/HOLD (or HOLD on the base) to return to your call.

NOTE: While a call is on hold on the handset, you can transfer the call to the base by pressing the SPEAKER button. You can also transfer a call on hold at the base to the handset by pressing the TALK button.



REDIAL

Press the RE/PA button to redial the last number you dialed, (up to 24 digits)


FLASH BUTTON

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

CHANNEL BUTTON


While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.



TEMPORARY TONE

This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:


1. Call the bank's information line.
2. Press the TONE button (*) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.



HOLD

You can use the FORM/HOLD button to interrupt a phone conversation without hanging up.

1. Press FORM/HOLD (or HOLD on the base) to place the active line on hold.
2. Press the LINE button for that call to resume the conversation.




CONF button

CONFERENCE

You can use the conference call feature when you have callers on both lines and want to have a three-way conversation.

1. Press FORM/HOLD (or HOLD on the base) to place the party on hold.
2. Press the other LINE button.
3. Dial the number of the second party.
4. Press CON (or CONF on the base).
5. Press LINE 1 or LINE 2 when finished to talk privately and disconnect the other line.




- Press LINE 1 or LINE 2 for whichever line you are talking on or place the handset in the base to hang up.

FINDING THE HANDSET

This feature helps to locate a misplaced handset.

Press and hold the PAGE/FIND INTERCOM button on the base. The display shows PAGING. The handset beeps continuously for about 2 minutes or until you press any button on the handset.




PAGE/FIND INTERCOM button

RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls.


VOLUME

The VOLUME buttons controls the volume of the handset's earpiece, with five listening levels.




MUTE

To prevent the person you are speaking to from hearing you while on a call, press the PGM/MUTE button on the handset or MUTE button on the base. *MUTE* shows in either display. Press PGM/MUTE or MUTE again to cancel.



VOICE MESSAGING

Provided your phone company offers voice messaging service and you subscribe to it, the CHARGE light on the base will flash when the phone is not in use to indicate there is a message waiting. It will stop flashing after the message has been reviewed.




CALLER ID FEATURES

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; *or* the name, phone number, date, and time. The unit can store up to 40 calls for later review.

CALLER ID WITH CALL WAITING

Provided you subscribe to Caller ID with Call Waiting service from your phone company, you are able to see who is calling when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- Press the FLASH button to put the current person on hold so that you can answer the incoming call.




VERY IMPORTANT: The Caller ID feature of this product requires a subscription to Caller ID service from your telephone company.

RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID Telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. *NEW* appears in the display for calls received that have not been reviewed.

NOTE: Check with your local phone company regarding name service availability.



REVIEWING MESSAGES

As calls are received and stored, the display is updated to let you know how many calls have been received.

- Press the arrow down button to scroll through the call records from the most recent to the oldest.
- Press the arrow up button to scroll through the call records from the oldest to the newest.