

EXHIBIT A

(FCC Ref. 2.1033(b)(3))

"Installation and Operating Instructions
Furnished to the User"

2-9769



**Caller ID Telephone
User's Guide**

We bring good things to life.

FCC ID: G9H2-9769
EXHIBIT A(1)
Marstech Report No. 98131D

FCC REGISTRATION INFORMATION

Your GE telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM


INTRODUCTION

Your GE cordless phone is designed to give you flexibility in use, and high quality performance. To get the most from your new phone, we suggest that you take a few minutes right now to read through this instruction manual.

TABLE OF CONTENTS


FCC REGISTRATION INFORMATION	2	DIALING A CALLER ID NUMBER	13
INTERFERENCE INFORMATION	2	STORING A NUMBER IN MEMORY	14
HEARING AID COMPATIBILITY	2	THE MEMORY FEATURE	14
INTRODUCTION	3	CHANGING A STORED NUMBER	15
INSTALLATION AND SETUP	4	DIALING A STORED NUMBER	16
MODULAR JACK REQUIREMENTS	4	CHAIN DIALING FROM MEMORY	16
DESKTOP INSTALLATION	5	INSERTING A PAUSE IN THE DIALING	
WALL MOUNT INSTALLATION	6	SEQUENCE	17
TELEPHONE SETUP	7	REVIEWING AND DELETING STORED NUMBERS	
CALLER ID SETUP	7	17
TELEPHONE OPERATION	8	CHANGING THE BATTERY	18
RECEIVING A CALL	8	BATTERY SAFETY PRECAUTIONS	19
MAKING A CALL	8	GENERAL PRODUCT CARE	19
PHONE LIGHT	8	MESSAGE INDICATORS	20
REDIAL	8	HANDSET SOUND SIGNALS	21
FLASH BUTTON	8	TROUBLESHOOTING TIPS	21
CHANNEL BUTTON	8	CALLER ID	21
TEMPORARY TONE	9	TELEPHONE	22
PAGING THE HANDSET	9	TROUBLESHOOTING TIPS	22
RINGER SWITCH	10	TROUBLESHOOTING TIPS	23
VOLUME SWITCH	10	CAUSES OF POOR RECEPTION	24
CALLER ID OPERATION	10	SERVICE	24
RECEIVING AND STORING CALLS	10	ACCESSORY ORDER FORM	25
CALLER ID DISPLAY	11	INDEX	26
REVIEWING MESSAGES	11	LIMITED WARRANTY	27
MESSAGE ERRORS	12		
DELETING RECORDS	12		
DELETING THE CURRENT RECORD	13		
DELETING ALL RECORDS	13		

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



INSTALLATION AND SETUP


Make sure your package includes the items shown here.



VERY IMPORTANT: This product requires a subscription to Caller ID service from your telephone company.


MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.



INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If such interference continues, move the cordless telephone farther away from the TV or VCR.

DESKTOP INSTALLATION






1. Set the PULSE/TONE switch to TONE for touch-tone service, or PULSE for rotary service. If you don't know which type of service you have, check with the phone company.
2. Plug the telephone line cord into the base and into a modular jack.
3. Plug the power supply cord into the base, into an AC outlet.
4. Raise the base antenna.

NOTE: Use only the Thomson 5-XXXX power supply that came with this unit. Using other adapters may damage the unit.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.


WALL MOUNT INSTALLATION

1. Remove the base plate from the back by pressing down on the snap tabs located at the top, and then lifting the base plate off.
2. Plug the short phone line cord into the phone jack on the back of the unit and then thread it through the bottom of the base plate.
3. Plug the power supply adapter into the POWER 12V DC jack on the back of the unit, and then thread it through the bottom of the base.
4. Replace base plate.
5. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)
6. Connect the power supply adapter to an AC outlet.
7. Plug the phone line cord into the modular jack.




TELEPHONE SETUP

1. Set the PULSE/TONE switch (on the top of the unit) to TONE for touch-tone service, or PULSE for rotary service. If you don't know which type of service you have, check with the phone company.
2. Place handset in the base to charge for 12 hours. The CHARGE/IN USE light comes on indicating that the battery is charging.
3. Turn on the RINGER switch so the handset rings for incoming calls.



CALLER ID SETUP

1. For proper Caller ID operation, you must enter your area code. Make sure the phone is OFF.
2. Press and hold ENTER for 3 seconds. The Caller ID display on the handset prompts you to enter your area code.
3. Enter your 3-digit area code by pressing the appropriate number keys. The phone emits 2 beeps to confirm it has accepted the area code entry.
4. To change or enter your area code again, follow steps 1-3 above.



TELEPHONE OPERATION

RECEIVING A CALL


1. Check the display to see who is calling.
2. Press the PHONE button.

MAKING A CALL

To make a call, press the PHONE button before you dial and press it again to hang up.

PHONE LIGHT

You know the phone is on when you see the PHONE light on the handset come on.



REDIAL

Press the REDIAL button to redial the last number you dialed.



FLASH BUTTON


Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

The FLASH button is also used to enter a pause in the dialing sequence.

TIP: Don't use PHONE button to activate customer calling services such as call waiting, or you'll hang up the phone.

CHANNEL BUTTON


While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.



TEMPORARY TONE

This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

1. Call the bank's information line.
2. Press the TONE button (☎) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.




PAGING THE HANDSET

Press the PAGE/FIND button on the base to get the attention of the person using the phone or to locate a misplaced handset. Remember that the RINGER switch must be ON for the handset to ring.

If you press and hold PAGE/FIND, the handset will continue to page until:

1. You release the button.
2. You press PHONE on the handset.




RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls (or when paging the handset).

VOLUME SWITCH

Controls the volume of the handset's earpiece.



CALLER ID OPERATION

This Caller ID Cordless Telephone receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time.


RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID Telephone between the first and second ring.

- You can monitor the information as it is displayed and decide whether or not to answer the call.
- If you are not at home, the telephone stores the information so that you can see who called while you were out.

VERY IMPORTANT: The Caller ID feature of this product requires a subscription to Caller ID service from your telephone company.

CALLER ID DISPLAY



REVIEWING MESSAGES

As calls are received and stored, the display is updated to let you know how many calls have been received and how many have been reviewed.

Use the arrow buttons ▲ or ▼ to scroll through the list of received calls.


- Press the arrow up button ▲ to scroll toward more recent calls (higher numbers).
- Press the arrow down button ▼ to scroll toward older calls (lower numbers).

Note: The Caller ID memory holds 25 names and numbers. When the memory is full, only the most recent calls are stored. The oldest stored number in memory is deleted to make room for the newest call, which will be designated as call #25 in the Caller ID display.

As you review calls, the display shows you the following information:

- The telephone number of the caller.
- The number of the call (with regard to the order received), whether it is a new call (NEW), and if a call has been received more than once from the same number (REPT).
- The name of the caller (if this service is available in your area).

If the information doesn't fit in the display, press ENTER to see the rest of the Caller ID information.



09:15 AM 10/22 NEW CALL #23
1-234-555-6789
JOE SMITH

This Caller ID record shows that Joe Smith called at 9:15 am on October 22nd. This is the 23rd call stored in memory and it is a new call.

NOTE: Check with your local phone company regarding name service availability.

MESSAGE ERRORS

If there is an error in the transmission of information to your caller ID phone, *CALLER ID ERROR* appears in the display.




CALLER ID ERROR

Caller ID transmission error.

DELETING RECORDS

Use the DELETE button to erase the record currently shown in the display or all records.



DELETING THE CURRENT RECORD

1. Press DELETE.

The display asks you to confirm the deletion.

2. Press DELETE again to erase the record.



ERASE CALL ID?

Display asks you to confirm the deletion.

DELETING ALL RECORDS

1. Press and hold DELETE.

The display asks you to confirm that you want to erase all records.


2. Press DELETE again to erase all records.



Display asks you to confirm the deletion.

DIALING A CALLER ID NUMBER

- Make sure the phone is ON.
- Use the arrow buttons to display the desired Caller ID record.
- Press the CALL BACK button if the number is local.
- Press the # key (1+) to dial a long distance number or a number that requires you to dial "1" for proper connection.



THE MEMORY FEATURE

Store up to 10 16-digit numbers in memory for quick dialing. This memory feature is in addition to the 25 Caller ID records and the 5 VIP records that can be stored in memory.


STORING A NUMBER IN MEMORY

The phone must be **OFF** when you store numbers.

1. Press the **MEMORY** button.
2. Press **ENTER**.

The display will prompt you to "ENTER NAME."

3. Use the keypad to store a name (up to 15 characters). More than one letter is stored in each of the number keys. For example, to enter Joe Smith, press 5 for J; press 6 three times for O; press 3 two times for E; press 1 to enter a space before you start entering the last name; press 7 four times for S; press 6 for M; press 4 three times for I; press 8 for T; and 4 two times for H. If you're using two letters consecutively that are stored in the same number key, you must press **ENTER** between the letters. For example, if you enter Barb, press 2 two times for B; press **ENTER**; press 2 for A; 7 three times for R; and 2 two



NOTE: If you don't want to enter the name, skip step 3.

times for B. You need to press enter between the B and the A since they are stored within the same number key.

4. Press MEMORY.


The display will prompt you to "ENTER TEL NUMBER."

5. Use the keypad to enter the number you want to store (up to 32 digits).

6. Press MEMORY and then press a number key (0-9) to store the dialed number in that memory location.

7. Record whose number is stored in the location on the memory directory card on the back of the handset. You will also be able to view the name and number in the phone's display.

CAUTION: If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.




CHANGING A STORED NUMBER

Use the same procedure to change a stored number as you do to store a number—in a sense, you're just reassigning the memory location.

DIALING A STORED NUMBER

1. Make sure the phone is **ON** by pressing the **PHONE** button.
2. Press **MEMORY**
3. Press the number (0-9) for the desired memory location OR use the arrow buttons to scroll through the numbers stored in memory and press **CALL BACK** when you reach the desired number.




CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

<i>The Number For</i>	<i>Memory Location</i>
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

1. Make sure the phone is **ON**.
2. Press **MEMORY** and then press 7.
3. When you hear the access tone, press **MEMORY** and then press 8.
4. At the next access tone, press **MEMORY** and then 9.



TIP: Wait for the access tones before pressing the next memory button, or your call might not go through.


INSERTING A PAUSE IN THE DIALING SEQUENCE

Press the FLASH button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.



REVIEWING AND DELETING STORED NUMBERS

1. Press MEMORY, then press the arrow keys to view the entry.
2. While the entry is displayed, press the DELETE key to delete the entry.




The display asks you to confirm that you want to delete the entry.



Display asks you to confirm the deletion.

3. Press DELETE a second time to delete the entry.

To exit the memory review mode, press the memory location button again.




CHANGING THE BATTERY

The handset runs on a consumer-replaceable nickel cadmium battery pack. If you experience any of the following problems, you may need to replace the battery pack:


- Short talk time
- Limited range
- Poor sound quality
- CHARGE/IN USE light fails to light

Make sure phone is **OFF** before you replace battery.



1. Slide open the battery compartment door.
2. Unhook the strap holding the battery in place.
3. Pull out the battery plug.
4. Remove the battery pack.







Battery Holding Strap



Plug




5. Replace and plug in the new battery pack. (use GE BT-12 replacement battery.)
6. Reconnect the strap to secure the battery.
7. Replace the battery compartment door.
8. Charge the battery for 12 hours before use.



BATTERY SAFETY PRECAUTIONS

- Don't disassemble, mutilate, puncture, wet, or dispose of battery in fire. Like other batteries of this type, if it is burned or punctured, it could release toxic materials which can cause injury.
- Keep batteries out of the reach of children.



NOTE: The RBRC seal on the battery used in your Thomson Consumer Electronics product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or contact your local recycling center.

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a soft cloth.

MESSAGE INDICATORS

The following indicators show the status of a message or the unit.

CALLER ID ERROR	Caller information has been interrupted during transmission or the phone is excessively noisy.
ENTER AREA CODE	Prompt telling you to enter your area code.
ENTER NAME	Prompt telling you to enter name into VIP memory or one of the 10 memory locations.
ERASE ALL?	Prompt asking you if you want to erase all Caller ID records.
ERASE CALL ID?	Prompt asking you if you want to erase the current Caller ID record or VIP record that is shown on the display.
ERASE MEMO?	Prompt asking you if you want to erase one of the 10 numbers stored in the phone's outgoing memory.
END OF LIST	Indicates that there is no additional information in Caller ID memory.
MESSAGE WAITING	Somebody left a voice mail message. Note that voice mail is a subscription service; check with your local telephone company for availability.
NEW	Number of new calls for you to review.
OUT OF AREA	The incoming call is from an area not serviced by Caller ID or the information was not sent
PAGING YOU	Someone is pressing the PAGE button.
PRIVATE	The person is calling from a number that has been blocked from transmission.
REPT	Repeat call message. Indicates that a new call from the same number was received more than once.

HANDSET SOUND SIGNALS

<i>Signal</i>	<i>Meaning</i>
Three long beeps	Page signal
A long warbling tone (with ringer on)	Signals an incoming call
Four short beeps	Out of range warning

TROUBLESHOOTING TIPS

CALLER ID

<i>Problem</i>	<i>Solution</i>
No Display	<ul style="list-style-type: none">• If you are using battery power, try replacing the battery.• If you are using AC power, make sure that the unit is connected to a non-switched electrical outlet. Disconnect the unit from the plug and plug it in again.• Did you order Caller ID service from your local telephone company? The display won't work unless unless you order Caller ID service from your phone company.
Data Error Message	<ul style="list-style-type: none">• The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first ring. This message indicates either the presence of noises on the line, or that an invalid message has been sent from the telephone company.

TROUBLESHOOTING TIPS

TELEPHONE

<i>Problem</i>	<i>Solution</i>
No dial tone	<ul style="list-style-type: none">• Check installation:<ul style="list-style-type: none">– Is the base power cord connected to a working outlet?– Is the PHONE light on?– Is the telephone line cord connected to the base unit and the wall jack?• Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone in the second phone, the problem might be your wiring or local service.
No dial tone (<i>continued</i>)	<ul style="list-style-type: none">• Is the handset out of range of the base?• Make sure the battery is properly charged (12 hours).• Is the battery pack installed correctly?• Did the handset beep when you pressed the PHONE button? Did the Phone-in-Use light come on? The battery may need to be charged.
Dial tone is OK, but can't dial out	<ul style="list-style-type: none">• Make sure the TONE/PULSE switch on the base is correctly set.
Handset does not ring	<ul style="list-style-type: none">• Make sure the RINGER switch on the handset is turned to ON.• You may have too many extension phones on your line. Try unplugging some phones.• See solutions for "No dial tone."

TROUBLESHOOTING TIPS

<i>Problem</i>	<i>Solution</i>
You experience static, noise, or fading in and out	<ul style="list-style-type: none">• Change channels• Is handset out of range? Move closer to the base.• Does the base need to be relocated?• Charge battery.• Make sure base is not plugged into an outlet with another household appliance.
Unit beeps	<ul style="list-style-type: none">• Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge battery for 12 hours.• Clean charging contacts on handset and base with a soft cloth, or an eraser.• See solutions for "No dial tone."• Replace battery.
Memory Dialing	<ul style="list-style-type: none">• Did you program the memory location keys correctly?• Did you follow proper dialing sequence?• Make sure TONE/PULSE switch is correctly set.• Did you reprogram numbers into memory after power outage or replacing battery?

CAUSES OF POOR RECEPTION

- Aluminum siding
- Foil backing on insulation
- Heating ducts and other metal construction can shield radio signals
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms
- Base is installed in the basement or lower floor of the house
- Base is plugged into an AC outlet with other electronic devices
- Baby monitor is using the same frequency
- Handset battery is low.
- You're out of range of the base.

SERVICE

The FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this Guide.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____ Name of store _____

INDEX

A

Accessory Order Form 25

B

Battery Safety Precautions 19

C

Caller ID 21

Caller ID Display 11

Caller ID Operation 10

Caller ID Setup 7

Causes of Poor Reception 24

Chain Dialing from Memory 16

Changing a Stored Number 15

Changing the Battery 18

Channel Button 8

D

Deleting All Records 13

Deleting Records 12

Deleting the Current Record 12

Desktop Installation 5

Dialing a Caller ID Number 13

Dialing a Stored Number 16

F

FCC Registration Information 2

Flash Button 8

G

General Product Care 19

H

Handset Sound Signals 21

Hearing Aid Compatibility 2

I

Inserting a Pause in the Dialing
Sequence 17

Installation and Setup 4

Interference Information 2

26

Introduction 3

L

Limited Warranty 27

M

Making a Call 8

Message Errors 12

Message Indicators 20

Modular Jack Requirements 4

P

Paging the Handset 9

Phone Light 8

R

Receiving a Call 8

Receiving and Storing Calls 10

Redial 8

Reviewing and Deleting Stored Numbers
17

Reviewing Messages 11

Ringer Switch 10

S

Service 24

Storing a Number in Memory 14

T

Table of Contents 3

Telephone 22

Telephone Operation 8

Telephone Setup 7

Temporary Tone 9

The Memory Feature 14

Troubleshooting Tips 21, 22, 23

V

Volume Switch 10

W

Wall Mount Installation 6

LIMITED WARRANTY

What your warranty covers

- Any defect in materials or workmanship

For how long after your purchase

- One year.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new, or at our option, a refurbished unit.
- The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc
Product Exchange Center
32B Spur Drive
El Paso, Texas 79906

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty *does not* cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

Model 2-9769
15347740 (Rev. 0 E/S)
96-06
Printed in China

 **THOMSON CONSUMER ELECTRONICS**
P.O. Box 1976, Indianapolis, IN 46206
© 1996 Thomson Consumer Electronics, Inc.
Trademark(s) ® Registered
Marca(s) ® Registrada(s)