



Please DO NOT return product to the retail store.  
For technical assistance and product return information, please call  
Customer Care: 877-221-1252 Mon. - Fri. 8:00 A.M. to 4:30 P.M. (CST)

[www.chaneyinstrument.com](http://www.chaneyinstrument.com)

Timex® is a registered trademark of Timex Corporation in the U.S. and other countries.  
Indiglo® is a registered trademark of Indiglo Corporation in the U.S. and other countries.

Manufactured and serviced by  
Chaney Instrument Co.  
Lake Geneva, WI 53147  
[www.chaneyinstrument.com](http://www.chaneyinstrument.com)

© 2010 Chaney Instrument Co.  
INST - 75071T 120210

#### LIMITED ONE YEAR WARRANTY

Chaney Instrument Company warrants that all products it manufactures to be of good material and workmanship and to be free of defects if properly installed and operated for a period of one year from date of purchase. REMEDY FOR BREACH OF THIS WARRANTY IS EXPRESSLY LIMITED TO REPAIR OR REPLACEMENT OF DEFECTIVE ITEMS. Any product which, under normal use and service, is proven to breach the warranty contained herein within ONE YEAR from date of sale will, upon examination by Chaney, and at its sole option, be repaired or replaced by Chaney. In all cases, transportation costs and charges for returned goods shall be paid for by the purchaser. Chaney hereby disclaims all responsibility for such transportation costs and charges. This warranty will not be breached, and Chaney will give no credit for products it manufactures which shall have received normal wear and tear, been damaged, tampered, abused, improperly installed, damaged in shipping, or repaired or altered by others than authorized representatives of Chaney.

THE ABOVE-DESCRIBED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES ARE HEREBY DISCLAIMED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. CHANEY EXPRESSLY DISCLAIMS ALL LIABILITY FOR SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES, WHETHER ARISING IN TORT OR BY CONTRACT FROM ANY BREACH OF THIS WARRANTY. SOME STATES DO NOT ALLOW THE EXCLUSIONS OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. CHANEY FURTHER DISCLAIMS ALL LIABILITY FROM PERSONAL INJURY RELATING TO ITS PRODUCTS TO THE EXTENT PERMITTED BY LAW. BY ACCEPTANCE OF ANY OF CHANEY'S EQUIPMENT OR PRODUCTS, THE PURCHASER ASSUMES ALL LIABILITY FOR THE CONSEQUENCES ARISING FROM THEIR USE OR MISUSE. NO PERSON, FIRM OR CORPORATION IS AUTHORIZED TO ASSUME FOR CHANEY ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF ITS PRODUCTS. FURTHERMORE, NO PERSON, FIRM OR CORPORATION IS AUTHORIZED TO MODIFY OR WAIVE THE TERMS OF THIS PARAGRAPH, AND THE PRECEDING PARAGRAPH, UNLESS DONE IN WRITING AND SIGNED BY A DULY AUTHORIZED AGENT OF CHANEY. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

#### For in-warranty repair, please contact:

Customer Care Department  
Chaney Instrument Company  
965 Wells Street  
Lake Geneva, WI 53147

Chaney Customer Care  
877-221-1252  
Mon-Fri 8:00 a.m. to 4:30 p.m. CST  
[www.chaneyinstrument.com](http://www.chaneyinstrument.com)

# TIMEX®

Intelli-Time® Digital Clock  
with extra large LCD  
#75071T



## USER GUIDE

### Package Contents:

- (1) Digital Clock
- (1) User Guide


### What You'll Need:

- (4) AA Batteries

Thank You for purchasing this TIMEX® product. This digital clock features Intelli-Time® technology, which instantly sets the clock once the batteries are in. Please read this manual in its entirety to fully enjoy the benefits and features of this product. Please keep this manual for future reference.

**NOTE:** A protective plastic case is placed over the display at the factory that must be removed prior to using this product.

### 1 • OVERVIEW OF FEATURES




BACK OF CLOCK

## About Intelli-Time®

Your new digital clock is equipped with Intelli-Time® technology which is pre-programmed with the correct time and date. Intelli-Time® instructs the clock to set itself once batteries are installed. The Intelli-Time® feature requires an internal memory battery to operate correctly. This battery is located in the Intelli-Time® memory battery compartment on the back of the clock and is pre-installed at the factory. We suggest replacement of the backup battery every 5 years. We recommend the replacement of backup battery in 1-2 years if the unit is not powered on for a long period of time. Do not replace the memory battery unless the clock is powered and the display is operating with the correct time.

### 2 • SETUP



#### BATTERY INSTALLATION:

- 1 REMOVE BATTERY COMPARTMENT COVER
- 2 INSTALL 4 "AA" ALKALINE BATTERIES

- 3 **INITIAL SETUP:** Once the batteries are installed, the clock will power up. The clock will set itself to the correct time and date, defaulting to EST (eastern standard time).

### Setting the time zone and daylight saving time:

1. Press, then release the "TIME ZONE" button on the back of the digital clock until it reaches the desired time zone position. You will see the time zone on the front of the clock in the upper right hand corner.

#### TIME ZONES

AST: Atlantic	MST: Mountain
EST: Eastern	PST: Pacific
CST: Central	AKST: Alaska
	HAST: Hawaii-Aleutian

2. You must also determine which Daylight Saving time setting to use on the back of the unit; new or old. Due to possible future changes in DST, this unit is equipped with a selection switch to choose between the traditional DST setting (OLD) or the new DST time change dates. You may slide the button to the left for (OLD), middle for (NEW) or right for (OFF). "DAYLIGHT ST" will appear on the screen when Daylight Saving Time is observed.

The following chart illustrates the differences between the auto DST settings and when each setting automatically changes the time during the year.

NEW DST	OLD DST	OFF
2007 and beyond	2006	NO DST changes
2:00 am 2nd Sunday in March	2:00 am 1st Sunday in April	
2:00 am 1st Sunday in November	2:00am last Sunday in October	

**AUTO DST NOTE:** portions of the country do not observe daylight savings time. If you live in an area that does not observe daylight saving time, please turn off DST function.

## Changing the Backup Battery

**Do not change the backup batteries unless the main 4 "AA" batteries are working. This will prevent the clock from being without power, and the internal calendar memory will function properly.**

When changing the backup batteries, remove the battery compartment cover on the back of the unit. The backup battery compartment is inside. Open the backup battery cover. Replace the 1 "3V" CR2032 lithium battery with a fresh one and replace the cover.

## Optional Custom Time Setting:

If you wish to set the clock slightly ahead or slightly behind, or if the Intelli-Time® internal memory battery is allowed to go dead, you may set the time and date by simply following the custom setup procedure below:

1. Press and hold the "SET" button for 5 seconds then release to enter the manual time set mode.
2. The hour will be flashing, adjust up or down using the "UP" or "DOWN" buttons. Note the AM or PM indicator on the display.
3. Press and release the "SET" button once to move on to the minute setting mode.
4. The minute will be flashing, adjust up or down using the "UP" or "DOWN" buttons.
5. Press and release the "SET" button once to move on to the month setting mode.
6. The month will be flashing, adjust up or down using the "UP" or "DOWN" buttons.
7. Press and release the "SET" button once to move on to the day setting mode.
8. The day will be flashing, adjust up or down using the "UP" or "DOWN" buttons.
9. Press and release the "SET" button once to move on to the year setting mode.
10. The year will be flashing, adjust up or down using the "UP" or "DOWN" buttons.
11. Press and release the "SET" button again to exit the manual set mode.

To view the MONTH/DAY/YEAR at any time press and release the "SET" button.

### 3 • TROUBLESHOOTING

During shipping a static charge may build up. It will **NOT** damage the product but may prevent the display from showing. To restore the display you need to reset the unit. To do this, simply look at the back of the clock. You will see a small hole that is the RESET button. Use the end of a paper clip to press the button. This will restore the display.

**PRODUCT REGISTRATION**

To receive product updates and information,  
Log on to  
**www.chaneyinstrument.com**

[TECHNOLOGY](#) [SUPPORT](#) [ABOUT US](#) [CONTACT US](#)

- Product Documentation
- Frequently Asked Questions (FAQ)
- Troubleshooting
- Product Registration**