


CLEANING AND MAINTAINING



Brush areas where dirt and dust get trapped.

Wipe body off with a soft rag or tact cloth.

Do not clean vehicle with chemicals or water.

FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Contains 1 x 3.7V LiPo battery pack. Requires 3 x 1.5 V AAA (LR03) alkaline batteries (not included). Batteries or battery packs must be recycled or disposed of properly. When this product has reached the end of its useful life it should not be disposed of with other household waste. The Waste Electrical and Electronic Equipment Regulations require it to be separately collected so that it can be treated using the best available recovery and recycling techniques. This will minimize the impact on the environment and human health from soil and water contamination by any hazardous substances, decrease the resources required to make new products and avoid using up landfill space. Please do your part by keeping this product out of the municipal waste stream! The "wheele bin" symbol means that it should be collected as "waste electrical and electronic equipment". You can return an old product to your retailer when you buy a similar new one. For other options, please contact your local council.

MANUFACTURER'S NOTE

"Modifications not authorized by the manufacturer may void users authority to operate the device."

ATTENTION PARENTS

This toy and all accessories need to be periodically examined for potential hazards and any potentially hazardous parts be repaired or replaced.

Please regularly check the wires, plugs, chassis and the other components whether damaged, please stop using if found damage, until repair intact.

MADE IN SHENZHEN, CHINA
TOY STATE INTERNATIONAL LIMITED
66 MODY ROAD, KOWLOON, HONG KONG



WARNING: Not suitable for children under 36 months due to small parts. Choking hazard.

IN THE INTEREST OF BETTER QUALITY AND VALUE, WE ARE CONSTANTLY IMPROVING AND UPDATING OUR PRODUCTS. CONSEQUENTLY, PICTURES IN THIS INSTRUCTION SHEET MAY SOMETIMES DIFFER FROM THE MODEL ENCLOSED.

The MINI logo and the MINI wordmark are trademarks of BMW AG and are used under license.

OWNER'S MANUAL
CAUTION-ELECTRICALLY OPERATED PRODUCT:
NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE, AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK, INPUT: 120V AC 60Hz 300mA, OUTPUT: 5.5V DC 500mA.

NIKKO

RADIO CONTROL JUMPIN' STUNT™



CONTROLLER
3 x AAA/LR03
Batteries Not Included

VEHICLE
RECHARGABLE LiPo
Included (Non-Removable)

8+
#37140

Important! Carefully read the Owners Manual before play!

NIKKO

www.nikko.eu

GETTING STARTED

What's included

Remove the R/C vehicle, controller and charger from the package. Insert batteries into the controller and use the charger to fully charge the internal battery in the vehicle to begin play (see "Battery Installation" section for further details).



Instructions to parents: "Transformers and power supplies for toys are not intended to be used as toys, and the use of these products by children shall be under the full supervision of parents."


CAUTION

Important Battery Information

- Dispose of batteries properly.
- Do not dispose of batteries in fire.
- Use only batteries of the type recommended.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Remove batteries from R/C controller if vehicle will not be used for a long period of time.
- Do not attempt to remove the LiPo battery from the vehicle.

BATTERY INFORMATION


CONTROLLER



1. To remove battery cover, loosen screw to open.
2. Insert 3 "AAA" batteries into the controller. Be sure the + and - are properly matched.

NOTE: For best performance, always use alkaline batteries only.


R/C VEHICLE




1. Play
2. OFF
3. Charge

1. Ensure vehicle is in 'charge' mode.
2. Securely plug the charger cable into the charging port.
3. Plug the wall adaptor into an electrical outlet.

The LED light on the rear of the vehicle indicates that it is charging. After a full charge, the light will go out. This should take about 120 minutes.




3. Power Supply: Rating: DC 5.5V, 500mA




WARNING! ONLY USE THE WALL CHARGER INCLUDED TO CHARGE JUMPIN' STUNT™.

Internal LiPo Battery Removal Instructions: At the end of this product's life span, the internal battery must be removed by an adult and recycled. Do not puncture, cut, tear, compress, bend or deform the battery in any way. Ensure the vehicle is turned OFF before removal. Use a screwdriver to remove 4 screws from the bottom of the vehicle. This separates the body from the chassis. Next, remove 2 more screws from the chassis to remove the plastic engine cover. The battery is located on the inside of this cover. Pull the battery out and disconnect the battery from the electronics by pulling on the plastic connector located at the end of the battery wires. Dispose of the battery in accordance with your local battery recycling or disposal laws.

OPERATING R/C VEHICLE



Turn switch located on back of R/C vehicle to the PLAY position (as shown).



360° Spins!

HOW TO JUMP



1. Press button to load!

2. Drive forward & press button to jump!

3. Jumps over 1ft!


JUMPIN' STUNT™ is capable of jumping in the air while flipping. Be careful! The jump up lever on the bottom of the vehicle should not be placed above, below or near any person, animal or breakable object while turned on.

1. Hit the 'Load' button on the controller. You'll hear the car prepare to jump by winding an internal spring. The LED light in the car and controller will start to flash.
2. After a few seconds the lights stop flashing. Now the vehicle is ready to jump!
3. Check that the jump zone is clear of people, animals and breakable objects. Hit the **forward or reverse** drive button at the **same time** as the **'Jump'** button on the controller for **JUMPIN' STUNT™**.


Note! The vehicle must be driving forward or reverse in order to jump.

After play, always turn vehicle off. Remove batteries from controller when not in use or when storing. Leakage may occur and cause damage if left for a long period of time.

TROUBLESHOOTING AND CARE FOR R/C VEHICLE



LIMITED RADIO CONTROL RANGE
While R/C vehicle may be visible at a distance, full operational control may be lost. Hold controller high in the air and direct vehicle back.




INTERFERENCE
Other radio signals may cause loss of control. Remove vehicle from an area of interference.

R/C VEHICLE DOES NOT JUMP	<ul style="list-style-type: none"> • Ensure the "Wind Spring" button has been pushed and the spring has finished winding. • The vehicle must be driving forward or backward when the jump button is pressed. • Ensure the vehicle is on a horizontal surface, right side up and the wheels are touching the ground. • The car has been left idle for over 1 minute and the spring has automatically unwound. • Check to ensure the vehicle is in the "PLAY" position and has a charged battery.
R/C VEHICLE DOES NOT MOVE	<ul style="list-style-type: none"> • Are the + and - contacts correctly matched in the controller? • Are the metal contact tabs touching, rusty or dirty in controller? • Are there batteries in the controller? • Is the power switch on the vehicle turned on? • Are the batteries weak or out of power?
R/C VEHICLE MOVES BY ITSELF	<ul style="list-style-type: none"> • There is radio interference in the area. • Another R/C vehicle with the same frequency is close by.
R/C VEHICLE RUNS SLOWLY	<ul style="list-style-type: none"> • There is radio interference in the area. • Another R/C vehicle with the same frequency is close by. • Are the batteries weak or out of power?
PERFORMANCE DROP, INCONSISTENT MOVEMENT OR FAILS TO RUN	<ul style="list-style-type: none"> • Check batteries. If necessary, replace the controller with new alkaline batteries or charge the vehicle. • Push the "reset" button on the back of the vehicle.

TREAT YOUR R/C VEHICLE WELL

Radio waves control the R/C vehicle. Care for your vehicle and it will provide hours of fun! Avoid water, heat, sand and high impact crashes!



No Collisions.

R/C vehicle may get stuck on carpet or grass.

Avoid running 2 vehicles with the same radio control frequencies.