



MIRAI  
2 0 1 6



QUICK REFERENCE GUIDE

# 2016 Mirai

This *Quick Reference Guide* is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The *Quick Reference Guide* is not intended as a substitute for the *Owner's Manual* located in your vehicle's glove box. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor Sales, U.S.A., Inc. wish you many years of satisfied driving in your new Mirai.

## A word about safe vehicle operations

This *Quick Reference Guide* is not a full description of Mirai operations. Every Mirai owner should review the *Owner's Manual* that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the *Owner's Manual*. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this *Quick Reference Guide* is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

# INDEX

## OVERVIEW

Fuel door release button and cap	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
<b>Keyless entry<sup>1,2</sup></b>	<b>6</b>
Light control-Instrument panel	8
<b>Smart Key System<sup>1,2</sup></b>	<b>6-7</b>

## HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

Automatic high beams	10
Blind spot monitor (BSM)	13
Hydrogen fuel cell system	9
Lane Departure Alert (LDA)	11
Pre-Collision System (PCS)	12
Water release (H2O) switch	10

## FEATURES/OPERATIONS

Automatic air conditioning system	20
Audio	21
Automatic Transmission	14-15
<b>Auto lock/unlock<sup>1,2</sup></b>	<b>14</b>
<b>Bluetooth® Device Pairing Section</b>	<b>30-39</b>
Clock	22
Dynamic radar cruise control	24-25
<b>Lights<sup>1</sup> &amp; turn signals</b>	<b>19</b>
Multi-Information display	23
Parking brake	16
Power outlet	21
Seat adjustments-Front	16
Seat heaters	19
Seats-Head restraints	17
Seats-Folding down rear seats	17
Starting your vehicle	14
Steering wheel switches	22
Windows-Power	17
Windshield wipers & washer	18
Tilt & telescopic steering wheel	18
USB/AUX port	21
Wireless charger	22

## SAFETY AND EMERGENCY FEATURES

Door locks	28
Doors-Child safety locks	28
Emergency tire puncture repair kit	26
Floor mat installation	28
<b>Garage door opener (Homelink®)<sup>3</sup></b>	<b>27</b>
Seat belts	27
Seat belts-Shoulder belt anchor	27
Star Safety System™	29
Tire pressure monitoring (warning) system	26

<sup>1</sup> Visit your Toyota dealer for information on customizing this feature.





<sup>2</sup> Programmable by customer. Refer to the Owner's Manual for instructions and more information.

<sup>3</sup> HomeLink® is a registered trademark of Gentex Corporation.


# OVERVIEW

## Instrument panel

### Steering wheel controls




- 1 Multimedia controls
- 2 Multi-Information display controls
- 3 Dynamic Radar Cruise Control (DRCC) distance switch
- 4 Lane Departure Alert (LDA) ON switch
- 5 Cruise control
- 6 Turn signal lever and headlight switch
- 7 Windshield wiper and washer switch
- 8 Power switch
- 9 Audio/Navigation system<sup>1</sup>
- 10 Emergency flasher switch
- 11 Main display
- 12 Multi-Information Display
- 13 Shift position indicator
- 14 Clock
- 15 "POWER MODE" switch



- 16 "ECO MODE" switch
- 17 "Traction OFF" or "ON" switch
- 18 "P" position switch
- 19 Luggage security system (disable trunk opener) switch
- 20 Transmission
- 21 Parking brake lever
- 22 Tilt and telescopic steering control switch
- 23 Hood lock release lever
- 24 Trunk opener
- 25 Fuel door opener
- 26 Instrument panel light control switches
- 27 Water release switch
- 28 Automatic high beam switch

<sup>1</sup> For details, refer to the "Navigation System Owner's Manual."

**Instrument cluster**




























- 1 Indicators and warning lights
- 2 Main display
- 3 Multi-Information Display
- 4 Clock
- 5 Transmission shift position indicator

**Indicator symbols**

For details, refer to “Indicators and warning lights,” Section 3-3, 2016 Owner’s Manual.

	Hydrogen leak warning
	Brake system warning <sup>1</sup>
	Charging system warning <sup>1</sup>
	High coolant temperature warning
	Brake system warning light (yellow indicator) <sup>1</sup>
	Supplemental Restraint System warning
	Anti-lock Brake System warning <sup>1</sup>
	Electric power steering system warning <sup>1</sup>
	Pre-Collision System warning light
	Slip indicator <sup>1</sup>
	Parking brake warning <sup>1</sup>
	Open door warning

<sup>1</sup> If indicator does not turn off within a few seconds of starting Hydrogen Fuel Cell System, there may be malfunction. Have vehicle inspected by your Toyota dealer.


	Low fuel level warning
	Driver seat belt reminder (alarm will sound if speed is over 12 mph)
	Master warning <sup>1</sup>
	Low tire pressure warning <sup>1</sup>
	Brake Override System/Drive-Start Control warning light
	Turn signal indicator
	Headlight low/high beam indicator
	Automatic high beam indicator
	READY indicator
	Radar cruise control indicator <sup>3</sup>
	Cruise control SET indicator
	Cruise control indicator <sup>2,3</sup>
	Lane Departure Alert indicator
	Intuitive parking assist indicator
	Vehicle Stability Control OFF indicator
	Blind Spot Monitor indicators
	Blind Spot Monitor outside rearview mirror indicators
	Security indicator
	Shift position indicator
	ECO mode indicator
	Power mode indicator
	Engine brake mode indicator
	Power restriction indicator
	H <sub>2</sub> O indicator
	Airbag ON/OFF

<sup>2</sup> If this light flashes, refer to “Cruise control,” Section 2-4, 2016 Owner’s Manual.


<sup>3</sup> If this light flashes, refer to “Dynamic radar cruise control,” Section 2-4, 2016 Owner’s Manual.

## Keyless entry


### Locking operation



### Unlocking operation



### Unlocking trunk




### Panic button



**NOTE:** If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

## Smart Key system

### Start function



### Power (without starting the Fuel Cell System)

Without depressing the brake pedal, pressing the “POWER” switch will change the operation mode in succession from:

- Accessory** | Accessories such as the radio will operate.
- Ignition On** | Power ON; Fuel Cell System is not engaged.
- OFF** | All systems OFF.



**Unlocking**

Driver door unlock\*

Grasp

Carry remote to unlock

**Locking**

All-door lock

Touch

Carry remote to lock

**Back door lock/unlock**

Push


Unlock Lock

Carry remote to lock/unlock


\* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping passenger door handle or pushing unlock button on rear hatch will unlock all doors. (If equipped)

**NOTE:** Doors may also be locked/unlocked using remote.

**Light control-Instrument panel**



**Fuel door release button and cap**



When the fuel door is open, the fuel cell system will not start. When the "READY" indicator is on, the fuel door will not open.

# HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

## Hydrogen Fuel Cell System

Fuel cell vehicles efficiently use electricity, which is generated by a chemical reaction between hydrogen and oxygen in a fuel cell stack. Excess electricity is stored in a traction battery that is used to power high voltage systems and assist on initial acceleration.


The fuel is H<sub>2</sub> (compressed hydrogen gas), so the exhaust, when running, is only water and water vapor. As they do not emit CO<sub>2</sub> (Carbon Dioxide) and NO<sub>x</sub> (Nitrogen Oxides) at the tailpipe, fuel cell vehicles are environmentally friendly vehicles.

**NOTE: Fuel consumption and energy information of the Hydrogen Fuel Cell System are shown on the Multi-Information Display.**

### Tips for improved fuel economy

- Ensure tire pressures are maintained at levels specified in the *Owner's Manual*.
- Drive vehicle smoothly. Avoid abrupt acceleration and deceleration.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the conditioning.

The hydrogen gas nozzle will differ depending on the facilities of the hydrogen station.



Note: This hydrogen gas nozzle features a latch to lock/unlock the handle lever.

- 1 Latch
- 2 Handle lever


Fill with fuel at hydrogen stations compliant with SAE J2601. If you have questions about hydrogen station compliance, Consult your Authorized Mirai Fuel Cell Toyota Dealer.

Observe the notices and cautions shown at the hydrogen station.

The filling time and amount may differ depending on the equipment of the hydrogen station. It may make the possible driving distance shorter.

# HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES


## Water release (H<sub>2</sub>O) switch



When the fuel cell system is stopped, water is automatically purged from the tailpipe. To minimize water accumulation in parking garages, etc., purge can be done manually before parking. While the “READY” indicator is on, press the H<sub>2</sub>O switch.

Refer to the *Owner’s Manual* for more details on this system before attempting to use it.

## Automatic high beams




The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beams on or off as necessary.

To turn the high beams on/off manually, pull the lever to the original position or press the switch.

Refer to the *Owner’s Manual* for more details on this system before attempting to use it.

## Lane Departure Alert (LDA)


Camera sensor



While driving on a road that has lane markers, this system recognizes the lane markers using a camera sensor and alerts the driver when the vehicle deviates from its lane.

Refer to the *Owner's Manual* for more details on this system before attempting to use it.

### Turning the LDA system ON



Press the LDA switch (in steering wheel) to turn the LDA system ON, the indicator will illuminate. Press again to turn OFF.

### Indication on the multi-information display



When the inside of both lane lines turn white:

- Indicates that both right and left lane markers are recognized.

When the inside of either lane line turns white:


- Indicates that the lane marker on the white-marked side is recognized.

When the inside of both lane lines are black:

- Indicates that no lane markers are recognized or the LDA system is temporarily canceled.

# HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

## Pre-Collision System (PCS)




When a high possibility of a frontal collision is detected by the radar sensor, a buzzer sounds and a message urging the driver to take evasive action appears on the multi-information display. If the driver then applies brakes, the system applies greater brake force in relation to how strongly the brake pedal is depressed. If the system determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed. The alert timing for the pre-collision system can be changed or turned on/off, as necessary, by pressing TRAC switch.

The system is enabled each time the power switch is turned to ON mode.

Refer to the *Owner's Manual* for more details on this system before attempting to use it.


### Changing the pre-collision warning timing



Each time the Pre-Collision System switch is pressed, the response to the distance changes as follows:


- ① Far
- ② Middle
- ③ Near

### Disabling the Pre-Collision System



Press the TRAC switch for 3 seconds or more.

## Blind Spot Monitor (BSM)



- 1 Outside rear view mirror indicators
- 2 Rear cross Traffic Alert buzzer


The Blind Spot Monitor is a system that has two functions:

- The Blind Spot Monitor function (assists the driver in making the decision when changing lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)

The system uses radar sensors to detect vehicles that are traveling in the area that is not reflected in the outside rearview mirror (the blind spot), and advises the driver of the vehicles' existence via the outside rearview mirror indicator.

Refer to the *Owner's Manual* for more details on this system before attempting to use it.

### Turn the BSM system ON



To turn ON (activate)/OFF (deactivate) from multi-information display, select



# FEATURES/OPERATIONS

## Starting your vehicle



- (1) Depress the brake pedal, and press the “POWER” switch briefly and firmly.
- (2) The “READY” light will blink. After a few seconds, when the light remains steady and a beep sounds, you may begin driving.


## Auto lock/unlock

Automatic door lock functions can be set, or turned OFF.

- Doors lock when shifting to any positions other than P.
- Doors lock when the vehicle speed is approximately 12 mph or higher.
- Doors unlock when shifting into P.
- Doors unlock when the driver’s door is opened.

Refer to the *Owner’s Manual* for more details.


## Automatic transmission



\* The engine brake is the equivalent of downshifting. Shift to “Br” when strong regenerative braking is desired (i.e. downhill driving, coasting to a stop, etc.).




## ECO Mode




ECO Mode helps achieve low fuel consumption during trips that involve frequent accelerating and braking.

## POWER Mode




Use when a higher level of response is desired, such as when driving in mountainous regions or overtaking.

## Br mode




Suitable for driving that requires strong regenerative braking, such as down-hill driving, etc. To select Br mode, shift the shift lever down.

## Parking brake




## P position switch



The shift position can be changed to P through the use of the P position switch.


## Seat adjustments-Front

### Power seat (driver side only)\*




- ① Seatback angle adjustment
- ② Lumbar support adjustment
- ③ Vertical height adjustment
- ④ Seat cushion (front) angle adjustment
- ⑤ Seat position (forward/backward)


## Seats-Head restraints



## Seats-Folding down rear seats



## Windows-Power




**Automatic operation** Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

**Window lock switch** Deactivates all passenger windows. Driver's window remains operable.

## Windshield wipers & washer

### Operating wiper lever

\* When AUTO is selected, wipers will operate automatically when sensor detects falling rain.



**MIST** Temporary operation


**OFF**

**AUTO** Rain-sensing operation


**LO** Low speed operation

**HI** High speed operation

Increase




Decrease



Pull to wash and wipe

Select AUTO to increase or decrease sensor sensitivity.

## Tilt & telescopic steering wheel



Push lever to move steering wheel:

- up, down to adjust angle,
- left, right to adjust length (toward driver and away from driver.)

**NOTE: Do not attempt to adjust while the vehicle is in motion.**

## Lights & turn signals

Headlights  
 Parking lights  
**AUTO** Auto or OFF  
 DRL OFF

(1) In **AUTO** or position, push lever away from you

(2) Push to activate automatic highbeam

**Automatic light cutoff system** Automatically turns lights off after a delay of 30 seconds, or when lock switch on remote is pushed after all doors are locked.

## Turn signals

Right turn  
 Lane change  
 Lane change  
 Left turn

## Seat heaters

**Driver seat**

Hi  
 Lo  
 R  
 Touch

Touch switch to change temperature intensity.


High Low Off

**Rear passenger seat**

Push  
 Hi  
 Lo  
 Push


Push button to change temperature intensity. Depress again and light indicates heater is off.

**Automatic air conditioning system**




- Outside air (indicator off)/Recirculated mode
- Windshield defogger
- AUTO** Automatic air
- Fan speed (Slower)
- Fan speed (Faster)
- Airflow mode
- Rear defogger
- System OFF
- Eco heat/cool mode
- A/C** Air conditioning ON/OFF
- SYNC** Synchronize temperature
- Driver seat heater
- Heated steering wheel\*
- Windshield wiper de-icer
- Passenger seat heater

**Airflow mode**



Touch and slide up/down to adjust




When adjusting the temperature setting a sound buzzes and automatically sets temperature, fan outlet and speed.

\*Turns off automatically after 30 minutes


## Audio

Entune™ Premium JBL Audio with Integrated Navigation and App Suite




Refer to the *Navigation System Owner's Manual* and *2016 Entune Audio Quick Reference Guide* for more details.

## USB / AUX port




By inserting a USB or an auxiliary cable plug into the USB/AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in USB/AUX mode.

## Power outlet




Designed for car accessories. Power switch must be set at "ACCESSORY" or "ON" in order to use power outlets.

## Wireless charger




Designed for car accessories. Power switch must be set at “ACCESSORY” or “ON” in order to use power outlets.

## Steering wheel switches



## Clock




Using steering wheel switches, select “Home” from multi-information screen, then select “” to set clock:

- (1) Select “General”
- (2) Select “System Time”
- (3) Select “Enter Time Zone” to autofill accurate time



## Multi-Information Display



- 1 Select category and items
- 2 Select/Set
- 3 Return to the previous screen

### **i** Drive information

- Energy monitor
- Fuel cell system indicator and ECO meter
- Fuel consumption history display
- Drive monitor
- ECO diary
- Suspension of the settings display

### **N** Navigation system-linked display

Select to display the following navigation system-linked information.

- Route guidance
- Compass display (north-up display/heading-up display)

### **M** Audio system-linked display

Select to enable selection of an audio source or track on the display using the meter control switches.

### **AS** Driving assist systems display

Displays when each driving assistance system is used.

- Dynamic radar cruise control
- LDA (Lane Departure Alert)
- Intuitive parking assist
- PCS (Pre-Collision System)


### **W** Warning message display

Select to display warning messages and measures to be taken if a malfunction is detected.


## Dynamic radar cruise control

Refer to the *Owner's Manual* for more details and complete safety precautions before attempting to use "Dynamic Radar Cruise Control."

### Distance control mode




- 1 Vehicle-to-vehicle distance button
- 2 Indicators
- 3 Set speed
- 4 Display
- 5 Dynamic radar control switch




In **distance control mode**, vehicle will cruise at a set speed, decelerate to maintain selected distance from a slower vehicle traveling in front, and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push the ON-OFF button to activate/deactivate the system.
- (2) To set, pull the lever down.
- (3) To increase and set speed, push the lever up.  
To decrease, push lever down. Move the lever slightly to adjust in 1 mph increments. Move all way up/down to adjust in 5 mph increments.
- (4) To resume set speed, push up and hold.  
To cancel pull the lever toward you, or depress the brake pedal.




Push the vehicle-to-vehicle distance button to change distance.

## Change to constant speed mode



### To select constant speed mode

- (1) Push the ON-OFF button.
- (2) Push the lever away from you and hold until the “” indicator appears.

To set, cancel and resume a speed refer to Distance control mode.


# SAFETY AND EMERGENCY FEATURES

## Emergency tire puncture repair kit

Your vehicle is not equipped with a spare tire, but instead is equipped with an emergency tire puncture repair kit (bottle of sealant and compressor.) After temporarily repairing the tire with the repair kit, have the tire repaired or replaced by your Toyota dealer.


Refer to the *Owner's Manual* for more details.

### Location



- ① Wheel nut wrench
- ② Towing eyelet
- ③ Emergency tire puncture repair kit
- ④ Jack handle
- ⑤ Jack

## Tire Pressure Monitoring (warning) System


If the Tire Pressure Warning indicator “” illuminates without blinking, adjust tire pressures to factory-specified levels.\* The light will turn off after a few minutes. The warning light is designed to turn on when tire pressure is critically low, but it may also come on due to temperature changes or changes in tire pressure from natural air leakage.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.

Refer to the *Owner's Manual* for more details.

\* Refer to load label on door jamb or the *Owner's Manual* for tire inflation specifications.


## Seat belts



NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.


To find more information about seat belts, and how to install a child restraint system, refer to the *Owner's Manual*.

## Seat belts-Shoulder belt anchor



## Garage door opener (HomeLink®)\*

- ❶ Homelink® indicator light
- ❷ Homelink® icon - illuminates while operating
- ❸ Garage door operation indicators
- ❹ Buttons




Garage door openers manufactured under license from HomeLink®\* can be programmed to operate garage doors, gates, entry doors door locks, home lighting systems, security systems and other devices.

Refer to “Garage door opener,” Section 6-4 in the *Owner's Manual* for more details.


For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com>.

\* HomeLink® is a registered trademark of Gentex Corporation.

### Door locks



### Doors-Child safety locks




Moving the lever to lock position will allow the door to be opened only from the outside.

### Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

**To keep your floor mat properly positioned, follow these steps:**

- Only use floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



## Star Safety System™

All new Toyota vehicles come standard with the Star Safety System™, which combines Vehicle Stability Control (VSC), Traction Control (TRAC), Anti-lock Braking System (ABS), Electronic Brake-force Distribution (EBD), Brake Assist (BA) and Smart Stop Technology (SST).

### Enhanced Vehicle Stability Control (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

### Traction Control (TRAC)

VSC helps prevent loss of traction during cornering by reducing Motor power output, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).

Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits Motor power output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

### Anti-Lock Brake System (ABS)

ABS helps prevent brakes from locking up by “pulsing” brake pressure to each wheel. This limits brake lockup and helps provide directional control for the current road conditions.

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by “pulsing” each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

### Electronic Brake Force Distribution (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. Abrupt stops can cause a vehicle to tilt forward, reducing the braking power of the rear wheels. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

### Brake Assist (BA)

Brake Assist is designed to detect sudden or “panic” braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

### Smart Stop Technology (SST)

Smart Stop Technology automatically reduces driving torque when the accelerator and brake pedals are pressed simultaneously under certain conditions.

# **BLUETOOTH® DEVICE PAIRING SECTION**



To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.<sup>1</sup>


## Bluetooth® Pairing for Android® phone and Entune™ touch screen system

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.<sup>2</sup>

### Initiate Bluetooth® on your Android®



**STEP 1**  
From your APPS SCREEN, select SETTINGS



**STEP 2**  
Select CONNECTIONS and select BLUETOOTH



**STEP 3**  
Ensure BLUETOOTH is ON



**STEP 4**  
Select YOUR PHONE DEVICE to make it discoverable.

*Phone will seek out Bluetooth devices while remaining discoverable.*



**STEP 5**  
While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

<sup>1</sup> To determine which head unit is installed in your vehicle, refer to Audio section in this guide.

<sup>2</sup> Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

# BLUETOOTH® DEVICE PAIRING

## Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



### STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.




### STEP 7

Select **BLUETOOTH**



### STEP 8

Select **ADD**, to add your phone device



### STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

*You may need to enter the provided Bluetooth PIN on your phone.*



### STEP 10

Your smartphone is now paired with Entune.



### STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

## Initiate Bluetooth® on your Entune™ Multimedia Head Unit



### STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts

*It is recommended to check the "Don't ask again" box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota*



### STEP 13

A confirmation will appear once your phone has been paired and connected.

### Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:  
[www.toyota.com/connect](http://www.toyota.com/connect)

Your Toyota Owner's Manual  
*Located in the vehicle glovebox*

Toyota Customer  
Experience Center  
(800) 331-4331

### Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See [Toyota.com/entune](http://Toyota.com/entune) for details.


## Bluetooth® Pairing for iPhone® and Entune™ touch screen system

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all iPhone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

### Initiate Bluetooth® on your iPhone®



**STEP 1**  
From the **HOME SCREEN**, select **SETTINGS**



**STEP 2**  
Select **BLUETOOTH**



**STEP 3**  
Ensure **BLUETOOTH** is **ON**



**STEP 4**  
Your iPhone will seek out Bluetooth devices while remaining discoverable



**STEP 5**  
While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

## Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




### STEP 6

Select **SETUP** BUTTON on the Home Screen.



### STEP 7

Select **BLUETOOTH**



### STEP 8

Select **ADD**, to add your phone device



### STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

*You may need to enter the provided Bluetooth PIN on your phone.*



### STEP 10


Your smartphone is now paired with Entune.



### STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

# BLUETOOTH® DEVICE PAIRING



## STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts

*Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.*



## STEP 13

A confirmation will appear once your phone has been paired and connected.

### Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:  
[www.toyota.com/connect](http://www.toyota.com/connect)

Your Toyota Owner's Manual  
*Located in the vehicle glovebox*

Toyota Customer  
Experience Center  
(800) 331-4331

### Disclosures

- This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.
1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
  2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
  3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See [Toyota.com/entune](http://Toyota.com/entune) for details.

## Bluetooth® Pairing for Windows Phone® and Entune™ touch screen system

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Windows Phone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

### Initiate Bluetooth® on your Windows Phone®



#### STEP 1

From your APP LIST, select **SETTINGS**



#### STEP 2

Select **BLUETOOTH**



#### STEP 3

Ensure **BLUETOOTH** is ON



#### STEP 4

Phone will seek out Bluetooth devices while remaining discoverable



#### STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

# BLUETOOTH® DEVICE PAIRING

## Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



### STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



### STEP 7

Select **BLUETOOTH**



### STEP 8

Select **ADD**, to add your phone device



### STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

*You may need to enter the provided Bluetooth PIN on your phone.*



### STEP 10

Your smartphone is now paired with Entune.



### STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.



## Initiate Bluetooth® on your Entune™ Multimedia Head Unit



### STEP 12

Using your smartphone, you may need to allow Entune access to your contacts



### STEP 13

A confirmation will appear that your phone has been paired and connected.

### Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:  
[www.toyota.com/connect](http://www.toyota.com/connect)

Your Toyota Owner's Manual  
*Located in the vehicle glovebox*

Toyota Customer  
Experience Center  
(800) 331-4331

### Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See [Toyota.com/entune](http://Toyota.com/entune) for details.

## NOTES





CUSTOMER EXPERIENCE CENTER  
1-800-331-4331

