



Product Summary

The Flip Top KeyChain Touchpad enables the user to turn the system on and off after exiting or before entering the home or to turn on the siren and to call the central monitoring station if there is an emergency. If lamp modules have been installed, the KeyChain Touchpad can be used to turn all lights using the lamp modules on or off.

Installation Overview

General Information

The KeyChain Touchpad is a lithium battery-powered, wireless touchpad designed to fit on a keychain, in a pocket or purse. It provides users a convenient option for the following system operations:

- Arm the system (doors, windows, and motion sensors)
- Arm the system with no entry delay (if programmed)
- Disarm the system
- Trigger Panic alarms
- Turn system controlled lights on or off
- Open the garage door or turn outside lights on (if programmed)

Installation Guidelines

Use the following guidelines when adding Key-chain Touchpads to the system:

- KeyChain Touchpads are learned into the Con-

trol Panel as sensors or touchpads.

- KeyChain Touchpads when programmed as sensors are programmed as a non-supervised sensor.
- Each learned KeyChain Touchpad uses one of the available sensor numbers.
- KeyChain Touchpads can be programmed with no entry delay.

Programming

Follow these instructions to program the touchpad:

1. Open the control panel cover.
 2. Enter Utility Access Code 1 or 2 using the red-numbered buttons.
 3. Press Add from the Start Menu.
 4. Press the Sensor/Remote button from the Main menu and you will hear keychain remote.
- Note:** When adding sensors, if you wish to use a more descriptive location you may press the option button to use the compass directions (north, north east, east, south east, south, south west, west, north west).
5. Press DONE.
 6. Enter the sensor type number (01, 03, 06, or 07) with the red numbered keys.

Note: If you wish to use a sensor number other than the next available, enter a 2 digit sensor number with the red numbered keys immediately after entering the sensor type.

7. Press the lock and unlock buttons simultaneously until the transmitter LED is lit.

Testing Flip Top KeyChain Touchpads Used with the SIMON® Control Panel

Perform Sensor Test

The following steps describe the guidelines for testing sensors.

1. Open the Control Panel cover.
2. Enter the Utility Access Code 1 or 2 using the red-numbered buttons.
3. Press the Test button once.
4. Press DONE.
5. Trip the sensor by pressing the Lock and Unlock buttons simultaneously until the LED is lit.

- Note the number of siren beeps indicating how many RF packets the Control Panel received from the sensor. You should hear 7-8 beeps.

Specifications

Model No.: 600-1003-95R

RF Frequency: 319.5 MHz

Compatibility: Simon and Concord™ control panels

Battery Type: 3 V lithium battery

Estimated Battery Life: 5 to 8 years

Dimensions (mm): 58 x 37 x 12 (L x W x H)

FCC NOTICE

This device complies with FCC Rules Part 15. operation is subject to the following two conditions:

1) This may not cause harmful interference.

2) This device must accept any interference that may be received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Interactive Technologies, Inc. can void the user's authority to operate the equipment.

FCC ID: B4Z-869-FOB



GE Security

1275 Red Fox Road, Arden Hills, MN 55112

USA & Canada: 800-777-5484 Technical Support: 800-777-2624

©2004 GE Security, Inc. Simon is a registered trademark of GE Security. Concord is a Trademark of GE Security. All other trademarks are properties of the owners All rights reserved.