

L10 Remote control use instruction

1. Introduction : Remote control build in 250mAh polymer rechargeable batteries, When it is in fully charged, more than 3 months for standby, more than 70 hours for continuous working. The control distance is more than 10 meters.



2. Functional specifications:

- 1) Press the ① key to turn it off , Press any ②③④⑤⑥⑦ key to turn it on.
- 2) ① is the key for closing, the remote control will enter standby mode once pressed this key.
- 3) ②③④⑤⑥⑦ are the patterns function keys , The corresponding pattern on the backpack will be displayed once pressed these keys.
- 4) ⑧ is the input port for charging, Connect the Micro-USB cable to charge it when the remoted control become low battery.
- 5) When in charging, ⑦ key will show the red light, and the red light will be closed after finish the charge.

3. Technical parameters:

Model Name	Wireless Remote control
Model No.	L10
Input	5.0V/100mA
Volume	65*39*16mm
Battery Capacity	3.7V/250mAh/0.925WH

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.