



Read and Save These Instructions

All Hoods Must Be Installed By A Qualified Installer

INSTALLATION INSTRUCTIONS

ZTH WALL MOUNT HOOD

Read All Instructions Thoroughly Before Beginning Installation

WARNING - TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING:

- A. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction. Switch power off at service panel and lock the service disconnecting means to prevent power from being switched on accidentally during installation.**

- B. When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.**

- C. Ducted fans must always be vented to the outdoors.**

- D. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent back drafting. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and local code authorities.**


WARNING - TO REDUCE THE RISK OF FIRE, USE ONLY METAL DUCTWORK

Ducting Do's and Don'ts


NEVER restrict the duct size. The single blower unit (B100) requires 6" round duct or equivalent (28 square inches), and the dual blower unit (B200) requires 8" round duct or equivalent (50 square inches). When combining ducts together, the square inch area must reflect the total square inch area of the ducts being combined. Using Vent-A-Hood transitions (back page) will ensure proper efficiency.

Blower	Duct Size	Sq. Inch Area	Vent-A-Hood Transition
Dual (B200)	8" round or equivalent	50"	N/A
Single and Dual (B100 & B200)	10" round or equivalent	79"	VP562 (Optional)


Do not use flexible or corrugated duct. This type of duct will restrict air flow and reduce performance. Only use smooth galvanized metal duct. Observe local codes regarding special duct requirements and placement of duct against combustibles. Make the duct run as short and as straight as possible with as few turns as possible. Avoid sharp angled turns. Instead, use smooth gradual turns such as adjustable elbows or 45 degree angled turns. For duct runs over 20 feet, increase duct diameter by one inch for every ten feet of duct. A 90 degree elbow is equivalent to 5 feet of duct. Using Vent-A-Hood roof jacks or wall louvers (back page) will ensure proper efficiency. Air must not be restricted at the end of duct run. Do not use screen wire or spring loaded doors on wall louvers or roof jacks. Do not terminate vent into an attic or chimney. Where possible, seal joints with duct tape. The hood must be ducted unrestricted to the outdoors.




Smooth Duct




Smooth Gradual Turn




Proper Combining of Two Ducts



Flexible Duct



Sharp Angled Turns




Improper Combining of Two Ducts

Vent-A-Hood®

Installation Details

- 1) Read all instructions thoroughly before beginning installation.
- 2) When installing the ZTH, it is recommended that the bottom edge of the hood be located 30" from the countertop. Exceeding recommended mounting height may compromise performance.



- 3) IF THE HOOD IS TO BE "BACK VENTED", PROCEED DIRECTLY TO STEP 4.


Pre-install the duct from the outside of the home to the ceiling over the exhaust outlet of the hood. The end of the duct should extend 1" below the ceiling. Consult the connection diagrams (below) for further details on exhaust outlet placement.

Use duct tape to seal all joints. A complete listing of available Vent-A-Hood ducting materials is provided on the back page of this instruction sheet.

Transition heights are as follows:


- Dual Blower (B200) : 8" round duct will connect directly to the exhaust outlet of the hood.
- Single and Dual Blower (B100 & B200): 6" round duct will connect directly to the exhaust outlet of the hood; 8" round will connect directly to the exhaust outlet of the hood. Optional 10" round combination transition (VP562) is 17 1/2" tall.

Connection Diagram 36" - 48" Widths



600 CFM B200 Dual Blower
(Top View)


Connection Diagram 54" Width




900 CFM B200 Dual Blower B100 Single Blower
(Top View)

Installation Details Continued

- 4) Remove the hood from the packaging and place the back of the hood on the floor or countertop in front of the wall where it will hang.
- 5) Remove the blower shield(s) (A) by loosening the two brass screws on the bottom of the shield. Gently close the back draft dampers from the top side of the hood. To remove the blower housing(s), un-snap the suitcase latches (B) (one on each side of the housing). The housing(s) should be pulled forward and gently “tipped” to clear the blower wheels and then out of the hood.



- 6) Remove the three screws retaining the blower motors. Unplug and remove the motors, taking care not to damage the blower wheels. It is not necessary to remove the blower wheel from the motor.



Warning: Make sure power is off and locked at the service disconnecting means on the service panel during installation.

- 7) Install an appropriate 1/2" UL listed electrical wire clamp through each motor box electrical opening on top of the hood. Pre-install electrical wiring from the service panel to the hood location for each motor box. Consult the connection diagrams (on previous page) for further details on electrical placement. Extend wire to the

Model	Type	Volts	Amps	HZ	RPM	CFM SP@0.0"	Equivalent CFM	CFM SP@0.1"	CFM SP@0.2"	CFM SP@0.3"	Minimum Round Duct Size	Square Inches
B100 Single	Shaded Pole	115	1.7•	60	1550	300	450	286	270	240	6" (or equivalent)	28
B200 Dual	(2) Shaded Pole	115	3.4•	60	1550	600	900	572	540	480	8" (or equivalent)	50


●Note: Add .5 amp for each halogen bulb. Equivalent CFM refers to the fact that the Magic Lung blower uses centrifugal filtration units, whereas others use conventional filters. Apply this guideline when comparing blower units made by other manufacturers.

- 8) Remove the duct cover from its packaging. Remove and save the screws from the bottom of the duct cover. Place the duct cover into the top of the hood. Attach the duct cover to the hood with the screws previously removed. Lift the hood and hold in place on the wall in the location where it will be installed. Lightly mark the wall with a short horizontal mark along the bottom edge of the hood.
- 9) Measure on the wall 9" above the mark made in Step 8 and lightly mark the wall with a level horizontal line. Measure where the center (left to right) of the hood will be and mark the horizontal line on the wall with a short vertical centerline.
- 10) Remove the screws inside the top of the back of the hood that retain the wood strip recessed in the mounting channel. Note: Some retaining screws may be located behind the blower(s). Remove the wood mounting strip from the back of the hood and place the top edge of the strip on the upper horizontal line on the wall. Referencing the vertical centerline in Step 9, place the mounting strip so it is centered on the wall in the space where the hood will be (left to right). Using proper hardware, attach the mounting strip to at least two wall studs. Drill pilot holes in the strip to prevent splitting.

Installation Details Continued


- 11) **FOR BACK VENTING APPLICATIONS ONLY. IF NOT BACK VENTING, PROCEED DIRECTLY TO STEP 12.**
Note: Wall studs may interfere with back venting installations. Additional framing may be required. It is necessary to cut a duct access hole in the wall prior to installing the hood. To accomplish this, first remove and set aside the duct cover that was previously installed in Step 8. Hold the hood on the mounting strip by aligning the channel at the top of the back of the hood over the wood mounting strip on the wall. Place the appropriate elbow(s) on top of the hood in line with the hood exhaust collar(s). On the wall, trace around the elbow(s). Remove the hood and elbow(s) from the wall. Cut around the outside of the traced line(s), avoiding wall studs. Install the duct from the outside of the home to the opening in the wall. Use duct tape to seal joints. Place the duct cover back into the top of the hood and reattach to the hood.
- 12) Hang the hood on the mounting strip by aligning the channel at the top of the back of the hood over the wood mounting strip on the wall. While holding the hood in place, mark locations on the mounting strip through the two mounting holes in the channel at the top of the hood. Some mounting holes may be located behind the blower(s). Remove hood and drill 3/32" pilot holes at the center of marks in the wood strip to prevent splitting.
- 13) **FOR BACK VENTING APPLICATIONS ONLY. IF NOT BACK VENTING, PROCEED DIRECTLY TO STEP 14.**
Place the appropriate back vent elbow(s) on the top of the hood. Elbow(s) should be placed inside the collar(s) of the exhaust outlet(s). Use duct tape to seal joint(s).
Insert the electrical wire from the service panel through the electrical wire clamp on each motor box. Tighten the wire clamp(s).
Lift the hood into position while taking care to align the duct connection between the hood and the wall. Secure the hood to the mounting strip by installing the screws (removed from the strip in Step 10) into the pilot holes drilled in Step 12. Secure the slack in the electrical wire.
SKIP STEPS 14 AND 15. PROCEED DIRECTLY TO STEP 16.
- 14) If applicable, install transition inside the exhaust collars and seal with duct tape. Insert the electrical wire from the service panel through the electrical wire clamp(s) on each motor box. Tighten the wire clamp(s). Cut a piece of duct the length of the duct cover allowing room for the transition on the top of the hood (if applicable). If a transition is used, cut the duct to reach the transition outlet plus 1". This will allow the transition to engage 1" inside of the duct. See Page 3 for transition heights. One end of the duct must be crimped to fit inside the duct in the ceiling. Insert non-crimped end over the transition or into the exhaust collar on top of the hood and seal with duct tape.
- 15) Lift the hood into position while aligning the duct connection between the hood and the duct in the ceiling. Secure the hood to the mounting strip by installing the screws (removed from the strip in Step 10) into the pilot holes drilled in Step 12. Secure the slack in the electrical wire.
- 16) Using UL listed wire nuts, attach the "neutral" wire(s) to the white lead(s), the "hot" wire(s) to the black lead(s), and the ground wire(s) to the green lead(s) inside the motor box(es).
- Warning: Do not operate hood without proper ground connection.**
- 17) Plug the motors into the hood and reinstall the blower motors using the three retaining screws that were removed in Step 6.
- 18) Replace the blower housing(s) and the blower shield(s). Make sure the dampers open and close smoothly.
- 19) Refer to the Owner Maintenance Guide Operating Instructions for proper hood operation. Test all blower and light functions to ensure they are operating properly.

WALL LOUVER




MODEL	DIM
VP526	6" RD
VP527	7" RD
VP528	8" RD
VP538	6"x8 1/2"

WALL LOUVER




MODEL	DIM
VP554	10" RD

WALL LOUVER




MODEL	DIM
VP555	12" RD

WALL LOUVER




MODEL	DIM
VP560	3 1/4"x10"

LOW PROFILE ROOF JACK (MAXIMUM 4/12 PITCH)




MODEL	DIM
VP539	6"
VP540	7"
VP541	8"

LOW PROFILE ROOF JACK (MAXIMUM 4/12 PITCH)




MODEL	DIM
VP552	10"
VP553	12"

ADJUSTABLE ELBOW




MODEL	DIM
VP513	6"
VP514	7"
VP515	8"

BACK/SIDE VENT ELBOW




MODEL	DIM
VP561	8"-6" x 8 1/2"

BACK VENT ELBOW




MODEL	DIM
VP559	3 1/4"X10"

MULTI-BLOWER TRANSITION




MODEL	DIM
VP562	10"
VP563	12"

"Y" TRANSITION




MODEL	DIM
VP517	8" x 8" - 12"
VP518	6" x 8" - 12"
VP551	6" x 8" - 10"

10 TO 7 TRANSITION




MODEL	DIM
VP521	3 1/4" x 10" - 7"

OFFSET KIT-ROUND




MODEL	DIM
VP529	6" TO 7"

OFFSET KIT-RECTANGLE




MODEL	DIM
VP550	6"-3 1/4"X10"

STANDARD ISLAND TRANSITION




MODEL	DIM
VP565	

CLUSTER BLOWER TRANSITION




MODEL	DIM
VP564	

OFFSET L & R TRANSITION FOR ISLAND BLOWERS




MODEL	DIM
VP542	TOP LEFT ISLAND
VP543	TOP RIGHT ISLAND

SIDE VENT TRANSITION L & R FOR ISLAND HOODS




MODEL	DIM
VP544	LEFT SIDE
VP545	RIGHT SIDE

ROUND COLLAR




MODEL	DIM
VP533	6"
VP535	8"

COLLAR, SQUARE




MODEL	DIM
VP537	6 x 8 1/2"

ROUND DUCT




MODEL	DIM
VP500	6"
VP501	7"
VP502	8"

3 1/4" RECTANGLE DUCT



MODEL	DIM
VP504	3 1/4" x 10"
VP505	3 1/4" x 12"
VP506	3 1/4" x 16"

6" RECTANGLE DUCT



MODEL	DIM
VP507	6" x 8 1/2"