



User Manual

VAB-820-W

11n+BT WiFi board

Introduction:

VAB-820-W is a WLAN 11n and Bluetooth board, which fully supports the features and functional compliance of IEEE 802.11b/g/n standards, Bluetooth v2.1, v3.0 and v4.0 standards. It supports up to 150Mbps WLAN network

It is designed to provide excellent performance with low power consumption and enhance the advantages of robust system and cost-effective.

Specification

WiFi / Bluetooth

- CM-8723BY 11n+BT WiFi module (USB interface)

Onboard I/O

- 1 x USB pin header for WiFi/BT module

Operation temperature

- 0 ~ 60°C

Humidity

- 0% ~ 95% (non-condensing)

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device is intended only for OEM integrators under the following conditions:

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed

IMPORTANT NOTE: In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

End Product Labeling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labeled in a visible area with the following: "Contains FCC ID: NCI-VAB820-WA1". The grantee's FCC ID can be used only when all FCC compliance requirements are met.

Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.


This end user manual shall include all required regulatory information/warning as show in this manual.

Host integration instructions

1 Pin Description

Onboard USB connector

The VAB-820-W module has an onboard USB connector labeled as "USB4". The pinout of the connector is shown below.




Pin	Signal
1	NC
2	NC
3	GND
4	USB HS_DP
5	USB HS_DM
6	VCC

2 Installations

Installing EMIO-5531-00A1 WLAN Kit


Step 1

Install the VAB-820-W module and secure it with two screws.



Step 2

Connect the USB transmittal cable to the onboard USB connector (USB4). Then connect the other end of the cable to the "JUSB" pin header/connector on the mainboard.



Step 3

Insert the port of antenna cable into the antenna hole from the inside of the panel. Insert the washer, fasten it with the nut and install the dipole antenna.



Step 4

Gently connect the other end of antenna cable to the mini RF connector on VAB-820-W module.

