

Wireless PannerOperating Instructions



Wireless Panner Specs

1. Distance: Up to 10 meters
2. Charging power: 5V/500mA
3. Power consumption: 0.2W
4. Battery: 3.7V/2200mA
5. Remote battery

Diagram of features:

A: Power button [on panner]

B: LED light [on panner]

C: Left control button: pans to the left [on remote]

D: Right control button: pans to the right [on remote]

E: Charging port [on panner]



VT-9512TX

FCC ID:2ABFHVT-9512TX

Operation:

Deploy the camera:

Lower your camera to the desired depth, then position the cable in the u-shaped channel on the bottom of the panner. Use the retainer clip to anchor the camera cable in place. Open the legs of the panner and position it above the hole in the ice.

Turn on and operate the panner:

Press and hold the power button (A) about 3-4 seconds until the light is on.

Press the C or D button to pan left or right.

Turn off the panner:

Press and hold the power button (A) for about 3-4 seconds until the light is off.

TROUBLE SHOOTING:

1. Pairing:

Turn on the wireless panner, and quickly press the power button (A) 3 times in 3 seconds.

Next, press and hold either button (C or D) on the remote until the motor is rotating to left or right. This means that the pairing is OK, and the wireless panner can be controlled by this remote.

2. Using a new remote:

If the remote is lost, you first must order a new remote. Once you have a new remote:

Step 1: Turn on the wireless panner, and quickly press the power button (A) 6 times in 6 seconds, the LED light will turn off automatically in 10 seconds.

Step 2: Turn the wireless panner back on and quickly press the power button (A) 3 times in 3 seconds;

Step 3: Press and hold either button (C or D) of the new remote until the motor is rotating to left or right. This means that the pairing is OK, and the wireless panner can be controlled by this remote.

3. Charging instruction:

1. When the panner is charging, the LED light will be pulsing slowly.
2. When it has fully charged, the LED light will stop pulsing and always be on.
3. If the charger is disconnected during the charging process, the panner will be turned off automatically.
4. When the panner is working, a steady LED light means a fully charged

battery. If the light is flickering in a pattern, the number of flickers indicates the battery strength out of a possible 4 levels. [Example: the light flickering in a repeating pattern of 2 indicates battery strength is 2 out of 4.

5. The LED light flickering very quickly indicates the battery does not have sufficient power.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device meets RF Exposure requirements without any restriction.