

You must install and charge battery before using the telephone.

STOP!

See page 7 for easy instructions.

For customer service or product information, visit our web site at **www.telephones.att.com** or call **1-800-222-3111**.

Please also read ***Important Product Information*** Enclosed in product package.



CAUTION: To reduce the risk of fire or injury to persons or damage to the telephone, read and follow these instructions carefully:

- Use only replacement battery 2420 (SKU 00578) (Part number 80-5542-00-00).
- Do not dispose of the battery in a fire, it could explode. Check with local codes for special disposal instructions.
- Do not open or mutilate the battery. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
- Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause harm.
- Charge the battery provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
- Observe proper polarity orientation between the battery and battery charger.

Do not disassemble your telephone. There are no user-serviceable parts inside. Refer for servicing to qualified service personnel.

User Manual (Part 2)

2.4 GHz Cordless Telephone E2715B

with Caller ID & Call Waiting



Table of contents

Getting Started

Quick reference guide	2
Parts checklist	4
Before you begin	5
Telephone base installation.....	6
Battery installation & charging	7
Wall mounting	8
Belt clip & optional headset.....	9

Telephone Operation

Basic operation.....	10
Options while on calls	11
Intercom calls	12
Call Forward and Call Transfer	13
Handset settings.....	14

Phone book

About the phone book.....	16
New phone book entries.....	17
Phone book search.....	18
To dial, change or delete entries ...	19

Caller ID Logs

How Caller ID works	20
To review your call log.....	21

Appendix

Screen icons, indicator lights & tones...	22
In case of difficulty	23
Technical specifications	25
Index	26

Getting Started

Quick reference guide

Handset

▼ CID

Press to scroll down in menus. Press when phone is not in use to display Caller ID information (see page 21). While entering names, press to move the cursor to the left.

Select/Menu

Press to display menu, or to select highlighted item from menu.

▲ DIR

Press to scroll up in menus. Press when phone is not in use to display phone book entries (see page 16). While entering names, press to advance cursor.

Phone/Flash

Press to begin a call, then dial a number. During a call, press to receive an incoming call, if Call Waiting is activated (see page 11).

Off/Clear

During a call, press to hang up. While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display.

Redial/Pause

Press to view redial memory (see page 10). While entering numbers, press and hold to insert a dialing pause (see page 17).

Mute/Delete


Press to mute microphone (see page 11). While reviewing call log, press and hold to clear Caller ID log (see page 21).

Speaker

Press to activate handset speakerphone. Press again to resume normal handset use (earpiece).


Intercom

Press to transfer a call or initiate an intercom conversation.



Feature menu

> shows highlighted item



Menu

Feature Menu

- DirectorySee page 16
- Call LogSee page 20
- Ringer VolumeSee page 14
- Ringer ToneSee page 14
- Key ToneSee page 14
- Handset NameSee page 15
- LanguageSee page 15
- CLR Voice MailSee page 15
- Dial TypeSee page 15

Press ▲ or ▼ to scroll through menu items.

Press **SELECT** to select or modify a highlighted item.

Press **OFF** to cancel an operation, back up to the previous menu, or exit the menu display.

Getting Started

Quick reference guide


Telephone Base

Handset Locator

Press to locate handset if lost (see page 10).

New Voice Mail

Flashes when you have new voice mail (requires voice mail service from your local telephone company).



Charging

On when handset battery is charging.

In Use

On when handset is in use. Flashes when another phone is in use on the same line, or answering system is answering an incoming call.

Getting Started

Parts checklist

Remember to save your sales receipt and original packaging in case you ever need to ship your telephone for warranty service. Check to make sure the telephone package includes the following:




Telephone base




Telephone handsets




Charger



Power adapters



Belt clips




Batteries



Short telephone line cord



Long telephone line cord



Wall mount bracket

Getting Started

Before you begin

About Caller Identification

Caller ID with Call Waiting features in this telephone let you see who's calling before you answer the phone, even when you're on another call. These features require services provided by your local telephone company.

Contact your telephone service provider if:

- You have both Caller ID and Call Waiting, but as separate services (you may need combined service)
- You have only Caller ID service, or only Call Waiting service
- You don't subscribe to any Caller ID or Call Waiting services.

You can use this phone with regular Caller ID service, and you can use its other features without subscribing to either Caller ID or combined Caller ID with Call Waiting service. There may be fees for these services, and they may not be available in all areas.

Caller ID features will work only if both you and the caller are in areas offering Caller ID service, and if both telephone companies use compatible equipment.

See Caller ID Operation, beginning on page 20, for more details about how these features work.

Telephone operating range

This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and base can communicate over only a certain distance — which can vary with the locations of the base and handset, the weather, and the construction of your home or office.

If you receive a call while you are out of range, the handset might not ring — or if it does ring, the call might not connect when you press **PHONE**. Move closer to the base, then press **PHONE** to answer the call.


If you move out of range during a phone conversation, you might hear noise or interference. To improve reception, move closer to the base.

If you move out of range without pressing OFF, your phone will be left off the hook. To hang up properly, walk back toward the telephone base, periodically pressing **OFF** until the call is disconnected.

Getting Started

Telephone base installation

Install the telephone base as shown below. Choose a base location away from electronic equipment, such as personal computers, television sets or microwave ovens. Avoid excessive heat, cold, dust or moisture.




NOTE: Use only the power cord supplied with this product. If you need a replacement, call 1-800-222-3111. Be sure to use an electrical outlet not controlled by a wall switch.

Getting Started

Battery installation & charging

After battery installation, place the handsets in their base unit or charger and allow to charge for 15 hours before use. You can keep the batteries charged by returning the handsets to their base unit or charger after each use. When the battery is fully depleted, a recharge takes about 10 hours.




Press tab to open battery compartment.

Caution: Use only supplied rechargeable battery or AT&T replacement battery model 2420 (SKU 00578) (Part number 80-5542-00-00).

Then, insert battery and replace compartment cover.

Plug charger power cord into jack on underside of charger, then plug transformer into electrical outlet.



Place handset in base to charge for 15 hours before first use.




Getting Started

Wall mounting

The speakerphone base can be installed on any standard wall-phone outlet as shown below. Choose a location away from electronic equipment, such as personal computers, television sets or microwave ovens. Avoid excessive heat, cold, dust or moisture.

Connect cords as shown on page 6, then press and slide down firmly so base is held securely on outlet mounting pegs.







Getting Started

Belt clip & optional headset

Install belt clip as shown below if desired.

For hands-free telephone conversations, you can use any industry standard 2.5 mm headset (purchased separately). For best results use an AT&T 2.5 mm headset.





Telephone Operation

Basic operation

Making and answering calls

To answer an incoming call, press **PHONE** (or **SPEAKER**, or any dial pad key). To make a call, press **PHONE** or **SPEAKER**, then dial a number. Press **OFF** to hang up.

To preview numbers before dialing, enter numbers first, then press **PHONE** or **SPEAKER** to dial. Press **DELETE** or **CLEAR** at any time to make corrections as you are entering numbers.

The screen displays the elapsed time as you talk (in hours, minutes and seconds).

Hands-free speakerphone calls

To answer a call, press **SPEAKER**. To make a call, press **SPEAKER**, then dial a number. During a call you can press **SPEAKER** to toggle between hands-free speakerphone and normal handset use. Press **OFF** to hang up.

Last number redial

Press **REDIAL** to display the most recent called number (up to 32 digits). Use the **▲** **▼** buttons to view up to 5 other recently called numbers. The handset will beep twice at the beginning or end of the list.

Press **PHONE** to redial any displayed number. Press **DELETE** to delete the number from the redial memory.

Handset locator

If you misplace the handset, press **HANDSET LOCATOR** at the base. The handset will beep for 60 seconds to help you locate it. To stop the beeping, press **PHONE**, **SPEAKER**, or any dial pad button at the handset, or press **HANDSET LOCATOR** at the base.

Telephone Operation

Options while on calls



Volume control

Press the **VOLUME** buttons on the side of the handset to adjust listening volume. Each button press raises or lowers volume by one level.

When you change the volume level, the new setting becomes the default. The new volume level will be applied each time you use the handset, speakerphone or headset.


Call waiting

If you have Call Waiting service, you will hear a beep if someone calls while you are already on a call. Press **FLASH** to put your current call on hold and take the new call. You can press **FLASH** at any time to switch back and forth between calls.

3-way conference calls

During an outside call, you can use two system handsets for a three-way conversation.

While a call is in progress, others can press **PHONE** or **SPEAKER** to join the conference call. Others can press **OFF** or place the handset in the base or charger to drop out of the conference call, but the call will not be terminated until all sets hang up.



Mute

Press **MUTE** to silence the microphone. You will be able to hear, but your caller will not be able to hear you until you press **MUTE** again and resume speaking.


Ring silencing

Press **OFF** or **MUTE** while the phone is ringing to silence the ringer.

Temporary tone dialing

If you have dial pulse (rotary) service, you can switch to touch tone dialing during a call by pressing . This can be useful if you need to send tone signals for access to answering systems or long-distance services.





Telephone Operation

Intercom calls

Intercom calls

Use the intercom feature to have conversations between the handsets.

Press the **INTERCOM** button on a handset to initiate an intercom call. This handset will call the other handset.

Press **PHONE** on the handset being paged to enter intercom mode with the first handset.

To end the intercom call:

- Press **OFF** or **INTERCOM** at the handset.
- Place the handset in the charger or base.



NOTE: The intercom feature cannot be utilized while either handset is in phone book mode.

Handling incoming calls

The phone will beep if you receive an outside call during an intercom conversation.

- Press **PHONE** to terminate the intercom call and answer the incoming call.
- Press **INTERCOM** to transfer an external call to other handset.



NOTE: It is possible to disconnect the intercom connection without answering the waiting call by pressing **OFF**.