





## Base settings

### Keypad tone

The base is preset to beep with the pressing of each key. The keypad tones can be turned on or off in this menu.

- Press the **MENU** softkey to enter the main menu. Press  four times to reach the **Settings** menu and press the **SELECT** softkey to confirm.
- Press the  twice to highlight **Keypad Tone** and press the **SELECT** softkey to confirm.
- Use the  or  to select whether you prefer the keypad tone to be **On** or **Off**.
- Press the **SET** softkey to confirm.
- The screen will show **Choice saved** to confirm the new setting.




## Base settings

### Language

In this menu, you can select the language used in all menus and screen displays. The choices are English, Español or Français.


- From the **Settings** menu, press **OK** three times to enter the **Language** menu, and press the **SELECT** softkey to confirm.
- Press the **Up** or **Down** to scroll through the languages available: English, Español and Français.
- Press the **SET** softkey to confirm your selection.
- The screen will show **Choice saved** to confirm the new setting.



### LCD Contrast

This setting allows you to adjust the contrast of the display on the telephone base to your liking.

- From the **Settings** menu, press **OK** four times to highlight **LCD Contrast** and press the **SELECT** softkey to confirm.
- When the contrast bar appears on the screen, press **Up** or **Down** to change the contrast of the display. A sample of the contrast is displayed on screen during the adjustment.
- Press the **SET** softkey to confirm your selection. There will be a confirmation tone and **Choice saved** is displayed on the screen to confirm the new setting.



### Clear Voice Mail

If you subscribe to voicemail services provided by your local telephone company, there will be a text message on the handset and the VOICEMAIL light on the telephone base will light when there is new voicemail. To manually turn off the new voicemail indication:



## Base settings



### NOTES:

1. This feature removes the VOICEMAIL indication from all handsets and the telephone base.
2. Unreviewed voicemail will not be deleted.

- Press the **MENU** softkey to enter the main menu. Press four times to reach the **Settings** menu and press the **SELECT** softkey to confirm.
- From the **Settings** menu, press three times to enter the **Clear Voice Mail** menu. Press the **SELECT** softkey to confirm.
- Press the **YES** softkey if it is decided to turn off the VOICEMAIL light, or press the **NO** softkey to keep the VOICEMAIL on until all voicemail have been reviewed.

### Default settings


This menu allows you to restore the default settings for all menu and answering system settings. It will not clear the directory, call log, redial log, or messages menu.

- Press the **MENU** softkey to enter the main menu. Press three times to reach the **Settings** and press the **SELECT** softkey to confirm.
- From the **Settings** menu, press twice to enter the **Default Settings** menu and press the **SELECT** softkey to confirm.
- Press the **Yes** softkey to confirm, or press the **No** softkey to keep all settings.

### Delete handsets

A handset must be de-registered first before it can be registered to another telephone base.

- Press the center NavKey on the handset.
- Press the up or down NavKey or four times for Settings.
- Press the center NavKey to enter into the Settings menu.
- Press the up NavKey once to select Delete Registration.
- Press the center NavKey and you will be prompted to select **YES/NO** for handset de-registration.









## Ringers

### **Ringer volume**

---


At this menu, you can set the ringer volume level (1 - 6), or turn off the ringer.

- In the Main Menu, press  five times to reach **Ringers**.
- Press the **SELECT** softkey and a volume indication with six levels appears. Adjust the volume by pressing  or  to decrease or  or  to increase the volume or press the **OFF** softkey to turn the ringer off.
- Press the **SET** softkey to confirm your selection and the screen will show **Choice saved**. The icon  will flash on the screen of the telephone base if its ringer is turned off.

### **Ringer melody**

---

This feature allows you to customize the ringer on the telephone base. The menu includes options for eight ringer melodies. There will be a sample of each ringer melody when scrolling through the choices.

- Press the **MENU** softkey to enter the main menu. Press  five times to reach the **Ringers** menu and press the **SELECT** softkey to confirm.



## Basic handset operation

### Making, answering and ending calls

To make a call, press **HOME/FLASH** or **SPEAKER**, then dial the number. Press **OFF/CANCEL** to hang up. To answer a call on the home line, press **HOME/FLASH** or **SPEAKER** or any dial pad key to make or answer a call on the cellular line, press **CELLULAR**.


To predial (preview numbers before dialing), enter numbers first, then press **HOME/FLASH** or **SPEAKER** to dial. Press the **OFF/CANCEL** to delete. Pressing # for about two seconds when predialing will bring out a P on the screen to signify a two-second pause.

### Handsfree speakerphone calls

To make a call using the handsfree speakerphone, press **SPEAKER**, then dial a number.

To answer an incoming call, press **SPEAKER**.

During a call, press **SPEAKER** to alternate between handsfree speakerphone and the normal handset use. Press **OFF/CANCEL** to hang up.



### Mute

Press the softkey **MUTE** to silence the microphone while on a call. **Microphone Muted** is displayed on the handset screen. You will be able to hear the other party, but the other party will not be able to hear you until you press the **UNMUTE** softkey to resume the conversation.

## Basic handset operation



### NOTES:

1. Any digits currently in the display will be dialed out when HOLD is released.
2. If the call is not resumed in 15 minutes, the originating handset will ring and the display will show CALL ON HOLD RING BACK. If the RING BACK is not answered in 30 seconds, the call will be disconnected.
3. If the telephone base or handset does not answer the intercom call in one minute, the intercom ringing stops and the call remains on hold until it times out in fifteen minutes.

### Hold

Press the **HOLD** softkey to place a call on hold. Press **HOME/FLASH** OR **SPEAKER** to resume the call. Placing a call on hold cancels the MUTE feature.

When a call is put on hold, the **HOME/FLASH** button of the handsets will flash and the **HOME** key on the telephone base will also flash.

### Hold

Press the **HOLD** softkey to place a call on hold. Press **HOME** to resume the call. Placing a call on hold cancels the MUTE feature.

When a call is put on hold, the **HOME** light on the telephone base and handset(s) will flash.

You can send an external call to the telephone base or to another handset if additional handsets are registered for use with the system.


- Press the softkey HOLD to put the call on hold.
- Press the center NavKey to enter the Main Menu.
- Press the down NavKey three times to reach Intercom.
- Press the center NavKey to enter the Intercom menu.
- Select from the list of destinations: Global Page (if you wish to call all handsets), BASE (if you wish to call only the telephone), or one of the registered handsets. Press the center NavKey to confirm.

## Basic base operation




### Making, answering and ending calls


To make a call, press  **HOME**, then dial a number. Press  **HOME** again to hang up.

To answer an incoming call, press  **HOME**.

To predial (preview numbers before dialing), enter numbers first, then press  **HOME** to dial. Press **CANCEL** anytime to correct any wrong numbers. Pressing the **PAUSE** or **STOP** softkey to generates a two-second pause before dialing the next digit.

### Last number redial

Press the **REDIAL** softkey to display a list of twenty numbers recently dialed. Use the up or down Navkeys  or  Navkey to select a number, then press  **HOME** to dial (see pages 52-53 to delete the entry, or save it to your directory).



## Options while on calls

### Mute


---

Press the **MUTE** softkey to silence the microphone and the screen will show **MICROPHONE MUTED**. You will be able to hear the other party, but the other party will not be able to hear you until you press the softkey **UNMUTE** to resume the conversation.

### Volume control

---

Press **▲/VOLUME** on the telephone base to adjust the listening volume. Each time the button is pressed, the volume is raised or lowered by one level.



#### NOTES:


1. If the call is not resumed in fifteen minutes the telephone base will ring. The display will show **CALL ON HOLD RING BACK!**. If the **RING BACK** is not answered in 30 seconds, the call will end.
2. Any digits currently in the display will be dialed when **HOLD** is released.
3. If a handset does not answer the intercom call in one minute, the intercom ringing stops and the call remains on hold until it times out in fifteen minutes.



## Options while on calls

### Call waiting

If you have call waiting service, there will be a beep if there is an incoming call during a telephone conversation. Press **HOME/FLASH** on the handset or press **FLASH** on the telephone base to put the current call on hold and pick up the new call. Press **HOME/FLASH** anytime to alternate between calls.



### Ringer silencing

Press **OFF/CANCEL** or the **SILENCE** softkey while the handset is ringing (or **CANCEL** or the **SILENCE** softkey on the telephone base) to silence the ringer for this call only. You can choose to answer the call, or let the caller leave a message. The ringer silencing function automatically cancels when the current call terminates. The next incoming call will ring normally.




### Multi-party on home line

During an outside call, both the handset and the telephone base (or up to 4 handsets and the telephone base or up to four handsets) can be used for a three-party conversation.

While a call is in progress, others can press **HOME/FLASH** or **SPEAKER** on any handset (or **HOME/FLASH** on the telephone base) to join the conference call. **Joining call on Home Line** will be displayed on the screen of the newly joint handset or telephone base. Press **OFF/CANCEL** on the handset (or **HOME** on the telephone base) to quit the conference call. The call will not end until all parties hang up.

**NOTE:** The ringer silencing function automatically cancels when the current call terminates.



Press **INTERCOM** on the telephone base.



OR



## Intercom calls






### Intercom calls

The intercom feature allows conversation between the handset and the telephone base, or between handsets if additional handsets are registered for use with the system.

### Initiating an intercom call




- Press **INTERCOM** to enter the **Intercom** menu.
- Select from the list of destinations: **Global Page**, or one of the registered handsets. Press or to highlight the destination handset.
- Press the softkey **SELECT** to confirm.
- From the idle mode, press **INTERCOM** on the telephone base to initiate an intercom call.
- From the idle mode, press the center NavKey to enter the main menu. Press the down NavKey three times to reach the **Intercom** menu. Press the center NavKey to confirm selection. Press the up or down NavKey or to scroll down to select **Global Page** to page all handsets, or select **BASE** or one of the registered handsets. Press the center NavKey (or the **SELECT** softkey on the telephone base) to page the selected handsets or the telephone base.
- On the selected handset or the telephone base, press **HOME/FLASH** on the destination handset, or **INTERCOM** on the telephone base to answer an intercom page. The telephone base will ring until **HOME** is pressed or until the page is cancelled by pressing **CANCEL**.

## Intercom calls

- When the intercom call is finished, press **END** softkey or  **OFF/CANCEL** on the handset (or **END** softkey or  **HOME** or **INTERCOM** on the telephone base) to end the call.
- When the destination handset starts to ring, press the **ANSWER** softkey or  **SPEAKER** on the destination handset to pick up the intercom call.
- Press  **HOME** or **END** softkey or  **SPEAKER** on the telephone base to terminate the intercom call, then the destination handset can go off-hook to pick up the call on hold to start the conversation.

### Handling incoming calls

During an intercom conversation, the telephone will beep if there is an incoming external call.

- On the handset, press the **END** softkey or  **OFF/CANCEL** to terminate the intercom call. The handset will ring normally. Press  **HOME/FLASH** to answer the incoming call.
- On the telephone base, press the **END** softkey to terminate the intercom call. The telephone base will ring normally. Press  **HOME** to answer the incoming call.

## Bluetooth

If your cellular phone is compatible with Bluetooth wireless technology, you can use the handset or telephone base to make or answer calls using a cellular line.

This feature is useful for maximizing the benefits of cellular services (such as free unlimited nights and weekends, or cellular to cellular calling plans) by utilizing unused peak minutes with your home telephone.


To use this feature, you must first pair and connect the cellular phone to the telephone base.

Important:

- The following procedures must be performed using the telephone base.
- Up to two cellular phones, or a headset and a cellular phone, can be connected.
- To optimize the performance of the connection between the telephone base and the cellular phone, it is recommended to use the cellular phone in close proximity with the telephone base.
- While you are on a cellular phone, the air time and battery consumption of the cellular phone is deducted from your cellular phone for the duration of the call.



## Bluetooth operation




### Pairing and connecting a cellular phone

1. Press the **MENU** softkey to enter the main menu on the telephone base.
2. Press  to highlight Bluetooth and press the **SELECT** softkey.
3. Press the **SELECT** softkey to enter Setup Cellular.
4. When the screen displays `Set Your Cellular to search for Bluetooth devices`, press the **NEXT** softkey.
5. The screen will then display `AT&T EP5632 in Discoverable Mode PIN=0000` (the default PIN).

The telephone base is now ready to be paired with the cellular phone.



Follow the instructions of your cellular phone to enter the Bluetooth registration mode. The telephone base PIN (defaulted as 0000) maybe required for registration. Follow the procedures on the cellular phone to pair with the telephone base.

6. While the cellular phone is pairing with the telephone base, `Pairing in Progress` will be shown on the screen of the telephone base. Once the pairing is successfully made, `Paired with cellular` will be displayed on the screen of the telephone base.
7. Press the **YES** softkey when `Pairing complete. Connect to Cellular?` is shown on the screen of the telephone base.
8. If the cellular phone and the telephone base are successfully connected, `Cellular setup Completed` will be displayed, and a steady icon  1 will also appear on the screen of the telephone base for the first connected device;  2 will appear for the second connected device.






## Bluetooth operation

Using a Bluetooth-enabled headset, you can enjoy a handsfree conversation by registering your headset to the telephone base.



### Pairing and connecting a headset


Turn your Bluetooth headset on before registration.

1. Press the **MENU** softkey to enter the Main Menu on the telephone base.
2. Press  to highlight Bluetooth and press the **SELECT** softkey.
3. Press the **SELECT** softkey to enter Set up Headset.
4. When the screen displays Set Headset in Discoverable mode, press the **NEXT** softkey.
5. The telephone base will then start searching for available headsets.
6. Press the **PAIR** softkey to connect to the headset.
7. You will then be asked to enter the PIN. Depending on the manufacturer of the headset, you must enter the PIN for the headset. Check your headset manual for the PIN number. Press the **DONE** softkey after entering the PIN.
8. Press the **YES** softkey when the screen displays Pairing complete. Connect to Headset?
9. Headset setup completed will be shown if the headset and the telephone base are successfully connected. If the headset is the first Bluetooth device to be connected, a steady icon of  1 will also appear on the screen of the telephone base. If the headset is the second Bluetooth device to be connected, a steady icon of  2 will also appear on the screen of the telephone base.


## Bluetooth operation

### Making an ending call on the cellular lines

#### Handset

1. To make a call, press  **CELLULAR** and enter a number.

**-OR-**

Enter a number first, then press  **CELLULAR**.

Press the **OFF** softkey at anytime to make corrections when entering numbers.

2. Select the desired cellular phone.

3. Press the **DIAL** softkey.

4. Press the **OFF** softkey to hang up.


The screen displays the elapsed time of the call (in hours, minutes and seconds).

#### Telephone base

1. Press  **CELLULAR** on the telephone base.



2. Enter a number, then press the **DIAL** softkey.

**-OR-**


Enter a number first before pressing  **CELLULAR**. Press **CANCEL** anytime to make corrections when entering numbers.

### Answering call

#### Handset

Press  **CELLULAR** to answer a call; press  **OFF/CANCEL** to hang up.

#### Telephone base

Press  **CELLULAR** to answer a call; press again to hang up.







**NOTE:** If there are two cellular telephones connected to the telephone base, you need to select the desired cellular telephone line to use.

## Bluetooth operation





### Making a call from the directory

---


1. Select **HOME** line or **CELL** line.
2. Press  **MENU/SELECT** to enter the main menu, and press again to enter the directory.
3. Press  or  to select the number you want to dial.
4. Press  **CELLULAR** to make a call.



### Telephone base

1. Press the **MENU** softkey, and press the **SELECT** softkey to enter the directory.
2. Press the **DELETE** softkey or  to select the number to dial.
3. Press  **CELLULAR** to dial.

### Headset



1. Press the **MENU** softkey on the telephone base, and press the **SELECT** softkey to enter the directory.
2. Press the **DELETE** softkey or  to select the number to dial.
3. Press **HEADSET** to dial.



## Bluetooth operation

### Ringers for different call lines



You may choose the ringer volume and ringer melody for different incoming call lines. This function enables you to identify the destination line of the incoming call before picking up the call.

To setup, press the **MENU** softkey, and scroll down to select Ringers in the Main Menu. Press the up or down Navkey  or  to select the destination line (HOME, CELL 1 or CELL 2) for the incoming call. Choose between Ringer Volume and Ringer Melody to adjust the desired settings. Refer to page 13 and page 21 for details.



### Making call through land line during a cellular call





You may use the land line to make a call while a cellular line is in use.

#### Handset

While a call is on the cellular line, press the **HOLD** softkey or the **HOME** line to put the call on hold. The  **CELLULAR** button will then flash. Press  **SPEAKER** to turn the speakerphone on to dial another call through the land line.

#### Telephone base

While a call is on the cellular line, press the **HOLD** softkey to put the call on hold. The  **CELLULAR** button will then flash. Press  **HOME** to turn the speakerphone on to dial another call on the land line.





## Bluetooth operation

### Making a call through cellular line during a land line call



---



You may use the cellular line to make a call while the land line is already in use.

#### Handset

While the land line is in use, press the **HOLD** softkey to put the call on hold, the  **HOME/FLASH** button will then flash. Press  **CELLULAR**, and choose the desired cellular line. Press the **SELECT** softkey. If there are two cellular telephones connected, choose the desired cellular telephone line. You will be prompted to enter the desired number and press the **DIAL** softkey to make a call on the cellular line.

#### Telephone base



While the land line is in use, press the **HOLD** softkey to put the call on hold, and the  **HOME** button will flash. Press  **CELLULAR**, and enter the desired number before pressing the **DIAL** softkey to make the call. If there are two cellular telephones connected, choose the desired cellular telephone line to use.



## Paired devices






All paired devices are stored on the **Paired Devices** list, which means once you have paired a device with the telephone base, the device will be stored in the telephone base and you do not have to repeat the pairing procedure next time.




Up to eight devices (any combination of cell phones and headsets) can be paired with the telephone base.

If the device is successfully paired with the telephone base, the icon  (for cell phone) or  (for headset) and the name of the device will be shown on the **Paired Devices** list.

### Rename or delete a paired device

You can rename or delete any device on the **Paired Devices** list.






- Press the **MENU** softkey on the telephone base while in idle mode
  - Press the up and down NavKey  or  to highlight **Bluetooth**, then press the **SELECT** softkey.
  - Press the down NavKey  to highlight **Paired Devices**, and press the **SELECT** softkey.
  - Press the up and down NavKey  or  to highlight the the name of the desired device.
  - Press the **RENAME** softkey to rename a device.
- OR-**
- Press the **DELETE** softkey to delete the high-lighted device on the list.



## Active devices




### Selecting active devices

If you choose to connect a device immediately after the pairing, the device will be put under the **Active Devices** list automatically; otherwise, you need to follow the procedures below to add a paired device to the active devices list manually.

- Press the **MENU** softkey on the telephone base while in idle mode.
- Press the up and down NavKey  or  to highlight **Bluetooth**, and press the **SELECT** softkey.
- Press the down NavKey  to highlight **Active Devices**, then press the **SELECT** softkey.
- Press the **ADD** softkey, and the screen will then display all paired devices. Press the up or down NavKey  or  to choose the desire device, and press the **CONNECT** softkey to establish the connection.



Only devices on the **Active Devices** list can establish Bluetooth connection with the telephone base. A maximum of two devices can be in active mode at the same time. Either two cell phones or a cell phone and a headset can be connected.





Please note that the Bluetooth technology is designed for one to one connection. In this case, even though there are two devices in the active mode, only one of them can establish audio connection at a time, not both.





## Active devices

### Disconnect, replace or remove a device

On the **Active Devices** list, you may disconnect any device by pressing the up or down NavKey  or  to highlight the desired device, then press the **DISCONN** softkey.

You may also replace or remove any device on the list. Press the up or down NavKey  or  to highlight the desired device, then press the **OPTIONS** softkey. Press the NavKey  or  again to select either **Replace Devices** or **Remove Devices** from the **Active Devices** list.



 **NOTE:** When there are no paired headset or cellular telephone, then pushing the up Navkey  will shortcut to set up the cellular telephone.



# Handset directory

## Memory capacity

---

There are separate directories in the handset and the telephone base. The directory in the handset can store up to one hundred entries. Each entry can store a number with up to thirty-two digits, and a name up to sixteen alphanumeric characters (including spaces).

If you subscribe to caller ID service from your local telephone company, you can select a picture or an animation to be displayed with each directory entry. You can also select a distinctive ringer melody for each entry so that this caller's identity is known as soon as the telephone rings. A convenient search feature can help you find and dial numbers quickly (see page 32).

If additional handsets are registered, all handsets and the telephone base will have separate directories and call logs.

## Timeouts and error tones


---



If you pause for over sixty seconds while inputting an entry, the procedure will time-out and it will be necessary to begin again.

If all memory locations are in use, an error tone will sound when you attempt to enter a new number. This means the memory is full, and you will not be able to store a new number until an existing one is deleted.




## New directory entries




- Press the center NavKey  to enter the main menu.
- When the directory is shown on the screen, press the center NavKey  to enter the directory menu.
- Press the **NEW** softkey to insert a new entry.


### Entering a name


Use the dial pad and the table below to enter a name (up to sixteen characters). Each press of a particular key will cause characters to be displayed in the following order:



Dial key	Characters by number of key presses								
	1	2	3	4	5	6	7	8	9
1	space	1							
2	A	B	C	2	a	b	c		
3	D	E	F	3	d	e	f		
4	G	H	I	4	g	h	i		
5	J	K	L	5	j	k	l		
6	M	N	O	6	m	n	o		
7	P	Q	R	S	7	p	q	r	s
8	T	U	V	8	t	u	v		
9	W	X	Y	Z	9	w	x	y	z
0	0								
*	*	?	!	/	(	)			
#	#	'	,	-	.	&			

 **NOTE:** Up to 16 characters (including spaces) can be used for each name.

The cursor moves to the right automatically after two seconds or when you press another dial pad key or the right NavKey  (press twice to enter a space). When the name is complete, press the **DONE** softkey.

- Press the **ERASE** softkey or the left NavKey  to correct a mistake.

## New directory entries



**i** **NOTE:** When customizing the ringer or picture, and the ringer or picture is highlighted, pressing the center NavKey would move to the Ringer option or Picture option using the full screen. Once selected, it would go back to the customizing screen.

### Entering a number

Use the dial pad to enter up to thirty-two digits. When finished entering, press the **DONE** softkey.

- Press the **ERASE** softkey to correct a mistake.
- To insert a two-second dialing pause, press and hold # until P appears to replace the # on the screen.

Use the dial pad and the table on page 30 to enter a name (up to sixteen characters). Each press of a particular key will cause characters to be displayed in the order as shown in the table on page 30.



### Customizing entries

Press the down NavKey to scroll down to Ringers selection, then the left or right NavKey or to assign a distinctive ringer (see page 12). If you have caller ID service, the designated ringer will alert you when this person calls.

Press the down NavKey to scroll down to picture selection, then the left or right NavKey or to assign a picture or an animation to this entry (see page 11).

Press the **SAVE** softkey to save your new entry or press the **ERASE** softkey to change the current selection (or press **OFF/CANCEL** to discard changes and exit).








**NOTE:** If the entry does not exist, the closest alphabetic match preceding the entry will be selected.

## Directory search



There are two ways to enter the directory:

- Using the down NavKey  from the idle mode can enter the directory search.

**-OR-**

- Pressing the center NavKey  to enter the main menu.
- When the directory is shown on the screen, press the center NavKey  to enter the directory menu.

### Browsing through the directory

To browse, press the up or down NavKey  or  to scroll through all entries one by one.

### Searching alphabetically




To shorten your search, press the **FIND** softkey, then use the dial pad on the handset to enter the first letter of a name. When you press the **SET** softkey, the first name beginning with that letter will be displayed.

Press the appropriate dial pad key once for the first letter, twice for the second, three times for the third, as shown on page 30.


Alphabetical search can also be done directly from the directory listing by entering the first character of the name. The first name beginning with that letter will immediately be shown.

For example, press 5 (JKL) once to find Jenny, twice to find Kristen, or three times to find Linda.

### Calling a displayed number










When you find the entry desired, press  **HOME/FLASH** (or  **SPEAKER**) to dial on the HOME line, or press  **CELLULAR** to dial out on the CELL line.

## Editing or deleting an entry



### Editing a listing




When any directory entry is displayed, press the **EDIT** softkey to modify the entry. You can change the name, number, distinct ringer or picture setting by following the steps on pages 30-31.

- Press the center NavKey  to enter the main menu.
- When the directory screen is displayed, press the center NavKey  to confirm.
- When the directory listing is displayed, use the up and down NavKey  or  to scroll through the list and highlight the desired entry.
- Press the center NavKey  to confirm selection.
- When all the information for that entry is displayed on the screen, press the up or down NavKey  or  to highlight the category to be edited.
- Press the left or right NavKey  or  to move the cursor one space to the left or right.
- Use the table on page 30 to enter the appropriate letter or digit.
- Use the **ERASE** softkey to delete any mistake.
- When finished editing, press the **SAVE** softkey and the screen will show `Entry saved to Directory.`

## Editing or deleting an entry

### Deleting an entry

---




When the directory name or an entire directory entry is displayed, use the up or down NavKey  or  to highlight that entry and press the center NavKey  to select the entry.

- Press the **DELETE** softkey.
- Press the center NavKey .


A confirmation tone will sound and the next entry in the directory will be shown.

### Deleting all entries

---

- To delete all entries in the directory, press the **DELETE** softkey to see all the delete options.
- Use the up or down NavKey  or  to select **Delete All Entries**.
- Press the center NavKey  to confirm selection.
- You will then be prompted to delete the entire directory. Press the **YES** or **NO** softkey to confirm your selection.



 **NOTE:** Once deleted, entries cannot be recovered.



# Base directory

## Memory capacity

---

There are separate directories in the handset and the telephone base. The directory in the telephone base can store up to 100 entries. Each entry can contain a number up to thirty-two digits, and a name up to sixteen characters. A convenient search feature can help you find and dial numbers quickly (see page 38).

## Timeouts and error tones

---

If you pause for over sixty seconds while making an entry, the procedure will time out and it will be necessary to begin again.

If all memory locations are in use, an error tone will sound when you attempt to enter a new number. This means the memory is full, and you will not be able to store a new number until an existing one is deleted.

## New directory entries

- Press the **MENU** softkey to bring up the directory on the screen.
- Press the **SELECT** softkey to enter the directory.
- Press the **NEW** softkey and the screen shows `Enter Name.`



Enter name, then press **MENU/SELECT** to confirm.

### Entering a name

Use the dial pad and the table below to enter a name (up to sixteen characters). Each press of a particular key will cause characters to be displayed in the following order:

Dial key	Characters by number of key presses								
	1	2	3	4	5	6	7	8	9
1	space	1							
2	A	B	C	2	a	b	c		
3	D	E	F	3	d	e	f		
4	G	H	I	4	g	h	i		
5	J	K	L	5	j	k	l		
6	M	N	O	6	m	n	o		
7	P	Q	R	S	7	p	q	r	s
8	T	U	V	8	t	u	v		
9	W	X	Y	Z	9	w	x	y	z
0	0								
*	*	?	!	/	(	)			
#	#	'	,	-	.	&			

The cursor moves to the right when you press another dial pad key or the **RIGHT** softkey. Press 1 to insert a space between letters.

- Press **LEFT** to move the cursor one space to the left, or **RIGHT** to move the cursor to the right until the character to be edited is blinking.
- Press the **ERASE** softkey to erase the highlighted letter.
- Press the **DONE** softkey and then the **SAVE** softkey to save your new directory entry. To change it later, see page 39.

## New directory entries

### Entering a number



---

Use the dial pad to enter up to thirty-two digits.



Enter number, then press **MENU/SELECT** to confirm.





- Press and hold # to insert a dialing pause until "F" appears on the screen to indicate a dialing pause.
- Move the cursor one space to the right by pressing  to insert an extra number.
- Move the cursor one space to the left by pressing  to insert an extra number.
- Press the **ERASE** softkey on the telephone base to delete any wrong input.
- Press the **DONE** softkey and then the **SAVE** softkey to save when finished.

The screen will show, *Entry saved to Directory*, along with a confirmation tone.

## Directory search

- Press the **MENU** softkey to bring up the directory on the screen.
- Press the **SELECT** softkey to enter the directory.

### Browsing through the directory

Use the  or  buttons to browse through the directory, or search to find a specific entry. Press **CANCEL** anytime to exit the directory.


### Searching alphabetically


- From idle, press the **MENU** softkey to bring up the directory on the screen.
- When **Directory** is highlighted, press the **SELECT** softkey to enter the directory.
- Press the **FIND** softkey to enter the directory search mode.
- When the screen shows **Search for**, use the telephone base dial pad to enter the first letter of a name. Press the **SET** softkey to start the search.
- Press the appropriate dial pad keys once for the first letter, twice for the second, three times for the third, as shown on page 36.

For example, press 5 (JKL) once to find Jenny, twice to find Kristen, or three times to find Linda.


If an entry does not exist, the closest alphabetical match preceding that entry will be selected.

### Calling a displayed number

When the desired entry is highlighted, press  **HOME** to dial, or press the **EDIT** softkey to modify the entry (see next page).










Use  OR  to search for the desired entry.

 **NOTE:**  
Alphabetical search and browsing can be combined.

## Editing or deleting an entry

### Editing a listing

- Press the **MENU** softkey to bring up the directory on the screen.
- Press the **SELECT** softkey to enter the directory.
- Use  or  to scroll through the listing to find the desired entry which is highlighted.
- Press the **SELECT** softkey to bring out the highlighted entry in the directory.
- Press the **EDIT** softkey.
- When the name is displayed, press  to move the cursor one space to the left, or press  to move the cursor one space to the right.
- Use the table on page 36 to enter the appropriate character.
- When finished editing the name, press  to reach the programmed telephone number of the same entry.
- Press  to move the cursor one space to the left, or press  to move the cursor one space to the right.
- Use the dialpad keys to enter the correct number.
- Press the **SAVE** softkey to confirm and save the edited entry.



**i** **NOTE:** When in the editing mode, the cursor is on the first letter of the name. A new letter is placed before the cursor and does not replace the letter under the cursor.







## Editing or deleting an entry



### Deleting an entry

---

- Press the **MENU** softkey to bring up `Directory` on the screen.
- Press the **SELECT** softkey to enter the directory.
- Use the up or down NavKey  or  to scroll through the listing to find the desired entry.
- Press the **SELECT** softkey to bring up the details of the highlighted entry.
- Press the **DELETE** softkey to bring out all the `Delete Options`.
- When `Delete Entry` is highlighted, press the **SELECT** softkey to delete that one entry only, and a confirmation tone will sound.

### Deleting all entries

---

- Press the **MENU** softkey to bring up the directory on the screen.
- Use the  or  NavKey to highlight any entry.
- Press the **DELETE** softkey to bring out all the `Delete Options`.
- When `Delete All Entries` is highlighted, press the **YES** softkey if you wish to delete all entries in the telephone base. Once deleted, entries cannot be recovered. Press the **NO** softkey to keep the entire directory.



**NOTE:** Once deleted, entries cannot be recovered. Press the **NO** softkey to keep the entire directory.

# IMPORTANT

## Information about caller ID with call waiting

This product has a caller ID with call waiting feature which works with services from your local telephone service provider.

Caller ID with call waiting lets you see the name and telephone number of the caller before answering the telephone, even when on another call.

**You may need to change your telephone service to use this feature.** Contact your telephone company if:





- you have both caller ID and call waiting, but as separate services (you may need combined service).
- you have only caller ID service, or only call waiting service.
- you don't subscribe to any caller ID or call waiting services.

You can use this product with regular caller ID service, or you can use this product's other features without subscribing to either caller ID or combined caller ID with call waiting service.

There are fees for caller ID services, but these may not be available in all areas.


Depending on your service subscription, you may see the caller's number, or the caller's name and number. This product can provide information only if both you and the caller are in areas offering caller ID service, and if both telephone companies use compatible equipment. The time and date are sent by the telephone company along with the call information.

# Handset call log & redial



## How caller ID on the HOME line works

If you subscribe to the caller ID service, information about each caller will be displayed after the first or second ring.

You can review the call log to find out who has called, return the call by pressing  **HOME/FLASH** or **CELL** or copy the caller's name and number into your directory.

The call log can store up to 100 entries. Calls are displayed in reverse chronological order (the latest unreviewed first). When the call log is full, the earliest reviewed entry is automatically deleted to make room for new incoming call information.

If you answer a call before the information appears on the screen, the caller ID information will not be saved in the call log.

## Clear call log


Use the **DELETE** softkey to clear a single entry or all entries in the call log.

## Review redial

This screen shows a list of the last twenty numbers dialed from this handset. You can redial any number, delete it from the redial log, or copy it to your directory.

## Clear redial

Use the **DELETE** softkey to delete a single entry or all twenty recently called numbers from your redial list.








**i NOTE:** Names of callers are displayed only if the information is provided by your local telephone company. If the telephone number of the caller matches an entry in the directory, the name shown on screen will match the name entered into the directory. (Example: If "Christine Smith" calls, her name will appear as "Chris" if this is how you entered it.)

## Reviewing your call log

### Reviewing your call log

The call log keeps track of the last 100 calls received, and lets you check voice messages from your handset if there is a voice message attached to that call log.

- Press the center NavKey  to enter the main menu.
- Press the down NavKey  once to reach call log, then press the center NavKey  to confirm.
- Use the up or down NavKey  or  to scroll through and review the call log entries.

The call log can also be accessed directly by pressing the **CALLER ID** softkey when in the idle mode.

### Missed Calls

For calls with caller ID information, each handset will log the caller ID information and keep a running counter of the number of unanswered calls. The number of unanswered calls is shown on the handset idle screen as **Missed Calls**.

**XX MISSED CALLS** are calls that have not been reviewed on that handset. When a new call log entry is reviewed, the number of missed calls on that handset is decreased by one. The number of **MISSED CALLS** on the other handset(s) remains unchanged until they are reviewed on those handsets.



If there are no **NEW** call log entries, the **Missed Calls** indication will not be shown.

To quickly clear the **Missed Calls** indication on the screen, press and hold **OFF/CANCEL** when in the idle mode and the handset which displays **MISSED CALLS** will be cleared. After the **Missed Calls** indication is cleared, the **NEW** indication on the call log entries will also be cleared.

## Reviewing your call log

### Returning a call

---


Press  **HOME/FLASH** or  **SPEAKER** to call the number currently displayed.

### Saving an entry

---

Press the **SAVE** softkey to copy the displayed information into the handset's directory (see page 29).


This will take the directory entry feature in edit mode for you to edit a name or number, and customize a ringer and picture. Once you have completed a new entry and pressed the **SAVE** softkey, the screen will return to the call log entry.



### Deleting an entry

---

Press the **DELETE** softkey to delete this entry from your call log.



### Deleting all entries

---

To clear all the call log entries, return to the call log listing, then press the **DELETE** softkey to bring out the **Delete Options** menu. Select **Delete ALL Entries** and you will be prompted to delete all entries. To con-




## Dialing a call log entry




When any caller ID screen is displayed, press  **HOME/FLASH** or  **SPEAKER** to dial the number on the screen.

### Playback options

---






- From the idle screen, press the **CALLER ID** softkey to enter the call log.
- Press the up or down NavKey  or  to scroll through the call log entries.
- Press the right NavKey  to play the message.

To delete a message, press the **DELETE** softkey while the message is playing. Press  **OFF/CANCEL** to stop playback and exit the **Call Log** menu.

### Dialing options

---

Caller ID numbers may appear with an area code that may not be required for local calls. If the number displayed is not in the correct format, you can change how it is dialed.

Press the center NavKey  to see a list of dialing options. Press the up or down NavKey  or  to select the desired option. To dial the number, press  **HOME/FLASH** or  **SPEAKER**, or the **DIAL** softkey.


## Reviewing your redial log

### About the redial log

---



You can review the redial log to see the last twenty numbers recently called, redial, or copy the number into the directory.

When there are already twenty entries in the redial memory, the earliest reviewed entry is automatically deleted to make room for the new one.







### Reviewing your redial log


---

The latest call is displayed first. Press the up or down NavKey  or  to scroll through the list.

### Dialing an entry



---

Press the **REDIAL** softkey to display a list of twenty numbers recently dialed. Use the up or down NavKey  or  to highlight a number, then press  **HOME/FLASH** or  **SPEAKER** to dial.



### Saving an entry

---




- Press the **REDIAL** softkey to bring out the redial memory listing.
- Use the up or down NavKey  or  to highlight the desired entry.
- Press the **SAVE** softkey to store the number in the directory.
- Enter the name of the directory entry using the table on page 30.
- Press the **DONE** softkey when finished, or press the **ERASE** softkey to delete any mistake.


## Reviewing your redial log



### Deleting an entry

---

- Press the **REDIAL** softkey to bring out the redial memory listing.
- Press the up or down NavKey  or  to highlight the entry to be deleted.
- Press the **DELETE** softkey to bring up the Delete Options menu.
- When **Delete Entry** is highlighted, press the center NavKey  to confirm deletion. A confirmation tone will sound.



### Deleting all entries

---

- To clear the redial log of all entries, return to the redial log listing, then press the **DELETE** softkey to bring out the **Delete Options** menu.
- Select **Delete All Entries** and you will be prompted to **delete all Redial numbers**.
- To confirm, press the **YES** softkey. To keep the redial log, press the **NO** softkey.





## Reviewing voice messages






At this menu, you can use your handset to listen to your memos or voice messages left in your answering system on the telephone base (see pages 59-60). A total of 99 messages or 15 minutes of recording can be stored in the answering system, with each message not exceeding 4 minutes.




### Message playback

At the **Messages** screen, use the NavKey to control message playback:

- Press the left NavKey  to repeat the message currently playing. Press twice to hear the previous message.
- Press the right NavKey  to skip to the next message.

On the handset, voice messages are played through the speakerphone. If you prefer to listen privately, press  **SPEAKER** to switch to handset playback.

To delete a message, press the **DELETE** softkey while the message is playing.

Press the **STOP** softkey or  **OFF/CANCEL** to stop playback and exit the **Messages** menu.





# Base call log & redial



## Call log


---

There are separate call logs in the handset and the telephone base. The call log in the telephone base can store up to 100 entries, with each entry containing a name up to 32 alphanumeric characters and a number up to 16 digits.

If you have caller ID service, press the **CID** softkey to enter the call log menu. Then press  or  to review the call log to find out who has called, return the call by pressing  **HOME** or  **CELLULAR**, or copy the caller's name and number into the directory of the telephone base.

## Reviewing redial log

---

This screen shows a list of the 20 most recently dialed numbers. You can call one of the numbers again by pressing  **HOME**, or copy the number into the directory of the telephone base.