



Get to Know the Parts

Front of remote



Use the Left arrow to go back to the previous screen. Play/Pause/Forward/Rewind are not available at this time.


Back of remote




Lock
Press to prevent accidental typing while using front of remote.

ALT
Press ALT for characters in blue—i.e. press ALT then Q for 1. You will need to press ALT for each character.

Front of camera



Top of adaptor box



WPS
Use for wireless setup with WPS capable routers. (Currently not available)

SD Slot
Use for viewing media (Currently not available)

Front of adaptor box




Network Indicator
Glowing LED indicates connection to home network.

Message Indicator
Glowing LED indicates new messages.

Power
Glowing LED indicates adaptor is on.

Back of adaptor box



The Reset button has two functions, depending on the length of time held:

Normal Reset
Insert a thin object and hold the Reset button for 2-5 seconds to reboot the adaptor and keep your personal settings.

Factory Reset
Insert a thin object and hold the Reset button for 15 or more seconds to delete ALL personal settings and restore the adaptor to the default factory settings.




xfinity

Getting Started Guide

XFINITY® is your interface to a growing number of new products, services and features that will become available to you on your HDTV.

What's in the Box


If anything is missing, please call Comcast at 877-704-7713 for assistance.



You'll Also Need:



- HDMI-capable Comcast set-top box



- HDTV
- Internet connection with at least 1.5 Mbps simultaneous upload and download speeds (check your speeds at <http://speedtest.comcast.net>)

- Comcast ID
- Skype™ account

Note: This packaging has been specially designed using sustainable materials. Be kind to the environment and re-use this box.

Important Information

Important Information

Save time during activation by completing the information below.

Comcast Account

You must use your Comcast ID to activate. To add more Comcast email addresses (up to six) to your account, please visit <http://customer.comcast.com>.

@comcast.net

Password:

Skype Account

You will link your Comcast ID to a Skype account during the TV activation process. If you don't have a Skype account or need to create a new one, you can do so during activation.

Skype Name

Password:

Home Network

If you choose to use your wireless home network, you'll need the following information during the TV activation. If you have a compatible router with WiFi Protected Setup (WPS), this will be detected and you'll automatically connect to your wireless network. (WPS is currently not available)

Network Name (SSID)

Network Password (Key)

Security Encryption Method
(for hidden wireless networks only)

If you need help during setup or activation, please call 877-704-7713.

1 Set Up

TV Top:

- A** Place the front of the camera on top of your TV, with the bottom lip resting just below the top of the screen.*
- B** Push the clip down until it touches the back of the TV and the camera is secured.
- C** Pivot the angle of the camera and adjust to capture your preferred viewing area.

*The recommended viewing distance is 5' - 12'. Camera should not be used near strong magnetic fields.

OR

Flat Surface:

- A** Place the camera on your level surface with the lens facing the viewing area.*
- B** Hold the rubber bottom in place while pivoting the angle of the camera to capture your preferred viewing area.


*The recommended viewing distance is 5' - 12'. Camera should not be used near strong magnetic fields.

Important Note for Wall-Mounted TVs



Make sure the combined weight of the camera (8.81 oz.) and TV does not exceed the maximum rating for your wall mount. Check the wall mount manufacturer's manual for the maximum rating. The camera clip is not compatible with all TV wall mounts. For wall-mounted TVs that have been installed flush with the wall, camera placement on your TV is not recommended due to space constraints which may result in damage to your TV or the camera.

Important Note for Fireplace-Mounted TVs

The camera is not intended for use in high-temperature locations, such as above fireplaces.



OR




2 Connect and Power Up

- A** Plug in one of the provided HDMI cables to your set-top box and the other end to the **HDMI Cable In** port on your adaptor box.
- B** Plug the second HDMI cable to the **HDMI TV Out** port on your adaptor box and the other end to one of the available HDMI ports on your TV.
- C** Plug the camera cable into the **Camera** port. If the camera cable is not long enough to reach the **Camera** port, connect the provided USB extension cable to the camera cable.
- D** Decide if you want to connect to your home network using a wired Ethernet cable or wireless connection.


Ethernet connection:
Plug a CAT-6 Ethernet cable (not provided) to the Ethernet port on the adaptor box and the other end to an available port on your modem or router.

Wireless connection:
Skip this step and follow the instructions during TV activation.
- E** If you're using an audio receiver, disconnect the SPDIF (Optical Digital Audio) cable from your set-top box and plug it into the **Audio** port on the adaptor box instead.
- F** Connect the power adaptor to the power adaptor cable.



Plug the power adaptor into the **Power** port on the adaptor box and the power adaptor cable to an electrical outlet. There is no actual power button on your adaptor box so this power cable is the only way to turn the system on and off.

- G** Using your TV remote, select the same HDMI input to which you connected the adaptor box.



3 Activate

If you need help during setup or activation, please call 877-704-7713

- A** Once you've connected the devices, you'll see an XFINITY screen. **In a few minutes (up to 15), you'll be greeted with a Welcome screen. Please don't unplug or reset the adaptor box before you see this screen.** If you do unplug or reset before activation is complete, the system will restart from the beginning of the setup process.
- B** If you haven't already done so, pull the tab from the remote's battery compartment before using.
- C** Flip the remote to the keyboard side. See **Get to Know the Parts** for keyboard tips. Complete the activation by following the directions on your TV screen.
- D** You'll need the **Important Information** section (for your Comcast account, Skype account/password, and home network info) to complete some steps.
- E** You have several options for network connectivity:
 1. Wired connection using an Ethernet cable
 2. Wireless connection to an available or hidden network
 3. WPS for WPS-capable routers only (WPS is currently not available)
- F** A short series of diagnostic tests will run automatically to ensure everything is working properly and you'll have the choice to merge your XFINITY and Skype contacts.
- G** Click **FINISH** to jump right in!

Ready to Connect with Family and Friends?

First, make sure you're signed in.

If you already have an existing Skype account with contacts:

- Go to **Home > Contacts** and select from the list.
- Click **VIDEO CALL**, **AUDIO CALL** or **MESSAGE** to connect.

If you've just set up your Skype account and don't have any contacts yet:

- Go to **Home > Contacts** and select **Add Contact**.
- Flip the remote and use the keyboard (see **Get to Know the Parts** for tips) to enter a Skype Name or email address. Once your invitation to connect is accepted, the person will appear in your **Contacts**. Select the person.
- Click **VIDEO CALL**, **AUDIO CALL** or **MESSAGE** to connect.

Support Information

Please visit www.comcast.com/skype for additional online support information. For setup or activation-related questions, please call 877-704-7713 for assistance.

For questions following activation, please contact our customer care staff 24-hours a day at 877-704-7713. We are here to assist with all of your service needs.