

XAC

A Partner You Can Trust

TABLET POS HUB

INSTALLATION GUIDE



MODEL:
TP72-HUB

1. BEFORE STARTING

Find the power input on the right side of the terminal. Connect the plug from the power adapter into the power input (Figure 1). Plug the power adapter into a 120-volt electrical outlet or into a surge suppressor (recommended) after the power cord is connected to the power adapter.



Figure 1

- Operating Temperature: 0 °C to 40 °C
- RTC battery spec. : 3V, CR2032
- Adapter: LITEON,PA-1061-71, I/P: 100-240Vac, 47-63Hz, 1.5A, O/P: 12Vdc, 5.0A

Caution: Risk of explosion if the battery is replaced by an incorrect type. Please dispose of used battery according to the instructions.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

2. POWER ON

Plug the power cord into the power jack and plug the power adapter into a 120-volt electrical outlet or into a surge suppressor (recommended) after the power cord is connected to the power adapter. Press the “Cancel” button at the front of device (Figure 2) until the system is booted up.



Figure 2

3. PORT CONFIGURATION

There are several ports at the back side of TP72-HUB (Figure 3).

- USB Host x 4
- USB Device x 1
- RS232 port x 1
- Cash drawer port (RJ11)
- Ethernet port (RJ45)



Figure 3

4. LOADING THE PAPER

Gently press the “Open” button on the cover’s left side (Figure 4). Load a roll of thermal paper (Appleton 1012 recommended) into the TP72-HUB. (Figure 5) Close the cover by pressing down. TP72-HUB integrated 3” Thermal printer with auto-cutter.



Figure 4



Figure 5

5. WIRELESS COMMUNICATION OPTIONS

There are two wireless communication options used in TP72-HUB. (Figure 6)

- Bluetooth (MFI)
- Wi-Fi (plug-in WiFi USB device)



Figure 6

Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Caution: Use only shielded signal cables to connect I/O devices to this equipment. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.