

Coolpad Lithium



Hello from Coolpad

Thank you for purchasing your Coolpad Lithium mobile phone! Please follow these simple but important instructions for optimal use of your new phone.

Application features and functions may vary among countries, regions or hardware specifications, and any third-party application malfunctions are the responsibility of those manufacturers.

Exercise caution when editing User Registration Settings as this may cause functional or compatibility problems for which Coolpad will not be responsible.

We offer self-service for our smart terminal device users. Please visit the Coolpad Americas official website (at www.coolpad.us) for more information on supported product models. Information on the website takes precedence.

Device Layout




Charging the Battery

1. Connect the USB Type-C side of the data cable to the USB Type-C port on your device. This is located on the bottom of your phone.
2. Connect the USB end to the travel adapter.
3. Connect the travel adapter to an electrical outlet to fully charge your phone.

Power Phone On & Off

- To power the phone on, slide the slider on the upper, right-hand side of your phone. Press and hold the **Power key** for a few seconds to turn on your phone.
- To turn off your phone, press and hold the **Power key** until the menu pops up, and then select **Power off**.

SIM Card




1. Insert the ejection pin into the hole to open the SIM card tray.
2. Gently pull out the SIM card tray. Place the Nano SIM card in card slot 1. If you have a microSD card (sold separately) place it in card slot 2.

Fingerprint Recognition

In addition to unlocking your phone, you can also use your fingerprint to authorize purchases and app access.

- To register your fingerprint, swipe up on the Home screen and tap **Settings** > **Security & location** > **Fingerprint**.
- Enter your unlock password to continue. If you haven't set the unlock password, you would be prompted to choose a backup screen lock method first.
- Place your finger on the fingerprint recognition sensor on the back of your phone and follow the on-screen instructions to register your fingerprint.
- Once your fingerprint is registered, you can use the fingerprint to unlock the screen or open apps.




Customizing your Home Screen

The Home screen displays widgets, favorite apps, and more. To view other panels, swipe to the left or right.

On the Home screen, tap and hold an empty area to access the available options including changing Home screen settings, changing wallpaper and adding widgets.

- To add an app, swipe up to enter the Apps screen, and tap and hold it, and then drag it to the Home screen. To add widgets, tap and hold an empty area on the Home screen, tap **Widgets**, tap and hold a widget, and then drag it to the Home screen.
- To move an app, tap and hold an item on the Home screen, and then drag it to a new location. To move the item to another panel, drag it to the side of the screen.
- To remove an item, tap and hold the item. Then, drag it to **Remove** at the top of the screen.
- To create a folder, tap and hold an app, and then drag it over another app; drop the app when a folder frame appears around the apps; a new folder containing the selected apps will be created. To add more apps to the folder, tap and hold another app, and then drag it to the folder.



Notifications and Quick Settings Panel

Notifications alert you to the arrival of new messages, calendar events, and alarms.


- Swipe down from the top of your phone screen to open the notification panel and view details.
- When you're finished with a notification, swipe it away. To dismiss all notifications, touch **CLEAR ALL** at the bottom right of the notifications list.

Use Quick Settings to easily get to frequently used settings, like turning on airplane mode.

To change a setting, just touch the icon:

- **Wi-Fi:** Turn Wi-Fi on or off. To open Wi-Fi settings, tap and hold the "Wi-Fi" icon.
- **Bluetooth:** Turn Bluetooth on or off. To open Bluetooth settings, tap and hold the "Bluetooth" icon.
- **Battery Saver:** Turn Battery Saver on or off. Tap and hold the "Battery Saver" icon to see battery life and usage.
- **Auto-rotate:** Lock your device's orientation in portrait or landscape mode.
- **Do not disturb:** Turn "Do not disturb" mode on or off. Tap and hold the "Do not disturb" icon to access feature settings.
- **Flashlight:** Turn the flashlight on or off.
- **Airplane mode:** Turn airplane mode on or off. Airplane mode means your phone won't connect to Wi-Fi or a cell signal, even if one is available.

- **Location:** Turn the location service on or off.
- **Mobile data:** See mobile data usage and turn it on or off.
- **Screenshot:** Capture screenshot of the current screen.
- **Hotspot:** Touch to turn your device's hotspot on or off.
- **Night Light:** Turn Night Light mode on or off.
- **Invert colors:** Turn invert colors on or off.
- **Data Saver:** Turn Data Saver on or off.
- **Cast:** Cast screen to other devices.
- **Nearby:** Scan for links from things nearby.
- **Display brightness:** Slide to lower or increase the brightness of your screen.



Phone

Making a call

On the Home screen, tap at the bottom or swipe up and then tap to enter the Phone screen.

1. Enter a phone number in the keypad to make a call. If the keypad does not appear on the screen, tap to open it.
2. Tap and then choose someone to call from your contacts list. To choose someone to call scroll, type a name or use the voice calling Google option.
3. To place a call, tap the contact's name.
4. To view recent calls, tap Call History tab.
5. During a call, you can tap at the bottom of the screen to hang up.

Receiving a Call

The incoming call screen pops up when a call comes in, along with the caller ID and other information you've entered in the Contacts.

- There are various options available when a call comes in.
- To answer a call, slide up.
 - To reject a call, slide down.
 - To reject the call and send an SMS message to the caller, slide up from the bottom left of the screen and tap one of the preset text messages to send it to the caller.

Camera

You can use the Camera app to take pictures and record videos.

Taking a Photo

1. On the Home screen, tap or swipe up and then tap to enter Camera screen.
2. Focus on your subject by looking through your phone screen.
3. Tap to start recording a video.
4. Tap to stop when you finish recording.

Creating a Video

1. On the Home screen, tap or swipe up and then tap to enter Camera screen.
2. Swipe to the right to activate the Video mode.
3. Tap to start recording a video.
4. Tap to stop when you finish recording.

Photos

On the Home screen, swipe up and then tap to enter the Photos screen. You can view and manage photos and videos stored in your phone.

When you're signed into your device with your Google Account, the Photos app makes it easy to auto-backup all the photos and videos you take, organize them, and share with friends.

- To delete an image or a video, select an image or a video, tap to move it to trash and it will be removed after 60 days or tap on the top right of the Photos screen and tap **Delete from device**.
- To delete multiple images and videos, tap and hold any image or video to delete, and then tap other images or videos you would like to remove. A check mark icon will appear. Then tap to move them to trash or tap on the top right of the Photos screen and tap **Delete**.
- To edit an image, select an image, tap Edit , select the options and tap **SAVE**.

Wireless Settings

Connecting to a Wi-Fi Network

1. On the Home screen, swipe up and then tap to enter the Settings screen. Then, choose **Network & internet** > **Wi-Fi** to turn Wi-Fi on/off.
2. Drag the slider to On enabling your phone to scan for available Wi-Fi networks.
3. Tap the name of a desired network to connect, entering the password if necessary. Note: Previously connected and saved networks will be automatically joined. A user can join a network and forget it, removing it from the known networks list.

Wi-Fi Calling

Wi-Fi Calling allows you to make and receive phone calls and messages over a Wi-Fi connection.

Important! You must have an E911 address registered with your account in order to use Wi-Fi Calling. You can register an E911 address via the myMetro™ Android™ app that is either preinstalled on your phone, or available for download from the Google Play™ Store. If you do not have an Android smartphone, you can call 611 to update the address.

Metro® by T-Mobile Service Information

Service

You will need the following information when activating service:

- Your name, address and an eight-digit number that you will use to access your account (your personal identification number "PIN").
- Your serial number (IMEI) and SIM card number. If your phone has a removable battery, to locate the serial number, remove the phone from the box and remove the battery cover from the phone. The serial number is located near the bar code. It will be either 14 or 18 digits. If your phone does not have a removable battery, check the box label or phone settings to locate the serial number. The SIM card number can be located below the bottom bar code on the back of the SIM card holder.
- Your choice of Metro by T-Mobile plan and services including unlimited data, talk and text plans

- Install the battery, if applicable, and SIM card in your new phone by following the step-by-step instructions in this phone's User Guide.
- Once your phone is powered up, dial 1.888.8metro8 (1.888.863.8768) to connect with an activation representative who will assist you in activating your phone. You can also activate your phone online by visiting metropcs.com. (As soon as your service is activated, be sure to fully charge the phone's battery before using it again.)

For Assistance:

- Please visit your local Metro by T-Mobile store or refer to the following options if you need additional assistance.
- Sign up for MyAccount to view account details, check your balance, make a payment, manage eWallet and more.
- Metro by T-Mobile automated customer service from any phone 1.888.8metro8 and follow the prompts (1.888.863.8768).
- Online information at metropcs.com.

Don't hesitate to ask your Metro by T-Mobile representative for more information on additional features and services or visit metropcs.com.

Account Detail:

- **Text Message Reminder.** Metro by T-Mobile provides a text message reminder on your phone before payment is due.
- **E-statement.** View your statement summary online. (Only available in select states.)
- **Call Detail.** View your call detail online for a listing of all local calls made during the service cycle. (Additional charge applies.)

Payment Options:

There are several ways to pay for your Metro by T-Mobile service.

- **Auto Pay.** Your credit or debit card is automatically debited two days before payment is due.
- **Express Pay.** Pay by credit or debit card online at metropcs.com.
- **By Mail.** Include your account number and phone number on your check or money order and mail to: Metro by T-Mobile, P.O. Box 5119, Carol Stream, IL 60197-5119.
- **By Phone via Automated System.** Pay by credit or debit card from your Metro by T-Mobile phone by dialing 1.888.8metro8. (Convenience fee applies.)
- **Store Payment Machine.** * Accepts cash, debit or credit card (with PIN). (Convenience fee applies.)
- **Over the Counter.** * Pay at an Authorized Payment Location with cash, check, credit or debit card.

* Sign up for MyAccount through metropcs.com and create your own secure eWallet where you can safely store cards for quick payment and set up auto pay.

• **Text to Pay.** The secure and easy way to pay your monthly Metro by T-Mobile service. Register your credit or debit card with the Metro by T-Mobile eWallet service and simply respond to a text from PAYNOW (729699) to pay.

* Not available at all locations.

MyMetro®

Manage your Metro by T-Mobile account right on your phone. By dialing any of the customer service numbers you can change your rate plan, change your features and pay for service. Just follow the instructions on your phone.

For Assistance:

- Please visit your local Metro by T-Mobile store or refer to the following options if you need additional assistance.
- Sign up for MyAccount to view account details, check your balance, make a payment, manage eWallet and more.
- Metro by T-Mobile automated customer service from any phone 1.888.8metro8 and follow the prompts (1.888.863.8768).
- Online information at metropcs.com.

Please follow us at:

- @metrobytmobile
- [facebook.com/Metrobytmobile](https://www.facebook.com/Metrobytmobile)

Your device may not work if you alter its original software. This device will only operate with firmware versions that have been approved for use by Metro by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function.

Hearing aid compatibility: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Your phone's GPS system is enabled by default in order to permit use of planned future services, at no additional cost, with the ability to restrict the placement of charges for premium and third-party services on your account. Contact customer care or go to www.metropcs.com/blocking for more information.

Metro by T-Mobile Terms and Conditions of Service

For the most recent and up-to-date version of the Metro by T-Mobile Terms and Conditions of Service to which you agree and will be bound when you activate, use, change or pay for your Metro by T-Mobile service, please visit metropcs.com/terms. (Convenience fee applies.)

Welcome to Metro by T-Mobile. We are pleased that you have selected us as your wireless carrier. Our Terms and Conditions of Service are available at <https://www.metropcs.com/terms-conditions/terms-conditions-service.html>. These Terms and Conditions of Service apply to all devices and wireless services provided by us to you and consist of several parts, which may be amended from time to time.

In the event that the terms and conditions relating to a feature you may have selected or may be included in your Rate Plan conflict with the Metro by T-Mobile Terms and Conditions of Service, the Metro by T-Mobile Terms and Conditions of Service shall control.

By: (a) giving us a written or electronic signature or telling us orally that you accept the Metro by T-Mobile Terms and Conditions of Service; (b) activating Service (if you are a new subscriber); (c) using your Service after your Service is activated or after you make a change or addition to your Service; (d) paying for the Service; or (e) failing to activate Service within 30 days after the purchase of your wireless device, unless you return your wireless device within Metro by T-Mobile applicable return period, you agree to the Metro by T-Mobile Terms and Conditions of Service and the terms and conditions of service and use related to any feature you may have selected or may be included in your Rate Plan, including, but not limited to:

- You waive your right to a jury trial in disputes with Metro by T-Mobile;
- Your disputes with Metro by T-Mobile will be decided by an arbitrator;
- You waive your right to institute or participate in class action litigation against Metro by T-Mobile;
- You will provide Metro by T-Mobile with accurate information about yourself;
- Metro by T-Mobile may communicate with you from time to time about your Service;
- You will pay all taxes and regulatory fees even if your rate plan is inclusive of taxes and regulatory fees; and
- Metro by T-Mobile may terminate your Service if you fail to timely pay for your Service or violate the Terms and Conditions of Service in any way, including abuse of the Service or violations of applicable laws.

Customer Service. If you have any questions regarding your Service or information in this Agreement, you may call our activation center at 1-888-8metro8 (1.888.863.8768).

Billing for Premium and Third-Party Services

California Residents Only
Certain parties besides Metro by T-Mobile have the ability to place charges on your bill for premium services. You may access these services and authorize the placement of charges on your bill through your phone or online account. Metro by T-Mobile also provides customers, at no additional cost, with the ability to restrict the placement of charges for premium and third-party services on your account. Contact customer care or go to www.metropcs.com/blocking for more information.

Google Apps


Google provides entertainment, social media, and business apps. Google Play Store is all-in-one entertainment point with music, movies, books and apps on the web.

For more details, visit www.support.google.com/android.

Get Updates

Get updates, user guides and more information for your Coolpad Lithium at www.coolpad.us. Discover what's going on right now in cell phone news, trends, techniques & other cool stuff by connecting with us by:

@CoolpadAmericas



Trademarks and Copyrights

Coolpad and the Coolpad logo are registered trademarks of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. Google and Android are trademarks of Google Inc. Other trademarks and trade names are the property of their respective owners. Copyright © 2019 Coolpad Technologies Inc. All Rights Reserved. Reproduction, transfer, distribution of the contents herein in any manner without the prior written permission of Coolpad Technologies, Inc. is prohibited. Coolpad Technologies, Inc. reserves the right to add, modify or delete, any of the contents herein or withdraw this documents at any time without prior notice and without assigning any reasons thereof.

Metro, MetroPCS and other words, slogans, designs and devices are registered or unregistered trademarks of T-Mobile USA, Inc. Copyright © 2019 T-Mobile USA, Inc. All other trademarks and other intellectual property are the properties of their respective owners.

Quick Start Guide