

User Manual

Please read the manual before use.

WELCOME:

Thank you for choosing the pad. After reading this guide, you will be able to fully master the use of your pad and appreciate all its functions and case of use.

DECLARATION:

This manual as device use instruction does not represent the explanation of the device's software and hardware, the features possibly is different refer to the different area.

The pad is compatible with CDMA1X/CDMA2000/EVDO technology. Some functions referred in this guide also need the support from network operators or service providers.

In order to ensure your safety, please read the "Safety

Notice”.

MANUAL ICON:



Indicates warning information.

WARNING



Indicates caution information.

CAUTION



Indicates device tips.

[]

Indicates function key.

BOLD

Indicates a menu or an icon.

Content

1.	GETTING TO KNOW YOUR PAD	9
	KEYS.....	10
	GETTING TO USE YOUR PAD.....	4
	INSERT SIM/UIM CARD.....	4
	INSERT UIM/SIM CARD:	6
	INSERT A MEMORY CARD	7
	BATTERY CHARGING.....	9
	TURN YOUR PAD ON AND OFF	12
	PASSWORD.....	12
	PIN CODE.....	12
	PIN2 CODE	12
	PUK AND PUK2 CODE.....	13
2.	QUICK START GUIDE	14
	LOCK AND UNLOCK THE SCREEN	14
	LOCK AND UNLOCK THE DEVICE.....	14
	MAIN SCREEN	15
	STATUS ICON.....	16
	APPLICATION MENU.....	18
	DATE AND TIME.....	19
	MAKE CALLS	19
	MAKE CALLS FROM DIALER	19
	MAKE A CALL FROM CONTACTS.....	20
	MAKE A CALL FROM CALL LOG.....	21
	MAKE A CALL FROM FAVORITES	21
	CREATE A NEW CONTACT IN FAVORITES	21
	RECEIVING CALLS, AND CHECKING MISSED CALLS	22
	RECEIVE CALLS.....	22
	CHECK MISSED CALLS.....	22
	MESSAGING.....	23

3.	TEXT ENTRY AND PAD SETTINGS	24
	TEXT ENTRY	24
	PAD SETTINGS	26
	SOUND SETTINGS.....	26
	SCREEN SETTINGS	27
	PRIVACY SETTING.....	29
	MAIN SCREEN SETTINGS	30
4.	INTERNET	32
	BROWSER	32
	BLUETOOTH	34
	TURN ON/ OFF BLUETOOTH	34
	BLUETOOTH SETTINGS.....	34
	CONNECT THIS PAD TO A NEW DEVICE.....	35
	WI-FI.....	36
	CONNECT TO WI-FI.....	36
	WI-FI SEARCH AND CONNECTION	37
5.	CONTACTS	39
	CHECK CONTACTS	39
	ADD CONTACTS	40
	EDIT CONTACT	41
	DELETE CONTACT	41
	IMPORT AND EXPORT CONTACT	42
6.	MESSAGING AND EMAIL	43
	MESSAGING	43
	CREATE NEW MESSAGE.....	43
	MESSAGE REPLY	44
	CREATE NEW MMS.....	44
	MANAGE MESSAGES.....	45
	EMAIL	46
	SET UP EMAIL	47
	SEND EMAILS.....	47

	RECEIVE EMAILS	48
7.	MULTIMEDIA	50
	MUSIC PLAYER	50
	PLAY MUSIC	51
	VIDEO PLAYER	52
	SOUND RECORDER	53
8.	OTHER APPLICATIONS	54
	ALARM CLOCK	54
	ADD ALARM CLOCK	54
	CALENDAR	55
	NEW EVENT	55
	MANAGE EVENTS	56
	CALCULATOR	56
	NAVIGATION	57
9.	MAINTENANCE	58
	BATTERY MAINTENANCE	58
	DEVICE MAINTENANCE	59
	TROUBLESHOOTING	61
10.	FCC WARNING AND STATEMENT	63

Safety Notice:

Before using the PAD, please read and follow the rules below carefully.



If you dial or answer a call while driving, please use the hands-free device (e.g. earphone, vehicle hands-free system, PAD hands-free system) or use your PAD after parking the vehicle.



Please switch off your PAD where you see signs forbidding PAD use. Such signs can be found in medical centers or establishments containing medical equipment.



The PAD may interfere with the communication network of airplanes, so please make sure your PAD is switched off during the flight.



To avoid the risk of any explosion, please switch off the PAD at petrol stations and places which are near fuel, chemical solvent or other dangerous substances.



Please switch off your PAD in areas where there could be a risk of explosion and in areas where you are asked to switch off bidirectional radios. Pay attention and adhere to any rules and regulations concerning pad use.



All PADs can be subject to interference, which could affect its performance.



In order to ensure high performance and to avoid damage the PAD, please use the original accessories and battery. Avoid using devices which are not compatible.



Keep this device away from excessive moisture and extreme temperatures.



Please neither burn the PAD battery nor use it as ordinary rubbish, as this could endanger life and damage to the environment. Please obey the environmental policy of the local government and dispose of and recycle them in time.



If you need to connect your PAD to other devices, please read the user guide carefully to ensure the procedure is carried out safely.



Keep small parts (e.g. SIM card) out of the reach of children to prevent batteries from being swallowed or causing other dangers.



Please back up the important information of PAD and be sure to have a second copy in case data is lost from your PAD.




Make sure the PAD is switched on and has service coverage before inputting the emergency number. Press the call key for your position to be located. Please don't end call unless told to do so.


1. Getting To Know Your PAD



Front








Below side



Back side

Keys

key	function
	Power Key: Turn on/off the pad by pressing for 3 seconds; A short press to turn off the screen backlight.

	<p>Volume: Adjust the pad's volume.</p>
	<p>Home Key: Tap in any interface to quit and back to the standby interface; Press for a while in any interface to obtain lately used 6 menu options.</p>
	<p>Menu Key: Tap for more options</p>
	<p>Back: Tap to go back to the previous menu</p>

Getting To Use Your Pad

Insert SIM/UIM Card



CAUTION

Always switch off your device before installing or removing SIM card.

In order to protect UIM/SIM card when plugging or unplugging in use, the system will shut down automatically!

UIM/SIM card is provided by the service provider, which can store some basic data, such as contact names and telePADs, ect. Some UIM/SIM card may not match with this pad, please resort to the service provider for replacement.

This device includes original lithium

battery. DO NOT attempt to open or repair this battery. Battery performance depends on many factors, including network configuration, signal strength, the temperature of the environment to operate the device, the features and/or settings select and used, and other application services.



WARNING

To reduce risk of fire or burns:

- Do not attempt to open or repair the battery pack.
- Do not disassemble, crush, puncture, short circuit the external contacts of the battery, or dispose it in fire or water.
- Do not expose the battery in environments of temperatures above 60°C (140°F).
- Replace only with the battery pack designated for this device.
- Recycle or dispose of used battery as stipulated by local regulations.

Insert UIM/SIM card:

- (1) Insert the UIM/SIM card into the slot (please pay attention to card direction to insert).



Insert a Memory Card

Insert a memory card to expand the memory space (This device employs Micro SD card).

(1)Insert a memory card: insert into the slot with the side of the golden contacts facing down, push in the direction as indicated in the picture to make a click.



(2)Take out a memory card: slightly push down the Micro SD card, and take out the popup card.



CAUTION Recommend to use originally equipped Micro SD card, or Micro SD card of San Disk or Kingston and other leading brands. Please confirm

the compatibility of Micro SD card with this device.


Please keep the children from MicroSD to avoid any unexpected swallow.


Battery Charging

Charging the battery by the travel charger:

(1) Connect the USB cable to the travel charger.

Insert the USB cable to the USB port on the PAD carefully, and connect the charger to a standard wall outlet.



- (2) During normal charging, battery status icon  will show up. The fully charged icon will show up when charging ends.

(3) After fully charged, please disconnect charger from power supply, and then disconnect the PAD.



CAUTION New batteries are shipped partially charged. Before start using your device, it is recommended to charge the battery as new batteries perform best after several full charge/discharge cycles.

Please charge timely as over discharge will damage the battery.

It is normal that PAD generates slight heat in charging.



CAUTION This device only supports exclusive charger, and other PC or laptop could not fully charge the device.

After shut down with low battery, this device takes 5-10 minutes in charging to switch on. This is a normal phenomenon.

Turn Your PAD On and Off

Please first check there is battery with enough power in your PAD, and press [Power Key] for 3 seconds to turn your PAD on and off.

Password

PIN Code

PIN code (Personal Identification Number) avoids your SIM card being used illegally. PIN code is provided with SIM card. If wrong PIN code is input for continuous three times, you should unlock it by PUK code. For more information, please consult the network operator.

PIN2 Code

You need to enter PIN2 code to start some functions. If wrong PIN2 code is input for three times, you should unlock it by PUK2 code. For more information, please consult the network operator.

PUK and PUK2 Code

PUK and PUK2 code may be provided with SIM card. If wrong PIN/PIN2 code is input for three times, the device requires PUK/PUK2 code. Please consult the network operator if such codes are not available.



CAUTION If wrong PIN code is input for three times continuously, SIM card will be locked. Please resort to the network operator for help to decode. Decoding by you may result in a permanent invalid SIM card.

2. Quick Start Guide

Learn how to perform basic operations and use the main features of your pad.

Lock and Unlock the Screen

1. Lock the screen

Press the [Power Key] to lock the device, save the battery and avoid misoperation.

2. Unlock the screen

Press the power key to light up the screen.

Lock and Unlock the Device

In order to avoid any misoperation, you may lock the device.

1. Lock the device

Press the [Power Key] to lock the device.

Attention: if no operation is done during the screen timeout time as defaulted or as set in the pad, the device will be locked automatically.

2. Unlock the device

Press the [Power Key] and slide the unlock key to the right side to unlock the device

Main Screen







You may activate functions of this device by operations on the touch screen. There are five main screens, which could be switched by sliding to the left or the right. Tap [Home Key] in any

interface to go back to the main screen. Tap an application icon on the main screen to start that application. Tap Apps Panel to find all applications.



You may add or cancel icons on the main screen as expected. Please find more details in the device basic settings.

Status Icon

Icon	Description
	Network signal
	3G data connection
	Airplane mode
	Battery capacity



Wi-Fi signal



No SIM card



No Micro SD card



Notification



BT is on.



GPS is on.



Missed call



New message



New Email



Silent mode



PAD vibration



Alarm clock



USB connected

If there is any missed call or new message, the status bar on top of the screen will indicate the notifications. Slide down from the status bar to find the notifications and tap to check.

Application Menu

Tap Apps Panel on the main screen, you can view and set all the applications.

Tap Main Screen Panel to go back to main screen.



Date and Time

You can set date, time, time zone and format.

In the applications interface, tap settings>Date & time.

Date & time settings include: Automatic, Set date, Select time zone, Set time, Use24-hour format and Select date format.




CAUTION Automatic item is available with UIM/SIM card inserted.

Make Calls


Make Calls from Dialer

1. Tap Apps Panel>Phone in the main screen to enter dialer interface



2. Input the PAD number you want to dial in the interface, tap  to make a call.




Tap  to delete wrong inputting.

Make a call from Contacts

1. Tap Apps Panel>Phone>Contacts, or tap Contacts.

2. Choose the contact you need to enter contact details menu.

3. Tap the number  to call.

Call home
884-646-52

Make a call from Call log

1. In Idle mode, press Apps Panel >Phone>Call log

2. Select a call log. Tap  to call back the number.

Make a call from Favorites

You can call numbers in frequent use from Favorites.

1. In Idle mode, press Apps Panel >Phone>Favorites


2. Select a number. Tap  to call back the number.

Create a new contact in Favorites

1. In Idle mode, tap Apps Panel>Phone>Contacts

2. Select a contact, tap  in contacts detail interface.




CAUTION If you want to delete contacts in Favorites, tap  again in contacts detail interface.

Receiving Calls, and Checking Missed Calls

Receive calls

When a call comes, slide the green answer key to the right to answer the call, or slide the red end key to reject the call.

Check missed calls


If there is a missed call, the status bar will indicate a missed call icon . Slide down from the status bar to check the missed calls.

You may also tap Apps Panel >Phone>Call log to check missed calls.

Messaging

You may send or receive SMS or MMS with multimedia file.

Tap Apps Panel > Messaging to enter the message interface.





3. Text Entry and PAD Settings

Text Entry

You may use Android keypad and other input method to edit, such as add contact information and edit message ect..

Switch the input methods:

1. Enter the editing interface.
2. Press on the edit area and the edit menu will pop up.
3. Tap the input method and select the expected input method.



PAD Settings

Sound settings

You can select the ringtone you like to set as incoming ringtone.

Ringtone Settings

1. In the applications menu, tap Settings>Sound>Phone ringtone.
2. Scroll the ringtone list up and down, tap the ringtone name to listen; select one and tap OK to save.

Ringer volume

1. In the applications menu, tap Settings>Sound >Volume.
2. Scroll the incoming volume indicator to adjust, select and tap OK to save.
3. In the main screen, press the volume on the side

to adjust the current volume. Press the volume down key to set as vibration mode and silent mode.



Press the [Power Key] for a while, and tap the silent mode in this option menu as a short cut to activate the silent mode.

Screen settings

Set wallpaper

1. In the main screen, tap [Menu Key] to open the options.
2. Tap Wallpaper and select from Gallery, Live wallpapers or Wallpapers.
3. Scroll the wallpaper thumbnails; select the wallpaper you like and tap Set wallpaper.

Live wallpaper

You may set the screen with live wallpaper.

1. In the main screen, tap [Menu Key] to open the

menu options.

2. Tap Wallpaper and select from Live wallpapers.
3. Select the wallpaper you like and tap Set wallpaper.

Brightness setting

1. In the applications menu, tap Settings>Display>Brightness.
2. Scroll to adjust the brightness, tap OK to save.

Screen timeout time setting

You can set the screen timeout time to adjust the time before the screen automatically locks.

1. In the applications menu, tap Settings>Display>Screen timeout.
2. Select and tap the screen timeout time to finish the settings.

Privacy setting

Back up my data

You can back up your settings and other applications data if you turn this function on.

1. In the applications menu, tap Settings>Privacy>Back up my data.
2. Tap Back up my data and tap OK to finish the settings.

Automatic restore

1. In the applications menu, tap Settings> Privacy> Automatic restore.
2. Tap Automatic restore to turn on/off this function.

Factory data reset

1. In the applications menu, tap Settings> Privacy >Factory data reset
2. Tap Reset phone.
3. Tap Erase everything and the pad will restart and

reset to the factory date.

Main screen settings

There are 5 main screens on the pad, and you can switch by sliding to the left or right. Tap the [Home Key] in any interface to go back to the main screen.

You may add Shortcuts, Widgets, Folders and Wallpapers to the main screen as you like.

Add Shortcuts in the main screen


1. Tap [Menu Key] to show menu in the idle mode.
2. Tap Add >Shortcuts.
3. Select one and save in the main screen.

Add Widgets in the main screen

4. Tap [Menu Key] to show menu in the idle mode.
5. Tap Add >Widgets.

6. Select one and save in the main screen.

Delete icons in the main screen

1. In the main screen, press on the icon to be deleted until  shows, and drag the icon to



4. Internet

Browser


Open the web browser to start to visit the web and use the applications based on web. If necessary, please consult your service provider on how to connect.



CAUTION

The web connection type depends on services from your service provider. Costs vary from different connection types. Please consult your service provider for more details on tariff.

In the applications menu, tap the Browser.

There is an address line  in the browser, tap and input the webpage address that wants to visit,

tap  to visit.

Tap [Menu Key] and options will be shown:



New window: add a new window.



Exit: exit the browser.



Bookmarks: save the favorite webpage.



Windows: tap the key to switch and manage the windows being opened; tap new window to create a new window. Tap this key again to close the windows switching interface.





Refresh: refresh the current webpage.



More: more options, including forward, back, add a bookmark, search the webpage, ect.

Bluetooth

Turn on/ off Bluetooth

1. In the applications menu, tap Settings> Wireless & networks.
2. Tap Bluetooth. The Bluetooth indicator  in highlight shows Bluetooth is on. Meanwhile, the status line will show the Bluetooth indicator  on top of the device.




CAUTION To save battery and ensure the Bluetooth security, please close the Bluetooth if the Bluetooth is not used. The device may not connect to another device after closing the Bluetooth, unless you turn on the Bluetooth again.

Bluetooth settings

In the applications menu, tap Settings> Wireless &

networks> Bluetooth settings.

Bluetooth settings include:



Connect this pad to a new device

1. Make sure the Bluetooth is on and visible within appropriate range (about 10 meters).
2. In the applications menu, tap Settings> Wireless & networks> Bluetooth settings.
3. Tap Bluetooth to turn it on.
4. Tap Scan for devices and the device being found will be shown.

5. Tap the device in need, tap matching or input the device code for matching with the device (the default code is 0000). Turn on the Bluetooth, and the Bluetooth indicator will be shown in the status line.





CAUTION The Bluetooth devices may have specific functions, connections in detail and usage, please refer to related instructions.

Wi-Fi

You may connect to Wi-Fi for wireless internet and download.

Connect to Wi-Fi

1. In the applications menu, tap Settings> Wireless & networks.


2. Tap Wi-Fi. The Wi-Fi indicator  in highlight shows the Wi-Fi is on. Meanwhile, the status line will show the Wi-Fi indicator  on top of the device.



CAUTION To extend the battery life, please turn off Wi-Fi if it is not used.

Wi-Fi search and connection


1. In the applications menu, tap Settings> Wireless & networks> Wi-Fi settings.
2. Tap Wi-Fi to turn on and search. The device will list the networks in the range being searched.
3. Tap Wi-Fi settings to see the searched networks.
4. Tap the network to be connected, and tap Connect.

5. If necessary, input the wireless password and other information, then tap Connect. The wireless indicator  will show in the status line after the device reaches the network. The Wi-Fi and the Bluetooth can't synchronization using.

5. Contacts

You can save the name, PAD number, email address etc. in Contacts.

Check contacts



In the applications menu, tap Contacts to enter the


contact menu.

Scroll up or down the contact list to check more contacts.

Tap [Menu Key] to enter menu options, such as Search, New contact, Accounts, and Import/Export.

Add contacts

1. In the application menu, tap Contacts to enter the contact menu.
2. Tap [Menu Key] to enter menu options, tap New contact.
3. Tap relevant items to input contact information.
4. Tap Done to save the contact information.



Edit contact

1. In the applications menu, tap Contacts and enter contact list.
2. Tap the contact to be edited for a while to enter options>Edit contact
3. Tap Done to save the contact after inputting information.

Delete contact

1. In the applications menu, tap Contacts to enter contact list.
2. Tap the contact to be edited for a while to enter

options > Delete contact

Import and export contact



1. In the applications menu, tap Contacts to enter contact list.
2. Tap [Menu Key] to enter menu options>Import/Export. You can choose Import form SD card or Export to SD card.
3. Choose the type of import and then choose the contact, tap Done.

6. Messaging and Email

Messaging

You can send and receive SMS and MMS with multimedia file.

Create new message

1. In the applications menu, tap Messaging>New message.
2. Tap recipient and edit the recipient information, or add the recipient from .
3. Tap and edit the text.
4. Tap  key to send the message.




There is no inbox and sent box in this device. The messages will be shown in the form of dialogue threads for easy reading.

Message reply

The notification line on top of the device will show the reminder when you get a new message.

1. In the applications menu, tap Messaging>New message.
2. Tap the message and edit the text to reply.



3. Tap  key to send the message.

Create new MMS:

1. In the applications menu, tap Messaging>New message.

2. Tap recipient and edit the recipient

information, or add the recipient from  .

3. Tap [Menu Key] to open menu options>Add subject, tap Subject to input the MMS theme that will be sent.

4. Tap and edit the text, then tap key to send the message.



You can tap [Menu Key] to add Attach or Insert smiley and so on.

Manage messages

Delete messages

Tap a dialogue thread, tap one message, select delete messages and tap delete. Then the message will be deleted.

Delete threads

Tap a dialogue thread, tap [Menu Key] to select Delete thread and tap Delete. Then the message will be deleted.

Forward messages

Tap a dialogue thread, press on a message, and select Forward to forward the message.

Email

You may receive and send emails via Email.



CAUTION You need to set up your own email, and then receive and send the emails.

Receiving and sending emails requires Internet connection. Please consult your service provider for details about setup parameters.

Set up Email

1. In the applications menu, tap Email.
2. Input email address and password, tap Next, give this account a name, your name (displayed on outgoing messages) and signature, tap Done.

You may also use Manual setup for the email account:

1. Input email address and password.
2. Tap Manual setup to select the type of account.
3. Finish details like server.
4. Tap Next to complete the setup.

Send emails

You may send emails to one or more recipients.

Before sending, add the recipient email address,

or select from Contacts.

1. In the applications menu, tap Email.
2. Tap [Menu Key] > Compose for the editing interface.
3. Tap recipient and input the recipient's email address. If necessary, tap [Menu Key] for Add Cc/Bcc address, input other recipient's email address for cc or bcc.
4. Tap Subject and input the subject.
5. Tap Compose Mail and input the text.
6. Tap [Menu Key] > Add attachment to insert the file as needed.
7. Tap Send to send the email.

Receive emails

1. In the applications menu, tap Email.
2. Tap [Menu Key] > Refresh.

3. The device will connect to the server and download emails. All emails received will be saved in the Inbox.
4. Tap the email to read.
5. During reading, tap [Menu Key] and tap Forward to forward the email to others; or tap Reply to edit and send the email to the sender.

7. Multimedia


Music Player

You can play your favorite music in music player.



CAUTION Please install the memory card with music saved before playing music.

In the applications menu, tap Music.



The music files are classified and saved according to the artists, albums and playlists. Select a category and tap the music or playlist in need.

Play music

You just need to tap the music that you want to play to access music player.



In the music player, press the side key to

adjust the volume.

Video player

You can play favorite videos in video player.



CAUTION Before playing, please install a SD card with videos saved.

1. In the applications menu, tap Videos.
2. Tap the video in need to access the video player.




During playing the video, tap the side key to adjust the volume. Also you may pause or drag the progress bar for video in need.

S

Sound recorder

In the applications menu, tap Sound Recorder.




CAUTION Please install the memory card before using the sound recorder.

8. Other applications

Alarm clock

In the applications menu, tap Clock.

Add alarm clock

Tap [Menu Key] to select Add alarm, set alarm information and tap Done. When  shows in green means on.

When the alarm functions, the user can select Snooze/Dismiss.

Tap the indicator on the right side of the alarm to be started. The indicator in highlight shows the alarm clock is on.

You may dismiss the alarm clock when it is ringing, or tap snooze to postpone the alarm clock.

Calendar

In the applications menu, tap Calendar. You can use calendar to arrange and manage the schedules.

The calendar may be viewed by day, week, month or list.



CAUTION You may need to set the correct date and time before using the calendar.

New event

Tap the date for a while to enter options: Show day, Show agenda and New event. Select New event to create a new event.

1. Edit event name, time, place, description and other detailed information, set time to start, time to end and emergency procedures etc.
2. Tap Done to save new event.

Manage events

You need to create an event before view or edit it.

Select an event, the device would show the recorded event.

Add reminder

Click an event to enter the details interface, press on [Menu Key] to select Add reminder.

Edit event

Click an event to enter the details interface, press on [Menu Key] to edit event.

Delete event

Click an event to enter the details interface, press on [Menu Key] to select Delete event.

Calculator

In the applications menu, tap Calculator.

The calculator has limited precision and can be

used in simple calculations only.

Navigation

In the applications menu, tap Navigation.

Press [Menu Key] to select the operations.



CAUTION This function is only used outdoors. The service condition in specific depends on UIM/SIM card and the data service you applied for. Relevant information flow may charge you. Please consult your service provider for detail costs.

9. Maintenance

Battery Maintenance

1. This device could use rechargeable battery as power supply. Please recharge the battery with inadequate power. To maintain battery life, it is better to consume all the power before recharge.
2. When charger is not used, please separate it from the power supply. Do not connect charger with battery more than a continuous week, as overcharge will shorten battery life.
3. Temperatures influence the battery limit to be charged. So before charge, battery may need to be cooled or warmed. If battery temperature is over 40°C, battery may not be charged immediately.
4. Please use the battery on the original

purposes to avoid short circuit. Short circuit may happen when conducting substances connect the anode and cathode of battery.

5. Do not use damaged battery.

6. Keeping battery in extreme cold or extreme hot places leads to shorten battery life. Battery being exposed in cold or hot places may lead to abnormal function, even battery is fully charged.

7. Do not put the battery in the fire! Please dispose of dead batteries according to local regulations.

Device Maintenance

1. Please keep children out of reach of the pad and the accessories.

2. Avoid the pad from direct contact with water or other liquids. If liquids enter the pad, this could cause a short circuit, battery leak or

other malfunction.

3. Please keep the pad away from the high temperature, as it will shorten the life of the pad, melt the plastic and damage the battery.

4. Do not disassemble or modify the pad, as it will cause damage to the pad such as battery leakage or circuitry failure.

5. Do not use acid or alkali to clean the PAD.

6. Do use the original accessories otherwise the warranty will be failed.

Troubleshooting

Problems	Cause; Solution
Unable to turn on	The battery is used up; Charge the pad.
SIM card malfunction	SIM card is damaged; Contact your network service provider for help. SIM card is not properly inserted; Confirm SIM card is properly inserted. There is a foreign substance on the metal surface of the SIM card; Use a clean cloth to wipe off the metal contact point of the SIM card
Poor reception	Using the pad in an area with poor reception such as near tall buildings or in a basement where radio waves cannot be reached; Try in an open field.
	Using the pad when the network is busy, such as during rush hour, making it impossible to get through; Try with available network.
	Far away from the base station built by the network; You may request the network service provider for a service area plan.
Echo or noise	Caused by poor network trunks, it is a regional problem with poor connection; Hang up and redial, or renew the trunks.
Unable to call	The call barring being activated; Deactivate the barring. The fixed dialing being activated; Deactivate the fixed call.
Unable to charge	Battery or charger is damaged; Replace the battery or charger. Recharging in the environment of less than -10C or higher

	<p>than 55C;</p> <p>Try to charge in an appropriate environment.</p> <p>Poor contact;</p> <p>Check if the plug is properly connected</p>
Unable to connect to the network	<p>Expired SIM card;</p> <p>Contact your network service provider.</p> <p>Out of the GSM service area;</p> <p>Consult your network provider on the service area.</p> <p>Poor signal;</p> <p>Please move to a place with a better signal and try again</p>
Standby time being shortened	<p>Standby time is related to the settings of network system;</p> <p>Please temporarily turn off your pad, as you are located in an area with poor reception.</p>
	<p>Batteries need to be replaced.</p>
	<p>When no signal is available, the pad will continue to transmit the signal to find a base station, so large amounts of power will consume the standby time; Pleas move to an area with a strong signal or temporarily turn off the pad.</p>
Incorrect PIN number	<p>Consecutively enter the wrong password for three times;</p> <p>Contact your network provider.</p>
Unable to add new contact	<p>The storage space of the contacts is full;</p> <p>Delete a portion of the contact entries.</p>
Unable to set some functions	<p>Your network provider does not support this function or you did not apply for it;</p> <p>Consult your network provider for help.</p>

Environmental Instructions

Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr6+	PBB	PBDE
PAD	X	O	O	O	O	O
Battery	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

O: indicates the content of this hazardous substance in the all materials of the device is lower than the required volume in the standard of SJ/T 11363-2006.

X: indicates the content of this hazardous substance in the all materials of the device is higher than the required volume in the standard of SJ/T 11363-2006.

Note: this device is marked with " X" because currently there is no alternative technology or parts for replacement.



10. FCC Warning statement and Safety Info

Changes or modifications made to this equipment not expressly approved by Yulong Computer Telecommunication Scientific(Shenzhen) Co., Ltd. for compliance could void the user's authority to operate the equipment.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Safety Information

1 . SAFETY INFORMATION FOR FIXED WIRELESS TERMINALS

.POTENTIALLY EXPLOSIVE ATMOSPHERES

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

INTERFERENCE TO MEDICAL DEVICES

Certain electronic equipment may be shielded against RF signal from your wireless phone. (pacemakers, Hearing Aids, and so on) Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. RF signals may affect improperly installed or inadequately shielded electronic system in motor vehicles.

.EXPOSURE TO RF ENERGY

Use only the supplied or an approved replacement antenna. Do not touch the antenna unnecessarily when the phone is in use. Do not move the antenna close to, or touching any exposed part of the body when making a call.

SAFETY INFORMATION FOR RF EXPOSURE

Body worn operation

This device was tested for typical body-worn operations with the back of the phone kept 20 mm. from the body. To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 20 mm. separation distance between the user's body and the back of the phone, including the antenna. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

SAR INFORMATION

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. *

Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is

because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for user to CDMA antenna SAR value is 1.390 W/Kg and user to WIFI antenna SAR value is 0.288 W/Kg when worn on the body, as described in this user guide. (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: R38-YLM31. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.